

Service Manual

JS110
JS130
JS150LC

PUBLISHED BY THE
TECHNICAL PUBLICATIONS DEPARTMENT
OF JCB SERVICE; ©
ROCESTER, STAFFORDSHIRE, ST14 5LS,
ENGLAND

Tel. ROCESTER (0889) 590312
PRINTED IN ENGLAND

Publication No. 9803/6100

General Information	1
Care & Safety	2
Routine Maintenance	3
Optional Equipment	A
Body & Framework	B
Electrics	C
Hydraulics	E
Transmission	F
Brakes	G
Track & Running Gear	J
Engine	K

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below




- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Service Tools (continued)

SECTION E - HYDRAULICS

Servo Hand Control Valve - JS 110, 130 and 150LC



Joint Removal Tool

Items 1 and 2 are assembled with an interference fit.

In this publication and on the machine, there are safety notices. Each notice starts with a signal word. The signal word meanings are given below.

DANGER

Denotes an extreme hazard exists. If proper precautions are not taken, it is highly probable that the operator (or others) could be killed or seriously injured.

INT-1-2-1

WARNING

Denotes a hazard exists. If proper precautions are not taken, the operator (or others) could be killed or seriously injured.

INT-1-2-2

CAUTION

Denotes a reminder of safety practices. Failure to follow these safety practices could result in injury to the operator (or others) and possible damage to the machine.

INT-1-2-3

General Notes

For the type of grease to use at each point, see *Lubricants and Capacities*.

Do not mix different types of grease. Keep them separate.

⚠ WARNING

You will be working close into the machine for these jobs. Lower the attachments if possible. Remove the starter key and disconnect the battery. This will prevent the engine being started.

8-3-1-3

Swing Ring Teeth and Swing Pinion

Ensure swing ring is kept full of grease. Always grease whenever the machine has been steam-cleaned.

For location of the swing ring gear refer to *Component Location Diagrams* at the end of this section.

1 Make the Machine Safe

Stop the engine and remove the starter key.

2 Grease the Swing Ring

a Remove the cover **A**.


b Apply grease to the slew ring via aperture **B**.

3 Swing the Machine

Start the engine and swing the machine a few degrees. Stop the engine, remove the starter key and apply grease again.


Repeat until the whole ring is greased. Check that grease exudes around the entire circumference.

4 Refit the Cover



Swing Ring Bearing

The three grease nipples are situated around the turntable circumference. Two of the nipples are indicated **C**, with the third on the opposite side.



Checking/Adjusting the Track Tension

- 1 Position the machine on firm and level ground.

⚠ WARNING

NEVER position yourself or any part of your body under a raised machine which is not properly supported. If the machine moves unexpectedly you could become trapped and suffer serious injury or be killed.

INT-3-3-7

- 2
 - a Raise the track to be measured off the ground. Block the undercarriage.
 - b Rotate the track in forward direction only to ensure that the track is able to rotate freely.
 - c Stop the engine and remove the key.
- 3 Measure dimension **A**, between track plate and undercarriage.

Note: See the table on the following page for the correct values for dimension **A** and the position at which the measurement must be taken. (The position will vary between models).

- 4 If the chain is too tight, release a small amount of grease from the tension unit, by loosening the check valve **B** on the tensioner.

Note: A maximum of 3 turns of the check valve should be sufficient.

⚠ WARNING

When opening the check valve always stand to one side and loosen a little at a time until grease starts to come out. If you over-loosen too much grease could spurt out or the valve cover fly out and cause serious injury.

8-3-4-5


⚠ WARNING

Under no circumstances must the check valve be dismantled or any attempt made to remove the grease nipple from the check valve.

8-3-4-9

- 5 If the chain is too slack, pump grease into the tensioner.
- 6 Remove the blocks from beneath the undercarriage and lower the track to the ground using the boom and dipper controls.
- 7 Repeat the procedures for the other track.

Note: The machine shown is typical. The track rollers must be counted from the front, i.e. the idler end. The example shows the measurement taken at track roller number 3.



Draining Fuel Tank Impurities

Stop the engine and remove the key.


Loosen the drain tap **A** on the underside of the fuel tank. Drain the water and deposits until clean diesel oil flows out.

Close the drain tap firmly.

WARNING

Fuel oil is highly inflammable. Completely wipe off any spilt fuel which could cause a fire.

8-3-4-3




Draining the Water Separator

The water separator should be drained at least every 50 hours, but more often if necessary.

Stop the engine and remove the key.

Open the drain plug **C** to release the accumulated water in the bowl.

Under no circumstances should the float **D** be allowed to rise above the red line **E** or water could get taken further into the system with serious consequences.



Technical Data - Electrics JS 110, 130, 150LC



System	24 Volt, negative earth
Battery	2 x 12 Volt Heavy Duty, 120Ah
Alternator	24 Volt, 40 Amp
Starter Motor	24 Volt, 3.5 or 4.5 kW, 30 secs.

Light Bulbs


Working, Boom Mounted	70 Watt
Working, Tank Mounted	70 Watt
Cab	10 Watt x 2
Engine Compartment	10 Watt

Circuit Protection**Circuits**

	Rating (Amps)	Fuse No.
Controller	10	1
Electric Control	15	2
Horn/Working Light	15	3
Windscreen Wiper	15	4
Cab Light/Radio	10	5
Oil Pressure	10	6
Heater/Cooler (Optional)	15	7
Spare	15	8




Removal and Replacement



Removal

Before removing the Systems Control Monitor, remove the starter key from the starter switch.

1. Remove the ash tray 1.



Technical Data - JS 110

Pump			
Type	Variable displacement, two element piston pump in tandem. Integral gear servo pump.		
*Control Valve			
Manufactured in two halves and bolted together.			
Left Hand Valve	Servo actuation of bucket, boom and right track (from Serial No 697014 on).†		
Right Hand Valve	Servo actuation of dipper, swing and left track (from Serial No 697014 on).†		
† Mechanical track actuation on earlier Serial Nos.			
* Pressures			
(All pressure checks should be undertaken at maximum speed in the 'S' mode with the hydraulic fluid at 50° C ± 5° (3 to 4 LED's illuminated).			
	bar	kgf/cm²	lbf/in²
Servo	39 + 5/ - 0	40 + 5/ - 0	570 + 72.5/ - 0
Main Relief Valve (M.R.V.)	294 ± 5	300 ± 5	4270 ± 72.5
Control Valve Mounted Auxiliary Relief Valves (ARV's)			
Boom Raise (Head Side)	245 ± 5	250 ± 5	3555 ± 72.5
Boom Lower (Rod Side)	206 ± 5	210 ± 5	2985 ± 72.5
Bucket Open (Rod Side)	255 ± 5	260 ± 5	3700 ± 72.5
Bucket Close (Head Side)	255 ± 5	260 ± 5	3700 ± 72.5
Dipper In (Head Side)	255 ± 5	260 ± 5	3700 ± 72.5
Dipper Out (Rod Side)	255 ± 5	260 ± 5	3700 ± 72.5
Component Mounted Relief Valves			
Swing Cross Line Relief Valves	211 ± 5	215 ± 5	3057 ± 72.5
Track Cross Line Relief Valves	323 ± 5	330 ± 5	4700 ± 72.5
Rams			
	Bore	Rod Dia.	Stroke
Boom (2 off)	100mm (3.9in.)	65mm (2.6in.)	1043mm (41.1in.)
Dipper	110mm (4.3in.)	75mm (3.0in.)	1282mm (50.5in.)
Bucket	100mm (3.9in.)	65mm (2.6in.)	890mm (35.0in.)
* Motors			
Track	Variable displacement, axial piston motor		
Swing	Fixed displacement, axial piston motor		

Schematic Hydraulic Circuit JS 150LC (from Machine No. 701045)

Component Key

P1	Front Pump Element
P2	Rear Pump Element
P3	Servo Pump
M	Engine
1	Swing Park Brake Solenoid Valve
2	Shuttle Valve
3	Swing Motor
3A	Cross Line Relief Valves
4	Dipper Ram
5	Dipper Hose Burst Check Valve
6	Track Motor LH
6A	Counterbalance Spool
6B	Brake Release Piston
6C	Brake Release Valve
6D	Cross Line Relief Valve
6E	Speed Selection Spool
6F	Speed Actuator
7	Rotary Coupling
8	Track Motor RH
9	Bucket Ram
10	Boom Rams
11	Boom Hose Burst Check Valves
12	Control Valve
12A	Main Relief Valve
12B	Track Spools
12C	Boom Spool
12D	Bucket Spool
12E	Dipper Boost Spool
12F	Dipper Spool
12G	Swing Spool
12H	Boom Boost Spool
12J	Straight Ahead Track Valve
12K	Boom Rod Side ARV
12L	Boom Head Side ARV
12M	Bucket Rod Side ARV
12N	Bucket Head Side ARV
12O	Dipper Rod Side ARV
12P	Dipper Head Side ARV
12R	Swing Left ARV
12S	Swing Right ARV
12T	Negative Control Pressure Relief Valves
12U	Swing Priority Valve
13	Swing Brake Release Pressure Switch
14	Cooler
15	Cooler Check Valve (0.49 bar, 7.1 lb in ²)
16	Breather
17	Cooler Check Valve (3.4 bar, 49.8 lb in ²)
18	Return Filter (10 μ)
19	Filter By-pass Relief Valve (0.98 bar, 14.2 lb in ²)
20	Suction Strainer (150 μ)
21	Hydraulic Tank
22	Drain Line Filter (10 μ)
22A	Filter By-pass Relief Valve (0.6 bar/8.5 lb in ²)
23	Servo Hand Control Valve LH
24	Servo Hand Control Valve RH
25	Warm Up Filter (100 x 800 Mesh)
26	Warm Up Restrictor
27	Cushion Valve Solenoid
28	Cushion Valve
29	Servo/Drain Manifold




30	Accumulator
31	Servo Isolator Solenoid Valve
32	Check Valve (0.4 bar/5.7 lb in ²)
33	Servo Filter (10 μ)
33A	Filter By-pass Relief Valve (1.03 bar/14.9 lb in ²)
34	Auxiliary Control Valve
34A	Auxiliary Services ARV's
34B	Auxiliary Control Valve MRV
35	Hydraulic Pump
35A	Proportional Solenoid Valve
35B	Swing Pump Control
35C	Summator Assembly
35D	Pump Control Spool
35E	Pump Control Actuators
36	Servo Pump Relief Valve
37	Speed Change Solenoid
38	Servo Track Control RH
39	Servo Track Control LH
40	Servo/Drain Manifold

Note: To aid the clarity of the diagram, some servo lines have been omitted. To assist in tracing these lines, an identification letter has been included where the line terminates, e.g. f. The component to which the line connects has been added after the letter, e.g. f(12). Therefore, reference f(12) means that the line connects to line f on component 12, the control valve.

JS 150LC (cont'd)


SYMPTOM	POSSIBLE CAUSE	ACTION
5. Swing Motor (cont'd) d. (cont'd)	3. The relief valve plunger seat is defective.	Dismantle and inspect the relief valve, as detailed on page 36-5, paying particular attention to the valve seat. Renew the seat if damage is found.
e. Oil leak at the oil seal.	1. Damage or wear to oil seal lip. 2. The shaft is damaged or worn. 3. Abnormal pressure in the casing.	* Renew oil seal, as detailed on pages 36-1 to 36-4. * Renew shaft and oil seal, as detailed on pages 36-1 to 36-4. Check drain line for damage or blocking. Clear or renew drain pipe.
f. Oil leaks from mating face.	1. 'O' ring damaged or missing. 2. The seal face is damaged. 3. Bolts are loose.	* Dismantle and inspect, as detailed on pages 36-1 to 36-4, and renew 'O' rings. * Dismantle and inspect, as detailed on pages 36-1 to 36-4, and repair as necessary. Check bolts and torque tighten to specified torque.
6. Hand Control Valves a. Low pressure from hand control to main control valve spool.	1. Servo pressure is low. 2. Spring 241 is damaged. 3. The clearance between the spools and casing is too large. 4. The handle unit is loose.	* Check servo pressure as detailed on page 10-6 and adjust as necessary. Renew spring. Renew spool and casing assembly Renew the handle unit.
b. Unstable pressure from hand control to main control valve spool.	1. Sliding parts are sticking. 2. Air is trapped in the pipes.	* Dismantle and inspect as detailed on pages 40-1 to 40-10. Repair or renew as necessary. Operate the valve several times to remove the air.
c. High pressure from hand control to main control valve spool.	1. Sliding parts are sticking.	* Dismantle and inspect as detailed on pages 40-1 to 40-10. Repair or renew as necessary.

Front Regulator




Dismantling - JS 110, 130, 150LC (cont'd)

32. Remove snap ring **P49** and spacer **P26**. Using a press and jig, remove bearing **P15**, noting the positions of all components as an aid to assembly.



33. Remove servo pump case **P36** and servo pump cover **P35**. Remove coupling **P39** (JS 110, 130 only), drive gear **P37**, driven gear **P38** and washer **P44** (JS 110, 130 only).

Note: Gear shaft **P40** is lightly press fitted into pump casing **P36**, and key **P41** (JS 110, 130 only) is lightly press fitted into coupling **P39** (JS 110, 130 only). If there is no fault in this area do not dismantle them. In addition, if there is no reason to remove bushes **P42** and **P43** leave them in place.



34. Remove screw **P73** and remove swash plate gear **P72** from swash plate **P10**.

Note: The swash plate gear **P72** is adjusted so that its engagement with guide gear **P71** is correct and fastened in place using Loctite. As long as there are no faults in this area, such as teeth wear, do not attempt to dismantle it.




35. Remove guide gear assembly **P71** from flange **P4** and rear cover **P5**.

Note: If there is no fault with the swash plate gear (see step 34) do not dismantle the guide gear assembly.



Assembly - JS 110, 130, 150LC (cont'd)

15. Mount pins **P46** and collars **P18** on both sides of port block **P3**. Apply a thin film of grease to the rear surfaces of valve plates **P11** and **P12** and fit them in position.




16. Fit belville spring assembly **P22** and spring seat **P23** in the retainer holder **P14** in the positions from which they were removed. Mount the retainer holder onto cylinder block assembly **P6**.



17. Lift retainer plate **P13** into position above cylinder block assembly **P6**. Apply clean hydraulic fluid to the cylinder block piston bores and insert piston assemblies **P9**, one at a time, in the positions from which they were removed.




18. Apply clean hydraulic fluid to the sliding face of swash plates **P10**. Fit the rotating groups assembled in step 17 to shafts **P7** and **P8** and lower onto swash plates **P10**, taking care to prevent piston assemblies **P9** from falling out of cylinder blocks **P6**. Fit front valve plate **P11** and rear valve plate **P12** onto their respective cylinder block assemblies. Ensure that each valve plate is fitted to the correct position as each cylinder block is machined to fit the respective valve plate.



Checks After Installation JS 110, 130, 150 LC

After the pump has been fitted to the engine, the following procedure must be carried out.

- * 1. Remove pump drain port **A** and loosen air bleed plug **B**.
2. Fill the pump casing with clean hydraulic fluid (approximately 2litres).
3. Bleed air from hydraulic piping.
- * 4. Fit and tighten the drain and air bleed plugs **A** and **B**.
- * 5. Start the engine and run at a slow speed. Check the pump for abnormal noises which could signify air trapped in the pump. If the pump is noisy, stop the engine, vent the hydraulic pressure and loosen the air bleed plug **B**. When satisfactory, tighten the plug, restart the engine and check for abnormal noises.
6. When satisfactory, gradually increase engine speed until the machine operating range is reached.
7. Operate each service several times with a light load. Check for leaks. If satisfactory, operate each service with a greater load. If satisfactory, operate each service under normal working loads.
- * 8. For stable control of the Solenoid Proportional Pressure Control valve, it is necessary to bleed air from the valve by loosening bleed screw **C**. When all air has vented, torque tighten the screw to 0.15 - 0.245 Nm (0.11 - 1.8 lbf ft).



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Bucket Side Control Valve (4 Spool Valve)

Dismantling

Note: To aid reassembly, all items should be labelled during dismantling.

1. Remove bolts **21** and cap **19**. Remove 'O' ring **20** from the cap and discard.
 2. Withdraw spools **12**, **13** and **14** from the valve housing as a sub-assembly.
 3. The threads of each spool are coated with adhesive, to remove the cap screw, heat each spool to 200 to 250°C (392 to 482F) and immediately remove cap screw **18**. Remove spring seat **16** and spring **17**. To prevent damage to the outer surface of the spools, set the spool between wooden spool clamps, see **X**, and clamp in a vice.
 4. Remove bolts **10** and cap **9**. Withdraw spool **11** from the valve housing as a sub-assembly.
 5. Remove spring side seal **2**, wiper **3** and seal plate **4** from the spool. Heat the threaded portion of spool **11**, remove cap screw **8** and dismantle spring seat **5**, spring **7** and spacer **6**.
 6. Heat spool head **15**, as detailed in **3** above, and dismantle it.
 7. Remove bolt and cap **22** from the opposite side of the valve housing.
 8. Remove plug **25** and withdraw poppet **23** and spring **24** from the valve housing.
 9. Remove check valve **35** and withdraw poppet **33** and spring **34** from the valve housing (JS 150 only).
- Note:** For the JS 110/130, check valve **35**, spring **34** and poppet **33** are replaced by plug **25**, spring **24** and poppet **23**.
10. Remove relief valves **30** and **31** from the valve housing.
 11. Remove relief valve **32** from the valve housing. As the plug in the front end of the relief valve is removed during disassembly, ensure that the plug and poppet do not remain inside the valve housing after disassembly.

* **Note:** For Disassembly/Assembly of relief valves, refer to page 26-1 of this Section.

12. Disassemble plug assembly **27** and remove it from the valve housing. As this plug is blind, do not dismantle unless it is defective.

Cleaning and Inspection

1. Clean all disassembled parts in clean mineral oil and dry using compressed air.

2. Check the surfaces of all parts for burrs, scratches and other defects.
3. Check the seating surface of each valve housing for pitting and scratches. Remove all small flaws by rubbing with polishing powder. Ensure that all polishing powder has been removed after polishing.
4. Check the outside surfaces of all spools for scratches, dents and other flaws. Use an oil stone or cloth, dipped in a polishing solution to remove small flaws.
5. All sliding and engaging parts should slide smoothly and freely. Check that each channel or groove is free from dirt and dust.
6. Replace all broken, damaged, deformed or worn springs.

Assembly

Note: Hydraulic fluid should be applied to all screw threads unless otherwise stated.


1. Fit new 'O' rings to components during assembly.
2. Apply adhesive and hardening accelerator to the threads of cap screw **18**. Fit spring seat **16** and spring **17** in place and fit the screw into spool **12**. Torque tighten to 9.8 to 11.8 Nm (7.2 to 8.7 lbf. ft.). Care must be taken not to overtorque the screw as deformation of the spool could occur, leading to faulty operation.
3. Repeat item **2** for spools **13** and **14** and fit spring seat **16**, spring **17** and cap screw **18** to each spool.
4. Apply adhesive to the threads of spool head **15** and fit it to spool **11** (into the larger diameter end). Torque tighten to 10 to 12 Nm (7.2 to 8.7 lbf. ft.).
5. Fit seal **2**, wiper **3** and seal plate **4** on the opposite side. Fit spring seat **5**, spacer **6** and spring **7**. Apply adhesive to the threads of cap screw **8** and fit the cap screw into spool **11**. Torque tighten to 10 to 12 Nm (7.2 to 8.7 lbf. ft.).
6. Fit each spool assembly into the valve housing in the position from which it was removed.
7. Fit 'O' ring **20** into cap **19**. Fit the cap in the valve housing using bolts **21**. Torque tighten to 19.7 to 24.5 Nm (14.5 to 18.1 lbf. ft.).
8. Fit cap **9** and secure with bolts **10**. Torque tighten to 9.8 to 11.8 Nm (7.2 to 8.7 lbf. ft.).

Dismantling - JS 110, 130, 150LC


Refer to the sectional illustration on page E/30-1 as a guide to dismantling and assembly.

Details of service tools used in the dismantling and assembly procedures are given in Section 1, Service Tools.


- 1 Remove socket head bolts **10** and then cover **9**.



- 2 Remove and discard O-ring **8**.




- 3 Remove socket head bolts **7** and then thrust plate **6**.




Dismantling - JS 110, 130 (cont'd)

16. Remove 'O' ring 10 from housing 24 and 'O' ring 12 from piston 11.




17. Remove friction plate 9 and mating plate 8.



18. Hold the end of cylinder 23 and pull the cylinder assembly out of housing 24.

Note 1: The end face of cylinder 23 is a sliding contact face and should be protected to prevent damage.

Note 2: Make alignment marks or write numbers on the piston bores and piston assemblies to ensure that the piston assemblies are replaced in the same bores during assembly.




19. Remove the outer ring of taper roller 3 from the housing.




Assembly - JS 110, 130 (cont'd)


21. Apply JCB Multi-Gasket to the mating face of housing 24.




22. Align housing 24 and cover 16 to marks previously made. Carefully fit cover 16 and balance plate 20 onto housing 24, ensuring that they do not fall out.



23. Fit cover securing bolts 46. Torque tighten to 157 Nm (115.7 lbf. ft.).



24. Fit check valves 31 and springs 28 into cover 16. Fit and torque tighten caps 27 to 137 Nm (101.3 lbf. ft.).



Dismantling - JS 110, 130, 150LC



Refer to the sectional drawings on page 40-1 as a guide to dismantling and assembling.

Before attempting to dismantle the hand control valve, blank all inlet and outlet ports and wash the outer surfaces with a suitable solvent to remove all dirt and dust. Dry using compressed air.

-
1. Hold the control valve casing **101** in a vice. Detach the bellows from the lower edge of the casing and remove the bellows over the handle.

Protect the jaws of the vice to prevent damage to the casing.

-
2. Loosen the locknut and the adjusting nut **312** and remove the complete handle assembly. Hold the disc **302** with a spanner to prevent it turning. Remove the adjusting nut **312** and the disc **302**.



Boom, Dipper and Bucket Rams

The illustrations opposite apply as follows:

View A - JS110, JS130 boom and dipper
JS110, JS130, JS150LC bucket

View B - JS150LC boom and dipper

Dismantling

- 1 Drain all hydraulic fluid from the ram, disconnect and remove the hydraulic pipes.
- 2 Place the ram horizontally on a dismantling/assembly fixture and secure firmly.
- 3 Remove end cap 1 as follows:
 - a View A - unscrew the gland using a suitable hook spanner (refer to table on page 45 - 4 for correct size).
 - b View B - unscrew retaining bolts 2 using an Allen key.
- 4 Use slings to support the weight of the piston rod assembly 3 and pull the assembly clear of the ram cylinder 4. Use a suitable container to catch any residual hydraulic fluid displaced.

Note: It may be necessary to apply air or hydraulic pressure to the head side of the ram in order to extract the piston rod assembly from the cylinder.

WARNING

If air or hydraulic pressure is used to force out the piston assembly, ensure that the end cap is securely fitted. Severe injury can be caused by a suddenly released piston rod.

HYD-1-2

WARNING

You can be injured if you use faulty lifting equipment. Make sure that lifting equipment is in good condition. Make sure that lifting tackle complies with all local regulations and is suitable for the job. Make sure that lifting equipment is strong enough for the job.

INT-1-3-7

- 5 Position the piston rod assembly on the ram piston head dismantling/assembly rig (see page 45 - 5) with the piston rod resting on support block J.
- 6 Remove grub screw 5, after drilling out the staking. Remove steel ball 6.
- 7 Remove piston nut 7 as detailed on page 45 - 6.
- 8 Remove shim 8, piston head 9, cushion ring 10 and end cap assembly 1, in order, from piston rod 11.
- 9 Hold piston head 9 in a soft jawed vice and proceed as follows:-
 - a Remove upper and lower slide bearing rings 12 and 13 by hand.
 - b Cut and remove piston head main seal 14, taking care not to damage the seal groove.
 - c Remove 'O' ring 15
- 10 Remove the end cap seals 16, 17, back-up rings 18, 'U' shaped seal 19 and wiper seal 20 (or 20A †).

- 11 Remove wear ring 21 (JS150LC only - view B).

Note: Care must be taken not to damage any seal grooves.

- 12 Remove gland external 'O' rings 22 and back-up rings 23.
- 13 If it is necessary to remove bush 24 from end cap 1, remove snap ring 25. Push out the bush with a suitable press and tube. Discard all 'O' rings, seals and back-up rings.

Assembly

Before assembly, make sure all components are thoroughly cleaned in a suitable solvent and then dried. Use new 'O' rings, seals and back-up rings, lightly greased before use.

- 1 Fit a new bush 24, using a suitable tube and press. Fit snap ring 25 into end cap 1.
 - 2 Fit buffer seal ring 17 into end cap 1. Bend gland seal 16 into a 'U' shape (bend radius greater than 6 mm (0.24 in) to avoid kinking) and install into its groove. The open end of the 'U' shape **must** face towards the piston head.
 - 3 Install a new back-up ring 18 and 'U' shaped seal 19 ('U' shape facing piston head). Make sure there is no twisting and rolling of the ring 18 and seal 19.
 - 4 Fit wear ring 21 (JS150LC only - view B).
 - 5 Fit new wiper seal 20 (or 20A †).
 - 6 Install new gland external 'O' rings 22 and back-up rings 23 ('O' rings closest to the piston head).
 - 7 Fit 'O' ring 15 into the middle groove of piston head 9, making sure it is not twisted.
 - 8 Fit piston head seal 14 as follows (refer to illustration on page 45 - 3):
 - a Smear the surface of inner guide X with grease and fit seal 14 onto it in a horizontal position.
 - b Fit lower slide bearing rings 12 and 13 to the piston head by hand.
 - c Fit the thin end of inner guide X over the upper section of piston head 9.
 - d Position outer guide Y over inner guide X so that it rests on seal 14.
 - e Use a hydraulic press to push seal 14 off inner guide X and into its groove on piston head 9.
- Note:** Press carefully to ensure that the seal fits straight onto the inner guide X and thence squarely into its groove. Once pressing starts do not stop in mid-travel or the seal will become deformed.

- f Withdraw the press and remove guides X and Y.

- † Wiper seal 20A is fitted as follows:
JS110 machines from serial no. 697025
JS130 machines from serial no. 699060
JS150LC machines from serial no. 701051


Removal

- 1 Slacken the check valve to bleed out grease.

⚠ WARNING

Slacken the check valve slowly and stop when grease is released. The grease and valve are under extremely high pressure and could cause injury if suddenly released.

TRANS 6-2




- 2 Disconnect the track link.


⚠ WARNING

Stand clear and to one side of the track while you remove the master pin. When the master pin is removed the track could fall forward and injure you.

TRACK 1-1




- 3 Lift the side of the undercarriage high enough to permit drive sprocket removal. Support with wooden blocks.



- * 4 Stop the engine and operate the control lever to relieve pressure in the hydraulic system.

Slacken the air breather cap (as detailed in Section 3, page 5-1) to release pressure in the hydraulic tank.




Dismantling - JS 110/130 (continued)


- 17 Remove two plugs 1-8 and one plug 1-7. Fit eye-bolts in place of plugs 1-8.

Using a length of bar positioned against the eye-bolts, rotate the cover plate 1-27 until the wire 1-29 is visible through the hole for plug 1-7.


Pull out the wire with pliers whilst rotating the cover.




- 18 Connect a hoist to the eye-bolts and lift off the cover 1-27.



- 19 Remove thrust plate 1-23 and drive gear 1-22.




- 20 Remove three planetary gears 1-18 and their needle bearings 1-19.




Assembly - JS 110/130 (continued)

- 23 Position spool 33-1 in a vice fitted with soft jaws and install the check valve and spring 33-3.




- 24 Fit a new 'O' ring 33-5 to plug 33-4 and install them into spool 33-1. Using a 10 mm dia. round rod through the 11 mm dia. hole of spool 33 to prevent the spool from turning, tighten the plug to 100-116 Nm (73-86 lbf ft).




- 25 Fit new 'O' ring 37-2 onto cap 37-1. Assemble steel ball 37-4 and spring 37-5 in that order.

Fit new 'O' ring 37-6 and plug 37-7.



- 26 Lubricate and install spool 33, turning it slowly as it enters the base plate.




Dismantling - JS 150LC (continued)

- 17 Remove 2-speed control piston assembly, comprising piston 161, shoe 162 and spring 191, by applying compressed air to port A in housing 2.

CAUTION

When using compressed air, wear safety glasses and gloves. Do not direct compressed air at your skin.

8-3-4-2







- 18 To remove circlip 145, place the cylinder block on a press capable of exerting a pressure of at least 100 kgf (220 lbf) and compress spring 114 by means of a suitable tubular tool (see **Service Tools**, Section 1) pressing on washer 110.

During this operation, protect the machined surface of the cylinder block with suitable sheeting.

- 19 Remove circlip 145, followed by washer 110, spring 114 and the second washer 110.

- 20 Remove shaft 102 complete with inner race of bearing 149.




Assembly - JS 150LC (continued)

- 21 Assemble the cylinder block and pistons assembly with the swash plate 103 and retainer plate 107 onto the shaft 102.

Support this complete assembly by means of a hook fitted onto the end of the shaft (see **Service Tools**, Section1).

Insert the outer race of bearing 149 into the housing 2. Carefully lower the assembly into the housing 2, making sure that the swash plate locates correctly on the steel balls 167.

After assembly, rotate the cylinder block to check that there is no backlash.



- 22 Dip brake friction plates 115 in hydraulic fluid before assembly.

Install the friction plates 115 and the counter plates 116. Make sure that they are installed in the correct order as noted during dismantling.



- 23 Lightly grease 'O' rings 135 and 139. Install them with back-up rings 147 and 148 into the grooves of brake piston 112.



- 24 Install the brake piston 112 into housing 2 taking care not to damage the 'O' rings.


Note: If necessary, lightly hammer the piston with a plastic hammer to overcome the resistance of the 'O' rings.



Assembly - JS 110/130 (continued)

- 5 Degrease both the outer surfaces of a new oil seal 53 and its bore in the casing. Apply JCB Multigasket and press in the seal using the jig shown in **Service Tools** (Section 1).


Apply grease to the seal lip after fitting.



- 6 Screw an eye-bolt into the M18 tapped hole in the end of the shaft.


Fit a seal protector (see **Service Tools**, Section 1) over the end of the shaft to prevent the splines from damaging the oil seal.

Turn the casing over and lower the shaft and bearing assembly into the casing.



- 7 Fit snap ring 47.

Note: To assist future removal of the snap ring, position the gap in the snap ring approximately 30 mm (1.2 in) away from the cut-out in the casing.




- 8 Heat the inner race of bearing 54 and install the bearing as far as the shoulder in the shaft.




Assembly - JS 150LC

- 7 Turn the assembly over and make sure that the distance from the end of the seal ring to the end of the shaft is 80.0-80.3 mm (3.150-3.161 in).




- 8 Position casing 102 on a level bench. Suspend the drive shaft assembly vertically and install it into the casing.

Tap on the outer ring of each bearing until it is completely level. If a light tap will not level a bearing, do not use force but remove the bearing and refit with the outer ring level.



- 9 Fit 'O' ring 803 into the groove in cover 101.




Contents	Page No.
Idler Wheel and Recoil Unit	
Removal	2 - 1
Replacement	2 - 2
Idler Wheel	
Dismantling	3 - 1
Assembly	3 - 2
Wear Limits	4 - 1
Grease Cylinder	
Removal	5 - 1
Replacement	5 - 2
Dismantling	6 - 1
Assembly	6 - 1
Drive Sprocket	
Removal	7 - 1
Replacement	7 - 2
Wear Limits - JS110/130	7 - 3
Wear Limits - JS150LC	7 - 4
Top Roller	
Removal	8 - 1
Replacement	8 - 2
Dismantling	9 - 1
Assembly	9 - 2
Wear Limits	10 - 1
Bottom Roller	
Removal	11 - 1
Replacement	11 - 2
Dismantling	12 - 1
Assembly	12 - 2
Wear Limits	13 - 1

Removal (continued)

- 5 Remove the bottom roller (third from front).




- 6 Remove the bolts, then take out the grease cylinder from the track frame.

**Replacement**


- 1 With the undercarriage lifted and supported as shown under **Removal**, install the grease cylinder into the track frame.

Fit the mounting bolts and tighten to 264-303 Nm (195-224 lbf ft).




- 2 Position the roller on the track link as shown.

Align the holes in the brackets with the tapped holes in the undercarriage.




Dismantling

- 1 Clean the roller with a suitable solvent. Remove the plug 13 and drain the oil.




- 2 Remove bolt 12, spring washer 11 and cover 10 from roller 1.


Remove 'O' ring 9 from cover 10.



- 3 Remove bolt 8, washer 7 and thrust plate 6 from the shaft.



- 4 Pull roller 1 from shaft 2.



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL