

Shop Manual

CK30-1

COMPACT TRACK LOADER

SERIAL NUMBERS **CK30-1** **A30001** and UP

This material is proprietary to Komatsu America Corp. and is not to be reproduced, used, or disclosed except in accordance with written authorization from Komatsu America Corp.

It is our policy to improve our products whenever it is possible and practical to do so. We reserve the right to make changes or add improvements at any time without incurring any obligation to install such changes on products sold previously.

Due to this continuous program of research and development, periodic revisions may be made to this publication. It is recommended that customers contact their distributor for information on the latest revision.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below




- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL




2. TIGHTENING TORQUE FOR NUTS OF FLARED



Use these torques for nut part of flared.

Thread diameter of nut part (mm)	Width across flats of nut part (mm)	TIGHTENING TORQUE	
		kgm	Nm
1/2" - 20	17	2.6±0.5	25.5±4.9
9/16" - 18	17	4±0.5	39.2±4.9
3/4" - 16	22	6.7±2	65.7±19.6
7/8" - 14	27	8±2	78.5±19.6
1.1/16 - 12	32	9.7±3	95.15±29.4
1.5/16 - 12	38	17±3	166.7±29.4
1.5/8 - 12	50	20±5	196.2±49
22	27	8±2	78.5±19.6
33	41	20±5	196.2±49



Use these torques for nut part of flared.

Thread diameter of nut part (mm)	Width across flats of nut part (mm)	TIGHTENING TORQUE	
		kgm	Nm
9/16" - 18	17	2.3–2.5	23–25
11/16" - 16	22	3.4–3.9	33–38
13/16" - 16	24	5.2–5.8	51–57
1" - 14	30	8.2–9.2	80–90
1.3/16 - 12	36	12.2–13.3	120–130
1.7/16 - 12	41	15.3–17.3	150–170
1.11/16 - 12	50	18.4–20.4	180–200
2" - 12	57	20.4–24.4	200–240


From Nm to kgm

1 Nm = 0.102 kgm

	0	1	2	3	4	5	6	7	8	9
0	0	0.102	0.204	0.306	0.408	0.510	0.612	0.714	0.816	0.918
10	1.020	1.222	1.224	1.326	1.428	1.530	1.632	1.734	1.836	1.938
20	2.040	2.142	2.244	2.346	2.448	2.550	2.652	2.754	2.856	2.958
30	3.060	3.162	3.264	3.366	3.468	3.570	3.672	3.774	3.876	3.978
40	4.080	4.182	4.284	4.386	4.488	4.590	4.692	4.794	4.896	4.998
50	5.100	5.202	5.304	5.406	5.508	5.610	5.712	5.814	5.916	6.018
60	6.120	6.222	6.324	6.426	6.528	6.630	6.732	6.834	6.936	7.038
70	7.140	7.242	7.344	7.446	7.548	7.650	7.752	7.854	7.956	8.058
80	8.160	8.262	8.364	8.466	8.568	8.670	8.772	8.874	8.976	9.078
90	9.180	9.282	9.384	9.486	9.588	9.690	9.792	9.894	9.996	10.098
100	10.200	10.302	10.404	10.506	10.608	10.710	10.812	10.914	11.016	11.118
110	11.220	11.322	11.424	11.526	11.628	11.730	11.832	11.934	12.036	12.138
120	12.240	12.342	12.444	12.546	12.648	12.750	12.852	12.954	13.056	13.158
130	13.260	13.362	13.464	13.566	13.668	13.770	13.872	13.974	14.076	14.178
140	14.280	14.382	14.484	14.586	14.688	14.790	14.892	14.994	15.096	15.198
150	15.300	15.402	15.504	15.606	15.708	15.810	15.912	16.014	16.116	16.218
160	16.320	16.422	16.524	16.626	16.728	16.830	16.932	17.034	17.136	17.238
170	17.340	17.442	17.544	17.646	17.748	17.850	17.952	18.054	18.156	18.258
180	18.360	18.462	18.564	18.666	18.768	18.870	18.972	19.074	19.176	19.278
190	19.380	19.482	19.584	19.686	19.788	19.890	19.992	20.094	20.196	20.298

LOWER IDLER ROLLER


2-LIP TYPE



RKS04180

- | | |
|-------------|--------------|
| 1. Roller | 4. Shaft |
| 2. Shoulder | 5. Gasket |
| 3. Bushing | 6. Snap ring |

3-LIP TYPE




RKS04190

- | | |
|-------------|--------------|
| 1. Roller | 4. Shaft |
| 2. Shoulder | 5. Gasket |
| 3. Bushing | 6. Snap ring |

**HST PUMP LPV45 +45 (STANDARD FLOW AND HIGH FLOW)
FUNCTION**

- The rotation and torque transmitted to the pump shaft is converted into hydraulic energy, and pressurised oil is discharged according to the load.
- It is possible to change the discharge amount by changing the swash plate angle (plus, zero and minus)




RKS04770

- | | | |
|-------------------|-------------------|-------------------------|
| 1. Shaft | 6. Slider | 11. Main bearing |
| 2. Case | 7. Shoe | 12. Spline |
| 3. Cradle bearing | 8. Piston | 13. Sub bearing |
| 4. Rocker cam | 9. Cylinder block | 14. Charge pump |
| 5. Control piston | 10. Valve plate | 15. Work equipment pump |

STRUCTURE

- Cylinder block (9) is supported to shaft (1) by a spline (12), and shaft (1) is supported by the front and rear bearings (11), (13).
- The tip of piston (8) is a concave ball, and shoe (7) is caulked to it to form one unit. Piston (8) and shoe (7) form a spherical bearing.
- Rocker cam (4) has flat surface **A**, and shoe (7) is always pressed against this surface while sliding in a circular movement. There is a cradle bearing (3) between cradle and rocker cam (4) which is secured to the case. Rocker cam (4) sways on cradle bearing.
- Piston (8) carries out relative movement in the axial direction inside each cylinder chamber of cylinder block (9).
- The cylinder block seals the pressurised oil to valve plate (10) and carries out relative rotation. This surface is designed so that the oil pressure balance is maintained at a suitable level. The oil inside each cylinder chamber of cylinder block (9) is sucked in and discharged through valve plate (10).

CHARGE PUMP

RKS00150


1. Slide plate
2. Coupling
3. Shaft
4. Outer ring
5. Case
6. Inner rotor
7. Outer rotor

FUNCTION


- HST charge pump is built-in the HST pump and driven with HST pump at the same time.
- The pressurised oil generated by the charge pump is sent to safety valve in the charge circuit and to AS valve.
- Charge pump sucks oil from hydraulic tank.

SPECIFICATIONS


- Type: trochoid pump
- Theoretical delivery: 32 cm³/rev




Section A - A




Section B- B



Section C - C



Section AA-AA



Section BB-BB

RKS04820

- 1. Main relief valve
- 2. Suction valve (bucket bottom side)
- 3. Plug
- 4. Plug
- 5. Series - parallel circuit switching valve
- 6. Spool (lift arm)

- 7. Spool (bucket)
- 8. Spool (attachment)
- 9. Flow divider
- 10. Check valve (circulating circuit)
- 11. Combination circulating valve
- 12. Leveling circulating valve

CLSS

1. OUTLINE


Features

CLSS stands for Closed centre Load Sensing System, and has the followings characteristics.

- Controlability, not influenced by load;
- Controllable digging force at fine control range;
- Easy simultaneous operation by spool opening proportional flow dividing function.

2. PRESSURE COMPENSATION CONTROL


- A valve (pressure compensation valve) is installed to the inlet port side of the control valve to balance the load. When there is compound operation of the actuators, this valve acts to make pressure difference ΔP constant for the upstream flow (inlet port) and downstream flow (outlet port) of the notch of each spool. In this way, the flow of oil from the pump is divided in proportion to area of opening **S1** and **S2** of each valve.



FKS00691


SOLENOID VALVE ST3

OVERRIDE CONTROL




RKS04490


1. SV4 - Backhoe boom lockout
- a. T port - To transmission
- b. Port 1 - From transmission
- c. T1 port - Boom lockout cylinder




Section A - A




Section B - B



Section C - C



Section D - D




Section E - E


RKS00810

- | | |
|---------------------|------------|
| 1. Spool | 6. Nut |
| 2. Metering spring | 7. Joint |
| 3. Centering spring | 8. Cover |
| 4. Piston | 9. Stopper |
| 5. Disc | 10. Body |

ELECTRICAL DIAGRAM (FRAME LINE STANDARD) (2/3)




ELECTRICAL DIAGRAM (CABIN LINE OPTIONAL) (1/7)



RKS03310

ELECTRICAL DIAGRAM (TOP-CABIN LIGHT LINE HOMOLOGATION) (2/2)



COMPONENTS

- GND4** Ground ø6 terminal
- GND6** Ground ø8 terminal
- H1** Beacon light
- H4** Left low beam
- H5** Left side light
- H6** Right low beam
- H7** Right side light
- H8** Left rear lamp
- H9** Right rear lamp
- H10** Left rear work light
- H11** Right rear work light
- H12** Plate light
- HA2** Horn
- X108** Front low beam 2 way connector

- X109** Front low beam 2 way connector
- X110** Rear work lights 2 way connector
- X111** Rear work lights 2 way connector
- X115** Front traffic lights 1 way connector
- X116** Front traffic lights 1 way connector
- X117** Front traffic lights 1 way connector
- X118** Front traffic lights 1 way connector
- X119** Front traffic lights 1 way connector
- X120** Front traffic lights 1 way connector
- X121** Rear traffic lights 1 way connector
- X122** Rear traffic lights 1 way connector
- X123** Rear traffic lights 1 way connector
- X124** Rear traffic lights 1 way connector
- X125** Rear traffic lights 1 way connector
- X126** Rear traffic lights 1 way connector

- X127** Rear traffic lights 1 way connector
- X128** Rear traffic lights 1 way connector
- X129** Plate light connector
- X130** Plate light connector
- XP1** Current intake 12v, beacon light
- XP1A** Current intake 12v, beacon light

**PAGE INTENTIONALLY
LEFT BLANK**

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

6 - After you have loosened the check nuts for the pump (6) and the screws (7), rotate the injection pump (5) outwards or towards the engine.

- To ADVANCE injection, rotate pump (4) outwards.
- To DELAY injection rotate the pump (4) towards the cylinder block.


★ Check the extent of the movement on the scale (8).

7 - Lock the nuts (6) that fasten the pump to its block.

★ After adjustment of the fuel injection timing:


8 - Connect the fuel delivery tubes (5) to the pump and replace the clamp (3).

9 - Bleed any air from the fuel circuit.




- **Pressure adjustment at high pressure**

- 1 - Loosen the nut (3), and adjust the operating pressure of the AS valve (with the engine at 2690 ± 30) using the following procedure:
 - To INCREASE pressure, turn the screw (4) in a CLOCKWISE direction.
 - To REDUCE pressure, turn the screw (4) in a COUNTER-CLOCKWISE direction.
- ★ Rotating the screw by one turn (4) will vary pressure by 1.47 bar.



- 3 - Tighten the nut (3) and check that the working pressure remains within permissible limits.

 Nut: 34.3–58.8 Nm

30 REMOVAL AND INSTALLATION

HOW TO READ THE MANUAL	3	FUEL TANK	31
PRECAUTIONS TO BE TAKEN WHILE WORKING	4	• Removal.....	31
ENGINE HOOD.....	5	• Installation.....	32
• Removal.....	5	ENGINE-PUMP GROUP	33
• Installation	5	• Removal.....	33
CAB	6	• Installation.....	36
• Dump.....	6	COMPLETE HYDRAULIC PUMP	37
• Removal	10	• Removal.....	37
• Installation	13	• Installation.....	39
BATTERY	14	GEAR PUMP	40
• Removal	14	• Removal.....	40
• Installation	14	• Installation.....	40
STARTING MOTOR	15	ENGINE-PUMP COUPLING	41
• Removal	15	• Removal.....	41
• Installation	15	• Installation.....	41
ALTERNATOR	16	CONTROL VALVE.....	42
• Removal	16	• Removal.....	42
• Installation	16	• Installation.....	42
AIR INTAKE FILTER	17	PPC VALVES.....	43
• Removal	17	• Removal.....	43
• Installation	17	• Installation.....	43
MUFFLER.....	18	LIFT CYLINDER	44
• Removal	18	• Removal.....	44
• Installation	19	• Installation.....	44
VALVE COVER	20	BUCKET CYLINDER	45
• Removal	20	• Removal.....	45
• Installation	20	• Installation.....	46
INJECTORS.....	21	WORK EQUIPMENT CYLINDERS	47
• Removal	21	• Disassembly	47
• Installation	21	• Assembly	49
INJECTION PUMP.....	22	COMPLETE WORKING EQUIPMENT	53
• Removal	22	• Removal.....	53
• Installation	24	• Installation.....	54
CYLINDER HEAD.....	25	WORKING EQUIPMENT SUPPORT FRAME	55
• Removal	25	• Removal.....	55
• Installation	27	• Installation.....	55
COOLANT LIQUID PUMP	28	HEATING SYSTEM BLOWER FAN	56
• Removal	28	• Removal.....	56
• Installation	28	• Installation.....	57
RADIATOR GROUP	29	TRACK.....	58
• Removal	29	• Removal.....	58
• Installation	30	• Installation.....	59


STARTING MOTOR

Removal

- 1 - Tilt the cab and secure it in its safety position.
- 2 - Remove the battery (1).
(For details, see "BATTERY")



- 3 - Disconnect the cables (2) and (3).
- 4 - Loosen the screws (4) and take out the starting motor (5).




Installation

- To install, reverse removal procedure.

- 11- Loosen three screws (18) and remove the complete injection pump (4) with its O-ring (19).

[*6]




Installation

- To install, reverse the removal procedure.



[*1]

- ★ Check accelerator cable travel. (See "20 TESTING AND ADJUSTMENTS" for details).

[*2]


-  High pressure pipe: 19.6-24.5 Nm

[*3]


-  Cover contact surface liquid gasket
-  Fan screws: 22.6-28.4 Nm

[*4]

- ★ Align marks between gears before installing pump and nut.

-  Nut: 113-123 Nm

[*5]

-  Pump clamping nut:..... Nm
- ★ Check injection point timing. (See "20 TESTING AND ADJUSTMENTS" for details).


[*6]

-  Pump screws: 22.6-28.4 Nm


CAB

Removal

- 1 -Remove the complete attachments.
(For details, see "COMPLETE WORKING EQUIPMENT").
- 2 -Loosen the nuts (1) and tilt the rear panel (2) towards the front of the machine.



- 3 -Disconnect the connectors (3) from the cab cabling (4) and release the engine cabling (5) from its retaining clamps.




- 4 -Tilt the cab. (For details, see "CAB" - «Dump »).
- 5 -Disconnect the four pipes (6) on the RH side, the two servo-control feed-pipes (7) and the four pipes (8) on the LH side.


- ★ To disconnect the pipes, remove the retainer (9) push the pipe (6) completely inside the union (10) and extract the pipe (6).
Then, mount the retainer (9) on the pipe (6).

[*1]

- ★ Mark the hoses to avoid mixing them during re-assembly.






- 6 -Pull out the cab cabling (5).





Installation

- To install, reverse removal procedure.


[*1]


-  Flange screws: 80 Nm
-  Flange screws: Loctite 262
-  Pump shaft: Lithium EP MS2 NLGI 2

[*2]

-  Pump screws: 195 Nm
-  Pump screws: Loctite 262

- 1 - Fill the tank up to maximum level.

 Hydraulic oil requirement: approx. 32 ℓ

 Bleed the air from the pump.
(For details, see "20 TESTING AND ADJUSTMENTS").


- 2 - Start the engine to circulate the oil and check that there are no leaks.
- 3 - Stop the engine, check the levels and, if necessary, top them up.
- 4 - Bleed the air from the hydraulic circuits and pressurise the tank.
(For details, see "20 TESTING AND ADJUSTMENTS").

WORK EQUIPMENT CYLINDERS


Disassembly

1 - Take off the guard rings (1) from both sides of the cylinder and from the piston rod.


- ★ Make sure that the tube unions are not plugged.




2 - Place the cylinder (2) on the apparatus **A**. Engage the cylinder in the tools **B**, having the same bushing diameter.



3 - Attach the special wrench **C** (adjusted to fit the cylinder) to the head (3) and apply the dynamometric tool **D**.



4 - Unscrew the head (3) and extract it completely from the cylinder (2).




Installation

- To install, reverse removal procedure.


[*1]

- ★ Adjust track tension.
(For details, see "20 TESTING AND ADJUSTMENTS").


9 -Remove the side gears (10) (4 pcs.) together with bearings (11).



10 -Remove snap ring (12).



11 -Remove the complete housing (13) from the drive motor (14).




12- Remove the first ring of packing (15) from drive motor (14).




Assembly

1 - Install grommet (62) to flanged hub (41) so it is flush with the hub.


★ Pay attention to grommet orientation.

 Grommet lip: grease




2 - Install the outer ring of bearing (61) to the flanged hub (41) and install the inner ring to the drive shaft (60).


★ Pay attention to ring orientation.




3 - Install the complete drive shaft (60).




4 - Install springs (58) to pistons (57).




42 -Using a press and a suitable push rod, complete the assembly of the motor (13).




43 -Lock motor (13) in place using snap ring (12).




44 -Install the complete side gears (10) (4 pcs.).



45 -Lock gears (10) in place using snap rings (9).




REAR IDLER WHEEL



Unit: mm

No.	Check item	Criteria				Remedy
		Standard size		Repair limit		
1	Outer diameter	350		-		Reconstruct by welding or replace
2	Track guide width	44		20		
3	Clearance between shaft and bushings	Standard size	Tolerance		Minimum clearance	Clearance limit
			Shaft	Hole		
4	Interference between bushing and roller					Replace bushing
5	Roller float	Standard size		Clearancelimit		





RKS04960

Unit: mm

No.	Check item	Criteria					Remedy
		Standard size			Repair limit		
		Free installed x Øe	Installed length	Installed load	Free length	Installed load	
1	Spool return spring (lift arm)	28.8x17.1	26.8	38.2 N	–	30.6 N	Replace springs. If there are damage or deformation
2	Spool return spring (bucket)	26.3x17.7	18.5	176.5 N	–	141.2 N	
3	Spool return spring (bucket)	21.6x14.8	10	38.7 N	–	31.0 N	
4	Spool return spring (ATT)	28x11.5	24.5	137.3 N	–	109.8 N	
5	Spring of series - parallel circuit switching valve	38.3x15.2	24	161.8 N	–	129.5 N	
6	Spring of unload valve	32.9x18.2	18	74.0 N	–	59.2 N	
7	Spring of unload valve	18.7x9.3	16	3.4 N	–	2.7 N	
8	Spring of pressurecompensation valve	15.4x6	13	2.5 N	–	2.0 N	
9	Spring of pressurecompensation valve	20x8.4	12	6.9 N	–	5.5 N	

CYLINDERS



RKS01500

Unit: mm

N°	Check item	Cylinder	Criteria					Remedy
			Standard size	Tolerance		Minimum clearance	Clearance limit	
				Shaft	Hole			
1	Tolerance between bushing and piston rod mounting pin	Lifting bucket	35	-0.01 -0.05	+ 0.072 + 0.134	0.082- 0.184	1.0	Replace bushing
		Tilt bucket	35	-0.01 -0.05	+ 0.072 + 0.134	0.082- 0.184	1.0	
2	Tolerance between bushing and cylinder mounting pin	Lifting bucket	35	-0.01 -0.05	+ 0.072 + 0.134	0.082- 0.184	1.0	
		Tilt bucket	35	-0.01 -0.05	+ 0.072 + 0.134	0.082- 0.184	1.0	
3	Tolerance between piston rod and cylinder head	Lifting bucket	40	-0.025 -0.087	+ 0.039 + 0	0.025- 0.126	0.426	Replace head
		Tilt bucket	35	-0.025 -0.087	+ 0.039 + 0	0.025- 0.126	0.426	

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL