

SERVICE MANUAL

Boomer™ 46D CVT

Boomer™ 54D CVT

Tier 4B (final)

Compact Tractor

Part number 47851943

1st edition English

February 2016



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

CONTAINMENT OF AIR CONDITIONING REFRIGERANTS

The following procedure is a guide to servicing mobile air conditioning systems in a way that minimizes the potential for losing refrigerant to the atmosphere. Following the procedures in this section will help ensure compliance with SAE J2211 for **R134A** systems.

⚠ DANGER

Avoid injury!

Observe ALL precautions listed below when servicing the air-conditioning system and handling refrigerant.

Failure to comply will result in death or serious injury.

D0043A

Fire or explosion hazard exists with R-134a under certain conditions. R-134a has been shown to be nonflammable at ambient temperature and atmospheric pressure. However, tests under controlled conditions have indicated that, at pressures above atmospheric and with air concentrations greater than 60% by volume, R-134a can form combustible mixtures. While it is recognized that an ignition source is also required for combustion to occur, the presence of combustible mixtures is a potentially dangerous situation and should be avoided.

R-134a service equipment or vehicle air conditioning systems should not be pressure tested or leak tested with compressed air. Mixtures of air and R-134a have been known to be combustible at elevated pressures. These mixtures are potentially dangerous and could result in fire or explosion causing injury or property damage. Additional health and safety information may be obtained from refrigerant and lubricant manufacturers. Failure to comply could result in death or serious injury.

Recovery

1. Be sure that all service equipment hose lines have shutoff valves or check valves within **30 cm (12 in)** of their ends. This will ensure that only minimal quantities of refrigerant escape to the atmosphere when the equipment is disconnected from the air conditioning system, and only small amounts of moisture and other contaminants can enter the system.
2. Be sure that all equipment, including the connecting hose lines and manifold, are compatible with the refrigerant in the system with which you are going to work, and that your equipment has previously been used only with the refrigerant you are about to service.
3. Be sure that all shutoff valves are tight before connecting them to the air conditioning system.

NOTE: *Keep shutoff valves closed at all times unless they are connected to a vehicle's air conditioning system, a refrigerant storage container or another piece of service equipment containing the same refrigerant. This prevents refrigerant from escaping into the atmosphere, damaging the environment, contaminating the equipment, and costing you money.*

4. Connect the extraction or recovery equipment to the air conditioning system in accordance with the instructions supplied by the equipment manufacturer.
5. Start the recovery process by turning on the extraction equipment and extracting the refrigerant from the air conditioning system in accordance with the equipment manufacturer's instructions.
6. Continue to extract refrigerant until the air conditioning system is under a vacuum and there is no refrigerant remaining in the vehicle system.
7. Verify that there is no refrigerant remaining in the system by:

a) Shutting off the extraction unit and observing the system pressure level.

b) Waiting five minutes and observing the system pressure again. If the system pressure has not risen above atmospheric pressure (0 gauge pressure), all refrigerant has been removed and you may proceed to step 8.

If after five minutes, the system pressure reading has risen above atmospheric pressure (0 gauge pressure), the extraction / recovery process must be repeated until the pressure reading remains at or below atmospheric for at least two minutes with the extraction equipment shut off before proceeding to step 8.


8. Close the shutoff valve in the service lines.
9. Remove the service lines from the vehicle system. If the recovery equipment has automatic closing shutoff valves, verify that they are operating properly and do not leak.

International symbols

As a guide to the operation of the machine, various universal symbols have been utilized on the instruments, controls, switches, and fuse box. The symbols are shown below with an indication of their meaning.

 Thermostat starting aid	 Radio	 PTO	 Position Control
 Alternator charge	 KAM Keep alive memory	 N Transmission in neutral	 Draft Control
 Fuel level	 Turn signals	 Creeper gears	 Accessory socket
 Automatic Fuel shut-off	 Turn signals -one trailer	 Slow or low setting	 Implement socket
 Engine speed (rev/min x 100)	 Turn signals -two trailers	 Fast or high setting	 %age slip
 Hours recorded	 Front windshield wash/wipe	 Ground speed	 Hitch lower (rear)
 Engine oil pressure	 Rear windshield wash/wipe	 Differential lock	 Hitch height limit (rear)
 Engine coolant temperature	 Heater temperature control	 Rear axle oil temperature	 Hitch height limit (front)
 Coolant level	 Heater fan	 Transmission oil pressure	 Hitch disabled
 Tractor lights	 Air conditioner	 FWD engaged	 Hydraulic and transmission filters
 Headlamp main beam	 Air filter blocked	 FWD dis-engaged	 Remote valve extend
 Headlamp dipped beam	 Parking brake	 Warning!	 Remote valve retract
 Work lamps	 Brake fluid level	 Hazard warning lights	 Remote valve float
 Stop lamps	 Trailer brake	 Variable control	 Malfunction! See Operator's Manual
 Horn	 Roof beacon	 Pressurized! Open carefully	 Malfunction! (alternative symbol)
	 Warning! Corrosive substance		

INTRODUCTION



NHIL14CT00745GA 1

Engine and crankcase - Remove remove the engine from the frame


⚠ DANGER

Heavy objects!

Lift and handle all heavy components using lifting equipment with adequate capacity. Always support units or parts with suitable slings or hooks. Make sure the work area is clear of all bystanders. Failure to comply will result in death or serious injury.


D0076A

1. Use jack stands under the frame rails to support the front frame/engine assembly.
2. Remove the A/C compressor guard, **(1)**, from the tractor.
3. Remove the two M16 flange bolts **(2)**, and loosen the two grommet bolts **(3)**.



NHIL16CT00011AA 1

4. Remove the radiator hose guard **(1)** from the tractor.
5. Loosen the two grommet bolts **(2)**, and remove the two M16 bolts **(3)**.
6. Drain the coolant from the radiator into a suitable container.
7. Remove the top, **(3)**, and the bottom, **(4)**, radiator hoses.
8. Remove the radiator. See **Radiator - Remove (10.400)**.
9. Attach a chain sling to the two hoist eyes on the engine.
10. Attach a suitable hoist to the chain sling, and raise the hoist enough to support the engine.



NHIL16CT00010AA 2

Contents

Engine - 10

Air cleaners and lines - 202

FUNCTIONAL DATA

Air cleaner	
Dynamic description	3

SERVICE


Air cleaner	
Remove	4
Install	5

Index

Engine - 10

Engine cooling system - 400

Engine cooling system - Dynamic description	3
Radiator - Install	9
Radiator - Remove	4




NHIL12CT00628FA 2

Variator Assembly

The variator assembly (2) is an electro-hydraulically controlled variable speed transmission. The variator assembly consists of a gerotor style fixed displacement hydraulic pump, input drive pulley, output driven pulley, drive chain and mechanical torque sensor. The fixed displacement gerotor pump produces the oil flow for the complete transmission system except for the Forward/Reverse clutch which oil is supplied by the power steering hydraulic pump. The throat of the input and output pulleys are adjusted simultaneously by the use of both hydraulic and spring pressure to set the desired speed of the transmission. The driven output pulley also incorporates a mechanical torque sensor that acts similar to a mechanical governor. As the torque sensor senses torque rise it adjusts and increases the pressure to the input (P1) (3) and the output (P2) (4) pulleys to compensate and apply more force to the variator assembly. If the torque load increase to the point where the variator cannot hold the chain assembly safely, the transmission logic will dump the Forward/Reverse clutches and the unit will lose drive pressure, similar to blowing a pressure relief valve in a hydrostatic transmission.


Planetary Reduction

The planetary reduction (5) uses the speed from the input pulley assemblies to control the sun gear (6) and carrier (7). By controlling the speed at which the sun gear turns in comparison to the carrier, we can reduce the high speed revolutions of the variator assembly to a usable drive pinion ratio. The drive pinion is the direct out put of the planetary assembly.



NHIL12CT00452FA 2


Reverse Left Side View



NHIL12CT00451FA 3


Reverse Right Side View

4. From inside the transmission box, disconnect and remove hydraulic tube, (5), from line (6). Disconnect and remove tubes (6), and (7).




NHIL12CT00441AA 4

5. Remove the M10 x 1.25 x 88mm Allen head bolt, (1), and the reverse idler gear assembly, (2).




86084744N 5

6. Remove the M16 x 15mm Allen bolt, (1), and engine speed sensor, (2).




86084746N 6

7. Remove regulating valve, (1), and spring, (2).




36084718N 7

12. Install needle bearing (1) over shaft bushing (2). Install the forward (34 tooth) (3) and reverse (30 tooth) (4) shuttle clutch gears.




36084733N 15

13. Using a press (1) install thrust washer (2) and bearing (3).



86084754N&36084 16

14. Install the four sealing rings (1) onto shaft (2).



NHIL12CT00443AA 17

Continuously Variable Transmission (CVT) - Test - (PIV) valve pressure transducer

⚠ WARNING

Unexpected machine movement!

Support the front axle and rear axle off the ground with jack stands before you perform the transmission test. The front axle drive will engage automatically when you depress the brake pedals.

Failure to comply could result in death or serious injury.

W1444A

⚠ CAUTION

Escaping fluid!


Hydraulic fluid or diesel fuel leaking under pressure can penetrate the skin and cause infection or other injury. To prevent personal injury: Relieve all pressure before disconnecting fluid lines or performing work on the hydraulic system. Before applying pressure, make sure all connections are tight and all components are in good condition. Never use your hand to check for suspected leaks under pressure. Use a piece of cardboard or wood for this purpose. If injured by leaking fluid, see your doctor immediately.

Failure to comply could result in minor or moderate injury.

C0104A


Pressure transducer hydraulic pressure to voltage comparison test

The following test procedure will provide the availability of the hydraulic pressures present at the (PIV) valve and the output voltages of the (PIV) pressure transducers simultaneously. Comparing hydraulic pressures to voltage outputs will provide information to assist in trouble shooting transmission operation concerns.



NHIL15CT01156AA 1

1. Support front and rear axles with jack stands.
2. Remove both rear tires from the tractor.




NHIL16CT00060AA 2

Continuously Variable Transmission (CVT) - Visual inspection Gerotor pump


Inspection

1. Thoroughly clean all parts in a suitable solvent and air dry.



86084051N 1

2. Inspect the bushings, (1), in spacer plate, (2), and pump body, (3), for damage or excessive wear. If bushings are found to be damaged, replace pump.



86084052N 2

NOTE: Internal parts for this pump are not serviceable, if damage is visible on any of the components, replace the pump.

Continuously Variable Transmission (CVT) - Remove Secondary Pulley Output Shaft

Prior operation:

Power Take-Off (PTO) clutch - Remove (31.114)

Prior operation:


Differential - Remove (27.106)

Prior operation:

Continuously Variable Transmission (CVT) - Disconnect (21.504)


Removal

1. Remove M6 x 12mm screw, (1), and pull HPL drain tube, (2), from differential housing.




36084013N 1

2. Remove snap ring, (1), and gear, (2), from the front of the secondary pulley output shaft, (3).
3. Remove large snap ring, (4), that secures the secondary pulley output shaft in housing.



36084014N 2

4. Using an aluminum or brass drift, (1), drive the secondary pulley output shaft, (2), forward, from the differential housing, as an assembly.
5. Remove snap ring, (3), from differential housing.



86084015N 3

Index

Transmission - 21

Continuously Variable Transmission (CVT) - 504

Continuously Variable Transmission (CVT) - Assemble - PIV (ARON) Valve	79
Continuously Variable Transmission (CVT) - Assemble Forward/Reverse Shuttle Clutch	60
Continuously Variable Transmission (CVT) - Assemble Front Transmission Box	50
Continuously Variable Transmission (CVT) - Assemble Gerotor pump	102
Continuously Variable Transmission (CVT) - Assemble Planetary Reduction Gear	133
Continuously Variable Transmission (CVT) - Assemble Reverse Idler	75
Continuously Variable Transmission (CVT) - Calibrate Forward / Reverse Shuttle Clutch	68
Continuously Variable Transmission (CVT) - Calibrate Variator	96
Continuously Variable Transmission (CVT) - Component identification CVT transmission sensors, valves and switches	21
Continuously Variable Transmission (CVT) - Component identification Transmission Control Valve Filter	26
Continuously Variable Transmission (CVT) - Connect	42
Continuously Variable Transmission (CVT) - Disassemble - PIV (ARON) Valve	77
Continuously Variable Transmission (CVT) - Disassemble Forward/Reverse Shuttle Clutch	55
Continuously Variable Transmission (CVT) - Disassemble Front transmission box	45
Continuously Variable Transmission (CVT) - Disassemble Planetary Reduction Gear	131
Continuously Variable Transmission (CVT) - Disassemble Reverse idler	74
Continuously Variable Transmission (CVT) - Disconnect	39
Continuously Variable Transmission (CVT) - Dynamic description - Forward/Reverse Power Flow	27
Continuously Variable Transmission (CVT) - Dynamic description PIV (ARON) Valve	11
Continuously Variable Transmission (CVT) - Electrical test Torque Pressure Sensor	112
Continuously Variable Transmission (CVT) - Electrical test Variator Output Speed Sensor	109
Continuously Variable Transmission (CVT) - Flow test - Gerotor Pump	105
Continuously Variable Transmission (CVT) - Hydraulic schema FWD	37
Continuously Variable Transmission (CVT) - Hydraulic schema Forward-Reverse Clutch	33
Continuously Variable Transmission (CVT) - Hydraulic schema PIV (ARON) Valve and Variator ..	30
Continuously Variable Transmission (CVT) - Hydraulic schema PTO	35
Continuously Variable Transmission (CVT) - Install - PIV (ARON) Valve	81
Continuously Variable Transmission (CVT) - Install Gerotor Pump	104
Continuously Variable Transmission (CVT) - Install Gerotor Pump Inner Filter	114
Continuously Variable Transmission (CVT) - Install Park Lock Control	123
Continuously Variable Transmission (CVT) - Install Primary Pulley Oil Distribution Pipe	126
Continuously Variable Transmission (CVT) - Install Rear PTO/FWD Hydraulic Valves	117
Continuously Variable Transmission (CVT) - Install Secondary Pulley Output Shaft	120



PRINTED IN U.S.A.


© 2016 CNH Industrial America LLC.

All rights reserved. No part of the text or illustrations of this publication may be reproduced.

NEW HOLLAND policy is one of continuous improvement and the right to change prices, specification or equipment at any time without notices is reserved.


All data given in this publication is subject to production variations. Dimensions and weight are approximate only and the illustrations do not necessarily show products in standard condition. For exact information about any particular product, please consult your NEW HOLLAND Dealer.

5. Keep washer, **(11)**, and remove sleeve, **(12)**, and spacer, **(13)**.




NHIL12CT00603AA 4

6. Loosen screws, **(14)**, and turn fork, **(15)**, so as to release sleeve, **(16)**.
7. Remove sleeve, **(16)**, and gear, **(17)**.




NHIL12CT00604AA 5

8. Keep washer, **(18)**, and remove sleeve, **(19)**.




NHIL12CT00605AA 6

9. Remove retaining ring, **(20)**, on the front side of the PTO drive shaft, **(21)**, and retaining ring, **(22)**, on the rear of the housing.




NHIL12CT00606AA 7

10. Remove the four forward pivot M14 x 50mm bolts and M14 nuts and lock washers **(3)**. (Left side shown.)



NHIL13CT00741AA 9

(Right side shown.) **(4)**




NHIL13CT00742AA 10

11. Roll the axle and wheel and tire assembly forward and clear of the tractor chassis.

NOTICE: Support the FWD shaft as it will fall away from the axle spline.

12. Disconnect the tie rod ends / steering cylinder ends by removing the cotter pin **(1)** and castle nut **(2)**.

NOTE: Make note of tie rod toe in measurement **(A)**. (Left side shown.)



NHIL13CT00739AA 11

Powered front axle - Install front axle cover

⚠ WARNING

Avoid injury!

Handle all parts carefully. Do not place your hands or fingers between parts. Use Personal Protective Equipment (PPE) as indicated in this manual, including protective goggles, gloves, and safety footwear.


Failure to comply could result in death or serious injury.

W0208A

NOTE: Right side shown. Use this procedure for the left side also.

Installation

1. Install the floating seal (1) to the front axle cover (2) and the axle shaft (3).



NHIL13CT00656AA 1


NOTICE: Make sure that the seal rings and O-rings are installed in the correct order.

NOTE: (A) is an exploded view.


Installation order :

- O-ring (1).
- Seal ring (2).
- Seal ring (3).
- O-ring (4).

NOTICE: Install the seal rings so that the machined surfaces of upper and lower seal rings face each other. Lubricate mating surfaces of seal rings with oil before installation.



NHIL13CT00658BA 2



NHIL13CT00639FA 2

Bevel Pinion Shaft Components


(1) Bevel gear assembly (Item (2) and (3))	(4) Adjusting collar	(7) Spacer cylinder
(2) 22T bevel gear	(5) Taper roller bearing	(8) Snap ring
(3) Bevel pinion shaft 10T	(6) Nut M28	(9) Oil seal

Pinion shaft installation

1. Insert the inner adjusting shim (1) into the housing.
2. Insert the pinion shaft (2) with the tapered bearings and the locking nut into the housing.
3. Install the outer adjusting shim (3) and snap ring (4).
4. Tighten the locking nut (5) so that the proper amount of preload is applied to the tapered bearings.
5. Check the preload of the tapered bearings is correct by measuring the rolling torque of the pinion shaft.


NOTE: See *Powered front axle - Preload of pinion shaft taper roller bearings (25.100)* for measuring and adjusting the rolling torque of pinion shaft.

6. When the preload of the tapered roller bearing is obtained, peen the locking nut so that the nut will not loosen.
7. Insert the differential assembly (6) with the 22T bevel gear (7) and the bearing into the left side of the axle support housing (8) Make sure the 22T gear faces inner side.
8. Insert the shim (9) and install the snap ring (10).
9. Measure the backlash and the contact area of the pinion gear and 22T bevel gear.



NHIL13CT00688BA 2


10. Insert the new oil seal (11) onto the pinion shaft.



NHIL13CT00689AA 3

NOTE: Make sure that the oil seal is inserted **1 mm (0.040 in)** deeper than the edge of the housing. (A)

4. Measure the clearance **(A)**.



NHIL13CT00635BA 4


5. Install a shim **(5)** which is **0.2 - 0.5 mm (0.008 - 0.020 in)** thicker than the clearance **(A)**.

Size of shims:

- 0.5 mm (0.020 in)
- 0.8 mm (0.030 in)
- 1.0 mm (0.040 in)
- 1.2 mm (0.050 in)


NOTE: Standard shim size: **1.0 mm (0.040 in)**.

6. Tighten the axle support M12 mounting bolts **(4)** to **78 - 90 N·m (57 - 67 lb ft)**.



NHIL13CT00674AA 5


8. Install the planetary gear carrier, (1), shims, (2), and spacer, (3), onto the axle shaft and secure with the snap ring, (4).



36084223N 5

NOTE: Shim sizes are 0.15 mm (0.006 in).

9. Measure the end play of the planetary gear carrier, (1), by placing a dial indicator, (2), against the planetary gear carrier as shown.




80085847N 6

10. Set the dial indicator, (2), to zero, and then slide the planetary gear carrier, (1), back and forth on the axle shaft. The planetary gear carrier should have an end play of 0.05 - 0.7 mm (0.002 - 0.028 in).

NOTICE: If the end play measurement is not correct the shims will need to be readjusted.

11. Install the washers, (1), planetary gears, (2), and needle bearings, (3), onto the planetary gear carrier, (4).



36084222N 7

NOTE: To aid in assembly, apply petroleum jelly to the needle bearings


NOTE: When the value of the clearances is zero, the value is not stamped on the drive pinion.

The following is the formula for the rear pinion gear shim, **(1)**, calculation:


- $S2 = S1 + (D1 - D2) / 100 + (H1 - H2)$
- D1 = Deviation value of original pinion
- D2 = Deviation value of replacement pinion
- H1 = Pinion head height of original pinion
- H2 = Pinion head height of replacement pinion
- S1 = Shim amount of original pinion
- S2 = Shim amount of replacement pinion

NOTE: D1 and D2 values engraved on pinion heads are expressed in hundredths of mm. All other dimensions are in mm.

NOTE: H1 and H2 dimensions are found by measuring the height (H) of the pinion gear.



36080701N 2



36084030N 3

Replacement Shim Amount (S2) Calculation

$$S2 = S1 + (D1 - D2) / 100 + (H1 - H2)$$

Example:

- D1 = 15
- D2 = 5
- H1 = 36.9
- H2 = 37.1
- S1 = 1.4

$$S2 = S1 + (D1 - D2) / 100 + (H1 - H2)$$

$$S2 = + 1.4 + (15 - 5) / 100 + (36.9 - 37.1)$$

$$S2 = 1.4 + (10 / 100) + (-0.2)$$

$$S2 = 1.4 + 0.1 + (-0.2)$$


$$S2 = 1.5 + (-0.2)$$

$$S2 = 1.3$$

NOTE: Replacement shim amount is **1.3 mm (0.051 in)**

Incorrect tooth contact

NOTE: Distance of the pinion from the ring gear centerline must be reduced. (As shown in figures 5 and 6



NHIL12CT00577AA 5

(C) Concave side (Ring Gear)

1. Current starts at the battery, and flows through the positive (+) battery cable to the engine starter motor.
2. From the starter motor, current flows to splice- (2), then through the **80 A** fuse to splice- (5). Splice- (5) sends current in two directions:
 - To splice- (3), then to terminal (B) of the ignition switch.
 - To ring terminal (13) on the un-switched power stud.
3. When the ignition switch is placed in the ACC/RUN position current is transferred across the following ignition switch terminals:
 - (B) to (C) terminals.
4. Current flows from the (C) terminal of the ignition switch to terminal (#86) of the cab power relay.

Un-switched Battery Power Stud

1. The un-switched battery power stud sends current in two directions:
 - Current flows from the un-switched battery power stud to ring terminal (14).
 - Current flows from the un-switched battery power stud to ring terminal (15).
2. Ring terminal (14) sends current in two directions:
 - To fuse (#18), **10 A** fuse. Current flows through fuse (#18) to terminal (#14) of the transmission control unit.
 - To fuse (#16), **10 A** fuse. Current flows through fuse (#16) to terminal (#32) on the ADIC instrument cluster.
3. Ring terminal (15) sends current to terminal (#30) of the cab power relay.

Cab Power Relay

1. When current is provided to terminal (#86) of the cab power relay from terminal (C) of the ignition switch and a ground circuit is completed to the chassis ground from terminal (#85) of the power relay, the cab power relay is energized.
2. When the relay is energized, terminals (#30) and (#87) are latched, providing current to ring terminal (10) of the switched battery power stud.

Switched Battery Power Stud

1. The switched battery power stud sends current in two directions:
 - Current flows from the switched battery power stud to ring terminal (11).
 - Current flows from the switched battery power stud to ring terminal (12).
2. Ring terminal (11) sends current to fuse (#9), **15 A** fuse.
3. Current flows through fuse (#9) to terminal (3) of the transmission control unit.
4. Ring terminal (12) sends current in two directions:
 - To fuse (#3), **20 A** fuse. Current flows through fuse (#3) to terminal (#31) on the ADIC instrument cluster.
 - To fuse (#8), **7.5 A** fuse. Current flows through fuse (#8) to terminal (A) on the PTO activation switch.

PTO Activation Switch


1. When the PTO activation switch is activated (switch pulled up) it sends current from terminal (C) of the activation switch to terminal (#20) of the transmission control unit.

Power Take-Off (PTO) case - Disassemble

Prior operation:


Power Take-Off (PTO) case Cover - Remove (31.114)

1. Remove the seal cover plate, (1), from the rear of the PTO cover, (2), by removing the three M6 x 12mm bolts, (3).



86084263N 1


2. Disengage the PTO using the external PTO lever, (1), and then remove the snap ring and thrust washer, (2) and (3), from the rear PTO output shaft, (4).



86084264N 2

NOTE: When the PTO is disengaged the rear PTO gear, (5), will be able to spin without the PTO output shaft spinning.


3. Remove the bearing, (1), from the rear PTO output shaft, (2), by using a suitable puller, (3).



86084265N 3


NOTE: To aid in disassembly use a suitable heat source to apply heat to the bearing before removing it.

4. Inspect each friction disc, **(1)**, for thickness, damage, or excess wear. Replace if the thickness of the discs is less than **1.675 mm (0.065 in)**.
5. Lay each clutch plate and the clutch backing plate on a plate of glass or other flat surface and inspect them for warpage, excess wear, or damage. Replace as needed.



30000382 4

6. Inspect the clutch brake disc, **(1)**, thickness and replace the brake disc if damaged or if the thickness is less than **5.25 mm (0.20 in)**.
7. Inspect the brake pressure plates for warpage, excess wear, or damage. Replace as needed.
8. Clean and inspect the clutch housing, piston, spring, and distribution block for excess wear or damage. Replace the clutch assembly if any of these are found to be damaged or show excess wear.



30000381 5


Central Power Take-Off (PTO) - Disassemble

Prior operation:

Central Power Take-Off (PTO) - Remove (31.120)


Disassembly

1. Place the mid PTO shaft, (1), into a vice.
2. Remove the snap ring, (2), from the mid PTO cover, (3).
3. Remove the mid PTO shaft, (1), from the vise then use a dead blow hammer to remove the mid PTO shaft from the mid PTO cover, (3).
4. Use a seal removal tool to remove the oil seal from the mid PTO cover, (3).




86084250N 1

5. Remove the snap ring, (1), and thrust washer, (2), from the mid PTO shaft, (3).



36084251N 2

6. To remove the bearing, (1), from the mid PTO shaft, (2), place a bearing splitter, under the bearing, (1), and place the mid PTO shaft, (2), in a hydraulic press with the splined end of the shaft facing up.



86084252N 3

NOTE: The bearing splitter (3) will rest on the press plates on the hydraulic press.

7. Carefully press the mid PTO shaft, (2), down through the bearing, (1).

Contents

Brakes and controls - 33

Mechanical service brakes - 120

TECHNICAL DATA

Mechanical service brakes	
General specification	3


FUNCTIONAL DATA

Mechanical service brakes	
Static description	4

SERVICE

Mechanical service brakes	
Remove	6
Inspect	12
Assemble and Install	14
Adjust	21
Adjust	23

19. Install the lower lift links, **(1)** and **(2)**, to the rear axle, **(3)**.
20. Install the first lift link, **(1)**, to the rear axle by installing the pin, **(4)**, through the link then secure using the M8 x 16mm bolt and M8 Belleville washer, **(5)**. Torque to **23 N·m (17 lb ft)**.
21. Install the second lift link, **(2)**, to the rear axle by installing the M12 x 70mm bolt, M12 flat washer and M12 lock nut, **(6)**. Torque to **66 N·m (49 lb ft)**
22. Fill the combined transmission, differential and rear axle with clean **NEW HOLLAND AMBRA MULTI G 134™ HYDRAULIC TRANSMISSION OIL**.
23. Reinstall the rear wheels onto the tractor.
24. Jack up the back of the tractor and remove the jack stands from the differential housing, then lower the tractor and remove the jack.




86084297N 17

NOTE: The installation procedure is the same for the left and right axle housings.


Filters

The tractor hydraulic filtration consists of five filters.


1. Suction strainer
2. Hydraulic system pressure filter
3. Steering system pressure filter
4. Transmission control valve filter
5. Gerotor pump filter



NHIL15CT00238AA 3




NHIL12CT00105AA 4



NHIL13CT10509AA 5

Hydraulic systems - Overview Front Remote (Two Spool) Loader Control Valve - Fluid Flow Diagrams



(A) Pump Pressure

(B) Tank

(C) Power Beyond Pressure

(D) Static Pressure

Hydraulic systems - Disassemble Rear Lift External Controls

⚠ WARNING

Avoid injury!


Handle all parts carefully. Do not place your hands or fingers between parts. Use Personal Protective Equipment (PPE) as indicated in this manual, including protective goggles, gloves, and safety footwear.

Failure to comply could result in death or serious injury.

W0208A


NOTE: Lift external control can be disassembled and reassembled only with the lift on a work bench or on a rotary stand.

Proceed as follows:



86083826N 1

1. Remove the hydraulic lift from the transmission housing and place on a work bench or fix on a rotary stand.
2. Remove the position control lever.
3. Remove the M9 Allen screw, (1) , and remove the position control lever stop plate, (2).
4. Remove two M8 bolts, (3) , and lock washers, (4) , and remove position control lever hub, (5) , along with nylon washer, (6).



86083827N 2

Hydraulic systems - Remove Control Valve

⚠ WARNING

Avoid injury!

Handle all parts carefully. Do not place your hands or fingers between parts. Use Personal Protective Equipment (PPE) as indicated in this manual, including protective goggles, gloves, and safety footwear.

Failure to comply could result in death or serious injury.

W0208A

⚠ WARNING

Pressurized system!

Before disconnecting the couplers, you must:

- lower the connected attachments,
- stop the engine,
- move the control levers forward and backward to discharge pressure from the hydraulic system.


Failure to comply could result in death or serious injury.

W0389A

Removal


Lower the 3-point hitch to the ground to relieve any hydraulic pressure in the valve.

1. Remove the two mounting bolts, **(1)** securing the valve assembly, **(2)** to the front of the hydraulic lift cover.
2. Remove the valve assembly from the lift cover.



36090162N 1

3. Remove three Allen bolts **(3)**, separate valve body.
4. Inspect the three O-rings, **(4)** on the valve body, replace if damaged.



86071997 2

NOTE: The control valve spool components are not serviced separately but the valve could be disassemble and cleaned if in case of oil contamination.


Index

Hydraulic systems - 35

Hydraulic systems - 000

Hydraulic systems - Adjust Control Valve	69
Hydraulic systems - Assemble Control Valve	66
Hydraulic systems - Assemble Rear Lift External Controls	45
Hydraulic systems - Assemble Rear Lift Internal Controls	52
Hydraulic systems - Detailed view - hydraulic lift control valve	17
Hydraulic systems - Disassemble Control Valve	63
Hydraulic systems - Disassemble Rear Lift External Controls	44
Hydraulic systems - Disassemble Rear Lift Internal Controls	47
Hydraulic systems - Disassemble hydraulic system mid mount valve relief valve	77
Hydraulic systems - Disassemble hydraulic system rear remote valve and rear hitch relief valve ..	78
Hydraulic systems - Dynamic description - hydraulic lift control valve operation	18
Hydraulic systems - Dynamic description - hydraulic lift operation	15
Hydraulic systems - General specification	4
Hydraulic systems - Hydraulic schema	11
Hydraulic systems - Install Install Mechanical Lift Assembly	42
Hydraulic systems - Install Lift Arm Shaft	60
Hydraulic systems - Overview Front Remote (Two Spool) Loader Control Valve - Fluid Flow Dia- grams	26
Hydraulic systems - Pressure test - mid mount valve relief valve	73
Hydraulic systems - Pressure test - rear remote and rear hitch relief valve	75
Hydraulic systems - Remove Control Valve	62
Hydraulic systems - Remove Lift Arm Shaft	57
Hydraulic systems - Remove Overhaul Mechanical Lift Assembly	40
Hydraulic systems - Sealing	6
Hydraulic systems - Special tools	6
Hydraulic systems - Static description	7
Hydraulic systems - Static description - hydraulic lift controls	10
Hydraulic systems - Tension adjust Rear lift external controls	46
Hydraulic systems - Torque	5
Hydraulic systems - Troubleshooting	79

13. See **Remote control valve - Adjust - mid mount valve control cables (35.204)** for adjustment of control cables.
14. When cable adjustment is completed, tighten socket head retaining bolts (**17**) and jam nut (**18**).



NHIL15CT01152AA 9

Next operation:

Remote control valve - Adjust - mid mount valve control cables (35.204)

29. Lubricate and install a new seal ring **(10)** and new O-ring **(11)** on the check valve guide **(12)**. Install the check valve guide **(12)** into the valve body.

NOTE: O-ring, **(13)** was installed earlier during valve body and spool assembly.

30. Lubricate and install the wiper ring **(14)** in the valve body.
31. Install the lever control support **(15)** on the valve body. Install the two bolts **(16)** and lock washers to secure the lever control support to the valve body. Tighten securely.

NOTICE: On the four valve face ports **(A)** each port has an O-ring and retaining ring. Only the lower middle port has a third anti-extrusion ring. Make sure all O-rings and retaining rings are in place before installing the valve assembly to the tractor.



PRINTED IN U.S.A.

© 2016 CNH Industrial America LLC.


All rights reserved. No part of the text or illustrations of this publication may be reproduced.

NEW HOLLAND policy is one of continuous improvement and the right to change prices, specification or equipment at any time without notices is reserved.

All data given in this publication is subject to production variations. Dimensions and weight are approximate only and the illustrations do not necessarily show products in standard condition. For exact information about any particular product, please consult your NEW HOLLAND Dealer.


9. Rotate the control valve body and remove the check valve ball **(1)**.

NOTICE: The check ball **(1)**, is located in the deepest bolt hole. Mark the hole after removing the ball.




27856 8

10. Position the control valve body so that the sleeve control shaft trim pin is in a horizontal position.
11. Push the rotating valve inwards, so that the valve, the valve seat sleeve and the thrust bearing can be removed from the control valve body.




24709 9

12. Remove the two thrust washers, the thrust bearing, and the spring retaining ring from the valve seat sleeve.



24710 10

13. Remove the valve sleeve trim pin **(1)**, from the rotating valve assembly.



24711 11

Contents

Steering - 41

Pump - 206

FUNCTIONAL DATA

Power steering pump	
Static description	3

SERVICE

Power steering pump	
Remove	4
Disassemble	5
Assemble	7
Install	9



PRINTED IN U.S.A.

© 2016 CNH Industrial America LLC.

All rights reserved. No part of the text or illustrations of this publication may be reproduced.

NEW HOLLAND policy is one of continuous improvement and the right to change prices, specification or equipment at any time without notices is reserved.

All data given in this publication is subject to production variations. Dimensions and weight are approximate only and the illustrations do not necessarily show products in standard condition. For exact information about any particular product, please consult your NEW HOLLAND Dealer.

Contents

Cab climate control - 50

Air conditioning - 200

TECHNICAL DATA

Air conditioning

General specification - Ambient temperature versus manifold pressure gauge reading 4

General specification - Temperature/pressure Chart 4

Air-conditioning compressor

General specification 5

Special tools 5

FUNCTIONAL DATA

Air conditioning

Dynamic description 6

Dynamic description control panel 10

Component identification 11

Dynamic description flushing A/C system 13

Air-conditioning compressor

Dynamic description Compressor protection switches 16

SERVICE

Air conditioning

Service instruction - Precautionary statements 17

Pressure test Example 1 28

Pressure test Example 2 30

Pressure test Example 3 32

Pressure test Example 4 34

Pressure test - Example 5 36

Pressure test - Example 6 38

Pressure test - Example 7 40

Pressure test - Example 8 42

Pressure test - Example 9 44

Pressure test Example 10 46

Pressure test Example 11 48

Flush A/C system making a dummy Thermal Expansion Valve (TXV) 49

Decontaminating - Complete circuit flushing 51

Equipment that removes refrigerant from a mobile air conditioning system (recovery equipment) may allow you to put the used refrigerant back in the system without first cleaning it to minimize performance. You may also use such conditioning systems. Non-mobile air conditioning systems use refrigerants and contain contaminants that are different from those in mobile air conditioning systems. Recovery equipment may therefore allow the mixing of different types of refrigerants or introduce contaminants that may not be removable by recycling equipment available in the service shop.

If you want to remove, clean and reuse **R134A** refrigerant, you must use a machine that both extracts and recycles refrigerant from mobile air conditioning systems. Dedicate that machine to **R134A** only.

Recycling equipment meeting SAE standards J1990 and J2210 is designed to extract and recycle refrigerants that have been in mobile air conditioning systems only. **R134A** refrigerant that also is used in non-mobile systems may introduce contaminants to the refrigerant that equipment meeting SAE J1990 and J2210 cannot remove. This equipment is not intended for use on non-mobile systems.

Using Extraction Equipment


Extraction equipment is relatively small and easily portable. It is best used if a shop must service vehicles, such as agricultural or off-highway equipment, that cannot easily be brought into the shop. It is also convenient for shops that must deal with a variety of different refrigerant types and exchange recovered refrigerant at some central location.

Always use extraction equipment on those refrigerants for which it was designed. The lubricants, hoses, and seals in this equipment have been designed to work with only one refrigerant.

To help avoid a mix-up of service equipment and refrigerants, equipment hoses designed for use with each refrigerant are easily identifiable. New service hoses used with **R134A** must have a black stripe along the hose length and carry the designation "SAE J2196/R134a" (hoses labeled SAE J 2196" and lacking the black stripe were used for R12.)

If you use extraction equipment and send your recovered refrigerant to a reclamation facility, reclaimed refrigerant you purchase must meet the Air Conditioning and Refrigeration Institute standards of purity (ARI Standard 700-88). This will ensure that the refrigerant you are using not only meets the purity requirements of SAE J1991 (for R12) OR J2099 (for **R134A**), but also that it does not contain incompatible lubricants or other contaminants from non-automotive air conditioning systems.

Air conditioning - Pressure test - Example 6



200900740 1

Symptoms

1. Cooling is insufficient during the hottest part of hot days.
2. The low side pressure reading is normal **20.7 - 207 kPa (3 - 30 psi)**.
3. The high side pressure reading is normal but drops when the low side reading shows a vacuum. Reference pressure-temperature chart: for correct gauge readings.
4. Evaporator air is sufficiently cold until the low side pressure gauge shows a vacuum; then it becomes warm.

DIAGNOSIS: Excessive moisture is in system. Drying agent in receiver/drier is saturated and releases moisture during high outside air temperatures. This moisture collects and freezes in the expansion valve, preventing a flow of refrigerant through the evaporator.

Corrective Procedures

1. Extract the refrigerant from the system.
2. Replace the receiver/dryer.
3. Evacuate the system.
4. Charge the system.
5. Performance test the system.

NOTE: Test procedure based upon ambient temperature of **35 °C (95 °F)**. For proper high side gauge reading for other ambient temperatures, refer to the pressure-temperature chart.

Ambient Temperature* °C (°F)	High Pressure Gauge Reading kPa (psi)
21 °C (70 °F)	786 - 924 kPa (114 - 134 psi)
24 °C (75 °F)	869 - 1007 kPa (126 - 146 psi)
26 °C (80 °F)	972 - 1110 kPa (141 - 161 psi)
29.5 °C (85 °F)	1096 - 1234 kPa (159 - 179 psi)
32 °C (90 °F)	1158 - 1296 kPa (168 - 188 psi)
35 °C (95 °F)	1248 - 1386 kPa (181 - 201 psi)
38 °C (100 °F)	1386 - 1524 kPa (201 - 221 psi)
40.5 °C (105 °F)	1503 - 1641 kPa (218 - 238 psi)
43 °C (110 °F)	1696 - 1834 kPa (246 - 266 psi)


Air conditioning - Decontaminating - Component flushing

Prior operation:


Air conditioning - Service instruction - Evacuating the Refrigerant (50.200)

NOTE: The power flush unit uses shop air to atomize the flushing solvent and a pulsing action to scrub residue and contaminants out of components.

1. Attach flushing adapters to the component to be flushed. The condenser (1) or the compressor (2). These adapters can be shop built or a universal A/C flushing fitting set is available.




RCPH07CCH027AAC 1



NHIL15CT01136AA 2


2. Fill the flushing reservoir three-quarter full with approved flushing solvent. Do not overfill the reservoir or you will restrict the pulsing action of the unit.



RCPH07CCH265ABC 3


Air conditioning - Remove - HVAC Controls

1. Remove the six screws, (1), securing the HVAC panel to the roof.




86064000N 1

2. Remove the knob, (1), to switch being replaced by prying/pulling it outward.
3. Remove the nut, (2), securing the switch, (3), to the cover.




66064012N 2

Air-conditioning compressor - Install




NHIL16CT00067FA 1

1. Install the compressor (1) onto the compressor mount plate (2) using four M8 x 25 flange head bolts (3).
2. Install the high pressure line (4) and low pressure line (5) onto the compressor.
3. Connect the clutch wiring connector (6).
4. Install belt (7).



NHIL16CT00063AA 2

5. Adjust belt tension by moving adjuster pulley (8) upwards. Tighten pulley bolt (9) when proper belt tension is obtained.
 - Belt Deflection Force - **25 N (6 lb)**
 - Belt Deflection - **7 mm (0.28 in)**



NHIL16CT00064AA 3



PRINTED IN U.S.A.

© 2016 CNH Industrial America LLC.

All rights reserved. No part of the text or illustrations of this publication may be reproduced.

NEW HOLLAND policy is one of continuous improvement and the right to change prices, specification or equipment at any time without notices is reserved.

All data given in this publication is subject to production variations. Dimensions and weight are approximate only and the illustrations do not necessarily show products in standard condition. For exact information about any particular product, please consult your NEW HOLLAND Dealer.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.


CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Electrical system - Static description Reactivity / Response switch

The reactivity / response switch (2) is a two-position rocker switch located on the left control pod. This switch allows the selection between the high or low range of response settings.

The two positions of the reactivity switch are:


- **HIGH POSITION** - The high response range, which corresponds to faster acceleration and deceleration of the tractor, is activated by pressing the double arrow portion of the switch forward which will illuminate the light inside the switch.
- **LOW POSITION** - The low response range, which corresponds to slower acceleration and deceleration of the tractor, is activated by pressing the single arrow portion of the switch rearward which will illuminate the light inside the switch.



86083737 1


Electrical system - Test Stalk Switch

1. Disconnect the negative (-) battery cable from the negative (-) battery terminal.
2. Tilt the steering column forward
3. Remove the fastener, (1), and then remove the fuse panel, (2)
4. Remove the four retaining screws, (3), from the left side panel, (4), and then remove the panel.



76085891N 1


5. Unplug the connector, (1), that goes to the stalk switch from the wire harness connector.



86085897N 2

6. Use an ohmmeter to test each position of the stalk switch for electrical continuity.

NOTE: To get accurate test readings use an analog ohmmeter.



86085899N 3


Switch Function	Continuity of Terminal No.
Horn	(1) and (8)
High Beam	(2) and (4)
Low Beam	(4) and (7), (4) and (9)
Position Lights	(4) and (9)
Left Turn	(3) and (5)
Right Turn	(5) and (6)

Electrical system - Remove Enter / Home Switch

Prior operation:

Electrical system - Static description - Scroll Up/Down switch (55.000)

1. Disconnect the negative (-) battery cable from the negative (-) battery terminal.
2. To remove the program select switch, **(1)**, from the dash panel. Use a flat tip screwdriver to pry the switch out of the dash panel.
3. Once the switch is removed from the dash panel, unplug the wire harness connector from the program select switch.



86084088NN 1

Next operation:


Electrical system - Test Enter / Home Switch (55.000)

Electrical system - Install 2WD/4WD Select Switch

Prior operation:

Electrical system - Test 2WD/4WD Select Switch (55.000)

1. Plug the wire harness connector back into the 2WD/4WD select switch.
2. Push the switch **(1)** back into the control pod opening.
3. Reconnect the negative (-) battery cable to the negative (-) battery terminal.



86083737N 1


Electrical system - Remove Seat Safety Switch

Prior operation:

Electrical system - Static description Seat safety switch (55.000)

NOTE: The seat safety switch may be tested by removing the switch harness from the switch and placing ohmmeter test leads on the switch terminals. Push down on the middle of the seat to check for switch continuity. However, it is recommended to remove the seat switch from the seat for testing.

1. Tilt the seat forward to reveal the seat safety switch **(1)**.
2. Disconnect the seat switch harness from the switch.
3. Rotate the switch counterclockwise to release the locking tabs and remove the switch from the seat.



20054397N 1

Next operation:

Electrical system - Test Seat Safety Switch (55.000)

Test 3 – Test 2 is used to verify that the control module is functioning properly when the right turn signal is activated. This test simulates the turn signal switch being turned to the “Right” position.

1. Connect a jumper wire to terminal **(10)** of the control module and to the positive (+) terminal of a test light. This test light will simulate the left taillight (red). Connect a jumper wire to the (-) negative terminal of the test light and to the negative (-) terminal of the power source.
2. Connect a jumper wire to terminal **(11)** of the control module and to the positive (+) terminal of a test light. This test light will simulate the right taillight (red). Connect a jumper wire to the (-) negative terminal of the test light and to the negative (-) terminal of the power source.
3. Connect a jumper wire to terminal **(4)** of the control module and to the positive (+) terminal of a test light. This test light will simulate the right flasher (amber). Connect a jumper wire to the (-) negative terminal of the test light and to the negative (-) terminal of the power source.
4. Connect a jumper wire to terminal **(3)** of the control module and to the positive (+) terminal of a test light. This test light will simulate the left flasher (amber). Connect a jumper wire to the (-) negative terminal of the test light and to the negative (-) terminal of the power source.
5. Connect a jumper wire to the positive (+) terminal of the power source and the switch.
6. Connect a jumper wire to the switch and terminal **(7)** on the control module.
7. Connect a jumper wire to the positive (+) terminal of the power source and to terminal **(1)** of the control module.
8. Connect a jumper wire to the negative (-) terminal of the power source and to terminal **(6)** of the control module.
9. Switch the switch to the “On” position, observe the two test lights. The right flasher and the right taillight should both flash on and off while the left flasher and left taillight remain lit (solid).

Electrical system - Troubleshooting - Front work lights circuit

Problem	Possible Cause	Correction
Front work lamps will not illuminate or are dim	Insufficient battery charge	Test battery. Charge, add water, or replace as necessary
	Faulty power relay	Test relay and replace as necessary
	Work lamp bulb faulty	Check and replace bulb as necessary
	Blown 80 A main fuse	Inspect main fuse and replace as necessary
	Blown No. 6, 25 A fuse	Replace fuse as necessary.
	Faulty work light switch	Test light switch and replace as necessary.
	Faulty work light relay	Test relay and replace as necessary
	Improper connection at work lamp terminals or headlight socket	Check connections and lamp socket. Repair or replace as necessary.
Improper ground connection	Check ground connections and repair as necessary.	

Electrical system - Troubleshooting - Cab work lights circuit

Problem	Possible Cause	Correction
Cab work lights will not illuminate	Ignition switch not in the "ON" position	Place ignition switch in the "ON" position
	Faulty power relay	Test relay, replace if necessary
	Blown No. 6, 25 A fuse	Replace 25 A fuse
	Faulty cab work light switch	Check switch, replace if necessary.
	Faulty ground connection	Check ground circuit, correct if necessary
	Faulty light bulb	Replace bulb

Electrical system - Troubleshooting - Interior cab lights circuit

Problem	Possible Cause	Correction
Dome light will not illuminate	Blown No. 18, 10 A fuse	Replace 10 A fuse
	Blown No. 22, 2 A fuse	Replace 2 A fuse
	Faulty dome light switch	Check dome light switch, replace dome light assembly, if necessary.
	Faulty dome light bulb	Replace bulb
Dome light will not go out when doors are closed	Faulty door switch or misadjusted striker plate.	Test switches or adjust striker plates to actuate switch when doors are closed.

Electrical system - Troubleshooting - Hazard flasher circuit

Problem	Possible Cause	Correction
Hazard Signal Lights will not illuminate or flash	Blown No. 20, 20 A hazard signal fuse	Inspect fuse and replace as necessary
	Hazard signal bulb(s) burnt out	Inspect bulb(s) and replace as necessary
	Defective hazard switch	Test switch and replace as necessary
	Defective flasher cutoff relay	Test flasher relay by using a known functioning flasher relay and replace as necessary
	Defective hazard/turn flasher module	Test module and replace as necessary
	Faulty wiring or ground connection	Inspect the tractor's wiring harness and ground terminals for damage, corrosion, and short circuits. Repair or replace as needed
Instrument panel hazard indicator(s) does not illuminate	Blown No. 16 10 A fuse	Inspect fuse and replace as necessary

Contents

Electrical systems - 55

Harnesses and connectors - 100

FUNCTIONAL DATA

Wiring harnesses

Electrical schematic sheet 01 – Blank (*)	5
Electrical schematic sheet 02 – Blank (*)	6
Electrical schematic sheet 03 – Power distribution (*)	8
Electrical schematic sheet 04 – Starting and charging system (*)	10
Electrical schematic sheet 05 – Engine Control Unit (ECU) - vehicle side (*)	12
Electrical schematic sheet 06 – Engine Control Unit (ECU) - engine side (*)	14
Electrical schematic sheet 07 – Forward Neutral and Reverse (FNR) assembly, throttle control, Power Take-Off (PTO) and brake control (*)	16
Electrical schematic sheet 08 – Transmission control switches (*)	18
Electrical schematic sheet 09 – Transmission sensors (*)	20
Electrical schematic sheet 10 – Transmission controller (*)	22
Electrical schematic sheet 11 – Analog Digital Instrument Cluster (ADIC) (*)	24
Electrical schematic sheet 12 – Lighting (*)	26
Electrical schematic sheet 13 – Warning lights (*)	28
Electrical schematic sheet 14 – Grounds (*)	30
Electrical schematic sheet 01 – Blank (*)	33
Electrical schematic sheet 02 – Blank (*)	34
Electrical schematic sheet 03 – Power distribution (*)	36
Electrical schematic sheet 04 – Starting and charging systems (*)	38
Electrical schematic sheet 05 – Engine Control Unit (ECU) - vehicle side (*)	40
Electrical schematic sheet 06 – Engine Control Unit (ECU) - engine side (*)	42
Electrical schematic sheet 07 – Forward, Neutral and Reverse (FNR) assembly, throttle control, Power Take-Off (PTO) and brake control (*)	44
Electrical schematic sheet 08 – Transmission control switches (*)	46
Electrical schematic sheet 09 – Transmission sensors (*)	48
Electrical schematic sheet 10 – Transmission controller (*)	50
Electrical schematic sheet 11 – Analog Digital Instrument Cluster (ADIC) (*)	52
Electrical schematic sheet 12 – Lighting control (*)	54
Electrical schematic sheet 13 – Lighting (*)	56
Electrical schematic sheet 14 – Warning lights (*)	58

(*) See content for specific models

Wiring harnesses - Electrical schematic sheet 09 – Transmission sensors

Boomer™ 46D CVT Boomer 46D, CVT, TIER 4B (FINAL), ROPS	NA --- NA
Boomer™ 54D CVT Boomer 54D, CVT, TIER 4B (FINAL), ROPS	NA --- NA

Type	Component	Connector / Link	Description
Sensor	B-011	X-020 X-072	OIL PRESSURE SWITCH
Sensor	B-012	X-070	INPUT SPEED SENSOR
Sensor	B-013	X-071	OUTPUT SPEED SENSOR
Sensor	B-014	X-088	OUTPUT PULLEY PRESSURE SENSOR
Sensor	B-015	X-087	INPUT PULLEY PRESSURE SENSOR
Sensor	B-016	X-075	TORQUE PRESSURE SENSOR
Sensor	B-017	X-074	OIL TEMPERATURE SENDER
Connector	X-020	X-020	SW B+
Connector	X-070	X-070	INPUT SPEED SENSOR
Connector	X-071	X-071	OUTPUT SPEED SENSOR
Connector	X-072	X-072	OIL PRESSURE SWITCH
Connector	X-074	X-074	OIL TEMPERATURE SENDER
Connector	X-075	X-075	TORQUE PRESSURE SENSOR
Connector	X-087	X-087	INPUT PULLEY PRESSURE SENSOR
Connector	X-088	X-088	OUTPUT PULLEY PRESSURE SENSOR

Wiring harnesses - Electrical schematic sheet 04 – Starting and charging systems

Boomer™ 46D CVT Boomer 46D, CVT, TIER 4B (FINAL), Cab	NA --- NA
Boomer™ 54D CVT Boomer 54D, CVT, TIER 4B (FINAL), Cab	NA --- NA


Type	Component	Connector / Link	Description
ECU	A-004	X-041	GLOW PLUG CONTROL UNIT
ECU	A-050A	X-050A	RELAY BLOCK 1
Voltage source	G-001	BT-001BBT-001A	BATTERY
Voltage source	G-002	RT-5RT-7	ALTERNATOR
Ground	GND-001	GND-001	GROUND
Relay	K-001		NEUTRAL START RELAY
Relay	K-013	X-010	CRANK RELAY
Relay	K-014	X-013	FUEL HEATER CUTOFF RELAY
Relay	K-020	X-150	ENGINE CONTROL UNIT (ECU) START RELAY
Motor	M-001	RT-3RT-4	STARTER MOTOR
Resistor	R-001	X-176	GLOW PLUG 1
Resistor	R-002	X-175	GLOW PLUG 2
Resistor	R-003	X-174	GLOW PLUG 3
Switch	S-001		IGNITION SWITCH
Connector	X-009	X-009	IGNITION SWITCH
Connector	X-010	X-010	CRANK RELAY
Connector	X-013	X-013	FUEL HEATER CUTOFF
Connector	X-041	X-041	GLOW PLUG CONTROL UNIT
Connector	X-050A	X-050A	RELAY BLOCK
Connector	X-150	X-150	ENGINE CONTROL UNIT (ECU) START RELAY
Connector	X-158	X-158	ENGINE CONTROL UNIT (ECU) - VEHICLE
Connector	X-172	X-172	FUEL FILTER HEATER
Connector	X-174	X-174	GLOW PLUG 1
Connector	X-175	X-175	GLOW PLUG 2
Connector	X-176	X-176	GLOW PLUG 3
Connector	X-2P	X-2P	MAIN - CHASSIS POWER
Connector	X-2R	X-2R	CHASSIS - MAIN POWER
Connector	X-43P	X-43P	MAIN TO PANEL SIGNAL
Connector	X-43R	X-43R	PANEL - MAIN POWER
Connector	X-44P	X-44P	CHASSIS - PANEL SIGNAL
Connector	X-44R	X-44R	PANEL - CHASSIS SIGNAL
Connector	X-5P	X-5P	MAIN - JUMPER GLOW PLUG
Connector	X-5R	X-5R	JUMPER GLOW PLUG - MAIN
Sub-Assembly	Z-003	X-172	FUEL FILTER HEATER

Wiring harnesses - Electrical schematic sheet 13 – Lighting

Boomer™ 46D CVT Boomer 46D, CVT, TIER 4B (FINAL), Cab	NA --- NA
Boomer™ 54D CVT Boomer 54D, CVT, TIER 4B (FINAL), Cab	NA --- NA

Type	Component	Connector / Link	Description
Lamp	E-001	X-036 X-038	RIGHT-HAND (RH) HEAD LIGHT
Lamp	E-002	X-037 X-039	LEFT-HAND (LH) HEAD LIGHT
Lamp	E-005	X-082	LEFT-HAND (LH) FRONT WORK LIGHT
Lamp	E-006	X-083	RIGHT-HAND (RH) FRONT WORK LIGHT
Lamp	E-007	X-123	LEFT-HAND (LH) REAR WORK LIGHT
Lamp	E-008	X-124	RIGHT-HAND (RH) REAR WORK LIGHT
Lamp	E-009	X-100 X-101 X-102	DOME LIGHT
Ground	GND-002	GND-002	MAIN GROUND
Switch	S-021	X-121	WORK LIGHT SWITCH
Switch	S-022	X-104 X-117	LEFT-HAND (LH) DOOR SWITCH
Switch	S-023	X-103 X-116	RIGHT-HAND (RH) DOOR SWITCH
Connector	X-036	X-036	RIGHT-HAND (RH) HEAD LIGHT
Connector	X-037	X-037	LEFT-HAND (LH) HEAD LIGHT
Connector	X-038	X-038	RIGHT-HAND (RH) FRONT WORK LIGHT
Connector	X-039	X-039	LEFT-HAND (LH) FRONT WORK LIGHT
Connector	X-082	X-082	LEFT-HAND (LH) FRONT WORK LIGHT
Connector	X-083	X-083	RIGHT-HAND (RH) FRONT WORK LIGHT
Connector	X-100	X-100	DOOR SWITCH UNSWITCHED BATTERY POSITIVE (B+)
Connector	X-101	X-101	DOOR SWITCH
Connector	X-102	X-102	DOME LIGHT/GROUND
Connector	X-103	X-103	RIGHT-HAND (RH) DOOR SWITCH
Connector	X-104	X-104	LEFT-HAND (LH) DOOR SWITCH
Connector	X-116	X-116	GROUND
Connector	X-117	X-117	GROUND
Connector	X-121	X-121	WORK LIGHT SWITCH
Connector	X-123	X-123	LEFT-HAND (LH) REAR WORK LIGHT
Connector	X-124	X-124	RIGHT-HAND (RH) REAR WORK LIGHT
Connector	X-4P	X-4P	HOOD - MAIN
Connector	X-4R	X-4R	MAIN - HOOD


Cab Signal Connector C44P Identification and Function (C44P-C44R)



76086721N 3

Terminal No.(Wire Code)	Circuit	Terminal No.(Wire Code)	Circuit	Terminal No.(Wire Code)	Circuit
(1) (HM1 V)	Neutral Start Relay	(17) (HM112 BW)	Ground	(33) (HM33 BW)	Splice 11 to Ground
(2) (HM2 W)	Neutral Start Relay	(18)	N/A	(34) (HM34 DB)	Tail-License Lights
(3) (HM3 O)	Power Relay	(19)	N/A	(35) (HM35 DB)	Low Beam Relay
(4) (HM4 LG)	Front Wiper	(20) (HM20 DB)	Brake Switch	(36) (HM36 DB)	High Beam Relay
(5)	N/A	(21) (HM56 BW)	Engine Coolant Temperature	(37) (HM37 DB)	Hazard FlasherModule
(6) (HM6 O)	Front Wiper	(22) (HM54 Y)	Alternator	(38) (HM38 DB)	Hazard FlasherModule
(7) (HM7 LG)	Front Wiper	(23) (HM23 W)	Park Brake Switch	(39) (HM39 DB)	Work Light Relay
(8) (HM8 DB)	RH Warning Light	(24) (HM24 DB)	Splice 24 to RHWarning Lights	(40) (HM40 DB)	Splice 23-HazardLights
(9) (HM9 T)	Transmis-sionController	(25)	N/A	(41)	N/A
(10) (HM10 DB)	LH Warning Light	(26)	N/A	(42)	N/A
(11) (HM11 V)	F / R Shuttle	(27) (HM27 V)	2WD/4WD Switch	(43) (HM43 B)	Ground
(12) (HM12 V)	F / R Shuttle	(28) (HM28 DB)	Brake Pedal SignalTo Trans. Controller	(44) (HM42 G)	Diagnos-ticConnector
(13) (HM90 Y)	Engine OilPressure Switch	(29) (HM29 Y)	Can HI	(45)	N/A
(14) (HM93 Y)	Engine CoolantTemperature	(30) (HM30 DG)	Can LOW	(46)	N/A
(15) (HM22 Y)	Fuel Level Sender	(31) (HM31 W)	ADIC Opera-torPresence	(47) (HM12 O)	Horn
(16) (HM16 DB)	Head Lights	(32) (HM32 Y)	ADIC Rear PTOSpeed		

X-041 - GLOW PLUG CONTROL UNIT [A-004] (84356962) (Female)




84356962 3

84356962

Pin	From	Wire	Description	Color-Size	Frame
1	X-5P-Female-P-C	HM065	GLOW PLUG 3 BATTERY POSITIVE (B+)	OR - 1.0	SHEET 04
2	X-5P-Female-P-A	HM062	GLOW PLUG 1 BATTERY POSITIVE (B+)	OR - 1.0	
3	X-158 pin 22 ENGINE CONTROL UNIT (ECU) - VEHICLE CONNECTOR	HM053	GLOW PLUG UNIT DIAGNOSTIC FEEDBACK	YE - 0.8	
4	SP-003-P-X	HM101D	UNSWITCHED BATTERY POSITIVE (B+)	RD - 8.0	
5	SP-044-P-X	HM073	GLOW PLUG UNIT 31	BL - 3.0	
7	X-5P-Female-P-B	HM063	GLOW PLUG 2 BATTERY POSITIVE (B+)	OR - 1.0	
8	X-158 pin 52 ENGINE CONTROL UNIT (ECU) - VEHICLE CONNECTOR	HM052	GLOW PLUG UNIT CONTROL	YE - 0.8	

X-042 - DIAGNOSTIC CONNECTOR (Male)




87516075 4

87516075

Pin	From	Wire	Description	Color-Size	Frame
A	GND-003C-P-1 GROUND	HC202	GROUND	BK - 0.8	SHEET 11
B	X-076 (Female) pin D05 FUSE BLOCK	HC204	UNSWITCHED BATTERY POSITIVE (B+)	RD - 0.8	
C	SP-013-P-X	HC019B	CONTROLLER AREA NETWORK (CAN) HI	YE - 0.8	
D	SP-014-P-X	HC020B	CONTROLLER AREA NETWORK (CAN) LO	GN - 0.8	
G	X-2R (Male) pin 21 CHASSIS - MAIN POWER	HC021	SERVICE SWITCH	GY - 0.8	
H	X-2R pin 34 CHASSIS - MAIN POWER	HC034		GY - 0.8	


X-077 - POWER RELAY [K-016] (87699186) (Female)



87699186 7
87699186

Pin	From	Wire	Description	Color-Size	Frame
30	RT-15-P-1 UNSWITCHED BATTERY POSITIVE (B+)	HC139	UNSWITCHED BATTERY POSITIVE (B+)	RD - 8.0	SHEET 03
85	GND-003B-P-1 GROUND	HC138	GROUND	BK - 0.8	
86	X-2R pin 2 CHASSIS - MAIN POWER	HC002	SWITCHED BATTERY POSITIVE (B+)	OR - 0.8	
87	RT-10-P-1 SWITCHED BATTERY POSITIVE (B+)	HC137	SWITCHED BATTERY POSITIVE (B+)	OR - 8.0	


X-078 - FOUR-WHEEL DRIVE (4WD) SOLENOID [Y-004] (82012083) (Female)



82012083 8
82012083

Pin	From	Wire	Description	Color-Size	Frame
1	X-050A (Female) pin D3 RELAY BLOCK	HC209	FOUR-WHEEL DRIVE (4WD)SOLENOID	WH - 0.8	SHEET 08
2	GND-003C-P-1 GROUND	HC045	GROUND	BK - 0.8	


X-167 - FUEL INJECTOR 1 [Y-001] (87709793) (Female)



87709793 7
87709793

Pin	From	Wire	Description	Color-Size	Frame
1	X-159 (Female) pin 16 ENGINE CONTROL UNIT (ECU) - ENGINE	HE019	INJECTOR 1 SIGNAL	WH - 1.5	SHEET 06
2	X-159 (Female) pin 32 ENGINE CONTROL UNIT (ECU) - ENGINE	HE020	INJECTOR 1 RETURN	BL - 1.5	

X-168 - FUEL INJECTOR 2 [Y-002] (87709793) (Female)




87709793 8
87709793

Pin	From	Wire	Description	Color-Size	Frame
1	X-159 (Female) pin 17 ENGINE CONTROL UNIT (ECU) - ENGINE	HE021	INJECTOR 2 SIGNAL	WH - 1.5	SHEET 06
2	X-159 (Female) pin 48 ENGINE CONTROL UNIT (ECU) - ENGINE	HE022	INJECTOR 2 RETURN	BL - 1.5	

Wire connectors - Component diagram 04 – Connectors X-040 to X-049

Boomer™ 46D CVT Boomer 46D, CVT, TIER 4B (FINAL), Cab	NA --- NA
Boomer™ 54D CVT Boomer 54D, CVT, TIER 4B (FINAL), Cab	NA --- NA


X-040A - HORN BATTERY POSITIVE (B+) [H-001] (84120013) (Female)



84120013 1
84120013

Pin	From	Wire	Description	Color-Size	Frame
1	X-43P-Female-P-9	HM128	HORN BATTERY POSITIVE (B+)	OR - 0.8	SHEET 12

X-040B - HORN GROUND [H-001] (84120017) (Female)




84120017 2
84120017

Pin	From	Wire	Description	Color-Size	Frame
1	GND-002-Male-P-1 MAIN GROUND	HM129	HORN GROUND	BK - 0.8	SHEET 12

Pin	From	Wire	Description	Color-Size	Frame
1	SP-017-P-X	HC014C	SENSOR GROUND	BL - 0.8	SHEET 09
2	SP-016-P-X	HC105D	5V REFERENCE	PK - 0.8	
3	X-061 pin 17 TRANSMISSION CONTROLLER	HC121	TORQUE PRESSURE	YE - 0.8	


X-076 - FUSE BLOCK (87705026) (Female)



87705026 6
87705026

Pin	From	Wire	Description	Color-Size	Frame
2	X-121 (Female) pin 5 WORK LIGHT SWITCH	HR060	SWITCHED BATTERY POSITIVE (B+)	OR - 2.0	SHEET 13
2	X-091 (Female) pin 6B CAB ROOF FUSE BLOCK	HR012	SWITCHED BATTERY POSITIVE (B+)	OR - 2.0	
3	X-083 (Female) pin B RIGHT-HAND (RH) FRONT WORK LIGHT	HR057	RIGHT-HAND (RH) FRONT WORK LIGHT	VT - 1.0	
3	X-082 (Female) pin B LEFT-HAND (LH) FRONT WORK LIGHT	HR056	LEFT-HAND (LH) FRONT WORK LIGHT	VT - 1.0	
5	X-121 (Female) pin 2 WORK LIGHT SWITCH	HR060	SWITCHED BATTERY POSITIVE (B+)	OR - 2.0	
6	X-124 (Female) pin B RIGHT-HAND (RH) REAR WORK LIGHT	HR059	RIGHT-HAND (RH) REAR WORK LIGHT	VT - 1.0	
6	X-123 (Female) pin B LEFT-HAND (LH) REAR WORK LIGHT	HR058	LEFT-HAND (LH) REAR WORK LIGHT	VT - 1.0	
7	SP-038-P-X	HR028E	GROUND	BK - 0.8	

X-122 - HEATING VENTILATION AND AIR CONDITIONING (HVAC) MODE [S-025] (87716755) (Female)




87716755 3

87716755

Pin	From	Wire	Description	Color-Size	Frame
2	X-115 (Male) pin C FAN SWITCH	HR037	SWITCHED BATTERY POSITIVE (B+)	OR - 2.0	SHEET 15
3	X-092 (Female) pin C HEATING VENTILATION AND AIR CONDITIONING (HVAC)	HR038	SWITCHED BATTERY POSITIVE (B+)	OR - 2.0	
7	SP-037-P-X	HR025D	GROUND	BK - 0.8	


X-123 - LEFT-HAND (LH) REAR WORK LIGHT [E-007] (82003123) (Female)



82003123 4

82003123

X-169 - FUEL INJECTOR 3 [Y-003] (87709793) (Female)




87709793 9

87709793

Pin	From	Wire	Description	Color-Size	Frame
1	X-159 (Female) pin 1 ENGINE CONTROL UNIT (ECU) - ENGINE CONNECTOR	HE023	INJECTOR 3 SIGNAL	WH - 1.5	SHEET 06
2	X-159 (Female) pin 31 ENGINE CONTROL UNIT (ECU) - ENGINE CONNECTOR	HE024	INJECTOR 3 RETURN	BL - 1.5	

Wire connectors - Component diagram 11 - Connectors X-9110 to X-9119

Connector X-9113 - Glow-plugs control unit



84356962 1

84356962

CONNECTOR X-9113 - Glow-plugs control unit			
PIN NUMBER	WIRE NUMBER	CIRCUIT REFERENCE	ELECTRICAL SCHEMATIC FRAME
1	VE-9060	High Side Driver (HSD), Glow-plug 3	SHEET 01
2	VE-9058	High Side Driver (HSD), Glow-plug 1	
3	VE-9073	Feedback signal, Engine Control Unit (ECU)	
4	VE-9062	12 V Supply, Battery positive	
5	VE-9074	Reference ground, ECU	
6	-	-	
7	VE-9059	High Side Driver (HSD), Glow-plug 2	SHEET 01
8	VE-9072	Control signal, ECU	

Connector X-9116 - Engine shut-off relay

NOTE: Relays are in product relay panels. See product service manual for pinout image of this connector.

CONNECTOR X-9116 - Engine shut-off relay			
PIN NUMBER	WIRE NUMBER	CIRCUIT REFERENCE	ELECTRICAL SCHEMATIC FRAME
85	VE-9089	Switched battery voltage, Power relay	SHEET 02
86	VE-####	Low side control, Operator safety module	
30	VE-9053	Key switch signal (T50), Engine Control Unit (ECU)	
87A	-	-	
87	VE-9088, VE-9089	Switched battery voltage, Power relay	SHEET 02


Engine starter - Troubleshooting

Problem	Possible Cause	Correction
PINION SHAFT FAILS TO ADVANCE	Wiring: Open circuit battery, and switch terminal connections.	Repair or replace
	Wiring: Open circuit, fuse	Replace fuse
	Key switch: No contact	Repair or replace
	Starter motor: Sleeve bearing burnt out	Repair or replace
	Starter motor: Lever broken	Replace
	Solenoid: Plunger movement defective or coil open or shorted	Repair or replace
PINION MOTOR ROTATES BUT NO ROTATION TRANSMITTED TO ENGINE	Starting motor: Clutch defective	Replace
	Starting motor: Orbital gear or planetary gears damaged	Replace
MOTOR ROTATES BEFORE PINION MESHES WITH RING GEAR	Starter motor: Shift lever damaged	Replace
	Starter motor: :Shift lever damaged	Replace
	Starter motor: Slip ring defective	Replace
	Starter motor: Pinion teeth worn	Replace
	Starter motor: Pinion push out position defective	Adjust
	Engine: Ring gear worn	Replace
	Solenoid defective	Replace
PINION MESHES WITH RING GEAR BUT STARTING MOTOR FAILS TO TURN	Wiring: Line connecting solenoid to battery broken or defective ground	Repair or replace
	Wiring: Lead wire connecting solenoid to motor tightened improperly	Repair or replace
	Starting motor: Ball bearing locked	Replace
	Starting motor: Brush worn	Replace
	Starting motor: Improper installation	Reinstall
	Starting motor: Brush spring defective	Replace
	Starting motor: Commutator dirty	Clean
	Starting motor: Armature of field coil defective	Repair or replace
	Starting motor: Field coil-to-brush connection defective	Replace
	Solenoid: Contact not touching properly	Replace
	Solenoid: Contact contacting surface roughened	Replace
	Battery: In discharge state	Recharge or replace
MOTOR FAILS TO STOP AFTER ENGINE STARTS AND KEY SWITCH IS TURNED OFF	Key switch: defective	Replace
	Defective solenoid	Replace

Battery - Remove

1. Release and lift the tractor engine cover.
2. Disconnect the negative (-) battery cable.
3. Disconnect the positive (+) battery cable.
4. Remove the hardware, **(1)**, securing the battery.
5. Carefully remove the battery from the tractor.

NOTICE: Crossing the battery terminals may cause damage to the electrical system




86064532N 1

Next operation:
Battery - Install (55.302)


"On" Position

1. Push the hazard light switch to the ON position.
2. Using an ohmmeter, touch one of the test probes to terminal (2) . Touch the other test probe to terminal (3) .
3. Observe the ohmmeter. The ohmmeter should show little or no resistance indicating that continuity exists between terminal (2) and terminal (3) . If continuity does not exist between terminal (2) and terminal (3), the switch is defective and needs replaced.




36085905N 4

4. Using an ohmmeter, touch one of the test probes to terminal (5) . Touch the other test probe to terminal (6) .
5. Observe the ohmmeter. The ohmmeter should show little or no resistance indicating that continuity exists between terminal (5) and terminal (6) . If continuity does not exist between terminal (5) and terminal (6), the switch is defective and needs replaced.



36085906N 5

6. Using an ohmmeter, touch one of the test probes to terminal (6) . Touch the other test probe to terminal (7) .
7. Observe the ohmmeter. The ohmmeter should show little or no resistance indicating that continuity exists between terminal (6) and terminal (7) . If continuity does not exist between terminal (6) and terminal (7), the internal indicator bulb is defective and needs replaced.




36085904N 6

Next operation:

Turn signal and/or hazard lights - Install - Hazard Lights Switch (55.404)

Tractor Configuration

The machine configuration will determine which HH menus are available for each module. Use "ZF" for the instrument cluster and "SO" to access the electronic transmission control unit.





NHIL16CT00114AA 9

The table below shows which HH menus are enabled for each module. Select the module by pressing the UP / DOWN until the module is displayed on the LCD screen.

Module	Menu													
	HH	H1	H2	H3	H4	H5	H7	H8	H9	HB	HC	HE	HF	
ZF	X			X	X	X		X	X	X	X	X	X	
SO	X	X	X	X	X	X	X	X	X	X	X	X	X	

Electronic Transmission Control Module

The electronic transmission control module "SO" has subsystems on various HH menus. The subsystems available are the continuously variable transmission (CVT) and the Power Take-Off (PTO). These subsystems are only active on some of the HH menus. The table below shows the symbol that will be displayed when each subsystem is displayed and which HH menus are available for the subsystems.

Subsystems		Menu											
Subsystem name	Icon	H1	H2	H3	H4	H5	H7	H8	H9	HB	HC	HE	HF
CVT		X	X		X	X	X	X	X	X	X	X	X
PTO				X						X	X		


Electrical systems - Electronic modules

Diagnostic Trouble Code (DTC)	Failure Description	Suspected Part Number (SPN)	Fault Mode Indicator (FMI)
3137	Fuel metering unit has an open load error	159	2
3141	Fuel pump pressure has exceeded desired pressure limits	158	3
3146	Water in fuel detected or water in fuel circuit failure	11C	3
3176	High pressure pump fuel delivery quantity in over run exceeds a maximum threshold	157	3
3177	Engine over speed condition detected	54C	3
3179	CAN communication failure between vehicle controller and ECU - BC2ECU2 message	2B4	2
3180	CAN communication error between vehicle controller to ECU	1B5	2
3188	Open load error of injector in cylinder 1	167	2
3196	Open load error of injector in cylinder 3	169	2
3200	Open load error of injector in cylinder 2	168	2
3210	Injection bank 1 short circuit failure (all injectors of the same bank can be affected)	171	3
3218	Injection bank 2 short circuit failure (all injectors of the same bank can be affected)	173	3
3230	ECU internal failure - Injector CY33x component	17C	12
3235	Exceeded the number of injections for a given engine speed	17E	3
3236	Number of injections is limited by system	17E	4
3237	Number of desired injections exceeds threshold	17E	2
3238	ECU internal failure	1D1	3
3239	ECU internal failure - EEPROM read error	1D2	4
3240	ECU internal failure - EEPROM write error	1D2	2
3241	ECU internal failure - EEPROM write/read error	1D2	12
3242	ECU internal failure - Software resets in DSM 0	1D3	12
3243	ECU internal failure - Software resets in DSM 1	2D3	12
3245	ECU internal failure - Query/response communication errors	1D4	12
3252	ECU internal failure - SPI communication error	1D8	12
3253	ECU internal failure - Voltage ratio in ADC monitoring	1D9	3
3255	ECU internal failure - ADC test	1D9	2
3256	ECU internal failure - NTP error in ADC monitoring	1D9	12
3258	Starter relay high side driver circuit shorted to battery	1E1	3
3259	Starter relay high side driver circuit shorted to ground	1E1	4
3260	Starter relay low side driver circuit open	2E1	2
3261	Starter relay low side driver circuit shorted to battery	2E1	3
3262	Starter relay low side driver circuit shorted to ground	2E1	4
3265	Fuel injection requested during overrun	1E3	3
3266	ECU internal failure - Calculated engine speed	1E4	3
3283	ECU 5 volt sensor supply 2 out of range	1E7	3
3285	ECU 5 volt sensor supply 3 out of range	1E8	3
3293	Fuel rail pressure has exceeded maximum positive deviation limits	151	3
3301	Fuel rail pressure has exceeded maximum negative deviation limits	153	3
3305	Fuel rail pressure has dropped below the minimum limit	154	3
3309	Fuel rail pressure has exceeded maximum limit	155	3
3334	CAN communication failure between vehicle controller and ECU controller - TSC1_PE message	1C6	3
3335	CAN communication failure between vehicle controller and ECU controller - TSC1_PE message	2C6	2

Electronic modules - H7 - Vehicle test modes


NOTE: For HH menu navigation, refer to *Instrument cluster Analog-Digital Instrument Cluster (ADIC) - Detailed view HH Menus (55.408)*.

1. The H7 menu is used to manually adjust the clutch calibration values for the Forward and Reverse clutches.




NHIL16CT00106AA 1

2. Start the engine with the operator in the seat and set the engine speed between **1700 - 2000 RPM**.
3. Press the ENTER switch (1) again, CAL will appear in the display.




83083755 2



NHIL16CT00113AA 3

4. Use the shuttle lever (2) to select either the Forward or Reverse clutch. After the selection of the clutch, the display will show the specific calibration value currently stored for the selected channel (clutch).



NHIL14CT00738AA 4

DTC 141-02-Crankshaft speed sensor values are not plausible [ECU]	121
DTC 141-04-Crankshaft speed sensor pattern is not plausible [ECU]	123
DTC 143-02-Camshaft speed sensor values are not plausible [ECU]	125
DTC 143-04-Camshaft speed sensor pattern is not plausible [ECU]	127
DTC 144-03-Compared camshaft and crankshaft speed sensor values are not plausible [ECU]	129
DTC 151-03-Fuel rail pressure has exceeded maximum positive deviation limits [ECU]	130
DTC 153-03-Fuel rail pressure has exceeded maximum negative deviation limits [ECU].	131
DTC 153-03-Fuel rail pressure has exceeded maximum negative deviation limits [ECU].	133
DTC 154-03-Fuel rail pressure has dropped below the minimum limit [ECU]	135
DTC 155-03-Fuel rail pressure has exceeded maximum limit [ECU]	136
DTC 155-03-Fuel rail pressure has exceeded maximum limit [ECU]	138
DTC 157-03-High pressure pump fuel delivery quantity in over run exceeds a maximum threshold [ECU]	140
DTC 158-03-Fuel pump pressure has exceeded desired pressure limits [ECU].	141
DTC 159-02-Fuel metering unit has an open load error [ECU]	142
DTC 15D-03-PMCat Inducement less severe derating level [ECU]	144
DTC 161-02-Short circuit error of injector in cylinder 1 [ECU]	145
DTC 161-03-Short circuit of low side to high source of injector in cylinder 1 [ECU]	148
DTC 162-02-Short circuit error of injector in cylinder 2 [ECU]	150
DTC 163-02-Short circuit error of injector in cylinder 3 [ECU]	153
DTC 163-03-Short circuit of low side to high source of injector in cylinder 3 [ECU]	156
DTC 167-02-Open load error of injector in cylinder 1 [ECU].	158
DTC 168-02-Open load error of injector in cylinder 2 [ECU].	160
DTC 169-02-Open load error of injector in cylinder 3 [ECU].	162
DTC 171-03-Injection bank 1 short circuit failure (all injectors of the same bank can be affected) [ECU]	164
DTC 173-03-Injection bank 2 short circuit failure (all injectors of the same bank can be affected) [ECU]	165
DTC 17C-12-ECU internal failure - Injector CY33x component [ECU]	167
DTC 17E-02-Number of desired injections exceeds threshold [ECU].	168
DTC 17E-03-Exceeded the number of injections for a given engine speed [ECU].	169
DTC 17E-12-Number of injections is limited by quantity balance of high pressure pump [ECU]	170
DTC 17E - 04-Injection control : Number of injections is limited by system [ECU].	171
DTC 17F-12-Missing adjustment value programming for injector in cylinder 1 [ECU]	172
DTC 18F-02-Lambda sensor heater power stage open circuit [ECU].	173
DTC 18F-03-Lambda sensor heater power stage short circuit to battery [ECU].	175
DTC 18F-04-Lambda sensor heater power stage short circuit to ground [ECU].	177
DTC 18F-04-Lambda sensor heater power stage short circuit to ground [ECU].	179
DTC 199-02-Turbocharger boost pressure is higher than expected [ECU]	181
DTC 199-02-Turbocharger boost pressure is higher than expected [ECU]	182
DTC 1B1-03-CAN A Bus off failure [ECU]	183
DTC 1B1-04-CAN A Bus off passive failure [ECU].	185
DTC 1B5-02-CAN communication error between vehicle controller to ECU [ECU]	187
DTC 1B7-02-CAN transmit error - EEC1 message (Electronic Engine Control 1 message - Torque, accelerator pedal, engine speed, and other signals) [ECU].	189

With the FNR assembly **Z-001** shuttle lever in the forward position, measure the resistance between the component side of connector:

X-012 (Female) pin 1 and **X-012 (Female) pin 2** should indicate approximately **0.560K Ω**

With the shuttle in reverse position, measure the resistance between the component side of connector:

X-012 (Female) pin 1 and **X-012 (Female) pin 3** should indicate approximately **0.560K Ω**

If resistances are not okay, remove and replace the FNR assembly **Z-001**.

B. If the FNR assembly **Z-001** shuttle lever switch is okay, continue to step **4**

4. Check for a short circuit.

A. Check on the harness side between connector **X-012 (Female) pin 2** and **X-012 (Female) pin 3**. If a short is indicated, repair or replace the harness as required.

B. If a short circuit is not indicated, continue to step **5**

5. Check for a short to "key on" voltage.

A. Turn the ignition switch **S-001** to the ON position. Measure the voltage between connectors:

X-012 (Female) pin 2 and **X-012 (Female) pin 3** and ground.

If a voltage is indicated, repair or replace the harness as required.

B. If the harness is okay, download the correct level of software. If the fault reoccurs, remove and replace the TCU **A-001**.

Wiring harnesses - Electrical schematic sheet 10 (55.100.DP-C.20.E.10)

- E. Press and hold the program set switch **S-016**. The calibration procedure will start (throughout the procedure, the program set switch **S-016** must be kept pressed). The display will show on the three LSB digits the current value in mA growing along the calibration process

R123
.

- F. When the calibration current is reached the display stops and will show the calibration current flashing:

R123
.

- G. Release the program set switch **S-016** switch. The reverse clutch will be automatically selected (or it is possible to select another clutch by pressing the program select switch **S-017**) and it will be possible to calibrate it by pressing and holding the program set switch **S-016**. When the engine is shut off, the calibration value will be stored inside the non-volatile memory of the electronic module.

Note: Transmission output Revolutions Per Minute (RPM), shuttle lever position, program select switch **S-017**, and handbrake are constantly monitored. Calibration cannot proceed unless the tractor is stopped, the shuttle lever is in forward or reverse, the handbrake is engaged and program set switch **S-016** is pressed. If during the calibration process a wrong condition is detected, then a "U" code is displayed on the dot matrix display. Refer to the following list for an explanation of "U" codes:

19 = Transmission oil temperature low (Below **10 °C (50.0 °F)**)

20 = Handbrake is not engaged

21 = Engine Revolutions Per Minute (ERPM) is below 1700; increase throttle

22 = ERPM is above 2000; decreased throttle

23 = Shuttle lever is in neutral; shift it to forward or reverse

31 = Wheel speed sensed; check handbrake and start again

32 = FORWARD clutch cal too low - RPM dropped too soon, clutch pressure is not being controlled properly or something else caused RPM to drop

33 = FORWARD clutch cal too high - RPM did not drop, no pressure to clutch or mechanical failure breaking the torque path

34 = REVERSE clutch cal too low - RPM dropped too soon, clutch pressure is not being controlled properly or something else caused RPM to drop

35 = REVERSE clutch cal too high - RPM did not drop, no pressure to clutch or mechanical failure breaking the torque path.

99 = Unable to calibrate transmission (transmission disabled)

If errors 20, 21, 22, 23, or 31 become active during the calibration procedure, the calibration procedure will restart from the same cycle in which the problem appeared. If the remaining errors become active, the tractor should be shutdown and the procedure started again.

- H. If the error code is still displayed, continue to step 2.

NOTE: In cold or hot transmission oil conditions, it will still be possible to calibrate the clutches, however one of the following messages will appear:

*CL = Cold Oil Warning, displayed below **40 °C (104.0 °F)***

*CH = Hot Oil Warning, displayed above **100 °C (212.0 °F)***

*If the display shows the above messages, it is still possible to calibrate the clutches, just press the program select switch **S-017** for a while and the warning message will disappear.*

.

2. Check for other error codes being displayed.

A. If any other error code is being displayed, continue to these tests.

B. If no other error code is displayed, continue to step 3.

2615-Transmission Torque Pressure Sensor Open Circuit or Shorted to Ground

Control Module : TCU

NOTE: When the cause of the error code has been rectified, clear the error code and test the system for normal operation.

Context:

The Transmission Control Unit (TCU) **A-001** is sensing less than **0.44 V** at connector **X-061 (Female) pin 2** pin J1-7.

Cause:

There is a short to ground or open circuit in the torque pressure sensor **B-016** circuit.

Possible failure modes:

1. Faulty connector
2. Faulty torque pressure sensor **B-016**
3. Faulty harness
4. Faulty TCU **A-001**

Solution:

1. Check the torque pressure sensor connector **X-075** and the TCU connector **X-061**.
 - A. Ensure the connectors are connected, not damaged, the pins are in the correct position and that the fit is tight. Repair or replace as required.
 - B. If the connectors are okay, continue to step 2.
2. Check for correct voltage at TCU connector: Use multi-meter, and a back-probe pin to measure voltage at connector **X-061** pin J1-17 (Y). With the ignition switch **S-001** in the ON position, measure the voltage on the harness side of connector **X-061**, pin J1-17 (Y).
 - A. If the voltage indicated is not between **0.44 V** and **4.59 V**, continue to step 3.
 - B. If the voltage indicated is between **0.44 V** and **4.59 V**, reload correct level of software. If error reoccurs, remove and replace the TCU **A-001**.
3. Check for source voltage and clean ground: Disconnect connector **X-075**. With the ignition switch in the ON position, on the harness side of the connector measure the voltage between connector **X-075** pin 1 (BW) and **X-075** pin 2 (P)
 - A. If **5 V** are indicated, continue to step 4.
 - B. If **0 V** are indicated, continue to step 5.
4. Check for an open circuit or short to ground: Disconnect connectors **X-061** and **X-075**. Check to make sure the harness is continuous and not grounded between **X-075**, pin 3 and connector **X-061**, pin J1-17
 - A. If the harness between connector **X-075**, pin 3 and connector **X-061**, pin J1-17 is broken or grounded, repair or replace.
 - B. If the harness between **X-075**, pin 3 and connector **X-061**, pin J1-17 is not broken or grounded, replace torque pressure sensor **B-016**.
5. Check for 5V to chassis ground: Disconnect connector **X-075**, and test for voltage between pin 2 and chassis ground.
 - A. If **5 V** are indicated between connector **X-075**, pin 2, and chassis ground, repair or replace ground wire.

5080-PTO Clutch Solenoid Excessive Voltage

Control Module : TCU

NOTE: When the cause of the error code has been rectified, clear the error code and test the system for normal operation.

Context:

This fault will occur when the current on the Power Take-Off (PTO) clutch solenoid **Y-010** signal is less than **0.2 A** when driven.

Cause:

There is a short to ground or open circuit in the PTO clutch solenoid or circuit.

Possible failure modes:

1. Faulty connector
2. Faulty PTO clutch solenoid
3. Faulty harness
4. Faulty controller

Solution:

1. Check the PTO clutch solenoid connector **X-068** and the controller connector **X-061**.
 - A. Ensure the connectors are connected, not damaged, the pins are in the correct position and that the fit is tight. Repair or replace as required.
 - B. If the connectors are okay, continue to step 2.
2. Check the PTO clutch solenoid.
 - A. Disconnect connector **X-068**. Measure the resistance between the component side of connector, **X-068** pin 1 and 2. If the resistance indicated is not approximately **9 Ohms** at **20 °C (68.0 °F)**, remove or replace the PTO clutch solenoid.
 - B. If the PTO clutch solenoid is okay, continue to step 3.
3. Check for an open circuit.
 - A. Disconnect connectors **X-061**, and **X-068**. Check between connector:
X-068 pin 1 (V) and **X-061** pin J1-30 (V)
X-068 pin 2 (B) and **X-061** pin J1-6(B)
If an open circuit is indicated, repair or replace the harness as required.
 - B. If an open circuit is not indicated, continue to step 4.
4. Check for a short to ground
 - A. Check between connector: **X-068** pin 1 (V) and pin 2 (B) to chassis ground. If a short to ground is indicated, repair or replace the harness as required.
 - B. If the harness is okay, download the correct level of software. If the fault reoccurs, remove and replace the controller.

Then use the multimeter to perform the following tests, on the vehicle (VE) harness from :

From	To	Value
X-9125 pin 1	X-9125 pin 2	There should be no continuity
X-9125 pin 1	X-9125 pin 3	There should be no continuity
X-9125 pin 2	X-9125 pin 3	There should be no continuity

Then use the multimeter to perform the following tests, on the vehicle (VE) harness from :

From	To	Value
X-9125 pin 1	Chassis ground	There should be no continuity
X-9125 pin 3	Chassis ground	There should be no continuity

- A. If the results are not as expected for any of the wiring tests listed above, there is an open, short or grounded circuit condition in the vehicle harness (VE) wiring. Use the appropriate vehicle service manual and schematics to diagnose and repair the wiring.
- B. If the results are as expected in all of the wiring tests listed above, the wiring is ok. Leave connectors **X-9102** and **X-9125** disconnected and continue with Step 5.
5. Check for key switch voltage supply to water in fuel switch S-9102.

With the key switch in an ON position, use a multimeter to perform the following test, on the vehicle (VE) harness side from :

From	To	Value
X-9125 pin 3	Chassis ground	There should be key switch voltage.
X-9125 pin 1	Chassis ground	There should be no key switch voltage.

- A. If there is key switch voltage present in the first check and not present in the second check, continue with Step 6.
- B. If key switch voltage is not present in the first check or present in the second check, use the appropriate vehicle service manual and schematics to diagnose and repair the wiring.
6. Replace the water in fuel switch S-9102, then check to see if this fault has been resolved.
- A. If the fault is resolved, return the machine to service.
- B. If the fault is not resolved, check the ECU A-9000 for the appropriate software and re-flash, if necessary.
7. Visually inspect the relevant harnesses and connectors for damage, bent or dislocated pins, corroded terminals, or broken wires. Verify that the connectors are fully installed. Flex the harnesses involved to reveal intermittent breaks or shorts in the wiring concerned. Operate the machine while you monitor the display.
- A. If you find damage or the display indicates other than normal readings, then repair the damage discovered during the inspection or locate and repair the other than normal display condition and verify that the error has been resolved.
- B. If you do not find damage and the display indicates only normal readings, then erase the fault code and continue operation.

Wiring harnesses - Electrical schematic sheet 02 – Engine Control Unit (ECU) power and after treatment system (engine schematics) (55.100.DP-C.20.E.02)

4. Check the fuel temperature sensor B-9002 engine harness (EN) wiring for a short to ground condition.

Disconnect the engine harness (EN) from the ECU A-9000 at connector **X-9001**.

With the key in the OFF position use the a multimeter to perform the following continuity checks for a short to ground condition on the engine harness (EN) side :

From	To	Value
X-9005 pin 1	All pins in connector X-9001 .	There should be no continuity.

- A. If the specified values are not measured, there is a fault in the fuel temperature sensor B-9002 engine harness (EN) wiring. Locate and repair the failed conductor.
- B. If there is no continuity, check the ECU A-9000 for the appropriate software and re-flash, if necessary.
5. Visually inspect the relevant harnesses and connectors for damage, bent or dislocated pins, corroded terminals, or broken wires. Verify that the connectors are fully installed. Flex the harnesses involved to reveal intermittent breaks or shorts in the wiring concerned. Operate the machine while you monitor the display.
- A. If you find damage or the display indicates other than normal display readings, then repair the damage discovered during the inspection or locate and repair the other than normal display condition and verify that the error has been resolved.
- B. If you do not find damage and the display indicates only normal readings, then erase the fault code and continue operation.

**Wiring harnesses - Electrical schematic sheet 03 – Engine sensors and fuel injection (engine schematics)
(55.100.DP-C.20.E.03)**

DTC 151-03-Fuel rail pressure has exceeded maximum positive deviation limits

Control Module : ECU

NOTE: If the Pressure Relief Valve (PRV) is replaced, it is necessary to perform the Replacement of the Rail Pressure Relief Valve (PRV) - Reset ECU Data with the Electronic Service Tool (EST) before you return the machine to service. See **Common rail Relief valve - Configure - Reset ECU data (10.218)**, if necessary.

NOTE: If the rail pressure sensor B-9004 is replaced, it is necessary to perform the Replacement of the Rail Pressure sensor - Reset ECU Data with the Electronic Service Tool (EST) before you return the machine to service. See **Common rail pressure sensor - Configure - Reset ECU data (Rail pressure sensor) (55.010)**, if necessary.

Context:

The Engine Control Unit (ECU) A-9000 monitors fuel rail pressure. If the measured rail pressure is lower than the desired pressure by **100 bar (1450 psi)** depending on engine speed, this fault will occur. For more information regarding fuel system troubleshooting, see **Fuel injection system - Troubleshooting (10.218)**.

Cause:

The ECU A-9000 has determined that the measured rail pressure is **100 bar (1450 psi)** lower than desired fuel pressure based on engine speed.

Possible failure modes:

1. Faulty fuel metering unit Y-9000, internal failure.
2. Faulty charge gear pump, low efficiency.
3. Faulty fuel filters, clogged.
4. Faulty low pressure fuel supply lines, clogged or damaged.
5. Faulty high pressure fuel supply lines, clogged or damaged.
6. Faulty Pressure Relief Valve (PRV), leakage.
7. Faulty high pressure fuel pump, low efficiency.
8. Faulty fuel injectors, worn, clogged or internal leakage.
9. Faulty rail pressure sensor B-9004, drifted or leaking.
10. Faulty ECU A-9000, software.

DTC 161-03-Short circuit of low side to high source of injector in cylinder 1

Control Module : ECU

Context:

The Engine Control Unit (ECU) A-9000 monitors the fuel injector power stages for a short circuit condition. If the ECU A-9000 detects a short circuit condition in the injector number 1 Y-9001 circuit, this fault will occur.

Cause:

The ECU A-9000 has detected a short circuit between the high side driver and low side driver of the fuel injector number 1 Y-9001.

Possible failure modes:

1. Faulty fuel injector number 1 Y-9001 wiring, short circuit.
2. Faulty fuel injector number 1 Y-9001, internal failure.
3. Faulty ECU A-9000, software.

Solution:

1. Verify this fault code is still present and in an active state.

Use the Easy Engine software provided on the Electronic Service Tool (EST) to check the fault status and to perform the cylinder cut-out test.

A. If the fault is still present and active, continue with Step 2.

B. If the fault is no longer present or is in an inactive state, the fault may be intermittent and not currently active. Continue with Step 6.

2. Check the fuel injector number 1 Y-9001 internal resistance.

Disconnect the engine harness (EN) from the fuel injector number 1 Y-9001 at connector **X-9030**.

Use a multimeter to measure the resistance of fuel injector number 1 Y-9001 on the injector pins :

From	To	Value
X-9030 pin 1	X-9030 pin 2	There should be between .03 - .05 Ω

A. If there is between **.03 - .05 Ω**, leave connector **X-9030** disconnected and continue to Step 3.

B. If the resistance is not between **.03 - .05 Ω**, fuel injector number 1 Y-9001 solenoid coil has failed. Replace fuel injector number 1 Y-9001.

3. Check the fuel injector number 1 Y-9001 injector harness (INJ) wiring for a short circuit condition.

With the key in the OFF position, use a multimeter to perform the following continuity check on the engine harness (EN) side :

From	To	Value
X-9030 pin 1	X-9030 pin 2	There should be no continuity.

A. If there is no continuity, leave connector **X-9030** disconnected and continue to Step 4.

B. If there is continuity, there is a short circuit in the fuel injector number 1 Y-9001 wiring in the engine harness (EN) wiring. Locate and repair the shorted conductor.

4. Check the fuel injector number 1 Y-9001 vehicle harness (VE) wiring for a short circuit condition.

Disconnect the engine harness (EN) from the ECU A-9000 at connector **X-9001**.

- A. If you find damage or the display indicates other than normal display readings, then repair the damage discovered during the inspection or locate and repair the other than normal display condition and verify that the error has been resolved.
- B. If you do not find damage and the display indicates only normal readings, then erase the fault code and continue operation.

**Wiring harnesses - Electrical schematic sheet 03 – Engine sensors and fuel injection (engine schematics)
(55.100.DP-C.20.E.03)**

4. Determine the condition of the ECU A-9000 CAN circuit.

With the key switch in the OFF position, use a multimeter to measure the resistance of the CAN connection on the vehicle (VE) harness side:

From	To	Value
X-9102 pin K24	X-9102 pin K25	There should be 120 Ω .
X-9102 pin K24	chassis ground	There should be no continuity
X-9102 pin K25	chassis ground	There should be no continuity

Use a multimeter to measure the resistance of the CAN termination resistor, internal to the ECU A-9000:

From	To	Value
X-9102 pin K24	X-9102 pin K25	There should be 120 Ω .

- A. If the measured resistances are correct and neither conductor is grounded, check the ECU A-9000 for the appropriate software and re-flash, if necessary.
 - B. If the measured resistances are not correct or one or both of the conductors is grounded, see the appropriate vehicle service manual and electrical schematics, if necessary, to locate and restore the termination resistance to the CAN circuit.
5. Visually inspect the relevant harnesses and connectors for damage, bent or dislocated pins, corroded terminals, or broken wires. Verify that the connectors are fully installed. Flex the harnesses involved to reveal intermittent breaks or shorts in the wiring concerned. Operate the machine while you monitor the display.
- A. If you find damage or the display indicates other than normal display readings, then repair the damage discovered during the inspection or locate and repair the other than normal display condition and verify that the error has been resolved.
 - B. If you do not find damage and the display indicates only normal readings, then erase the fault code and continue operation.

Wiring harnesses - Electrical schematic sheet 02 – Engine Control Unit (ECU) power and after treatment system (engine schematics) (55.100.DP-C.20.E.02)

DTC 1D8-12-ECU internal failure - SPI communication error

Control Module : ECU

Context:

The Engine Control Unit (ECU) A-9000 monitors the communication between the ECU A-9000 processor and the power stage controller over the SPI bus. If there is an error in the communication, this fault will occur.

Solution:

1. Check the ECU A-9000 for the appropriate software and re-flash, if necessary.
 - A. If the fault has been resolved, return the machine to service.
 - B. If the fault has not been resolved, escalate an ASIST concern.

4. Disconnect the engine harness (EN) from the ECU A-9000 at connector **X-9001**.

Check the following pins listed below on the ECU A-9000 and in connectors **X-9001** and **X-9102**.

Pin	Physical condition
X-9102 pin K17	The pin and connector should be free of corrosion or damage.
X-9102 pin K18	The pin and connector should be free of corrosion or damage.
X-9001 pin A29	The pin and connector should be free of corrosion or damage.

- A. If a pin or connector shows signs of corrosion or damage, repair as necessary.
- B. If a pin or connector shows no signs of corrosion or damage, continue to Step 5.
5. Check the ECU A-9000 for the appropriate software and re-flash, if necessary.
- A. If the fault has been resolved, return the machine to service.
- B. If the fault has not been resolved, escalate an ASIST concern.
6. Visually inspect the relevant harnesses and connectors for damage, bent or dislocated pins, corroded terminals, or broken wires. Verify that the connectors are fully installed. Flex the harnesses involved to reveal intermittent breaks or shorts in the wiring concerned. Operate the machine while you monitor the display.
- A. If you find damage or the display indicates other than normal display readings, Then, repair the damage discovered during the inspection or locate and repair the other than normal display condition and verify that the error has been resolved.
- B. If you do not find damage and the display indicates only normal readings, Then, erase the fault code and continue operation.

Wiring harnesses - Electrical schematic sheet 02 – Engine Control Unit (ECU) power and after treatment system (engine schematics) (55.100.DP-C.20.E.02)

Wiring harnesses - Electrical schematic sheet 03 – Engine sensors and fuel injection (engine schematics) (55.100.DP-C.20.E.03)

A. If there is less than approximately **12 V**, continue to Step 5.

B. If there is approximately **12 V**, check the ECU A-9000 for the appropriate software and re-flash, if necessary.

5. Check the ECU A-9000 voltage supply wiring for a short circuit to ground.

With the key in the ON position, use a multimeter to perform the following voltage check on the vehicle harness (VE) side :

From	To	Value
X-9102 pin K01	Chassis ground	There should be no continuity.
X-9102 pin K03	Chassis ground	There should be no continuity.
X-9102 pin K05	Chassis ground	There should be no continuity.

A. If there is continuity, there is a short circuit to ground condition in the ECU A-9000 voltage supply wiring. Use the appropriate service manual to locate and repair the shorted conductor.

B. If there is no continuity, check the ECU A-9000 for the appropriate software and re-flash, if necessary.

6. Visually inspect the relevant harnesses and connectors for damage, bent or dislocated pins, corroded terminals, or broken wires. Verify that the connectors are fully installed. Flex the harnesses involved to reveal intermittent breaks or shorts in the wiring concerned. Operate the machine while you monitor the display.

A. If you find damage or the display indicates other than normal display readings, then repair the damage discovered during the inspection or locate and repair the other than normal display condition and verify that the error has been resolved.

B. If you do not find damage and the display indicates only normal readings, then erase the fault code and continue operation.

Wiring harnesses - Electrical schematic sheet 02 – Engine Control Unit (ECU) power and after treatment system (engine schematics) (55.100.DP-C.20.E.02)

DTC 26F-04-The minimum rail pressure value necessary to allow fuel injection has not been reached

Control Module : ECU

NOTE: If the Pressure Relief Valve (PRV) is replaced, it is necessary to perform the Replacement of the Rail Pressure Relief Valve (PRV) - Reset ECU Data with the Electronic Service Tool (EST) before you return the machine to service. See **Common rail Relief valve - Configure - Reset ECU data (10.218)**, if necessary.

NOTE: If the rail pressure sensor B-9004 is replaced, it is necessary to perform the Replacement of the Rail Pressure sensor - Reset ECU Data with the Electronic Service Tool (EST) before you return the machine to service. See **Common rail pressure sensor - Configure - Reset ECU data (Rail pressure sensor) (55.010)**, if necessary.

Context:

The Engine Control Unit (ECU) A-9000 monitors fuel rail pressure. If the ECU A-9000 determines that fuel rail pressure is less than **130.0 bar (1885.0 psi)** or below a limit value from an ECU A-9000 calculated curve, this fault will occur. Other active faults may have caused this fault to occur. For more information regarding fuel system troubleshooting, see **Fuel injection system - Troubleshooting (10.218)**.

Cause:

The ECU A-9000 has determined that fuel rail pressure is too low to continue engine operation.

Possible failure modes:

1. Faulty fuel metering unit Y-9000, stuck closed or internal failure.
2. Faulty high pressure pump, low efficiency.
3. Faulty charge gear pump, low efficiency.
4. Faulty fuel filters, clogged.
5. Faulty fuel lines, leakage or blockage.
6. Faulty electric fuel pump (if equipped).
7. Faulty fuel injectors, internal leakage or stuck open.
8. Faulty Pressure Relief Valve (PRV), leakage.
9. Faulty rail pressure sensor B-9004 drifted signal or leaking.
10. Faulty ECU A-9000, software.

- B. If there is no continuity, check the ECU A-9000 for the appropriate software and re-flash, if necessary.
- 4. Visually inspect the relevant harnesses and connectors for damage, bent or dislocated pins, corroded terminals, or broken wires. Verify that the connectors are fully installed. Flex the harnesses involved to reveal intermittent breaks or shorts in the wiring concerned. Operate the machine while you monitor the display.
 - A. If you find damage or the display indicates other than normal display readings, then repair the damage discovered during the inspection or locate and repair the other than normal display condition and verify that the error has been resolved.
 - B. If you do not find damage and the display indicates only normal readings, then erase the fault code and continue operation.

Wiring harnesses - Electrical schematic sheet 01 – Power distribution and glow plugs (engine schematics) (55.100.DP-C.20.E.01)

Wiring harnesses - Electrical schematic sheet 02 – Engine Control Unit (ECU) power and after treatment system (engine schematics) (55.100.DP-C.20.E.02)

B. If the voltage is not present for one or more of the checks, see the appropriate vehicle service manual and electrical schematics, if necessary, to locate and restore supply power to the ECU A-9000.

4. Determine the condition of the ECU A-9000 CAN circuit.

With the key switch in the OFF position, use a multimeter to measure the resistance of the CAN connection on the vehicle (VE) harness side:

From	To	Value
X-9102 pin K24	X-9102 pin K25	There should be 120 Ω .
X-9102 pin K24	chassis ground	There should be no continuity
X-9102 pin K25	chassis ground	There should be no continuity

Use a multimeter to measure the resistance of the CAN termination resistor, internal to the ECU A-9000:

From	To	Value
X-9102 pin K24	X-9102 pin K25	There should be 120 Ω .

A. If the measured resistances are correct and neither conductor is grounded, check the ECU A-9000 for the appropriate software and re-flash, if necessary.

B. If the measured resistances are not correct or one or both of the conductors is grounded, see the appropriate vehicle service manual and electrical schematics, if necessary, to locate and restore the termination resistance to the CAN circuit.

5. Visually inspect the relevant harnesses and connectors for damage, bent or dislocated pins, corroded terminals, or broken wires. Verify that the connectors are fully installed. Flex the harnesses involved to reveal intermittent breaks or shorts in the wiring concerned. Operate the machine while you monitor the display.

A. If you find damage or the display indicates other than normal display readings, then repair the damage discovered during the inspection or locate and repair the other than normal display condition and verify that the error has been resolved.

B. If you do not find damage and the display indicates only normal readings, then erase the fault code and continue operation.

Wiring harnesses - Electrical schematic sheet 02 – Engine Control Unit (ECU) power and after treatment system (engine schematics) (55.100.DP-C.20.E.02)

- A. If you find damage or the display indicates other than normal display readings, then repair the damage discovered during the inspection or locate and repair the other than normal display condition and verify that the error has been resolved.
- B. If you do not find damage and the display indicates only normal readings, then erase the fault code and continue operation.

**Wiring harnesses - Electrical schematic sheet 03 – Engine sensors and fuel injection (engine schematics)
(55.100.DP-C.20.E.03)**

- A. If the fault has been resolved, return the machine to service.
 - B. If the fault has not been resolved, check the ECU A-9000 for the appropriate software and re-flash, if necessary.
4. Visually inspect the relevant harnesses and connectors for damage, bent or dislocated pins, corroded terminals, or broken wires. Verify that the connectors are fully installed. Flex the harnesses involved to reveal intermittent breaks or shorts in the wiring concerned. Operate the machine while you monitor the display.
- A. If you find damage or the display indicates other than normal display readings, then repair the damage discovered during the inspection or locate and repair the other than normal display condition and verify that the error has been resolved.
 - B. If you do not find damage and the display indicates only normal readings, then erase the fault code and continue operation.

Wiring harnesses - Electrical schematic sheet 01 – Power distribution and glow plugs (engine schematics) (55.100.DP-C.20.E.01)

Wiring harnesses - Electrical schematic sheet 02 – Engine Control Unit (ECU) power and after treatment system (engine schematics) (55.100.DP-C.20.E.02)

DTC 5E3-04-ECU internal failure - Torque request due to air control exceeds maximum torque limit

Control Module : ECU

Context:

The Engine Control Unit (ECU) A-9000 monitors “lead torque”, which is the input torque request that is calculated for determining fuel pressure. If the ECU A-9000 determines that “lead torque” is less than the limited maximal torque, this fault will occur.

Solution:

1. Check the ECU A-9000 for the appropriate software and re-flash, if necessary.
 - A. If the fault has been resolved, return the machine to service.
 - B. If the fault has not been resolved, escalate an ASIST concern.

- A. If the fault has been resolved, return the machine to service.
 - B. If this fault has not been resolved, check the ECU A-9000 for the appropriate software and re-flash, if necessary.
4. Visually inspect the relevant harnesses and connectors for damage, bent or dislocated pins, corroded terminals, or broken wires. Verify that the connectors are fully installed. Flex the harnesses involved to reveal intermittent breaks or shorts in the wiring concerned. Operate the machine while you monitor the display.
- A. If you find damage or the display indicates other than normal display readings, then repair the damage discovered during the inspection or locate and repair the other than normal display condition and verify that the error has been resolved.
 - B. If you do not find damage and the display indicates only normal readings, then erase the fault code and continue operation.

Wiring harnesses - Electrical schematic sheet 02 – Engine Control Unit (ECU) power and after treatment system (engine schematics) (55.100.DP-C.20.E.02)

From	To	Result
X-9113 pin 7	chassis ground	There should be no continuity.

- A. If there is continuity, the short to chassis ground condition is in glow plug circuit in the vehicle harness (VE). Use the appropriate service manual, if necessary, to locate and repair the grounded conductor.
- B. If there is no continuity, continue with Step 6.
5. Replace the glow plug control module Z-9101, then use EST to check to see that this fault has been resolved.
- A. If the fault has been resolved, return the machine to service.
- B. If the fault has not been resolved, check the ECU A-9000 for the appropriate software and re-flash, if necessary.
6. Visually inspect the relevant harnesses and connectors for damage, bent or dislocated pins, corroded terminals, or broken wires. Verify that the connectors are fully installed. Flex the harnesses involved to reveal intermittent breaks or shorts in the wiring concerned. Operate the machine while you monitor the display.
- A. If you find damage or the display indicates other than normal display readings, then repair the damage discovered during the inspection or locate and repair the other than normal display condition and verify that the error has been resolved.
- B. If you do not find damage and the display indicates only normal readings, then erase the fault code and continue operation.

**Wiring harnesses - Electrical schematic sheet 01 – Power distribution and glow plugs (engine schematics)
(55.100.DP-C.20.E.01)**



PRINTED IN U.S.A.

© 2016 CNH Industrial America LLC.

All rights reserved. No part of the text or illustrations of this publication may be reproduced.

NEW HOLLAND policy is one of continuous improvement and the right to change prices, specification or equipment at any time without notices is reserved.

All data given in this publication is subject to production variations. Dimensions and weight are approximate only and the illustrations do not necessarily show products in standard condition. For exact information about any particular product, please consult your NEW HOLLAND Dealer.


Pneumatically-adjusted operator seat - Disassemble

Prior operation:

Pneumatically-adjusted operator seat - Remove (90.124)

NOTE: Use rebuild kit 86530936 to rebuild the seat on the Boomer 46D, and 54D .


1. Remove the seat from the tractor.



30002436N 1


2. Place the seat assembly on a bench. Fold the seat front, and loosen the bolt, (1), in the center

3. Remove the seat from the seat pedestal.



66064043N 2

4. Remove the fore and aft slide lever, (1), and slide, (2), by removing the two nuts and washers, (3), on each side.



66064043N 3

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL