

SERVICE MANUAL

TD65F / TD75F / TD85F
Tractor

Part number 47913163
English
February 2016

AGRICULTURE

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

HYDRAULIC SYSTEMS

- Some fluid coming out from a very small port can be almost invisible and be strong enough to penetrate the skin. For this reason, NEVER USE YOUR HANDS TO CHECK FOR LEAKS, but use a piece of cardboard or a piece of wood for this purpose. If any fluid is injected into the skin, seek medical aid immediately. Lack of immediate medical attention may result in serious infections or dermatitis.
- Always take system pressure readings using the appropriate gauges.

WHEELS AND TYRES

- Check that the tyres are correctly inflated at the pressure specified by the manufacturer. Periodically check for possible damage to the rims and tyres.
- Stay at the tyre side when inflating.
- Check the pressure only when the tractor is unloaded and tyres are cold to avoid wrong readings due to over-pressure.
- Never cut, nor weld a rim with the inflated tyre assembled.
- To remove the wheels, block both front and rear tractor wheels. Raise the tractor and install safe and stable supports under the tractor in accordance with regulations in force.
- Deflate the tyre before removing any object caught into the tyre tread.
- Never inflate tyres using flammable gases as they may generate explosions and cause injuries to bystanders.

REMOVAL AND INSTALLATION

- Lift and handle all heavy components using lifting equipment of adequate capacity. Ensure that parts are supported by appropriate slings and hooks. Use lifting eyes provided to this purpose. Take care of the persons near the loads to be lifted.

HEALTH AND SAFETY

CONTENT

Section	Description	Page
	HEALTH AND SAFETY PRECAUTIONS	4
	ACIDS AND ALKALIS	5
	ADHESIVES AND SEALERS - see Fire	5
	ANTIFREEZE - see Fire, Solvents e.g. Isopropanol, Ethylene Glycol, Methanol.	5
	ARC WELDING - see Welding.	5
	BATTERY ACIDS - see Acids and Alkalis.	5
	BRAKE AND CLUTCH FLUIDS (Polyalkylene Glycols) - see Fire.	6
	BRAZING - see Welding.	6
	CHEMICAL MATERIALS - GENERAL - see Legal Aspects.	6
	DO'S.	6
	DO NOTS.	6
	CORROSION PROTECTION MATERIALS - see Solvents, Fire.	6
	DUSTS	7
	ELECTRIC SHOCK.	7
	EXHAUST FUMES.	7
	FIBRE INSULATION - see Dusts.. . . .	7
	FIRE - see Welding, Foams, Legal Aspects.. . . .	7
	FIRST AID.	7
	FOAMS - Polyurethane - see Fire.. . . .	7
	FUELS - see Fire, Legal Aspects, Chemicals - General, Solvents.. . . .	8
	GAS CYLINDERS - see Fire.. . . .	8
	GENERAL WORKSHOP TOOLS AND EQUIPMENT.	9
	LEGAL ASPECTS.	9
	LUBRICANTS AND GREASES.	9

Safety rules

PRECAUTIONARY STATEMENTS

Personal Safety

Throughout this manual and on machine signs, you will find precautionary statements ("DANGER", "WARNING", and "CAUTION") followed by specific instructions. These precautions are intended for the personal safety of you and those working with you. Please take the time to read them.

FAILURE TO FOLLOW THE "DANGER", "WARNING", AND "CAUTION" INSTRUCTIONS MAY RESULT IN SERIOUS BODILY INJURY OR DEATH.

Machine Safety

The precautionary statement ("IMPORTANT") is followed by specific instructions. This statement is intended for machine safety.

NOTICE: *The word "IMPORTANT" is used to inform the reader of something they need to know to prevent minor machine damage if a certain procedure is not followed.*

Information

NOTE: *Instructions used to identify and present supplementary information.*

LEGAL OBLIGATIONS

This machine may be equipped with special guarding or other devices in compliance with local legislation. Some of these require active use by the operator. Therefore, check local legislation on the usage of this machine.

ACCIDENT PREVENTION

Most accidents or injuries that occur in workshops are the result of a non compliance to simple and fundamental safety regulations. For this reason, **IN MOST CASES THESE ACCIDENTS CAN BE AVOIDED** by foreseeing possible causes and consequently acting with the necessary caution and care.

Accidents may occur with all types of machines, regardless of how well the machine in question was designed and built.

A careful and informed service technician is the best guarantee against accidents.

Decisive awareness of the most basic safety rule is normally sufficient to avoid many serious accident.

ATTENTION: *Shut down the machine, remove key, be sure all moving parts have stopped and all pressure in the systems is relieved before cleaning, adjusting or lubricating the equipment. Failure to comply will result in death or serious injury.*

SAFETY REQUIREMENTS FOR FLUID POWER SYSTEMS AND COMPONENTS - HYDRAULICS (EUROPEAN STANDARD PR EM 982)

Flexible hose assemblies must not be constructed from hoses which have been previously used as part of a hose assembly.

Do not weld hydraulic piping.

When flexible hoses or piping are damaged, replace them immediately.

It is forbidden to modify a hydraulic accumulator by machining, welding or any other means.

Before removing hydraulic accumulators for servicing, the liquid pressure in the accumulators must be reduced to zero.

Pressure check on hydraulic accumulators shall be carried out by method recommended by the accumulator manufacturer.

Care must be taken not to exceed the maximum allowable pressure of the accumulator. After any check or adjustment there must be no leakage of gas.

INTRODUCTION

O RING BOSS END FITTING OR LOCK NUT

Nom. SAE Dash Size	Thread Size	Newton-meters	lb/in	lb/ft
-6	9/16 - 18	48 to 54	432 to 480	
-8	3/4 - 16	70 to 78	612 to 684	
-10	7/8 - 14	102 to 114		75 to 84
-12	1-1/16 - 12	142 to 160		105 to 117
-16	1-5/16 - 12	237 to 254		175 to 187

37 DEGREE FLARE FITTING (STEEL HYDRAULIC FITTINGS)


Nom. SAE Dash Size	Tube OD/Hose ID		Thread Size	Newton-meters	lb/in	lb/ft
-2			5/16 - 24	8 to 9	72 to 84	
-3			3/8 - 24	11 to 12	96 to 108	
-4	6.4 mm	1/4 inch	7/16 - 20	14 to 16	120 to 144	
-5	7.9 mm	5/16 inch	1/2 - 20	18 to 21	156 to 192	
-6	9.5 mm	3/8 inch	9/16 - 18	27 to 33	240 to 300	
-8	12.7 mm	1/2 inch	3/4 - 16	46 - 56	408 to 504	
-10	15.9 mm	5/8 inch	7/8 - 14	77 to 85	684 to 756	
-12	19.0 mm	3/4 inch	1-1/16 - 12	107 to 119		79 to 88
-14	22.2 mm	7/8 inch	1-3/16 - 12	127 to 140		94 to 103
-16	25.4 mm	1.0 inch	1-5/16 - 12	131 to 156		97 to 117
-20	31.8 mm	1-1/4 inch	1-5/8 - 12	197 to 223		145 to 165
-24	38.1 mm	1-1/2 inch	1-7/8 - 12	312 to 338		230 to 250

37 DEGREE FITTINGS

TUBE NUTS FOR 37 DEGREE FLARED FITTINGS								O RING BOSS PLUGS ADJUSTABLE FITTING LOCKNUTS, SWIVEL JIC-37° SEATS			
TORQUE								TORQUE			
Size	Tubing OD		Thread Size	Newton·Meters		Foot Pounds		Newton·Meters		Foot Pounds	
	mm	in.		Min.	Max.	Min.	Max.	Min.	Max.	Min.	Max.
4	6.4	1/4	7/16-20	12	16	9	12	8	14	6	10
5	7.9	5/16	1/2-20	16	20	12	15	14	20	10	15
6	9.5	3/8	9/16-18	29	33	21	24	20	27	15	20
8	12.7	1/2	3/4-16	47	54	35	40	34	41	25	30
10	15.9	5/8	7/8-14	72	79	53	53	47	54	35	40
12	19.1	3/4	1-1/16-12	104	111	77	82	81	95	60	70
14	22.2	7/8	1-3/16-12	122	136	90	100	95	109	70	80
16	25.4	1	1-5/16-12	149	163	110	120	108	122	80	90
20	31.8	1-1/4	1-5/8-12	190	204	140	150	129	158	95	115


These torques are not recommended for tubes of **12.7 mm (0.5 in)** OD and larger with wall thickness of **0.89 mm (0.035 in)** or less. The torque is specified for **0.89 mm (0.035 in)** wall tubes on each application individually. Before installing and torquing 37° flared fittings, clean the face of the flare and threads with a cleaning solvent or Loctite® brand cleaner, and apply hydraulic sealant Loctite® 569™ to the 37° flare and the threads. Install fitting, and torque to specified torque, loosen fitting and re-torque to specifications.

5. Disconnect the electrical connection **(1)** of bonnet.




CLUTCH3 3

6. Detach the gas strut **(1)** from the bonnet.




CLUTCH4 4

7. Remove the two bonnet hinge bolts **(1)** and take out the spacers **(2)** lift the bonnet clear.




CLUTCH5 5

8. Disconnect the two retaining bolts of the guard **(1)** both on the right and left hand side of the engine.




SOLDAN 6

41. Hitch the engine to the hoist with the chains **(1)** anchoring it to the attachments on the engine.




MOTORKALDIRMA 39

42. Engine lifting points are **(1)** , **(2)** and **(3)** .



CLUTCH40 40

43. Position the movable tool for dismantling tractors 380000569 with the bracket 380000500 and adapter plate 380000844 under the engine and place a wooden block in between the points of contact between the tool and tractor as shown in the fig.



CLUTCH41 41


Index

Clutch - 18

Clutch mechanical release control - 100

Clutch mechanical release control - Height adjust	3
---	---

Clutch - Sectional view ADJUSTING THE PTO SWITCH




CLUTCPT05 1

ATTENTION: Use suitable tools to align the holes. NEVER USE FINGERS OR HANDS.


1. Check that the PTO clutch is disengaged.
2. Unscrew the screws (1) retaining the PTO engaged switch (2) and move away from the control valve lever (3) .
3. Move the switch (2) to wards the control valve lever (3) until the switch trips.
4. Lock the switch (2) in this last position with the screws (1) .

34. Disconnect the electrical connections from starter motor (1) .




CLUTCH32 32

35. Disconnect the electrical connections from alternator (1) .




CLUTCH33 33

36. Disconnect the electrical connection of water in fuel sensor (1) .



CLUTCH34 34

37. Remove the electrical connection of air filter clogging sensor (1) .



CLUTCH35 35

Clutch - Assemble

1. Refit the lever pivot pins and the relative springs.
2. Refit the main clutch disk in the clutch housing.
3. Install the main clutch pressure plate, securing to the pins with the bolts.
4. Install the Belleville spring disk, carefully position the three clamps and evenly and progressively compress the spring. Insert the six pins, making sure that they are securely inserted in their respective seats, then remove the clamps.
5. Install the PTO clutch disc; fit the three washers and helical springs in the articulation pins, tightening them with the three nuts.

Contents

Transmission - 21

Mechanical transmission - 114

TECHNICAL DATA

Mechanical transmission	
General specification	4
Torque	4
Sealing	6
Special tools	8

FUNCTIONAL DATA


Mechanical transmission	
Sectional view	11
Exploded view	12
Sectional view	13
Sectional view	14
Sectional view	16

SERVICE

Mechanical transmission	
Remove	17
Install	25
Disassemble	28
Assemble	34
Adjust	37

Mechanical transmission - Exploded view


Diagram for application of anaerobic sealant in the installation of brake assembly and side final drives in the transmission box.



LAIL1TL1051G0A 1


The use of anaerobic sealant is recommended **LOCTITE® 515™**.

21. Position one of the mobile trolleys (1) of tool 292320 under the front section of the transmission - gear box and move the other mobile trolley to the rear part of this section of the box.




LAIL11TL0606A0A 20

22. Position the fixed trolley (1) from tool 292320 insert a wooden block under the clutch box (3). Loosen the fixing bolts and if required, remove the rear wheels placing two fixed trestles under the ends of the side shafts.




LAIL11TL0607A0A 21

23. Loosen the bolts (1) which fasten the valve with the solenoid to the transmission/gear box and remove it.




LAIL11TL0608A0A 22

24. Use a chain to fasten the connection hook to the winch, loosen the six fixing bolts (1) and remove the towing support (2).




LAIL11TL0609A0A 23

16. Unlock the washer that securing the nut (1) and loosen the nut.




LAIL11TL0499A0A 16

17. Bolt the adapter 380000838 (2) on the pinion (3) and use the sliding hammer 380000549 (1) to move the pinion a few millimeters in the direction shown.




LAIL11TL0500A0A 17

18. Move the engagement sleeve (1) until it is possible to gain access with a pair of pliers (2) and remove the lock ring.



LAIL11TL0501A0A 18

19. Move the gear (1) in the direction shown and remove the two locking semi-rings (2). Loosen the nut (3) fully, remove the pinion and disassemble all the parts.



LAIL11TL0502A0A 19

Contents

Transmission - 21

Creeper - 160

TECHNICAL DATA

Creeper	
Torque	4
Special tools	4
General specification	8

FUNCTIONAL DATA

Creeper	
Sectional view	9
Sectional view	10
Dynamic description	11

SERVICE

Creeper	
Disassemble	12
Assemble	16

Creeper - Disassemble

Clutch box - supplementary inverter and reducer

DISASSEMBLY

⚠ WARNING

Avoid injury!


Handle all parts carefully. Do not place your hands or fingers between parts. Use Personal Protective Equipment (PPE) as indicated in this manual, including protective goggles, gloves, and safety footwear.

Failure to comply could result in death or serious injury.

W0208A


In order to be able to work on the supplementary inverter-reducer group, you will have to remove the platform following the instructions described in section **Mechanical transmission - Remove (21.114)** and remove the clutch box, then proceed as follows.

1. Fix the casing to the rotating stand 380000301 using the brackets 380000271 and 380000272.




LAIL11TL0446A0A 1

2. Remove the lock ring (1) and the gear (2).



LAIL11TL0447A0A 2

3. Remove the lock ring (1).



LAIL11TL0448A0A 3

Reverser - General specification

Synchroniser reverser main data

Type	Mechanical type spur gear unit, located between the main clutch and the gearbox. Comprises 1 driving gear, 1 intermediate gear and 1 idle gear
Control	Hand lever located on left-hand side of the operator

Gearbox main data

Gearbox	4 speed, constant-mesh, with synchronisers on all gears
Gearing type	helical
Reduction unit	Ordinary gear train with 3 ranges providing a total of 12 gears
Gearing type	spur
Gearbox and reduction unit controls	Independent, with two hand levers located on right-hand side of the operator

Reverser - Torque

Tightening torques

Parts	Thread	Torque value
Bolts or nuts securing the clutch box/inverter to the engine C ₁	M12 x 1.25	98 N·m (72 lb ft)
Nuts securing the cover C ₂	M8 x 1.25	17 N·m (13 lb ft)
Nuts securing the controlled shaft support cover of the inverter C ₃	M8 x 1.25	28 N·m (21 lb ft)
Bolts securing the controlled shaft plate of the inverter C ₄	M10 x 1.25	64 N·m (47.2 lb ft)
Bolts securing the clutch box/inverter to the rear transmission box/gearbox C ₅	M12 x 1.25	98 N·m (72 lb ft)

Reverser - Assemble

Clutch box - inverter

Assembly

Assemble the inverter considering the following:

1. Follow the illustrations shown in **Reverser - Sectional view (21.162)** for the orientation of the various components.
2. Observe the tightening torques indicated in **Reverser - Torque (21.162)**
3. Assemble the idler gear pin, complete from the various pieces, and the inverter's control gear pin and secure it through the appropriate plate and its bolt.
4. Assemble the control forks of the clutch collar sleeves on the respective clutch control shafts and secure them to these.
5. Assemble the cover support of the sleeves on the clutch collars.
6. Assemble the group of clutch collar sleeves on the related support and fasten it with the appropriate springs.
7. Assemble on the back side the inverter control shaft and attach it to the clutch box/inverter with its respective lock ring.
8. Place the inverter control gear with its bearings on the control shaft.
9. Assemble the inverter's driven gear with its bearings and spacers.
10. Assemble the synchronizer group with its control forks, rod, thrust washer and bearing, and lock it with its respective lock ring.
11. Assemble the ball, spring and fixing bolt using **LOCTITE® 515™** or Silastic.
12. Set the internal lever in place and assemble the transmission lever and secure it with its roll pin.
13. Take the clutch/inverter box off the trestle 380000301..

Index

Transmission - 21

Differential - 182

Differential - Adjust	4
Differential - Adjust	6

Index

Four-Wheel Drive (4WD) system - 23

Electro-hydraulic control - 202

Electro-hydraulic control - General specification	3
Electro-hydraulic control - Special tools	5
Electro-hydraulic control - Torque	4




Gearbox - Assemble

⚠ CAUTION

Pinch hazard!


Always use suitable tools to align mating parts. **DO NOT** use your hand or fingers.
Failure to comply could result in minor or moderate injury.

C0044A



BRAG12TRALL0140 1

8. Raise the tractor using the lifting hook (or using a hydraulic jack beneath the tractor) and place a support under the engine sump.




LAIL11TL0491A0A 8

9. **⚠ WARNING**

Avoid injury!
Handle all parts carefully. Do not place your hands or fingers between parts. Use Personal Protective Equipment (PPE) as indicated in this manual, including protective goggles, gloves, and safety footwear.
Failure to comply could result in death or serious injury.


W0208A

Loosen the bolts and remove the front wheels.




LAIL11TL0043A0A 9

10. Loosen the fixing bolts (1) of the rear axle support.



LAIL11TL0492A0A 10


11. Loosen the fixing bolts (1) of the front wheel drive support.



LAIL11TL0493A0A 11

Differential - Dynamic description

Sectional view of the self-locking differential



BRAG12TRALL0159 1

C_1 = Casing safety screw, torque adjustment from **56 – 62 N·m (41.3035 – 45.7289 lb ft)**

- | | |
|----------------------------|------------------------------|
| 1. Casing, middle flange. | 8. Fastening ring |
| 2. Casing, middle end cap. | 9. Eccentric retaining rings |
| 3. Side gear. | 10. Driven clutch. |
| 4. Side gear. | 11. Central eccentric. |
| 5. Springs. | 12. Backrest. |
| 6. Retainer spring. | 13. Ring gear. |
| 7. Central drive assembly. | 14. Drive shaft. |
| | 15. Front axle housing. |

Advantages of the self-locking system

The differential control performs the following key functions:

Differential - Gear tooth contact


Front wheel drive differential

Service


When the differential assembly needs to be serviced, it will be necessary to adjust the gap between the teeth of the planetary gears and satellite gears.

Proceed as follows:

1. Clean the differential components very well and carefully, and remove all the vestiges of oil that may prevent the correct measurement of clearance.
2. Install the planetary gears without the friction shims (self-locking system).
3. Fit in the two satellite gears complete with backing shims and fix the pin with the fixation bolt, turning it to keep the pin in place.
4. Place a calibrator gauge into the differential housing.
5. Move the planetary gear on the left-hand side in order to establish perfect contact with the satellite and then push against the differential housing and take the gap reading on the calibrator gauge "Gs".
6. Repeat the above operation to measure the gap on the right-hand side in the other planetary gear "Gd".



LAIL11TS0058A0A 1



LAIL11TS0058A0A 2

The shim to be installed in the differential housing is therefore determined by.

$S_s = G_s - 0.25 \text{ mm}$ for the planetary gear on the LH side.


$S_d = G_d - 0.25 \text{ mm}$ for the planetary gear on the RH side.

7. Install the shims as closely as possible to the calculated values and using the calibration gauge, follow the procedures described above, checking that the gap of the planetaries on the right and left sides is approximately **0.25 mm**.

Wheel hub - Adjust

Proceed as follows:

1. Install wheel hub and fixed gear unit onto the steering knuckle;
2. Using a torque wrench (1) and lock ring wrench 293837, progressively tighten the lock ring to **147 – 196 N·m (108.4 – 144.6 lb ft)**. While tightening the lock ring, rotate the hub to settle the bearings.
3. Fully slacken the lock ring and retighten to **59 N·m (43.5 lb ft)** while rotating hub.
4. Secure the lock ring by bending over a lockwasher tab (if necessary, further tighten the lock ring to align a slot with the tab)
5. Turn the hub by hand to check for excessive play or binding.



BRAG12TRALL0153 1



PRINTED IN TURKEY

© 2016 CNHI International


All rights reserved. No part of the text or illustrations of this publication may be reproduced.

NEW HOLLAND policy is one of continuous improvement and the right to change prices, specification or equipment at any time without notices is reserved.

All data given in this publication is subject to production variations. Dimensions and weight are approximate only and the illustrations do not necessarily show products in standard condition. For exact information about any particular product, please consult your NEW HOLLAND Dealer.

Hook to support the front hood (number 50132 - inscribed.
Values in mm)

Build using UNI C40.



LAIL11TL0945B0A 6

Powered rear axle - General specification

MAIN SPECIFICATION OF BEVEL GEAR PAIR AND DIFFERENTIAL

		All Models
Bevel gear pair gear ratio		10/44 = 1:4.4 (40 kph (24.9 mph))
Bevel gear pair tooth clearance	mm (in.)	0.18 – 0.23 (0.0071 – 0.0091)
Type of differential		with two planet gears
Elektrohydraulically controlled differential lock		controlled by switch on control panel
Release for elektrohydraulically controlled differential lock		controlled by foot brake pedals
Differential pinion internal seat diameter	mm (in.)	25.040–25.061 (0.9858 – 0.9867)
Differential pinion pin diameter	mm (in.)	24.939–24.960 (0.9818 – 0.9823)
Clearance between differential pinions and their pins	mm (in.)	0.080 – 0.122 (0.0031 – 0.0048)
Diameter of side gear hub seats on differential box	mm (in.)	51.100 – 51.146 (2.0118 – 2.0136)
Diameter of side gear hubs	mm (in.)	50.954 – 51.000 (2.0061 – 2.0079)
Clearance between side gears and their seats	mm (in.)	0.100 – 0.192 (0.0039 – 0.0076)
Bevel pinion positioning adjustment		see pages 39
Adjuster shims for bevel pinion positioning	mm (in.)	1.85 – 1.90 – 1.95 – 2.00 – 2.05 2.10 – 2.15 – 2.20 – 2.40 – 2.45 2.50 – 2.55 – 2.60 – 2.65 – 2.70 (0.0728 – 0.0748 – 0.0768 – 0.0787 0.0807 – 0.0827 – 0.0846 – 0.0866 0.0945 – 0.0965 – 0.0984 – 0.1004 0.1024 – 0.1043 – 0.1063)
Adjusting ring bevel gear bearings and bevel gear pair coupling clearance		see page 201
Differential pinion and side gear backlash	mm (in.)	0.18 (0.0071)
Thickness of differential side gear clearance adjustment shims	mm (in.)	1.5–1.6 (0.0591–0.0630)
Thickness of differential pinion thrust bearings	mm (in.)	1.47–1.53 (0.0579–0.0602)

Rear axle system - Rear bevel gear set and differential

<p>Clearance between planetary and satellite (gear) teeth</p> <p>Thickness of planetary adjustment shims (16), Mechanical transmission - Sectional view (21.114) and (17), Mechanical transmission - Sectional view (21.114)</p> <p>Thickness of satellite shims (4), Mechanical transmission - Sectional view (21.114) and Mechanical transmission - Sectional view (21.114)</p> <p>Adjustment of the gap between the planetary teeth and the satellites</p> <p>Differential lock adjustment</p> <p>Differential lock fork adjustment shim</p>	<p>0.15 – 0.18 mm - 1.5 mm - 1.6 mm -</p> <p>1.470 – 1.530 mm</p> <p>see Differential - Adjust (27.106)</p> <p>see Differential lock - Adjust (27.106) and 0.5 mm</p>
<p>Spring to unlock the differential (Mechanical control):</p> <p> free length of the spring</p> <p> length of spring under a pressure of 177 – 195 N (40 – 44 lb)</p>	<p>220 mm</p> <p>157.5 mm</p>

Contents

Power Take-Off (PTO) - 31

Rear mechanical control - 101

TECHNICAL DATA

Rear mechanical control	
General specification	3
Special tools	5
Torque	5
General specification INDEPENDENT POWER TAKE-OFF SERVO ASSIST PTO	6
General specification GROUND SPEED PTO	7
General specification POWER TAKE-OFF SPEED	9

FUNCTIONAL DATA

Rear mechanical control	
Sectional view	10

SERVICE

Rear mechanical control	
Remove (PTO 540/750 RPM)	12
Install (PTO 540/750 RPM)	15
Disassemble (PTO 540/750 RPM)	16
Assemble (PTO 540/750 RPM)	19

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.


CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Rear mechanical control - Remove (PTO 540/750 RPM)

ATTENTION: Handle all parts very carefully. Do not put hands or fingers between two parts. Always wear the referred safety equipment, including protection goggles, gloves and shoes.


Proceed as follows:

1. Disconnect the negative battery cable.
2. Remove the top link (1) of the three-point linkage.




SAM_0518_1 1

3. Remove the tow hook (1), if fitted.



SAM_0518_1 2

4. Remove the draw bar (1)



LAIL11TL0670A0A 3



PRINTED IN TURKEY

© 2016 CNHI International

All rights reserved. No part of the text or illustrations of this publication may be reproduced.

NEW HOLLAND policy is one of continuous improvement and the right to change prices, specification or equipment at any time without notices is reserved.

All data given in this publication is subject to production variations. Dimensions and weight are approximate only and the illustrations do not necessarily show products in standard condition. For exact information about any particular product, please consult your NEW HOLLAND Dealer.

Hydraulic service brakes - Remove

Removal

⚠ DANGER


Heavy objects!

Lift and handle all heavy components using lifting equipment with adequate capacity. Always support units or parts with suitable slings or hooks. Make sure the work area is clear of all bystanders. Failure to comply will result in death or serious injury.

D0076A


Proceed as follows to remove the side end drive casing:

1. Disconnect the negative battery cable (1).
2. Lock the front wheels with shims.




LAIL11TL0001A0A 1

3. Remove the arm (1) and the left stabiliser support (2).



LAIL11TL0002A0A 2

4. Lift the rear part of the tractor and place a fixed trestle under the flexing bar support.



LAIL11TL0003A0A 3

Contents

Brakes and controls - 33

Parking brake or parking lock - 110

SERVICE

Hand brake lever	
Travel adjust	3

Contents

Hydraulic systems - 35

Remote control valves - 204

FUNCTIONAL DATA

Remote control valve	
Sectional view	3
Dynamic description	5
Functional diagram	6
Dynamic description	7
Dynamic description	8
Hydraulic schema	13
Hydraulic schema	14

SERVICE


Remote control valve	
Leakage test	15
Leakage test	16

To lower the implement, move the lever forward. The spool **(2)** moves and the detent balls **(26)** fit into the spline, where they are kept in position by the bracket **(28)** and the spring **(24)**. The oil from the lower chamber flows to the exhaust **(T)** through the line **(B)**, while the upper chamber is connected to the pressure line **(A)**. When the lowering operation is completed, the detent is automatically released as described above.

Hitch control valve - Disassemble


with removed control valve

1. Remove the transmission cover (1) before removing the control valve.



BRAG12TRALL0215 1


2. Before removal, clean the surfaces of the control valve completely, hold the control valve in a bench clamp and loosen bolts (1) and (2).



25704

SEZ35CAP1A-87 2

3. Remove the cover (1) from the control valve body (2).



25705

SEZ35CAP1A-88 3

Contents

Hydraulic systems - 35

Regulated/Low pressure system - 322

TECHNICAL DATA

Regulated/Low pressure system	
Special tools	3
Low pressure pump	
General specification	4

SERVICE

Low pressure pump	
Disassemble	5
Inspect	6

Contents

Hitches, drawbars, and implement couplings - 37

Rear three-point hitch - 110

TECHNICAL DATA

Rear three-point hitch	
General specification	3
Special tools	4
Torque	4

FUNCTIONAL DATA


Rear three-point hitch	
Sectional view	6
Sectional view	7
Dynamic description	8
Exploded view	12

SERVICE

Rear three-point hitch	
Remove	13
Disassemble	18
Assemble	21
Adjust	23
Install	30

Rear three-point hitch - Exploded view


Hydraulic components of the lift control pump



LAIL11TL0996FOA 1


- | | | | |
|-----|------------------------------|-----|----------------------|
| 1. | Rear cover | 11. | Drive shaft retainer |
| 2. | Cover sealants | 12. | Locking ring |
| 3. | Pump body | 13. | Lock |
| 4. | Gear bushing | 14. | Nut |
| 5. | Drive and driven gear shafts | 15. | Bolt |
| 6. | Gear bushing | 16. | Washer |
| 7. | Guide | 17. | Key |
| 8. | Front cover | 18. | Guide |
| 9. | Drive shaft retainer | 19. | Lock washer |
| 10. | Spacer | 20. | Nut |

5. Fit the lift arms (1) on the shaft, matching up the reference marks. Secure in position with the bolts.



SEZ35CAP1A-69 5

6. Assemble the internal levers and the eccentric pin, and secure with the grub-screw.



SEZ35CAP1A-10 6

7. Carry out the assembly sequences described in the operation, see **Cab hitch controls - Adjust (55.523)**, for the REAR LIFT EXTERNAL CONTROLS.
8. Fit the internal position control lever.
9. Assemble the internal levers and the Lift-O-Matic lever.
10. Assemble and secure the cylinder and piston.
11. Assemble the internal levers and secure to the cylinder.
12. Carefully clean and degrease the mating surfaces, then apply sealing compound (approx. **2 mm (0.079 in)**) along the marked line shown in the drawing.
13. The types of sealing compounds to be applied are specified in **Basic instructions - Shop and Assembly**.
Fit the hydraulic lift on the lift box and secure in position with the relative retaining bolts.
Carry out the adjustments described below.

NOTE: The adjustments must be carried out in the order specified.



PRINTED IN TURKEY

© 2016 CNHI International


All rights reserved. No part of the text or illustrations of this publication may be reproduced.

NEW HOLLAND policy is one of continuous improvement and the right to change prices, specification or equipment at any time without notices is reserved.

All data given in this publication is subject to production variations. Dimensions and weight are approximate only and the illustrations do not necessarily show products in standard condition. For exact information about any particular product, please consult your NEW HOLLAND Dealer.

Power steering pump - Exploded view

Hydrostatic steering oil pump components



LAIL11FT0142F0A 1

- | | |
|---|------------------------------|
| (1) Front cover | (11) Drive shaft seal |
| (2) Cover seals | (12) Lock ring |
| (3) Pump body | (13) Safety washer |
| (4) Gear bracket | Nut (14) |
| (5) Drive gear shafts and driven gear shafts | Screw (15) |
| (6) Gear bracket | (16) washer |
| Bush (7) | Wrench (17) |
| (8) Control side cover | Bush (18) |
| (9) Drive shaft seal | (19) Safety washer |
| (10) Spacer | Nut (20) |

Steering cylinder - Remove

⚠ WARNING

Avoid injury!


Handle all parts carefully. Do not place your hands or fingers between parts. Use Personal Protective Equipment (PPE) as indicated in this manual, including protective goggles, gloves, and safety footwear.

Failure to comply could result in death or serious injury.

W0208A


To remove the front axle steering cylinder, proceed as follows:

1. Disconnect the negative cable from the battery.
2. Unscrew the unions securing the delivery and return hoses to the steering cylinder.




STEE77 1

3. Remove the retaining nut (1) of cylinder to the stub axle housing.



STEE78 2

4. Remove the retaining screw and extract the pin (1) securing the steering cylinder to the axle. Remove the steering cylinder.



STEE79 3

Power steering control valve - Remove

⚠ WARNING

Avoid injury!


Handle all parts carefully. Do not place your hands or fingers between parts. Use Personal Protective Equipment (PPE) as indicated in this manual, including protective goggles, gloves, and safety footwear.

Failure to comply could result in death or serious injury.

W0208A


To remove the hydrostatic steering control valve, proceed as follows:

1. Hood must be opened to access the engine.
2. Open the bonnet (1).




SAM_0119 1

3. Disconnect the negative cable (1) from the battery.




AKU 2

20. Using a **6 mm** Allenwrench, remove the threaded plug on the pressure relief valve and extract the seal.



BRAG12TRALL0246 17

21. Remove the pressure relief valve adjuster screw.
22. Turn the control valve body over and complete disassembly by extracting the spring and the pressure relief valve piston.




BRAG12TRALL0247 18

Power steering control valve - Test

control valveHydrostatic Steering

Condições de teste

- Oil Type: IDRAULICAR AP51 .
- Oil viscosity: **SAE 20 W**
- Oil temperature: **60 °C (140 °F)**
- Hydraulic pump capacity: **12 l/min**
- Electric engine speed: **1450 RPM**



LAIL11FT0141F0A 1


Installation diagram of the equipment for testing the rotary valve and seals and for installing the pressure relief valve

- | | |
|-------------------------|---------------------------------|
| 1. Control shaft spline | 3. Discharge line coupler |
| 2. Torque wrench | 4. Restriction |
| | 5. Pressure adjustment flywheel |

A. Checking the rotary valve


1. Make the connections and complete the circuit as shown in Fig. 1. Use control shaft spline (1), hold the steering control valve in the steering position (right or left).
2. Using the steering wheel (5), increase the circuit pressure until it is similar to the pressure relief valve opening pressure (pg. 1) without it actually being open.

4. Unscrew the wiper blade retaining screw **(1)** .




BRAG12TRALL0354 4

5. Unscrew the small nut **(1)** securing the wiper motor unit.



BRAG12TRALL0355 5

6. Unscrew the large nut and remove the wiper motor unit **(1)** from top the cab.




BRAG12TRALL0356 6


Alternator drive system Belt tensioner - Hydraulic symbol

Fan tensioning belt

Belt for models without air conditioning



Belt for models with air conditioning




1. Alternator
2. Tensioning belt
3. Safety nut on the tensioning belt
4. Belt

Positive diode test

Place an ohmmeter connection point in contact with the alternator's positive terminal (**X**) and the other with each of the three terminals in succession (**A**)- (**B**)- (**C**), Fig. 8).

Repeat the three measurements after reversing the connection points of the instrument.




LAIL11FT0166A0A 8

Negative diode test

Place an ohmmeter connection point in contact with the negative diode plate (**E**) and the other with each of the three terminals in succession (**A**)- (**B**)- (**C**), Fig. 9).

Repeat the three measurements after reversing the connection points of the instrument.

In the three previously described tests, the instrument should show resistance on each terminal (**A**)- (**B**)- (**C**). When you reverse the instrument's connection point, there should be no resistance (Fig. 9). If there is resistance in both cases, this indicates a short circuit in the diodes. If not, with a value of $R=0$ (interrupted diode), replace the entire rectifier bridge.




LAIL11FT0167A0A 9

Rotor

Checking the resistance of the rotor coil measured between pins connected to the brushes

Disconnect the exciter diodes' terminal cable connector (**1**) from the pin that is connected to the positive brush. Place both ends of the ohmmeter (set to the $\Omega \times 1$ scale) in contact with the two mounting pins of the voltage regulator brushes. If the resistance reading is different from the indicated value or reads as infinite (circuit broken), check the rotor. Replace the rotor if necessary (Fig. 10).



LAIL11FT0168A0A 10

Contents

Electrical systems - 55

Engine starting system - 201

TECHNICAL DATA

Engine starting system	
General specification	3
Torque	3

FUNCTIONAL DATA

Engine starting system	
Dynamic description	4
Electrical schema	5

SERVICE

Engine starter	
Test	7
Remove	9
Assemble	10
Disassemble Starter motor	11
Assemble Starter motor	13
Test Starter motor	14
Test Starter motor - Bench tests	15
Backlash	17

6. At this stage of the procedure, check the brushes and the switch. Check that the brushes are not stuck together and, if necessary, clean both the brushes and the respective channels with a cloth soaked in kerosene. Also check that the brushes are not worn. If the minimum length is less than that shown in the technical data, the starter motor will need to be replaced.

NOTE: *The brushes cannot be serviced separately. They are welded to their support and do not require replacement during the entire operating life of the starter motor.*


7. Extract the motor casing from the armature, **(10)** and the bracket on the control side.
8. Extract the control lever knuckle pin from the control side of the casing.
9. Remove the circlip that holds the control unit and the inner plate to the armature shaft, by first removing the circlip retaining collar perpendicularly using a suitably sized piece of piping. Then lever the circlip from the groove.
10. Extract the armature, **(10)** and control unit.

Index

Electrical systems - 55

Cab Heating, Ventilation, and Air-Conditioning (HVAC) controls - 051

Cab Heating, Ventilation, and Air-Conditioning (HVAC) controls - Dynamic description	3
--	---



BRAG12TRALL0375 2


	Condition	Indicator
(1)	Left direction indicator	Intermittent (green)
(2)	Position lights	Fixed (green)
(3)	Headlight high beams	Fixed (blue)
(4)	Water in fuel.	Fixed (red)
(5)	1st towing unit direction indicator	Flashing (green)
(6)	2nd towing unit direction indicator	Flashing (green)
(7)	Low engine oil pressure	Fixed (amber)
(8)	Low battery charge	Fixed (red)
(9)	Hand brake on	Fixed (red)
(10)	Right direction indicator	Flashing (green)
(11)	Power take off activated	Fixed (amber)
(12)	Differential Lock	Fixed (amber)

Fuel level sensor

This instrument shows the fuel level in the tank.

When the tank is full, the needle moves completely to the right.

When the tank is less than ¼ full, the needle moves into the yellow area.



BRAG12TRALL0377 3

If the battery was left to charge and rest, the electrolyte will be denser at the base of the elements. Periodically shake the battery to mix the electrolyte. This will improve charge amperage and will give more accurate readings.

Wiring harnesses - Electrical schematic sheet 07

DT-DL circuit

Wiring harnesses - Electrical schematic sheet 03


Head and parking lamps, number plate lamp circuit

Contents

Platform, cab, bodywork, and decals - 90


[90.154] Cab doors and hatches	90.1
[90.151] Cab interior	90.2

23. Remove the cover **(1)** to reach the forward and reverse control cable.




22222222 23

24. Unscrew the retaining cable bolt **(1)**.



23222323 24

25. Unscrew the bolt **(1)** from the supporting bracket and take off the pin **(2)**.



25252525 25

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL