

# SHOP MANUAL

## **KOMATSU**

### **PC1250-7**

### **PC1250SP-7**

### **PC1250LC-7**

| MACHINE MODEL | SERIAL No. |
|---------------|------------|
|---------------|------------|

|                 |                     |
|-----------------|---------------------|
| <b>PC1250-7</b> | <b>20001 and up</b> |
|-----------------|---------------------|

|                   |                     |
|-------------------|---------------------|
| <b>PC1250SP-7</b> | <b>20001 and up</b> |
|-------------------|---------------------|

|                   |                     |
|-------------------|---------------------|
| <b>PC1250LC-7</b> | <b>20001 and up</b> |
|-------------------|---------------------|

- This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you may require. Materials and specifications are subject to change without notice.
- PC1250-7 mounts the SAA6D170E-3 engine.  
For details of the engine, see the 6D170-3 Series Engine Shop Manual.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

# FOREWORD

## GENERAL

This shop manual has been prepared as an aid to improve the quality of repairs by giving the serviceman an accurate understanding of the product and by showing him the correct way to perform repairs and make judgments. Make sure you understand the contents of this manual and use it to full effect at every opportunity.

This shop manual mainly contains the necessary technical information for operations performed in a service workshop. For ease of understanding, the manual is divided into the following chapters; these chapters are further divided into the each main group of components.

### STRUCTURE AND FUNCTION

This section explains the structure and function of each component. It serves not only to give an understanding of the structure, but also serves as reference material for troubleshooting.

In addition, this section may contain hydraulic circuit diagrams, electric circuit diagrams, and maintenance standards.

### TESTING AND ADJUSTING

This section explains checks to be made before and after performing repairs, as well as adjustments to be made at completion of the checks and repairs.

Troubleshooting charts correlating "Problems" with "Causes" are also included in this section.

### DISASSEMBLY AND ASSEMBLY

This section explains the procedures for removing, installing, disassembling and assembling each component, as well as precautions for them.

### MAINTENANCE STANDARD

This section gives the judgment standards for inspection of disassembled parts.

The contents of this section may be described in STRUCTURE AND FUNCTION.

### OTHERS

This section mainly gives hydraulic circuit diagrams and electric circuit diagrams.

In addition, this section may give the specifications of attachments and options together.

### NOTICE

The specifications contained in this shop manual are subject to change at any time and without any advance notice. Use the specifications given in the book with the latest date.

**ELECTRIC WIRE CODE**

In the wiring diagrams, various colors and symbols are employed to indicate the thickness of wires.

This wire code table will help you understand WIRING DIAGRAMS.

Example: 5WB indicates a cable having a nominal number 5 and white coating with black stripe.

**CLASSIFICATION BY THICKNESS**

| Nominal number | Copper wire       |                                    |                                  | Cable O.D. (mm) | Current rating (A) | Applicable circuit              |
|----------------|-------------------|------------------------------------|----------------------------------|-----------------|--------------------|---------------------------------|
|                | Number of strands | Dia. of strands (mm <sup>2</sup> ) | Cross section (mm <sup>2</sup> ) |                 |                    |                                 |
| 0.85           | 11                | 0.32                               | 0.88                             | 2.4             | 12                 | Starting, lighting, signal etc. |
| 2              | 26                | 0.32                               | 2.09                             | 3.1             | 20                 | Lighting, signal etc.           |
| 5              | 65                | 0.32                               | 5.23                             | 4.6             | 37                 | Charging and signal             |
| 15             | 84                | 0.45                               | 13.36                            | 7.0             | 59                 | Starting (Glow plug)            |
| 40             | 85                | 0.80                               | 42.73                            | 11.4            | 135                | Starting                        |
| 60             | 127               | 0.80                               | 63.84                            | 13.6            | 178                | Starting                        |
| 100            | 217               | 0.80                               | 109.1                            | 17.6            | 230                | Starting                        |

**CLASSIFICATION BY COLOR AND CODE**

| Priority | Classification | Circuits |               |          |                |              |                |                |               |
|----------|----------------|----------|---------------|----------|----------------|--------------|----------------|----------------|---------------|
|          |                | Charging | Ground        | Starting | Lighting       | Instrument   | Signal         | Other          |               |
| 1        | Primary        | Code     | W             | B        | B              | R            | Y              | G              | L             |
|          |                | Color    | White         | Black    | Black          | Red          | Yellow         | Green          | Blue          |
| 2        | Auxiliary      | Code     | WR            | —        | BW             | RW           | YR             | GW             | LW            |
|          |                | Color    | White & Red   | —        | White & Black  | Red & White  | Yellow & Red   | Green & White  | Blue & White  |
| 3        |                | Code     | WB            | —        | BY             | RB           | YB             | GR             | LR            |
|          |                | Color    | White & Black | —        | Black & Yellow | Red & Black  | Yellow & Black | Green & Red    | Blue & Yellow |
| 4        |                | Code     | WL            | —        | BR             | RY           | YG             | GY             | LY            |
|          |                | Color    | White & Blue  | —        | Black & Red    | Red & Yellow | Yellow & Green | Green & Yellow | Blue & Yellow |
| 5        |                | Code     | WG            | —        | —              | RG           | YL             | GB             | LB            |
|          |                | Color    | White & Green | —        | —              | Red & Green  | Yellow & Blue  | Green & Black  | Blue & Black  |
| 6        |                | Code     | —             | —        | —              | RL           | YW             | GL             | —             |
|          |                | Color    | —             | —        | —              | Red & Blue   | Yellow & White | Green & Blue   | —             |

**DIMENSIONS**

|   | Item                      | Unit | PC1250-7 | PC1250SP-7 | PC1250LC-7<br>(Only North America) |
|---|---------------------------|------|----------|------------|------------------------------------|
| A | Overall length            | mm   | 16,020   | 14,790     | 16,020                             |
| B | Overall height            | mm   | 6,040    | 6,265      | 6,040                              |
| C | Overall width             | mm   | 5,355    | 5,355      | 5,355                              |
| D | Track shoe width          | mm   | 700      | 700        | 1,000                              |
| E | Height of cab             | mm   | 4,120    | 4,120      | 4,120                              |
| F | Tail swing radius         | mm   | 4,870    | 4,870      | 4,870                              |
| G | Track overall length      | mm   | 6,425    | 6,425      | 7,400                              |
| H | Length of track on ground | mm   | 4,995    | 4,995      | 5,970                              |
| I | Min. ground clearance     | mm   | 990      | 990        | 990                                |

**WORKING RANGES**

|   | Item                       | Unit | PC1250-7 | PC1250SP-7 | PC1250LC-7<br>(Only North America) |
|---|----------------------------|------|----------|------------|------------------------------------|
| A | Max. digging reach         | mm   | 15,350   | 14,070     | 15,350                             |
| B | Max. digging depth         | mm   | 9,350    | 7,900      | 9,350                              |
| C | Max. digging height        | mm   | 13,400   | 13,000     | 13,400                             |
| D | Max. vertical wall depth   | mm   | 7,610    | 5,025      | 7,610                              |
| E | Max. dumping height        | mm   | 8,680    | 8,450      | 8,680                              |
| F | Max. reach at ground level | mm   | 15,000   | 13,670     | 15,000                             |

Unit: kg

| Machine model                  | PC1250-7 (Loading shovel specification) |
|--------------------------------|---|
| Serial Number                  | 20001 and up                            |
| Track shoe assembly            |   |
| • Standard shoe (700 mm)       | 10,630                                  |
| • Wide shoe (1,000 mm)         | 12,940                                  |
| • Wide shoe (1,200 mm)         | —                                       |
| Boom assembly (excl. piping)   | 6,190                                   |
| Arm assembly (excl. piping)    | 4,970                                   |
| Bucket assembly (excl. piping) | 9,730                                   |
| Boom cylinder assembly         | 1,073 x 2                               |
| Arm cylinder assembly          | 602 x 2                                 |
| Bottom dump cylinder assembly  | 194 x 2                                 |
| Bucket cylinder assembly       | 845 x 2                                 |
| Boom foot pin                  | 72 x 2                                  |
| Boom cylinder foot pin         | 43.8 x 2                                |
| Boom cylinder top pin          | 43.8 x 2                                |
| Boom-arm connecting pin        | 80.6 x 2                                |
| Arm cylinder foot pin          | 24.2 x 2                                |
| Arm cylinder top pin           | 24.2 x 2                                |
| Bottom dump cylinder top pin   | 15.2 x 2                                |
| Bottom dump cylinder foot pin  | 23.1 x 2                                |
| Bucket cylinder top pin        | 50 x 2                                  |
| Bucket cylinder foot pin       | 42.9 x 2                                |
| Arm-bucket connecting pin      | 67.9 x 2                                |
| Bucket connecting pin          | 33.1 x 2                                |



SUP04896

- |                               |   |                                 |
|-------------------------------|---|---------------------------------|
| 1. Idler                      | 9. PTO  | 15. Swing brake solenoid valve  |
| 2. Center swivel joint        | 10. No. 3 pump (HPV160+160)   | 16. Travel speed solenoid valve |
| 3. Swing motor (KMF160AB-2)   | 11. No. 1 pump (HPV95+95)   | 17. Swing machinery             |
| 4. L.H. 5-spool control valve | 12. No. 2 pump (HPV95+95)   | 18. Swing circle                |
| 5. R.H. 4-spool control valve | 13. Control, PTO lubricating,<br>aftercooler fan drive pump<br>(SAR100+020+010) | A. Swing 4-spool control valve  |
| 6. Final drive, sprocket      | 14. Swing 4-spool control valve   | B. Swing brake solenoid valve   |
| 7. Travel motor (MSF340VP)    |   |                                 |
| 8. Engine (SAA6D170E-3)       |   |                                 |

**TRACK SHOE**


**Standard shoe**

| Item \ Model             | PC1250-7 | PC1250SP-7 | PC1250LC-7 |
|--------------------------|----------|------------|------------|
| Shoe width (double shoe) | 700 mm   | 700 mm     | 1000 mm    |
| Link pitch               | 280 mm   | 280 mm     | 280 mm     |
| No. of shoes (each side) | 48       | 48         | 55         |

Unit: mm

| No. | Check item                         | Criteria           |                     |                                     |              | Remedy               |                   |
|-----|------------------------------------|--------------------|---------------------|-------------------------------------|--------------|----------------------|-------------------|
|     |                                    |                    | Standard size       | Tolerance                           | Repair limit |                      |                   |
| 10  | Top-to-bottom width of idler guide | Track frame        | 200                 | 200±2                               | 205          | Rebuild or replace   |                   |
|     |                                    | Idler support      | 195                 | 195±1.2                             | 185          | Replace              |                   |
| 11  | Left-to-right width of idler guide | Track frame        | 395                 | 395±2                               | 405          | Rebuild or replace   |                   |
|     |                                    | Idler support      | 391                 | 391 <sup>+1.4</sup> <sub>-0.8</sub> | 383          | Replace              |                   |
| 12  | Recoil spring                      | Standard size      |                     |                                     | Repair limit |                      |                   |
|     |                                    | Free length x O.D. | Installation length | Installation load                   | Free length  |                      | Installation load |
|     |                                    | 1,508 x 351        | 1,280               | 578.2 kN {58,957 kg}                | —            | 460.9 kN {47,000 kg} |                   |


## AIR CIRCUIT DIAGRAM



9JG00066

1. Air compressor (capacity: 70 l/600 rpm)
2. Unloader valve
3. Air governor (cut-out pressure:  $0.71 \pm 0.03$  MPa { $7.2 \pm 0.3$  kg/cm<sup>2</sup>})  
(cut-in pressure:  $0.59 \pm 0.03$  MPa { $6.0 \pm 0.3$  kg/cm<sup>2</sup>})
4. Check valve
5. Air tank
6. Safety valve (set pressure:  $0.95_{-0.05}^0$  MPa { $9.7_{-0.5}^0$  kg/cm<sup>2</sup>})
7. Battery
8. Horn switch
9. Horn valve
10. Air horn
11. Grease pump
12. Grease reel
13. Lock valve
14. Grease gun

# HYDRAULIC TANK



9JG00071

- 1. Hydraulic tank
- 2. Strainer
- 3. Oil filler cap
- 4. Pressure valve
- 5. Safety valve
- 6. Return filter
- 7. Drain filter
- 8. Sight gauge
- 9. Hydraulic oil temperature gauge
- 10. Suction strainer
- 11. Drain valve

**Specifications**


Tank capacity: 1,146 l  
 Amount of oil inside tank: 664 l (at H level)

**Pressure valve**

Relief cracking pressure: 16.7 ± 6.9 kPa  
 {0.17 ± 0.07 kg/cm<sup>2</sup>}  
 Suction cracking pressure: 0 – 0.49 kPa  
 {0 – 0.005 kg/cm<sup>2</sup>}

Operation

1) Operation in direction of increase of pump discharge amount (max. angle)




SDP01550

- The control pump pressure **Psv** is taken to port **a**. Signal pressure **Pecn** from the NC valve is taken from port **b** to chamber **c**.
- When signal pressure **Pecn** rises, control piston (8) is pushed to the left by the hydraulic pressure in chamber **c**, and stops at a point where it balances the pressure of springs (4) and (4A).
- At the same time, arm (6) uses servo piston (19) as a fulcrum and sways to the left in the same way as control piston (8). This moves guide spool (13) to the left.
- When guide spool (13) moves, port **a** and port **d** are closed and port **d** is connected to drain chamber **e**.
- As a result, servo piston chamber **f** is also interconnected with chamber **e** through port **g** and port **d**.
- At the same time, port **a** is interconnected with port **h**, so the oil flows through port **i** to servo piston chamber **j**, pushes servo piston (19) to the left, increases the swash plate angle in the main piston pump and increases the pump discharge amount.
- When servo piston (19) moves, arm (6) rotates clockwise with its center at pin (7). Guide spool (13) is moved to the right and closes port **a**, port **d** and port **h**, so the discharge increases by an amount that matches signal pressure **Pecn**.

**FUNCTION AND OPERATION OF CO VALVE**

**1) When main pump discharge pressure is lower than relief pressure**



SDP01565


**Function**

- When the load becomes large during operations and the main pump discharge pressure rises to a point close to relief pressure, the cut-off function of the CO valve acts to reduce the pump discharge in order to reduce relief loss.
- At the same time, it has a cut-off cancel function actuated by the pilot pressure from the heavy-lift solenoid valve.
- The CO valve is controlled by balancing the spring with the total of main pump discharge pressure **PA** and CO valve output pressure **Pec**.

**Operation**

- Spool (4) is being pushed down fully by spring (3).
- As a result, port **a** and port **b** are fully open and TVC valve output pressure **Pe** and CO valve output pressure **Pec** are equal.
- In this way, CO valve output pressure **Pec** becomes the maximum and the main pump discharge amount also becomes the maximum.

**NO. 3 PUMP**  
HPV160+160




9JY01243

- 1. Front pump
- 2. Front servo valve
- 3. Front CO, NC valve
- 4. Rear servo valve
- 5. Rear pump

- PA1** : Discharge port
- PA2** : Discharge port
- Pd11** : Drain port
- Pd21** : Drain port
- Pc** : CO selector pilot port
- Pd** : Jet sensor downstream pressure IN port

- Pe** : TVC valve output pressure IN port
- Ps** : Suction port
- Pt** : Jet sensor upstream pressure IN port
- Psv** : Servo basic pressure IN port

## PILOT OIL FILTER



SUP04939

1. Relief valve
2. Case
3. Element
4. Center bolt






### Outline

The pilot oil filter is installed to the discharge side of the control pump and protects the PPC valve and other pilot pressure equipment.

Unit: mm

| No. | Check item                                   | Criteria              |                        |                      |              |                      | Remedy                                |
|-----|--|-----------------------|------------------------|----------------------|--------------|----------------------|---------------------------------------|
|     |  | Standard size         |                        |                      | Repair limit |                      |                                       |
|     |  | Free length<br>x O.D. | Installation<br>length | Installation<br>load | Free length  | Installation<br>load |                                       |
| 1   | Main relief valve, main valve spring         | 34.7 x 10.4           | 32.5                   | 394.2 N<br>{40.2 kg} | —            | 315.2 N<br>{32.2 kg} | Replace spring if damaged or deformed |
| 2   | Jet sensor relief valve, pilot poppet spring | 34.5 x 10.8           | 29.4                   | 30 N<br>{3.1 kg}     | —            | 24.3 N<br>{2.5 kg}   |                                       |
| 3   | Jet sensor relief valve, main valve spring   | 37.4 x 11.4           | 33                     | 49 N<br>{5.0 kg}     | —            | 39.2 N<br>{4.0 kg}   |                                       |
| 4   | Spool return spring                          | 69.9 x 57             | 63                     | 431 N<br>{44 kg}     | —            | 345 N<br>{35.2 kg}   |                                       |
| 5   | Spool return spring                          | 75 x 37               | 74.5                   | 0 N<br>{0 kg}        | —            | 0 N<br>{0 kg}        |                                       |
| 6   | Check valve spring                           | 78.2 x 26.6           | 52                     | 18.8 N<br>{1.92 kg}  | —            | 15.1 N<br>{1.54 kg}  |                                       |
| 7   | Check valve spring                           | 53.6 x 31             | 39                     | 18.8 N<br>{1.92 kg}  | —            | 15.1 N<br>{1.54 kg}  |                                       |

**SWING MOTOR**  
KMF160AB-2



SUP04951


- 1. Swing motor
- 2. Swing holding brake

- B** : From swing holding brake solenoid valve
- S** : From tank
- T1** : To tank
- T2** : From cooling piping port S
- MA**: From swing control valve port B1
- MB**: From Swing control valve port A1

**Specifications**

Model: KMF160AB-2  
 Theoretical discharge: 160.7 cc/rev  
 Rated speed: 1830 rpm  
 Brake release pressure:  
 1.8 ± 0.4 MPa {18.4 ± 4 kg/cm<sup>2</sup>}

### 1-4 Relief valve




SWP08666

#### Function

In addition to the pressure control function, this relief valve has a shockless function (2-stage pressure increase function). This acts to reduce the shock generated at the beginning when the speed is reduced (when the machine is stopped).

Unit: mm

| No. | Check item                    | Criteria            |                        |                      |                |                      | Remedy  |
|-----|-------------------------------|---------------------|------------------------|----------------------|----------------|----------------------|---|
|     |                               | Standard size       |                        |                      | Repair limit   |                      |   |
|     |                               | Free length<br>× OD | Installation<br>length | Installation<br>load | Free<br>length | Installation<br>load |   |
| 11  | Centering spring (for P3, P4) | 42.48 × 15.5        | 34                     | 17.6 N<br>{1.8 kg}   | —              | 13.7 N<br>{1.4 kg}   | Replace<br>spring if<br>damaged<br>or<br>deformed |
| 12  | Metering spring               | 26.7 × 8.14         | 24.9                   | 16.6 N<br>{1.69 kg}  | —              | 13.2 N<br>{1.35 kg}  |   |
| 13  | Centering spring (for P1, P2) | 38.71 × 15.5        | 34                     | 9.8 N<br>{1 kg}      | —              | 7.8 N<br>{0.8 kg}    |   |



9JG00076


- 1. Plug
- 2. Spring
- 3. Spool
- 4. Block

- 5. Connector
- 6. Solenoid
- 7. Movable iron core

**Operation**

**When solenoid is de-energized**


- When the signal current does not flow from the PPC lock switch or swing lock switch, solenoid (6) is de-energized. For this reason, spool (3) is pushed fully to the left by spring (2). As a result, the circuit between ports **P** and **A** closes and the pressurized oil from the control pump does not flow to the actuator. At the same time, the pressurized oil from the actuator flows from port **A** to port **T**, and is then drained to the tank.




SJP09434

**When solenoid is energized**

- When the signal current flows from the PPC lock switch or swing lock switch to solenoid (6), solenoid (6) is energized. For this reason, spool (3) is pushed to the right in the direction of the arrow. As a result, the pressurized oil from the control pump flows from port **P** through the inside of spool (3) to port **A**, and then flows to the actuator. At the same time, port **T** is closed, and this stops the oil from flowing to the tank.



SJP09435




SUP05155

Unit: mm

| No.   | Check item   | Criteria      |                  |                  |                    | Remedy       |                 |
|-------|--|---------------|------------------|------------------|--------------------|--------------|-----------------|
|       |  | Standard size | Tolerance        |                  | Standard clearance |              | Clearance limit |
| Shaft | Hole   |               |                  |                  |                    |              |                 |
| 1     | Clearance between bushing and mounting pin of boom and revolving frame | 160           | -0.043<br>-0.106 | +0.436<br>+0.350 | 0.393 –<br>0.542   | 1.5          | Replace         |
| 2     | Clearance between bushing and mounting pin of boom and arm             | 160           | -0.043<br>-0.106 | +0.172<br>+0.085 | 0.128 –<br>0.278   | 1.5          |                 |
| 3     | Clearance between bushing and mounting pin of arm and link             | 140           | -0.043<br>-0.106 | +0.404<br>+0.321 | 0.364 –<br>0.510   | 1.5          |                 |
| 4     | Clearance between bushing and mounting pin of arm and bucket           | 140           | -0.043<br>-0.106 | +0.397<br>+0.312 | 0.355 –<br>0.503   | 1.5          |                 |
| 5     | Clearance between bushing and mounting pin of link and link            | 140           | -0.043<br>-0.106 | +0.397<br>+0.312 | 0.355 –<br>0.503   | 1.5          |                 |
| 6     | Clearance between bushing and mounting pin of link and bucket          | 140           | -0.043<br>-0.106 | +0.404<br>+0.321 | 0.364 –<br>0.510   | 1.5          |                 |
| 7     | Bucket clearance   | 0.5 – 1.0     |                  |                  |                    | Adjust shims |                 |

**Engine speed control**

- The fuel control dial sends a signal voltage that matches the angle position to the engine controller.  
The engine controller calculates the engine speed to match that signal voltage and controls the control valve and fuel pump so that the engine runs at that speed.



SJP09437


**Operation**

**Control levers at neutral**

- If the engine is running at above the deceleration actuation speed (approx. 1300 rpm), and all the control levers are returned to neutral, the engine speed drops immediately to approx. 100 rpm below the set speed to the No. 1 deceleration position.
- If another 4 seconds passes, the engine speed is reduced to the No. 2 deceleration position (approx. 1300 rpm), and is kept at that speed until a lever is operated.


**When control lever is operated**

- If any control lever is operated when the engine speed is at No. 2 deceleration, the engine speed will immediately rise to the speed set by the fuel control dial.




SJP09441

- 1) Engine automatic warming-up function
- After the engine is started, if the engine coolant temperature is low, the engine speed is automatically raised to warm the engine.





- 2) Engine overheat prevention function
- This function protects the engine by lowering the pump load and engine speed to prevent overheating when the engine coolant temperature has risen too high.
  - This system is actuated at 105°C and above.









### 12. Components of system

#### Pump controller



9JG00105

Checks before starting (caution lamps all light up), when maintenance interval is exceeded. If the checks before starting or maintenance interval is exceeded items light up, the display of the hydraulic oil temperature gauge and the hydraulic oil temperature monitor are stopped, and the following cautions are displayed.


| Symbol  | Display item           | Check before starting item | When engine is stopped  | When engine is running   |
|---|------------------------|----------------------------|-------------------------|--|
| <br>SAP00520   | Engine oil pressure    | ●                          | —                       | When abnormal, lights up and buzzer sounds   |
| <br>SAP00522   | Battery charge         | ●                          | —                       | Lights up when abnormal  |
| <br>SAP00523   | Radiator coolant level | ●                          | Lights up when abnormal | When abnormal, lights up and buzzer sounds   |
| <br>SAP00519 | Engine oil level       | ●                          | Lights up when abnormal | —  |
| <br>SAP00521 | Air cleaner clogging   | ●                          | —                       | Lights up when abnormal  |
| <br>SJP08780 | Maintenance            |                            |                         | Lights up when there is a warning. Lights up for only 30 sec. after key is turned ON, then goes out. |

The problems that have occurred are displayed in order from the left.

When the above cautions are displayed, if the hydraulic oil temperature is high or low, only the symbol is displayed.

| Condition of hydraulic oil               | Color of symbol           |
|--|---------------------------|
| Low temperature (below B6 or equivalent) | Black on white background |
| Normal (B6 – B2)                         | No display                |
| High temperature (above B2)              | White on red background   |

- If the telephone number has been set using the telephone number input on the service menu, it is possible to switch on the service code/failure code and display the telephone symbol and telephone number. For details of inputting and setting the telephone number, see SPECIAL FUNCTIONS OF MONITOR PANEL in the TESTING AND ADJUSTING section.



SJP09581

---

# 20 TESTING AND ADJUSTING

---

## STANDARD VALUE TABLE

|  |      |
|--|------|
| STANDARD VALUE TABLE FOR ENGINE RELATED PARTS .....  | 20-2 |
| STANDARD VALUE TABLE FOR CHASSIS RELATED PARTS ..... | 20-6 |

|                             |        |
|-----------------------------|--------|
| TESTING AND ADJUSTING ..... | 20-101 |
|-----------------------------|--------|

|                       |        |
|-----------------------|--------|
| TROUBLESHOOTING ..... | 20-201 |
|-----------------------|--------|

★ Note the following when making judgements using the standard value tables for testing, adjusting, or troubleshooting.



1. The standard value for a new machine given in the table is the value used when shipping the machine from the factory and is given for reference. It is used as a guideline for judging the progress of wear after the machine has been operated, and as a reference value when carrying out repairs.
2. The service limit value given in the tables is the estimated value for the shipped machine based on the results of various tests. It is used for reference together with the state of repair and the history of operation to judge if there is a failure.
3. These standard values are not the standards used in dealing with claims.

**⚠ When carrying out testing, adjusting, or troubleshooting, park the machine on level ground, insert the safety pins, and use blocks to prevent the machine from moving.**

**⚠ When carrying out work together with other workers, always use signals and do not let unauthorized people near the machine.**

**⚠ When checking the coolant level, always wait for the coolant to cool down. If the radiator cap is removed when the coolant is still hot, the coolant will spurt out and cause burns.**

**⚠ Be careful not to get caught in the fan, fan belt or other rotating parts.**

| Applicable Model |                           |   |       | PC1250-7, PC1250LC-7,<br>PC1250SP-7 |                     |
|------------------|---------------------------|---|-------|-------------------------------------|---------------------|
| Category         | Item                      | Measuring Conditions  | Unit  | Standard value for new machine      | Service limit value |
| Travel           | Hydraulic drift of travel | <p>Work equipment posture</p>  <p>BVP03108</p> <ul style="list-style-type: none"> <li>• Engine stopped</li> <li>• Hydraulic oil temperature: 45 – 55°C</li> <li>• Stop machine on 12° slope with sprocket at uphill end of machine.</li> <li>• Do not place the work equipment on the ground.</li> <li>• Measure the distance the machine moves in 5 minutes.</li> </ul> | mm    | 0                                   | 0                   |
|                  | Leakage of travel motor   | <p>Work equipment posture</p>  <p>Lock pin TVP01443</p> <ul style="list-style-type: none"> <li>• Engine at full throttle</li> <li>• Hydraulic oil temperature: 45 – 55°C</li> <li>• Lock shoes and relieve travel circuit.</li> </ul>   | ℓ/min | Max. 20                             | Max. 40             |




# MEASURING AIR SUPPLY PRESSURE (BOOST PRESSURE)

- ★ Tools for measuring air supply pressure (boost pressure)


| Symbol | Part No.     | Part Name       |
|--------|--------------|-----------------|
| A      | 799-201-2202 | Boost gauge kit |

- ⚠ Be careful not to touch any hot parts when removing or installing the measuring tools.
- ★ Measure the air supply pressure (boost pressure) under the following conditions.
  - Coolant temperature: Within operating range
  - Hydraulic oil temperature: Within operating range

1. Remove air supply pressure measurement plug (1).



2. Fit nipple [1] of boost gauge kit A, then connect gauge [2].



3. Run the engine at a mid-range speed or above to bleed the oil from the hose.
  - ★ Insert the connection of the hose and pressure gauge about half way, repeat the action to open the self-seal portion at the hose end, and bleed the oil.
  - ★ If Pm kit (A) is available, the air bleed coupling (790-261-1130) inside the kit can be used.

- ★ If there is oil inside the hose, the gauge will not work, so always bleed the oil.

4. Run the engine at high idle under the following condition and measure the intake air pressure (boost pressure).
  - Working mode switch: A-mode
  - Heavy lift switch: ON
  - Work equipment, swing, travel: Relieve circuit by raising boom.




5. After completing the measurement, remove the measuring equipment and set to the original condition.

# MEASURING ENGINE OIL PRESSURE


- ★ Tools for measuring engine oil pressure

| Symbol | Part No. | Part Name                             |
|--------|----------|---------------------------------------|
| H      | 1        | 799-101-5002 Hydraulic tester         |
|        |          | 790-261-1203 Digital hydraulic tester |
|        | 2        | 799-401-2320 Hydraulic tester         |


- ★ Measure the engine oil pressure under the following conditions.
  - Engine oil temperature: Min. 80°C
  - Coolant temperature: Within operating range
- ★ The engine oil pressure can be checked with the monitoring function of the monitor panel (For the operating method, see SPECIAL FUNCTION OF MONITOR PANEL).
  - Monitoring code: **372** (Engine oil pressure)
  - The engine oil pressure is displayed in units of 1 kPa (1 kg/cm<sup>2</sup>, 1 PSI).



1. Remove oil pressure measurement plug (1).



2. Fit nipple [1] of hydraulic tester H1, then connect to hydraulic tester H2.



3. Start the engine, and measure the oil pressure at low idle and high idle.




4. After completing the measurement, remove the measuring equipment and set to the original condition.

## ADJUSTING ENGINE SPEED SENSOR

★ If the engine speed sensor has been removed and installed or the flywheel has been removed or installed, adjust as follows.

1. Remove engine speed sensor (1).

- ★ Before adjusting, remove the engine speed sensor, check that the tip of the sensor is not scratched and that there are no iron particles sticking to it, then install it again.



2. Screw in sensor (1) until the tip of the sensor contacts the tip of the tooth of flywheel ring gear (2).


- 🔧 Thread: **Loctite hydraulic sealant (No. 21028)**

3. Return sensor (1) by the specified angle from that position.

- ★ Angle to return: 1/2 – 3/4 turns
- ★ Adjust clearance **a** between the tip of the sensor and the tip of the gear tooth so that it is 0.75 – 1.25 mm.

4. Secure sensor (1) in position, then tighten locknut (3).

- 🔧 Locknut: **33.9 – 47.5 Nm {3.5 – 4.8 kgm}**



5. After completing the adjustment, switch the monitor panel to the monitoring display, and check that the engine speed is displayed normally.


- ★ For details of the method of operation, see SPECIAL FUNCTION OF MONITOR PANEL.
- Monitoring code: 010 Engine speed

**Adjusting**

- ★ Do not adjust any safety valve other than the swing motor safety valve.

**1. Adjusting main relief valve (high-pressure setting) of R.H. 4-spool control valve**

- ★ If the work equipment hydraulic pressure in the front pump circuit (during machine push-up operation) and the right travel hydraulic pressure are abnormal, adjust the high pressure setting side of main relief valve (7) of the R.H. 4-spool control valve according to the following procedure.



- ★ The high pressure setting is the state in which the 2-stage relief solenoid valve is turned ON and the pilot pressure is applied to the changeover port.

- 1) Disconnect hose (8).
- 2) Loosen locknut (9) and set elbow (10) free.
- 3) Fix holder (11) and loosen locknut (12).
- 4) Turn holder (11) to adjust the pressure.


- ★ If the holder is
  - turned to the right, the pressure rises.
  - turned to the left, the pressure lowers.

- ★ Pressure changed by 1 turn of holder:  
21.8 MPa {222 kg/cm<sup>2</sup>}

- 5) Fix holder (11) and tighten locknut (12).

- ☞ Locknut:  
**93 – 123 Nm {9.5 – 12.5 kgm}**

- ★ If the high pressure setting side is adjusted, the low pressure setting side changes. Accordingly, adjust the low pressure setting side, too.



- 6) Fix elbow (10) and tighten locknut (9).
- 7) Connect hose (8).
- 8) After finishing adjustment, check the hydraulic pressure again according to the above described measurement procedure.

**2. Adjusting main relief valve (low-pressure setting) of R.H. 4-spool control valve**

- ★ If the work equipment hydraulic pressure in the front pump circuit (during normal relief operation) is abnormal or the high pressure setting side was adjusted, adjust the low pressure setting side of main relief valve (7) of the R.H. 4-spool control valve according to the following procedure.


- ★ The low pressure setting is the state in which the 2-stage relief solenoid valve is turned OFF and the pilot pressure is not applied to the changeover port.

- 1) Disconnect hose (8).
- 2) Loosen locknut (9) and set elbow (10) free.
- 3) Fix union (14) and loosen locknut (15).
- 4) Turn union (14) to adjust the pressure.

- ★ If the union is
  - turned to the right, the pressure rises.
  - turned to the left, the pressure lowers.


- ★ Pressure changed by 1 turn of union:  
21.8 MPa {222 kg/cm<sup>2</sup>}

- (14): Front NC valve of No. 1 pump
- (15): Rear NC valve of No. 1 pump




- 1) Adjusting CO valve side
  - i) Fix adjustment screw (16) and loosen locknut (17).
  - ii) Turn adjustment screw (16) to adjust the pressure.
    - ★ If the adjustment screw is
      - turned to the right, the pressure rises.
      - turned to the left, the pressure lowers.
    - ★ Pressure changed by 1 turn of adjustment screw: 2.20 MPa {22.4 kg/cm<sup>2</sup>}
  - iii) Fix adjustment screw (16) and tighten locknut (17).


 Locknut:  
5.9 – 9.8 Nm {0.6 – 1.0 kgm}



- iv) After finishing adjustment, check the oil pressure again according to the above described measurement procedure.

- 2) Adjusting NC valve side
  - i) Fix adjustment screw (18) and loosen locknut (19).
  - ii) Turn adjustment screw (18) to adjust the pressure.
    - ★ If the adjustment screw is
      - turned to the right, the pressure rises.
      - turned to the left, the pressure lowers.
    - ★ Pressure changed by 1 turn of adjustment screw: 0.42 MPa {4.3 kg/cm<sup>2</sup>}
  - iii) Fix adjustment screw (18) and tighten locknut (19).


 Locknut:  
5.9 – 9.8 Nm {0.6 – 1.0 kgm}



- iv) After finishing adjustment, check the oil pressure again according to the above described measurement procedure.



### 3. Adjusting CO-NC valves of No. 3

- ★ If the CO-NC valve output pressure of the No. 3 pump is abnormal, adjust CO valve (20) and NC valve (21) of the No. 3 pump according to the following procedure.
- (20): CO valve of No. 3 pump



## TESTING TRAVEL DEVIATION

- ★ When traveling on level ground.
  1. Set the machine in the travel posture.
    - ★ For the travel posture, extend the bucket and arm cylinder rods fully, and hold the boom angle at 45°.
  2. Operate with the engine at full throttle, run up for 10 m, then measure the deviation **A** over the next 20 m.
    - ★ Install the oil pressure gauge and measure the pump discharge pressure at the same time.



## RELEASING REMAINING PRESSURE IN HYDRAULIC CIRCUIT


- ★ If the piping between the hydraulic cylinder and the control valve is to be disconnected, release the remaining pressure from the circuit as follows.
  - ★ The travel circuit is an open circuit, so there is no remaining pressure. It is enough to remove the oil filler cap.
1. Loosen the oil filler cap slowly to release the pressure inside the tank.
  2. Operate the control levers.
    - ★ When the levers are operated 2 – 3 times, the pressure stored in the accumulator is removed.
  3. Start the engine, run at low idle for approx. 5 minutes, then stop the engine and operate the control levers.
    - ★ Repeat the above operation 2 – 3 times to release all the remaining pressure.

| User code | User code |                               | Failure code |   |   | History division  |
|-----------|-----------|-------------------------------|--------------|---|---|-------------------|
|           | Code      | Contents                      | Code         | Component   | Trouble   |                   |
| E15       | C441      | Battery Voltage               | C441KK       | Battery voltage   | Lowering of source voltage (Input)                                  | Electrical system |
| E15       | C442      | Battery Voltage               | C442KG       | Battery voltage   | Rise of source voltage (Overcharge)                                 | Electrical system |
| E10       | C451      | Fuel Rail P. Sensor           | C451KX       | Fuel rail pressure sensor                               | Out of input signal range   | Electrical system |
| E10       | C452      | Fuel Rail P. Sensor           | C452KX       | Fuel rail pressure sensor                               | Out of input signal range   | Electrical system |
| E10       | C455      | Fuel Rail Actuator Circuit    | C455KZ       | Fuel rail actuator                                      | Disconnection or short circuit                                      | Electrical system |
| E11       | C467      | Timing Actuator Control       | C467LK       | Timing actuator   | Disagreement of feedback signal and output signal                   | Electrical system |
| E11       | C468      | Rail Actuator Control         | C468LK       | Fuel rail actuator                                      | Disagreement of feedback signal and output signal                   | Electrical system |
| E10       | C514      | Rail Actuator Stuck           | C514LK       | Fuel rail actuator                                      | Disagreement of feedback signal and output signal                   | Electrical system |
| E11       | C554      | Fuel Rail P. In Range Error   | C554L6       | Fuel rail pressure sensor                               | Disagreement of signals and run/stop of engine                      | Electrical system |
| —         | E101      | Abnormality Error Record      | DAF0KT       | Monitor controller                                      | Internal defect of controller                                       | Electrical system |
| —         | E112      | Wiper Drive (For) S/C         | DY2DKB       | Wiper motor (Forward)                                   | Short circuit   | Electrical system |
| —         | E113      | Wiper Drive (Rev) S/C         | DY2EKB       | Wiper motor (Reverse)                                   | Short circuit   | Electrical system |
| —         | E114      | Washer Drive S/C              | DY2CKB       | Windshield washer motor                                 | Short circuit   | Electrical system |
| —         | E115      | Wiper Working Abnormality     | DY20KA       | Wiper motor   | Disconnection   | Electrical system |
| —         | E116      | Wiper Parking Abnormality     | DY20MA       | Wiper motor   | Malfunction   | Electrical system |
| —         | E201      | CO Cancel Sol. S/C            | DW48KB       | Cut-off cancel solenoid valve                           | Short circuit   | Electrical system |
| —         | E202      | Travel Junction Sol. S/C      | DW91KB       | Travel neutral solenoid valve                           | Short circuit   | Electrical system |
| E03       | E203      | Swing Brake Sol. S/C          | DW45KB       | Swing holding brake solenoid valve                      | Short circuit   | Electrical system |
| —         | E204      | 2-stage Relief Sol. S/C       | DWK0KB       | 2-stage relief solenoid valve                           | Short circuit   | Electrical system |
| —         | E205      | Swing Priority Sol. S/C       | DW41KB       | Swing solenoid valve                                    | Short circuit   | Electrical system |
| —         | E206      | Travel Speed Sol. S/C         | DW43KB       | Travel high-low selector solenoid valve                 | Short circuit   | Electrical system |
| —         | E207      | Flash Light Relay S/C         | D163KB       | Flash light drive relay                                 | Short circuit   | Electrical system |
| —         | E211      | CO Cancel Sol. Disc.          | DW48KA       | Cut-off cancel solenoid valve                           | Disconnection   | Electrical system |
| —         | E212      | Travel Junction Sol. Disc.    | DW91KA       | Travel neutral solenoid valve                           | Disconnection   | Electrical system |
| E03       | E213      | Swing Brake Sol. Disc.        | DW45KA       | Swing holding brake solenoid valve                      | Disconnection   | Electrical system |
| —         | E214      | 2-stage Relief Sol. Disc.     | DWK0KA       | 2-stage relief solenoid valve                           | Disconnection   | Electrical system |
| —         | E215      | Swing Priority Sol. Disc.     | DW41KA       | Swing solenoid valve                                    | Disconnection   | Electrical system |
| —         | E216      | Travel Speed Sol. Disc.       | DW43KA       | Travel high-low selector solenoid valve                 | Disconnection   | Electrical system |
| —         | E217      | Model selection Abnormality   | DA2SKQ       | Engine throttle and pump controller S-NET communication | Disagreement of model selection signals                             | Electrical system |
| —         | E218      | S-Net Comm. Disc.             | DA2SKA       | Engine throttle and pump controller S-NET communication | Disconnection   | Electrical system |
| —         | E221      | J1939 Comm. Error             | DA2RKR       | Engine throttle and pump controller CAN communication   | Defective communication (Abnormality in objective component system) | Electrical system |
| —         | E222      | Working Mode Output S/C (1)   | D5ZJKB       | Working mode signal                                     | Short circuit   | Electrical system |
| —         | E223      | Working Mode Output Disc. (1) | D5ZJKA       | Working mode signal                                     | Disconnection   | Electrical system |
| —         | E224      | Working Mode Output S/C (2)   | D5ZLKB       | Working mode (Hi regulation) signal                     | Short circuit   | Electrical system |


**16. Function for Maintenance Record [03]**

The monitor panel records information on the maintenance of filters and oils. The stored information can be displayed through the following switch operation.

- 1) Selection of menu  
 Select 03 Maintenance Record in Service Menu and depress [✓] switch.



- 2) Information to be displayed
  - [1]: Name of oils and filters
  - [2]: Times of replacement to date
  - [3]: Service meter reading at the latest replacement



3) Monitoring items of automatic snap shot function

| Monitoring item                                   | Failure code | Criterion for abnormality  |
|---|--------------|--|
| Engine speed                                      | C115KZ       | Engine speed is not sensed.  |
| Engine overspeed                                  | C234N1       | Engine speed exceeds 2,900 rpm.  |
|   | A000N1       | Engine speed exceeds 2,625 rpm.  |
| Low engine oil pressure                           | B@BAZG       | Oil pressure is below straight line connecting each couple of following points. <ul style="list-style-type: none"> <li>• Engine speed of 600 rpm and oil pressure of 49 kPa {0.5 kg/cm<sup>2</sup>}</li> <li>• Engine speed of 1,000 rpm and oil pressure of 88 kPa {0.9 kg/cm<sup>2</sup>}</li> <li>• Engine speed of 1,500 rpm and oil pressure of 147 kPa {1.5 kg/cm<sup>2</sup>}</li> <li>• Engine speed of 1,800 rpm and oil pressure of 181 kPa {1.85 kg/cm<sup>2</sup>}</li> <li>• Engine speed of 2,000 rpm and oil pressure of 206 kPa {2.1 kg/cm<sup>2</sup>}</li> </ul> |
| High fuel temperature                             | C261NS       | Fuel temperature exceeds 76°C.   |
| High pump relief pressure                         | DHPAZL       | Relief pressure keeps above 37.3 MPa {380 kg/cm <sup>2</sup> } for 1 second.   |
|   | DHPBZL       |  |
|   | F@HCZL       |  |
| High PTO temperature                              | B@CBNS       | PTO temperature keeps above 125°C for 1 second.  |
| Abnormal gear pump pressure (for pilot)           | J100L6       | When engine speed is above 1,750 rpm and hydraulic oil temperature is above 50°C, <ul style="list-style-type: none"> <li>• gear pump pressure keeps below 2.8 MPa {29 kg/cm<sup>2</sup>} for 5 seconds.</li> <li>• gear pump pressure keeps above 3.7 MPa {38 kg/cm<sup>2</sup>} for 5 seconds.</li> </ul>   |
| Abnormal gear pump pressure (for driving A/A fan) | j100L6       | When engine speed is above 1,750 rpm and hydraulic oil temperature is above 50°C, <ul style="list-style-type: none"> <li>• gear pump pressure keeps below 4.9 MPa {50 kg/cm<sup>2</sup>} for 5 seconds.</li> <li>• gear pump pressure keeps above 22.5 MPa {230 kg/cm<sup>2</sup>} for 5 seconds.</li> </ul>   |
| High exhaust temperature                          | F@BYNS       | When engine speed is below 1,400 rpm, temperature keeps above 750°C for 1 second.  |
|   | F@BZNS       | Exhaust temperature keeps above straight line connecting each couple of following points for 1 second. <ul style="list-style-type: none"> <li>• Engine speed of 1,400 rpm and temperature of 750°C</li> <li>• Engine speed of 1,800 rpm and temperature of 700°C</li> </ul> Engine speed is above 1,800 rpm and temperature keeps above 700°C for 1 second.  |
|   | F@BYNR       | Engine speed is below 1,400 rpm and temperature keeps above 800°C for 10 seconds.  |
|   | F@BZNR       | Exhaust temperature keeps above straight line connecting each couple of following points for 10 seconds. <ul style="list-style-type: none"> <li>• Engine speed of 1,400 rpm and temperature of 800°C</li> <li>• Engine speed of 1,800 rpm and temperature of 750°C</li> </ul> Engine speed is above 1,800 rpm and temperature keeps above 750°C for 10 seconds.  |
| High blow-by pressure                             | F@BBZL       | Blow-by pressure exceeds 8.83 kPa {900 mmAq}   |
| High engine coolant temperature                   | B@BCNS       | Engine coolant temperature exceeds 105°C for 5 seconds.  |

Operating procedure for Quick Pm

| No. | Elapsed time         |                   | Time on snap data       | Fuel dial  | Swing lock switch | Operation of lever  | Data read in Pm clinic after data are downloaded  |
|-----|----------------------|-------------------|-------------------------|------------|-------------------|---|---|
| 1   | Start<br>↓<br>Finish | 0:00<br>↓<br>0:30 | -330.00<br>↓<br>-300.00 | MIN (Low)  | OFF               | Set all levers in neutral.  | <ul style="list-style-type: none"> <li>• Engine speed (Low idle)</li> <li>• Engine oil pressure (Low idle)</li> <li>• Engine coolant temperature</li> <li>• Hydraulic oil temperature</li> <li>• Outside temperature</li> <li>• Control pump pressure (Low idle)</li> </ul> |
| 2   | Start<br>↓<br>Finish | 0:30<br>↓<br>1:00 | -300.00<br>↓<br>-270.00 | MAX (High) | OFF               | Set all levers in neutral (Turn decelerator on).                                    | <ul style="list-style-type: none"> <li>• Engine speed (2nd deceleration speed)</li> </ul>   |
| 3   | Start<br>↓<br>Finish | 1:00<br>↓<br>1:30 | -270.00<br>↓<br>-240.00 | MAX (High) | OFF               | Move levers finely [Note] (Turn decelerator off).                                   | <ul style="list-style-type: none"> <li>• Engine speed (High idle)</li> <li>• Engine oil pressure (High idle)</li> <li>• Control pump pressure (High idle)</li> <li>• Fan pump pressure</li> </ul>   |
| 4   | Start<br>↓<br>Finish | 1:30<br>↓<br>2:30 | -240.00<br>↓<br>-180.00 | MAX (High) | OFF               | Raise right-hand track shoe and drive it idle (Set lever to stroke end).            | <ul style="list-style-type: none"> <li>• Front pump oil pressure (Hydraulic pressure)</li> </ul>  |
| 5   | Start<br>↓<br>Finish | 2:30<br>↓<br>3:30 | -180.00<br>↓<br>-120.00 | MAX (High) | OFF               | Swing 180°. Raise left-hand track shoe and drive it idle (Set lever to stroke end). | <ul style="list-style-type: none"> <li>• Rear pump oil pressure (Hydraulic pressure)</li> </ul>   |
| 6   | Start<br>↓<br>Finish | 3:30<br>↓<br>4:00 | -120.00<br>↓<br>-90.00  | MAX (High) | ON                | R.H. swing relief.  | <ul style="list-style-type: none"> <li>• Swing pump oil pressure (Relief pressure)</li> </ul>   |
| 7   | Start<br>↓<br>Finish | 4:00<br>↓<br>4:30 | -90.00<br>↓<br>-60.00   | MAX (High) | ON                | L.H. swing relief.  | <ul style="list-style-type: none"> <li>• Swing pump oil pressure (Relief pressure)</li> </ul>   |
| 8   | Start<br>↓<br>Finish | 4:30<br>↓<br>5:00 | -60.00<br>↓<br>-30.00   | MAX (High) | ON                | Arm OUT relief.   | <ul style="list-style-type: none"> <li>• Front, rear, swing pump oil pressure (Low relief pressure)</li> </ul>  |
| 9   | Start<br>↓<br>Finish | 5:00<br>↓<br>5:30 | -30.00<br>↓<br>00.00    | MAX (High) | ON                | Bucket DUMP relief.   | <ul style="list-style-type: none"> <li>• Front, rear pump oil pressure (Low relief pressure)</li> </ul>   |
| 10  | Start<br>↓<br>Finish | 5:30<br>↓<br>6:00 | 00.00<br>↓<br>30.00     | MAX (High) | ON                | Bucket CURL relief.   | <ul style="list-style-type: none"> <li>• Front, rear, swing pump oil pressure (Low relief pressure)</li> </ul>  |
| 11  | Start<br>↓<br>Finish | 6:00<br>↓<br>6:30 | 30.00<br>↓<br>60.00     | MAX (High) | ON                | Arm IN relief.  | <ul style="list-style-type: none"> <li>• Front, rear, swing pump oil pressure (Low relief pressure)</li> </ul>  |
| 12  | Start<br>↓<br>Finish | 6:30<br>↓<br>7:00 | 60.00<br>↓<br>90.00     | MAX (High) | ON                | Boom RAISE relief.  | <ul style="list-style-type: none"> <li>• Front, rear, swing pump oil pressure (High relief pressure)</li> <li>• Engine speed</li> <li>• Blow-by pressure, exhaust temperature, PTO oil temperature</li> </ul>   |
| 13  | Start<br>↓<br>Finish | 7:00<br>↓<br>7:30 | 90.00<br>↓<br>120.00    | MAX (High) | ON                | Set all levers in neutral (1st deceleration → 2nd deceleration)                     | <ul style="list-style-type: none"> <li>• Engine speed (1st deceleration speed)</li> </ul>   |
| 14  | —                    | 7:30              | 120.00                  | MIN (Low)  | ON                | Finish  |   |


Note: To turn off the decelerator and set the engine speed to high idle, move one of both work equipment control levers and both travel levers to a degree that the work equipment does not move or the machine does not swing or travel. (If the PPC oil pressure switch is turned ON, the auto-decelerator is turned OFF.)

**8. Resetting of VHMS Controller**

- ★ This step applies to works in the cab (on the personal computer).

[Machine Information]


- 1) Open the [Machine Information] tab.
  - ★ The [Machine Information] tab is displayed first in the [Data clear and Set up] menu.
- 2) Change all the data to the latest one or to the data recorded before the replacement.



BPP11994

- 3) When correcting information in [Date/Time], follow the procedures below:

- ★ Change the data in [Date/Time] except for [Time Zone] to the correct data at the time of correction.
- i) Press the [Edit] button on the right lower part of the [Date/Time] box to display the correction screen.
  - ii) Change the information to the correct one and then press the [OK] button.



BPP11547

- 4) When correcting the information in [SMR], follow the procedures below:

- ★ Be sure to set the value obtained by adding 0.1h to the data recorded before the replacement to the service meter.


Example :

123.4h (before replacement)⇒

123.5h (for resetting)

- ★ If an incorrect value is set to the service meter, data will come not to be managed on the WebCARE database. So, be sure to set correct values.


Delete the value in the [SMR (h)] and input the new value to be set.



BPP11997

- 5) When correcting information in the [Machine Information], follow the procedures below:


- i) Press the [Edit] button on the right lower part of the [Machine Information] box to display the correction screen.
- ii) Change the information to the one recorded before the replacement and then press the [OK] button.



BPP11995

## TESTING AND ADJUSTING DEVICES RELATED TO VHMS

### 1. Testing engine blow-by pressure sensor




BJP11586

- ★ The engine blow-by pressure sensor is a fine relative pressure sensor which introduces the engine crankcase pressure from its end "a" and atmospheric pressure from intermediate part "b" of the wiring harness to measure the difference between those pressures.
- ★ Accordingly, if oil, dust, water, etc. sticks to part "b" to introduce atmospheric pressure, the atmospheric pressure cannot be introduced stably. As a result, the atmospheric pressure cannot be measured normally.
- ★ If VHMS detects abnormal blow-by pressure and the sensor seems to be defective, check whole wiring harness "c" including part "b" to introduce atmospheric pressure for oil, dust, water, etc. before replacing the sensor. If part "b" or "c" is not clear, clean it.
- ★ Part "b" to introduce atmospheric pressure is about 700 mm from the end of the sensor.




- ★ If the snap shot operation is interrupted, the data collected up to now are not recorded. In this case, repeat the operation from the first.



- 6) Operate the fuel dial, swing lock switch, both work equipment control levers, and both travel levers according to the "Operating procedure for Quick Pm" and elapsed time.


- ★ The elapsed time is displayed on the monitor panel.

- ⚠ Since the operator must operate the work equipment, swing the boom, and drive the machine actually for the Quick Pm, take extreme care of safety around the machine during the work.



- 7) If the following screen appears 7 minutes 30 seconds after the snap shot is started, the snap shot is finished.

- ★ The initial screen of the service menu appears automatically 5 seconds after the snap shot operation is finished.



**5. Measuring and testing items other than snap shot items**

Measure and test the items that cannot be measured and tested with the snap shot function according to the check sheet.

2-1: Visual inspection of strainer

3: Work equipment speed

4-5: TVC pressure

4-6: Front CO-NC pressure

4-7: Rear CO-NC pressure

4-8: Swing CO-NC pressure

5-1: Fan speed

6: Hydraulic drift of work equipment

7: Hydraulic oil return strainer

**6. Downloading snap shot data**


- ★ The following devices are necessary for downloading and using the snap shot data.

| Symbol | Part No.       | Part name  |
|--------|----------------|--|
| W      | 1              | 799-608-3101 Service kit                                 |
|        | 1              | 799-608-3211 • Diskette                                  |
|        |                | 799-608-3220 • Harness                                   |
| 2      | Purchased Part | Note type personal computer (Windows98/2000/Me/XP/Vista) |
| 3      | Purchased Part | RS232C-USB conversion cable                              |

- 1) Check that the starting switch is in the OFF position.

- ⚠ When connecting and disconnecting the personal computer, be sure to turn the starting switch to the OFF position.

# SEQUENCE OF EVENTS IN TROUBLESHOOTING



## CLASSIFICATION AND STEPS FOR TROUBLESHOOTING

### Classification of troubleshooting

| Mode         | Content   |
|--------------|---|
| Code display | Troubleshooting when Error Code (electrical system) and Failure Code (mechanical system) are displayed. |
| E mode       | Troubleshooting of electrical system  |
| H mode       | Troubleshooting of hydraulic and mechanical systems   |
| S mode       | Troubleshooting of engine body  |

### Steps for troubleshooting

If some phenomenon occurs on a machine that looks like a failure, identify the corresponding troubleshooting No. and proceed to the explanations for diagnosis.

#### 1. Troubleshooting steps when calling User Code display in the monitor panel

In the User Code display, select and depress [✓] switch to display Error Code. Following displayed Error Code for the electrical system, carry out the troubleshooting along the corresponding code display.

#### 2. Troubleshooting steps when the electrical system Error Code or mechanical system Failure Code is recorded in the failure history:

If not calling User Code in the monitor panel, check the electrical system Error Code or mechanical system Failure Code, using the failure history function of the monitor panel.


- ★ If Error Code in the electrical system is recorded, delete the all codes once and revive the code in the display again to check if the same abnormality still persists.
- ★ Failure Code in the mechanical system cannot be deleted.





















#### 3. Troubleshooting steps without User Code display and no failure history is available



If there is no display of User Code nor the failure history in the monitor panel, it is possible that a failure that the monitor panel cannot diagnose by itself may have occurred in any of the electrical, hydraulic or mechanical system. In such a case, reexamine the phenomenon, find out the most similar phenomenon from among "Failure like Phenomena and Troubleshooting No." and carry out E mode, H mode or S mode troubleshooting related to the phenomenon in question.

| Connector No. | Connector Type | No. of pin | Place of use   | Address                       |              |              |              |              |
|---------------|----------------|------------|--|-------------------------------|--------------|--------------|--------------|--------------|
|               |                |            |  | 3-dimen-<br>sional<br>drawing | M<br>circuit | E<br>circuit | P<br>circuit | V<br>circuit |
| V07           | DT             | 2          | CO cancel solenoid valve                                 | K-3                           |              |              | G-1          |              |
| V08           | DT             | 2          | PPC pressure lock solenoid valve                         | E-1                           |              |              | G-1          |              |
| V09           | DT             | 2          | Boom RAISE shockless solenoid valve                      | I-2                           |              |              | G-1          |              |
| V10           | DT             | 2          | Boom LOWER shockless solenoid valve                      | I-2                           |              |              | G-1          |              |
| VC1           | 070            | 20         | VHMS controller (VHMS spec.)                             | N-6                           |              |              |              | A-8          |
| VC2A          | 070            | 18         | VHMS controller (VHMS spec.)                             | M-6                           |              |              |              | A-7          |
| VC2B          | 070            | 14         | VHMS controller (VHMS spec.)                             | M-6                           |              |              |              | A-6          |
| VC3A          | 070            | 18         | VHMS controller (VHMS spec.)                             | O-8                           | A-1          |              |              | A-5          |
| VC3B          | 070            | 12         | VHMS controller (VHMS spec.)                             | N-9                           |              |              |              | A-4          |
| VC4A          | 070            | 14         | VHMS controller (VHMS spec.)                             | N-9                           | A-1          | L-6          | F-1          | A-3          |
| VC4B          | 070            | 10         | VHMS controller (VHMS spec.)                             | N-9                           |              |              |              | A-2          |
| VH01          | DT             | 8          | Intermediate connector                                   | J-9                           |              |              | J-4          |              |
| VH02          | DT             | 3          | F pump pressure sensor                                   | G-9                           |              |              | L-4          |              |
| VH03          | DT             | 3          | R pump pressure sensor                                   | H-9                           |              |              | L-4          |              |
| VH04          | DT             | 4          | Swing pump pressure sensor                               | J-8                           |              |              | L-3          |              |
| VH05          | DT             | 2          | Engine oil temperature sensor (VHMS spec.)               | AJ-5                          |              |              |              | I-2          |
| VH06          | DT             | 3          | Engine front exhaust temp. sensor amplifier (VHMS spec.) | N-2                           |              |              |              | H-4          |
| VH07          | DT             | 3          | Engine rear exhaust temp. sensor amplifier (VHMS spec.)  | O-2                           |              |              |              | H-3          |
| VH08          | DT             | 3          | Engine blow-by pres. sensor (VHMS spec.)                 | AI-8                          |              |              |              | I-2          |
| VH09          | DT             | 2          | PTO oil temp. sensor (VHMS spec.)                        | K-6                           |              |              |              | I-2          |
| VH10          | DT             | 2          | Intermediate connector                                   | O-2                           |              |              |              | H-3          |
| VH11          | DT             | 3          | Control pump pres. sensor (VHMS spec.)                   | J-2                           |              |              |              | I-2          |
| VH12          | DT             | 3          | Aftercooler fan drive pump pres. sensor (VHMS spec.)     | K-5                           |              |              |              | I-1          |
| VH13          | BENDIX         | 5          | VHMS data download connector                             | N-3                           |              |              |              | H-1          |
| VH14          | DT             | 2          | Engine F exhaust temp. sensor amplifier (VHMS spec.)     | E-1                           |              |              |              | I-4          |
| VH15          | DT             | 2          | Engine R exhaust temp. sensor amplifier (VHMS spec.)     | F-1                           |              |              |              | I-3          |
| VH16          | DT             | 2          | Engine F exhaust temp. sensor (VHMS spec.)               | AG-8                          |              |              |              | I-4          |
| VH17          | DT             | 2          | Engine R exhaust temp. sensor (VHMS spec.)               | AH-8                          |              |              |              | I-3          |
| VH18          | DT             | 2          | Atmospheric temp. sensor (VHMS spec.)                    | E-9                           |              |              |              | I-3          |
| W03           | X              | 2          | Rear window limit switch (Optional for North America)    | AB-9                          | A-8          |              |              |              |
| W04           | M              | 6          | Upper wiper motor  | N-5                           | B-9          |              |              |              |
| W05           | M              | 6          | Lower wiper motor  | P-1                           | G-9          |              |              |              |
| W06           | M              | 2          | Lower wiper switch                                       | W-5                           | E-1          |              |              |              |
| X05           | M              | 4          | Swing lock switch  | Q-8                           | E-1          |              | A-1          |              |

★ This circuit diagram is made by extracting the monitor panel system, engine preheating/starting/charging system, light system, and communication network system from the general electric circuit diagram.



| No. of pins | M type connector  |  |                    |
|-------------|---|--|--------------------|
|             | Male (female housing)   | Female (male housing)  | T-adapter Part No. |
| 1           | Part No.: 08056-00171   | Part No.: 08056-00181  | 799-601-7080       |
| 2           |   <p>BWP04717</p>     |   <p>BWP04718</p>       | 799-601-7090       |
|             | Part No.: 08056-00271   | Part No.: 08056-00281  |                    |
| 3           |   <p>BWP04719</p>     |   <p>BWP04720</p>       | 799-601-7110       |
|             | Part No.: 08056-00371   | Part No.: 08056-00381  |                    |
| 4           |   <p>BWP04721</p> |   <p>BWP04722</p>   | 799-601-7120       |
|             | Part No.: 08056-00471   | Part No.: 08056-00481  |                    |
| 6           |   <p>BWP04723</p> |   <p>BWP04724</p>   | 799-601-7130       |
|             | Part No.: 08056-00671   | Part No.: 08056-00681  |                    |
| 8           |   <p>BWP04725</p> |   <p>BWP04726</p> | 799-601-7340       |
|             | Part No.: 08056-00871   | Part No.: 08056-00881  |                    |

| No. of pins | F type connector  |  |                    |
|-------------|---|--|--------------------|
|             | Male (female housing)   | Female (male housing)  | T-adapter Part No. |
| 4           |  <p>BWP03905</p> |  <p>BWP03906</p> | —                  |
|             | —   | —  |                    |



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL


- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below




- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Circuit diagram related to engine speed sensor



Circuit diagram related to throttle sensor




BJP11788


Error code in Electrical System **C132** (Throttle Sensor)

| User code  | Error code   | Failure Code  | Trouble | Throttle Sensor (Engine controller system) |
|--|--|---|---------|--|
| E14  | C132   | C132KX  |         |  |
| Contents of trouble                                | <ul style="list-style-type: none"> <li>Signal voltage of throttle sensor circuit is below 0.30 V.</li> </ul>   |   |         |  |
| Action of controller                               | <ul style="list-style-type: none"> <li>Flashes user code and turns on caution buzzer.</li> <li>Keeps engine speed at constant level.</li> </ul>  |   |         |  |
| Problem that appears on machine                    | <ul style="list-style-type: none"> <li>Engine speed and output lower suddenly.</li> </ul>  |   |         |  |
| Related information                                | <ul style="list-style-type: none"> <li>Input of the throttle sensor to the engine controller (Voltage) can be checked in the monitoring mode. (Code 030: Throttle sensor voltage)</li> <li>Method of reproducing error code: Turn starting switch ON.</li> </ul> |   |         |  |
| Possible causes and standard value in normal state | Cause  | Standard value in normal state/Remarks on troubleshooting |         |  |
|  | Carry out troubleshooting for error code [C131].   |   |         |  |

Circuit diagram related to atmospheric pressure sensor




Circuit diagram related to engine controller power supply




BJP11791

Circuit diagram related to fuel rail pressure sensor




Electric circuit diagram related to wiper motor (Single-wiper specification)




BJP11974

Electric circuit diagram related to wiper motor




BJP11974

Electric circuit diagram related to swing priority solenoid




Electric circuit diagram related to swing holding brake



BJP11767


Electrical Circuit Diagram for S-NET Communication



BWP10410




Electric circuit diagram related to F pump pressure sensor




BWP11976

Electric circuit diagram related to step light




BJP11780

Electric circuit diagram related to charging voltage




Electric circuit diagram related to VHMS controller power supply




BWP11980

Electric circuit diagram related to engine oil temperature sensor



BWP11984

Electric circuit diagram related to exhaust temperature sensors (front and rear)




BWP11986

Failure Code in VHMS System **F@BZNR** (High R cyl. Exhaust Temp. 2)

| User Code                       | Error Code   | Failure Code  | Failure phenomenon | High R cyl. Exhaust Temp. 2<br>(in VHMS controller system) |
|---------------------------------|--|---------------|--------------------|--|
| —                               | —  | <b>F@BZNR</b> |                    |  |
| Failure content                 | <ul style="list-style-type: none"> <li>The signal circuit of the rear exhaust temperature sensor detected that the temperature had exceeded exhaust temperature limit line 2 for 10 seconds.<br/>(Exhaust temperature limit line 2: The straight line connecting 750°C point in the speed range above the rated output speed and 800°C point in the speed range below the maximum torque speed)</li> </ul> |               |                    |  |
| Response from controller        | <ul style="list-style-type: none"> <li>None in particular.</li> </ul>  |               |                    |  |
| Phenomenon occurring on machine | <ul style="list-style-type: none"> <li>If the machine is used as it is, the engine may be broken.</li> </ul>   |               |                    |  |
| Relative information            | <ul style="list-style-type: none"> <li>The error codes of the VHMS system are not recorded in the failure history of the monitor panel.</li> <li>The 7-segment LED of the VHMS controller displays <b>n372</b> (displays the error 2 characters by 2).</li> <li>The exhaust temperature can be checked by downloading the data to a personal computer after performing the snap shot operation.</li> </ul> |               |                    |  |


| Presumed cause and standard value in normalcy | Cause  |  | Standard value in normalcy and references for troubleshooting  |  |         |
|---|--|--|--|--|---------|
|   | 1  | Abnormal rise of rear exhaust temperature (While system is normal) |  | Check the engine and repair all abnormality. |         |
| 2   | Rear exhaust temperature sensor system defective |  | If error code <b>[DGT5KA]</b> is displayed, perform troubleshooting for it.<br>If error code <b>[DGT5KB]</b> is displayed, perform troubleshooting for it. |  |         |
| 3   | VHMS controller defective                        |  | ★ Turn the engine starting switch OFF for the preparations, and hold it in the ON position or run the engine during the troubleshooting.                   |  |         |
|   |  |  | VC2A   | Exhaust temperature                          | Voltage |
|   |  | Between (5) and (12), (13)   | At 20°C  | Approx. 0.9 – 1.2 V                          |         |
|   |  |  | At 500°C   | Approx. 2.6 – 3.5 V                          |         |

Electric circuit diagram related to exhaust temperature sensors (front and rear)




BWP11986

Electric circuit diagram related to fan pump pressure sensor




BWP11989

Electrical Circuit Diagram for Engine Start and Battery Charging




Electric Circuit Diagram for Boom shockless control





Electrical Circuit Diagram for Right and Left Swing PPC hydraulic Switches



BJP11658

# TROUBLESHOOTING OF HYDRAULIC, MECHANICAL SYSTEM (H MODE)


|  |        |
|--|--------|
| BEFORE TROUBLESHOOTING FOR HYDRAULIC AND MECHANICAL SYSTEMS.....                                       | 20-552 |
| INFORMATION IN TROUBLESHOOTING TABLE.....  | 20-557 |
| H-1 Speed or power of all work equipment, travel, and swing is low .....                               | 20-558 |
| H-2 Engine speed lowers remarkably or engine stalls .....  | 20-560 |
| H-3 All work equipment, travel, and swing systems do not work.....                                     | 20-561 |
| H-4 Abnormal sound is heard from around pump .....   | 20-562 |
| H-5 Speed or power of boom is low .....  | 20-563 |
| H-6 Speed or power of arm is low .....   | 20-565 |
| H-7 Speed or power of bucket is low .....  | 20-566 |
| H-8 Boom does not move.....  | 20-567 |
| H-9 Arm does not move.....   | 20-567 |
| H-10 Bucket does not move .....  | 20-567 |
| H-11 Hydraulic drift of work equipment is large .....  | 20-568 |
| H-12 Time lag of work equipment is large .....   | 20-569 |
| H-13 Boom shockless function cannot be turned ON or OFF .....  | 20-570 |
| H-14 Machine deviates in one direction .....   | 20-570 |
| H-15 Machine deviates largely at start .....   | 20-572 |
| H-16 Machine deviates largely during compound operation .....  | 20-573 |
| H-17 Travel speed or power is low .....  | 20-573 |
| H-18 Machine does not travel (only one track).....   | 20-574 |
| H-19 Travel speed does not change.....   | 20-575 |
| H-20 Machine does not swing .....  | 20-576 |
| H-21 Swing speed or acceleration is low.....   | 20-577 |
| H-22 Swing speed or power is low in compound operation of travel and bucket .....                      | 20-578 |
| H-23 Swing speed or power is low in compound operation of travel and boom in swing priority mode ..... | 20-578 |
| H-24 Upper structure overruns largely .....  | 20-579 |
| H-25 Large shocks are made when upper structure stops swinging.....                                    | 20-580 |
| H-26 Large abnormal sounds are made when upper structure stops swinging .....                          | 20-581 |
| H-27 Hydraulic drift of swing is large .....   | 20-581 |

**H-3 All work equipment, travel, and swing systems do not work**

|                     |   |
|---------------------|---|
| Failure Phenomenon  | <ul style="list-style-type: none"> <li>All work equipment, travel, and swing systems do not work</li> </ul> |
| Related Information | <ul style="list-style-type: none"> <li>Carry out all the troubleshooting in working mode A.</li> </ul>      |

| Cause   |                                   | Standard value in normalcy and references for troubleshooting  |   |                         |
|---|-----------------------------------|--|---|-------------------------|
| Presumed cause and standard value in normalcy   | 1                                 | Defective safety lock valve linkage  | Since the safety lock valve linkage may be defective, check it directly.  |                         |
|   | 2                                 | Internal defect of PTO   | Since the control pump may not revolve because of an internal defect of the PTO, check the PTO directly.                                      |                         |
|   | 3                                 | Internal defect of control pump  | Since control pump may have a defect in it, check the inside of the pilot filter for metal chips.   |                         |
|   | 4                                 | Defective adjustment or malfunction of control relief valve  | ★ Prepare with the engine stopped, then carry out troubleshooting with the engine at high idle.   |                         |
|   |                                   |  | Work equipment, swing, and travel levers  | Control relief pressure |
| All levers in neutral   |                                   |  | $3.1 \begin{smallmatrix} +0.4 \\ 0 \end{smallmatrix} \text{ MPa}$<br>$\{32 \begin{smallmatrix} +3.5 \\ 0 \end{smallmatrix} \text{ kg/cm}^2\}$ |                         |
| If the oil pressure cannot be set normally by adjustment, check cause 3. If the result of check of cause 5 is normal, the control relief valve may have a malfunction. Check the control relief valve directly. |                                   |  |   |                         |
| 5   | Leakage in control system devices | ★ Stop the engine and block (1) – (13) in the drawing in order, then carry out troubleshooting with the engine at high idle. |   |                         |
|   |                                   | Work equipment, swing, and travel levers   | Control relief pressure   |                         |
|   |                                   | All levers in neutral  | $3.1 \begin{smallmatrix} +0.4 \\ 0 \end{smallmatrix} \text{ MPa}$<br>$\{32 \begin{smallmatrix} +3.5 \\ 0 \end{smallmatrix} \text{ kg/cm}^2\}$ |                         |

**Control system devices**




BJP11683

|                        |  |
|------------------------|--|
| Failure Phenomenon (2) | <ul style="list-style-type: none"> <li>Machine deviates in different directions, depending on its travel direction</li> </ul>  |
| Related Information    | <ul style="list-style-type: none"> <li>Check that the travel speed is normal. (If it is abnormal, carry out the related troubleshooting.)</li> <li>Carry out all the troubleshooting in working mode A.</li> </ul> |

| Presumed cause and standard value in normalcy   | Cause   | Standard value in normalcy and references for troubleshooting                                  |  |
|---|---|--|--|
|   | Presumed cause and standard value in normalcy | 1 Malfunction of travel PPC valve  | ★Prepare with the engine stopped, then carry out troubleshooting with the engine at high idle. |
| Travel lever                                    |   |  | PPC valve output pressure  |
| Full stroke                                     |   |  | $2.9^{+0.6}_{-0.2}$ MPa<br>{ $30^{+5.5}_{-1.5}$ kg/cm <sup>2</sup> }                           |
| 2 Malfunction of travel control valve (spool)   |   | Since the spool of the travel control valve may have a malfunction, check it directly.         |  |
| 3 Defective seal of center swivel joint         |   | ★Prepare with the engine stopped, then carry out troubleshooting with the engine at high idle. |  |
|   |   | Travel lever   | Leakage from swivel joint  |
|   |   | Relieved on one side   | Max. 100 cc/min  |
|   |   | If seal is defective, the machine deviates as shown in Fig.                                    |  |
| 4 Low set pressure of travel motor safety valve |   | ★Prepare with the engine stopped, then carry out troubleshooting with the engine at high idle. |  |
|   |   | Travel lever   | Travel relief pressure   |
|   |   | Relieved on one side   | $34.3^{+1.0}_{-2.5}$ MPa<br>{ $350^{+10}_{-25}$ kg/cm <sup>2</sup> }                           |

**Defective seals in center swivel joint and travel deviation directions**



TWP01578

**H-26 Large abnormal sounds are made when upper structure stops swinging**

|                        |   |
|------------------------|---|
| Failure Phenomenon (1) | <ul style="list-style-type: none"> <li>Large abnormal sounds are made when upper structure stops swinging in both directions</li> </ul> |
| Related Information    |   |

| Presumed cause and standard value in normalcy | Cause                              |   | Standard value in normalcy and references for troubleshooting                         |  |
|---|------------------------------------|---|---|--|
|   | 1                                  | Malfunction of back pressure compensation valve   | Since the back pressure compensation valve may have a malfunction, check it directly. |  |
| 2   | Internal defect of swing machinery | Since the swing machinery may have a defect in it, check it directly. (The defect can be judged by abnormal sound, abnormal heat, metal chips in drained oil, etc.) |   |  |

|                        |   |
|------------------------|---|
| Failure Phenomenon (2) | <ul style="list-style-type: none"> <li>Large abnormal sounds are made when upper structure stops swinging in one direction</li> </ul> |
| Related Information    |   |

| Presumed cause and standard value in normalcy | Cause                                      |   | Standard value in normalcy and references for troubleshooting                                   |  |
|---|--|---|---|--|
|   | 1  | Defective adjustment or malfunction of swing motor (safety valve)   | ★ Prepare with the engine stopped, then carry out troubleshooting with the engine at high idle. |  |
| Left control lever (swing)                    |  |   | Swing relief pressure   |  |
| Relieved                                      |  |   | $31.4^{+1.0}_{-2.5}$ MPa<br>$\{320^{+10}_{-25}$ kg/cm <sup>2</sup>                              |  |
|   |  | If the oil pressure cannot be set normally by adjustment, the safety valve may have a malfunction. Check the safety valve directly. (The malfunction can be judged from change of phenomenon after exchanging the safety valves with each other.) |   |  |
| 2   | Malfunction of swing motor (suction valve) | Since the suction valve of the swing motor may have a malfunction, check it directly. (The malfunction can be judged from change of phenomenon after exchanging the suction valves with each other.)  |   |  |

**H-27 Hydraulic drift of swing is large**

|                     |   |
|---------------------|---|
| Failure Phenomenon  | <ul style="list-style-type: none"> <li>Hydraulic drift of swing is large</li> </ul> |
| Related Information |   |

| Presumed cause and standard value in normalcy | Cause                                      |   | Standard value in normalcy and references for troubleshooting                                   |  |
|---|--|---|---|--|
|   | 1  | Malfunction of swing holding brake solenoid valve                                     | ★ Prepare with the engine stopped, then carry out troubleshooting with the engine at high idle. |  |
| Left control lever (swing)                    |  |   | Solenoid valve outlet pressure  |  |
| Neutral (At least 5 sec after)                |  |   | 0 MPa {0 kg/cm <sup>2</sup> }   |  |
|   |  | Operation   | 2.9 ± 0.6 MPa {30 ± 5.5 kg/cm <sup>2</sup> }  |  |
| 2   | Malfunction of swing motor (holding brake) | Since the holding brake of the swing motor may have a malfunction, check it directly. |   |  |





**S-13 OIL LEVEL RISES**

★ If there is oil in the coolant, carry out Troubleshooting S-11.

General causes why oil level rises

- Coolant in oil (milky white)
- Fuel in oil (diluted, and smells of diesel fuel)
- Entry of coolant or oil from other component

|                 |  | Causes                            |   |                              |  |                                   |                                |   |                           |                     |                           |   |
|-----------------|--|-----------------------------------|---|------------------------------|--|-----------------------------------|--------------------------------|---|---------------------------|---------------------|---------------------------|---|
|                 |  | Broken cylinder head, head gasket | Defective cylinder head injector sleeve | Cracks inside cylinder block | Damaged cylinder liner O-ring, holes caused by pitting | Broken, broken rear oil seal face | Broken oil cooler core, O-ring | Clogged water pump drain hole (breather hole), defective seal | Defective thermostat seal | Worn fuel pump seal | Cut, worn injector O-ring | Defective auxiliary equipment (pump, compressor) seal |
| Questions       | Confirm recent repair history  |                                   |   |                              |  |                                   |                                |   |                           |                     |                           |   |
|                 | Degree of use of machine   | Operated for long period          | △                                       |                              | △  | △                                 |                                | △   |                           |                     |                           | △   |
| Check items     | Fuel must be added more frequently   |                                   |   |                              |  |                                   |                                |   | ⊙                         | ⊙                   | ⊙                         |   |
|                 | Engine oil smells of diesel fuel   |                                   |   |                              |  |                                   |                                |   | ⊙                         | ⊙                   | ⊙                         |   |
|                 | There is oil in coolant  | ○                                 | ○                                       | ○                            | ○  |                                   | ⊙                              |   |                           |                     |                           |   |
|                 | When engine is first started, drops of water come from muffler   |                                   | ⊙                                       |                              |  |                                   |                                |   |                           |                     |                           |   |
|                 | When radiator cap is removed and engine is run at low idle, an abnormal number of bubbles appear, or coolant spurts back | ⊙                                 |   |                              |  |                                   |                                |   |                           |                     |                           |   |
|                 | Exhaust smoke is white   |                                   | ⊙                                       |                              |  |                                   |                                |   | ○                         |                     | ○                         |   |
|                 | Water pump drain hole (breather hole) is clogged   |                                   |   |                              |  |                                   |                                | ⊙   |                           |                     |                           |   |
|                 | When water pump drain hole (breather hole) is cleaned, water comes out   |                                   |   |                              |  |                                   |                                | ⊙   |                           |                     |                           |   |
|                 | Oil level goes down in PTO chamber   |                                   |   |                              |  | ⊙                                 |                                |   |                           |                     |                           |   |
|                 | Oil level goes down in hydraulic tank  |                                   |   |                              |  |                                   |                                |   |                           |                     |                           | ⊙   |
| Troubleshooting | When compression pressure is measured, it is found to be low   | ●                                 |   |                              |  |                                   |                                |   |                           |                     |                           |   |
|                 | Carry out pressure-tightness test of cylinder head   |                                   | ●                                       |                              |  |                                   |                                |   |                           |                     |                           |   |
|                 | Inspect cylinder block, liner directly   |                                   |   | ●                            | ●  |                                   |                                |   |                           |                     |                           |   |
|                 | Inspect rear oil seal directly   |                                   |   |                              |  | ●                                 |                                |   |                           |                     |                           |   |
|                 | Carry out pressure-tightness test of oil cooler  |                                   |   |                              |  |                                   | ●                              |   |                           |                     |                           |   |
|                 | Inspect water pump directly  |                                   |   |                              |  |                                   |                                | ●   |                           |                     |                           |   |
|                 | Inspect thermostat directly  |                                   |   |                              |  |                                   |                                |   | ●                         |                     |                           |   |
|                 | Inspect fuel pump directly   |                                   |   |                              |  |                                   |                                |   |                           | ●                   |                           |   |
|                 | Inspect injector directly  |                                   |   |                              |  |                                   |                                |   |                           |                     | ●                         |   |
|                 | Inspect pump auxiliary equipment (pump, compressor) directly   |                                   |   |                              |  |                                   |                                |   |                           |                     |                           | ●   |
| Remedy          | Replace  | Replace                           | Replace                                 | Replace                      | Correct  | Replace                           | Replace                        | Correct   | Replace                   | Correct             | Replace                   |   |

# PRECAUTIONS WHEN PERFORMING OPERATION

Be sure to follow the general precautions given below when performing removal or installation (disassembly or assembly) of units.

## 1. Precautions when performing removal work

- If the engine coolant water contains antifreeze, dispose of it properly.
- After disconnecting hoses or tubes, cover them or install blind plugs to prevent dirt or dust from entering.
- When draining oil, prepare a container of adequate size to catch the oil.
- Confirm the match marks showing the installation position, and make match marks in the necessary places before removal to prevent any mistake during assembly.
- To avoid loosening any wire contacts, do not pull on the wires. In-order to prevent excessive force to the wiring, hold onto the connectors when disconnecting them.
- Fasten tags to wires and hoses to identify them and show their installation position. This helps prevent any mistakes when re-installing.
- Count and check the number and thickness of the shims, and keep them in a safe place.
- When raising or lifting components, be sure to use proper lifting equipment of ample strength and safety.
- When using forcing screws to remove any components, tighten the forcing screws uniformly in turn.
- Before removing any unit, clean the surrounding area and install a cover to prevent any dust or dirt from entering after removal.

### ★ Precautions when handling piping during disassembly

Install the following blind plugs into the piping after disconnecting it during disassembly operations.

#### A. Face seal type hoses and tubes


| Nominal number | Plug (nut end) | Nut (elbow end) |
|----------------|----------------|-----------------|
| 02             | 07376-70210    | 02789-00210     |
| 03             | 07376-70315    | 02789-00315     |
| 04             | 07376-70422    | 02789-00422     |
| 05             | 07376-70522    | 02789-00522     |
| 06             | 07376-70628    | 02789-00628     |

#### B. Split flange type hoses and tubes

| Nominal number | Flange (hose end) | Sleeve head (tube end) | Split flange |
|----------------|-------------------|------------------------|--------------|
| 04             | 07379-00400       | 07378-10400            | 07371-30400  |
| 05             | 07379-00500       | 07378-10500            | 07371-30500  |

C. If the part is not under hydraulic pressure, the following corks can be used:

| Nominal number | Part Number | Dimensions |      |    |
|----------------|-------------|------------|------|----|
|                |             | D          | d    | L  |
| 06             | 07049-00608 | 6          | 5    | 8  |
| 08             | 07049-00811 | 8          | 6.5  | 11 |
| 10             | 07049-01012 | 10         | 8.5  | 12 |
| 12             | 07049-01215 | 12         | 10   | 15 |
| 14             | 07049-01418 | 14         | 11.5 | 18 |
| 16             | 07049-01620 | 16         | 13.5 | 20 |
| 18             | 07049-01822 | 18         | 15   | 22 |
| 20             | 07049-02025 | 20         | 17   | 25 |
| 22             | 07049-02228 | 22         | 18.5 | 28 |
| 24             | 07049-02430 | 24         | 20   | 30 |
| 27             | 07049-02734 | 27         | 22.5 | 34 |




DEW00401





**DISASSEMBLY AND ASSEMBLY**


**INSTALLATION**


- Carry out installation in the reverse order to removal.


※ 1  
 Air tube joint bolt:  
**44.1 – 53.9 Nm {4.5 – 5.5 kgm}**


※ 2  
 Fuel tube :  
**92.5 ± 2.5 Nm {9.45 ± 0.25 kgm}**



※ 3  
 ★ Tighten the aftercooler mounting bolts in the order shown in the diagram below.  
 Mounting bolt:  
**66.15 ± 7.35 Nm {6.75 ± 0.75 kgm}**





※ 4  
 ★ Tighten the turbocharger and exhaust manifold mounting bolts in the order shown in the diagram below.  
 Turbocharger, exhaust manifold assembly mounting bolt:  
**110.35 ± 12.25 Nm {11.25 ± 1.25 kgm}**




※ 5  
 Cylinder head cover mounting bolt:  
**31.85 ± 2.45 Nm {3.25 ± 0.25 kgm}**

※ 6  
 ★ Clean the hole of the mounting bolts and install.  
 ★ Check that the ball portion of the adjustment screw is fitted securely in the socket portion of the push rod.  
 Rocker arm mounting bolt:  
**98 ± 4.9 Nm {10 ± 0.5 kgm}**  
 Locknut:  
**67.62 ± 9.8 Nm {6.9 ± 1 kgm}**

※ 7  
 ★ Adjust the crosshead as follows.  
 1) Loosen the locknut, then turn back the adjustment screw.  
 2) Hold down the top surface of the crosshead lightly, and screw in the adjustment screw.  
 3) After the adjustment screw contacts the valve stem, screw it in a further 20°.  
 4) Tighten the locknut to hold the adjustment screw in position.  
 Locknut:  
**58.8 ± 5.88 Nm {6 ± 0.6 kgm}**

※ 8  
 Injector mounting bolt:  
**1st step:**  
**29.4 ± 4.9 Nm {3 ± 0.5 kgm}**  
**2nd step: Tighten 90 – 120°**

※ 9  
 Rocker arm housing mounting bolt:  
**98 ± 4.9 Nm {10 ± 0.5 kgm}**

## INSTALLATION

- Carry out installation in the reverse order to removal.

※ 1




Mount bolt:

**823.7 - 1,029.7 Nm {84 - 105 kgm}**


- **Refilling with oil**  
Add oil to the specified level. Run the engine to circulate the oil through the system. Then check the oil level again.
- **Refilling with coolant**  
Add coolant to the mouth of the radiator filler port. Tighten the cap and run the engine to circulate the coolant through the system. Then check the coolant level in the reserve tank.  
(Check if the coolant level goes up or down).
- **Bleeding air**  
Bleed the air from the main pump.  
For details, see TESTING AND ADJUSTING, Bleeding air from main pump.
- **Adjusting drive belt tension.**  
Adjust the air conditioner compressor drive belt and fan belt.  
For details, see TESTING AND ADJUSTING, Adjusting belt tension.

**7. Hub assembly**

- 1) Remove lock plate (13).
- 2) Using tool **J4**, remove nut (14).




- 3) Using eyebolts ④, remove hub assembly (15) together with bearing (16) from shaft (41).
- 4) Remove bearing (16) from hub (49).



- 5) Remove floating seal (17a) from hub (49)
  - ★ If the seal is to be used again, be careful not to damage the contact surface, and keep in a safe place.
- 6) Remove outer races (18).


**8. Spacer**

- 1) Remove spacer (19) from shaft (41).




**9. No. 2 carrier assembly**

- 1) Using eyebolts ⑤, remove No. 2 carrier assembly (20).
- 2) Disassemble No. 2 carrier assembly as follows.
  - i) Knock pin (21) into shaft (22).
  - ii) Push shaft (22) from pin side to remove.
    - ★ Remove the pin from the shaft.



- iii) Pull out gear (23) from carrier (27), then remove thrust washer (24) and bearing (25).
- iv) Remove thrust bearing assembly (26) from carrier (27).




# REMOVAL AND INSTALLATION OF SWING MACHINERY ASSEMBLY

## REMOVAL


**⚠** Lower the work equipment completely to the ground and stop the engine. Then loosen the oil filter cap slowly to release the pressure inside the hydraulic tank.

### ★ Center of chassis

1. Disconnect swing motor hose clamp (1).
2. Disconnect hoses (2) and (3) going to swing motor at front of chassis.
3. Disconnect drain hose (4).




4. Disconnect hose (5) coming from the control valve.
5. Disconnect swing brake release hose (6).
6. Remove mounting bolts (7) and lift off swing motor assembly (8).




### ★ Front of chassis


1. Disconnect hoses (9) and (10) coming from swing motor at center of chassis.
2. Disconnect drain hose (11).
3. Disconnect swing brake release hose (12).
4. Disconnect hose (13) going to boom LOWER regeneration valve.
5. Disconnect drain hose (14).


6. Remove mounting bolts (15), then lift off swing motor assembly (16).

 Swing motor assembly: **126 kg**



7. Remove mounting bolts, then lift off swing machinery assembly (17).

 Swing machinery assembly: **532 kg**




## INSTALLATION

- Carry out installation in the reverse order to removal.

※ 1

 Mounting bolt:  
**927 ± 103 Nm {94.5 ± 10.5 kg}**


- Refilling with oil  
Add oil to the hydraulic tank to the specified level. Run the engine to circulate the oil through the system. Then check the oil level again.

 Oil in swing machinery case:  
**Approx. 21.5 liters**


# REMOVAL AND INSTALLATION OF SWING CIRCLE ASSEMBLY


## REMOVAL

1. Remove revolving frame assembly.  
For details, see REMOVAL OF REVOLVING FRAME ASSEMBLY.
2. Remove grease tubes (1).
3. Remove mounting bolts (2). ※ 1




4. Pass a round bar through revolving frame mounting bolt holes, then fit wire and lift off swing circle assembly (3). ※ 2

 Swing circle assembly: **2,169 kg**




5. Remove seal (4).



## INSTALLATION


- Carry out installation in the reverse order to removal.

※ 1


 Mounting bolt:  
**Thread tightener (LT-2)**

 **N-m** Mounting bolt:  
**1,960 - 2,450 Nm {200 - 250 kgm}**

※ 2

 Mounting surface of swing circle:  
**Gasket sealant (LG-6)**

- ★ Amount of grease (G2-LI) to fill oil bath:  
Approx. 75 ℓ
- ★ Coat the inner teeth with grease (G2-LI).
- ★ Set the soft zone **S** mark on the inner race facing the left side of the machine, then install.




# DISASSEMBLY AND ASSEMBLY OF RECOIL SPRING ASSEMBLY

## SPECIAL TOOLS


| Symbol | Part No. | Part Name     | Necessity          | Q'ty | New/Remodel | Sketch |   |
|--------|----------|---------------|--------------------|------|-------------|--------|---|
| M      | 1        | 791-685-8501  | Compressor         | ■    | 1           |        |   |
|        |          | 791-635-3160  | Extension          | ■    | 1           |        |   |
|        |          | 796T-830-1110 | Plate              | ■    | 1           | N      | ○ |
|        |          | 796T-830-1120 | Spacer             | ■    | 1           | N      | ○ |
|        |          | 01010-61640   | Bolt               | ■    | 2           |        |   |
|        |          | 790-101-1600  | Cylinder (70 tons) | ■    | 1           |        |   |
|        |          | 790-101-1102  | Hydraulic pump     | ■    | 1           |        |   |

## DISASSEMBLY


- Set recoil spring assembly (1) to tool **M1**.
  - ⚠** The recoil spring is under a large installed load, so be sure to set the tool properly. Failure to do this is dangerous.
  - ★ Installed load of spring:  
**578 kN {58,957 kg}**



- Apply hydraulic pressure slowly to compress spring, then remove lock plate, and remove nut (2).
- Release hydraulic pressure gradually to relieve tension of spring, then remove recoil spring assembly (1) from tool **M1**.




- Remove rear pilot (4) and rod (5) from spring (3).



**DISASSEMBLY AND ASSEMBLY**

9. Using tool **L10**, apply standard pressure to roller oil filler port, and check for leakage of air from seal.

- ★ Standard pressure: 0.1 MPa (1 kg/cm<sup>2</sup>)
- ★ Method of checking  
The standard pressure shall be maintained for 10 seconds and the indicator of the gauge shall not go down.



10. Using tool **L10**, fill track roller assembly with oil, then tighten plug (11).





Track roller oil:

**800 - 850 cc (EO30-CD)**



Plug: **17 - 37 Nm {1.7 - 3.8 kgm}**



## REMOVAL AND INSTALLATION OF 4-SPOOL CONTROL VALVE ASSEMBLY (NO. 3)


### REMOVAL

- ⚠ Lower the work equipment completely to the ground and stop the engine. Then loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.
  - ⚠ Release the remaining pressure inside the hydraulic circuit.  
For details, see TESTING AND ADJUSTING, Releasing remaining pressure in hydraulic circuit.
  - ★ Before disconnecting the PPC hoses, make counter marks to distinguish the mounting positions.
  - ★ After disconnecting the hoses and tubes, fit blind plugs.
1. Remove control valve cover (1).




2. Remove tubes (2) and clamp.
3. Remove line filter tube (3).
4. Remove tube (4) for boom control valve.
5. Remove tube (5) for swing control.
6. Remove tube (6) for bucket control.
7. Remove tube (7) for arm control.

8. Remove tube (8) going to control valves No. 1 and No. 2.




9. Disconnect hoses (9) coming from the pilot valve.
10. Disconnect swing control tube (10).
11. Disconnect arm control tube (11).
12. Remove pilot hoses (12), (13), (14), and (15), and then disconnect main relief valve (16).



**26. Disassembly of swing priority valve assembly**

- 1) Remove mounting bolts (36), then remove cover (37).
- 2) Remove O-ring (38) from cover (37).
- 3) Remove plug (39).
- 4) Remove backup ring, O-ring (40), and O-ring (41) from plug (39).
- 5) Loosen nut (42), and remove sleeve (43).
- 6) Remove plug (44), spring (45), and check valve (46) from sleeve (43).
- 7) Remove backup ring and O-rings (47) and (48) from plug (44) and sleeve (43).
- 8) Remove mounting bolts (49), then remove flange (50) and O-ring (51).



**ASSEMBLY**


**1. Assembly of swing priority valve**

- 1) Fit washer to bolt (49), then install O-ring (51) and flange (50) to valve body (4).
- 2) Fit backup ring and O-ring (48) to sleeve (43), and assemble to valve body.


 Sleeve:  
**Liquid sealant {Seal end 242}**

 Sleeve:  
**177 - 216 Nm {18 - 22 kgm}**


- 3) Tighten nut (42) to sleeve (43).

 Nut: **177 - 216 Nm {18 - 22 kgm}**


- 4) Fit backup ring and O-ring (47) to plug (44).
- 5) Insert check valve (46) and spring (45) in sleeve (43), then assemble plug (44).

 Plug: **29.4 - 39.2 Nm {3 - 4 kgm}**

- 6) Fit backup ring and O-ring (40) and O-ring (41) to plug (39), then insert in valve body (4).
- 7) Fit O-ring, then set cover (37) together with bolt (36) to valve body (4).



2. Fit O-ring to plug (35) and install.

 Plug: **58.8 - 78.5 Nm {6 - 8 kgm}**


3. Fit backup ring and O-ring (34) to plug (33) and install.

 Plug: **118 - 162 Nm {12 - 16.5 kgm}**

4. Install main relief valve (32).

 Main relief valve:  
**275 - 368 Nm {28 - 37.5 kgm}**

5. Install jet sensor relief valve (31).

 Jet sensor relief valve:  
**177 - 196 Nm {18 - 20 kgm}**

6. Install orifice (30).

 Orifice:  
**127 - 177 Nm {13 - 18 kgm}**

7. Install suction-safety valve (29).

 Suction-safety valve:  
**216 - 235 Nm {22 - 24 kgm}**

## ASSEMBLY

1. Assemble valve (18) in body (19)
2. Assemble shim (17) and spring (16) to valve (18).
  - ★ Check the number and thickness of shim (17) for each mounting position, and assemble in the same position as before disassembly. Standard thickness of shim: 0.3 mm
  - ★ The top and bottom of spring (16) are not symmetrical, so set the small coil diameter (inside diameter) at the shim end when assembling.
3. Assemble spring (15), retainer (14), and piston (13).



Outside circumference of piston, hole in body: **Grease (G2-LI)**

4. Fit O-ring to collar (12) and assemble in body (19), then install seal (11).
5. Install damper assembly (9) to plate (10) and tighten mounting bolts (8).



Mounting bolt: **Thread tightener (LT-2)**



Mounting bolt: **4.41 ± 0.49 Nm {0.45 ± 0.05 kgm}**

6. Install plate and damper assembly (6), and tighten mounting bolts (8).

- ★ Temporarily assemble a standard washer (1.6 mm) for washer (7).

After the completion of assembly, measure the difference in the angle when the left and right levers are operated fully. If the difference in angle is greater than 0.7°, change the thickness of washer (7) to make the difference less than 0.7°.

- Thickness of washer: 1.0, 1.3, 1.6 mm

- ★ If the thickness of the washer is reduced by 0.3 mm, the angle when the lever is fully operated will be increased by 0.39°.



Mounting bolt: **30.87 ± 3.43 Nm {3.15 ± 0.35 kgm}**

7. Install case and shaft assembly (4) and tighten mounting bolts (3).



Rocking portion of shaft, connection of lever and piston: **Grease (G2-LI)**



Mounting bolt: **27.93 ± 3.43 Nm {2.85 ± 0.35 kgm}**


8. Install levers (2) and tighten screws (1).



Rocking portion of lever pin and plate: **Grease (G2-LI)**



Screw: **8.82 ± 0.98 Nm {0.9 ± 0.1 kgm}**



## REMOVAL AND INSTALLATION OF ARM CYLINDER ASSEMBLY


### LOADING SHOVEL REMOVAL

**⚠** Retract boom cylinder fully, and extend arm cylinder, then set the bottom of the bucket horizontal, lower the work equipment completely to the ground and stop the engine. Operate the control levers several times to release the remaining pressure in the hydraulic piping.

**⚠** Loosen the oil filler cap slowly to release the pressure inside the hydraulic tank.

★ Plug the hose to stop oil flow-out.


1. Disconnect grease tube (1) at piston rod end.



2. Sling arm cylinder assembly, and remove plate, then using forcing screws (Thread dia. = 16 mm, Pitch = 2.0 mm), pull out pin (2). ※ 1

★ Pull out the pin to a position where the piston rod can be disconnected.

 Pin: **24.2 kg**



3. Start engine and retract piston rod fully.

**⚠** Tie the rod with wire to prevent it from coming out.

**⚠** After stopping the engine, release the pressure inside the piping. For details, see TESTING AND ADJUSTING, Releasing pressure in PPC circuit.

4. Disconnect 4 arm cylinder hoses (3).


5. Sling piston rod end and bottom end, and remove plate, then using forcing screws (Thread dia. = 16 mm, Pitch = 2.0 mm), pull out pin (4). ※ 2


★ Pull out the pin to a position where the cylinder bottom can be disconnected.

 Pin: **24.2 kg**




6. Lift off arm cylinder assembly (5) carefully.

 Arm cylinder assembly: **602 kg**



- 9) Disassembly of head assembly
- i) Remove the O-ring and backup ring (20).
  - ii) Remove snap ring (21) and dust seal (22).
  - iii) Remove rod packing (23).
  - iv) Remove backup ring (24).
  - v) Remove bushing (25).




## ASSEMBLY

- ★ Take care not to damage the packings, dust seals, O-rings, etc.
- ★ Do not fit the backup rings forcibly. Warm them in water of about 50 - 60°C before fitting them.

### 1. Assembly of head assembly

- 1) Using tool **U4**, press fit bushing (25).
- 2) Fit backup ring (24).
- 3) Fit rod packing (23).
- 4) Using tool **U5**, fit dust seal (22) and fix it with snap ring (21).
- 5) Fit the O-ring and backup ring (20).



## INSTALLATION

- Carry out installation in the reverse order to removal.

※ 1



Inside surface of bushing when assembling pin:

**Anti-friction compound (LM-P)**



Grease after assembling pin:

**Grease (LM-G)**



When aligning the position of the pin hole, never insert your fingers in the hole.


- **Bleeding air**
  - ★ For details, see TESTING AND ADJUSTING, Air bleeding from each component.
- **Refilling with oil (hydraulic tank)**
  - ★ Add oil through oil filler to the specified level. Run the engine to circulate the oil through the system. Then check the oil level again.

- 3) Evenly apply paint primer to the surfaces to stick both-sided adhesive tapes and the surfaces out of those surfaces on operator's cab (8) which will be coated with the adhesive.


 Paint primer:

**SUNSTAR PAINT PRIMER  
580 SUPER or equivalent**



- ★ Do not apply the primer more than 2 times. (If it is applied more than 2 times, its performance will be lowered.)



- ★ Parts to be coated with primer: Apply the primer all over dimension **a**.
- Dimension to apply primer **a: 25 mm**



- ★ In addition to the above parts, apply the primer to right side window glass (1) and door lower window glass (3).
- Range to apply primer additionally for right side window glass (1): **b**
- Range to apply primer additionally for door lower window glass (3): **c**
- ★ After applying the primer, leave it for at least 5 minutes (within 8 hours) to dry.




- ★ Never apply wrong primer. If the glass primer is applied by mistake, wipe it off with white gasoline.

- 4) Evenly apply glass primer to the sticking surfaces of window glass (9).


 Glass primer:

**SUNSTAR GLASS PRIMER  
580 SUPER or equivalent**

- ★ Do not apply the primer more than 2 times. (If it is applied more than 2 times, its performance will be lowered.)





5. Install left corner blocks (1) and (2) and secure left corner bracket (6) with left striker bolt (4).
  - ★ Tighten the striker bolt securely after adjusting it in step 6.
  - ★ Install the left corner blocks so that there will be no level difference at 2 part **d**.
  - ★ Secure roller clearance **e**.



6. Adjust the striker bolts according to the following procedure (Adjust the "CLOSE" positions of the front window assembly locks).


- 1) Tighten left striker bolt (4) and right striker bolt (5) at roughly right positions so that front window glass (18) will be fitted to cab-side trim seal (19).



# HYDRAULIC CIRCUIT DIAGRAM (1/3)

## BACKHOE SPECIFICATION

BACKHOE SPEC.




# ELECTRICAL CIRCUIT DIAGRAM (3/7)

WIRING TABLE FOR FUSE BOX

| FUSE No. | RATED | SYSTEM  |
|----------|-------|---|
| 1        | 10A   | REDUNDANCY, SOLENOID VALVE                        |
| 2        | 10A   | SOLENOID VALVE                                    |
| 3        | 10A   | PPC LOCK SOLENOID, STARTER CUT RELAY              |
| 4        | 20A   | WIND/W WASHER                                     |
| 5        | 10A   | HORN, FLASH LIGHT                                 |
| 6        | 10A   | AUTO GREASE                                       |
| 7        | 10A   | BEACON  |
| 8        | 10A   | SPARE   |
| 9        | 10A   | RADIO   |
| 10       | 10A   | SPARE   |
| 11       | 25A   | A/C UNIT  |
| 12       | 20A   | VHMS CONTROLLER                                   |
| 13       | 20A   | SPARE   |
| 14       | 10A   | OPT POWER SUPPLY (1)                              |
| 15       | 10A   | OPT POWER SUPPLY (2)-STREET LAMP-12V POWER SUPPLY |
| 16       | 10A   | RADIO BACK UP                                     |
| 17       | 20A   | NET WORK BUS VB.                                  |
| 18       | 10A   | VHMS CONTROLLER (BACK UP)                         |
| 19       | 10A   | ROOM LAMP   |
| 20       | 10A   | STEP LIGHT  |

RADIO CONNECTION TABLE

| TERMINAL NO. | CONNECTION TABLE |
|--------------|------------------|
| 1            | SPEAKER LEFT(-)  |
| 2            | SPEAKER RIGHT(+) |
| 3            | ACC +B           |
| 4            | SPARE            |
| 5            | SPEAKER LEFT(-)  |
| 6            | SPEAKER RIGHT(+) |
| 7            | GND              |
| 8            | BACK UP          |
| 9            | SPARE            |



PC1250-7 9JG00391

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL