

DB58, DB58T & DB58TI DIESEL ENGINE

Shop Manual

65.99892-8026A

Daewoo reserves the right to improve our products in a continuing process to provide the best possible product to the market place. These improvements can be implemented at any time with no obligation to change materials on previously sold products. It is recommended that consumers periodically contact their distributors for recent documentation on purchased equipment.

This documentation may include attachments and optional equipment that is not available in your machine's package. Please call your distributor for additional items that you may require.

Illustrations used throughout this manual are used only as a representation of the actual piece of equipment, and may vary from the actual item.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below




- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

• Cylinder Block


(Unit : kg · m)



EJM1002S

• Fuel System (DB58, DB58T)

(Unit : kg · m)



1.5.10. Injection Timing



⚠ [CAUTION] Carefully keep away to be not entried dust or alien substance into injection pump when adjust injecting timing.

• Check and Adjust of flange Mounted Pump Injection Timing.

Flange mounted injection pump injection timing checking and adjustment.



• Checking Procedure

- 1) Align the crankshaft pulley TDC mark with the pointer.

Remove the inspection hole cover at the front of the injection pump on the timing gear case cover.

Check the alignment between the pointer ④ on the injection pump gear nut lock plate and the projection area mark ③ on the injection pump gear case.

If it is in misalignment, recheck with turning the crankshaft pulley one more turn to repeat the foregoing procedure to mark sure to be aligned.





Check the alignment of the notched lines ① and ②. (These notched lines were aligned at the plant to set injection pump body and mounting flange.)


Make sure the position of next crank angle of injection starting.

- 2) Turn the crankshaft pulley counterclockwise about 30° crankangle.



- 3) #1 plunger of injection can be visually sured when disconnect injection pipe.





EJM2005I


<Disassembly Steps>

- | | |
|---|-------------------------------------|
| 1. Cooling fan | 8. Injection nozzle |
| 2. Intake pipe | 9. Oil pile: oil filter- oil cooler |
| 3. Fuel return pipe | 10. Injection pump |
| 4. Fuel pipe: fuel filter to injection pump | 11. Fuel filter |
| 5. Fuel pipe; feed pump to filter | 12. Oil filter |
| 6. I/P boom hose (T) | 13. Preheating plug |
| 7. Injection pipe | |



2.2.6. Cylinder Head Disassembly Steps

• DB58



EJM2024S

<Disassembly Steps>

- | | |
|----------------------------------|--|
| 1. Exhaust manifold and gasket | 7. Spring seat (upper) or *Valve rotator |
| 2. Intake manifold and gasket | 8. Valve spring |
| 3. Coolant outlet pipe | 9. Spring seat (lower) |
| 4. Thermostat | 10. Valve |
| 5. Thermostat housing and gasket | 11. Valve stem oil seal |
| 6. Spring collar | |




Importance

- Split collar



Use the valve spring compressor when remove split collar



Valve spring compressor
EJM2027S

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.


CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

2.3.6. Rocker Arm Correction

Check of the valve stem contact part of roker arm


Grind contact surface with an abradant if it is irregularly contacted.

Replace the rocker arm if it is extremely damaged contact surface.



• Rockder Arm Shaft and Rocker Arm

Check the disassembled parts wehter damage or not.




• Outside Diameter of Rocker Arm Shaft



Measure the outside diameter of rocker arm with the micrometer.

Replace shaft if measured value escaped from the specified limit.



	Standard	Limit
Outside Diameter of Rocker Arm Shaft	18.98-19.00 mm	18.85 mm


Clearance of Rocker Arm Shaft and Rocker Arm



1) Measure tne inside diameter of rocker arm bushing with the vernier caliper.

2) Measure the outside diameter of rocker arm.

Replace the rocker arm or rocker arm shaft if measured value escaped from the specified limit.



	Standard	Limit
Inside Diameter of Rocker Arm Bushing	19.01-19.03 mm	19.05 mm

2.3.11. Connecting Rod




• Connecting Rod Alignment

Measure the changed between big end and small end from the calibration of connecting rod balancer.

Replace the connecting rod if the measured value escaped from the specified limit.

Connecting Rod Balancer (Standard 100 mm)

	Standard	Limit
Balancer	0.05 mm	0.20 mm




• Piston Pin and Small End Bushing clearance

Measure an inside of small end pushing and outside of pin with the caliper gauge and micrometer.

Replace a connecting rod bush or piston pin if the measured value escaped from the specified limit.

	Standard	Limit
Clearance of Piston Pin & Bushing	0.010-0.030 mm	0.05 mm



- 1) Fix connecting rod to vice.
- 2) Pull out connecting rod bush as of the using brass rod with the Press or hammer.



• Assemble of Connecting Rod Bush


Use special jig when assemble connecting rod bush.




▲ [CAUTION] Align connecting rod bush oil port and connecting rod oil port.



- 3) Grinde the piston pin hole with grinder or adjustable pilot reamer.



	Standard
Connecting Rod Bush Inside Diameter	35.017-35.025 mm





Warning


• Valve Stem Oil Seal



1) Spread the engine oil to oil seal and the assembled part.



2) Assemble the valve stem oil seal as it is the using jig.



EJM2109S


• Intake and Exhaust Valves

1) Put up the cylinder head on plate.



2) Spread the engine oil to valve stem.

3) Assemble guide position when it is an overhauling valve.




EJM2110S

• Spring of Intake and Exhaust Valve



Assemble the valve spring that it is the bottom painted parts.




EJM2111I

• Spring Seat Split Pin




1) Assemble the split pin with the spring compressed jig as it is a pressing spring.

2) After assemble split pin, completely assemble split pin as it is tapping with the rubber hammer.



Compressed Spring
EJM2112S



EJM2113S




Importance

• Flywheel



1) Apply engine oil on the flywheel bolt.

2) Orderly tighten the fly wheel bolt.(see figure)




EJM2142S

Bolt Torque	$22.3 \pm 2.2 \text{ kg} \cdot \text{m}$
-------------	--

• Injection Pump




Tighten the injection pump bolt as it is a specified torque after assemble the injection pump that it was agreed idler gear angle "C" carving seal and injection pump driving gear angle "C".



EJM1029S

Bolt Torque	$2.6 \pm 0.5 \text{ kg} \cdot \text{m}$
-------------	---



EJM2130S




• Crank shaft pulley nut

Tighten a nut with wrench.



Torque	$60.0 \pm 5.0 \text{ kg} \cdot \text{m}$
--------	--




EJM2144S

• Tappet Chamber Cover

Tighten a bolt spread sealant at the gasket.



Torque	$2.6 \pm 0.5 \text{ kg} \cdot \text{m}$
--------	---



EJM2145S



Importance


• Injection Nozzle



Adjust the injection opening pressure with an adjustment screw which is utilizing the nozzle tester.

Utilize a new gasket and dust cover when it is assemble the nozzle.

Torque	$1.9 \pm 0.2 \text{ kg} \cdot \text{m}$
--------	---




• Fuel Injection Pipe

Surely tighten the delivery valve holder as it is a specified torque.




It will be reason to leakage from the control rack and pipe if it is in excessive tightening.

Torque	$3.1 \pm 0.2 \text{ kg} \cdot \text{m}$
--------	---



• Oil Filter

Torque	$4.3 \sim 6.3 \text{ kg} \cdot \text{m}$
--------	--




• Fuel Pipe

Tighten the joint bolt as it is a specified torque when it is setting up fuel pipe not so as it is a changed to combine check bolt or valve joint.




Install the intake pipe and tighten the intake pipe flange bolts to the specified torque.

Torque	$1.7 \pm 0.1 \text{ kg} \cdot \text{m}$
--------	---



• Suction Pipe

Torque	$2.6 \pm 0.5 \text{ kg} \cdot \text{m}$
--------	---



• Adjustment of Injection Timing

See 1.5. "maintenance".




• **Inspection And Repair**

Correct and replace if it is found the worn, defect or others when check it.



<Unit Bearing>




6. ENGINE ELECTRICALS

6.1. Starter motor

- Main data and specifications

Rated voltage	24V
Rated output	4.5KW/2.5KW
Rating	30 sec
Direction of rotation (viewed from the pinion side)	clockwise
Operating speed	More than 6500 rpm(No load) More than 1600 rpm(Load)

- Construction



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL