

DOOSAN

01256ETRAV
September 2016

WHEEL LOADER

**Shop
Manual**

DL300-5TRAV (NEW YORK BID-21CT)

Serial Number 10001 and Up

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL



DANGER

DANGER - This signal word is used on safety messages and safety labels and indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



WARNING

WARNING - This signal word is used on safety messages and safety labels and indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION

CAUTION - This signal word is used on safety messages and safety labels and indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury.

Other Signal Words

In addition to safety signal words, the following signal words are used to indicate proper and effective use of machine.

IMPORTANT

This signal word identifies procedures which must be followed to avoid damage to machine.

NOTE: *The word "NOTE" identifies information for effective use.*

1. Turn battery disconnect switch to "ON" position.
2. Close battery compartment door.

Seat Belt

Check seat belt daily for correct function.

Inspect seat belt system more often if machine is exposed to severe environmental conditions or applications. Conduct the following inspections and replace seat belt system as necessary:

1. Check webbing. If system is equipped with a retractor, pull webbing completely out and inspect full length of webbing. Look for cuts, wear, fraying, dirt and stiffness.
2. Check buckle and latch for correct operation.
3. Make sure latch plate is not excessively worn, deformed or buckle is not damaged or casing is broken.
4. Check retractor web storage device (if equipped) by extending webbing and checking that it spools out and retracts correctly.
5. Check webbing in areas exposed to ultraviolet (UV) rays from sun or extreme dust or dirt. If original color of webbing in these areas is extremely faded and/or webbing is packed with dirt, webbing strength may be reduced.

NOTE: *Contact your DOOSAN distributor for seat belt system replacement parts.*



WARNING

AVOID DEATH OR SERIOUS INJURY

Failure to properly inspect and maintain seat belt and seat belt system can cause lack of operator restraint and can result in death or serious injury.

Before fastening seat belt, check that there is no problem in belt mounting bracket. If it is worn or damaged, replace seat belt immediately. Fasten seat belt so it is not twisted.

Always wear seat belt when operating machine.

Cleaning

Clean machine before performing inspection and maintenance.

If inspection and/or maintenance are done when machine is dirty, it will become more difficult to locate problems, and this increases the risk of serious injury from slipping on steps and/or the work platform areas.

When washing machine, do the following:

- Wear shoes with nonslip soles to prevent slipping and falling.
- Wear safety goggles and protective clothing when washing machine with high-pressure steam or water.
- Do not spray water directly on electrical components (sensors and connectors). If water gets into electrical system, it can cause operation problems.
- Pick up any tools or hammers that are laying in workplace. Wipe up any grease or oil to prevent slippery surfaces, that can cause tripping or slipping.
- When cleaning cabin top window which is made of polycarbonate material, use tap water. Avoid use of organic solvents for cleaning, such as benzene, toluene or methanol. These solvents can cause a chemical reaction that will dissolve and damage the window.




Figure 33

EX1400134

Proper Tools and Clothing

Only use tools that are intended for the type of service to be done. Metal pieces from low quality or damaged tools, such as chisels or hammers, can break off and cause death or serious injury.

Disassembling Precautions

When using a hammer to remove pins, pins can fly out or metal particles may break off. Always do the following:

- Hitting hard metal pins, bucket teeth, cutting edges or bearings with a hammer, can cause metal pieces to break or fly off resulting in serious injury. Always wear safety goggles and leather gloves. Keep personnel and bystanders away.

ENVIRONMENT AND CIRCUMSTANCES

Work Site Areas Requiring Extra Caution

- Do not operate too close to edge of a quay, ramp, etc.
- Do not operate too close to edge of a steep slope or drop-off. Use caution when working in a place where machine may tip over.
- Do not operate on soft ground or near riverbank that could collapse or where ground may not support weight of machine.
- Observe changes in ground and traction conditions after a rain or other changes in weather.

Digging Under an Overhang

Do not dig work face under an overhang. This can cause overhang to collapse and fall on top of the machine, resulting in death or serious injury.




Figure 45

Deep Digging

Do not perform deep digging under front of machine. The ground under machine may collapse and cause machine to fall resulting in death or serious injury.




Figure 46

Drop-off or Edge

When working near or at an edge of a drop-off, the machine could tip over, which can result in death or serious injury. Always fasten your seat belt. Check ground conditions of work site before operating to prevent the machine from falling or rollover, and to prevent ground, stockpiles, or banks from collapsing.

Do not travel too close to edge of a drop-off. When working on or from top of buildings or other structures, check if structure can support weight of machine and attachment. If a building structure collapses, this can cause death or serious injury.

MEMO

| Item | | Unit | Performance Standard | Remarks | Reference Page | Clearance |
|---|----------|--------------------------------|----------------------|---------|----------------|-----------|
| Front Settlement (Standard Boom, Empty Bucket) | None LIS | Boom Cylinder (Max Reach) | mm/ 5 min | 10 | | Below |
| | | Bucket Cylinder (Max Reach) | mm/ 5 min | 5 | | Below |
| Front Settlement (Standard Boom, Weight Bucket) | | Boom Cylinder (Max Reach) | mm/ 5 min | 10 | | Below |
| | | Bucket Cylinder (Max Reach) | mm/ 5 min | 5 | | Below |
| Front Settlement (Standard Boom, Empty Bucket) | LIS | Boom Cylinder (Max Reach) | mm/ 5 min | 20 | | Below |
| | | Bucket Cylinder (Max Reach) | mm/ 5 min | 5 | | Below |
| Front Settlement (Standard Boom, Weight Bucket) | | Boom Cylinder (Max Reach) | mm/ 5 min | 20 | | Below |
| | | Bucket Cylinder (Max Reach) | mm/ 5 min | 5 | | Below |
| Front Settlement (Highlift Boom, Empty Bucket) | None LIS | Boom Cylinder (Max Reach) | mm/ 5 min | 20 | | Below |
| | | Bucket Cylinder (Max Reach) | mm/ 5 min | 5 | | Below |
| Front Settlement (Highlift Boom, Weight Bucket) | | Boom Cylinder (Max Reach) | mm/ 5 min | 20 | | Below |
| | | Bucket Cylinder (Max Reach) | mm/ 5 min | 5 | | Below |
| Front Settlement (Highlift Boom, Empty Bucket) | LIS | Boom Cylinder (Max Reach) | mm/ 5 min | 30 | | Below |
| | | Bucket Cylinder (Max Reach) | mm/ 5 min | 5 | | Below |
| Front Settlement (Highlift Boom, Weight Bucket) | | Boom Cylinder (Max Reach) | mm/ 5 min | 30 | | Below |
| | | Bucket Cylinder (Max Reach) | mm/ 5 min | 5 | | Below |

MEMO

Fatigue Spalling

Flaking of surface metal resulting from fatigue.

Replace bearing - clean all related parts.




HASA530Si

Figure 10

Brinelling

Surface indentations in raceway caused by rollers either under impact loading or vibration while the bearing is not rotating.

Replace bearing if rough or noisy.



HASA540Si

Figure 11

Cage Wear

Wear around outside diameter of cage and roller pockets caused by abrasive material and inefficient lubrication.

Replace bearings - check seals.



HASA550Si

Figure 12

TORQUE WRENCH EXTENSION TOOLS

Very large diameter, high-grade fasteners (nuts, bolts, cap screws, etc.) require a great deal of turning force to achieve recommended tightening torque values.

Common problems that could occur as a result are:

- Recommended torque exceeds the measuring capacity of the torque wrench.
- Specialized sockets do not fit the adapter on the front end (nose) of the torque wrench.
- Generating adequate force on the back end (handle) of the wrench is difficult or impossible.
- Restricted access or an obstruction may make use of the torque wrench impossible.
- A unique application requires fabrication of an adapter or other special extension.

Most standard torque wrenches can be adapted to suit any one of the proceeding needs or situations, if the right extension tool is used or fabricated.

Torque Multiplication

A wrench extension tool can be used to increase the tightening force on a high capacity nut or bolt.

For example, doubling the distance between the bolt and the back (handle) end of the torque wrench doubles the tightening force on the bolt. It also halves the indicated reading on the scale or dial of the torque wrench. To accurately adjust or convert indicated scale or dial readings, use the following formula:

$I = A \times T / A + B$ where:

I = Indicated force shown on the torque wrench scale or dial.

T = Tightening force applied to the nut or bolt (actual Torque).

A = Length of the torque wrench (between the center of the nut or bolt and the center of the handle).

B = Length of the extension.

As an example, if a 12" extension is added to a 12" torque wrench, and the indicated torque on the dial reads "150 ft lb", the real force applied to the bolt is 300 ft lb:

$$I = \frac{A \times T}{A + B} = \frac{12 \times 300}{12 + 12} = \frac{3600}{24} = 150$$




Figure 1

0552A


INSPECTION

Cleaning the Engine

The engine must be cleaned before starting work.

Clean with water and use a hot wash. Also use a degreasing agent, if necessary.

Avoid spraying water on the engine control unit, see illustration. Clean the components that are inside the marked area.



FG020224



CAUTION

AVOID INJURY

Wear personal protective equipment (PPE) when cleaning engine with hot pressurized water.

Figure 2

SPECIAL TOOLS

| Number | Designation | Picture | Tool Board |
|---------|-----------------|-------------------------------|------------|
| 99 331 | Fixture | <p>FG020229</p> | A |
| 587 692 | Universal Stand | <p>99 612</p> <p>FG020230</p> | |
| 98 094 | Lifting Chain | <p>FG020233</p> | |

TIGHTENING TORQUES

Normal Tightening Torque

The specifications in the tables below show the normal tightening torque for screws, nuts and unions. The values are to be used unless other values are specified in the inspection information. Always check whether there are special tightening torques given in the descriptions for the respective areas in the inspection information before using the general values for normal and special tightening torques respectively.

The following conditions apply:

- A tolerance of $\pm 15\%$ applies to all values unless otherwise specified.
- All contact surfaces are to be clean and free of paint.
- Bolts and nuts are normally not lubricated regardless of surface treatment. All exceptions are specified in the inspection information.

Union Assemblies





The specified values apply with a tolerance of $\pm 5\%$. The values apply to tightening with a counterhold.

Thread Inserts

The specified tightening torques also apply to bolted joints with a thread insert (Heli-Coil).

Thread inserts often provide greater strength compared to a directly screwed thread. This generates a stronger bolted joint in aluminum or the like.

NOTE: *When a damaged thread is repaired with a thread insert, the normal screw and prescribed tightening torque are to be maintained. Install the thread insert as instructed in the inspection information.*

| | |
|--|--|
| Pressure Pipe | |
| <ul style="list-style-type: none"> Nut (M20): 38 Nm Nut (M16): 38 Nm Nut (M18 x 1.5): 35 ±5 Nm |  <p>EX1301851</p> |
| Accumulator | |
| <ul style="list-style-type: none"> End connection: 27 Nm + 90° Safety valve: 27 Nm + 90° Pressure sensor: 47 Nm | |
| High-pressure Pump | |
| <ul style="list-style-type: none"> Pump gear: 300 Nm |  <p>EX1301852</p> |
| <ul style="list-style-type: none"> High-pressure pump, cylinder head bolt: 68 Nm |  <p>EX1301853</p> |
| <ul style="list-style-type: none"> Screw for feed pump: 25 Nm |  <p>EX1301854</p> |

CYLINDER

Cylinder Head

Specifications

| | |
|-------------------------------------|--------------------|
| Intake Valve | |
| Oversize Valve Seat, Outer Diameter | 46.254 - 46.265 mm |
| Valve Seat Position, Outer Diameter | 46.200 - 46.216 mm |
| Valve Seat Position, Deep | 11.25 - 11.35 mm |
| Exhaust Valve Seat | |
| Oversize Valve Seat, Outer Diameter | 44.281 - 44.292 mm |
| Valve Seat Position, Outer Diameter | 44.200 - 44.216 mm |
| Valve Seat Position, Deep | 11.25 - 11.35 mm |

- Remove cylinder head according to the work description Operation & Maintenance Manual.
- Remove inlet and exhaust valves according to the work description Operation & Maintenance Manual.

Overview




Figure 28

EX1302147

- When the sealing surface of the valve seat insert has been machined, reduce the cutting pressure by turning 2 - 3 revolutions without any feed. Continue turning clockwise while turning the screw counterclockwise until cutter is free.

Disconnect the solenoid by briefly pressing switch position 2.

- Continue with the next valve seat insert as described in the steps above.

Height Check Valve Seat Insert

- Make sure that cylinder head is clean.

NOTE: Use the same exhaust valve for the measurement below to avoid measurement errors.

- Install the exhaust valve in the first valve guide. Measure the height of the exhaust valve.




Figure 66

- Install the same exhaust valve in the second valve guide. Measure the height of the exhaust valve.




Figure 67

- The height tolerance between exhaust valves is ± 0.05 mm. If the difference is greater, machine the valve seat insert which is highest until height tolerance is obtained.

Also check that distance between the valve disk and the bottom of the cylinder head is not less than 0.71 mm as shown in the illustration.




Figure 68

IMPORTANT

Measure the lower cylinder liner diameter to make sure the cylinder liner mounted in the cylinder block is 139 mm (5.47 in) or 140 mm (5.51 in).

| Reference Number | Description |
|------------------|----------------|
| 1 | Pin |
| 2 | Loose Stop Lug |




Figure 107

FG020334

1. Check the fixture. Insert the gauge and check that micrometer indicates 0.00 mm. The loose stop lug must be removed to use the gauge. Install the loose stop lug after checking and adjusting if required.

| Reference Number | Description |
|------------------|----------------|
| 1 | Gauge |
| 2 | Key |
| 3 | Loose Stop Lug |




Figure 108

FG020335

2. Remove hexagon socket screw in the center of the cutting head.





Figure 109

FG020336

Replacing the Rear Crankshaft Seal


1. Remove flywheel according to instructions.
2. Remove crankshaft seal using a screwdriver. Take care not to scratch the sealing surfaces on the crankshaft and the flywheel housing. Alternatively a self tapping screw can be screwed into the crankshaft seal so the crankshaft seal can be pulled out with a slide hammer.



FG020374

Figure152


NOTE: *The crankshaft seal must be installed dry and must not be lubricated. The sleeve in the seal must be left in place. Do not touch the sealing lip with your fingers.*



FG020375

Figure 153

3. Install a new crankshaft seal using tool 99 148. Place the crankshaft seal on the tool and fasten the tool with the bolts.
4. Tighten the bolts alternately until tool stops against the cover. Then remove tool and the protection ring of the crankshaft seal.
5. Clean the flywheel sealing surface using degreasing agent and wipe it dry before assembly.
6. Install the flywheel according to instructions.



FG020376

Figure 154

6. Apply sealant to the timing gear plate using nozzle 584 118. The sealant must be placed outside the milled grooves as illustrated. The diameter of the bead must be approximately 4 mm.

IMPORTANT

Ensure that you apply sealant inside the screw holes, but without allowing sealant into the crankcase. The sealant may block channels and nozzles. This is particularly important to bear in mind around oilways, where the flow of oil to the air compressor or injection pump can be blocked.

IMPORTANT

Assembly must be completed within 25 minutes of starting to apply the sealant.

7. Install the timing gear plate onto the cylinder block. Tighten the screws.
8. Install the intermediate gear as instructed in the work description "Installing Intermediate Gears" on page 4-1-154.
9. Ensure that markings on the camshaft gear point towards the center of the intermediate gear.
10. Install the camshaft gear and tighten the screws.
11. Install the flywheel housing as described in the work description "Installing the Flywheel Housing" on page 4-1-97.
12. Install the flywheel as described in the work description "Installing the Flywheel" on page 4-1-130l.
13. Install all components that were removed from the engine side: High-pressure pump, fuel filter housing with holder, engine control unit.
14. Remove all old sealing compound on the cylinder block and the sealing surface on the front camshaft cover. Clean off any oil and grease from the sealing surfaces using an alcohol based detergent.

IMPORTANT

Clean thoroughly, as the sealing surfaces must be completely free of grease.




Figure 183

FG020396




Figure 184

FG020397

6. Install the left-hand and right-hand rear adjustable stays (the longer model) on the front sliding bracket. Use 2 anti-slip devices on each stay.




Figure 221 Left

EX1301947




Figure 223 Right-hand Rear Stay

EX1301948

7. Install the 2 upper rollers
Turn the narrow groove on the roller towards the clutch.
Install screws and support sleeves between the adjustable stays.
Tighten the screws of the rollers and the rear adjustable stays to the sliding bracket.
A. Turn the narrow groove on the roller towards the clutch.




Figure 224

EX1301949

IMPORTANT

The belt tensioner should only be moved in the direction which releases belt transmission tension. The belt tensioner can be damaged if the belt tensioner is tightened in the wrong direction.

7. Check that poly-V-belt is correctly routed on all pulleys and idler rollers.

Checking the Poly-V-Belt

Check poly-V-belt for cracks and wear as follows:




Figure 258

FG020434

NOTE: *The poly-V-belt has cracks and must be replaced.*




Figure 259

FG020435

NOTE: *Poly-V-belt beginning to show signs of wear. The Poly-V-belt may be reinstalled.*




Figure 260

FG020436

The oil pump draws lubrication oil from the oil sump by the oil strainer.

After the oil pump, the lubricating oil passes a safety valve. If the oil pressure exceeds 9.5 bar, the safety valve opens and feeds the lubricating oil back to the oil sump. If the oil pressure is too high, the oil pump and other lubrication system components may be exposed to severe stress.

The lubrication oil then passes through the oil cooler. Some of the lubrication oil is passed through the centrifugal oil cleaner. After cleaning, the oil is fed back to the oil sump.

The rest of the lubrication oil passes through a relief valve which regulates the pressure in the oil system. Excess lubricating oil is drained back to the oil sump.

The lubrication oil passes on to the oil filter for cleaning.

Lubrication oil reaches the camshaft bearings and crankshaft main bearing by ducts in the cylinder block.

Ducts in the crankshaft lead the lubrication oil to the connecting rod bearings.

A duct leading from the main duct takes lubrication oil to the rocker arms.

The channel is constantly pressurized. The oil is fed to the roller tappet shafts by grooves in the camshaft bearing. The roller tappet shafts have drilled ducts for lubricating the roller tappets.

The pistons are cooled by the lubrication oil. Oil is sprayed up under the piston crown through special nozzles, one for each cylinder.

The piston cooling valve opens at 1.7 - 2.2 bar.

There is no piston cooling at low speed (Idling).




Figure 292

EX1302096




Figure 293

EX1302097



Figure 294

EX1302098

Troubleshooting

If chips are discovered, for example, in the engine oil, oil sump, engine oil filter, centrifugal oil cleaner or on the drain plug, there is a fault in the engine. Chips act as an internal abrasive and will ruin the engine. Always determine the cause of chips found inside the engine. Clean the parts that are to be reused and rectify any faults.

Magnetic chips are metal particles caused by excessive wear in, for example, gears, shafts, pistons and cylinder liners.

Because chips from bearings are not magnetic, they do not get caught by the magnetic drain plug.

A failed ceramic rod inside the high-pressure pump will result in white ceramic material appearing among the metal chips.

IMPORTANT

When checking the oil filter: Remove complete oil filter housing to stop any chips from entering the clean side. Lift out the filter housing cover with filter. Detach the old filter and check for chips on the inside and the outside of the filter. If there is only a small amount of chips, clean the oil filter housing and install a new oil filter.

See the components in the lubrication system in the illustration below.

NOTE: *high-pressure fuel pump and crankcase ventilation centrifugal oil separator are not part of the illustration.*

| Reference Number | Description |
|------------------|--|
| 1 | Oil Strainer |
| 2 | Oil Pump |
| 3 | Safety Valve (Located in the Oil Pump) |
| 4 | Oil Cooler |
| 5 | Centrifugal Oil Cleaner |
| 6 | Relief Valve (Located in the Oil Cleaner Housing) |
| 7 | Oil Filter |
| 8 | Piston Cooling Valve (Located in the Oil Cooler Housing) |
| 9 | Oil Pressure Sensor (Located in the Oil Filter Housing) |




Figure 328

Outline Diagram of the Oil Circulation in the Lubrication System

NOTE: *high-pressure fuel pump and crankcase ventilation centrifugal oil separator are not part of the illustration.*

- The exhaust gases are treated in several steps before being released by the tailpipe. These steps are based on the combustion control mode of the engine control unit.
- Through engine control unit (EMS) regulation, the exhaust gases are monitored and treated several steps before being released by the end pipe. The concentration of NOx is measured by the NOx sensor (8) and the EEC control unit transmits the value to the engine control unit. The exhaust gases then pass the oxidation catalytic converter (13) where the NO2 rate of the exhaust gases increases and any surplus diesel is burned.
- The exhaust gases pass the evaporator (6), where reductant is injected. In order for the process to work, the exhaust gas temperature must have reached 200 - 250°C. The exhaust gas temperature is measured by the temperature sensor (10) and the value read by the EEC control unit and sent to the engine control unit. If the temperature is too low or too high the engine control unit adjusts its combustion control mode.
- The EEC control unit controls the amount of reductant from the reductant tank (1) by activating and indicating the pump speed to the reductant pump (11) and the dose to the reductant doser (12). The values from the NOx sensors, exhaust gas temperature sensor and the combustion control mode of the engine control unit form the basis of the volume of reductant to be metered.
- When reductant has been mixed with the exhaust gases (evaporation), the exhaust gases pass the SCR catalytic converter (9), where the NOx is converted into water and nitrogen. In a last step the exhaust gases pass an ammonia slip catalytic converter (positioned in the SCR catalytic converter) that reduces any ammonia slip.
- Before the exhaust gases are released the NOx concentration is measured by NOx sensor (7). The value is read off by the EEC control unit and transmitted to the engine control unit. The value is compared to the NOx concentration from NOx sensor (8) and forms the basis of the combustion control mode of the engine control unit and any adjustment of the exhaust temperature or reductant dose.
- **Shutdown**
- When the engine is switched off after being subject to heavy loading and heat release, the reductant pump (11) continues for a set period to deliver reductant to the reductant doser (12). However, reductant is not injected into the evaporator (6) but is returned to the reductant tank (1) and has the purpose of cooling the reductant doser (12). Do not switch off the battery master switch during cooling, otherwise the reductant doser may be damaged by the radiated heat from the exhaust system.

IMPORTANT

The SCR system may need up to 30 minutes to cool the reductant doser in extreme conditions. The battery master switch must not be switched off before then.

Checking Reductant Pick-up Unit

Method for checking the reductant pick-up unit.

Fault codes EMS 8255 (low level within limit)

1. Top up with reductant.
2. Go to the next step if a fault code is still registered.

Preparations to check other EMS fault codes (8252/8253/8285/8284)

NOTE: *Remember to shut off the recirculation of coolant from the reductant pick-up unit before removal.*

1. Remove reductant pick-up unit from the tank.
2. Reconnect the cable harness.

Fault codes EMS 8252 or EMS 8253 (level outside limits)

1. Clean the float pipe of crystals.
2. Clean the suction pipe and the return pipe using compressed air and lukewarm water.

IMPORTANT

It takes approximately 3 minutes before ICL indicates the correct level. Wait for the value to stabilize. It is possible to check the reductant level in checking tool.

3. Position the float in the lowest position (1) and check the level on ICL or checking tool.
4. Position the float in the middle position (2) and check the level on ICL or checking tool.
5. Position the float in the uppermost position (3) and check the level on ICL or checking tool.
6. Replace the reductant pick-up unit if it shows the wrong temperature.

Fault codes EMS 8285 or EMS 8284 (temperature outside limits)

NOTE: *Incorrect temperature in the reductant pick-up unit can cause low consumption of urea.*

NOTE: *It is also possible to measure the resistance manually instead of using checking tool. Measure between pin 2 and pin 3 on sensor T116. The resistance must be approximately 2.2 kohm at 20°.*

1. Check that temperature for T116 in checking tool is stable.
2. Compare the temperature according to T116 with the temperature according to T27 in checking tool.
3. Replace the reductant pick-up unit if it shows the wrong temperature.




Figure 365

EX1302195

4. Remove pump.

IMPORTANT

Blow the new pump's suction nipple with compressed air (approximately 6 bar) for at least 3 seconds before installing the pump.

5. Install a new pump.
6. Install the electrical connection to the pump.
7. Install the hoses to the pump. Use soapy water or distilled water with a 3% urea mixture if required.
8. Remove clamps from the coolant hoses.
9. Perform a system check of the check tool system using checking tool to bleed and function test the system.




Figure 388

EX1302211

Replacing Reductant Filter



Figure 389

EX1302212





Figure 390

EX1302213

Removing the Reductant Tank


1. If necessary, empty the reductant tank by sucking out the fluid or opening the nipple.



WL1400Q55

Figure 415

2. Undo the screws and remove straps.



WL1400056i

Figure 416

3. Clamp the coolant hose using a welding clamp to stop the coolant flow.




WARNING

AVOID DEATH OR SERIOUS INJURY

The hose contains coolant from the engine. Open the coolant fill cap first to relieve any pressure.

4. Pull out the hoses. These connections may be tight.
5. Remove reductant tank. If there is a lot of fluid in the tank, to make it easier you can pull a strap through the opening in the reductant tank and pull it out on a trolley.



WL1400057

Figure 417




EX1302237

Figure 418

Variable Geometry Turbocharger

Location



FG020504

Figure 454

Function

Variable geometry turbocharger

Like the fixed geometry turbocharger, the variable geometry turbocharger consists of a turbine and a compressor. The turbine is driven by the engine exhaust gases and the compressor compresses the air going into the engine. The compressor impeller and turbine wheel are located on the same shaft. The bearing housing is situated between the compressor and the turbine.

There is an axially movable nozzle ring in the turbocharger which is used to control the width in the turbine intake. When the nozzle ring is moved so gap is reduced, a higher exhaust back pressure is obtained. A higher exhaust back pressure increases the speed of the exhaust gases, which produces a higher turbine rotation speed and therefore a greater airflow into the engine.

The movement of the nozzle ring is controlled by an electric motor which is controlled by the engine control unit. The variable geometry turbocharger then differs here from the conventional one, in which the volume of air going into the engine is directly dependent on the power output without any special regulating system.

The electric motor changes the position of the nozzle ring after receiving a CAN message from the engine control unit. There is

 **WARNING**

AVOID DEATH OR SERIOUS INJURY

Risk of crush injuries. The actuator can be activated automatically when supplied with voltage. Caution!

1. Drain the coolant.
2. Remove cable bracket (A).
3. Remove contact housing (B).




Figure 473

EX1302031

4. Remove nut on the rear to detach the link arm from the actuator.




Figure 474

EX1302032

Function

The charge air pressure sensor detects the absolute pressure in the intake manifold, i.e. the atmospheric pressure plus the positive pressure provided by the turbocharger.

The signal from the sensor is directly proportional to the charge air pressure. A high-pressure gives a high voltage and vice versa.

The engine control unit uses the information from the charge air pressure sensor to control the relationship between the intake air and EGR gases going to the engine.

Depending on the factors that requested the acceleration, engine speed, engine acceleration and charge air temperature, the engine control unit will expect a certain charge air pressure. Should there be a fault in the signal, the engine control unit will work to a preset pressure value. At the same time, the engine torque will be limited and a fault code will be generated.

Thermostat

Description

The thermostat is used to regulate the amount of coolant which passes through the radiator.

Location




Figure 501

FG020519

NOTE: *Replace coolant hoses if there is clear damage to the coolant hoses which were removed.*

2. Place a rag over the high-pressure pipe cap nut 1 (at the accumulator) of the cylinder in question. Then carefully undo the nut.
3. Undo the cap nut in the other end of the high-pressure pipe and remove pipe.
4. Undo the cap nut at connection 2. Hold tight so the connection is not turned when the cap nut is undone. There is a pin on the connection which can be damaged.

IMPORTANT

Make sure that it is clean around the connection before it is drawn out from the engine. Dirt must not enter the fuel system.

IMPORTANT

A high-pressure pipe that has been loosened or removed, must never be reinstalled but must be replaced by a new one.

5. Pull out the connection from the cylinder head. If it jams and is difficult to pull out, you can replace the cap nut with a nut with part number 812 889 and break carefully with a crow bar.




Figure 520

EX1302181




Figure 521 When removing unions and safety valve

FG020531

Several unions and the safety valve in the system are sealed with a sealing washer which must be replaced if the parts have been disassembled. There is a plug at the accumulator end on 5 cylinder engines. This is sealed with the same type of washer. The old washer is often stuck and can be difficult to remove without damaging the sealing surface.

Injector



WARNING

AVOID DEATH OR SERIOUS INJURY

The fuel system has a very high fuel pressure of up to 3,000 bar.

The system should always be treated as pressurized, even when the engine is switched off.

Wear protective gloves and goggles.

IMPORTANT

The fuel system is very sensitive to dirt. It is therefore very important that everything is as clean as possible when work is done on the fuel system.

Compressed air must not be used to blow components clean if the fuel system is open.

When cleaning, cloths or paper which shed fibers must not be used. Use lint-free cloths.

Clean tools before use.

Do not use worn chrome-plated tools as flakes of chrome may come off.

Cover connections of removed components with a lint-free cloth and tape.

IMPORTANT

The holes in the injection nozzles are very small and must not be cleaned with any kind of cleaning tool because it will damage them.


Function

There is one injector for each cylinder. The injector is controlled electrically by the engine control unit.

The injector operates in two phases. One phase is when no power is supplied to the injector and it is closed. The other phase is when power is supplied to the injector and it is open.

The injector consists of a piston, injection nozzle needle, spring and an electromagnetically controlled fuel valve.


The fuel enters the injector by the connection. The injector is continuously pressurized to a maximum of 2,400 bar. When the



FG021465

Figure 570

L - Low-pressure Check



FG021462

Figure 571

flow of air and exhaust gases into the engine is controlled by the variable or fixed geometry turbocharger, throttle and/or EGR valve.

You can read more about this process in the descriptions covering these components.

Exhaust Brake

If the engine control unit receives a request for exhaust braking, it sends a signal to the exhaust brake proportional valve. The proportional valve then distributes compressed air to the exhaust brake control cylinder. The control receives feedback on the back pressure that exhaust brake creates.

Industrial engines use an electrically controlled damper for the exchange of gases. By controlling the damper position, the exhaust gases are restricted thus creating a back pressure. Apart from enhancing the engine braking action, the back pressure created also warms up the engine more rapidly and keeps the exhaust gas aftertreatment system warm.

Interaction with Other Systems

Functions involving the interaction of the engine control unit with other systems are described below. A more detailed description is provided under the relevant user function.

Request for Torque

The control units for the gearbox management system, GMS, and brake management system, BMS, can, if necessary, request torque by the engine control unit when changing gear and for traction control. The system concerned may request maximum torque for a short period, then the torque is limited to approximately 70% for a further period. If the time limit is exceeded, the engine control unit resumes control.

If both systems request control over torque at the same time, the GMS request has the highest priority.

Request for Limited Torque

The control units for the gearbox management system, GMS, and brake management system, BMS, can, if necessary, request limited torque. The engine control unit then limits the fuel volume according to the system which requests the lowest torque. If required, the fuel injection can be switched off completely. The function is not accessible under start. If the torque is limited so much when idling there is a risk of the engine stopping, the idle speed control will intervene and increase the fuel volume so engine speed is maintained.

Request for Exhaust Brake During Rapid Warm-up and When Using the White Smoke Limiter

During rapid warm-up and when using the white smoke limiter, the engine control unit receives a request from the coordinator

| Control Unit Pin | Task | Signal Type | Source/Destination |
|------------------|--|---------------------------|---|
| B15 | | | |
| B16 | Grounding of Reductant Pump | Grounding (0V) | Reductant Pump (V183) |
| B17 | Reductant Pump Speed | Input Signal, PWM Signal | Reductant Pump (V183) |
| B18 | | | |
| B19 | | | |
| B20 | | | |
| B21 | | | |
| B22 | | | |
| B23 | | | |
| B24 | | | |
| B25 | | | |
| B26 | | | |
| B27 | | | |
| B28 | | | |
| B29 | | | |
| B30 | Measuring the Exhaust Gas Temperature Downstream of the Particulate Filter | Grounding (0V) | Temperature Sensor Downstream of the Particulate Filter (T113) |
| B31 | Measuring the Exhaust Gas Temperature Downstream of the Particulate Filter | Input Signal | Temperature Sensor Downstream of the Particulate Filter (T113) |
| B32 | Heating the Reductant Injection Nozzle | Output Signal, PWM Signal | Reductant Injection Nozzle (V117) |
| B33 | Heating the Reductant Injection Nozzle | Grounding (0V) | Reductant Injection Nozzle (V117) |
| B34 | | | |
| B35 | | | |
| B36 | Heating the Reductant Pickup Unit | Output Signal, PWM Signal | Reductant Pick-up Unit (V118) |
| B37 | Heating the Reductant Pickup Unit | Grounding (0V) | Reductant Pick-up Unit (V118) |
| B38 | Measuring Reductant Temperature | Input Signal | The Reductant Tank Level and Temperature Sensor (T116) Deviations can occur |
| B39 | Measuring Reductant Temperature and Level | Grounding (0V) | The Reductant Tank Level and Temperature Sensor (T116) Deviations can occur |
| B40 | Measuring Reductant Level | Input Signal | The Reductant Tank Level and Temperature Sensor (T116) Deviations can occur |
| B41 | Heating the Reductant Hose 1 (Option) | Grounding (0V) | Reductant Hose 1 (H25) |
| B42 | Heating the Reductant Hose 1 (Option) | Output Signal, PWM Signal | Reductant Hose 1 (H25) |
| B43 | Heating the Reductant Hose 2 (Option) | Grounding (0V) | Reductant Hose 2 (H26) |
| B44 | Heating the Reductant Hose 2 (Option) | Output Signal, PWM Signal | Reductant Hose 2 (H26) |
| B45 | | | |
| B46 | | | |

P3, Alternator

Description

The alternator supplies components with current and charges the batteries.

Location




Figure 628

EX1302318

Specification

| | 100 A |
|---------------------|-------------------|
| Designation | 28V 40/100A |
| Power at 6,000 rpm | 2,800 W |
| Resistance in rotor | 8.5 ohm $\pm 5\%$ |
| Brush length | > 1 mm |

| Engine speed (rpm) | 100 A |
|---------------------------|--------------|
| 500 | 40 |
| 600 | 60 |
| 800 | 80 |
| 1,500 | 100 |

Function


The engine control unit determines when the alternator is activated. The engine speed must be sufficient, i.e. approximately 400 rpm, to ensure that activation takes place. The engine control unit receives signals from the alternator if it is active and if charging is taking place. If the engine control unit registers a fault in charging from the alternator, a fault code is generated and the charging light on the instrument panel comes on. After checking the cable harness and connectors, it is advisable to perform a check on the alternator.

The alternator is driven by the engine's poly-V-belt. When the engine speed increases, the alternator speed also increases resulting in a higher alternator voltage.

A charge regulator installed on the alternator is used to ensure that alternator voltage does not become too high when the engine speed increases. It is a transistor type charge regulator and regulation takes place by grounding pin number 2 (L) on the charge regulator.

Connector C4001

Overview




WL1400027

Figure 659

Connection


| Pin | Signal |
|-----|--|
| 1 | Voltage U30 to the Engine Control Unit |
| 2 | U31, Ground |
| 3 | Voltage U15 to the Engine Control Unit |
| 4 | Voltage U30 to the Engine Control Unit |
| 5 | U31, Ground |
| 6 | CAN Signal High |
| 7 | CAN Signal Low |
| 8 | Engine Running, + 24 V |



WL1400028

Figure 660

Location



WL1400024

Figure 661

Drivetrain

The oil which is streaming out of the impeller, enters the turbine wheel and is there reversed in the direction of flow.

According to the rate of reversion, the turbine wheel and with it also the output shaft is receiving a more or less high reaction torque.

The stator (reaction member), the following the turbine, has the task to reverse the oil streaming out of the turbine once more and to deliver it under the suitable discharge direction to the impeller.

Due to the reversion, the stator is receiving a reaction torque.

The relation turbine torque/pump torque is called torque multiplication. This is the higher, the greater the speed difference of impeller and turbine wheel will be.

Therefore, the maximum torque multiplication is created at stationary turbine wheel.

With increasing output speed, the torque multiplication is decreasing. The adaption of the output speed to a certain required output torque will be infinitely variable and automatically achieved by the torque converter.

When the turbine speed is reaching about 80% of the pump speed, the torque multiplication becomes 1,0 i.e. the turbine torque becomes equal to that of the pump torque.

From this point on, the converter is working similar to a fluid clutch.

A stator freewheel serves to improve the efficiency in the upper driving range, in the torque multiplication range it is backing-up the torque upon the housing, and is released in the clutch range. In this way, the stator can rotate freely.

Engine Pickup Sensor

1. Detects revolution of gear array in engine side.
2. Specification
 - Resistance: $1050\Omega \pm 10\%$ (at 20°C)
 - Fasten torque: 3.06 kg.m (22 ft lb)
 - Gap: $0.5 + 0.3$ mm (0.0197 - 0.0118 in)
 - Output: 4 Pulse/Rev.




Figure 19

AJS0230L

Central Gear Pickup Sensor

1. Detects revolution of central gear array.
2. Specification
 - Resistance: $1050\Omega \pm 10\%$ (at 20°C)
 - Fasten torque: 3.06 kg.m (22 ft lb)
 - Gap: $0.5 + 0.3$ mm (0.0197 + 0.0118 in)
 - Output: 91 Pulse/Rev.




Figure 20

AJS0240L

Turbine Pickup Sensor

1. Detects revolution of gear array in turbine side.
2. Specification
 - Resistance: $1050\Omega \pm 10\%$ (at 20°C)
 - Fasten torque: 3.06 kg.m (22 ft lb)
 - Gap: $0.5 + 0.3$ mm (0.0197 + 0.0118 in)
 - Output: 59 Pulse/Rev.




Figure 21

AJS0250L

Output Speed Sensor

1. Detects revolution of gear array in transmission output side.
2. Specification
 - Voltage Supply: 20 V - 32 V
 - Operation Frequency: 2 Hz - 5 KHz
 - Fasten torque (M8): 2.35 kg.m (17 ft lb)
 - Gap: $0.5 + 0.3$ mm (0.0197 + 0.0118 in)
 - Output: 60 Pulse/Rev.





Figure 22

AJS0260L

**Kick-down: Forward Second Gear to Forward First Gear
(T/M Shift Switch MAN- Manual Mode)**




WL1400345

Figure 45

| Reference Number | Description |
|------------------|-----------------------|
| 1 | T/M Controller |
| 2 | T/M Selector Switch |
| 3 | T/M Control Valve |
| 4 | Fuse Box 1 |
| 6 | Downshift Switch |
| 7 | Output Speed Sensor |
| 8 | Speed Pickup Sensor 3 |
| 9 | Speedometer |

| Reference Number | Description |
|------------------|----------------------------|
| 10 | Parking Brake Switch |
| 11 | Vehicle Controller |
| 12 | Fuse Box 2 |
| 14 | T/M Oil Temperature Sensor |
| 15 | Bypass Filter Switch |
| 16 | Diagnostic Connector (T/M) |
| 17 | ECU |
| 22 | Keypad (T/M Shift Switch) |

9. Remove retaining clamp (1, Figure 64).




FG02064C

Figure 64

10. Loosen torx screws (1, Figure 65) and remove cover (2, Figure 65). Remove opposite cover (3, Figure 65) in the same way.

(S) Socket wrench TX-27 5873 042 002




FG020641

Figure 65

11. Remove wiring harness (1, Figure 66).


Loosen cylindrical screws (3, Figure 66), remove fixing plates and remove pressure controllers (2, Figure 66).



FG020642

Figure 66

12. Loosen torx screws, remove fixing plates and remove pressure controllers (1, Figure 67) on opposite side.



FG02064E

Figure 67

- Pull clutch (1, Figure 116) off the shaft.

NOTE: *Disassembly clutch (1, Figure 116) see Figure 122 - Figure 127.*




Figure 116

- Remove idler gear (1, Figure 117) using cut-off device and pull it off the clutch shaft.

(S) Cut-off device 5870 300 024

(S) Puller 5870 300 033




Figure 117

- Snap retaining ring (2, Figure 118) out of the idler gear (1, Figure 118) and remove ball bearing (3, Figure 118).




Figure 118

- Remove needle cage (1, Figure 119) from the shaft (2, Figure 119).




Figure 119

K3 Clutch

1. Snap out piston ring (1, Figure 171).




Figure 171

2. Pull tapered roller bearing (inner ring) off the shaft.
(S) Forcing device 5870 026 100
(S) Grab sleeve 5873 001 059




Figure 172

3. Remove axial bearing assembly (1, Figure 173).




Figure 173

4. Take off idler gear (1, Figure 174), remove needle cage (2, Figure 174) and axial bearing assembly (3, Figure 174).




Figure 174

3. Mount needle cage 60 x 68 x 20 (1, Figure 229) onto the shaft and oil it.




Figure 229

FG022870

4. Install ball bearing 50x90x18 (2, Figure 230) into the idler gear (1, Figure 230) until contact is obtained and attach it using retaining ring 90x3 (3, Figure 230).




Figure 230

FG022889

5. Press in preassembled idler gear (1, Figure 231) onto the shaft until contact is obtained.




Figure 231

FG022872

6. Place both O-rings (1 and 2, Figure 232) into the piston grooves and oil them.

| Reference Number | Description |
|------------------|-------------|
| 1 | 75 x 3 |
| 2 | 142 x 3 |

NOTE: Check function of the drain valve (see arrow). There must be no jamming of the ball.




Figure 232

FG022873

12. Heat up clutch inner diameter (approximately 120°C (248°F)).



FG022882

Figure 286


13. Mount clutch (1, Figure 287) until contact is obtained.



CAUTION

AVOID INJURY

Wear protective gloves.




FG022903

Figure 287

14. Mount running disk 55x78x5 (1, Figure 288), axial cage 55x78x3 (2, Figure 288) and axial washer 55x78x1 (3, Figure 288) and oil it.


NOTE: *Install chamfer (see arrow) of running disk (1, Figure 288) showing towards the axial cage.*



FG022904

Figure 288

15. Mount needle cage 55x63x50 (1, Figure 289) and oil it.



FG022905

Figure 289

- Secure drive gear using retaining ring 100x3 (1, Figure 344).




Figure 344

- Heat up bearing inner ring (approximately 120°C (248°F)).



Figure 345

- Mount bearing inner ring (1, Figure 346) until contact is obtained.



CAUTION

AVOID INJURY

Wear protective gloves.

NOTE: *Adjust bearing inner ring after cooling down.*




Figure 346

- Heat up bearing inner ring (approximately 120°C (248°F)).




Figure 347

Engine Connection, Oil Pressure Pump, Converter Back-pressure Valve and Temperature Sensor (Measuring Point "63" After the Converter)

Converter Back-pressure Valve

1. The figure shows the single parts of the converter back pressure valve.

| Reference Number | Description |
|------------------|--------------------|
| 1 | Oil Feed Housing |
| 2 | Piston |
| 3 | Compression Spring |
| 4 | Pressure Plate |
| 5 | Locking Plate |




FG023124

Figure 398

NOTE: Install pressure plate (4, Figure 398), with the pin ($\varnothing 6$ mm) showing to the locking plate (5, Figure 398).

2. Assemble single parts, preload them with assembly aid (S, Figure 399) and attach them using locking plate (1, Figure 399).

(S) Assembly aid 5870 345 107



FG023125


Figure 399

3. Mount temperature sensor (1, Figure 400) with O-ring 11x2.

Tightening torque $M_A = 25$ N.m

NOTE: Version without temperature sensor: Install a screw plug (1) with O-ring 11x2.

Tightening torque (M14x1.5) $M_A = 25$ N.m



FG023126

Figure 400

FAILURE CODE

The fault codes shown in this table are a complete list of codes that are common to more than one version of the transmission. Some of the versions are four speed and five speed.

NOTE: Refer to "Failure Code at Transmission Side" on page 11-1-107.

NOTE: This failure code table is applied to both of 4WG and 5WG transmission.

| Fault Code (Hex) | Meaning of the Fault Code (Possible Reason for Fault Detection.) | Reaction of the TCU | Possible Steps to Repair | Remarks |
|------------------|--|--|---|--|
| 10 | <p>Logical error at direction select signal 3rd shift lever. TCU detected a wrong signal combination for the direction.</p> <ul style="list-style-type: none"> Cable from shift lever 3 to TCU is broken. Cable is defective and is contacted to battery voltage or machine ground. Shift lever is defective. | <p>TCU shifts transmission to neutral if selector active.</p> <p>OP-Mode: transmission shut down if selector active.</p> | <ul style="list-style-type: none"> Check cables from TCU to shift lever 3. Check signal combinations of shift lever positions F-N-R. If shift lever is a CAN shift lever check CAN cable/shifter/device. | Fault is cleared if TCU detects a valid neutral signal for the direction at the shift lever. |
| 11 | <p>Logical error at gear range signal. TCU detected a wrong signal combination for the gear rang.</p> <ul style="list-style-type: none"> Cable from shift lever to TCU is broken. Cable is defective and is contacted to battery voltage or machine ground. Shift lever is defective. | <p>TCU shifts transmission to neutral.</p> <p>OP-Mode: transmission shut down.</p> | <ul style="list-style-type: none"> Check cables from TCU to shift lever. Check signal combinations of shift lever positions F-N-R. | Fault is taken back if TCU detects a valid signal for the position. |
| 12 | <p>Logical error at direction select signal. TCU detected a wrong signal combination for the direction.</p> <ul style="list-style-type: none"> Cable from shift lever to TCU is broken. Cable is defective and is contacted to battery voltage or machine ground. | <p>TCU shifts transmission to neutral.</p> <p>OP-Mode: transmission shut down.</p> | <ul style="list-style-type: none"> Check the cable from TCU to shift lever. Check signal combinations of shift lever positions F-N-R. | Fault is taken back if TCU detects a valid signal for the direction at the shift lever. |
| 13 | <p>Logical error at engine derating device. TCU detected no reaction of engine while derating device active</p> | <p>After selecting neutral, TCU changes to OP-Mode limp home</p> | <ul style="list-style-type: none"> Check engine derating device. | This fault is reset after power up of TCU. |
| 14 | <p>Logical error at parkbrake status. Parkbrake-status-signal measured by TCU and parkbrake-status-signal send by CAN don't fit.</p> <ul style="list-style-type: none"> One of the cables from status-switch to electronic box is broken One of the status-switches is defective. | <p>TCU shifts transmission to DCO-state.</p> <p>OP-Mode: normal</p> | <ul style="list-style-type: none"> Check the cables from electronic boxes to status switches. Check signals of the status switches. | |

| Fault Code (Hex) | Meaning of the Fault Code (Possible Reason for Fault Detection.) | Reaction of the TCU | Possible Steps to Repair | Remarks |
|------------------|---|---|---|---------|
| 95 | <p>S.C. to battery voltage at relay starter interlock.</p> <p>TCU detected a wrong voltage at the output pin, that looks like a s.c. to battery voltage.</p> <ul style="list-style-type: none"> • Cable is defective and is contacted to battery voltage. • Starter interlock relay has an internal defect. • Connector pin is contacted to battery voltage. | <p>No reaction.</p> <p>OP-Mode: normal</p> | <ul style="list-style-type: none"> • Check the cable from TCU to the starter interlock relay. • Check the connectors from starter interlock relay to TCU. • Check the resistance of starter interlock relay. | |
| 96 | <p>O.C. at relay starter interlock.</p> <p>TCU detected a wrong voltage at the output pin, that looks like a O.C. for this output pin.</p> <ul style="list-style-type: none"> • Cable is defective and has no connection to TCU. • Starter interlock relay has an internal defect. • Connector has no connection to TCU. | <p>No reaction.</p> <p>OP-Mode: normal</p> | <ul style="list-style-type: none"> • Check the cable from TCU to the starter interlock relay. • Check the connectors from starter interlock relay to TCU. • check the resistance of starter interlock relay. | |
| 9A | <p>S.C. to ground at converter lock up clutch solenoid.</p> <p>TCU detected a wrong voltage at the output pin, that looks like a S.C. to machine ground.</p> <ul style="list-style-type: none"> • Cable is defective and is contacted to machine ground. • Converter clutch solenoid has an internal defect. • Connector pin is contacted to machine ground. | <p>Converter lock up clutch solenoid connected at ADMX:</p> <p>TCU switch off VPS2</p> <p>Op-Mode: normal.</p> <p>Converter lock up clutch solenoid connected at AIP7:</p> <p>TCU switch off VPS2</p> <p>Op-Mode: normal.</p> | <ul style="list-style-type: none"> • Check cable from TCU to the converter clutch solenoid. • Check the connectors from converter clutch solenoid to TCU. • Check resistance of converter clutch solenoid. | |
| 9B | <p>O.C. at converter lock up clutch solenoid.</p> <p>TCU detected a wrong voltage at the output pin, that looks like a O.C. for this output pin.</p> <ul style="list-style-type: none"> • Cable is defective and has no connection to TCU. • Converter clutch solenoid has an internal defect. • Connector has no connection to TCU. | <p>Converter clutch always open, retarder not available.</p> <p>Op-Mode: normal.</p> | <ul style="list-style-type: none"> • Check cable from TCU to the converter clutch solenoid. • Check the connectors from converter clutch solenoid to TCU. • Check resistance of converter clutch solenoid. | |

| | |
|--|--------|
| Axle Air Breathing | 5-3-17 |
| Special Tools | 5-3-18 |
| List of Special Tools for Disassembly and Reassembly | 5-3-18 |
| Axle Oils | 5-3-25 |
| Oil Grade ZF-Powerfluid..... | 5-3-25 |
| Oil Change Intervals..... | 5-3-25 |
| Load Class | 5-3-25 |
| Removal | 5-3-26 |
| Installation | 5-3-29 |
| Completing Work | 5-3-29 |
| Disassembly and Reassembly..... | 5-3-30 |
| Disassembly Output and Brake..... | 5-3-30 |
| Disassembly Axle Housing..... | 5-3-36 |
| Disassembly Input | 5-3-37 |
| Disassembly Differentials | 5-3-40 |
| Disassembly Multidisk Differential Lock | 5-3-40 |
| Disassembly Differential..... | 5-3-43 |
| Disassembly Multidisk Differential Lock | 5-3-45 |
| Reassembly Differentials..... | 5-3-47 |
| Reassembly Multidisk Differential Lock..... | 5-3-47 |
| Reassembly Differential | 5-3-52 |
| Reassembly Multidisk Differential Lock..... | 5-3-55 |
| Reassembly Input..... | 5-3-59 |
| Determination of Shim Thickness to Obtain a Correct Contact Pattern | 5-3-59 |
| Reassembly of Input Pinion..... | 5-3-60 |
| Determination of Shims for Setting of Bearing Rolling Torque (Differential Housing) and Backlash (Bevel Gear Set)..... | 5-3-63 |
| Reassembly Axle Housing | 5-3-67 |
| Reassembly Output and Brake | 5-3-69 |






CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

| Disassembly | Reassembly | Subject-No. | Designation / Application Special Tools (S) |
|--------------------------------|----------------|------------------------------|--|
| See Figure 28 | | 5870 350 113 | Fixture |
| See Figure 32 | See Figure 187 | 5870 300 019 | Inner extractor (MT-L-3085 II)  FG022230 |
| See Figure 32 | See Figure 187 | 5870 204 073 | Eyebolt (MT-L-3085 II)  FG022231 |
| See Figure 40 | See Figure 187 | 5870 300 017 | Inner extractor  FG021346 |
| See Figure 32 | See Figure 187 | 5870 204 076 | Eye nut  FG021347 |
| See Figure 33 See Figure 45 | | 5873 014 016 5873 014 013 | Rapid grip  FG021348 |

15. Lift the disk package out of the brake housing.



Figure 37

16. Loosen hexagon screws, remove releasing cover and cup spring.



Figure 38

17. Mount breather valve and press piston out of the brake housing using compressed air.



Figure 39

18. If necessary, remove guide ring, backup rings and grooved rings out of the annular grooves of the brake housing (see arrows).

IMPORTANT

For the installation position of the single parts, refer to the following sketch.



Figure 40

- Mount two adjusting screws (S) and insert the housing cover until contact with the differential housing is obtained.

(S) Locating pins 5870 204 040

Preload the differential using the press and bolt with new locking screws.

Tightening torque (M16/12.9) $M_A = 400 \text{ N.m}$



Figure 96

- Install compression spring onto the sliding sleeve.



Figure 97

FG01996E

- Insert the premounted sliding sleeve into the housing cover.

Preload the compression spring using the press and engage the retaining ring into the annular groove of the sliding sleeve.



Figure 98

FG01994C

- Setting of disk package

Premount single parts according to the adjacent sketch.

| Reference Number | Description |
|------------------|------------------------|
| 1 | Housing Cover |
| 2 | Pressure Piece |
| 3 | Cage |
| 4 | Lever (12x) |
| 5 | Disk Carrier |
| 6 | Pressure Ring |
| 7 | Inner Disks |
| 8 | Outer Disks (Optional) |
| 9 | Retaining Ring |




Figure 99

FG019965

1. Insert the determined shim (e.g. $s = 1.0 \text{ mm}$) into the hole of the axle housing and adjust the bearing outer ring (see arrow) until contact is obtained.




Figure 148

2. Cover some drive and coast flanks of the crown wheel with marking ink.

Then insert the premounted differential into the axle drive housing.

(S) Load carrying device 5870 281 083




Figure 149

3. Insert the determined shim (e.g. $s = 1.1 \text{ mm}$) into the hole of the axle housing and adjust the bearing outer ring (Figure 148) until contact is obtained.



Figure 150

4. Mount two locating pins (S) and bring the axle housing into contact position with the axle drive housing using the lifting device.

(S) Locating pins 5870 204 024

Then preliminarily fix the axle housing with 4 hexagon screws.

Tightening torque (M20/10.9) $M_A = 560 \text{ N.m}$



Figure 151

IMPORTANT

Preliminarily mount the axle housing without O-ring.

32. Insert sun gear shaft into the planetary carrier.




Figure 199

33. Insert determined shim(s) e.g. $s = 1.60$ mm with grease into the sun gear shaft.



Figure 200

34. Install O-ring with grease into the countersink of the brake housing.



Figure 201

35. Grease O-ring (see arrow) and install it to the axle housing.



Figure 202

Tightening Torques for Screws

Tightening Torques for Screws (in N.m) According to Standard

0.12 for screws and nuts without subsequent treatment, and for phosphated nuts.

Unless otherwise specified, the tightening torques can be taken from the following chart:

| Metric ISO-Standard Thread DIN 13 | | | | Metric ISO-Fine Thread DIN 13 | | | |
|-----------------------------------|-------|-------|-------|-------------------------------|-------|-------|-------|
| Size | 8.8 | 10.9 | 12.9 | Size | 8.8 | 10.9 | 12.9 |
| M 4 | 2.8 | 4.1 | 4.8 | M 8 x 1 | 24 | 36 | 43 |
| M 5 | 5.5 | 8.1 | 9.5 | M 9 x 1 | 36 | 53 | 62 |
| M 6 | 9.5 | 14 | 16.5 | M 10 x 1 | 52 | 76 | 89 |
| M 7 | 15 | 23 | 28 | M 10 x 1.25 | 49 | 72 | 84 |
| M 8 | 23 | 34 | 40 | M 12 x 1.25 | 87 | 125 | 150 |
| M 10 | 46 | 68 | 79 | M 12 x 1.5 | 83 | 120 | 145 |
| M 12 | 79 | 115 | 135 | M 14 x 1.5 | 135 | 200 | 235 |
| M 14 | 125 | 185 | 215 | M 16 x 1.5 | 205 | 300 | 360 |
| M 16 | 195 | 280 | 330 | M 18 x 1.5 | 310 | 440 | 520 |
| M 18 | 280 | 390 | 460 | M 18 x 2 | 290 | 420 | 490 |
| M 20 | 390 | 560 | 650 | M 20 x 1.5 | 430 | 620 | 720 |
| M 22 | 530 | 750 | 880 | M 22 x 1.5 | 580 | 820 | 960 |
| M 24 | 670 | 960 | 1,100 | M 24 x 1.5 | 760 | 1,100 | 1,250 |
| M 27 | 1,000 | 1,400 | 1,650 | M 24 x 2 | 730 | 1,050 | 1,200 |
| M 30 | 1,350 | 1,900 | 2,250 | M 27 x 1.5 | 1,100 | 1,600 | 1,850 |
| M 33 | 1,850 | 2,600 | 3,000 | M 27 x 2 | 1,050 | 1,500 | 1,800 |
| M 36 | 2,350 | 3,300 | 3,900 | M 30 x 1.5 | 1,550 | 2,200 | 2,550 |
| M 39 | 3,000 | 4,300 | 5,100 | M 30 x 2 | 1,500 | 2,100 | 2,500 |
| | | | | M 33 x 1.5 | 2,050 | 2,900 | 3,400 |
| | | | | M 33 x 2 | 2,000 | 2,800 | 3,300 |
| | | | | M 36 x 1.5 | 2,700 | 3,800 | 4,450 |
| | | | | M 36 x 3 | 2,500 | 3,500 | 4,100 |
| | | | | M 39 x 1.5 | 3,450 | 4,900 | 5,700 |
| | | | | M 39 x 3 | 3,200 | 4,600 | 5,300 |


19. Tie the rear axle with rope to remove it



Figure 20

WL1400561

20. Remove bolts and washers (1, Figure 21) (4 ea) from the axle support.

- Tool: 46 mm ()
- Torque: 1,667 N.m (170 kg.m, 1,229 ft lb)

NOTE: Bind the axle, front support and rear support together after removing their bolts.





Figure 21 Bottom of the Rear Frame

WL1400891

21. Remove bolts and washers (2, Figure 22) (4 ea) from the axle support.

- Tool: 46 mm ()
- Torque: 1,667 N.m (170 kg.m, 1,229 ft lb)

NOTE: Bind the axle, front support and rear support together after removing their bolts.




Figure 22 Bottom of the Rear Frame

WL1400892

22. Move the rear axle slowly and carefully.

- Weight:
 - Axle: about 1,085 kg (2,392 lb) (with Oil)
 - Front support: about 110 kg (243 lb)
 - Rear support: about 210 kg (463 lb)
 - Total: about 1,405 kg (3,097 lb)




Figure 23

WL1400893

Disassembly Differential

1. Pull both tapered roller bearings from the differential.
(S) Grab sleeve 5873 012 016
(S) Basic tool 5873 002 001



Figure 75

2. Preload the differential using the press, loosen the hexagon screws and remove releasing housing cover.



Figure 76

3. Preload the differential using the press, loosen locking screws and housing cover.



Figure 77

4. Remove axle bevel gear with thrust washers from the differential housing.



Figure 78

IMPORTANT

Any deviation from the required installation clearance is to be corrected with corresponding outer disks (s = 2.7, s = 2.9, s = 3.0, s = 3.1, s = 3.2, s = 3.3 or s = 3.5 mm), taking care that difference in thickness between the left and the right disk package must only be 0.1 mm at maximum.

12. Attach the thrust washers into the housing cover using grease.



Figure 132

FG019982

13. Mount two adjusting screws (S) and insert the housing cover until contact with the differential housing is obtained.

(S) Locating pins 5870 204 040

Preload the differential using the press and bolt with new locking screws.

Tightening torque (M16/12.9) $M_A = 400 \text{ Nm}$



Figure 133

FG019982

14. Heat both tapered roller bearings and insert until contact is obtained.



CAUTION

AVOID INJURY

Adjust tapered roller bearing after letting it cool.



Figure 134

FG019982

12. Insert disk and cup spring with the convex side showing upwards into the piston.



Figure 181

13. Insert cover and attach it using hexagon screws.
Tightening torque (M8/10.9) $M_A = 34 \text{ Nm}$



Figure 182

14. Mount outer and inner disks.

IMPORTANT

For the number of disks and the disk arrangement please refer to the relating spare parts list.




Figure 183

15. Insert end plate.



Figure 184


Front Driveshaft



WL1400253

Figure 2


Center Driveshaft



WL1400254

Figure 3

Rear Driveshaft



WL1400255

Figure 4

Theory of Operation

Neutral Operation




Figure 4

WL1300659

With the steering wheel in the neutral position (wheels turned neither right nor left), the spool (2, Figure 4) and sleeve (1) are stationary at the position where the center pin (4) becomes centered in the spool space by the centering springs (3). Oil flow through the load sensing line (LS), port L, port R, and port T are bypassed to the tank line and the oil supply (P) is blocked by the directional spool in the steering unit. Even if an external force is applied to the steering cylinder, the steering unit is protected because the oil path is blocked by the directional spool.

Right Turn

The spool (2, Figure 4) is engaged with the spline of the steering shaft. When the steering wheel is turned to the right, the spool turns. The sleeve (1) is connected to the spool (2) by centering springs (3). When spool turns, the sleeve turns. The sleeve turning angle is about 10° less than the spool turning angle.


This allows the longitudinal slots in the spool to align with the ports in the sleeve. Oil from port P on the steering unit travels through the control spool and is directed to port R which directs the oil to the steering cylinders. The amount of flow metered to port R is controlled by the amount of steering wheel rotation. Excess oil flow through port P that is not metered to port R, is directed by the spool to port T and is then directed through the oil cooler and into the tank.

Left Turn

The spool (2, Figure 4) is engaged with the spline of the steering shaft. When the steering wheel is connected to the spool (2) by centering springs (3). When the spool turns, the sleeve turns. The sleeve turning angle is about 10° less than the spool turning angle. This allows the longitudinal slots in the spool to align with the ports in the sleeve. When the steering wheel is turned to the left, oil from port P on the steering unit is directed through the control spool in the steering unit, out port L and into the steering cylinders. The amount of oil flow metered to port L is controlled by the amount of steering wheel rotation. Excess oil flow through port P that is not metered to port L, is directed by the spool to port T and is then directed through the oil cooler and into the tank.

9. Oil drain method

A. Remove bolts (1, Figure 10) (6 ea) with cover (2) on oil tank, drain hydraulic oil using oil pump.

- Tool: 17 mm ()
- Torque: 63.7 N.m (6.5 kg.m, 47 ft lb)




Figure 10

WL1400203

B. Drain hydraulic fluid using drain plug (unscrew). (without oil pump) (Figure 11)

- Hydraulic oil tank volume:
 - (Full): 173 L
- Center of level gauge: 117 L




Figure 11

WL1400204

C. Plug the filter cap to location of suction filter. (Figure 12)

| Item | Part Number |
|------------|-------------|
| Filter Cap | 2188-1008 |




Figure 12

WL1400210

| Reference Number | Description |
|------------------|----------------|
| 1 | Suction Filter |
| 2 | Nut |
| 3 | Rod |

When installing. (Figure 13)

- Torque (2 nut): 88.2 N.m (9 kg.m, 65.1 ft lb)




Figure 13

WL1400200

Port and Hydraulic Circuit





Figure 1

WL1400286

Port Size


| Port | Size |
|------------|--------------------|
| HP, EF | 1 in SAE Flange |
| CL, CR, HT | 3/4 in SAE Flange |
| HT | PF 3/4 O-ring Boss |
| P, T, L, R | PF 1/2 O-ring Boss |
| LS | PF 1/4 O-ring Boss |



WL1400287

Figure 2

25. Remove LS orifice.

- Tool: 4 mm ()





Figure 37

26. Remove orifice.

- Tool: 4 mm ()




Figure 38

Body and Cover Parts

27. This is the completely disassembled cover part.




Figure 39

24. Insert the pin.




Figure 93

25. Place the stop ring in the groove.


NOTE: Do not place the end of the stop ring in the hole.



Figure 94

Direction Valve Part

26. Tighten the orifice to clamp it. (Right and left, 2 places)

- Tool: 4 mm (), \varnothing 2.3 (mandrel)
- Torque: 4.9 N.m (0.5 kg.m, 3.6 ft lb)




Figure 95





Figure 96

Hydraulic Circuit



WL1300515

Figure 2

| Reference Number | Description | Pressure Setting |
|------------------|------------------------------|--|
| C1, C2 | Check Valve | |
| R1 | Relief Valve | 214 ±2 kg/cm ² (210 ±2 bar) |
| R2 | Pilot Reducing Valve | 31 +2 kg/cm ² (30 +2 bar) |
| S1 | Brake Charge Solenoid Valve | |
| S2 | Pilot Cut-off Solenoid Valve | |
| FP | from Fan Pump | |
| G | Brake Charging Sensor | |
| MSP | to Charging Block | |
| P1 | to Pilot Control | |
| FM | to Fan Motor | |
| ACC | Accumulator for Pilot | |
| TP | Pressure Check | |

Functions

- Brake charging for service and parking brake (Charged pressure range, 100 - 160 bar)
- Supply pilot pressure, 30 +2 bar
- Variable fan speed control according to temp. of coolant and transmission oil
- Reverse fan (Auto, Manual)


When the pressure of brake charging line (after C2) goes down under 100 bar,

- S1 solenoid valve activates
- The fan pump makes max flow and pressure.

Then the pressure reaches up to 160 bar, brake charging finishes.

Brake charging function by main pump during working and 2 accumulators are added.

2. Release the parking brake by application of the required release pressure (min. 130 bar).
3. Rotate the screw cap in a counterclockwise direction and unscrew it.
4. Release the locknut (1, Figure 6) of the setting screw (2, Figure 6).
5. Rotate the setting screw (2, Figure 6) in an counterclockwise direction until pressure bolt (3, Figure 6) can be pushed completely into the piston (4, Figure 6).
6. Unscrew (lever) the pressure bolt (3, Figure 6) with a suitable screwdriver until it contacts the piston (4, Figure 6).



FG023260

Figure 7

| Reference Number | Description |
|------------------|-----------------|
| 1 | Counter Nut 1 |
| 2 | Adjusting Screw |
| 3 | Lining Pad |

| Reference Number | Description |
|------------------|---------------|
| 4 | Lining Pad |
| 5 | Lining Spring |

7. Release the counter nut (1, Figure 7) and unscrew the setting screw (2, Figure 7) from the brake housing.

IMPORTANT

The lining spring (5, Figure 7) is pre-tensioned. The lining spring (5, Figure 7) must be held in position with a suitable tool while removing the setting screw (2, Figure 7).


8. Remove lining spring (5, Figure 7).

Table of Contents

Cooling System

| | |
|--|-------|
| Safety Instructions | 8-1-5 |
| General Description | 8-1-5 |
| Function..... | 8-1-6 |
| Hydraulic Circuit | 8-1-7 |
| Fan Motor Pressure and Fan Speed | 8-1-8 |
| Checking Maximum Fan Speed | 8-1-9 |


5. Assembly shaft seal.



WL1300561

Figure 40


6. Install in bearing shells and spring.
Insert with grease.



WL1300562

Figure 41

7. Assemble swash plate (5, Figure 42) and piston rod (4, Figure 43) into pump.
Spring guide pin in correct position.
Check correct position of the spring.



WL1300563

Figure 42

MEMO

Main Pump

Edition 1


- Turn starter switch to "I" (ON) position.

! WARNING

AVOID DEATH OR SERIOUS INJURY

If engine must be running while performing maintenance, always use extreme caution. Always have one person in the cabin at all times. Never leave the cabin with engine running.

- Fully stroke work levers (joysticks) in all directions to relieve any pressure in piping.
- Turn key to "O" (OFF) position and remove from starter switch.
- Turn battery disconnect switch to "OFF" position. (Figure 10)



FG018156

Figure 9




Figure 10 Rear Frame

WL1400202

! WARNING

AVOID DEATH OR SERIOUS INJURY

Release any pressure in the hydraulic oil tank before doing any work.

- Loosen the oil tank air breather slowly to release the pressure inside the hydraulic oil tank.

Pulling the breather cap upward, the check valve 0.46 kg/cm² (0.45 bar) opens, and the air is discharged to the atmosphere from the top of the hydraulic oil tank.



Figure 11

WL1400201

Table of Contents

Main Control Valve

| | |
|-----------------------------|--------|
| Safety Instructions | 9-2-5 |
| General Description | 9-2-5 |
| Specification | 9-2-6 |
| Overview | 9-2-7 |
| Hydraulic Circuit | 9-2-8 |
| Parts List | 9-2-9 |
| Theory of Operation | 9-2-11 |
| Section View | 9-2-19 |
| Removal | 9-2-20 |
| Installation | 9-2-25 |
| Completing Work | 9-2-25 |
| Disassembly/Reassembly..... | 9-2-26 |

3. Main relief valve

The main relief valve is installed on the inlet section of the control valve and it is designed to set the maximum operating pressure of the system.

When abnormal pressure is built in the system so the oil pressure rises up to the setting pressure, this relief valve opens to send oil to the tank. When the pressure drops below the setting level, it closes to maintain the circuit pressure below the setting pressure to protect the circuit.

- Setting pressure: 280 bar




Figure 12

WL1400376

4. Port relief valve

It is installed in parallel with the control valve actuator line. When abnormally high-pressure is built in the actuator because of irregular external load, it is used to send oil to the tank line to keep the pressure in the actuator below the setting pressure to protect the circuit.

It is installed to the boom head, bucket head and rod line. In case of 3 spool, it is also installed to the auxiliary head and rod.

- Setting pressure (Boom head): 310 bar
- Setting pressure (Bucket head, rod): 280 bar
- Setting pressure (Aux head, rod): 280 bar




Figure 13

WL1400376

5. Anticavitation valve

During the boom down operation, the check valve supplies oil to the boom cylinder rod to compensate for insufficient oil flow because of the boom's sudden drop to prevent cavitation (makeup function).





Figure 14

WL1400377

Outlet Section



WL1400386

Figure 34

| Reference Number | Description | Torque | | |
|------------------|-------------------------|-------------|------------|---------|
| | | N.m | kg.m | ft lb |
| 1 | Housing | | | |
| 110 | Load Sense Relief Valve | 44.7 ±4.7 | 4.56 ±0.48 | 33 ±3.5 |
| 110A | O-ring | | | |
| 114 | Plug | 100.3 ±10.8 | 10.2 ±1.1 | 74 ±8 |

BUCKET CROWD OPERATION




Figure 9

WL1400314

The oil in the hydraulic tank (15) is supplied to the main pump (1) and the pilot pump (3) by the suction filter.

The oil supplied to the fan pump (3) flows to the brake pilot supply valve (6) by the brake pilot filter (11), and is supplied to the joystick valve (12).

The joystick valve (12) supplies oil to move the spool on the bucket crowd side of the main control valve (9), and the oil supplied from the main pump (1) is supplied to the bucket cylinder (18) head by the check valve.

When the oil flow to the bucket cylinder (18) is cut off, the bucket spool of the control valve is in neutral, and the oil paths are closed to stop the movement of the bucket.

When the micromotion of the bucket spool of the main control valve (9) causes a small motion, a pressure difference occurs between the main pump (1) outlet oil and actuator inlet oil, and under these circumstances, the flow control valve (102) controls the oil flow of the main pump (1) according to the load signal drain valve (901).

Does Not Work the Boom Floating




Table of Contents


Cabin

| | |
|--|---------|
| Safety Instructions | 10-2-5 |
| Cabin Identification | 10-2-5 |
| Roll-over Protective Structure (ROPS)/Falling Object Protective Structure (FOPS)..... | 10-2-5 |
| Dimensions of Cabin Glass | 10-2-7 |
| Removal and Installation of Cabin Glass.... | 10-2-12 |
| Removal of Cabin Glass..... | 10-2-12 |
| Installation of Cabin Glass..... | 10-2-14 |

Fuel Tank

Edition 1

Lift Cylinder



WL1400268

Figure 2

- Remove bolts (27) on the end of cylinder.

NOTE: *Wrap a cloth or other protective material around piston rod, to avoid possibility of accidentally scratching or scoring rod surface while fasteners are being loosened and removed. Component parts (numbered in parentheses) are keyed to Figure 3.*




Figure 18

0335

- Tap two bolts into cover of cylinder head, 180° apart. Tighten them in a staggered, even sequence, to back off piston rod end cover from edge of cylinder wall. Look for adequate clearance between cover and end of cylinder wall before using a plastic or other soft faced hammer for final disassembly.




Figure 19

HAOF610S

- Begin withdrawing piston rod assembly, away from cylinder. Attach a lifting support when final 1/3 of rod is still inside barrel of cylinder. Prepare support blocks for piston rod before it has been completely withdrawn.




Figure 20

0337

- Lower piston rod to support blocks and detach wear ring (outer surface) (19) from end of rod.





Figure 21

HAOF620S

| | |
|--|-----------------|
| Emergency Steering System Electrical Circuit | 11-1-36 |
| Lighting System | 11-1-38 |
| Light Circuit | 11-1-38 |
| Monitoring System | 11-1-42 |
| Instrument Panel | 11-1-43 |
| Function Check | 11-1-43 |
| Monitoring System Schematic..... | 11-1-44 |
| Operation | 11-1-46 |
| Instruments Gauge | 11-1-46 |
| Indicator Lights | 11-1-46 |
| Initial Operation | 11-1-48 |
| Multifunction Display | 11-1-49 |
| Indication of Warning Lights | 11-1-52 |
| Indication of Indicator Lights..... | 11-1-54 |
| Graphic Information Area Display..... | 11-1-56 |
| Overview | 11-1-56 |
| Main Menus for the Graphic Display Area..... | 11-1-56 |
| Menu Selector Buttons | 11-1-56 |
| User Menu | 11-1-57 |
| Service Menu | 11-1-71 |
| Information of Machine Operation | 11-1-81 |
| Failure Code | 11-1-88 |
| Failure Code at Machine | 11-1-88 |
| Failure Code at Engine Side | 11-1-92 |
| Failure Code at Transmission Side | 11-1-107 |
| Failure Code at Electric Steering Side | 11-1-111 |
| FMIs (Failure Mode Identifier) | 11-1-113 |
| Windshield Wiper..... | 11-1-114 |
| Front Windshield Wiper | 11-1-114 |
| Rear Windshield Wiper..... | 11-1-116 |

Electric MCV Control




WL1400397

Figure 14

| Reference Number | Description |
|------------------|--------------------------|
| 1 | Battery |
| 2 | Battery Relay |
| 4 | Circuit Breaker |
| 6 | Fuse Box |
| 13 | Vehicle Controller |
| 21 | Accelerator Pedal |
| 22 | Angle sensor (Boom) |
| 23 | Angle sensor (Bucket) |
| 24 | Electric Joystick (Boom) |

| Reference Number | Description |
|------------------|-------------------------------|
| 25 | Electric Joystick (Bucket) |
| 26 | Electric Joystick (Option) |
| 27 | Proportional Valve (Raise) |
| 28 | Proportional Valve (Float) |
| 29 | Proportional Valve (Crowd) |
| 30 | Proportional Valve (Dump) |
| 31 | Proportional Valve (Option 1) |
| 32 | Proportional Valve (Option 2) |

Emergency Steering Timer Circuit



WL1300777

Figure 33






| Reference Number | Description |
|------------------|-------------------------------|
| 1 | Emergency Steering Timer |
| 2 | Emergency Steering Indicator |
| 3 | Transmission Controller (TCU) |
| 4 | Emergency Steering Pump |
| 5 | Starter Switch "ON" |

| Reference Number | Description |
|------------------|------------------------------------|
| 6 | Starter Switch "START" |
| 7 | Main Steering Pressure Switch |
| 8 | Emergency Steering Pressure Switch |
| 9 | Emergency Steering Switch |

Test Mode before Emergency Steering Start

| Input Condition | | | Output | |
|-----------------|-----|-----|--|---|
| S0 | S3 | S4 | Emergency Steering Pump | Light |
| OFF → ON | OFF | OFF | Will be operated only one time for 3 seconds and stop. | Will be turned "ON" only Once for 3 seconds. Will be turned off when S2 is "ON". Will be blinking regularly when S2 is "OFF". |
| OFF → ON | ON | OFF | OFF | Turned off |
| OFF → ON | - | ON | Pump will be operated equally with S4 "ON" time. | Light will be turned "ON" equally with S4 "ON" time. |

Multifunction Display

| Function | Display | Sensor Specification | |
|------------------------------------|---|---------------------------------------|--|
| | | Input Terminal | Input Specification |
| Fuel Level Gauge |  | (Output Terminal) CN3-13 CN3-14 | Full → 0.6 ±5% kΩ 3/4 → 1.2 ±5% kΩ 1/2 → 2.19 ±5% kΩ 1/4 → 3.9 ±5% kΩ 1/5 → 4.42 ±5% kΩ → Red Zone Empty → 4.8 kΩ |
| Coolant Temperature |  | ECU-CAN Communication | 40°C → Min. 103°C → Red Zone 110°C → Max. |
| Transmission Oil Temperature Gauge |  | TCU-CAN Communication | 50°C → Min. 120°C → Red Zone 150°C → Max. |
| DEF (AdBlue®) Level Gauge |  | ECU-CAN Communication | 5% → Min. 20% → Red Zone 96% → Max. |
| Transmission Gear |  | TCU-CAN Communication | N = Neutral PN = Parking Brake 1F-5F = Forward 1st - 5th Gear 1R-3R = Reverse 1st - 3rd Gear |

3. GP Configuration

This menu is used to set up; password, brightness, default screen and time, and to input service phone number. Press UP (▲) or DOWN (▼) button and move cursor to see a reversed display on desired menu. Then, press SELECTION (↵) button to select menu.

Password Setting ↔ Screen Brightness Setting ↔ Default Screen Setting ↔ Time Setting ↔ Service Phone Number Setting ↔ Unit Setting ↔ Language Setting ↔ Notification Setting

Press ESC button to return to previous screen.

A. Password Setting

On "GP Setup" screen, when cursor is placed on "Password Setting", press SELECTION (↵) button to display screen brightness setting.

This function is used to set up a user password.

If password setting function is used, password must be correctly input to operate vehicle normally.

On "Password Setting" screen, when cursor is placed on password setting, press SELECTION (↵) button to display password input screen that was set up at factory. The initial password is set to "1111".

If you have changed the password, you should input the new password you have chosen.

IMPORTANT

If password input errors have been made three (3) times in a row, screen will move to default screen. After that, starting will be locked for 10 minutes.

How to Input Password:

- Press UP (▲) or DOWN (▼) button and select numbers of 0 - 9 at bottom. Then, press SELECTION (↵) button and input a password.
- If you erroneously input a password, select (←) key at right bottom and press SELECTION (↵) button to delete input password.
- On Password Setting screen, input a password to display a screen to select application of




Figure 65

FG021925




Figure 66

WL1300781




Figure 67

FG019188




Figure 68

FG019189


User Selection Data View

| User Data | | User Data | |
|------------------|------------------------|------------------|---------------------------------|
| 1. | Alternator | 25. | EMCV P/V Option 1 |
| 2. | Battery | 26. | EMCV P/V Option 2 |
| 3. | Fan Control P/V | 27. | E/G Speed |
| 4. | Main Pressure | 28. | Per. Load Cur. Speed |
| 5. | Steer Pressure | 29. | Intake Manifold Temp. |
| 6. | Brake Oil Pressure | 30. | Fuel Rate |
| 7. | Fan Motor Pressure | 31. | Total Used Fuel |
| 8. | Boom Cylinder Pressure | 32. | Coolant Temp. |
| 9. | Accel Pedal | 33. | E/G Oil Pressure |
| 10. | TMS Voltage Input | 34. | Boost Pressure |
| 11. | Angle Sensor Boom | 35. | DEF (AdBlue®) Level |
| 12. | Angle Sensor Bucket | 36. | Torque Converter Oil Temp. |
| 13. | Fuel Level Sensor | 37. | Sump Oil Temp. |
| 14. | Water In Fuel | 38. | Differential Lock Auto S/W |
| 15. | Hydraulic Temp. | 39. | Differential Lock Manual S/W |
| 16. | Elec. Steering Lever | 40. | Clutch CutOff S/W |
| 17. | Estimated Flow | 41. | Parking Brake S/W |
| 18. | EMCV Lever Boom | 42. | LIS S/W |
| 19. | EMCV Lever Bucket | 43. | FNR 2nd Gear Engaged |
| 20. | EMCV Lever Option | 44. | Differential Lock Engaged |
| 21. | EMCV P/V Raise | 45. | Torque Converter LockUp Engaged |
| 22. | EMCV P/V Float | 46. | BackUp Relay |
| 23. | EMCV P/V Crowd | 47. | LIS Relay |
| 24. | EMCV P/V Dump | | |

| GP Display Code | DTC Code | | FMI | GP Display Description | Severity | Light Status | Remarks |
|-----------------|----------|-----|-----|---|----------|--------------|---------|
| | HEX | DEC | | | | | |
| E000110-10 | 110 | 6E | 10 | Engine Coolant temperature (T33) is not plausible. | 3 | Yellow | |
| E000110-16 | 110 | 6E | 16 | Engine Coolant Water Temperature Too High. | 0 | None | |
| E000110-17 | 110 | 6E | 17 | Engine temp sensor1 (T_ENG1), temp below normal or VGT-temp above normal. | 3 | Yellow | |
| E000110-18 | 110 | 6E | 18 | Engine temp sensor1 (T_ENG1), temp above normal or VGT-temp below normal. | 3 | Yellow | |
| E000110-20 | 110 | 6E | 20 | Engine Coolant Water Temperature Too High. No Action. | 3 | Yellow | |
| E000110-21 | 110 | 6E | 21 | Coolant Temperature Below Thermostat Regulating Temperature | 0 | None | |
| E000111-01 | 111 | 6F | 1 | Engine coolant level too low. No action. | 3 | Yellow | |
| E000111-03 | 111 | 6F | 3 | Scania engines coolant level sensor, short circuit to battery | 0 | None | |
| E000111-04 | 111 | 6F | 4 | Engine Coolant Level Sensor/Switch Circuit Low, Short Circuit to Ground | 3 | Yellow | |
| E000131-02 | 131 | 83 | 2 | Exhaust pressure (T125) not plausible | 0 | None | |
| E000131-03 | 131 | 83 | 3 | Exhaust press sensor, short circuit to +24V | 3 | Yellow | |
| E000131-04 | 131 | 83 | 4 | Exhaust pressure sensor, short circuit to ground or open load | 3 | Yellow | |
| E000131-07 | 131 | 83 | 7 | Correlation error, EXP higher than MAP | 0 | None | |
| E000131-08 | 131 | 83 | 8 | Correlation error, EXP higher than Intercooler pressure | 0 | None | |
| E000131-09 | 131 | 83 | 9 | Exhaust pressure sensor Stuck. | 3 | Yellow | |
| E000131-10 | 131 | 83 | 10 | Correlation error, EXP higher than AAP | 0 | None | |
| E000131-15 | 131 | 83 | 15 | Exhaust pressure, high exhaust pressure during normal fueling | 3 | Yellow | |
| E000131-16 | 131 | 83 | 16 | Exhaust pressure, high exhaust pressure during motoring, no fueling | 3 | Yellow | |
| E000131-18 | 131 | 83 | 18 | Exhaust pressure, low exhaust pressure during exhaust brake | 0 | None | |
| E000131-20 | 131 | 83 | 20 | Plausibility error. EXP too high | 3 | Yellow | |
| E000131-21 | 131 | 83 | 21 | Plausibility error, EXP too low | 3 | Yellow | |
| E000132-00 | 132 | 84 | 0 | Mass flow sensor (DM_EGR), short circuit to +24V | 3 | Yellow | |
| E000132-01 | 132 | 84 | 1 | Mass flow sensor (DM_EGR), short circuit to ground or open load | 3 | Yellow | |
| E000132-02 | 132 | 84 | 2 | Mass flow sensor (DM_EGR), faulty | 3 | Yellow | |
| E000132-03 | 132 | 84 | 3 | Mass flow sensor (DM_EGR), supply | 3 | Yellow | |
| E000132-04 | 132 | 84 | 4 | Mass Flow Sensor Adaptation Under Low Threshold | 3 | Yellow | |
| E000132-05 | 132 | 84 | 5 | Mass Flow Sensor Adaptation Over High Threshold. | 3 | Yellow | |
| E000132-07 | 132 | 84 | 7 | Mass flow sensor (DM_EGR), stuck | 3 | Yellow | |
| E000156-00 | 156 | 9C | 0 | Fuel Rail pressure is excessively above command | 3 | Yellow | |
| E000156-01 | 156 | 9C | 1 | Fuel Rail pressure is excessively below command with engine on | 3 | Yellow | |
| E000156-02 | 156 | 9C | 2 | Fuel Rail press sensor (P_RAIL), faulty | 3 | Yellow | |
| E000156-03 | 156 | 9C | 3 | Fuel Rail press sensor (P_RAIL), short circuit to +24V or open load | 3 | Yellow | |
| E000156-04 | 156 | 9C | 4 | Fuel Rail press sensor (P_RAIL), short circuit to ground | 3 | Yellow | |
| E000156-08 | 156 | 9C | 8 | Fuel Rail press sensor (P_RAIL), stuck | 3 | Yellow | |
| E000156-09 | 156 | 9C | 9 | Fuel rail pressure is lagging. | 0 | None | |
| E000156-18 | 156 | 9C | 18 | Fuel Rail pressure is too low during cranking | 3 | Yellow | |
| E000167-02 | 167 | A7 | 2 | Alternator actuator (altU15Act), faulty | 3 | Yellow | |

| GP Display Code | FMI | DTC Code | | Failure Code (Hex) | Description |
|-----------------|-----|-----------|-----------|--------------------|--|
| | | SPN (Dec) | SPN (Hex) | | |
| T005560 | 5 | 5560 | 15B8 | 93 | O.C. at relay reverse warning alarm: Current below normal |
| T005570 | 4 | 5570 | 15C2 | 94 | S.C. to ground at relay starter interlock |
| T005570 | 3 | 5570 | 15C2 | 95 | S.C. to battery voltage at relay starter interlock |
| T005570 | 5 | 5570 | 15C2 | 96 | O.C. at relay starter interlock |
| T005590 | 4 | 5590 | 15D6 | 9A | S.C. to ground at converter lock up clutch solenoid: Voltage below normal |
| T005590 | 3 | 5590 | 15D6 | 9B | O.C. at converter lock up clutch solenoid: Voltage above normal |
| T005590 | 5 | 5590 | 15D6 | 9C | S.C. to battery voltage at converter lock up clutch solenoid: Current below normal |
| T005620 | 4 | 5620 | 15F4 | A4 | S.C. to ground at warning signal output |
| T005620 | 5 | 5620 | 15F4 | A5 | O.C. at warning signal output: Voltage above normal |
| T005620 | 3 | 5620 | 15F4 | A6 | S.C. to battery voltage at warning signal output: Voltage above normal |
| T005630 | 4 | 5630 | 15FE | A7 | S.C. to ground at LIS output: Voltage below normal |
| T005630 | 3 | 5630 | 15FE | A8 | S.C. to battery voltage at LIS output: Voltage above normal |
| T005630 | 5 | 5630 | 15FE | A9 | O.C. at LIS output: Current below normal |
| T005660 | 2 | 5660 | 161C | B1 | Slippage at clutch K1: Incorrect signal |
| T005665 | 2 | 5665 | 1621 | B2 | Slippage at clutch K2: Incorrect signal |
| T005670 | 2 | 5670 | 1626 | B3 | Slippage at clutch K3: Incorrect signal |
| T005675 | 2 | 5675 | 162B | B4 | Slippage at clutch K4: Incorrect signal |
| T005680 | 2 | 5680 | 1630 | B5 | Slippage at clutch KV: Incorrect signal |
| T005685 | 2 | 5685 | 1635 | B6 | Slippage at clutch KR: Incorrect signal |
| T005700 | 0 | 5700 | 1644 | B7 | Overtemp sump: Above normal range |
| T005730 | 0 | 5730 | 1662 | BA | Differential pressure oil filter: Above normal range |
| T005740 | 2 | 5740 | 166C | BB | Slippage at converter lockup clutch: Incorrect signal |
| T005745 | 15 | 5745 | 1671 | BC | Overspeed output: DATA VALID BUT BELOW NORMAL OPERATIONAL RANGE - LEAST SEVERE LEVEL |
| T005751 | 0 | 5751 | 1677 | C0 | Engine torque or engine power: Above normal range |
| T005752 | 0 | 5752 | 1678 | C1 | Transmission output torque overload: Above normal range |
| T005755 | 15 | 5755 | 167B | C2 | Transmission input torque overload: DATA VALID BUT BELOW NORMAL OPERATIONAL RANGE - LEAST SEVERE LEVEL |
| T005760 | 0 | 5760 | 1680 | C3 | Overtemp converter output |
| T005770 | 4 | 5770 | 168A | C4 | S.C. to ground at joystick status indicator: Voltage below normal |
| T005770 | 3 | 5770 | 168A | C5 | S.C. to battery voltage at joystick status indicator: Voltage below normal |
| T005770 | 5 | 5770 | 168A | C6 | O.C. at joystick status indicator: Voltage below normal |
| T005780 | 4 | 5780 | 1694 | C7 | S.C. to ground at overtemp neutral indicator: Voltage below normal |
| T005780 | 3 | 5780 | 1694 | C8 | S.C. to battery voltage at overtemp neutral indicator: Voltage above normal |
| T005780 | 5 | 5780 | 1694 | C9 | O.C. at overtemp neutral indicator: Current below normal |
| T005810 | 3 | 5810 | 16B2 | D1 | S.C. to battery voltage at power supply for sensors: Voltage above normal |
| T005810 | 4 | 5810 | 16B2 | D2 | S.C. to ground at power supply for sensors: Voltage below normal |
| T005820 | 4 | 5820 | 16BC | D3 | Low voltage at battery: Voltage below normal |
| T005820 | 3 | 5820 | 16BC | D4 | High voltage at battery: Voltage above normal |

Air-conditioning System Layout



WL1400404

Figure 5

| Reference Number | Description |
|------------------|-----------------------------|
| 1 | Air Conditioner/heater Unit |
| 2 | Condenser |
| 3 | Compressor |
| 4 | Receiver Dryer |
| 5 | Discharge Hose |
| 6 | Suction Hose |

| Reference Number | Description |
|------------------|----------------------------|
| 7 | Liquid Hose (1) |
| 8 | Liquid Hose (2) |
| 9 | Ambient Temperature Sensor |
| 10 | Sun Sensor |
| 11 | Control Panel |

Compressor

| Categories | Specifications |
|---------------|--|
| Output | 155.3 cc/rev |
| Oil Level | 120 cc (ND-OIL8) |
| Refrigerant | R134a |
| Rated Voltage | 24V |
| Relief Valve | Open: 35 - 42.2 kg/cm ² G Close: 28.1 kg/cm ² G |

Compressor sucks in refrigerant which evaporates completely in the evaporator and discharges it to the condenser.

Refrigerant undergoes repeated status change in the order of liquid, gas, and liquid in the freezing cycle, and the compressor makes evaporated refrigerant a high temperature and high-pressured gas to freeze it in the condenser.




Figure 22

Receiver Dryer

The receiver dryer reserves refrigerant enough to ensure smooth freezing cycle responding immediately to the change of level in the freezing cycle.

As liquid refrigerant from the condenser may contain refrigerant gas with bubbles whose presence in the expansion valve decreases the freezing power excessively, it separates liquid and gas and sends liquid only to the expansion valve.

Water in refrigerant shall be eliminated with dryer and through filter.

- Weight of refrigerant: 800 ±20 grams




Figure 23




Figure 24

FG001462

MEMO

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL