



135ZV-2

SHOP MANUAL

Disassembly & Reassembly
Service Standard

93217-00140



93217-00140
October 2008

SHOP MANUAL

WHEEL LOADER

135ZV-2

***Disassembly & Reassembly
Service Standard***

Powered by CUMMINS QST30-C ENGINE

Serial No. 13C1-9301~

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.


CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

| | |
|---|-------|
| 135ZV-2 Disassembly & Reassembly Brake Group | 54-1 |
| Brake Valve | 54-2 |
| Brake valve removing and installing | 54-2 |
| Brake valve disassembling and assembling | 54-4 |
| Unloader Valve | 54-10 |
| Unloader valve removing and installing | 54-10 |
| Unloader valve disassembling and assembling | 54-12 |
| Manifold Valve Assembly | 54-14 |
| Valve assembly removing and installing | 54-14 |
| Valve assembly disassembling and assembling | 54-16 |
| Accumulator | 54-17 |
| Accumulator removing and installing | 54-17 |
| Accumulator disassembling and assembling | 54-19 |
| Nitrogen gas charging | 54-25 |
| Service Brake | 54-27 |
| Service brake disassembling and assembling | 54-27 |
| Parking Brake | 54-31 |
| Parking brake removing and installing | 54-31 |
| Parking brake disassembling and assembling | 54-32 |
| | |
| 135ZV-2 Service Standard Brake Group | 55-1 |
| Brake Valve | 55-2 |
| Service Brake | 55-4 |
| Parking Brake | 55-5 |
| | |
| 135ZV-2 Disassembly & Reassembly Operator Station Group | 74-1 |
| Air Conditioner | 74-2 |
| Air conditioner removing and installing | 74-2 |
| Air conditioner disassembling and assembling | 74-4 |
| | |
| 135ZV-2 Service Standard Operator Station Group | 75-1 |
| Air Conditioner | 75-2 |
| Air conditioner periodical inspection/servicing | 75-2 |
| Air conditioner tightening torque | 75-2 |

Screw lock agent application procedure


Through-hole

Apply screw lock agent one or two lines on the male threads.



65ZV00002

How to wind a seal tape



65ZV00004

To avoid a piece of seal tape left in the circuit, leave 1 or 2 screws from the end of the thread and start threading it clockwise.

Hydraulic Tank

Hydraulic tank removing and installing

Hydraulic tank removing


⚠ WARNING

Unexpected movement of the machine could cause an accident resulting in injury or death. Be sure to observe the following items before starting hydraulic tank removal:

- Position the machine on level ground, and apply the parking brake.
- Lower the attachment onto the ground, and block the tires with chocks, etc. to prevent them from moving.
- Remove the engine key, and hang a "DO NOT START ENGINE!" tag on the operation board.

Before starting work:


- Drain hydraulic oil from the hydraulic tank. (Hydraulic tank capacity: 320 L (85 gal))
- Remove the left side deck.
- Clean the area around the tank.
- Put matching marks on the hoses connected to the hydraulic main tank.
- When removing the sub tank, remove the engine room by referring to "Engine Room".



1. Remove drain hose (1) from hydraulic main tank (2).

Note


Cover the disconnected hose with vinyl to protect it from dust and dirt.



2. Remove hose bands and remove return hoses (3)(4) from the hydraulic main tank.

Note

Cover or plug the disconnected hoses to protect them from dust, and dirt.




3. Remove hose bands and remove suction hose (5) from the hydraulic main tank.

Note

Cover the disconnected hoses with vinyl to protect them from dust and dirt.


14-16
 135ZV-2 Disassembly & Reassembly Chassis Group
 Floor Board



3. Disconnect hoses (3)(4) from air conditioner unit (5).

Note


Cover the disconnected hoses and pipes with vinyl to protect them from dust and dirt.



5. Remove hydraulic line hose (13) at plate C located on the front chassis.
 Remove hydraulic line hose (14) at plate D.

Note


Cover the disconnected hoses with vinyl to protect them from dust and dirt.



4. Remove brake line pipes and hoses (6)~(10) from the brake valve at plate A or B of the floor board.
 Disconnect hoses (11)(12) from the pilot valves also at plate A.

Note

Cover the disconnected pipes and hoses with vinyl to protect them from dust and dirt.




6. Remove hydraulic line hoses (15)(16) at the pilot valve (for steering).
 Remove hydraulic line hose (17) at the stop valves.
 Remove hydraulic line hose (18) at plate D.


Note


Cover the disconnected hoses with vinyl to protect them from dust and dirt.

14-26
 135ZV-2 Disassembly & Reassembly Chassis Group
 Center Pin



13. Remove ring (18) and remove bolts (19) from bearing cover (20).

 Bolt (19): 721 N-m (73.5 kgf-m) (532 lb-ft)



Note

When reinstalling bearing cover (20), be careful with the installation direction.


14. Remove shim (14).

Note

If the taper roller bearing is replaced, be sure to adjust the clearance using shims.

Thickness of shim (mm): 0.1, 0.2, 0.3, 0.5, and 1.0
 Refer to Section 15.


15. Replace the dust seals in the upper center pin and the lower center pin with new ones.




Note

Take care of the correct direction of dust seals as shown above.

Attachment Leveler




K135V2U15006



K135V2U15007


24-8
135ZV-2 Disassembly & Reassembly Power Group
Torque Converter Oil Cooler





Torque converter oil cooler installing

To reinstall the torque converter oil cooler, follow the above removal procedure in reverse order.

3. Temporarily sling torque converter oil cooler (6). Remove bolt (5), and then, remove torque converter oil cooler (6) with bracket (7).

 : Bolt (5): 94 N-m (9.6 kgf-m) (69 lb-ft)

 : T/C oil cooler (with bracket):
150 kg (330 lbs)



3. Remove the hose bands and remove rubber hose (9).

Note

Cover the disconnected hoses and pipes with caps, plugs, or vinyl to protect them from dust and dirt.

4. Disconnect pressure sensor (10).
 5. While supporting air cleaner case (11) with your hand, remove bolts (12), and then, lower the air cleaner case.
- Take out air cleaner case (11) from the opening.

Note



- This work should be done by two or more persons.
- Cover the open pipes with caps, plugs or vinyl.

Air cleaner installing

For reinstallation, follow the above procedure in reverse order.



Air cleaner installation cautions

- Be sure the inside of air cleaner case (11) are wiped clean before reinstallation.




- If the bands of the air duct are not properly positioned or tightened, the duct will draw in dust that will cause an engine problem. Carefully reinstall the air duct (One band is to be fixed on the beading, and the other one should be half-turned. See the figures.)

24-28
 135ZV-2 Disassembly & Reassembly Power Group
 Front Axle Assembly




12. Sling internal gear hub assembly (14) using internal gear hub hoisting tool (C), and remove internal gear hub assembly (14).

14. Remove floating seal (15).

 : Internal gear hub assy: 275 kg (605 lbs)


Note
 Disassemble the other wheels in the same manner. Refer to Section 54 for further procedures to disassemble the service brake.




13. Sling wheel hub (3) using wheel hub hoisting tools (D) and remove the turn buckle. Then remove wheel hub (3).

Front axle assembling


To reassemble the front axle, follow the above procedure in reverse order.

 : Wheel hub: 440 kg (970 lbs)

24-48
 135ZV-2 Disassembly & Reassembly Power Group
 Differential Assembly




3. Pull out right and left axle shafts (5) by 350 mm (14 in).





Note


14 spacers are inserted at bolt (6) in the front differential, and 12 spacers in the rear differential.

Front differential: At positions "*"
 Rear differential: At positions "#"





4. Remove bolt (6) from differential (7).

-  : Bolt (6)
 (Front): 608 N-m (62.0 kgf-m) (449 lb-ft)
 (Rear): 1,030 N-m (105 kgf-m) (760 lb-ft)
-  : Screw lock agent (Three Bond 1327)



5. Temporarily sling differential (7), and insert bolts into remover tap (Jack Screw) holes (8) to slightly lift the differential.










-  : Differential (front): 1,180 kg (2,600 lbs)
-  : Differential (rear): 1,270 kg (2,800 lbs)

Note


Be careful to sling the differential so that it is balanced and is lifted straight up.

Adjusting tooth contact

After adjusting the backlash to the standard value, check that manual rotation of the gear is possible. After that, paint blue or red on the tooth surface of ring gear, and check the tooth contact. To adjust the tooth contact, adjust the thickness of the shim between the pinion and cage, and turn the adjustment nut.

| | Tooth contact | Possible cause | Adjusting method | |
|---|---|---|--|---|
| A |  | | Correct | |
| B |  | Ring gear is too close to the drive pinion | Loosen the bearing adjuster on the rear side of ring gear, and tighten the adjuster of tooth side at the same quantity as loosening, so that the ring gear is far apart from the drive pinion. Check again the backlash and tooth contact. |  |
| C |  | Ring gear is too far from the drive pinion | Do the reverse adjusting as B. |  |
| D |  | Drive pinion is too close to the ring gear. | Increase the thickness of shim at the part of bearing cage being installed and makes drive pinion apart from the ring gear. Check again the backlash and tooth contact. |  |
| E |  | Drive pinion is too far from the ring gear. | Decrease the thickness of shim reverse as D, and makes drive pinion approach the ring gear. Check again the backlash and tooth contact. |  |

34-4
 135ZV-2 Disassembly & Reassembly Torque Converter and Transmission Group
 Torque Converter Assembly




3. Remove bolts (7) and remove the first propeller shaft.

- : Bolt (7): 221 N-m (22.5 kgf-m) (163 lb-ft)
- : Screw lock agent (Three Bond 1327)
- : First propeller shaft: 40 kg (90 lbs)

Note


- If the retainer bolts are too tight due to the screw lock agent, heat the bolt head using slow flame of a gas burner.
- Keep the flame away from the seals of the coupling.
- Do not reuse the bolts, always replace with new ones.



5. Remove all bolt (8) and insert three bolts (M12 x 1.75) into the remover tap (Jack screw) holes.


6. Remove the torque converter toward the front of the machine using the Jack screws.

- : Bolt (8): 94 N-m (9.6 kgf-m) (69 lb-ft)
- : With lubricating oil (engine oil or gear oil)




4. Temporarily sling the torque converter.



- : Torque converter (excluding oil):
540 kg (1,190 lbs)



3. Loosen drain plug (4) to drain the transmission oil.


 : Transmission oil: 200 L (53 gal)

4. Remove bolt (5) from the second propeller shaft on the transmission side only.
Remove retainer bolt (6) of the third propeller shaft on the transmission side only.




 : Bolt (5)(6): 221 N-m (22.5 kgf-m) (163 lb-ft)
 : Screw lock agent (Three Bond 1327)

Note

- If the retainer bolts are too tight due to the screw lock agent, heat the bolt head using slow flame of a gas burner.
- Keep the flame away from the seals of the coupling.
- Do not reuse the bolts, always replace with new ones.




5. Remove bolts (7) and remove the first propeller shaft.

 : Bolt (7): 221 N-m (22.5 kgf-m) (163 lb-ft)
 : Screw lock agent (Three Bond 1327)
 : First propeller shaft: 40 kg (90 lbs)

Note


- If the retainer bolts are too tight due to the screw lock agent, heat the bolt head using slow flame of a gas burner.
- Keep the flame away from the seals of the coupling.
- Do not reuse the bolts, always replace with new ones.







6. Remove suction hose (8), pipe (9) and brake line hose (10) from the transmission.

Note

Cover the removed hoses and pipes with vinyl or plastic caps to protect them from dust and dirt.




6. Install parking brake assembly to the transmission housing and tighten bolt (16)(17).



-  : Bolt (16): 230 N-m (23.5 kgf-m) (170 lb-ft)
-  : Bolt (17): 93.7 N-m (9.55 kgf-m) (69 lb-ft)
-  : With lubricating oil (engine oil or gear oil)
-  : Parking brake assembly: 330 kg (730 lbs)

Note

Make sure to install the gaskets to the contact surface between the parking brake housing and the transmission housing.




7. Turn over the transmission, and install ring (18), roller bearing (19) and snap ring (20) to the output shaft on the third propeller shaft side. Install oil seal (22) and O-ring (23) to seal retainer (21), and install seal retainer (21) to the transmission housing. Tighten bolt (24).

-  : Bolt (24): 230 N-m (23.5 kgf-m) (170 lb-ft)
-  : With lubricating oil (engine oil or gear oil)


Note

Apply grease to the oil seal (22) before installing them to the housing.

| |
|--|
| IMPORTANT |
| Be careful with the installation direction of the oil lip seal (22). |



8. Lift the clutch assembly to install it to the housing.


-  : Clutch assembly: 1,260 kg (2,780 lbs)

| |
|--|
| IMPORTANT |
| Be sure to align the oil holes of the clutch pack assembly with those of the transmission housing. |

Clutch assembly assembling


Before starting work:

- Clean and check each part, and replace any part with a new one, if necessary.
(Refer to Section 35 for the limit.)
- Be sure to apply the transmission oil to each necessary point when reassembling the clutch assembly.
- Replace the packing and the seals with new ones.
- Check each steel plate for flatness. If there is any warpage, replace the plate.



Measurement of piston stroke

Measure the piston stroke of the 2nd, 3rd, low and reverse clutch respectively.



- (a) Insert the desired clutch piston into each clutch housing completely, and measure the dimension as shown in the illustration. (This is dimension A.)

- (b) Set the necessary number of friction plates and steel plates referring to the following table and measure the total thickness. (This is dimension B.)

| | Friction plate | Steel plate |
|---------|----------------|-------------|
| 2nd | 4 pcs | 4 pcs |
| 3rd | 5 pcs | 5 pcs |
| Forward | 8 pcs | 8 pcs |
| Reverse | 8 pcs | 8 pcs |

- (c) Subtracting dimension B from dimension A equals to the piston stroke.
The piston stroke should be within the range shown in the following table.

| | Piston stroke mm (in) |
|---------|-----------------------------|
| 2nd | 5.0 ± 0.5 (0.1969 ± 0.0196) |
| 3rd | 7.0 ± 0.5 (0.2756 ± 0.0196) |
| Forward | 9.0 ± 0.5 (0.3543 ± 0.0196) |
| Reverse | 9.0 ± 0.5 (0.3543 ± 0.0196) |

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below




- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL


2nd Clutch Spider


2nd clutch spider disassembling and assembling


2nd clutch spider disassembling



1. Release calked lock plate (1) and remove bolt (2). Remove lock plate (1) and plate (3). Separate spider assembly (4) from internal gear (5).

 : Bolt (2): 132 N-m (13.5 kgf-m) (98 lb-ft)


 : With lubricating oil (engine oil or gear oil)




2. Knock in spring pin (7) that locks pin (6) all the way to unlock pin (6). Pull out pin (6).

Note

After removing pin (6), take spring pin (7) out of pin(6).





3. Remove planetary gears (8), needle bearings (9) and washer (10).





4. Remove snap ring (11) and remove bearing (12) from spider assembly (4).

135ZV-2 Disassembly & Reassembly Torque Converter and Transmission Group
Control Valve Assembly




- 3. Remove pipes (6)~(9).
- 4. Remove four bolts (10) to remove accumulator assembly (11).


- 5. Remove lock nut (12) from the solenoid valve. After removing coil (13), remove valve (14).


 : Nut (12): 9.8 N-m (1.0 kgf-m) (7.2 lb-ft)
 : Valve (14): 29.4 N-m (3.0 kgf-m) (22 lb-ft)

- 6. Remove four bolts (15) and remove valve assembly (16).


 : Bolt (15): 25.5 N-m (2.60 kgf-m) (19 lb-ft)

- 7. Remove eight bolts (17) to remove check valve assembly (18).

 : Bolt (17): 25.5 N-m (2.60 kgf-m) (19 lb-ft)



- 8. Remove eighteen bolts (19) to remove control valve (20).

 : Bolt (19): 86.6 N-m (8.80 kgf-m) (64 lb-ft)

135ZV-2 Service Standard Torque Converter and Transmission Group
Transmission Assembly

mm (in), N (lbf)

| Ref. | Item | | Standard value | | | Allowable limit | | Solution |
|------|----------|--|-------------------------------|------------------|-------------------|-------------------------------------|----------------|-------------|
| | | | Free length | Installed length | Installed load | Free length | Installed load | |
| 1 | Spring | Clutch return spring (F, R) | 105 (4.1) | 94.2 (3.7) | 369 (37.6) | — | — | Replacement |
| 2 | | Clutch return spring (3rd) | 70 (2.8) | 63 (2.5) | 298 (30.4) | — | — | Replacement |
| 3 | | Clutch return spring (2nd) | 60 (2.4) | 52.6 (2.1) | 330 (33.7) | — | — | Replacement |
| 4 | | Clutch return spring (1st) | 55 (2.2) | 49 (2.0) | 291 (29.7) | — | — | Replacement |
| 5 | | Parking brake spring | 130 (5.1) | 103 (4.1) | 5,084 (518.4) | — | — | Replacement |
| | Item | | Judgement criteria | | | | Solution | |
| | | | Standard value | | Allowable limit | | | |
| 6 | Oil seal | Shaft diameter of output yoke and input yoke | 109.91~110 (4.3272~4.3307) | | 109.8 (4.3228) | Replace oil seal when disassembling | Replacement | |
| 7 | | Shaft diameter of front yoke and rear yoke | 129.9~130 (5.1142~5.1181) | | 129.8 (5.1102) | | Replacement | |
| 8 | | Parking brake shaft diameter | 124.9~125 (4.9173~4.9213) | | 124.8 (4.9134) | | Replacement | |

Hydraulic Pump

Hydraulic pump removing and installing

Hydraulic pump removing

⚠ WARNING


Unexpected movement of the machine could cause serious injury or death. To prevent such an accident, observe the following items:

- Park the machine on level and solid ground.
- Apply the parking brake.
- Block the tires with chocks to prevent the wheels from moving.
- Lower the attachment onto the ground, and relieve the residual pressure from the loading line and the hydraulic tank to prevent the oil from spouting out.
- Before starting work, be sure to remove the engine key, and hang a "DO NOT START!" tag on the operation board or the operator's seat.
- Use a stepladder or work platform to reach the higher parts of the machine.
- Give proper instructions to the service technicians.

IMPORTANT

Starting the machine just after installing the hydraulic pump could make the hydraulic pump be seized.

- Before installing, pour new oil from the outlet and inlet ports into the pump to form an oil film inside the pump.
- When installing, clean the outer surface of the pump.
- Keep hoses and ports capped during installation to keep dirt out.
- After installing, supply hydraulic oil into the hydraulic tank, and remove the plugs of the pump suction pipe to vent air in the hydraulic pipe. If no oil comes out from the plug, pour hydraulic oil until the oil overflows from the plug.
- Operate the engine at low-idling speed for 5 minutes or more. Do not operate any hydraulic functions during this period.



Before starting work:

- Drain the hydraulic oil from the hydraulic sub tank.



: Hydraulic oil: Approx. 300 (79.3 gal)

- Relieve the residual pressure from the hydraulic circuit. Refer to the following procedures.

Hydraulic line residual pressure removal procedure


For loading line

1. Raise the boom. When the boom is approximately 30~50 cm (1~2 ft) above the ground, stop the engine.
2. Tilt the attachment all the way down, and lower the boom onto the ground.
3. Move the attachment and boom lever back and forth to fully relieve the pressure.
4. Push the cap of the hydraulic tank to relieve the internal pressure from the hydraulic tank.


For steering line (U.S.A. specification)

1. Install the hose for measuring pressure to the fitting at the steering cylinder rod side, and then relieve the residual pressure.
To prevent the machine from moving, be sure to apply the articulation stopper before starting work.
2. Push the cap of the hydraulic tank to relieve the internal pressure from the hydraulic tank.


44-14
 135ZV-2 Disassembly & Reassembly Hydraulic Group
 Hydraulic Pump



7. Remove plate (212) and shoe plate (211) from pump casing (271).




8. Tap the shaft-end of drive shaft (111), and pull out drive shaft (111) from plate (251).



9. Remove valve plate (314) from valve block (312).

10. Disassemble the rear pump following the same procedure.



11. If necessary, remove stopper (L) (534), stopper (S) (535), servo piston (532) and pin (531) from pump casing (271).
 Also, remove needle bearing (124) and spline (114) from valve block (312).

Note

- When removing pin (531), take care not to scratch the head of it.
- The connecting section of pin (531) and servo piston (532) have liquid adhesive applied to them. Take care not to scratch the servo piston while removing.
- Do not remove the needle bearing unless disassembly is absolutely necessary for replacement.

IMPORTANT

Do not loosen hexagon nuts (806, 808) of valve block (312) and plate (251).
 Loosening or misadjusting them causes oil flow amount change and it decreases performance of the pump.

Hydraulic steering pump assembling

To reassemble the steering pump, follow the above disassembling procedure in reverse order.

Pilot Valve (for Loading)

Pilot valve (for loading) removing and installing

Pilot valve (for loading) removing


⚠ WARNING

Unexpected movement of the machine could cause serious injury or death. To prevent such an accident, observe the following items:


- Park the machine on level ground, and then block the tires with chocks to prevent the wheels from moving. In addition, apply the parking brake.
- Lower the attachment onto the ground, and then, relieve the internal pressure from the line.
- Relieve the internal pressure from the hydraulic tank.

Before starting work:


- Stop the engine and lower the attachment to the ground. After that move the lever back and forth, left and right and relieve inner pressure from pilot line.



1. Remove connector from the control lever.




2. Remove screw (1) and cover (2) from the control lever.



3. Remove spring pin (3) and knob (4) from the control lever.

44-34
135ZV-2 Disassembly & Reassembly Hydraulic Group
Pilot Valve (for Steering)



Pilot valve (for steering) installing

To reinstall the pilot valve for steering, follow the removal procedure in reverse order.


Pilot valve (for steering) installation cautions

Be sure to wipe off any spilt oil inside the cab.

4. Protect the cab interior from spilt oil.
Disconnect "L" (Left) port hose (11), "R" (Right) port hose (12), "T" (Tank) port hose (13) and "P" (Pressure) port hose (14).


Note

- Before disconnecting these hoses, be sure to put matchmarks on them.
- Cover the disconnected hoses with vinyl, plugs or caps to protect them from dust and dirt.





5. Remove bolt (15) and then remove pilot valve (16).

44-44
 135ZV-2 Disassembly & Reassembly Hydraulic Group
 Steering Valve




4. Remove bolt (271) and remove covers (201)(202).

-  : Bolt (271): 62 N-m (6.3 kgf-m) (46 lb-ft)
- : Allen wrench width across flats
- : 8 mm (0.315 in)




6. Slowly loosen plug (155). Do not remove it here.

-  : Plug (155): 98 N-m (10 kgf-m) (72 lb-ft)
- : Width across flat: 41 mm (1.61 in)

Note


Carefully loosen plug (155). It may spring out by the spring force.




5. Remove spring (321) and spring seat (331), and then pull out spool (300).

Note


- Carefully pull out the spool so that the casing and the spool are not scratched.
- Put match marks on the spool and casing to assure the direction of the spool during reassembly.



7. Remove relief valve (602).

-  : Valve (602): 79 N-m (8 kgf-m) (58 lb-ft)
- : Width across flat: 19 mm (0.75 in)

8. Remove plug (156) and pull out spring (323) and spool (302) from casing (101).

-  : Plug (156): 98 N-m (10 kgf-m) (72 lb-ft)

Note

- Carefully remove plug (156). It may spring out by the spring force.
- Carefully pull out spool (302) so that casing (101) and spool (302) do not scratch each other.

9. Remove plug (155) loosened in the above step 6).

Stop Valve


Stop valve removing and installing

Stop valve removing

⚠ WARNING

Unexpected movement of the machine, attachment, or boom during service work could cause serious injury or death. To prevent such an accident, observe the following items:

- Park the machine on level ground, and apply the parking brake. In addition, block the tires with chocks to prevent the wheels from moving.
- Relieve the internal pressure from the hydraulic tank to prevent the oil from spouting out.
- Remove the engine key, and hang a "DO NOT START ENGINE!" tag on the operation board.
- Use a stepladder or the like to reach the higher position of the machine.




1. Disconnect hose (1) and oil pipe (2).

Note


Cover the disconnected hoses and pipes with plastic, plugs or caps to protect them from dust and dirt.

2. Remove bolt (3), and then, remove stop valve (4).

 : Bolt (3): 28 N-m (2.85 kgf-m) (21 lb-ft)

Stop valve installing

For reinstallation, follow the above procedure in reverse order.



- Remove grease pipe (7) and bolt (8) to remove pin (9).
 Sling steering cylinder (5) and remove it.

Note

There are shims (10) in the pin section at the bottom side. Carefully store the removed shims, and correctly reinsert the shims when reinstalling the cylinder.

Steering cylinder installing

To reinstall the steering cylinder, follow the above removal procedure in reverse order.

Steering cylinder installation cautions


⚠ WARNING

Articulation area is a crush zone. Moving the machine with a person in this area can cause injury or death. When moving the K-Lever while engine is running, do not enter the articulation area of the machine. If a person is in the articulation area, do not start the engine.

Pin installation

Be sure the pins accept grease after installation.

Shim adjustment



IMPORTANT


Insert shims so that the clearance between the chassis and the cylinder is 1.2 mm (0.047 in) or less. Place the same number of shims under the cylinder as on top of the cylinder. Refer to "Linkage Pin Standard Clearance Values" page 15-3.

Adjust the clearance on the rear chassis side first, and then, adjust the clearance on the front chassis side while checking that the cylinder is not inclined.


44-74
135ZV-2 Disassembly & Reassembly Hydraulic Group

MEMO


54-6
 135ZV-2 Disassembly & Reassembly Brake Group
 Brake Valve




7. Pull out pin (22), pedal pin (23), L-shape pin (24) and washer (25), and then, remove collar (26) and roller (27).



10. Loosen bolt (34) and remove spring washer (35) and mounting plate (36).

 : Bolt (34): 25.5 N-m (2.6 kgf-m) (18.8 lb-ft)

11. Remove dust cover (37) and seat (38).



8. Remove ring (28) and pull out boot (29).

9. Remove ring (30) for the joint, and remove pin (31) by using a pressing machine or equivalent to separate shaft assembly (32)(33).

Valve assembly disassembling and assembling


IMPORTANT

Before disassembly or reassembly, read and understand the aforementioned "Hydraulic Parts Disassembly and Assembly Cautions" page 44-3.

CAUTION

The accumulator pressure [11.8 MPa (1,706 psi)] is applied to the high pressure test ports, that may cause serious injury when escaping from the plugs. Completely depress brake pedal 80~100 times to relieve all pressure before removing plugs.

Valve assembly cross section and tightening torque



- T₁: 50 N-m (5.1 kgf-m) (37 lb-ft)
- T₂: 38 N-m (3.9 kgf-m) (28 lb-ft)
- T₃: 23.5 N-m (2.4 kgf-m) (17 lb-ft)
- T₄: 11 N-m (1.1 kgf-m) (8 lb-ft)



L₁: Screw lock agent application (Loctite® 262)

54-26

135ZV-2 Disassembly & Reassembly Brake Group
Accumulator

[Charging pressure: 2.9 MPa (30 kgf/cm²) (427 psi) at
20°C (68°F)]

Note

Gas pressure is variable with temperature.

Use the following formula for the correct nitrogen charging pressure.

If the pressure on the gauge is too high, slowly turn the handle (1-2) counterclockwise.

$$P_x = 30 \text{ (kgf/cm}^2\text{)} \times \{273 + t \text{ (}^\circ\text{C)}\} / \{273 + 20 \text{ (}^\circ\text{C)}\}$$

P_x : Charging gas pressure

t: Ambient temperature



30: Standard gas pressure

8. Turn handle (1-1) counterclockwise to return the piston of the gas valve. Then turn handle (1-2) counterclockwise to bleed the gas from the charging assembly and the hose.
9. After removing pressure gauge (2), remove the charging assembly from the accumulator.

Note


- Apply soapy water to the gas valve on the accumulator to check for gas leakage.
- Recheck the gas pressure once within a week after the charging.
- Check the gas pressure at every 2,000 operation hours.
- A little gas is lost each time of the checking, so add the gas to compensate for the loss.

54-36
 135ZV-2 Disassembly & Reassembly Brake Group
 Parking Brake



10. Assemble seal assemblies (16)(17) and wear ring (18) into piston (15).

14. Install cover (22) to the parking brake housing and tighten bolt (23).





: Bolt (23): 230 N-m (23.5 kgf-m) (170 lb-ft)
 : With lubricating oil (Engine oil or gear oil)

11. Assemble piston (15) into the parking brake housing, and tighten bolt (19).

Note
 Screw two prepared longer bolts completely into the holes that are diagonal from cover (22) installation bolt holes. Tighten fourteen bolts (23) to the rest of installation bolt holes. Remove two longer bolts tightened first, and then tighten two residual bolts (23).

: Bolt (19): 230 N-m (23.5 kgf-m) (170 lb-ft)
 : With lubricating oil (Engine oil or gear oil)



15. Gradually apply air pressure to the oil port, and check that the shaft stroke mount is constant and the shaft operates properly. Also check the air leakage.

12. Install ring (20) into the parking brake housing.

16. Install cover (24) and tighten bolt (25).


: Bolt (25): 27.9 N-m (2.85 kgf-m) (21 lb-ft)

13. Install eight springs (21) to piston (15).

Air conditioner disassembling and assembling

Air conditioner tightening torque

[Cooling unit]



97ZV74002

 : Bolt tightening torque

- T₁: 5.4 N-m (0.55 kgf-m) (4 lb-ft)
- T₂: 1.9 N-m (0.19 kgf-m) (1.4 lb-ft)
- T₃: 1.0 N-m (0.1 kgf-m) (0.7 lb-ft)
- T₄: 0.8 N-m (0.08 kgf-m) (0.6 lb-ft)
- T₅: 1.9 N-m (0.19 kgf-m) (1.4 lb-ft)
- T₆: 2.5 N-m (0.25 kgf-m) (1.8 lb-ft)

Air Conditioner

Air conditioner periodical inspection/servicing

| Inspection/maintenance item | | Criteria | Solution |
|-----------------------------------|---------------------------------|---|-----------------------------------|
| Refrigerant | Charge quantity | Air bubbles should not be seen through sight glass. | Inspection/adjustment |
| Condenser | Blockage in fins | Blockage should not be detected. | Clean |
| Compressor | Operating status | Magnetic clutch should operate. Abnormal sounds should not be detected. | Inspection/adjustment/replacement |
| Belt tension pulley | Operating status | Abnormal sounds and backlash should not be detected. | Inspection/replacement |
| V belt | Damage and tension | Damages should not be detected. | Replacement |
| Blower motor and fan | Operating status | Abnormal sounds or vibration should not be detected. | Inspection/replacement |
| Control mechanism | Operating status | Each part should operate in accordance with switch operations. | Inspection/replacement |
| Air filter for inside/outside air | Clogging | Air quantity should not be so small as to hinder air conditioning. | Cleaning/replacement |
| Each mounting area and piping | Looseness, gas leak and damages | Looseness, gas leak and damages should not be detected. | Tightening/charge |

Air conditioner tightening torque

Tightening torque for hose and pipes

| Connection type | Connection area | Pipe size or bolt size | Tightening torque N-m (kgf-m) (lb-ft) |
|-----------------|---------------------------|-----------------------------------|--|
| Nut type | Condenser-expansion valve | ø8 piping | 15 (1.50) (11) |
| | Compressor-condenser | D1/2 piping | 25 (2.50) (18) |
| | Evaporator-compressor | D5/8 piping | 34 (3.50) (25) |
| Block joint | Receiver | M6 bolt in receiver (4T) | 7 (0.70) (5.1) |
| | Evaporator-compressor | Any M6 bolt (6T) other than above | 12 (1.20) (8.7) |

Tightening torque for screws and bolts in special control regions

| Special control area | Bolt size | Tightening torque N-m (kgf-m) (lb-ft) |
|--|-----------|--|
| Head bolt of magnetic clutch | M6 | 18 (1.8) (13) |
| Mounting bolt for servo motor for inside/outside air selection (Tapping screw) | | 0.8 (0.08) (0.6) |
| Fixing nut of blower motor and condenser fan | M6 | 5.4 (0.55) (4.0) |
| Fixing bolt of blower motor and condenser motor | M5 | 4 (0.4) (2.9) |

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL