



93211-00450

May 25, 2009

85ZV-2

SHOP MANUAL

Troubleshooting

SHOP MANUAL

WHEEL LOADER

85ZV-2

Troubleshooting

Measurement for Performance

Check

Check & Adjustment

Powered by CUMMINS QSC8.3 ENGINE

Serial No. 85C5-9001~

93211-00450

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

How to Use Quick Troubleshooting Table

To immediately determine the cause of the problem without disassembling parts, use the quick troubleshooting table. From the problem explained by the user and the check points written in the table, you can immediately determine the cause of the problem.

How to use quick troubleshooting table

1. According to the problem explained by the user, open the quick troubleshooting table to the page where the corresponding problem is described.
2. Check the machine according to the "Symptoms/check point" field in the table. Start from the most easily checked point.
3. Operate the machine, and write the check marks "✓" in the corresponding circles "○" if the problem occurs.
4. Generally, the possible cause that has many check marks will be actual cause. If two or more possible causes have several check marks, check each possible cause to prevent an incorrect diagnosis. In this case, start from the most easily checked item.

9. Automatic speed change is not possible. Check before starting work. 1. Manually change the speed from 1st speed to 4th speed. If manual speed change is impossible, refer to "Machine does not move at a certain shift lever position." (No.2) 2. Check the error code No. shown on the MODM.		Symptoms / check point												
Possible cause		Speed is fixed to 2nd speed, and automatic speed change is not possible.	Speed is fixed to 3rd speed, and is not increased to 4th speed.	Speed is properly increased on a downward slope.	Actual speed increase or reduction does not correspond with the set speed.	Speed indicator lamp does not change even if machine speed is changed.	One or more planetaries are excessively hot/parking brake is hot or discolored.							Solution
	Defective shift lever "A" position or defective wiring to controller	<input type="radio"/>												Shift lever replacement or repairing wire
	Damaged speed sensor or disconnected sensor	<input type="radio"/>												Sensor replacement or repairing wire
	Speed sensor signal output error or improperly adjusted speed sensor	<input type="radio"/>	<input type="radio"/>		<input type="radio"/>									Sensor replacement or readjustment
	Defective controller	<input type="radio"/>	<input type="radio"/>		<input type="radio"/>									Controller replacement
	Low machine speed	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>										Inspection & repair
	Parking or service brakes dragging	<input type="radio"/>					<input type="radio"/>							Test/repair brake circuit
	Engine power too low / Engine speed too low	<input type="radio"/>												See E/G troubleshooting
	Speed indicator lamp failure					<input type="radio"/>								Replacement

9. Ride control does not work. Check before starting work. 1. Check the error code No. shown on the MODM.		Symptoms / check point												
Possible cause		Ride control does not work.	It takes a time to function.	Damping condition too soft.	Damping condition too hard.	Reducing valve chattering.								Solution
	Ride control switch defective	<input type="radio"/>												Replacement
	Charge spool stuck	<input type="radio"/>												Disassembly & repair
	Malfunctioning reducing valve	<input type="radio"/>		<input type="radio"/>	<input type="radio"/>									Disassembly & repair
	Malfunctioning solenoid valve	<input type="radio"/>												Disassembly & repair or replacement
	Main spool stuck or moving slowly	<input type="radio"/>	<input type="radio"/>		<input type="radio"/>									Disassembly & repair
	Flow control spool stuck or moving slowly	<input type="radio"/>	<input type="radio"/>		<input type="radio"/>									Disassembly & repair
	Accumulator piston seal failure	<input type="radio"/>												Disassembly & repair
	Accumulator gas pressure low			<input type="radio"/>										Check & charge gas
	Depressure valve loosened	<input type="radio"/>												Retighten
	Bucket fully roll-back till touching with stopper	<input type="radio"/>												Make a clearance between stoppers
	Check valve defective					<input type="radio"/>								Replacement

2. Fuse for controller is blown. Check before starting work. 1. Check the error code No. shown on the MODM.		Symptoms / check point											
Possible cause		Fuse blows off immediately after replacing.	Fuse blows off if the machine sways during travelling.	Coil of the solenoid valve has extremely low resistance.	In the solenoid valve continuity test, changing the positive and negative sides to each other and both of them are continuity.	Both the forward and reverse shift lever position enable the engine to start.	Parking brake remains unreleased regardless of the parking brake switch position.	Fuse blows off when a certain speed or direction is selected.					Solution
Controller power line contacts with chassis. (Wire pinched by other components, etc.)		<input type="radio"/>											Inspection & repair
Controller power line occasional contacts with chassis.			<input type="radio"/>										Inspection & repair
Clutch solenoid valve coil shortcircuited				<input type="radio"/>				<input type="radio"/>					Solenoid valve replacement
Clutch solenoid valve diode failed				<input type="radio"/>									Solenoid valve replacement
Neutral or controller failure or kickout relay power line contacts with chassis.		<input type="radio"/>											Inspection & repair
Neutral or controller failure or kickout relay power line occasional contacts with chassis.			<input type="radio"/>										Inspection & repair
Parking brake solenoid valve power line contacts with chassis.		<input type="radio"/>					<input type="radio"/>						Inspection & repair
Parking brake solenoid valve power line occasional contacts with chassis.			<input type="radio"/>										Inspection & repair
Neutral relay power line contacts with chassis.					<input type="radio"/>								Inspection & repair

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

01-44
85ZV-2 Troubleshooting
Electrical Group

FAULT CODE/ LAMP	DESCRIPTION	QSB4.5 (60ZV-2)	QSB6.7 (70ZV-2) (70TMV-2)	QSC8.3 (80ZV-2)	QSC8.3 (85ZV-2)	QSM11 (90ZV-2)	QSM11 (92ZV-2)	QSM11 (95ZV-2)	QSK19 (115ZV-2)	QST30 (135ZV-2)
EG2964 None	Intake Manifold Temperature High - warning.								○	
EG2973 Yellow	Intake Manifold Pressure Sensor Circuit - data erratic, intermittent, or incorrect.	○	○	○	○					

(09D20E)

Accumulator Circuit Charging Time	03-48
Number of Brake Pedal Applications	03-50
Declutch Engagement	03-51

Engine

WARNING

Unexpected movement of the machine may cause an accident resulting in injury or death.

Therefore, to provide repair service with the engine running, be sure to observe the following items:

- Park the machine on level ground.
- Apply the parking brake.
- Block the tires with chocks to prevent the tires from moving.
- Determine the signals between the service men.
- Prohibit any person from walking into dangerous areas.
 - Near articulation area of the machine
 - Under the machine
 - Around the engine
 - In front of or behind the machine

CAUTION

Do not touch the fan or V-belt of the engine or high-temperature section if the engine is running.

An accident resulting in injury may occur.

Be sure to stop the engine before you open the access panel of the engine room.

Keep all guards in place.

Avoid high temperature components even when the engine is stopped.

Use a photo tachometer when checking engine revolution.

Measurement conditions

Temperature of torque converter oil :

50~80°C (120~180°F)

Temperature of hydraulic oil :

50~80°C (120~180°F)

Temperature of engine coolant :

50~80°C (120~180°F)

1. Press the brake pedal.
Set and confirm the transmission shift lever is neutral position.
2. Set and confirm the parking brake to the "ON" position.
3. Lower the bucket onto the ground.
4. Set the boom and bucket control lever to "Neutral position".
5. Set the shift lever to the forward position.

Note

To avoid "Hibernate mode".

In "Hibernate mode", decrease the engine speed 800 min⁻¹ to 725 min⁻¹ under following condition.

When the transmission shift lever is placed in "N" position, the engine coolant temperature is higher than 60°C, and the engine speed is held at 950 min⁻¹ or less for 10 seconds.

6. Record low idle speed.
7. Set and confirm the transmission shift lever is neutral.
8. Set the declutch ON/OFF switch to ON.
Press the brake pedal all the way to the floor.

Note

To avoid "fuel saving mode at idle time".

In "fuel saving mode at idle time", not activated promptly and engine may not reach the maximum revolution.

Press the brake pedal all the way to the floor with the declutch ON/OFF switch to ON, release this mode.

9. Gradually increase the engine speed.
Measure the speed (high Idle) when the accelerator pedal is fully pressed down.
10. Record high idle speed.

Measuring engine speed

Measurement instrument

- Tachometer (MODM)

Standard measurement value

Low idle (min⁻¹): 800±50

High idle (min⁻¹): 2,250±50

03-22

85ZV-2 Measurement for Performance Check

Full Steering Cycle Time

14. Measure and record time required for full steering.


- From full left to full right or
 - From full right to full left
- Turn the steering wheel as fast as possible during the test.

Possible causes for slow steering times:

Possible cause	Solution
Damaged steering pump / seals	Disassembly & repair
Malfunctioning steering valve flow control plunger or steering spool	Disassembly & repair


IMPORTANT

After measuring, return the stopper bolts.
(Refer to "Stop valve" in Check & Adjustment.)




Full steering

97ZV03007



90ZV03005

Measuring steering circuit overload relief pressure



95ZV42033

1. Attach the pressure gauge to the port ((1) for the left turn, (2) for the right turn).
2. Adjust the main relief valve pressure to 25.5 MPa (260 kgf/cm²) (3,697 psi) + 1/4 additional turn, so the pressure is above the overload relief pressure.
3. Steer the machine until the front and rear chassis contact each other. Continue to hold the steering wheel fully turned.

Note

Because the stop valve is installed into the steering line, oil pressure does not reach the set point when the steering is fully turned.

When measuring oil pressure, be sure to apply the articulation stopper or screw the stopper (bolt) in until the front and rear chassis contact each other.

4. Set the shift lever to the forward position.

Note


To avoid "Hibernate mode".

In "Hibernate mode", decrease the engine speed 850 min⁻¹ to 725 min⁻¹ under following condition.

When the transmission shift lever is placed in "N" position, the engine coolant temperature is higher than 60°C, and the engine speed is held at 950 min⁻¹ or less for 10 seconds.

5. Keep the engine speed at low idle, and measure and record the pressure.
 Raise the engine speed to 1,000 min⁻¹ if fail to do.

Adjusting overload relief pressure



70ZV43005

Loosen the lock nut and adjust the pressure by the adjusting screw.

Turn clockwise the adjusting screw to raise the set pressure, or turn counterclockwise the adjusting screw to lower the set pressure.

⚠ WARNING

If the machine begins to move with the articulation stopper applied, it may cause an accident resulting in injury or death.

After the measurement, be sure to disconnect and store the articulation stopper.


IMPORTANT

At the completion of check and adjustment of overload relief valve pressure, be sure to reset the main relief valve to the original condition.

03-42

85ZV-2 Measurement for Performance Check
Parking Brake

Brake lining abrasion check



80ZV53004

12 rivets are inserted to fix the lining to the brake shoe. If the distance from the lining to the rivet head "B" is 0.8 mm (0.03 in) or less at one of the 12 rivet areas, replace the shoe assembly.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL