



93213-00450

May 25, 2009

90ZV-2

SHOP MANUAL

Troubleshooting

SHOP MANUAL

WHEEL LOADER

90ZV-2

Troubleshooting

***Measurement for Performance
Check***

Check & Adjustment

Powered by CUMMINS QSM11 ENGINE

Serial No. 90C5-9001~

93213-00450

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

How to Use Quick Troubleshooting Table

To immediately determine the cause of the problem without disassembling parts, use the quick troubleshooting table. From the problem explained by the user and the check points written in the table, you can immediately determine the cause of the problem.

How to use quick troubleshooting table

1. According to the problem explained by the user, open the quick troubleshooting table to the page where the corresponding problem is described.
2. Check the machine according to the "Symptoms/check point" field in the table. Start from the most easily checked point.
3. Operate the machine, and write the check marks "✓" in the corresponding circles "○" if the problem occurs.
4. Generally, the possible cause that has many check marks will be actual cause. If two or more possible causes have several check marks, check each possible cause to prevent an incorrect diagnosis. In this case, start from the most easily checked item.

9. Ride control does not work. Check before starting work. 1. Check the error code No. shown on the MODM.		Symptoms / check point												
Possible cause		Ride control does not work.	It takes a time to function.	Damping condition too soft.	Damping condition too hard.	Reducing valve chattering.								Solution
	Ride control switch defective	<input type="radio"/>												Replacement
	Charge spool stuck	<input type="radio"/>												Disassembly & repair
	Malfunctioning reducing valve	<input type="radio"/>		<input type="radio"/>	<input type="radio"/>									Disassembly & repair
	Malfunctioning solenoid valve	<input type="radio"/>												Disassembly & repair or replacement
	Main spool stuck or moving slowly	<input type="radio"/>	<input type="radio"/>		<input type="radio"/>									Disassembly & repair
	Flow control spool stuck or moving slowly	<input type="radio"/>	<input type="radio"/>		<input type="radio"/>									Disassembly & repair
	Accumulator piston seal failure	<input type="radio"/>												Disassembly & repair
	Accumulator gas pressure low			<input type="radio"/>										Check & charge gas
	Depressure valve loosened	<input type="radio"/>												Retighten
	Bucket fully roll-back till touching with stopper	<input type="radio"/>												Make a clearance between stoppers
	Check valve defective					<input type="radio"/>								Replacement

2. Fuse for controller is blown. Check before starting work. 1. Check the error code No. shown on the MODM.		Symptoms / check point											
Possible cause		Fuse blows off immediately after replacing.	Fuse blows off if the machine sways during travelling.	Coil of the solenoid valve has extremely low resistance.	In the solenoid valve continuity test, changing the positive and negative sides to each other and both of them are continuity.	Both the forward and reverse shift lever position enable the engine to start.	Parking brake remains unreleased regardless of the parking brake switch position.	Fuse blows off when a certain speed or direction is selected.					Solution
Controller power line contacts with chassis. (Wire pinched by other components, etc.)		<input type="radio"/>											Inspection & repair
Controller power line occasional contacts with chassis.			<input type="radio"/>										Inspection & repair
Clutch solenoid valve coil shortcircuited				<input type="radio"/>				<input type="radio"/>					Solenoid valve replacement
Clutch solenoid valve diode failed				<input type="radio"/>									Solenoid valve replacement
Neutral or controller failure or kickout relay power line contacts with chassis.		<input type="radio"/>											Inspection & repair
Neutral or controller failure or kickout relay power line occasional contacts with chassis.			<input type="radio"/>										Inspection & repair
Parking brake solenoid valve power line contacts with chassis.		<input type="radio"/>					<input type="radio"/>						Inspection & repair
Parking brake solenoid valve power line occasional contacts with chassis.			<input type="radio"/>										Inspection & repair
Neutral relay power line contacts with chassis.					<input type="radio"/>								Inspection & repair

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

01-44
 90ZV-2 Troubleshooting
 Electrical Group

FAULT CODE/ LAMP	DESCRIPTION	QSB4.5 (60ZV-2)	QSB6.7 (70ZV-2) (70TMV-2)	QSC8.3 (80ZV-2)	QSC8.3 (85ZV-2)	QSM11 (90ZV-2)	QSM11 (92ZV-2)	QSX15 (95ZV-2)	QSK19 (115ZV-2)	QST30 (135ZV-2)
EG2964 None	Intake Manifold Temperature High - warning.								○	
EG2973 Yellow	Intake Manifold Pressure Sensor Circuit - data erratic, intermittent, or incorrect.	○	○	○	○					

(09D20E)

Accumulator Circuit Charging Time	03-47
Number of Brake Pedal Applications	03-49
Declutch Engagement	03-50

Engine

WARNING

Unexpected movement of the machine may cause an accident resulting in injury or death.

Therefore, to provide repair service with the engine running, be sure to observe the following items:

- Park the machine on level ground.
- Apply the parking brake.
- Block the tires with chocks to prevent the tires from moving.
- Determine the signals between the service men.
- Prohibit any person from walking into dangerous areas.
 - Near articulation area of the machine
 - Under the machine
 - Around the engine
 - In front of or behind the machine

CAUTION

Do not touch the fan or V-belt of the engine or high-temperature section if the engine is running.

An accident resulting in injury may occur.

Be sure to stop the engine before you open the side cover of the engine room.

Keep all guards in place.

Avoid high temperature components even when the engine is stopped.

Use a photo tachometer when checking engine revolution.

Measurement conditions

Temperature of torque converter oil :

50~80°C (120~180°F)

Temperature of hydraulic oil :

50~80°C (120~180°F)

Temperature of engine coolant :

50~80°C (120~180°F)

1. Press the brake pedal.
Set and confirm the transmission shift lever is neutral position.
2. Set and confirm the parking brake to the "ON" position.
3. Lower the bucket onto the ground.
4. Set the boom and bucket control lever to "Neutral position".
5. Set the shift lever to the forward position.

Note

To avoid "Hibernate mode". In "Hibernate mode", decrease the engine speed 800 min^{-1} to 725 min^{-1} under following condition.

When the transmission shift lever is placed in "N" position, the engine coolant temperature is higher than 60°C , and the engine speed is held at 950 min^{-1} or less for 10 seconds.

6. Record low idle speed.
7. Set and confirm the transmission shift lever is neutral.
8. Gradually increase the engine speed.
Measure the speed (high Idle) when the accelerator pedal is fully pressed down.
9. Record high idle speed.

Measuring engine speed

Measurement instrument

- Tachometer (MODM)

Standard measurement value

Low idle (min^{-1}): 800 ± 50


High idle (min^{-1}): $2,250 \pm 50$

14. Measure and record time required for full steering.

- From full left to full right or
 - From full right to full left
- Turn the steering wheel as fast as possible during the test.

IMPORTANT

After measuring, return the stopper bolts.
 (Refer to "Stop valve" in Check & Adjustment.)




97ZV03007

Full steering


Possible causes for slow steering times:

Possible cause	Solution
Damaged steering pump / seals	Disassembly & repair
Malfunctioning steering valve flow control plunger or steering spool	Disassembly & repair



90ZV03005

Measuring pilot circuit relief pressure (reducing pressure)



Adjusting pilot line pressure

Loosen the lock nut and adjust the pressure by the adjusting screw.

Turn clockwise the adjusting screw to raise the pilot line pressure.

IMPORTANT

After the completion of the adjustment of the pilot line pressure, be sure to tighten the lock nut.

115ZV43007

1. Attach the pressure gauge to the port (3).

Gauge port plug width across flat
5 mm

2. Move the bucket control lever to the roll back position.
3. Set the shift lever to the forward position.

Note

To avoid "Hibernate mode".

In "Hibernate mode", decrease the engine speed 800 min^{-1} to 725 min^{-1} under following condition.

When the transmission shift lever is placed in "N" position, the engine coolant temperature is higher than 60°C , and the engine speed is held at 950 min^{-1} or less for 10 seconds.

4. Keep the engine speed at low idle and record the pressure.
5. Hold the bucket control lever at the roll back position and record the pressure.


Brake Circuit Oil Pressure

WARNING

Unexpected movement of the machine may cause an accident resulting in injury or death. Therefore, to provide repair service with the engine running, be sure to observe the following items:

- Park the machine on level ground.
- Apply the parking brake.
- Block the tires with chocks to prevent the tires from moving.
- Determine the signals between the service men.

Unloader valve setting pressure



85V2E53001

WARNING



Injection Hazard

Depress brake pedal 80~100 times to completely discharge the brake accumulators prior to removing these test plugs.

135ZV52035

Brake line main pressure is regulated by the unloader valve.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL