

HYDRAULIC EXCAVATOR

SHOP MANUAL

model

SK25SR SK30SR SK35SR

This is the shop manual for KOBELCO hydraulic excavator. Contained is the necessary technical data concerning the maintenance and repair of this model. The manual is divided into the following four major sections ; GENERAL, SYSTEMS, COMPONENTS and PROCEDURE.

*GENERAL

PW01.	SPECIFICATION	PW04.	MAINTENANCE STANDARD AND TEST PROCEDURE
—	OPERATION AND CONTROLS (Refer to Operators Manual)	—	PREVENTIVE MAINTENANCE (Refer to Operators Manual)
PW03.	LOCATION AND WEIGHT OF COMPONENTS	PW07.	WORKING STANDARD

*SYSTEMS

PW12.	HYDRAULIC SYSTEM	PW22.	CONTROL SYSTEM
PW15.	UPPER STRUCTURE	PW25.	ELECTRIC SYSTEM
PW18.	TRAVEL SYSTEM		
PW21.	ATTACHMENTS	PW29.	TROUBLE SHOOTING

*COMPONENTS

12.	HYDRAULIC PUMP	16.	SWIVEL JOINT
13.	CONTROL VALVE	17.	HYDRAULIC CYLINDER
14.	OTHER VALVES		
15.	HYDRAULIC MOTOR	50.	ENGINE

*PROCEDURE

When checking or repairing the machine we suggest that you refer to this manual carefully. We hope that reference to this manual will help to maintain a high level of working efficiency and reliability. For further details on maintenance and checks refer to the "OPERATORS MANUAL" which has been supplied with the machine.

Although all data was correct at the time of printing, due to continual design changes and improvements, some contents may not conform to the actual machine. Take special care to order parts only after confirming the validity of the part number in the "PARTS MANUAL".

If you notice any explanatory discrepancies, after consulting one of our representatives, please update your manual according to the latest data. However, in the event of any specification changes, we will issue revised edition.

INDEX

KOBELCO

Book code No. S5PW0001E②

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below




- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.


CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

■SK30SR (CANOPY SPEC.)

Unit : mm (ft-in)



■SK30SR (CAB SPEC.)




NOTE : Numerical values marked * do not include the height of the shoe lug.
 Numerical values enclosed in parentheses [] indicate steel crawler specifications.

4. TYPE OF SHOES

Model	Applicable Machines	Type	Shoe Width mm (ft.-in)	Total Width of Crawler mm (ft.-in)	Ground Pressure kg-f/cm ² (PSI)		Weight kg (lbs)
					Canopy	Cab	
SK25SR	PV10001~ PV12000	Rubber Shoe	300	1,500	0.27(3.8)	0.29(4.1)	120(260)
		Steel Shoe	(11.8")	(5'1")	0.28(4.0)	0.30(4.3)	140(310)
	PV12001~	Rubber Shoe	300	1,500	0.28(4.0)	0.30(4.3)	125(280)
		Steel Shoe	(11.8")	(5'1")	0.29(4.1)	0.30(4.3)	140(310)
SK30SR	PW07001~ PW09500	Rubber Shoe	300	1,500	0.30(4.3)	0.31(4.4)	126(280)
		Steel Shoe	(11.8")	(5'1")	0.31(4.4)	0.32(4.6)	147(320)
	PW09501~	Rubber Shoe	300	1,500	0.30(4.3)	0.31(4.4)	131(290)
		Steel Shoe	(11.8")	(5'1")	0.30(4.3)	0.31(4.4)	147(320)
SK35SR	PX05001~ PX06500	Rubber Shoe	350	1,700	0.26(3.7)	0.27(3.8)	150(330)
		Steel Shoe	(13.8")	(5'7")	0.27(3.8)	0.28(4.0)	195(430)
	PX06501~	Rubber Shoe	350	1,700	0.26(3.7)	0.27(3.8)	160(350)
		Steel Shoe	(13.8")	(5'7")	0.27(3.8)	0.28(4.0)	195(430)


5. TYPE OF BUCKETS

Model	Heaped Capacity m ³ (cu.yd)	Outside Width of Bucket mm (ft.-in)		Number of teeth	Weight kg (lbs)	Remarks
		With side cutters	Without side cutters			
SK25SR	0.035 (0.045)	300(11.8")	235(9.3")	3	38(84)	
	0.080 (0.105)	500(1'8")	435(1'5")	3	46(101)	
	0.080 (0.105)	500(1'8")	435(1'5")	4	51(112)	Standard
	0.088 (0.115)	600(2'0")	540(1'9")	4	51(112)	Heavy duty Type
SK30SR	0.050 (0.065)	350(1'2")	280(11")	3	60(132)	
	0.070 (0.092)	450(1'6")	380(1'3")	3	68(150)	
	0.090 (0.118)	500(1'8")	430(1'5")	3	71(157)	Standard
	0.090 (0.118)	500(1'8")	430(1'5")	4	75(165)	Heavy duty Type
	0.10 (0.131)	600(2'0")	530(1'9")	4	79(174)	
SK35SR	0.044 (0.058)	350(1'2")	280(11")	3	63(139)	
	0.063 (0.082)	450(1'6")	380(1'3")	4	71(157)	
	0.11 (0.144)	600(2'0")	530(1'9")	4	82(165)	Standard
	0.11 (0.144)	600(2'0")	530(1'9")	5	86(190)	Heavy duty Type
	0.12 (0.157)	700(2'4")	630(2'1")	4	89(196)	




■SK30SR (CANOPY SPEC)


(9) Standard Arm




(10) Standard Arm



(11) Long Arm



(12) Long Arm




■ SK30SR

Applicable Machine : PW07001~

Model : 3TNE82A-YB


Rated Output : 23ps/2,300rpm (16.9kw/2,300min⁻¹)



3. WEIGHT OF ATTACHMENTS


3.1 OVERALL SPECIFICATIONS OF BOOM

Model	SK25SR	SK30SR	SK35SR
Total length × Total height × Total width L × H × W mm (ft-in)	2235 × 805 × 200 (7'4" × 2'8" × 7.9")	2390 × 830 × 200 (7'10" × 2'9" × 7.9")	2575 × 885 × 200 (8'5" × 2'11" × 7.9")
Weight kg (lbs)	115(254)	139(306)	154(340)




3.2 OVERALL SPECIFICATIONS OF ARM+BUCKET

Model	SK25SR	SK30SR	SK35SR
Arm + Bucket	1.13m + 0.08m ³ (3'8" + 0.105cu.yd)	1.18m + 0.09m ³ (3'10" + 0.118cu.yd)	1.28m + 0.11m ³ (4'2" + 0.144cu.yd)
Total length × Total height × Total width L × H × W mm (ft-in)	2055 × 400 × 500 (6'9" × 1'4" × 1'8")	2170 × 465 × 500 (7'1" × 1'6" × 1'8")	2330 × 445 × 500 (7'8" × 1'6" × 1'8")
Weight kg (lbs)	116(256)	155(342)	179(395)



3.3 OVERALL SPECIFICATIONS OF ARM

Model	SK25SR	SK30SR	SK35SR
Total length × Total height × Total width L × H × W mm (ft-in)	1465 × 300 × 200 (4'10" × 11.8" × 7.9")	1530 × 310 × 200 (5'0" × 1'0" × 7.9")	1650 × 355 × 200 (5'5" × 12" × 7.9")
Weight kg (lbs)	70(154)	93(205)	97(214)



Model				SK35SR							
Applicable machines				PX05001~PX05600		PX05601~PX06500 PX06501~					
Pos.	Item			Unit	Standard value	Reference value for remedy	Standard value	Reference value for remedy			
Cylinders	Cylinder speed	Boom	Canopy	Ext.	Sec.	2.5±0.5	3.5	2.9±0.5	3.9		
				Ret.		2.2 ^{+0.8} _{-0.2}	3.2	2.7±0.5	3.7		
			Cab	Ext.		2.5±0.5	3.5	2.7±0.5	3.7		
				Ret.		2.2 ^{+0.8} _{-0.2}	3.2	2.2±0.5	3.2		
		Arm	Ext.	3.2 ^{+0.8} ₀		4.2	4.1±0.5	5.1			
			Ret.	3.2 ^{+1.8} _{-0.2}		5.2	3.7±0.5	4.7			
		Bucket	Ext.	3.1 ^{+0.4} _{-1.1}		4.6	3.4±0.5	4.4			
			Ret.	2.5 ^{+1.8} _{-0.3}		4.6	2.4±0.5	3.4			
		Swing	Ext.	7.0 ⁰ _{-2.0}		9.0	6.2±0.5	8.0			
			Ret.	7.0 ⁰ _{-2.0}		9.0	4.8±0.5	8.0			
		Dozer blade	Ext.	2.2 ^{+0.3} _{-1.2}		3.7	2.5±0.5	3.5			
			Ret.	1.6 ^{+0.9} _{-0.6}		3.1	1.8±0.5	3.8			
		Natural Cylinder drop	Boom			mm (in)	10 ⁰ ₋₁₀ (0.39 ⁰ _{-0.39})	20 (0.79)	10 ⁰ ₋₁₀ (0.39 ⁰ _{-0.39})	22 (0.87)	
			Arm				4 ⁰ ₋₄ (0.16 ⁰ _{-0.16})	8 (0.31)	4 ⁰ ₋₄ (0.16 ⁰ _{-0.16})	8 (0.31)	
	Bucket			2 ⁰ ₋₂ (0.08 ⁰ _{-0.08})	4 (0.16)		2 ⁰ ₋₂ (0.08 ⁰ _{-0.08})	4 (0.16)			
	Swing			5 ⁰ ₋₅ (0.20 ⁰ _{-0.20})	10 (0.39)		5 ⁰ ₋₅ (0.20 ⁰ _{-0.20})	10 (0.39)			
	Dozer blade			2 ⁰ ₋₂ (0.08 ⁰ _{-0.08})	4 (0.16)		2 ⁰ ₋₂ (0.08 ⁰ _{-0.08})	4 (0.16)			
	Bucket tip			125 ⁰ ₋₁₂₅ (4.9 ⁰ _{-4.9})	250 (9.8)		125 ⁰ ₋₁₂₅ (4.9 ⁰ _{-4.9})	250 (9.8)			
	Slew bearing	Bucket tip play			mm (in)	50 ⁰ ₋₅₀ (2.0 ⁰ _{-2.0})	100 (3.9)	50 ⁰ ₋₅₀ (2.0 ⁰ _{-2.0})	100 (3.9)		
		Slew bearing play				0.7±0.4 (0.03±0.02)	1.5 (0.06)	0.7±0.4 (0.03±0.02)	1.5 (0.06)		
Crawler	Crawler tension	Steel		mm (in)	118~128 (4.6~5.0)		118~128 (4.6~5.0)				
		Rubber			60~70 (2.4~2.8)		60~70 (2.4~2.8)				

1. TIGHTENING TORQUES FOR CAPSCREWS AND NUTS

Tables 1 and 2 indicate tightening torques applicable to cases where no special note is given.

Overtightening of bolts may result in a twist-off

and a fracture under load.

Insufficient tightening may lead to a loosening or loss of bolts. Always tighten bolts to proper torques.

Table 1 Standard tightening torques for metric coarse screw threads unit: kgf·m (ft·lbs)

Classification	4		7		10	
	No lubrication	Oil lubrication	No lubrication	Oil lubrication	No lubrication	Oil lubrication
M 6 P=1	0.45±0.05 (3.3±0.4)	0.38±0.04 (2.7±0.3)	0.98±0.1 (7.1±0.7)	0.83±0.08 (6.0±0.6)	1.77±0.18 (13±1)	1.5±0.15 (11±1)
M 8 P=1.25	1.09±0.11 (7.9±0.8)	0.92±0.09 (6.7±0.7)	2.4±0.2 (17±1)	2.0±0.2 (14±1)	4.3±0.4 (32±3)	3.6±0.4 (26±3)
M10 P=1.5	2.2±0.2 (16±1)	1.83±0.18 (13±1)	4.7±0.5 (34±4)	4.0±0.4 (29±3)	8.5±0.9 (61±7)	7.2±0.7 (52±5)
M12 P=1.75	3.7±0.4 (27±3)	3.2±0.3 (23±2)	8.1±0.8 (59±6)	6.8±0.7 (49±5)	14.6±1.5 (110±11)	12.3±1.2 (89±9)
M14 P=2	5.9±0.6 (43±4)	5.0±0.5 (36±4)	12.8±1.3 (93±9)	10.8±1.1 (78±8)	23±2 (170±14)	19.5±1.9 (140±14)
M16 P=2	9.0±0.9 (65±7)	7.6±0.7 (55±5)	19.5±2.0 (140±14)	16.4±1.6 (120±12)	35±4 (250±29)	29±3 (210±22)
M18 P=2.5	12.4±1.2 (90±9)	10.5±1.0 (76±7)	27±3 (200±22)	23±2 (170±14)	49±5 (350±36)	41±4 (300±29)
M20 P=2.5	17.5±1.7 (130±12)	14.7±1.4 (110±10)	38±4 (270±29)	32±3 (230±22)	68±7 (490±51)	57±6 (410±43)
M22 P=2.5	23±2 (170±14)	19.6±2.0 (140±14)	51±5 (370±36)	43±4 (310±29)	92±9 (670±65)	77±8 (560±58)
M24 P=3	30±3 (220±22)	24±3 (170±22)	65±7 (470±51)	53±5 (380±36)	118±12 (850±87)	96±10 (690±72)
M27 P=3	44±4 (320±29)	36±4 (260±29)	96±10 (690±72)	78±8 (560±58)	173±17 (1300±120)	140±14 (1000±100)
M30 P=3.5	60±6 (430±43)	50±5 (360±36)	131±13 (950±94)	110±11 (800±80)	235±24 (1700±170)	198±20 (1400±140)
M33 P=3.5	81±8 (590±58)	68±7 (490±51)	176±18 (1300±130)	148±15 (1100±110)	317±32 (2300±230)	266±27 (1900±200)
M36 P=4	105±10 (760±72)	88±9 (640±65)	227±23 (1600±170)	190±19 (1400±140)	409±41 (3000±300)	343±34 (2500±250)

Table 2 Standard tightening torques for metric fine screw threads unit: kgf·m (ft·lbs)

Classification	4		7		10	
	No lubrication	Oil lubrication	No lubrication	Oil lubrication	No lubrication	Oil lubrication
M 8 P=1	1.15±0.11 (8.3±0.8)	0.97±0.1 (7.0±0.7)	2.5±0.2 (18±1)	2.1±0.2 (15±1)	4.5±0.4 (33±3)	3.8±0.4 (27±3)
M10 P=1.25	2.3±0.2 (17±1)	1.91±0.19 (14±1)	4.9±0.5 (35±4)	4.2±0.4 (30±3)	8.9±0.9 (64±7)	7.5±0.7 (54±5)
M12 P=1.25	4.0±0.4 (29±3)	3.4±0.3 (25±2)	8.7±0.9 (63±7)	7.3±0.7 (53±5)	15.7±1.6 (110±12)	13.2±1.3 (95±9)
M16 P=1.5	9.4±0.9 (68±7)	7.9±0.8 (57±6)	20±2 (140±14)	17.2±1.7 (120±12)	37±4 (270±29)	31±3 (220±22)
M20 P=1.5	19±1.9 (140±14)	15.8±1.6 (110±12)	41±4 (300±29)	34±3 (250±22)	74±7 (540±51)	62±6 (450±43)
M24 P=2	32±3 (230±22)	27±3 (200±22)	70±7 (510±51)	58±6 (420±43)	126±12 (910±87)	105±10 (760±72)
M30 P=2	65±6 (470±43)	54±5 (390±36)	142±14 (1000±100)	118±12 (850±87)	255±26 (1800±190)	212±21 (1500±150)
M36 P=3	109±11 (790±80)	91±9 (660±65)	238±23 (1700±170)	198±20 (1400±140)	428±43 (3100±310)	357±36 (2600±260)

KOBELCO

Book Code No.

S5PW12^{01E②}

SHOP MANUAL

SK25SR SK30SR SK35SR

— HYDRAULIC SYSTEM —

PW12

TABLE OF CONTENTS


1. SUMMARY	
1.1 FUNCTION AND FEATURES OF HYDRAULIC CIRCUIT	1
2. HYDRAULIC CIRCUITS AND COMPONENT MODELS	2
3. OPERATIONAL EXPLANATION OF HYDRAULIC CIRCUIT	
3.1 OUTLINE FOR HYDRAULIC CIRCUIT	10
3.2 NEUTRAL CIRCUIT	11
3.3 TRAVEL OPERATING CIRCUIT	12
3.4 SLEW OPERATING CIRCUIT	13
3.5 BUCKET OPERATING CIRCUIT	14
3.6 BOOM OPERATING CIRCUIT	15
3.7 ARM OPERATING CIRCUIT	16
3.8 SWING OPERATING CIRCUIT	17
3.9 DOZER BLADE OPERATING CIRCUIT	18
3.10 TRAVEL/BOOM COMPOUND OPERATING AND TRAVEL STRAIGHT CIRCUIT	19
4. PIPING CONNECTIONS	
4.1 PILOT PIPING	20
4.2 MAIN PIPING	22



KOBE STEEL, LTD.

2.8 BREAKER SPECIFICATION

■SK35SR Applicable machines : PX05001~PX05124



No	NAME	MODEL No.
1	PUMP	AP2D18
2	CONTROL VALVE	BCV-35
3	SLEW MOTOR	MSG-27P-19
4	TRAVEL MOTOR	PHV-300
5	BOOM CYLINDER	φ 85 × φ 45 × 5751
6	ARM CYLINDER	φ 80 × φ 45 × 590
7	BUCKET CYLINDER	φ 70 × φ 40 × 4901
8	SWING CYLINDER	φ 80 × φ 45 × 476
9	DOZER BLADE CYLINDER	φ 90 × φ 45 × 150
10	SWIVEL JOINT	YV-7090A
11	PILOT VALVE	TH40M1011A
12	SOLENOID VALVE	2KWE5A-20
13	SHUTTLE VALVE	-
* 14A	MULTI CONTROL VALVE	K16AR6-11
15	RETURN FILTER	Y-25021
16	RELIEF VALVE	Y-1740
17	SUCTION STRAINER	Y-1405
18	HYDRAULIC TANK	-
19	LINE FILTER	Y-410200
20	FILTER	-
21	OIL COOLER	-
22	CHECK VALVE	LV08-35
* 23	CONTROL VALVE	BCV-35

*marked items are option.

Note: This is for reference only, because the model number might be changed due to improvement.

Fig. 7-1 Hydraulic diagram

3.8 SWING OPERATING CIRCUIT

The operation is conducted by the operation pedal which is connected to the link mechanism. The circuits for swing and arm are made in parallel.

3.8.1 Swing (left) Operating Circuit

(1) Swing Operation

At stepped down the left swing operation pedal for toe side (front side), it shifts the swing valve spool in control valve(2) through the link mechanism. Since the pilot oil pressure is not utilized for it, as same case as the dozer, it is actuated regardless to the lever lock.

(2) Main Circuit

1) Supply Circuit for Cylinder(8)

The oil discharged from the P2 port on variable pump enters into the P2 port on control valve(2). The pressurized oil came out from the A3 port through swing valve is supplied to the R side of cylinder(8) to actuate the swing (left). Because of the throttle effect provided in the passage in swing valve, the oil flow into the cylinder (8) is restricted to make the swing motion slowly and stably for both swings for leftward and rightward.




Fig. 16 Swing (left) operating circuit

1. CANOPY OR CAB (OPT)

1.1 REMOVAL AND INSTALLATION OF CANOPY ASSY

Fig. 1-1 shows the constitution of canopy assy. Carry out the removal and installation referring to Fig. 1-1 and Table 1-1.

Weight of canopy : 38kg (84lbs)

Component parts

No.	NAME	Q'TY	
		A	B
1	CANOPY	1	1
2	SUPPORT	1	1
3	SEMS BOLT	4	4
4	CAPSCREW	4	4
5	SEMS BOLT	10	5
6	HAND RAIL	1	4
7	HAND RAIL	1	4
※8	RUBBER	(1)	—
9	RUBBER	1	1
10	LOCK WASHER	4	4
11	WASHER	4	4
14	LOCK WASHER	—	4
15	WASHER	—	4
16	CAPSCREW	—	4
17	HOOK	—	1
18	RUBBER	—	1

Note 1 : For the quantity of A and B, refer to the following table for the applicable machine number.



	SK25SR	SK30SR	SK35SR
A	PV10001~10618	PW07001~07992	PX05001~05196
B	PV10619~	PW07993~	PX05197~

Note 2 : ※ No. 8 RUBBER has disused for the following machine numbers and after.


PV10239~ | PW07421~ | PX05003~

Table 1-1 Tightening torque

No.	Hex. (mm)	Torque : kgf·m (ft·lbs)
3, 5, 16	17	3.5±0.4(25±3)
4	19	6.1±0.6(44±4)



Installing position for hook



Apply Locktite #262
Install hook at illustrated direction

Fig. 1-1 Removal and installation of canopy assy

- 3) Install the bracket (A2) together with the control valve with the capscrews (A3) (A4).

● : 17mm, Tightening torque : 7.2±0.7kgf·m
(52±5ft·lbs)

- 4) Reconnect the hoses to their original positions.

Tightening torque Unit : kgf·m (ft·lbs)

Thread size	Hex (mm)	O-ring Type	30° Flare Type
PF 1/4	19	3.5±0.5 (25±4)	2.5 ^{+0.5} ₀ (18 ⁺⁴ ₀)
PF 3/8	22	5.5±0.5 (40±4)	5.0 ^{+0.5} ₀ (36 ⁺⁴ ₀)
PF 1/2	27	6.5±0.5 (47±4)	6.0 ^{+0.5} ₀ (43 ⁺⁴ ₀)
PF 3/4	26	12.0±0.5 (87±4)	12.0 ^{+0.5} ₀ (87 ⁺⁴ ₀)

- 5) Tighten up the drain plug (13).
- : 27mm, Tightening torque: 6.5±0.5kgf·m
(47±4ft·lbs)

- 6) Refill the specified hydraulic oil, and tighten the oil filling port plug (9) confirming the oil level with the oil level gauge (12).

- 7) Start up the engine keeping to open the plug (10) of hydraulic oil tank. After the engine operation for 2 to 3 minutes at low idling, operate each cylinder several times to bleed air in the lines.

- 8) Pressurize the hydraulic oil tank. Extend each cylinder up to their stroke ends to take the machine the posture shown in Fig. 5-3. While keeping this posture, tighten up the plug (10). The tank is pressurized by means of retracting the rod of cylinder while operating the attachment.

● : 22mm, Tightening torque: 3±0.3kgf·m
(22±2ft·lbs)

- 9) Again take the machine the posture shown in Fig. 5-1, and stop the engine. Reconfirm the hydraulic oil volume and no leakages on each portion.

5.3 REMOVAL AND INSTALLATION OF FUEL TANK

(1) Removal

- 1) Open the filler cap (3), and loosen the drain plug (26-2) to empty the remaining oil.
- 2) Disconnect two hoses, and plug the bores.
- 3) Disconnect the wiring for level sensor (11) at the connector.
- 4) Remove the capscrews (6) (B5) (B10) that are fixing the tank. Apply a rope to the tank to lift it up.

● : 17mm

Table 5-1 Tightening torque

No.	Hex. (mm)	Torque : kgf·m (ft·lbs)
2	55	12±1(87±7)
5	17	4.7±0.5(34±4)
10	22	3±0.3(22±2)
12	17	1.8±0.2(13±1.4)
13	27	6.5±0.5(47±4)
A3, A4	17	7.2±0.7(52±5)




Fig. 5-3 Pressuring posture for hydraulic oil tank








Fig. 5-4 Removal and installation of fuel tank




- 4) Install the plate assy with the sems bolts (26) and wing bolt (22).
 : 13mm
- 5) Fill cooling water up to the specified level.
- 6) After reconnecting the battery, operate the engine for about 10 minutes to confirm no leakages.
- 7) Install the components around the radiator assy such as covers, counterweight and so on, to their original positions.



■SK35SR (Fig. 11-2)

(1) Removal

- 1) Disconnect the radiator hoses (1) (2) (28), sub-tank hose (8) and the hydraulic oil pipings connected to the oil cooler.
- 2) Remove the wing bolt (22) and seas bolt (26), then remove the plate assy (21).
 : 13mm
- 3) Remove the capscrews (13), then remove the support (19).
 : 17mm
- 4) Apply a rope sling to the radiator assy, and give a slight tension on the rope.
- 5) Remove the capscrews (B1) that are fixing the legs portion, then lift up the radiator assy paying attention not to get touch with the shroud (18-4) and engine fan.
 Weight of radiator assy : Approx. 22kg (49lbs)
 : 17mm

(2) Installation

- 1) Lift up the radiator assy to put it to the desired position. Fix it with the capscrews (B1) confirming the evenness for the clearance against the fan and shroud. (Refer to Fig. 11-2)
 : 17mm
- 2) Install the support (19) with the capscrews (13).
 : 17mm
- 3) Reconnect the connecting hoses for the radiator and oil cooler.
- 4) Install the plate assy with the sems bolts (26) and wing bolt (22).
 : 13mm
- 5) Fill out cooling water up to the specified level.
- 6) After reconnecting the battery, operate the engine for about 10 minutes to confirm no leakages.
- 7) Install the components around the radiator assy such as covers, counterweight and so on, to their original positions.



Set-up Criteria for Fan and Shroud

Fig. 11-2 Removal and installation of radiator assy

Major component parts

No.	NAME	Q'TY	No.	NAME	Q'TY
1	HOSE	1	18	RADIATOR ASSY	1
2	HOSE	1	19	SUPPORT	1
3	SUB-TANK	1	21	PLATE ASSY	1
6	DRAIN COCK	1	22	WING BOLT	1
8	HOSE	1	25	CLIP	5
9	HOSE	1	26	SEMS BOLT	6
10	CLIP	1	28	HOSE	1
11	CLIP	4	29	TUBE	1
13	CAPSCREW	5	B1	CAPSCREW	4

1. CRAWLER

1.1 PROCEDURE FOR REMOVING AND INSTALLING RUBBER CRAWLER

(1) Removing

- 1) Loosen grease nipple (1) for crawler adjuster to loosen tension of crawler.

① : 19mm

! Use care that high-pressured grease is not spouted or the nipple is not come out by turning nipple abruptly or overloosening.

! One turn of grease nipple for adjuster is enough to discharge grease, however, if the discharge is poor, move the machine back and forth.

! The rubber crawler is an endless type. When it is confirmed that grease has been discharged and that the rubber crawler has slackened, open the grease nipples and discharge the grease till the idler is pushed to the deepest end.

- 2) Lift the one side of machine with front attachment, as shown in Fig. 2, and place square timber or equivalent under lower frame to support machine.

! When lifting up the body, adjust the angle of boom and arm to 90°~110°, and support the face of bucket bottom.

- 3) When the idler has been pushed to the deepest end, put an iron pipe in the rubber crawler, turn the sprocket backward slowly and when the rubber crawler has floated off the idler, slide it sideways and remove it.




Fig. 1 Adjusting crawler tension

PH-B83




Fig. 2 Supporting machine

PH-B83




Fig. 3 Removing rubber crawler

YRm-3-26

Weight of rubber crawler (one side)

SK25SR	117kg(260lbs)
SK30SR	123kg(270lbs)
SK35SR	135kg(300lbs)

3. LOWER ROLLER

3.1 REMOVAL AND INSTALLATION

(1) Removing

- 1) Slightly loosen capscrews fasten lower roller assy with the track frame.

● : 22mm

- 2) Loosen the crawler tension by the crawler adjuster.

● : 19mm

- 3) Lift the machine to remove the lower roller, using the front attachment and dozer blade.

- 4) After lifting the track frame to a proper level and place square wooden blocks under the lower frame to stabilize the machine.

⚠ Always place square wooden blocks so they support the front and rear lower frames, in order to stabilize the machine. Lower the front attachment on the ground, stop the engine and proceed to work.

- 5) Loosen the capscrews fastening the lower roller and remove the lower roller.

● : 22mm

Weight of lower roller assy
: about 10kg (22lbs)

(2) Installing

- 1) Coat the mounting capscrews with Loctite #262 in advance. Align the capscrews with the bolt holes and fasten them temporarily.

• Refer to Fig.32 for the fitting position depending on the kind of crawler.

- 2) Lower the machine in full contact with the ground and tighten the capscrews (2).

● : 22mm,

Tightening torque : $18.5 \pm 2 \text{ kgf}\cdot\text{m}$
($134 \pm 14 \text{ ft}\cdot\text{lbs}$)

- 3) Tighten the grease nipple of the crawler adjuster, adjust the crawler tension.

● : 19mm

Tightening torque : $6 \pm 1 \text{ kgf}\cdot\text{m}$
($43 \pm 7 \text{ ft}\cdot\text{lbs}$)




Fig. 32 Lower roller assy




Fig. 33 Supporting machine





Fig. 34 Adjusting crawler tension

- 9) Lower the hydraulic jack slowly till the spring is extended to its free length. Remove the retainer plate and take off bracket (4). Measure the free length of the spring and check it with the value given in the maintenance standard.

 : 30mm

Free length of the spring :
345mm(13.6in)

- 10) Put lifting nut (W) at the end of grease cylinder (2). Place a wire sling to it and remove with spring (3).
- 11) Remove grease cylinder (2) from spring (3).




Fig. 59 Removing retainer plate

(2) Installing

Installing is done in the reverse order of removing.


- 1) Install spring (3) to grease cylinder (2) and stand it in the center of the jig (V) upright.
- 2) Install bracket (4) on top of spring (3). Align the rod of grease cylinder (2) with the holes in bracket (4). Install the retainer plate and put four nuts. Tighten the nuts evenly all round and fix the idler adjuster assy to the jig body.


 : 30mm

- 3) Raise the hydraulic jack, compress spring (3) to a set length and tighten nut (5) to the threaded part at the end of grease cylinder (2).

Set length	Unit:mm(in)
SK25SR	296(11.7)
SK30SR	287(11.3)
SK35SR	274(10.8)

- 4) Tighten nut (5) till the holes for locking spring pin (9) are aligned. Then fit spring pin (9).

 : 36mm



PH-883

Fig. 60 Removing and installing idler adjuster assy




Fig. 61 Installing idler adjuster assy to jig body

- 4) Install plug (9) to outer race (1) confirming the direction and the position of the hole for taper pin (8).
- 5) Drive taper pin (8) and caulk the head of the taper pin with a punch.
- 6) Confirm that grease nipple (7) is normal. Apply grease (NLGI-2) and confirm that the outer race rotates smoothly.

9.3.2 MAINTENANCE STANDARD

Regarding the maintenance standard for the wear of the slewing bearing, refer to Maintenance Standard and Test Procedure and Measuring Slewing Performance that are explained in a separate manual.




Fig. 87 Fitting spacer (4), (5)

PH-B83

9.3.3 TOOLS AND JIGS

No.	ITEM	SKETCH
y	T-Bolt	<p>The sketch shows a T-bolt with a top flange of width 120 (4.7) and a total height of 90 (3.5). The stem has a diameter of 30 (1.2) and is labeled M12.</p>

2.2 CONSTRUCTION

(1) Applicable Machines ■SK25SR : PV10001~PV12000

■SK30SR : PW07001~PW09500

■SK35SR : PX05001~PX06500




Fig. 15 Construction of arm

No.	NAME	Q'TY	No.	NAME	Q'TY	No.	NAME	Q'TY
1	ARM ASSY (With Bushing and Collar)	1	6	PIN	1	12	GREASE NIPPLE	1
2	BUCKET LINK (With Bushing)	1	7	CAPSCREW M10 (Each dimension in length)	5	13	PIN	1
3	LINK(RH)	1	8	NUT M10	10	14	BUCKET CYLINDER	1
4	LINK(LH)	1	9	DUST SEAL	10	15	PIN	1
5	PIN	2	10	DUST SEAL	2	16	PIN	1
			11	GREASE NIPPLE	4	17	PIN	1
						—	SHIM(t=1.0,0.5,0.2)	SELECT

■SK30SR Applicable Machines PW09501~

Unit : mm (in)

Pos.	Item		Standard dimension		Shim adjusted clearance X (total of both sides)			Pin length		Remedy
			Code	Dimension	Standard value	Reference value for remedy	Serviceability limit	Code	Dimension	
A	Arm point	Arm	L1	122 ^{-0.2} _{-0.4} (4.803 ^{-0.008} _{-0.016})	0.1~1.0			ℓ 1	252 (9.92)	Shim adjustment
		Bucket		124 ^{+0.2} _{-1.2} (4.882 ^{+0.008} _{-0.047})						
B	Bucket link	Link side	L2	122 ^{-0.2} _{-0.4} (4.803 ^{-0.008} _{-0.016})	0.6~1.0			ℓ 2	252 (9.92)	
		Bucket		124 ^{+0.2} _{-1.2} (4.882 ^{+0.008} _{-0.047})						
C	Idler link (Connected part of arm)	Arm	L3	122 ^{-0.2} _{-0.4} (4.803 ^{-0.008} _{-0.016})	Less than 0.5 (0.020)	1.5 (0.059)	2.0 (0.079)	ℓ 3	214 (8.43)	
		Link side		- (-)						
D	Bucket link (Rod side)	Rod side	L4	45 ⁰ _{-0.5} (1.772 ⁰ _{-0.020})	0.6~1.0 (0.024-0.039)			ℓ 5	214 (8.43)	
		Link side		48 ±0.5 (1.890 ±0.020)						
	Bucket link (Idler link side)	Bucket link	L5	122 ^{+0.2} _{-0.8} (4.803 ^{+0.008} _{-0.031})						
		Idler link		- (-)						
E	Bucket cylinder (Head side)	Head side	L6	45 ⁰ _{-0.5} (1.772 ⁰ _{-0.020})	0.6~2.0	2.5 (0.098)	3.0 (0.118)	ℓ 6	112 (4.41)	
		Arm		47 ^{+1.0} ₀ (1.850 ^{+0.039} ₀)						
F	Arm foot	Arm	L7	123 ^{-0.2} _{-0.4} (4.843 ^{-0.008} _{-0.016})	Less than 0.5 (0.020)	1.5 (0.059)	2.0 (0.079)	ℓ 7	190 (7.48)	
		Boom		125 ^{+1.0} ₀ (4.921 ^{+0.039} ₀)						
G	Arm cylinder (Rod side)	Rod side	L8	50 ⁰ _{-0.5} (1.969 ⁰ _{-0.020})	0.6~2.0	2.5 (0.098)	3.0 (0.118)	ℓ 8	121 (4.76)	
		Arm		52 ^{+1.0} ₀ (2.008 ^{+0.039} ₀)						

■SK35SR Applicable Machines PX06501~

Unit : mm (in)

Pos.	Item		Standard dimension		Shim adjusted clearance X (total of both sides)			Pin length		Remedy
			Code	Dimension	Standard value	Reference value for remedy	Serviceability limit	Code	Dimension	
A	Arm point	Arm	L1	125 ^{-0.2} _{-0.4} (4.921 ^{-0.008} _{-0.016})	0.1~1.0			ℓ 1	255 (10.0)	Shim adjustment
		Bucket		127 ⁺¹ _{+0.5} (5.000 ^{+0.039} _{+0.020})						
B	Bucket link	Link side	L2	125 ^{-0.2} _{-0.4} (4.921 ^{-0.008} _{-0.016})	0.6~1.0			ℓ 2	255 (10.0)	
		Bucket		127 ⁺¹ _{+0.5} (5.000 ^{+0.039} _{+0.020})						
C	Idler link (connected part of arm)	Arm	L3	125 ^{-0.2} _{-0.4} (4.921 ^{-0.008} _{-0.016})	Less than 0.5 (0.020)	1.5 (0.059)	2.0 (0.079)	ℓ 3	221 (8.70)	
		Link side		- (-)						
D	Bucket link (Rod side)	Rod side	L4	45 ⁰ _{-0.5} (1.772 ⁰ _{-0.020})	0.6~1.0 (0.024-0.039)			ℓ 5	221 (8.70)	
		Link side		48 ±0.5 (1.890 ±0.020)						
	Bucket link (Idler link side)	Bucket link	L5	125 ^{+0.2} _{-0.5} (4.921 ^{+0.008} _{-0.020})						
		Idler link		- (-)						
E	Bucket cylinder (Head side)	Head side	L6	45 ⁰ _{-0.5} (1.772 ⁰ _{-0.020})	0.6~2.0	2.5 (0.098)	3.0 (0.118)	ℓ 6	116 (4.57)	
		Arm		47 ^{+1.0} ₀ (1.850 ^{+0.039} ₀)						
F	Arm foot	Arm	L7	130 ^{-0.2} _{-0.4} (5.118 ^{-0.008} _{-0.016})	Less than 0.5 (0.020)	1.5 (0.059)	2.0 (0.079)	ℓ 7	197 (7.76)	
		Boom		132 ^{+1.0} ₀ (5.197 ^{+0.039} ₀)						
G	Arm cylinder (Rod side)	Rod side	L8	55 ⁰ _{-0.5} (2.165 ⁰ _{-0.020})	0.6~2.0	2.5 (0.098)	3.0 (0.118)	ℓ 8	131 (5.16)	
		Arm		57 ^{+1.0} ₀ (2.244 ^{+0.039} ₀)						

■SK30SR Applicable Machines PW07001~PW09500

Unit : mm (in)

Pos.	Item		Standard dimension		Shim adjusted clearance X (total of both sides)			Pin length		Remedy
			Code	Dimension	Standard value	Reference value for remedy	Serviceability limit	Code	Dimension	
A	Boom foot	Boom	L1	$178 \begin{smallmatrix} -0.2 \\ -0.4 \end{smallmatrix} (7.008 \begin{smallmatrix} -0.008 \\ -0.016 \end{smallmatrix})$	Less than 0.5 (0.020)	1.0 (0.039)	1.5 (0.059)	l 1	275 (10.83)	Shim adjustment
		Swing bracket		$180 \begin{smallmatrix} +1.0 \\ 0 \end{smallmatrix} (7.087 \begin{smallmatrix} +0.039 \\ 0 \end{smallmatrix})$						
B	Boom cylinder (Head side)	Boom cylinder	L2	$55 \begin{smallmatrix} 0 \\ -0.5 \end{smallmatrix} (2.165 \begin{smallmatrix} 0 \\ -0.020 \end{smallmatrix})$	0.6~1.0 (0.024-0.039)	1.5 (0.059)	2.0 (0.079)	l 2	248 (9.76)	
		Swing bracket		$61 \begin{smallmatrix} +1.0 \\ 0 \end{smallmatrix} (2.402 \begin{smallmatrix} +0.039 \\ 0 \end{smallmatrix})$						
C	Arm cylinder (Head side)	Arm cylinder	L3	$50 \begin{smallmatrix} 0 \\ -0.5 \end{smallmatrix} (1.969 \begin{smallmatrix} 0 \\ -0.020 \end{smallmatrix})$	0.6~2.0 (0.024-0.079)	2.5 (0.098)	3.0 (0.118)	l 3	160 (6.30)	
		Boom		$51 \begin{smallmatrix} +1.0 \\ 0 \end{smallmatrix} (2.008 \begin{smallmatrix} +0.039 \\ 0 \end{smallmatrix})$						
D	Boom cylinder (Rod side)	Boom cylinder	L4	$55 \begin{smallmatrix} 0 \\ -0.5 \end{smallmatrix} (2.165 \begin{smallmatrix} 0 \\ -0.039 \end{smallmatrix})$	0.6~2.0 (0.024-0.079)	2.5 (0.098)	3.0 (0.118)	l 4	160 (6.30)	
		Boom		$56 \begin{smallmatrix} +1.0 \\ 0 \end{smallmatrix} (2.205 \begin{smallmatrix} +0.039 \\ 0 \end{smallmatrix})$						
※[A]	Boom foot	Boom	L1	$178 \begin{smallmatrix} -0.2 \\ -0.4 \end{smallmatrix} (7.008 \begin{smallmatrix} -0.008 \\ -0.016 \end{smallmatrix})$	0.2~0.7 (0.008-0.028) w/out Shim	1.0 (0.039)	1.5 (0.059)	l 1	302 (11.89)	
		Swing bracket		$※178 \begin{smallmatrix} +0.3 \\ 0 \end{smallmatrix} (7.008 \begin{smallmatrix} +0.012 \\ 0 \end{smallmatrix})$						
※[B]	Boom cylinder (Head side)	Boom cylinder	L2	$55 \begin{smallmatrix} 0 \\ -0.5 \end{smallmatrix} (2.165 \begin{smallmatrix} 0 \\ -0.020 \end{smallmatrix})$	0.6~1.0 (0.024-0.039)	1.5 (0.059)	2.0 (0.079)	l 2	197 (7.76)	
		Swing bracket		$※61 \begin{smallmatrix} +2 \\ 0 \end{smallmatrix} (2.402 \begin{smallmatrix} +0.079 \\ 0 \end{smallmatrix})$						

(Note) •The ※ marked Pos. [A] and [B] are applicable for the machine number PW08508~09500.

■SK35SR Applicable Machines PX05001~06500

Unit : mm (in)

Pos.	Item		Standard dimension		Shim adjusted clearance X (total of both sides)			Pin length		Remedy
			Code	Dimension	Standard value	Reference value for remedy	Serviceability limit	Code	Dimension	
A	Boom foot	Boom	L1	$178 \begin{smallmatrix} -0.2 \\ -0.4 \end{smallmatrix} (7.008 \begin{smallmatrix} -0.008 \\ -0.016 \end{smallmatrix})$	Less than 0.5 (0.020)	1.0 (0.039)	1.5 (0.059)	l 1	275 (10.83)	Shim adjustment
		Swing bracket		$180 \begin{smallmatrix} +1.0 \\ 0 \end{smallmatrix} (7.087 \begin{smallmatrix} +0.039 \\ 0 \end{smallmatrix})$						
B	Boom cylinder (Head side)	Boom cylinder	L2	$60 \begin{smallmatrix} 0 \\ -0.5 \end{smallmatrix} (2.362 \begin{smallmatrix} 0 \\ -0.020 \end{smallmatrix})$	0.6~1.0 (0.024-0.039)	1.5 (0.059)	2.0 (0.079)	l 2	242 (9.53)	
		Swing bracket		$61 \begin{smallmatrix} +1.0 \\ 0 \end{smallmatrix} (2.402 \begin{smallmatrix} +0.039 \\ 0 \end{smallmatrix})$						
C	Arm cylinder (Head side)	Arm cylinder	L3	$55 \begin{smallmatrix} 0 \\ -0.5 \end{smallmatrix} (2.165 \begin{smallmatrix} 0 \\ -0.020 \end{smallmatrix})$	0.6~2.0 (0.024-0.079)	2.5 (0.098)	3.0 (0.118)	l 3	160 (6.30)	
		Boom		$56 \begin{smallmatrix} +1.0 \\ 0 \end{smallmatrix} (2.205 \begin{smallmatrix} +0.039 \\ 0 \end{smallmatrix})$						
D	Boom cylinder (Rod side)	Boom cylinder	L4	$60 \begin{smallmatrix} 0 \\ -0.5 \end{smallmatrix} (2.362 \begin{smallmatrix} 0 \\ -0.020 \end{smallmatrix})$	0.6~2.0 (0.024-0.079)	2.5 (0.098)	3.0 (0.118)	l 4	160 (6.30)	
		Boom		$61 \begin{smallmatrix} +1.0 \\ 0 \end{smallmatrix} (2.402 \begin{smallmatrix} +0.039 \\ 0 \end{smallmatrix})$						
※[A]	Boom foot	Boom	L1	$178 \begin{smallmatrix} -0.2 \\ -0.4 \end{smallmatrix} (7.008 \begin{smallmatrix} -0.008 \\ -0.016 \end{smallmatrix})$	0.2~0.7 (0.008-0.028) w/out Shim	1.0 (0.039)	1.5 (0.059)	l 1	302 (11.89)	
		Swing bracket		$※178 \begin{smallmatrix} +0.3 \\ 0 \end{smallmatrix} (7.008 \begin{smallmatrix} +0.012 \\ 0 \end{smallmatrix})$						
※[B]	Boom cylinder (Head side)	Boom cylinder	L2	$60 \begin{smallmatrix} 0 \\ -0.5 \end{smallmatrix} (2.362 \begin{smallmatrix} 0 \\ -0.020 \end{smallmatrix})$	0.6~1.0 (0.024-0.039)	1.5 (0.059)	2.0 (0.079)	l 2	197 (7.76)	
		Swing bracket		$※61 \begin{smallmatrix} +2 \\ 0 \end{smallmatrix} (2.402 \begin{smallmatrix} +0.079 \\ 0 \end{smallmatrix})$						

(Note) •The ※ marked Pos. [A] and [B] are applicable for the machine number PX05601~06500.

■SK25SR Applicable machines : PV10927~PV12000

Unit : mm (in)

No.	Item	Pin parts No.	Standard dimension			Clearance			Remedy
			Pin dia	Tolerance on pin dia	Tolerance on bushing bore dia	Standard value	Reference value for remedy	Serviceability limit	
A	Swing cylinder (Rod side)	PM02B01156P1	φ 35 (φ 1.3780)	-0.050~ -0.075 (-0.0020~ -0.0030)	+0.25~ +0.05	0.10~0.33 (0.0039~ 0.0130)	1.0 (0.04)	1.5 (0.06)	Replace bushing or pin
B	Swing cylinder (Head side)	PM02B01117P1		-0.06~ -0.09 (-0.0024~ -0.0035)	(+0.0098~ +0.0020)	0.11~0.34 (0.0043~ 0.0134)			
C1	Swing center (Upper side)	PV02B01170P1	φ 60 (φ 2.3622)	-0.030~ -0.060	+0.17~ +0.06	0.09~ 0.23			
C2	Swing center (Lower side)	PW02B01142P1		(-0.0012~ -0.0024)	(+0.0067~ +0.0024)	(0.0035~ 0.0091)			

(Note) •The tolerance for bushing inside diameter means the dimension after insertion of it into the place.

•The part number for pins may be changed due to improvement, use them only for reference.

■SK30SR Applicable machines : PW07001~PW08507

■SK35SR Applicable machines : PX05001~PX05600

Unit : mm (in)

Pos.	Item	Pin parts No.	Standard dimension			Clearance			Remedy
			Pin dia	Tolerance on pin dia	Tolerance on bushing bore dia	Standard value	Reference value for remedy	Serviceability limit	
A	Swing cylinder (Rod side)	PW12B01055D5	φ 45 (φ 1.7717)	-0.06~ -0.09	+0.20~ +0.05	0.11~ 0.29	1.0 (0.04)	1.5 (0.06)	Replace bushing or pin
B	Swing cylinder (Head side)	PW02B01079P1			(+0.0079~ +0.0020)	(0.0043~ 0.0114)			
C1	Swing center (Upper side)	PW02B01076D2	φ 60 (φ 2.3622)	(-0.0024~ -0.0035)	+0.17~ +0.06	0.12~ 0.26			
C2	Swing center (Lower side)	PW02B01076D1		(+0.0028~ +0.0024)	(0.0047~ 0.0102)				

(Note) •The tolerance for bushing inside diameter means the dimension after insertion of it into the place.

•The part number for pins may be changed due to improvement, use them only for reference.

■SK30SR Applicable machines : PW08508~PW09500

■SK35SR Applicable machines : PX05601~06500

Unit : mm (in)

Pos.	Item	Pin parts No.	Standard dimension			Clearance			Remedy
			Pin dia	Tolerance on pin dia	Tolerance on bushing bore dia	Standard value	Reference value for remedy	Serviceability limit	
A	Swing cylinder (Rod side)	PW02B01136P1	φ 45 (φ 1.7717)	-0.050~ -0.075 (-0.0020~ -0.0030)	+0.20~ +0.05	0.10~0.28 (0.0039~ 0.011)	1.0 (0.04)	1.5 (0.06)	Replace bushing or pin
B	Swing cylinder (Head side)	PW02B01079P1			(+0.0079~ +0.0020)	0.11~0.29 (0.0043~ 0.0114)			
C1	Swing center (Upper side)	PW02B01133P2	φ 60 (φ 2.3622)	-0.030~ -0.060	+0.17~ +0.06	0.09~ 0.23			
C2	Swing center (Lower side)	PW02B01142P1		(-0.0012~ -0.0024)	(+0.0028~ +0.0024)	(0.0035~ 0.0091)			

(Note) •The tolerance for bushing inside diameter means the dimension after insertion of it into the place.

•The part number for pins may be changed due to improvement, use them only for reference.

(2) Installation of Cylinder

- 1) Replace the worn-out pins and bushing and the dust seal at every removal to new one referring to the "Maintenance Standard" for each section of boom, swing and dozer blade. For the installing direction of dust seal, refer to "How to fix Dust Seal" in "Construction" of each section.
- 2) Check the clearance for thrust direction on attaching portion of each pin to determine the thickness of shim, referring to aforesaid "Maintenance Standard."
 - Preliminary carry out the adjustment for the clearance with a resin shim. then insert an iron shim.
- 3) Lift up the cylinder applying a rope to the center of gravity, and align pin bore on the head side cylinder.

⚠ When aligning the pin bore, do it visually, and never put finger into the bore.

- 4) Apply grease on the shims whose thickness was determined by the above 2) and pin, then insert them, and install the loose-out prevention capscrew and nuts. (Refer to Fig. 40)

🔧 : 17mm

- 5) Align the bore on rod side cylinder, apply grease on the connecting pin, insert it into the place, then install the loose-out prevention capscrew and nuts. For the head side boom cylinder, install the loose-out prevention plate and tighten it with two capscrews.

🔧 : 17mm, 19mm

- 6) Connect the hydraulic hose to the cylinder.

🔧 : 19mm, 22mm

Tightening Torque Unit : kgf·m (ft·lbs)

Thread Size	Hex. mm	O-ring Type	30° Flare Type
PF 1/8	—	2.0±0.2 (14±1)	1.0 ^{+0.5} / ₀ (7 ⁺⁴ / ₀)
PF 1/4	19	3.5±0.5 (25±4)	2.5 ^{+0.5} / ₀ (18 ⁺⁴ / ₀)
PF 3/8	22	5.5±0.5 (40±4)	5 ^{+0.5} / ₀ (36 ⁺⁴ / ₀)
PF 1/2	27	6.5±0.5 (47±4)	6 ^{+0.5} / ₀ (43 ⁺⁴ / ₀)

- 7) Tighten the air drain plug on hydraulic oil tank.

Tightening torque : 3.0±0.3kgf·m(22±2ft·lbs)




Fig. 39 Section at cylinder installing portion





Fig. 40 Tightening procedure for nuts

(19) Antenna (Spec. by country)

The antenna is contained in the left rear cab. The antenna can be extended to 60cm over from the cab, so contract it during transportation, etc. to prevent it from breaking.

(20) Monitor panel display


(21) Engine coolant temperature



This indicates the temperature of engine coolant. While operating, if the indicating needle is in the range of white zone, it is in normal condition.


If the needle indicates in the range of red zone, change the engine to low idling and wait until the needle indicates in the range of white zone.

(22) Fuel level gauge



This shows the remainder of fuel tank. The indication may move up after a while from the key switch ON. This phenomenon does not mean the failure.

(23) Hour meter




This indicates the total cumulative operating time of engine. The hour meter advances if the engine only is operating even though the vehicle does not move.

While the engine is rotating, the operation pilot lamp on the meter section indicates that the meter is advancing.

It operates on the operating time of the alternator regardless of the engine speed. Regard it as a reference for inspection and maintenance.


(24) Fuel level alarm lamp



When the remaining fuel level in the fuel tank arrives at about 10%, the lamp lights for 30 seconds and then the alarm buzzer sounds for 10 seconds.

Replenish fuel before fuel is exhausted.

(25) Engine hydraulic pressure lamp



This warns that there is an abnormal drop of engine lubricating oil pressure.

When the lamp lights up, stop the engine and check for the engine oil level.

(26) Battery charge lamp



This battery charge lamp lights up by the starter switch "ON", and after starting engine the lamp goes off when the battery starts charging.

If the lamp does not go off after a while from the engine starting, check the charging system.

(27) Engine coolant temperature lamp



This warns that the engine coolant temperature is in the range of red zone. When the lamp goes on, stop operation immediately, change the engine speed to idling, wait until the temperature lowers to the range of white zone, stop the engine, then check for the coolant level, tension of fan belt, and on radiator core for clogging, etc.


(28) 2nd-speed travel lamp



This indicates that the travel speed change switch is placed on the high speed side.

The travel speed selector switch is located on the grip of the right travel lever. The speed automatically returns to low (1st.) speed when the starter switch is set to "OFF".

(29) Glow lamp



If you turn the starter switch to "HEAT", the glow lamp lights, whereupon the air heater of the engine is heated.

(For others, refer to Starting the Engine.)

(30) Air cleaner clog lamp



This warns that the element of air cleaner is clogged. When the lamp lights up, stop the engine and check or clean the element.


(3) Deceleration control

■ SK35SR

Applicable machines: PX05001 ~ 05600

When the decel (deceleration) switch on the monitor panel is pushed down, the decel relay is excited, and the decel (governor) motor (6) is actuated. The inner cable of cable (6A) acts to link lever (5B) to rotate it to rightward making the pin (5C) as the fulcrum (Fig. 12 Details F). Then the outer casing of control cable (2) that is attached to the link lever (5B) with two nuts, moves to rightward together with the inner cable, and the control lever of governor is moved to decel side (low idling side), leaving the throttle lever at its original position.

When the decel switch is again pushed down, the decel relay is de-excited, and the motor moves to return direction to release the deceleration.



DETAIL F

No.	NAME	Q'TY	No.	NAME	Q'TY
1	THROTTLE LEVER	1	5B	LINK LEVER	(1)
2	CONTROL CABLE	1	5C	PIN	(1)
4	CONTROL LEVER (E/G side)	(1)	6	DECEL MOTOR	1
5	LINK ASSY	1	6A	DECEL MOTOR CABLE	(1)
5A	BRACKET	(1)			

CAPSCREW (M6)
Tightening torque : 0.45±0.05kgf·m(3.3±0.4ft·lbs)




Fig. 11 Link assy




Fig. 12 Deceleration control

KOBELCO

Book Code No.

S5PW25_{01E①}

SHOP MANUAL

SK25SR SK30SR SK35SR

ELECTRIC SYSTEM

TABLE OF CONTENTS

1. HOW TO READ CIRCUIT DIAGRAM AND HARNESS CONNECTION	1
2. ELECTRIC CIRCUIT DIAGRAM	2
3. HARNESS ASSY (FOR MAIN)	
3.1 COMPONENTS ARRANGEMENT	3
(1) UPPER FRAME PORTION	3
(2) ENGINE PORTION	5
(3) CONSOL BOX & RELAY UNIT PORTION	7
3.2 HARNESS	8
4. HARNESS ASSY (FOR RELAY ASSY)	
4.1 COMPONENTS ARRANGEMENT	15
4.2 HARNESS	18
5. HARNESS FOR CAB (OPTION)	21
6. BOOM WORK LIGHT	22
7. CAB WORK LIGHT (OPTION)	22
8. POWER SOURCE (EUROP. SPEC.ONRY)	23

PW2

 **KOBE STEEL, LTD.**

MAIN HARNESS CONNECTION TABLE
(SK25SR · SK30SR)



番号 WIRE NO	線色 WIRE COLOR	線径・サイズ WIRE SIZE	FROM	接続 CONNECTION	TO	機能 FUNCTION
2A	Y	AVSS0.75sq	CN-305F	—————	CN-322F	FUSE-BOX → DECEL RELAY
2B	Y	AVSS0.75sq	CN-301F	—————	CN-332F	FUSE-BOX → TRAVEL LOCK MOTOR
3	RW	AVSS0.75sq	CN-301F	—————	CN-331F	FUSE-BOX → DECELE MOTOR
5A	RL	AVS2sq	CN-303F	—————	CN-340F	FUSE-BOX → J/C-GREEN
5B	RL	AVSS0.75sq	CN-306F	—————	CN-340F	E/G STOP SOL ← J/C-GREEN
5C	RL	AVSS0.75sq	CN-321F	—————	CN-340F	TIMER UNIT ← J/C-GREEN
5D	RL	AVS2sq	CN-320F	—————	CN-340F	E/G STOP RELAY ← J/C-GREEN
6A	WG	AVSS0.75sq	CN-301F	—————	CN-340F	FUSE-BOX → J/C-GREEN
6B	WG	AVSS0.75sq	CN-323F	—————	CN-340F	SAFETY RELAY ← J/C-GREEN
6C	WG	AVSS0.75sq	CN-306F	—————	CN-340F	ALTERNATOR ← J/C-GREEN
8	R	AVS8sq	CN-334F	—————	CN-327M	SAFETY RELAY → FUSIBLE LINK
9	R	AVS8sq	CN-327M	—————	CN-304M	FUSIBLE LINK → ALTERNATOR
11	WY	AVSS0.75sq	CN-323F	—————	CN-306F	SAFETY RELAY → ALTERNATOR
13	BW	AVSS0.75sq	CN-301F	—————	CN-323F	KEY SW → SAFETY RELAY
14	W	AVS3sq	CN-304M	—————	CN-334F	STARTER MOTOR → SAFETY RELAY
15A	Y	AVSS0.75sq	CN-326F	DOUBLE SPLICE	CN-321F	DIODE ← TIMER UNIT
15B	Y	AVSS0.75sq	CN-320F	—————	CN-321F	E/G STOP RELAY ← TIMER UNIT
16A	RW	AVSS0.75sq	CN-326F	DOUBLE SPLICE	CN-321F	DIODE ← TIMER UNIT
16B	RW	AVSS0.75sq	CN-320F	—————	CN-321F	E/G STOP RELAY → TIMER UNIT
17	PB	AVSS0.75sq	CN-301F	—————	T-2	HORN SW → HORN
33	O	AVSS1.25sq	CN-301F	—————	F-3	LIGHT RELAY → WORK LIGHT
39A	Sd	AVSS0.75sq	CN-301F	DOUBLE SPLICE	CN-328F	CONTROL CUT LS (LEFT) → CONTROL CUT SOL
39B	Sd	AVSS0.75sq	CN-301F	—————	CN-324F	CONTROL CUT LS (LEFT) → TRAVEL LOCK RELAY
41	Brw	AVSS0.75sq	CN-301F	—————	CN-329F	TRAVEL 2-SPEED RELAY → TRAVEL 2-SPEED SOL
45	BW	AVSS0.75sq	CN-302M	—————	F-1	CLUSTER GAUGE → TRAVEL 2-SPEED SW
46	WB	AVSS0.75sq	CN-302M	—————	F-2	CLUSTER GAUGE → TRAVEL 2-SPEED SW
47	L	AVS5sq	CN-303F	—————	CN-304M	KEY SW → AIR HEATER
48	LgB	AVSS0.75sq	CN-302M	—————	CN-306F	CLUSTER GAUGE ← ALTERNATOR
50	GB	AVSS0.75sq	CN-302M	—————	CN-306F	CLUSTER GAUGE ← HYD. SW
51	YB	AVSS0.75sq	CN-302M	—————	CN-306F	CLUSTER GAUGE ← E/G THERMO SW
52	YR	AVSS0.75sq	CN-302M	—————	CN-306F	CLUSTER GAUGE ← E/G THERMO SENSOR
53	RG	AVSS0.75sq	CN-302M	—————	CN-306F	CLUSTER GAUGE ← AIR CLEANER ALARM SW
55	YW	AVSS0.75sq	CN-305F	—————	CN-101F	FUSE-BOX ← FUEL SENSOR
56	YG	AVSS0.75sq	CN-302M	—————	CN-101F	CLUSTER GAUGE ← FUEL SENSOR
60	GL	AVSS0.75sq	CN-322F	—————	CN-331F	DECELE RELAY → DECELE MOTOR
61	LB	AVSS0.75sq	CN-302M	—————	CN-322F	CLUSTER GAUGE → DECELE RELAY
63	BY	AVSS0.75sq	CN-322F	—————	CN-331F	DECELE RELAY → DECELE MOTOR
64	L	AVSS0.75sq	CN-322F	—————	CN-331F	DECELE RELAY → DECELE MOTOR
65	GL	AVSS0.75sq	CN-324F	—————	CN-332F	TRAVEL LOCK RELAY → TRAVEL LOCK MOTOR
66	BY	AVSS0.75sq	CN-324F	—————	CN-332F	TRAVEL LOCK RELAY → TRAVEL LOCK MOTOR
67	L	AVSS0.75sq	CN-324F	—————	CN-332F	TRAVEL LOCK RELAY → TRAVEL LOCK MOTOR
70	R	AVS2sq	CN-320F	—————	CN-304M	E/G STOP RELAY → E/G STOP SOL
75	RW	AVSS0.75sq	CN-305F	—————	CN-328F	COOLER → POWER SHIFT SOL

CONNECTORS SELECTION TABLE

番号 WIRE NO	線色 WIRE COLOR	線径・サイズ WIRE SIZE	FROM	接続 CONNECTION	TO	機能 FUNCTION
E1	B	AVSS1.25sq	CN-305F	—————	CN-340F	INST-HARNESS → J/C-GREEN
E2	B	AVSS0.75sq	CN-321F	—————	CN-340F	TIMER UNIT → J/C-GREEN
E3	B	AVSS0.75sq	CN-323F	—————	CN-340F	SAFETY RELAY → J/C-GREEN
E6	B	AVSS0.75sq	CN-101F	—————	CN-340F	FUEL SENSOR → J/C-GREEN
E7	B	AVSS0.75sq	CN-306F	—————	CN-340F	AIR CLEANER ALARM SW → J/C-GREEN
EB	B	AVSS0.75sq	CN-328F	DOUBLE SPLICE	P-4	CONTROL CUT SOL → BODY EARTH
E9	B	AVSS0.75sq	CN-329F	—————	P-4	TRAVEL 2-SPEED SOL → BODY EARTH
E10	B	AVS1.25sq	M-1	—————	CN-340F	WORK LIGHT → J/C-GREEN
E12	B	AVS3sq	P-2	DOUBLE SPLICE	CN-305F	BODY EARTH ← INST HARNESS
E13	B	AVS2sq	P-2	—————	CN-306F	BODY EARTH ← E/G STOP SOL
E14	B	AVSS1.25sq	P-1	DOUBLE SPLICE	CN-340F	BODY EARTH ← J/C-GREEN
E15	B	AVSS1.25sq	P-1	—————	CN-340F	BODY EARTH ← J/C-GREEN
E16	B	AVSS1.25sq	CN-302M	—————	CN-340F	INST HARNESS → J/C-GREEN
E17	B	AVSS0.75sq	CN-331F	—————	CN-340F	DECELE MOTOR → J/C-GREEN
E5	B	AVSS0.75sq	T-1	DOUBLE SPLICE	P-3	HORN → BODY EARTH
E18	B	AVSS0.75sq	CN-332F	—————	P-3	TRAVEL LOCK MOTOR → BODY EARTH
E19	B	AVSS0.75sq	CN-324F	—————	CN-340F	TRAVEL LOCK RELAY → J/C-GREEN
E20	B	AVSS0.75sq	CN-328F	—————	CN-340F	POWER SHIFT SOL → J/C-GREEN

コネクタ名 (ピン数) CONNECTOR NAME (PIN NUM.)	メーカー MANUFUC.	部品番号 (PART. NUMBER)				
		ハウジング HOUSING	ターミナル TERMINAL	ハーネスシール HARNESS SEAL	リターナ ドックプレート LOCK PLATE	ワメ性 SEALING PULG
2PAF-HW	SUMITOMO	6189-0129	1500-0106	7165-0118	6918-0322	7161-9787
2PAF-090	SUMITOMO	6180-2321	1500-0110	7160-8234		
2PAM-090	SUMITOMO	6187-2311				
2PAF-D	YAZAKI	7123-6026-60	7116-2871		7157-6222-50	
2PAF-L(BLUE)	YAZAKI	7123-4129-90	7116-3251		7157-6421-80	
			7116-3250			
2PAF-L(RED)	YAZAKI	7123-4125-50	7116-3251		7157-6421-80	
			7116-3250			
2PAM-L	YAZAKI	7122-4125-50	7114-3250		7157-6420-80	
3PAF-090H	SUMITOMO	6180-3261	1500-0110	7160-8234	7160-9465	
4PAF	YAZAKI	7123-2446	7116-2090			
4PAM-312	YAZAKI	7282-3040	7114-6041			
			7114-6042			
4PAF-X	YAZAKI	7123-6244-40	7116-2873	7157-3570	7157-6740-30	
4PAF-P&B	P&B AMP	VCF7-1000	280756-4			
			42281-1			
5PAM-P&B	P&B PACKARD	VCF4-1003	12015865			
6PAF	YAZAKI	7123-2262	7116-2092			
			7116-2020			
6PAF-X	YAZAKI	7219-3460	7116-1050	7157-3290		7157-9740
6PAM-BS	YAZAKI	7118-3460	7187-3290			7157-9740
10PAF	YAZAKI	7123-2800	7116-2090			
CA104	YAZAKI	7120-8012	7113-1020			
CB104	YAZAKI	7120-1010	7115-1050			
CB104-L	YAZAKI	7120-2010	7115-2020			
J/C-GREEN	SUMITOMO	6400-0013	8240-4422			
		6409-0072				

(5) CASE OF COOLER SPEC. (OPT)




No.	NAME	Q'ty	REMARKS
B1	INST. HARNESS	1	
B2	HARNESS (FOR SAFETY RELAY)	1	
B3	HARNESS (FOR HEATER SW.)	1	HEATER SPEC.
B4	HARNESS (FOR WIPER & RADIO)	1	CAB SPEC.
B6	JAMPER CONNECTOR	1	CAB SPEC.
C3	HARNESS (FOR COOLER)	1	COOLER SPEC.

1. OUTLINE

Troubleshooting provides process locating for the cause of trouble in the order that trouble occurred. This manual describes how to solve the specific phenomenon systematically as early as possible. For troubleshooting concerning the inside of equipment, refer to troubleshooting for each manual of equipment.

1.1 JUDGMENT OF ACTUAL THING AT SITE

- (1) Get to the site as quickly as possible.
Verify model, serial number, situation of trouble and field, and notify person of arrival time.
- (2) Verify background of trouble occurred.
 - 1) Model name and serial number
 - 2) Kind of attachment
 - 3) Operating time by hour-meter
 - 4) History of trouble occurred and additional works
 - 5) Recurrence of past trouble, or problems on the additional works
- (3) How to diagnose trouble
 - 1) Verify defective part.
 - 2) Make the condition of trouble again.
 - 3) Where defective parts can not be verified, surmise causes systematically.
 - 4) Verify reasons for surmise.
 - 5) Report methods, procedure, and period for repairing to user.
- (4) Explanation of the cause of trouble
 - 1) Explain the cause of trouble to clients. For example, oil leak through piston is caused by flaws on the piston rod. And the method of using the machines should be explained so that the same kind of trouble does not reoccur.
 - 2) Treatment of damaged parts
The damaged parts to be claimed and returned are evidence so they should be handled with care. Protect them from entry of water, soils, etc. into port of hydraulic unit, etc. and return them. And also use care not to flaw and damage those surfaces.



Attending the field to verify actual thing.

YR-B76



Verifying background of trouble occurred.

YR-B76




Diagnosing failure by means of troubleshooting.

YR-B76

3.4 SLEWING SYSTEM


(11) Slewing operation is unavailable.

Basic concept ;First of all, think that only the slewing action is out of order or that the arm action is out of order. Secondly, if only the slewing action is impossible, confirm that abnormally worn metallic particles are present in the hydraulic oil return filter.



(12) Slewing speed is slow.

Basic concept ;If the speed is low, it means that the flow rate is lower than standard; check to see that the oil flow to the slewing motor is low or that standard flow is utilized effectively by the slewing motor.



2. CONSTRUCTION AND OPERATION

2.1 CONSTRUCTION

■SK25SR




Fig. 2-1 Pump

No.	NAME	Q'TY	No.	NAME	Q'TY
100	DRIVE SHAFT SECTION	1	500	CONTROL SPRING SECTION	1
200	HANGER SECTION	1	600	CONTROL PISTON SECTION	1
300	ROTARY GROUP SECTION	1	700	GEAR PUMP SECTION	1
400	COVER SECTION	1	800	HOUSING SECTION	1

3. REMOVAL AND INSTALLATION

3.1 TOOLS AND JIGS

(1) Tools


NAME	Q'TY	NOMINAL DIMENSION	NAME	Q'TY	NOMINAL DIMENSION
Allen wrench	each 1	HEX 3,5,6,8,10	Screw driver	2	Medium size
Spanner	1	HEX 17	Torque wrench	—	For the specified torque.
Plastic hammer	1	Medium size	Grease	small Q'TY	
Snap ring plier	1	For hole (Snapping 72)	Adhesive	small Q'TY	Loctite #270
Snap ring plier	1	For shaft (Snapping 28, 30)			

(2) Jigs

1) Work bench for removal and installation

This is a plate to put the pump downward. If the shaft ends don't contact it, square timber or an equivalent can be used to replace it.

2) Bearing built in jig




PY-884

3.2 REMOVAL AND INSTALLATION

3.2.1 GENERAL PRECAUTIONS

- (1) Before removing, clarify the purpose and understand fully the internal structure of pump.
- (2) After the oil in the pump has been drained, clean the pump, remove or install it on the work bench on rubber mat is placed. Then select proper tools, take care not to damage parts while working and take measures to prevent the entry of foreign matter.





PY-884

3.2.2 REMOVAL

⚠ Precautions

- 1) Do not adjust the adjusting screw, unless otherwise required. The movement of adjusting screw changes the setting horse power.
 - 2) While removing, take care not to damage any part.
- (1) Removing gear pump.
 - 1) Remove two socket bolts (736) M10×25 and remove gear pump (700).


 : 8mm



PY-884

(7) Install seal casing (102) with oil seal (107) in housing (800) straight along axis.


● Apply grease on oil seal lip.



102
Fig. 53 Installing casing (102)

PY-BB4


(8) Fix snap ring (109) to housing (800) and fix shaft (101).



109
800
Fig. 54 Fixing snap ring (109)

PY-BB4


(9) Install pistons (301) in retainer (304) of rotary group (300).



301
304
Fig. 55 Installing piston (301)

PY-BB4

(10) Apply grease on three parallel pins (308), fit it in the cylinder block (302).



308
302
Fig. 56 Fitting parallel pin (308)

PY-BB4

KOBELCO

Book Code No.

S5 12039_{7E}

SHOP MANUAL

Applicable Model :
SK30SR

— HYDRAULIC PUMP —


12

TABLE OF CONTENTS

1. SPECIFICATION	
1.1 General View	1
1.2 Specification	1
2. CONSTRUCTION AND OPERATION	
2.1 Construction	2
2.2 Operation	4
3. REMOVAL AND INSTALLATION	
3.1 Removal	6
3.2 Installation	10
4. MAINTENANCE STANDARDS	
4.1 Check and Measurement	15
5. TROUBLESHOOTING	16


 **KOBE STEEL, LTD.**

b. Remove the front cover (101).




c. Remove the bushing (111).


d. Remove the drive gear (103) and driven gear (104).




e. Remove the gear case (102).



f. Remove the gear case (105).



g. Remove the bushing (111), drive gear (107) and driven gear (108).



1. SPECIFICATION

1.1 GENERAL VIEW





Fig. 1

No.	PORT NAME	SIZE
A3	Dozer blade & Slewing delivery port	PF1/2
P4	Pilot delivery port	PF3/8
S5	Suction port	-



HYDRAULIC CIRCUIT


PY-884


1.2 SPECIFICATIONS

Table 1

Item	Type	Specification 1		Specification 2	
		SK25SR		SK35SR	
Applicable Model		SK25SR		SK35SR	
Type of each single pump		GSP2-08	G1-04	GSP2-12	G1-04
Working pressure	kgf/cm ² (psi)	180(2,560)	40(570)	180(2,560)	40(570)
Displacement capacity	cc/rev(cu·in/rev)	8.6(0.52)	4.5(0.27)	12.1(0.74)	4.5(0.27)
Amount of delivery	ℓ/min(gal/min)	20.2(5.3)	10.6(2.8)	28.4(7.5)	10.6(2.8)
Rated revolution	rpm	2,350		2,350	

21) Install gear pump (GSP2) to gear pump (G1) with four cap screws M10 (735).


 : 17mm, Tightening torque: 6kgf·m
(43ft·lbs)



PY-884

Fig. 33 Installing the gear pumps


22) Fit O ring (739) to front frame (720).



PY-884

Fig. 34 Fitting O ring (739)

(7) TRAVEL (RIGHT) ASSY (SECTION F-F)



No.	Tightening torque kgf·m(ft·lbs)
8	0.4~0.5(2.9~3.6)
13	0.6~0.7(4.3~5.1)
15	
12	4(29)

Fig. 9 Apply Locktite #270

No.	NAME	Q'TY	No.	NAME	Q'TY	No.	NAME	Q'TY
1	BODY	1	7	SPRING	1	13	SOCKET BOLT	2
2	SPOOL	1	8	SPOOL END	1	14	COVER	1
3	O-RING	2	9	POPPET (CHECK VALVE)	1	15	SOCKET BOLT	2
4	DUST WIPER	2	10	SPRING	1	16	PLUG	2
5	SEAL PLATE	2	11	O-RING	1			
6	SPRING SEAT	2	12	PLUG	1			

(8) SUPPLY & TRAVEL STRAIGHT ASSY (SECTION G-G)




Fig. 10

No.	Tightening torque kgf·m(ft·lbs)
4	0.5~0.6(3.6~4.3)
18	0.6~0.7(4.3~5.1)
5	0.8~1.0(5.8~7.2)
R1	4(29)

No.	NAME	Q'TY	No.	NAME	Q'TY	No.	NAME	Q'TY
1	BODY	1	7	SPRING	2	13	SPRING	1
2	SPOOL	1	8	POPPET (CHECK VALVE)	2	14	STOPPER	1
3	STEEL BALL	1	9	FILTER CASE	1	15	O-RING	2
4	PLUG	1	10	O-RING	1	16	COVER	1
5	PLUG	2	11	FILTER	1	17	COVER	1
6	O-RING	2	12	RETAINING RING	1	18	SOCKET BOLT	4

*Main relief valve(R1) is included in overall component parts.

3.3 REMOVAL


3.3.1 Pulling off Procedures for Spool

- Precaution for Replacement of Spool

If replacement of spool is required, do not remove the spool, but replace it to new one at assembly.


Put the valve on the working bench making the cylinder port upwards.

(A) In case of Hydraulic Pilot Changeover Type (based on Fig. 2 Slewing spool, Section B-B for an example - Fig. 29)

- 1) Remove the two socket bolts (14).
 : 4mm
- 2) Remove the cover (13).
- 3) Remove the spool assy from the body (1) by means of pulling the spring (4) for axial direction.


- At that time, confirm that if the O-ring (11) is left at the bottom of the cover (12) in opposite side.

(B) In case of Manual Changeover Type (based on Fig. 2 Dozer spool, Section A-A for an example - Fig. 30)

- 1) Remove two socket bolts (15).
 : 4mm
- 2) Remove the cover (14).
- 3) Remove the spool assy from the body (1) by means of pulling the spring (4) for axial direction.

- At that time, pay special attention not to damage the lip of spool seal [dust wiper (4) and O-ring (3)] of the opposite side. Because the spool seal tends to move to the spool edge.

(C) In case of Travel Straight Spool (based on Fig. 2 Supply & travel straight assy, Section G-G for an example - Fig. 31)

- 1) Remove two socket bolts (18).
 : 4mm
- 2) Remove the cover (17).
- 3) Remove the spring (13) and stopper (14).
- 4) Holding the edge of the spool, pull off the spool assy (2~4) from the body (1).
 - At that time, confirm that if the O-ring (15) is left in the place.
- 5) Remove the bolt (18) of the opposite side.
- 6) When the cover (16) is removed, the filter case assy (9~12) is now possible to remove.




Fig. 29 Slewing spool (hydraulic pilot changeover type)




Fig. 30 Dozer spool (manual changeover type)




Fig. 31 Supply & travel straight parts

5.2 RELIEF VALVE

The relief valve is the most important parts in terms of function and safety. Since it is extremely difficult to reset the pressure of it, always replace the assy in case such faults as shown below should occur.

Trouble	Cause	Remedy
1. No pressure rise at all.	Plunger of each relief valve The poppet is stuck and left open or dirt is included in the valve seat.	<ul style="list-style-type: none"> • Check for foreign matter on each valve. • Make sure that each part slides freely.
2. Unstable relief pressure.	Damaged poppet of relief valve. Piston sticks against plunger valve.	<ul style="list-style-type: none"> • Replace damaged parts. • Clean all parts thoroughly. • Smooth surface damage.
3. Irregular relief pressure.	1) Wear due to foreign matter. 2) Loosened lock nut or adjusting screw. <ul style="list-style-type: none"> • Broken or deformed spring. 3) Malfunctioning relief valve and port relief valve. Refer to item 1. 1) above.	1) Replace assy 2) Adjust pressure. <ul style="list-style-type: none"> • Replace assy 3) Measure port relief valve and port relief valve pressure. Refer to item 1. 1) above.
4. Oil leak.	1) Damaged seat. Worn out O ring. 2) Sticking component due to foreign matter.	1) Replace damaged or worn component. Confirm that each component operates smoothly before reassembling. 2) Confirm that there are no scratches, scores, or foreign matter present before installing.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

4. MAINTENANCE STANDARDS

4.1 PARTS REPLACEMENT STANDARD

- 1) Replace O rings and other seals at each removal and installation.
- 2) Replace worn parts if leaks affects the operating system.
- 3) Replace spools having excessive wear on their moving areas.
- 4) Replace a push rod that is worn to 1mm (0.04in) or over on its top end. (See Fig. 12.)
- 5) Replace operating lever and pins that have a gap of 2mm (0.08in) or over.
- 6) Replace such parts that arise abnormal sounds, hunting and drops in the primary pressure.




Fig. 12 Wear of push rod

5. TROUBLESHOOTING

Trouble	Cause	Remedy
Secondary pressure does not rise.	<ol style="list-style-type: none"> 1) Primary pressure is insufficient. 2) Springs (241-1, 241-2) are broken or fatigued. 3) Clearance between spool (201-1, 201-2) and valve body (101) is abnormally large. 4) Lever has a gap. 	<ol style="list-style-type: none"> 1) Secure primary pressure. 2) Replace with new ones. 3) Replace assembly. 4) Disassembly and reassembly or replace lever section.
Secondary pressure is unstable.	<ol style="list-style-type: none"> 1) Sliding parts are caught. 2) Tank line pressure varies. 3) Air has mixed into pipeline. 	<ol style="list-style-type: none"> 1) Correct. 2) Bring pressure directly to oil tank. 3) Let air off.
Secondary pressure is high	<ol style="list-style-type: none"> 1) Tank line pressure is high. 2) Sliding parts are caught. 	<ol style="list-style-type: none"> 1) Bring pressure directly to oil tank. 2) Correct.

4. MAINTENANCE STANDARDS

4.1 PARTS REPLACEMENT STANDARD

- 1) Replace O rings and other seals at each removal and installation.
- 2) Replace worn parts if leaks affects the operating system.
- 3) Replace spools having excessive wear on their moving areas.
- 4) Replace a push rod that is worn to 1mm (0.04in) or over on its top end. (See Fig. 12.)
- 5) Replace operating lever and pins that have a gap of 2mm (0.08in) or over.
- 6) Replace such parts that arise abnormal sounds, hunting and drops in the primary pressure.




Fig. 12 Wear of push rod

5. TROUBLESHOOTING

Trouble	Cause	Remedy
Secondary pressure does not rise.	<ol style="list-style-type: none"> 1) Primary pressure is insufficient. 2) Springs (241-1, 241-2) are broken or fatigued. 3) Clearance between spool (201-1, 201-2) and valve body (101) is abnormally large. 4) Lever has a gap. 	<ol style="list-style-type: none"> 1) Secure primary pressure. 2) Replace with new ones. 3) Replace assembly. 4) Disassembly and reassembly or replace lever section.
Secondary pressure is unstable.	<ol style="list-style-type: none"> 1) Sliding parts are caught. 2) Tank line pressure varies. 3) Air has mixed into pipeline. 	<ol style="list-style-type: none"> 1) Correct. 2) Bring pressure directly to oil tank. 3) Let air off.
Secondary pressure is high	<ol style="list-style-type: none"> 1) Tank line pressure is high. 2) Sliding parts are caught. 	<ol style="list-style-type: none"> 1) Bring pressure directly to oil tank. 2) Correct.

1. SPECIFICATION

1.1 GENERAL VIEW

No.	PORT NAME	PORT SIZE
A	MAIN PORT	PF3/8
B	MAIN PORT	PF3/8
T	TANK PORT	PF3/8
DR	DRAIN PORT	PF1/4
PP	PARKING BRAKE RELEASE COMMAND PORT	PF1/4
PB	PARKING BRAKE RELEASE PRESSURE PORT	PF1/4






Fig. 1 General view of slewing motor unit

1.2 SPECIFICATIONS

Table 1

Item		Specification	
Model		PCL-50-21B-1FS2-8563A	
Reduction unit	Theoretical torque	kgf·m (ft·lbs) 61(441)	
	Gear ratio	1/20.7	
	Rotational direction (viewed from shaft end)	Inlet A port : cw, Inlet B port : ccw	
Hydraulic motor	Displacement	cc/rev (cu·in/rev) 13.3(0.81)	
	Rated flow	ℓ/min (gal/min) 20.0(5.28)	
	Parking brake	Brake torque	kgf·m (ft·lbs) 4.1(30)
		Release pressure	kgf/cm ² (psi) Min 35(500) Max 90(1280)
Relief valve	Set pressure	kgf/cm ² (psi) 140(1990) at 20 ℓ/min (5.3gal/min)	
	Cracking pressure	kgf/cm ² (psi) 115(1640) or more at 11 ℓ/min (2.9gal/min)	
Set time of hydraulic timer		Sec 4±2 [Oil temperature 50°C (122°F)]	
Weight (with Reduction unit)		kg (lbs) 29(64)	

12) Remove shaft (203) and swash plate (210).

- In case the shaft is hard to remove, tap it lightly from the end face of the opposite side by means of a plastic hammer.
- Ball bearing (216) is press fitted to the shaft ; do not remove the shaft except where the ball bearing is replaced.




Fig. 23 Removing shaft (203) and swash plate (210)

13) Remove two filters (214) and parallel pin (215).




Fig. 24 Removing filters (214) and parallel pin (215)

3.2.2 Removal of reduction unit

1) Remove the s2 gear (108), then remove the carrier assy 2 (103) and carrier assy (102) in turn.




Fig. 25 Removing s2 gear (108) and carrier assy

5) Press-fit the outer race of the taper roller bearing (121) into the body (101). Then fill grease in the installing portion of the hearing.

- Volume of grease filled in :
approx. 80% of the space.




Fig. 61 Press-fitting outer race of the roller bearing (121)

6) Insert the pinion shaft (104) assy into the body (101).

- Pay attention not to give any damages on the lip of oil seal (123).





Fig. 62 Installing shaft (104)

7) Turn over the body (101), and press-fit the inner race of the taper roller bearing (122) into the pinion shaft (104).

- Prior to the press-fitting of the inner race, warm it up to the temperature of ambient temperature plus 50°C(122°F).




Fig. 63 Press-fitting inner race of the taper roller bearing (122)

8) Install the pre-load collar (119) to the pinion shaft (104).

- Adjust the thickness of the pre-load collar (119) at 0 to +0.05mm (0.002 in) against the actual measurement for the groove width L that is the clearance between both the end faces of bearing (122) and groove of pinion shaft (104) side.





Fig. 64 Installing preload collar (119)

2. CONSTRUCTION AND OPERATION

2.1 CONSTRUCTION (Spec. 1)

(1) Hydraulic Motor

■Applicable machines : PW07001~PW07244




Fig. 2 Hydraulic motor

No.	Tightening torque kgf·m (ft·lbs)
4	3 (22)
19	5.6 (41)
33	6 (43)
36	1 (7)
41	7 (51)
44	0.6 (4.3)

No.	NAME	Q'TY	No.	NAME	Q'TY	No.	NAME	Q'TY
M1	HOUSING	1	M16	X-RING	1	M31	VALVE HOUSING	1
M2	FLANGE	1	M17	O-RING	3	M32	STEEL BALL	2
M3	PINION GEAR	1	M18	O-RING	1	M33	PLUG	2
M4	PLUG	1	M19	SOCKET BOLT	8	M34	O-RING	2
M5	PISTON	1	M20	SHAFT FACE SEAL	1	M35	SPRING	2
M6	RING	1	M21	GEROLLER	1	M36	PLUG	1
M7	PLATE	1	M22	DRIVE	1	M37	O-RING	2
M8	DISK PLATE	7	M23	VAVLE PLATE	1	M38	O-RING	1
M9	STEEL PLATE	7	M24	VALVE DRIVE	1	M39	O-RIG	2
M10	SPRING	12	M25	VAVLE	1	M40	O-RING	1
M11	BEARING (FR)	1	M26	BALANCING RING	1	M41	CAPSCREW	4
M12	SNAP RING	1	M27	SPRING	2	M42	NAME PLATE	1
M13	SNAP RING	1	M28	INNER FACE SEAL	1	M43	RIVET	2
M14	BEARING (RE)	1	M29	PIN	2	M44	PLUG	2
M15	SNAP RING	1	M30	OUTER FACE SEAL	1			

204

6) Remove the valve (M25).




Fig. 17

7) Remove the valve plate (M23) and valve drive (M24)




Fig. 18

8) Remove the geroller (M21) and drive (M22).





Fig. 19

9) Remove the socket bolts (M19), then remove the flange (M2) and springs (M10).

 : 8mm




Fig. 20

23) Install the O-rings (V20) to the relief valve body (V1). And tighten up the relief valve assy with the socket bolts (V19).

 : 6mm

Tightening torque: 3.5kgf·m (25ft·lbs)




Fig. 57

2.2 FUNCTION AND OPERATION

(1) Hydraulic Motor

This hydraulic motor is of an axial piston motor type (rotating cylinder slant swash plate type), and to convert the hydraulic energy to the rotating motion.

Nine pistons are incorporated in the cylinder block. And the end face of the cylinder block gets in contact with the two crescent shaped port A and B (a distributor valve for high/low pressure).

<Principle of Torque Generation>

When highly pressurized oil (pressurized oil P) is led to the A port, it pushes up the pistons at the force of $(F=P \times A/\text{piston};$ where A is the cross sectional area of piston), and this force acts to the swash plate. On the other hand, the piston receives a reaction force from the swash plate, and an element for the rotating direction is generated against such reaction force. And a rotating force is generated on the cylinder block due to the sum of the element for the rotating direction on the pistons being at the high pressure side. The torque comes from the rotating force being transmitted to the shaft through the spline, and rotates the shaft.

Conversely, when highly pressurized oil is led to the B port, the cylinder block is reversely rotated.

The rotating torque and speed are calculated from the following formula.

◎ Output Torque (T)

$$T = \frac{P \times D \times i \times \eta_m \times \eta_G}{2 \times \pi \times 100}$$

◎ Rotating Speed (N)

$$N = \frac{Q \times 1000 \times \eta_v}{D \times i}$$

- Where ;
- D : Total Displacement (cc/rev)
 - P : Effective Driving Pressure (cc/cm²)
 - Q : Oil Flow Rate (ℓ/min)
 - η_m : Mechanical Efficiency (motor)
(% $\times 10^{-2}$)
 - η_v : Volumetric Efficiency (motor)
(% $\times 10^{-2}$)
 - i : Reduction Gear Ratio
 - η_G : Efficiency on Reduction Gear
(% $\times 10^{-2}$)




Fig.5 Construction of motor

7-4) Remove the cylinder block (103), friction plate (126), disk plates (127) and other parts.

- Cylinder block (103)
- Collar (114)
- Spring (115)
- Washer (116)
- Snap ring (117)
- Piston assy (106)
- Retainer plate (107)
- Retainer holder (108)
- Pin (113)
- Friction plate (126)
- Disk plate (127)




Fig. 22 Removal of cylinder block (103) and others

7-5) Remove the retainer plate (107) and piston assy (106).




Fig. 23 Removal of piston (106)

7-6) Remove the retainer holder (108), then remove the pins (113)




Fig. 24 Removal of retainer holder (108)

7-7) Pushing the washer (116) with a jig, remove the snap ring (117).

Tool: Snap ring plier (No. 26)
Jig (No. 48)




Fig. 25 Removal of snap ring (117)

4-13) Install 22 pcs. of the spring (128) and O-ring (122)




Fig. 60 Installation of spring (128) and O-ring (122)

4-14) Press fit the bearing (112) into the valve unit (102) using the jig and press machine.

Tool : Jig (No. 41)

Press machine (No. 34)




Fig. 61 Pressing fit of bearing (112)

4-15) Set the pin (119), and lock it with a punch.





Fig. 62 Setting of pin (119)

4-16) Applying grease to back side of the valve plate (105), install it to the valve unit (102) aligning the recess to the pin (119).

4-17) Set the pins (118) to the valve unit (102).




Fig. 63 Installation of valve plate (105), and pin (118)

5.2 FOR FUNCTION OF VALVES INTEGRATED IN MOTOR

Condition	Possible Causes	Remedial Action
<p>a) Motor does not rotate or speed is low.</p>	<p>1. Mal-function on any of equipment other than valve (integrated in motor), piston motor, or reduction gear.</p>	<p>Check for oil pressure at valve inlet, then check and repair damaged equipment.</p>
	<p>2. Due to damage on O-ring or seal in relief valve, internal relief is increased.</p>	<p>Repalace damaged O-ring or back-up ring to new one.</p>
	<p>3. Due to defective sealing in valve or piston, leakage is increased.</p>	<p>Retouch damaged condition or repalce relief valve and valve body to new one.</p>
	<p>4. Defect on seat in make-up valve causing mal-function.</p> <p>1) Foreign matters are caught on seat.</p> <p>2) Sliding face on check valve (102) becomes rough or damaged.</p> <p>3) Snapping off of spring.</p>	<p>Remove foreign matters, retouch damages, make them clean, then reassemble it. If scores are deep causing much oil leakage, replace it.</p> <p>Retouch sliding face, or replace check valve to new one.</p> <p>Replace spring. At that time, remove foreign matters, retouch damages, make them clean, then reassemble. If scores are deep causing much oil leakage, replace it.</p>
	<p>5. Defective seat on relief valve.</p> <p>1) Foreign matters are caught on seat.</p> <p>2) Snapping off of spring.</p>	<p>Remove foreign matters, retouch damages, make them clean, then reassemble it. If scores are deep causing much oil leakage, replace it.</p> <p>Replace relief valve assy to new one.</p>
	<p>6. Lowering cracking pressure on relief valve</p> <p>1) Setting on spring.</p> <p>2) Clogging on poppet orifice.</p>	<p>Replace relief valve assy to new one.</p> <p>Make clean orifice with cleaning oil, then reassemble poppet.</p>


264

2. CONSTRUCTION AND FUNCTION

2.1 CONSTRUCTION


2.1.1 BASIC CONSTRUCTION

(1) Standard Specification




■ Applicable Machines SK25SR : PV10001 ~ PV12000
SK35SR : PX05001 ~ PX06500

■ Applicable Machines SK25SR : PV12001 ~
SK35SR : PX06501 ~



Hydraulic diagram



Hydraulic diagram

Fig. 2 Basic construction of travel motor

3. REMOVAL AND INSTALLATION

3.1 GENERAL PRECAUTIONS TO BE EXERCISED AT REMOVAL

- 1) Because hydraulic components are precision finished in general, handle them in a clean place. Use clean tools, cleaning oil and dry compressed air. Avoid using rag and paper.
- 2) Plug each of the ports of the travel motor removed from the machine and clean all dirt and oil completely from outside the motor before proceeding to disassembly operation.
- 3) Leave matching marks on the mating surface of parts, as required. Arrange removed parts in order during operation, exercising care so as not to damage parts and not to lose them
- 4) Sealing parts, such as, O rings and backup rings can not be reused once removed. Check prearranged parts against "Parts Manual" to prepare for reassembly.
- 5) Some parts can not be supplied singly and can only be supplied in subassy. Prepare such parts in advance, referring to "Parts Manual".

- Do not remove the parts (bearings, pins, etc.) marked "Press Fit" in the manual, as a rule.
- The numbers in parentheses after part names represent the structure drawings (Fig. 3, 4 and 5)

3.2 CLASSIFICATION OF REMOVING ITEMS

The travel motor assy consists of a hydraulic motor, a reduction unit and a brake valve all put together in one piece.

Removal consists roughly of the following : Refer to installation of necessary items for each of the hydraulic motor, the reduction unit and the brake valve, and perform removal.


- Avoid removing unnecessary portions.

The removal is roughly grouped as follows : For details, refer to Installation.

- (1) Preparation before removal.
 - 1) Cleaning
 - 2) Installing the travel motor assy onto a work bench
 - 3) Draining out oil
- (2) Removing the reduction unit
- (3) Removing relief valve assy
- (4) Removing motor cover
- (5) Removing body (202)
- (6) Rough cleaning of parts
- (7) Each parts of finish cleaning and dry

- 9) Place thrust collar (115) so it contact with four gear B1 evenly.

SHAFT(203)
(In case of SK35SR)



PH-883

Fig. 40 Installing thrust color (115)

- 10) Install the carrier II assy so it mates with four gear B1 (106) and shaft (203). Fit O ring (129) to casing (101).

- In case of SK25SR
Install the S2 gear (109).


Thereafter, fill in lube oil.

Lubricant oil : API class CD SAE30

Oil : SK25SR : 600cc(37cu·in)

SK35SR : 700cc(43cu·in)

109(SK25SR)
203(SK35SR)




PH-883

Fig. 41 Installing carrier II assy and fitting O ring (129)

- 11) Install the slide ring (116) to the cover (102).

- Apply grease to fix it.
- Place the larger chamfer side on the cover side.




PH-883

Fig. 42 Installing slide ring (116)

- 12) Install the cover (102) on the body.

- Coat the O ring with grease and fit it level so as not to score it.
- Align the upper and lower threaded holes (PF3/8) with the notch of the casing and install it.



PH-883

Fig. 43 Installing cover (102)

2.1.4 RELIEF BLOCK ASSY





Fig. 5 Section of relief valve assy

Component parts

No.	NAME	Q'TY	No.	NAME	Q'TY	No.	NAME	Q'TY
501	VALVE BODY	1	- 6	O-RING	1	- 13	O-RING	1
502	VALVE ASSY	1	- 7	O-RING	1	503	O-RING	3
- 1	VALVE BODY	1	- 8	O-RING	2	504	O-RING	2
- 2	POPPET	1	- 9	BACK-UP RING	1	505	SOCKET BOLT	2
- 3	PLUG	1	- 10	BACK-UP RING	1	506	SOCKET BOLT	2
- 4	SHIM A	3	- 11	SPRING	1	507	PLUG	3
- 5	SHIM B	3	- 12	SPRING HOLDER	1	508	PLUG	2


(9) Remove the base plate (30).

- Pay attention not to let the cylinder block come out.
- If it is difficult to remove, tap it lightly with a plastic hammer for the removal direction, or wrench it lightly with a screw driver.



(10) Remove the pins (49), valve plate (25) and O-rings (28) and (29).


- For the machine with parking brake:
Remove the springs (18).



- For the machine with parking brake:

(11) Remove the brake piston (17).


- Apply compressed air to the parking brake releasing port on the flange holder (101) to remove it.




(12) Remove and disassemble the cylinder block assy (7).

- Remove the pins (12) and retainer holder (13) from the cylinder block (7).
- Remove the retainer plate (14) and pistons (15) from the cylinder block (7).
 - Pay attention not to give any scores on the sliding surface on the cylinder block .

- For the machine with parking brake:
 - Remove the disk (16).




- c. Install the pins (12) to each of three bores on the cylinder block.
- Apply grease to the pins.



- d. Install the retainer holder (13), retainer plate (14) and piston assy's (15).
- Apply hydraulic oil to the bores on the cylinder block.


■ For the machine with parking brake:

- e. Install the disk (16).




(22) Install the cylinder block assy.

- a. Install it making the spline on the shaft as a guide.



- b. Confirm the action of springs by means of pushing up the cylinder block (7) with hands.
- Apply hydraulic oil to the sliding surface on the cylinder block.



KOBELCO

Book Code No.

S5 16012_{3E}

SHOP MANUAL

— SWIVEL JOINT —

TABLE OF CONTENTS

1. CONSTRUCTION AND FUNCTION	
1.1 Construction	1
1.2 Function	2
2. REMOVAL AND INSTALLATION	
2.1 General Precautions	3
2.2 Removal	3
2.3 Installation	5
3. MAINTENANCE STANDARDS	
3.1 Service Limit of the Parts	7
3.2 Inspection after Installation	7
4. TROUBLESHOOTING	8

KOBELCO

Book Code No.

S5 17024_{1E}①

SHOP MANUAL

Applicable Models :
SK25SR
SK35SR (except swing
cylinder)

— HYDRAULIC CYLINDER —

TABLE OF CONTENTS

1. SPECIFICATIONS	
1.1 General View	1
1.2 Specifications	1
2. CONSTRUCTION AND FUNCTION	
2.1 Construction	2
2.2 Function	7
3. REMOVAL AND INSTALLATION	
3.1 Preparation before Removal	9
3.2 Removal	11
3.3 Cleaning	14
3.4 Installation	14
4. MAINTENANCE STANDARDS	
4.1 Inspection after Removal	18
4.2 Service Limits	19
4.3 Tightening Torque	19
4.4 Inspection after Installation	19
5. TROUBLESHOOTING	20
6. SPECIAL TOOLS LIST	21

17

 **KOBE STEEL, LTD.**

3. REMOVAL AND INSTALLATION

3.1 PREPARATION BEFORE REMOVAL

Before removal, it is necessary to keep a dustfree workshop and facilities.

3.1.1 Work Area

The following working area is required for removal.

(1) Ample space

For removal of the hydraulic cylinder, the cylinder tube and the piston rod must be extracted.

Therefore, the first prerequisite is that the working area must have sufficient space for such work. It is also necessary that the working area has ample space widthwise to accommodate removal, cleaning and measuring facilities.

(2) Suitable working environment

The hydraulic cylinder is a precision-machined product incorporating seals and packings made of rubber and plastic materials. For this reason, care should be used so that the hydraulic cylinder is free from dust, dirt, sand, metal chips, weld slag and other hard substance. If the hydraulic cylinder is assembled without being aware of hard particles stuck on the cylinder tube and the piston rod, the tube inner surface and the rod surface may be scratched as the cylinder operates, thereby disabling it in worst cases. Damage to the piston seals and the rod seals will result in oil leaks. For this reason, grinding and welding operation should be avoided near the working area to keep it clean.

3.1.2 Apparatus

The following equipment are required for removal

(1) Hoist or crane

The hoist or crane must be capable of carrying the cylinder in an assembled condition. It must also be capable of performing level and linear movement under load for inserting and extending the piston rod and the tube.

(2) Work bench

The work bench must have strength and rigidity capable of accommodating the total length of the cylinder in its most retracted condition and of withstanding the reactive force of the tightening torques of the cylinder head and the piston nut. Since a vise is to be attached to the bench, the width of the work bench must be sufficiently large.

(3) Support stand

If the fixing pin side of the piston rod is fully extended in a free condition, the bushing and the seals may be damaged as the rod bushing and the piston are twisted due to the weight of the rod. A stand is required to support the rod to prevent such troubles.

(4) Hydraulic source

A hydraulic source is required for removal and installation of the cylinder head and piston nut and for oil leak tests after completion of installation.

(5) Jet air source

It is used for drying after oil draining and cleaning of the cylinder.

(6) Cleaning bath, cleaning oil and detergent

(7) Oil pan and oil reservoir

An oil pan is necessary to contain oil drained from the cylinder and oil spilt during work. An oil reservoir is required to collect oil spilt on the floor and waste oil.

(8) Others

Oil extracting hoses, wooden skids, rag and sawdust in which oil soaked are also necessary.

4.2 SERVICE LIMITS

Service limits represent the limits of wear on the sliding surfaces of the cylinder tube and the piston rod that have no such faults as may degrade the sealing effect.

- (1) Clearance between piston rod and rod bushing:

Replace the bushing if the clearance between the piston rod and the rod bushing exceeds 0.25mm (0.01in).

- (2) Bend of piston rod:

The allowable bend of the rod is maximum 1mm / 1m(0.04 in/39.4 in). For measurement, support both ends of the parallel section of the piston rod with V-blocks, set a dial indicator in the center between the two V-blocks turn the piston rod, and read the difference between the maximum and minimum oscillations on the dial indicator.




Fig. 32 Measuring method

Table 4 shows an example of measurement.

Table 4 Example of measurement

Distance between V-blocks m(in)	Deflectional value of the dial gauge mm(in)	Remedy
1(39.4)	1(0.04)	Replace
2(78.7)	2(0.08)	Replace

- Even if the bend is within the tolerable limit, the cylinder may not operate smoothly because of localized bend. Beware of it during function test after installation. Replace the rod if the cylinder makes a squeaking noise or dose not operate smoothly.

4.3 TIGHTENING TORQUE

A : CYLINDER HEAD

B : PISTON ASSY

C : SETSCREW




Fig. 33 Applicable portions for tightening torque

Table 5 Tightening torque

Unit: kgf·m(ft·lbs)


Model	SK25SR			SK35SR		
	A	B	C	A	B	C
Cylinder						
Boom	39(280)	70(510)	0.7(5.1)	50(360)	150(1080)	1.65(11.9)
Arm	↑	↑	↑	46(330)	110(800)	
Bucket	31(220)	45(330)	↑	39(280)	55(400)	0.7(5.1)
Swing	43(310)	70(510)	1.65(11.9)	—	—	—
Dozer	46(330)	110(800)	↑	59(430)	120(870)	1.65(11.9)

4.4 INSPECTION AFTER INSTALLATION

- 1) Place the cylinder on the work bench, and check its operating conditions by means of applying load to extend and retract the piston rod several times by each stroke end.
- 2) Hold the hydraulic pressure for 3 minutes at extended and retracted positions respectively to check leakage on piston rod and cylinder head as well as the welded portions.

(3) Bucket cylinder


■SK30SR



No.	NAME	Q'TY	No.	NAME	Q'TY	No.	NAME	Q'TY
1	PISTON PACKING	1	10	PIPE	1	19	BUSHING	1
2	ROD PACKING	1	11	ROD COVER	1	20	SNAP RING	1
3	BACK-UP RING	1	12	PISTON ROD	1	21	GREASE NIPPLE	1
4	DUST SEAL	1	13	PISTON	1	22	GREASE NIPPLE	1
5	O-RING	1	14	PACKING HOLDER	1	23	CAPSCREW	1
6	O-RING	1	15	BUSHING	2	24	SPRING WASHER	1
7	BACK-UP RING	1	16	PACKING HOLDER	1	25	WEAR RING	2
8	O-RING	1	17	NUT	1	26	DUST SEAL	4
9	TUBE	1	18	SPLIT PIN	1			


(4) Swing cylinder

■SK30SR · SK35SR



No.	NAME	Q'TY	No.	NAME	Q'TY	No.	NAME	Q'TY
1	PISTON PACKING	1	10	ROD COVER	1	23	BUSHING	2
2	ROD PACKING	1	12	PISTON ROD	1	24	BUSHING	1
3	BACK-UP RING	1	13	PISTON	1	25	SETSCREW	1
4	DUST SEAL	1	14	PACKING HOLDER	1	26	GREASE NIPPLE	1
5	O-RING	1	16	PACKING HOLDER	1	27	WEAR RING	2
6	O-RING	1	17	CUSHION SEAL	1	28	DUST SEAL	4
7	BACK-UP RING	1	19	SPACER	1	29	ORIFICE	1
8	O-RING	1	20	SNAP RING	1			
9	TUBE	1	21	STOPPER	1			


- 2) Install the O-ring (29) and back-up ring (30) to the outer periphery of retainer.



(4) Installation of piston:

Y1-D439


- 1) Install the back rings (46), back-ring (47) and slipper ring (48) to the piston (12).



Y3-D416

- 2) Install the wear ring (27) to the piston (12) and packing holder (49).


- Expand the split on the wear ring (27) as minimum as required to install it from the axial direction.



Y3-D413

(5) Installation of piston rod assy:

- 1) Set up the rod cover (23) and retainer (24).
- Aligning the recess on the rod cover (23) to the bore (F) on the retainer (24), insert the retainer (24) into the rod cover (23).



Y3-D418

1. SUMMARY

1.1 GENERAL PRECAUTIONS

- (1) Applications of Breaker or Nibbler & Breaker
 - Breaker Piping
Applicable when a breaker is mounted.
 - Nibbler & Breaker Piping
Applicable when nibbler and a breaker are mounted.

- (2) Modification Work

There are some specific precautions to be followed to use the breaker or nibbler & breaker. Therefore, when the machine is to be modified at our service shop, contact to the nearest breaker and nibbler manufacturer's office to obtain instructions for the correct piping and handling of them.

- (3) Difference between Hydraulic Piping for Nibbler and Breaker

- Piping for Breaker

The oil flow to the breaker is a single flow circuit. The discharged oils from P2 and P3 pumps which join together in the main control valve, flow to the breaker through the control valve for breaker. The return oil directly flows into the tank from the breaker.

- Piping for Nibbler

The oil flow to the nibbler is a twin flow circuit. The discharged oils from P2 and P3 pumps join together in the main control valve, and the flowing direction of oil is changed over in the control valve for nibbler to operate it.

- (4) Operation of Pedal

The operation of breaker and nibbler is conducted by the optional pedal of left front of driver's seat.

Operation of Pedal

Stepping Direction of Pedal	Breaker Spec.	Nibbler & Breaker Spec.	
		Breaker	Nibbler
Toe stepping (front)	—	—	Close (grasp)
Heel stepping (rear)	Operated	Operated	Open (release)

- ⚠ Do not put your foot on the pedal unless otherwise the operation, to avoid any mis-operation.
- Lock the pedal with the pedal locking device, while the breaker or nibbler is not used.

1.2 BASIC DISPOSITION TO BE TAKEN AT MOUNTING OF BREAKER OR NIBBLER & BREAKER

When mounting the breaker or nibbler & breaker, always put the following items into effect.

- (1) Tighten up the set screw on the discharge block of main control valve to shut off oil passage to the tank and allow oil flowing to the carry-over port.

- (2) Return the low pressure line of breaker (return line) directly to the hydraulic oil tank.

⚠ If the return oil from breaker is put into the control valve, it causes for the damages on the machine due to transmission of pulsatory motion to the oil cooler.

- (3) Install the pedal for breaker or nibbler & breaker and the control valve which is operated by the link system.

- Control Valve

for Breaker : Without Overload Relief

- Control Valve

for Nibbler & Breaker: With Overload Relief

- (4) On the machine with the nibbler & breaker, install the selector valve to change over each oil flow for the nibbler or breaker.

- (5) Reinforce the arm with a plate to mount the nibbler & breaker.

⚠ Make sure to reinforce the arm, otherwise it causes for the breakage of it.

- (6) For the case of not using our genuine parts but using the piping materials of breaker manufacturer, make sure to carry out the above items.

- (7) For the arm whose length is longer than the one on the standard machine, the breaker and nibbler & breaker are not applicable.

3.4 RETURN HYDRAULIC PIPING

3.4.1 Additional Parts

Install the additional parts shown in the Table 7 to the hydraulic piping on the standard machine in accordance with the Fig. 13.

Note : • Confirm the preparations for the required parts prior to setting about the modification work.

• At assembly, pay attention not to allow dropping off of O-ring.


Table 7 Additional Parts for Breaker Specification

No.	PART NO.	NAME	QTY	REMARK	No.	PART NO.	NAME	QTY	REMARK
	PV32H00003F2	RETURN HYDRAULIC PIPING		SK25SR	24	HH35S08008G1	ELBOE	1	
	PW32H00005F2	RETURN HYDRAULIC PIPING		SK30SR	25	HX22L08150DX	HOSE (L=1500)	1	
	(PX32H00003F2)	RETURN HYDRAULIC PIPING		(SK35SR)	26	PW32H01009D3	HOSE (L=1870)	1	
	PX32H00004F2	RETURN HYDRAULIC PIPING		SK35SR	27	YN20M01046D5	TUBE	2	
	23	HH45S08008G1	CONNECTOR	1	28	HH25S08012G1	CONNECTOR	1	




Note : • The part numbers are subject to change due to improvement or modification.

Use them for your reference only.

• The numbers are corresponding to the numbers in Parts Catalog for SK25SR, SK30SR and SK35SR.



27 : The tube is applied to the contacted portion with slewing motor.



3.4.2 Disuse Parts

The parts shown in the Table 8 which were used on the standard machine are not used anymore. (refer to Fig. 13)

Table 8

NO.	PART NO.	NAME	QTY
19	ZE72X12000	PLUG	1
20	ZE72X08000	PLUG	1

Fig. 13 Return Hydraulic Piping (This Fig. shows the case for SK30SR)

5.1.4 Arm Hydraulic Piping

Install the additional parts shown in the Table 17 to the plate which was attached to the arm as per the above 5.1.3, in accordance with the Fig. 22.

- Note :
- At assembly, pay attention not to allow dropping off of O-ring.
 - Apply the locktite #242 to the cap screw to fix the stop valve.

Table 17 Additional Parts for Arm Hydraulic Piping

No.	PART NO.	NAME	QTY	No.	PART NO.	NAME	QTY
	PV46H00004F1	ARM HYDRAULIC PIPING		4	HH45S08008G1	ELBOW 45°	2
1	PV68H01006D7	HOSE (L=600)	2	5	ZE72X08000	PLUG	2
2	ZS18C08016	CAP SCREW (M8×16)	4	6	PV46H01001P1	STOP VALVE	2
3	ZW26X08000	LOCK WASHER (M8)	4				

Note : The part numbers are subject to change due to improvement or modification.

Use them for your reference only.




Fig. 22 Arm Hydraulic Piping (SK25SR)

309

7. PRECUATIONS TO USE NIBBLER & BREAKER

7.1 OPERATION OF CARRY-OVER FUNCTION

To operate the nibbler or breaker, it is necessary to use the function of carry-over in the main control valve. The function of carry-over is activated by the following preparations.

• Working Procedures

- (1) Remove the protective tube (1).
- (2) Loosen the lock nut (2).
🔧 : 13mm
- (3) Screw up the set screw (3).
🔧 : 4mm
Tightening Torque : 1.4kgf·m (10 ft·lbs)
- (4) Lock the set screw with the lock nut (2).
🔧 : 13mm.
Tightening Torque: 1 kgf·m (7.2 ft·lbs)
- (5) Check for the correct set dimension. Then install the protective tube.

Note :

A loose tightening of the set screw (3) and lock nut (2) might cause for a possibility that the plug in the control valve does not seal the seat sufficiently or, once it seals the seat, the seat is occasionally opened, leaking oil into the tank port. Therefore, make sure to tighten them at the specified torque, and check for the L dimension.

Note :

- 1.The L dimension for the set screw (3) is 21mm (0.83") when the function of carry-over is not used.
- 2.The L dimension for the set screw (3) is 14 ± 1 mm (0.55 ± 0.04 ") when the function of carry-over is used.





Fig. 33 Operation of Carry-over Function

CONTENTS

1. Specifications and Performance	1-1
1-1 2TNE68	1-1
1-2 3TNE68	1-2
1-3 3TNE74	1-3
1-4 3TNE78A	1-4
1-5 3TNE82A	1-5
1-6 3TNE82	1-6
1-7 3TNE84	1-7
1-8 3TNE88	1-8
1-9 4TNE82	1-9
1-10 4TNE84	1-10
1-11 4TNE88	1-11
1-12 3TNE84T	1-12
1-13 4TNE84T	1-13
2. Cross Sectional Views	2-1
2-1 Special Swirl Pre-combustion Chamber System	2-1
2-2 Direct Injection System	2-2
3. Cooling Water, Lubricating Oil and Fuel Oil	3-1
3-1 Cooling water	3-1
3-2 Lubricating oil	3-1
3-3 Fuel oil	3-3
4. Troubleshooting	4-1
4-1 Trouble causes and remedies	4-1
4-2 Trouble diagnosis through measurement of compression pressure	4-3
5. Special Service Tools and Measuring Instruments	5-1
5-1 Special service tools	5-1
5-2 Measuring instruments	5-3
6. Measurement, Inspection and Adjustment	6-1
6-1 Measuring the compression pressure	6-1
6-2 Adjusting the valve head clearance	6-3
6-3 Checking the V-belt tension	6-4
6-4 Measuring and checking the injection pressure and spray patterns of the fuel injection valve	6-4
6-5 Checking and adjusting the fuel injection timing	6-8
6-6 Adjusting the no-load maximum (or minimum) revolutions	6-10
6-7 Checking the cooling water system and radiator for water leakage	6-10
6-8 Checking the battery	6-11
6-9 Checking sensors	6-13
6-10 Checking the oil cooler	6-14
6-11 Checking the piston cooling nozzle	6-15

1-5 3TNE82A

* Output conditions: Intake back pressure ≤ 250 mmAq, Exhaust back pressure ≤ 550 mmAq, other conditions complying with JIS D 1005-1986. After minimum 30 hour's run-in.

Item		Model		3TNE82A						
		Unit	CL			VM				
Application		—	CL			VM				
Type		—	Vertical, 4-cycle water-cooled diesel engine							
Combustion system		—	Direct injection system							
No. of cylinders - Bore × Stroke		mm	3 - 82 × 84							
Displacement		ℓ	1.330							
Firing order		—	1 - 3 - 2 - 1							
Revolution speed		rpm	1500	1800	2000	2200	2400	2600	2800	3000
Output*	Continuous rating	kW(HP)	9.9 (13.3)	12.0 (16.1)	—	—	—	—	—	—
	Max. rating	kW(HP)	11.0 (14.8)	13.2 (17.7)	14.6 (19.6)	16.0 (21.5)	17.5 (23.5)	19.0 (25.5)	20.5 (27.5)	21.9 (29.4)
Max. revolution speed at no load		rpm	1575 ⁺⁵⁰ ₀	1870 ⁺⁵⁰ ₀	2180 ⁺⁵⁰ ₀	2375 ⁺⁵⁰ ₀	2570 ⁺⁵⁰ ₀	2780 ⁺⁵⁰ ₀	2970 ⁺⁵⁰ ₀	3180 ⁺⁵⁰ ₀
Min. revolution speed at no load			≤1200	≤800						
Direction of rotation		—	Counterclockwise (viewed from flywheel)							
Power take off		—	Flywheel							
Compression ratio		—	18.0							
Fuel injection timing (FID, b.T.D.C.)		deg	10±1		12±1		14±1		16±1	
Compression pressure		MPa (kgf/cm ²)	3.04±0.1 (31±1), at 250 rpm							
Fuel injection pressure		MPa (kgf/cm ²)	19.6 ^{+1.0} ₀ (200 ⁺¹⁰ ₀)							
Recommended diesel gas oil		—	ISO 8217 DMA, BS 2869 A1 or A2 (Cetane No. 45 min.)							
Lubrication system		—	Forced lubrication with trochoid pump							
Lubricating oil capacity Max/Effective		ℓ	3.6/1.3			5.0/1.7				
Recommended lubricating oil		—	API grade CC class or higher							
Cooling system		—	Liquid cooling/Radiator							
Cooling water capacity		ℓ	1.8 (for engine only)							
Cooling fan No. of blade × dia.		mm	Pusher type, 6 × φ335							
Crank V-pulley dia./ Fan V-pulley dia.		mm	φ120/φ90			φ110/φ110				
Governor		—	Mechanical centrifugal governor (All speed type)							
Starting system		—	Electrical							
*1 Dimensions L × W × H		mm	553 × 489 × 565			520.5 × 489 × 565 / 528 × 489 × 565				
*1 Dry weight		kg	138			112/128				
PERFORMANCE	Governing performance (full speed range)	Transient speed difference	%	≤10	≤8	≤12				
		Steady state speed band	%	≤5	≤4	≤9	≤8	≤7	≤6	
		Recovery time	sec	≤5			≤6			
		Fluctuation of revolution	rpm	≤15			≤25			
L.O. press.	Rated operation	MPa (kgf/cm ²)	0.25 ± 0.05 (2.5 ± 0.5)		0.29 ± 0.05 (3.0 ± 0.5)					
	Idling		≥0.06 (≥0.6)							


*1. Designation of engine dimension and dry weight in numerals.

CL/CH application: engine with flywheel housing

VM/VH application: engine with back plate/with flywheel housing

2. Cross Sectional Vi

2-1. Special Swirl Pre-co (Indirect Inj



6. Measurement, Inspection and Adjustment

6-1. Measuring the compression pressure

1. Measuring Procedure

(1) Warm up the engine. Remove the fuel injection pipe and fuel injection valve from the cylinder to be measured.


(2) Crank the engine before attaching the compression gauge adapter.

* :1. Crank the engine when the regulator handle has been turned to "STOP" position (no injection state).

2. For the compression gauge and compression gauge adapter, refer to Chapter 5, 5-2.

(3) Attach the compression gauge adapter and compression gauge to the cylinder to be measured.

* : Never fail to attach the gasket to the tip of the adapter.



Measuring the compression pressure


(4) Crank the engine by the starting moter until the reading of the compression gauge is stabilized, by taking steps shown in (2), *1.

[Reference: List of Engine Compression Pressures]

Model	Compression pressure at 250 rpm (kgf/cm ²)		Dispersion of compression pressure among cylinders (kgf/cm ²)
	Standard	Limit	
2TNE68	33 ± 1	25	2 ~ 3
3TNE68	33 ± 1	25	2 ~ 3
3TNE74	35 ± 1	27	2 ~ 3
3TNE78A	32 ± 1	25	2 ~ 3
3TNE82A	31 ± 1	24	2 ~ 3
3TNE82	31 ± 1	24	2 ~ 3
3TNE84	33 ± 1	25	2 ~ 3
3TNE88	35 ± 1	27	2 ~ 3
4TNE82	31 ± 1	24	2 ~ 3
4TNE84	33 ± 1	25	2 ~ 3
4TNE88	35 ± 1	27	2 ~ 3
3TNE84T	30 ± 1	24	2 ~ 3
4TNE84T	30 ± 1	24	2 ~ 3

6-8. Checking the battery



1. Structure of the battery



2. Checking the battery

(1) Electrolyte level

Check the electrolyte level in each cell. If the level is low, add deionized water to bring the level to the UPPER level as illustrated below.




(2) Battery charge

Using a battery tester or hydrometer, check the state of the battery. If the battery is discharged, recharge it.

○ Measurement with a battery tester

To check the battery with a battery tester, securely hold the \oplus terminal of the battery with the red clip of the battery tester and the \ominus terminal with the black clip. Judge battery charge level from the indicator position:

- Green zone: normal
- Yellow zone: somewhat discharged
- Red zone: abnormal or much discharged



(Measuring the battery charge)
with battery tester

[Replacing the Valve Guide]

(1) Extract the valve guide from the cylinder head using the valve guide extraction tool.


* For the valve guide extraction tool, refer to Chapter 5, 5-1.

(2) In a container containing liquefied nitrogen, ether or alcohol together with dry ice, put the valve guide to cool it. Then hit the sufficiently cooled valve guide to fit into the cylinder head using the valve guide insertion tool.

* For the valve guide insertion tool, refer to Chapter 5, 5-1.

(3) After inserting the valve guide, finish the inside of the valve guide with a reamer.

(4) Check the projection of the valve guide.



(Valve guide projection)


4. Valve stem seal

[Time of Replacement]

- (1) When oil loss is found excessive
- (2) When the valve stem seal is removed
- (3) When intake/exhaust valves are removed

[Precautions on Installation]



Make sure that the entire surface of valve stem is smooth, and sufficiently apply lubricating oil to the valve stem before reassembling intake/exhaust valves.



(mm)

	2/3TNE68		3TNE74	
	Standard	Wear limit	Standard	Wear limit
Valve guide projection	7	—	9	—

	3TNE78A 3TNE82A		3/4TNE82, 3/4TNE84(T), 3/4TNE88	
	Standard	Wear limit	Standard	Wear limit
Valve guide projection	12	—	15	—




(Hatched portion indicates where to apply lubricating oil.)

6. Measuring the outside diameter of the piston pin and the pin hole diameter

Measure outside diameter of the piston pin and pin hole diameter. Replace the piston pin if the wear limit is exceeded.

Apply lubricating oil to the piston pin before inserting it into the piston.




(Measuring point of the piston pin O. D.)


(mm)

		2/3TNE68		3TNE74	
		Standard	Wear limit	Standard	Wear limit
Piston and piston pin	Piston pin outside diameter	19.991 ~20.000	19.90	20.991 ~21.000	20.90
	Piston pin hole dia.	20.000 ~20.008	20.02	21.000 ~21.008	21.02
	Oil clearance	0.000 ~0.017	0.12	0.000 ~0.017	0.12

		3TNE78A 3TNE82A		3/4TNE82, 3/4TNE84(T), 3/4TNE88	
		Standard	Wear limit	Standard	Wear limit
Piston and piston pin	Piston pin outside diameter	22.991 ~23.000	22.90	25.987 ~26.000	25.90
	Piston pin hole dia.	23.000 ~23.008	23.02	26.000 ~26.009	26.02
	Oil clearance	0.000 ~0.017	0.12	0.000 ~0.022	0.12



(Measuring the piston pin outside diameter)



Apply oil to piston pin

Circlip

(Insertion of piston pin)

7. [Reference] Top clearance

(mm)

	2/3TNE68		3TNE74	
	Standard	Wear limit	Standard	Wear limit
Top clearance	0.610 ~0.730	—	0.658 ~0.778	—

	3TNE78A 3TNE82A		3/4TNE82, 3/4TNE84(T), 3/4TNE88	
	Standard	Wear limit	Standard	Wear limit
Top clearance	0.650 ~0.770	—	0.660 ~0.780	—

7-8. Gears

1. Checking gears

Inspect the gears and replace if the teeth are damaged, worn, or chipped.


2. Measuring the backlash

Apply a dial gauge onto the pitch circle of the gear, and measure the backlash.

(mm)

		2/3TNE68, 3TNE74	3TNE78A/82A, 3/4TNE82, 3/4TNE84(T), 3/4TNE88
Backlash	Crankshaft gear, Camshaft gear, Idle gear and Fuel injection pump drive gear	0.04~0.12	0.07~0.15
	L.O. pump gear	0.11~0.19	

(Indirect Injection system)




3. Checking and measuring the idling gear shaft and idling gear

- (1) Measure the bushing inside diameter and the idle gear shaft outside diameter, and replace the bushing or idling gear shaft if the oil clearance exceeds the wear limit.

(mm)

		2/3TNE68, 3TNE74		3TNE78A/82A, 3/4TNE82, 3/4TNE84(T), 3/4TNE88	
		Standard	Wear limit	Standard	Wear limit
Idle gear	Shaft outside dia.	19.959 ~19.980	19.93	45.950 ~45.975	45.93
	Bushing inside dia.	20.000 ~20.021	—	46.000 ~46.025	46.08
	Oil clearance	0.020 ~0.062	0.15	0.025 ~0.075	0.15

(Direct Injection system)



- (2) Make sure that the oil hole of the idle gear shaft and bushing is a through hole.


(5) Where to use liquid packings

1. Between the cylinder block and gear case flange
2. Between the gear case flange and gear case cover
3. Between the cylinder block and oil seal case (indirect injection system only)
4. Oil pan installation surface

* Use *Three Bond No. 005* (Yanmar part code: 97777-001212) as the liquid packing.

* Apply the liquid packing so as not to form any break on the midway. Otherwise, oil leakage, etc., may result.


(6) Coating the lubricating oil on Intake/ exhaust valve stem




Apply lubricating oil down to the lower surface (hatched portion in the figure) of the valve guide before reassembling the valve stem.

(7) Reassembly of the piston ring

1. Insert the piston ring into the ring groove, where the side with the manufacturer's mark on the matching ends facing up (to the combustion chamber side), using a piston ring replacer. After fitting the piston ring, make sure it moves easily and smoothly.



2. Assemble the piston rings to the cylinder, staggering the piston rings joints at 120° intervals, making sure that they are not aligned along the piston. Apply lube oil to the circumference of the piston.



10. Tightening Torque

10-1 Main bolt/nut

(Unit: kgf-m)

No.	Item	Model				
		Torque	2/3TNE68	3TNE74	3TNE78A 3TNE82A	3/4TNE82, 3/4TNE84(T), 3/4TNE88
1	Cylinder head bolt	Lubricating oil applied (Thread dia. × pitch)	3.8~4.2 (M8 × 1.25)	6.0~6.5 (M9 × 1.25)	6.8~7.2 (M9 × 1.25)	8.7~9.3 (M10 × 1.25)
2	Connecting rod bolt	Lubricating oil applied (Thread dia. × pitch)	2.3~2.8 (M7 × 1.0)	2.3~2.8 (M7 × 1.0)	3.8~4.2 (M8 × 1.0)	4.5~5.5 (M9 × 1.0)
3	Flywheel clamping bolt	Lubricating oil applied (Thread dia. × pitch)	8.2~8.8 (M10 × 1.25)	8.0~9.0 (M10 × 1.25)	8.5~9.0 (M10 × 1.25)	8.5~9.0 (M10 × 1.25)
4	Metal cap clamping bolt	Lubricating oil applied (Thread dia. × pitch)	5.3~5.7 (M9 × 1.25)	8.0~8.5 (M10 × 1.25)	7.8~8.2 (M10 × 1.5)	9.8~10.2 (M12 × 1.5)
5	Crankshaft V-pulley clamping bolt	Lubricating oil applied (Thread dia. × pitch)	S48C:11.5~12.5 FC25: 8.5~9.5 (M12 × 1.5)	S48C:11.5~12.5 FC25: 8.5~9.5 (M12 × 1.5)	11.5~12.5 (M14 × 1.5)	11.5~12.5 (M14 × 1.5)
6	Fuel injection nozzle nut	Lubricating oil not applied (Thread dia. × pitch)	5.0~5.4 (M20 × 1.5)	5.0~5.4 (M20 × 1.5)	0.7~0.9 (M6 × 1.0)	0.7~0.9 (M6 × 1.0)
7	Timer clamping nut	Lubricating oil not applied (Thread dia. × pitch)	—	—	6.0~7.0 (M12 × 1.75)	6.0~7.0 (M12 × 1.75)
8	Glow plug	Lubricating oil not applied (Thread dia. × pitch)	1.5~2.0 (M10 × 1.25)	1.5~2.0 (M10 × 1.25)	—	—
9	Stub shaft bolt	Lubricating oil not applied (Thread dia. × pitch)	5.5~6.5 (M10 × 1.5)	5.5~6.5 (M10 × 1.5)	—	—
10	Governor weight support nut	Lubricating oil not applied (Thread dia. × pitch)	7.0~7.5 (M12 × 1.25)	7.0~7.5 (M12 × 1.25)	4.5~5.0 (M12 × 1.25)	4.5~5.0 (M12 × 1.25)
11	High pressure pipe sleeve clamping nut	Lubricating oil not applied (Thread dia. × pitch)	3.0~3.5 (M12 × 1.5)	3.0~3.5 (M12 × 1.5)	3.0~3.5 (M12 × 1.5)	3.0~3.5 (M12 × 1.5)

10-2 Standard bolt and nut


* : Lubricating oil not applied

(Unit: kgf-m)

Item	Thread dia. × pitch	Tightening torque	Remarks
Hexagon headed bolt (7T) and nut	M6 × 1	1.0~1.2	1) When bolting the aluminum parts, tighten the bolts with 80% of the tightening torque specified in the Table. 2) 4T bolt and lock nut should be tightened with 60% of the torque shown in the table.
	M8 × 1.25	2.3~2.9	
	M10 × 1.5	4.5~5.5	
	M12 × 1.75	8.0~10.0	
PT plug	1/8	1.0	_____
	1/4	2.0	
	3/8	3.0	
	1/2	6.0	
Pipe joint bolt	M8	1.3~1.7	_____
	M12	2.5~3.5	
	M14	4.0~5.0	
	M16	5.0~5.5	


12-3. Disassembly

- (1) Remove the bottom cover from the fuel injection pump to drain lubricating oil from the fuel injection pump.
- (2) Turn the fuel injection pump upside down to drain fuel oil.




- (4) Remove the fuel feed pump.

* Do not disassemble the fuel feed pump.




- (3) Take out the governor weight assembly using the governor weight extractor tool (special service tool)



* For separating the governor assembly from the fuel injection pump, refer to Chapter 13, 13-3.



- (5) Remove the fuel injection pump side cover.




(17) Mount the fuel injection pump side cover.



(20) Tighten the holder stopper to the specified torque. (kgf-m)

	All models
Tightening torque	0.3


(18) Mount the fuel injection pump bottom cover.




(19) Tighten the delivery valve spring holder to the specified torque. (kgf-m)

	All models
Tightening torque	3.5 ~ 4.0

* Never tighten the delivery holder excessively. Otherwise, it upsets, causing oil to leak through it.



(21) Mount the fuel feed pump.




- *1. Tighten the delivery valve spring holder by hand as far as possible. If the bolt get hard to turn part way, the packing or delivery valve may be out of position. Remove, correct, and start tighten again.
- *2. Never tighten the delivery valve holder excessively. Excessive tightening causes the control rack to malfunction.

13-5. Reassembly

Inspect all parts after disassembly and replace any parts as necessary. Before starting reassembly, clean all parts and put them in order.

Make sure to readjust the unit after reassembly to obtain the specified performance.

- (1) Fix the bearing holder with a vise to hold the fuel injection pump camshaft. Insert the governor weight assembly in the taper portion at the end of the fuel injection pump camshaft. Mount the washer, and tighten the governor weight support nut with the specified torque.




(kgf-m)


	Governor weight support nut tightening torque
Indirect injection system	7.0 ~ 7.5
Direct injection system	4.5 ~ 5.0

- (2) Open the governor weight to the outside, and insert the sleeve in the end of the fuel injection pump camshaft.

* *Make sure that the sleeve moves smoothly after inserting it.*



- (3) After the stop lever is disassembled, mount the stop lever return spring on the stop lever, tap the stop lever lightly with a wooden hammer to insert it, and tighten the stop lever stop pin. (DI only)



- (4) After the control lever shaft is removed, lightly tap and insert the control lever shaft and washer from inside the governor case, using an appropriate plate.
- (5) If the governor lever has been disassembled, tap in the spring pin.

15. Service Information for CARB ULG regulation

Introduction


This chapter describes only the items designated as special specifications for servicing the TNE engine under 25 HP that complies with CARB ULG regulation (Regulation for small Utility engines and Lawn & Garden from California Air Resource Board, effects to the engines manufactured on Jan. 1st 1995 and later).

15-1. Emission control label

15-1-1. Content of the label

Size and contents of the label are as shown below.

[Example]



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL