

HYDRAULIC EXCAVATOR

**SHOP
MANUAL**

**model SK330(LC)-6E
SK330NLC-6E**

INDEX

1	SPECIFICATION SECTION
2	MAINTENANCE SECTION
3	SYSTEM SECTION
4	DISASSEMBLY SECTION
5	TROUBLESHOOTING
6	ENGINE SECTION
7	INSTALLATION PROCEDURES FOR OPTIONAL ATTACHMENT

SPECIFICATION

MAINTENANCE

SYSTEM

DISASSEMBLING

TROUBLESHOOTING

E/G

OPT

KOBELCO

Book code No. S5LC0009E②

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Applicable Machines

LC08-06201~

YC08-03001~

LC09-06323~

YC09-03088~

Revision	Date of Issue	Remarks
First edition	March, 2003	S5LC0209E K
First revision	November, 2003	S5LC0209E① K

KOBELCO

Book code No.

S5LC03_{09E}①

SHOP MANUAL **SK330(LC)-6E** **SK330NLC-6E**

LC03

— ATTACHMENT DIMENSION —

TABLE OF CONTENTS

1. BOOM	
1.1 Boom dimensional drawing	1
1.2 Boom maintenance standard	2
2. ARM	
2.1 Arm dimensional drawing	4
2.2 Arm maintenance standard	5
3. BUCKET	
3.1 Bucket dimensional drawing	7
3.2 Bucket dimensional table	7
3.3 Dimensional drawing of lug section	8
3.4 Dimensional drawing of boss section	9

KOBELCO CONSTRUCTION MACHINERY CO., LTD.

Applicable Machines

LC08-06201~


YC08-03001~

LC09-06323~

YC09-03088~

Revision	Date of Issue	Remarks
First edition	March, 2003	S5LC1109E K
First revision	November, 2003	S5LC1109E① K

10. ENGINE MOUNTING PEDESTAL



MATERIAL ; WOOD

No.	NAME	Q'TY	REMARKS
1	SUPPORT	2	80×320×40 (3.15×12.6×1.57)
2	SUPPORT	2	80×320×40 (3.15×12.6×1.57)
3	PLATE	2	150×710×20 (5.91×30.0×0.787)
4	PLATE	2	150×330×20 (5.91×13.0×0.787)
5	FRAME	2	55×55×840 (2.16×2.16×33.1)
6	FRAME	2	55×55×380 (2.16×2.16×15.0)

This page is left blank for editing convenience.

NAME OF WORK	NAME OF TROUBLE	Unit ; Hour
Oil 03-70		
Replacing engine oil.		0.6
Oil filter 03-71		
Replacing oil filter assy.	Oil leaks from oil filter. Oil filter casing is damaged. Oil filter head is scored. Oil filter system in general is out of order.	1.0
Cleaning or replacing oil filter assy. (1 set)		0.5
Inspecting or replacing relief valve. Detaching and attaching oil filter assy.	Relief valve parts are faulty.	0.4
Turbocharger 03-62		
Detaching/attaching or replacing turbocharger assy.		2.7
Overhauling turbocharger. (single) Incl. : Cleaning (1 pc.).		1.3
Detaching/attaching or replacing 2-stack oil filter assy.	Oil leaks from oil filter. Oil filter casing is damaged. Oil filter head is damaged. Oil filter system in general is out of order.	—
Oil pan 03-72		
Detaching and attaching oil pan and replacing gasket.	Oil leaks from oil pan gasket. Oil pan parts are faulty. Oil pan system in general is out of order.	2.8
Retightening oil pan attaching bolts.		0.5
Replacing oil level gauge guide or packing.	Oil level gauge parts are defective.	—
Oil piping 03-74		
Replacing oil piping. (between filter and cooler)	Oil leaks from oil piping. Oil piping system in general is out of order.	—
Replacing breather pipes. (2 pcs.)	Oil piping system in general is out of order.	0.3
Oil pump 03-75		
Detaching/attaching or replacing oil pump.		4.3
Overhauling oil pump assy. Incl. : Detaching/attaching oil pump.		—
Overhauling oil pump. Excl. : Detaching and attaching oil pump.		1.0
Detaching/attaching or replacing oil strainer.	Oil screen is installed incorrectly. Oil screen is broken. Oil screen is clogged. Oil screen stay is broken. Oil pump system in general is out of order.	3.5

(2) 2-stage main relief valve
 (Common for travel and ATT sections)
 Start from the boosting side, first. Loosen nut (1), adjust the pressure with adjusting screw (2) and tighten nut (1) after completion of the adjustment on the boosting side. Then, loosen nut (3), adjust the pressure on the standard side with adjusting screw (4) and tighten nut (3) after completion of the adjustment.





-  : 32mm Tightening torque : 2.8~3.2kgf·m (20~23 lbf·ft)
-  : 22mm Tightening torque : 2.8~3.2kgf·m (20~23 lbf·ft)
-  : 19mm Adjust screw
-  : 6mm

Table 3

No. of turns of adjust screw	Pressure change kgf/cm ² (psi)
Boosting side 1 turn	Approx. 180 (2560)
STD side 1 turn	Approx. 180 (2560)

(3) Over load relief valve
 (Boom, bucket, arm sections)
 Loosen lock nut (1) and adjust it with adjust screw (2).



-  : 22mm Tightening torque : 2.8~3.2kgf·m (20~23 lbf·ft)
-  : 6mm

Table 4

No. of turns of adjust screw	Pressure change kgf/cm ² (psi)
1 turn	Approx. 180 (2560)

(4) Over load relief valve (Swing)
 When the adjustment of pressure is required, loosen lock nut (1) and adjust the pressure with cap (2).





-  : 30,38mm Tightening torque : 12kgf·m (87 lbf·ft)
-  : 12mm

Table 5

No. of turns of adjust screw	Pressure change kgf/cm ² (psi)
1 turn	Approx. 102 (1450)

(5) Travel overload relief valve adjusting procedure
 The valve can not be pressure adjusted externally. Loosen cap (5) and adjust it with shim (8). Increasing the shim thickness increases the pressure.

-  : 35mm Tightening torque : 10~12kgf·m (72~87 lbf·ft)
-  : 27mm




Fig. 9 Main relief valve
 (Travel, ATT common section)




Fig. 10 Over load relief valve
 (Boom, bucket, arm sections)




Fig. 11 Swing over load relief valve





Fig. 12 Travel over load relief valve

O.D, I.D. and thickness of shims (mm)	Pressure change kgf/cm ² (psi)
Ø17×Ø10×1	Approx. 50 (710)
Ø17×Ø10×0.5	Approx. 25 (360)


1.3 BOOM UP CONFLUX CONTROL



(1) Boom up conflux

- 1) Start boom up operation, and the boom up operation secondary pilot pressure switches boom spool and boom conflux spool, and inputs into low pressure sensor.
- 2) The voltage output of the low pressure sensor for the boom is put into the mechatro controller, processed internally and put out to the P2 cut solenoid proportional valve as command current according to the input voltage.
- 3) The P2 cut solenoid proportional valve puts out the secondary proportional valve pressure according to the current command from the mechatro controller and changes the P2 cut valve.
- 4) The moment the boom spool and the P2 bypass cut valve are shifted, it is put into the negative control pressure sensor and back pressure sensor.
- 5) The voltage output of the negative control pressure sensor and back pressure sensor is put into the mechatro controller. The controller processes the negative control signal inside and puts out a current command to the P1 and P2 pump solenoid proportional valves according to the voltage input.
- 6) The P1 and P2 pump solenoid proportional valves put out the secondary proportional pressure according to the current command from the mechatro controller and changes the delivery rates of the P1 and P2 pumps.
- 7) A pure hydraulic command changes over the boom main spool and the boom conflux valve. When the mechatro controller command shifts the P2 bypass cut valve, the oil delivered by the P1 pump is combined with that by the P2 pump when the boom up operation is performed.

No.	DISPLAY	REMARKS	No.	DISPLAY	REMARKS
11	No.11 PRESS. SENSOR B-5 BUCKET DIG <u>4.5V</u> <u>3.0M</u> B-6 BUCKET DUNP <u>45V</u> <u>3.0M</u>	Sensor voltage / Pressure converted value Sensor voltage / Pressure converted value	19	No.21 PROPO-VALVE D-2 P2 CUT COMP. <u>647mA</u> <u>2.5M</u> MEAS. <u>642mA</u> <u>2.5M</u>	Command current / Pressure converted value Feedback current / Pressure converted value
12	No.12 PRESS. SENSOR B-7 SWING (R) <u>4.5V</u> <u>3.0M</u> B-8 SWING (L) <u>4.5V</u> <u>3.0M</u>	Sensor voltage / Pressure converted value Sensor voltage / Pressure converted value	20	No.22 PROPO-VALVE D-3 S-TRAVEL COMP. <u>647mA</u> <u>2.5M</u> MEAS. <u>642mA</u> <u>2.5M</u>	Command current / Pressure converted value Feedback current / Pressure converted value
13	No.13 PRESS. SENSOR B-9 TRAVEL (R) <u>4.5V</u> <u>3.0M</u> B-10 TRAVEL (L) <u>4.5V</u> <u>3.0M</u>	Sensor voltage / Pressure converted value Sensor voltage / Pressure converted value	21	No.23 PROPO-VALVE D-6 A-RECIRCULAT COMP. <u>510mA</u> <u>1.6M</u> MEAS. <u>510mA</u> <u>1.6M</u>	Command current / Pressure converted value Feedback current / Pressure converted value
14	No.14 PRESS. SENSOR C-1 PUMP P1 <u>3.3V</u> <u>35M</u> C-2 PUMP P2 <u>3.3V</u> <u>35M</u>	Sensor voltage / Pressure converted value Sensor voltage / Pressure converted value	22	No.24 PROPO-VALVE E-1 P1 PUMP COMP. <u>350mA</u> <u>0.6M</u> MEAS. <u>395mA</u> <u>0.6M</u> POWER SHIFT <u>0mA</u>	Command current / Pressure converted value Feedback current / Pressure converted value
15	No.15 PRESS. SENSOR B-16 P1 OPT. <u>4.5V</u> <u>3.0M</u> B-17 P2 OPT. <u>4.5V</u> <u>3.0M</u>	Sensor voltage / Pressure converted value Sensor voltage / Pressure converted value	23	No.25 PROPO-VALVE E-2 P2 PUMP COMP. <u>350mA</u> <u>0.6M</u> MEAS. <u>350mA</u> <u>0.6M</u> POWER SHIFT <u>0mA</u>	Command current / Pressure converted value Feedback current / Pressure converted value
16	No.16 PRESS. SENSOR B-16 P1 NEGATIVE CONTROL <u>0.5V</u> <u>0.0M</u> B-17 P2 NEGATIVE CONTROL <u>0.5V</u> <u>0.0M</u>	Sensor voltage / Pressure converted value Sensor voltage / Pressure converted value	24	No.39 MECHATRO ADJT. CONT. SW <u>TEST</u> CONT. VOL <u>50%</u> PROG. SW <u>OFF</u>	RUN/TEST indication Inner trimmer ON/OFF indication
17	No.19 PROPO-VALVE B-15 BACK PRESS. <u>1.6V</u> <u>0.8M</u>	Sensor voltage / Pressure converted value	25	No.40 RELEASE SW KPSS <u>OFF</u> SWING BRAKE <u>OFF</u>	ON/OFF indication ON/OFF indication
18	No.20 PROPO-VALVE D-3 P1 CUT COMP. <u>647mA</u> <u>2.5M</u> MEAS. <u>642mA</u> <u>2.5M</u>	Command current / Pressure converted value Feedback current / Pressure converted value	26	No.26 PROPO-VALVE D-13 SWING PRIORITY COMP. <u>647mA</u> <u>2.5M</u> MEAS. <u>642mA</u> <u>2.5M</u>	Command current / Pressure converted value Feedback current / Pressure converted value Arm in and swing simultaneous operation



This section describes boom down operation.

- 3) Boom down pilot circuit
- 4) Prevention of natural fall by lock valve and actuation at a down
- 5) Constant recirculation function of boom down main circuit

7.3 BOOM DOWN PILOT CIRCUIT

Operation :

<Hydraulic>

- 1) If the boom down operation is performed, the secondary pilot proportional pressure comes out of port④ of the right pilot valve (10) and acts upon the low pressure sensor (SE-4). At the same time, the pressure is branched off into two lines and acts upon the PBb port and the PLC1 port of C/V (2).

<Mechatronics>

- 2) The voltage output of the low pressure sensor (SE-4) enters the mechatronics controller. By shifting boom spool, the pressure of negative control sensor (SE-26) drops, and the P1 pump flow rate increases with the control of mechatronics negative controller.

<Hydraulic>

- 3) Then, the proportional secondary pressure fed into C/V (2) PBb port switches boom spool. And the proportional secondary pressure flows into C/V (2) PLC1 port releases boom lock valve.

7.4 PREVENTION OF NATURAL FALL BY LOCK VALVE AND ACTUATION AT LOWERING

Purpose :

Prevention of natural fall when the lever is neutral

Principle :

The oil is prevented from returning to the boom spool by the poppet seat of the boom lock valve.

Operation :

In the boom down action, the selector valve is changed over by the boom down pilot pressure. Then the poppet spring chamber of the lock valve gets through the drain line (Drc) and makes the lock valve poppet open. When the boom lever is at neutral, the drain line on the lock valve poppet spring chamber is closed which causes the poppet closed.

The result is that the oil returning from the boom cylinder head (H) to the boom spool is held and makes the leakage from the boom spool zero.

Thus the boom cylinder is prevented from making a natural fall.

7.5 CONSTANT RECIRCULATION FUNCTION OF BOOM DOWN MAIN CIRCUIT

Purpose :

Prevention of cavitation during boom downing motion.

Principle :

The oil returning from the boom cylinder head (H) is recirculated to the rod (R).

Operation :


When the oil is supplied to the boom cylinder rod (R) side during boom lower operation, the boom moves faster by the self weight of the attachment.

On that occasion, the circuit pressure on the rod (R) side is on the negative side.

The oil supplied to the boom cylinder rod (R) flows into the A1 port of the P1 pump and the P1 port of C/V. The oil then passes through the boom spool and goes out of the Bb port.

On that occasion, the oil returning from the head (H) goes through the recirculation path in the boom spool, pushes the check valve (C) in the spool open, is recirculated to the Bb port and is supplied to the rod (R). When the (R) pressure is larger than the (H) pressure, the check valve (C) closes.

Thereupon, the recirculation is stopped.



CONFLUX(COMBIEND) CIRCUIT : Swing left/Swing priority & Conflux function at Arm in **KCME**

KOBELCO

Book code No.

S5 LC23_{09E}①

SHOP MANUAL SK330(LC)-6E SK330NLC-6E

ELECTRIC SYSTEM

TABLE OF CONTENTS

1. ELECTRIC CIRCUIT DIAGRAM	1
2. ELECTRICAL EQUIPMENT LIST	11
3. HARNESS	
3.1 Harness list	13
3.2 Chart of Harness Connection	15
3.3 Operators Controls	17
3.4 Controller Assy	18
3.5 Instrument Panel Assy	27
3.6 Upper Electric Assy	28
3.7 Upper Harness Assy	29
3.8 Engine Harness Assy	45
3.9 Floor Harness Assy	47
3.10 Cab Harness Assy	55
3.11 Cab Assy	58
3.12 Battery & Battery Install	59
3.13 Light Install	59
3.14 Boom Harness Assy	62
3.15 Fuel Pump Assy Install	63
3.16 Alarm Assy	64

LC23

KOBELCO CONSTRUCTION MACHINERY CO., LTD.




Fig.1E,1F (2/4)

WIRE NO	WIRE COLOR	WIRE SIZE	FROM	CONNECTION	TO
1A	RY	AVSS0.75sq	CN-14M	—	CN-53F
1B	RY	AVSS0.75sq	CN-5F	—	CN-14M
1C	RY	AVSS0.75sq	CN-5F	—	CN-53F
1D	RY	AVSS0.75sq	CN-20F	—	CN-53F
1E	RY	AVSS0.75sq	CN-100F	—	CN-53F
2A	WY	AVSS0.75sq	CN-14M	—	CN-53F
2B	WY	AVSS0.75sq	CN-16F	—	CN-53F
2C	WY	AVSS0.75sq	CN-17F	—	CN-53F
2D	WY	AVSS0.75sq	CN-29F	—	CN-53F
2E	WY	AVSS0.75sq	CN-39F	—	CN-53F
2F	WY	AVSS0.75sq	CN-45F	—	CN-53F
2G	WY	AVSS0.75sq	CN-34F	—	CN-53F
3A	G	AVSS0.75sq	CN-14M	—	CN-35M
3B	R	AVSS0.75sq	CN-14M	—	CN-35M
4A	Y	AVSS0.75sq	CN-14M	—	CN-53F
4B	Y	AVSS0.75sq	CN-103F	—	CN-53F
4C	Y	AVSS0.75sq	CN-103F	—	CN-53F
4D	Y	AVSS0.75sq	CN-35M	—	CN-53F
4E	Y	AVSS0.75sq	CN-44F	—	CN-53F
4F	Y	AVSS0.75sq	CN-66M	—	CN-53F
5	YL	AVSS0.75sq	CN-14M	—	CN-38M
6A	WG	AVSS0.75sq	CN-14M	DOUBLE SPLICE	CN-15F
6B	WG	AVSS0.75sq	CN-15F	—	CN-15F
7	YR	AVSS0.75sq	CN-14M	—	CN-36M
8	WV	AVSS0.75sq	CN-14M	—	CN-38M
9A	YB	AVSS0.75sq	CN-14M	—	CN-26F
9B	YB	AVSS0.75sq	CN-36M	—	CN-26F
9C	YB	AVSS0.75sq	CN-54F	—	CN-26F
9D	YB	AVSS0.75sq	CN-5F	—	CN-26F
9E	YB	AVSS0.75sq	CN-26F	—	CN-26F
9F	YB	AVSS0.75sq	CN-102F	—	CN-26F
9G	YB	AVSS0.75sq	CN-102F	—	CN-26F
10	WV	AVSS1.25sq	CN-14M	—	CN-36M
11	OL	AVSS0.75sq	CN-14M	—	CN-42F
12A	RG	AVSS1.25sq	CN-14M	—	CN-26F
12B	RG	AVSS0.75sq	CN-17F	—	CN-26F
12C	RG	AVSS0.75sq	CN-57F	—	CN-26F
12D	RG	AVSS0.75sq	CN-56F	—	CN-26F
13A	W	AVSS0.75sq	CN-14M	—	CN-26F
13B	W	AVSS0.75sq	CN-38M	—	CN-26F
13C	W	AVSS0.75sq	CN-38M	—	CN-26F
13D	W	AVSS0.75sq	CN-34F	—	CN-26F
14A	RB	AVSS1.25sq	CN-14M	—	CN-27F
14B	RB	AVSS1.25sq	CN-29F	—	CN-27F
14C	RB	AVSS0.75sq	CN-61F	—	CN-27F
14D	RB	AVSS0.75sq	CN-37F	—	CN-27F
15A	WB	AVSS0.75sq	CN-14M	—	CN-27F
15C	WB	AVSS0.75sq	CN-32M	—	CN-27F
15D	WB	AVSS0.75sq	CN-34F	—	CN-27F
16	RW	AVSS1.25sq	CN-14M	—	CN-16F
17A	WL	AVSS1.25sq	CN-14M	—	CN-27F
17B	WL	AVSS1.25sq	CN-49F	—	CN-27F
17C	WL	AVSS0.75sq	CN-49F	—	CN-27F

WIRE NO	WIRE COLOR	WIRE SIZE	FROM	CONNECTION	TO
18	WG	AVSS1.25sq	CN-14M	—	CN-36M
19	RL	AVSS0.75sq	CN-14M	—	CN-36M
20A	WR	AVSS1.25sq	CN-14M	DOUBLE SPLICE	CN-43F
20B	WR	AVSS1.25sq	CN-62F	—	CN-43F
30	G	AVSS0.75sq	CN-12F	—	CN-30F
50	L	AVSS1.25sq	CN-14M	—	CN-36M
51	W	AVS2sq	CN-14M	—	CN-30F
52	R	AVS5sq	CN-14M	—	CN-33M
53	Y	AVS5sq	CN-14M	—	CN-33M
54	R	AVS2sq	CN-14M	—	CN-30F
55	WP	AVSS1.25sq	CN-14M	—	CN-30F
58	P	AVSS0.75sq	CN-30F	—	CN-103F
59	W	AVSS0.75sq	CN-30F	—	CN-101F
60A	WL	AVSS0.75sq	CN-46F	—	CN-26F
60B	WL	AVSS0.75sq	CN-36M	—	CN-26F
60C	WL	AVSS0.75sq	CN-45F	—	CN-26F
60D	WL	AVSS0.75sq	CN-2F	—	CN-26F
60E	WL	AVSS0.75sq	CN-40F	—	CN-26F
61A	GrB	AVSS0.75sq	CN-36M	—	CN-27F
61B	GrB	AVSS0.75sq	CN-2F	—	CN-27F
61C	GrB	AVSS0.75sq	CN-40F	—	CN-27F
62	W	AVSS0.75sq	CN-35M	—	CN-45F
63A	WY	AVSS0.75sq	CN-36M	—	CN-27F
63B	WY	AVSS0.75sq	CN-30F	—	CN-27F
63C	WY	AVSS0.75sq	CN-35M	—	CN-27F
64	LW	AVSS0.75sq	CN-30F	—	CN-12F
65A	WR	AVSS0.75sq	CN-30F	—	CN-26F
65B	WR	AVSS0.75sq	CN-2F	—	CN-26F
65C	WR	AVSS0.75sq	CN-38M	—	CN-26F
65D	WR	AVSS0.75sq	CN-12F	—	CN-26F
65E	WR	AVSS0.75sq	CN-42F	—	CN-26F
67	BG	AVSS0.75sq	CN-103F	—	CN-35M
70A	YW	AVSS0.75sq	CN-101F	—	CN-27F
70B	YW	AVSS0.75sq	CN-46F	—	CN-27F
70C	YW	AVSS0.75sq	CN-12F	—	CN-27F
71A	YL	AVSS0.75sq	CN-40F	—	CN-27F
71B	YL	AVSS0.75sq	CN-101F	—	CN-27F
71C	YL	AVSS0.75sq	CN-101F	—	CN-27F
80	GrR	AVSS0.75sq	CN-38M	—	CN-29F
81	GrB	AVSS0.75sq	CN-38M	—	CN-29F
82	GO	AVSS0.75sq	CN-30F	—	CN-29F
83	GO	AVSS0.75sq	CN-30F	—	CN-15F
84A	WR	AVSS0.75sq	CN-15F	—	CN-27F
84B	WR	AVSS0.75sq	CN-32M	—	CN-27F
84C	WR	AVSS0.75sq	CN-36M	—	CN-27F
85A	WB	AVSS1.25sq	CN-16F	—	CN-26F
85B	WB	AVSS1.25sq	CN-30F	—	CN-26F
85D	WB	AVSS0.75sq	CN-36M	—	CN-26F
86A	OW	AVSS0.75sq	CN-27F	—	CN-32M
86B	OW	AVSS0.75sq	CN-27F	—	CN-30F
86C	OW	AVSS0.75sq	CN-27F	—	CN-46F

WIRE NO	WIRE COLOR	WIRE SIZE	FROM	CONNECTION	TO
87	YV	AVSS0.75sq	CN-32M	—	CN-7F
88	PG	AVSS0.75sq	CN-17F	—	CN-30F
89	BrL	AVSS0.75sq	CN-32M	—	CN-49F
90A	RY	AVSS1.25sq	CN-49F	—	CN-26F
90B	RY	AVSS1.25sq	F-1	—	CN-26F
90C	RY	AVSS1.25sq	F-3	—	CN-26F
90D	RY	AVSS0.75sq	CN-30F	—	CN-26F
98	LW	AVSS0.75sq	CN-36M	—	CN-25F
99	Br	AVSS0.75sq	CN-36M	—	CN-25F
100	LR	AVSS0.75sq	CN-36M	—	CN-24F
101	OB	AVSS0.75sq	CN-36M	—	CN-24F
150	BP	AVSS0.75sq	CN-36M	—	CN-30F
151	R	MVSS0.75sq	CN-36M	—	CN-32M
152	G	4 CORES SHIELD	CN-36M	—	CN-32M
153	W		CN-36M	—	CN-32M
154	B		CN-36M	—	CN-32M
SH4	Gr		CN-36M	—	CN-32M
202	GR	AVSS0.75sq	CN-38M	—	CN-22F
203	GB	AVSS0.75sq	CN-38M	—	CN-22F
204	BL	AVSS0.75sq	CN-38M	—	CN-23F
205	BP	AVSS0.75sq	CN-38M	—	CN-23F
210	LB	AVSS0.75sq	CN-37F	—	CN-61F
211	LW	AVSS0.75sq	CN-37F	—	CN-61F
214	YG	AVSS0.75sq	CN-18F	—	CN-19F
215	GR	AVSS0.75sq	CN-18F	—	CN-19F
216	O	AVSS0.75sq	CN-18F	—	CN-80F
217A	LO	AVSS0.75sq	CN-18F	—	CN-26F
217B	LO	AVSS0.75sq	CN-41F	—	CN-26F
217C	LO	AVSS0.75sq	CN-36M	—	CN-26F
218	P	AVSS0.75sq	CN-19F	—	CN-80F
219A	GY	AVSS0.75sq	CN-19F	—	CN-27F
219B	GY	AVSS0.75sq	CN-41F	—	CN-27F
219C	GY	AVSS0.75sq	CN-32M	—	CN-27F
220A	LW	AVSS0.75sq	CN-26F	—	CN-46F
220B	LW	AVSS0.75sq	CN-26F	—	CN-18F
220C	LW	AVSS0.75sq	CN-26F	—	CN-19F
220D	LW	AVSS0.75sq	CN-26F	—	CN-39F
222	LW	AVSS0.75sq	CN-61F	—	CN-34F
230	VR	AVSS0.75sq	CN-42F	—	CN-30F
231	VY	AVSS0.75sq	CN-42F	—	CN-30F
232	Gr	AVSS0.75sq	CN-42F	—	CN-30F
233	GrB	AVSS0.75sq	CN-42F	—	CN-30F
301	Sb	AVSS0.75sq	CN-35M	—	CN-63F
328	GrR	AVSS0.75sq	CN-35M	—	CN-65F
329	LeR	AVSS0.75sq	CN-35M	—	CN-44F
330	Le	AVSS0.75sq	CN-35M	—	CN-44F
401	GR	AVSS0.75sq	CN-55F	—	CN-56F
402	YG	AVSS0.75sq	CN-55F	—	CN-56F
403	Br	AVSS0.75sq	CN-55F	—	CN-56F
500	LeR	AVSS0.75sq	CN-1F	—	CN-30F
501	LeW	AVSS0.75sq	CN-1F	—	CN-30F

WIRE NO	WIRE COLOR	WIRE SIZE	FROM	CONNECTION	TO
502	LeY	AVSS0.75sq	CN-1F	—	CN-30F
503	LO	AVSS0.75sq	CN-1F	—	CN-30F
504	PG	AVSS0.75sq	CN-1F	—	CN-30F
505	PL	AVSS0.75sq	CN-1F	—	CN-30F
506	VY	AVSS0.75sq	CN-1F	—	CN-30F
507	VG	AVSS0.75sq	CN-1F	—	CN-30F
508	VY	AVSS0.75sq	CN-1F	—	CN-31M
509	Sb	AVSS0.75sq	CN-1F	—	CN-31M
510	GR	AVSS0.75sq	CN-2F	—	CN-30F
511	LY	AVSS0.75sq	CN-2F	—	CN-30F
512	Sb	AVSS0.75sq	CN-3F	—	CN-30F
513	LeR	AVSS0.75sq	CN-3F	—	CN-31M
514	GO	AVSS0.75sq	CN-3F	—	CN-31M
515	V	AVSS0.75sq	CN-2F	—	CN-30F
516	L	AVSS0.75sq	CN-2F	—	CN-30F
517	P	AVSS0.75sq	CN-1F	—	CN-36M
518	L	AVSS0.75sq	CN-34F	—	CN-7F
519	V	AVSS0.75sq	CN-34F	—	CN-7F
524	WR	AVSS0.75sq	CN-34F	—	CN-7F
525	WY	AVSS0.75sq	CN-3F	—	CN-80F
526	LeY	AVSS0.75sq	CN-3F	—	CN-80F
541	PL	AVSS0.75sq	CN-2F	—	CN-31M
542A	GrG	AVSS0.75sq	CN-4F	—	CN-27F
542B	GrG	AVSS0.75sq	CN-32M	—	CN-27F
542C	GrG	AVSS0.75sq	CN-36M	—	CN-27F
545	Le	AVSS0.75sq	CN-2F	—	CN-10F
547	GB	AVSS0.75sq	CN-4F	—	CN-30F
548	GY	AVSS0.75sq	CN-4F	—	CN-30F
549	Le	AVSS0.75sq	CN-4F	—	CN-30F
550	BG	AVSS0.75sq	CN-4F	—	CN-30F
551	GL	AVSS0.75sq	CN-4F	—	CN-30F
552	BrL	AVSS0.75sq	CN-4F	—	CN-30F
553A	VW	AVSS0.75sq	CN-27F	—	CN-30F
553B	VW	AVSS0.75sq	CN-27F	—	CN-4F
553C	VW	AVSS0.75sq	CN-27F	—	CN-20F
556	BrW	AVS0.5sq	CN-4F	—	CN-51F
557	L	AVSS0.75sq	CN-4F	—	CN-38M
558	G	AVSS0.75sq	CN-4F	—	CN-38M
559A	PB	AVSS0.75sq	CN-7F	—	CN-27F
559B	PB	AVSS0.75sq	CN-38M	—	CN-27F
559C	PB	AVSS0.75sq	CN-60F	—	CN-27F

WIRE NO	WIRE COLOR	WIRE SIZE	FROM	CONNECTION	TO
560	LeY	AVSS0.75sq	CN-7F	————	CN-38M
562	O	AVS0.5sq	CN-52F	————	CN-32M
563	O	AVSS0.75sq	CN-7F	————	CN-30F
564	LY	AVS0.5sq	CN-32M	————	CN-52F
566	LW	AVSS0.75sq	CN-6F	————	CN-30F
580	W	PEXBS0.5fsq	CN-2F	————	CN-30F
581	B	2 CORES SHIELD	CN-2F	————	CN-30F
SH1	Gr		CN-2F	————	CN-30F
582	W	MVVS0.75sq	CN-4F	————	CN-38M
770	R	3 CORES SHIELD	CN-4F	————	CN-38M
980	B		CN-4F	————	CN-38M
SH2	Gr		CN-4F	————	CN-38M
583	VW	AVSS0.75sq	CN-30F	————	CN-44F
590	LY	AVS0.5sq	CN-30F	————	CN-52F
591	WY	AVSS0.75sq	CN-41F	————	CN-4F
592	YY	AVSS0.75sq	CN-41F	————	CN-7F
593	GY	AVSS0.75sq	CN-41F	————	CN-30F
594	LeY	AVSS0.75sq	CN-41F	————	CN-30F
600	YR	AVSS0.75sq	CN-38M	————	CN-30F
601	BrR	AVSS0.75sq	CN-38M	————	CN-30F
700	WG	AVSS0.75sq	CN-5F	————	CN-30F
701	V	AVSS0.75sq	CN-5F	————	CN-10F
702	LeB	AVSS0.75sq	CN-5F	————	CN-30F
703	P	AVSS0.75sq	CN-5F	————	CN-30F
704	LeR	AVS0.5sq	CN-4F	————	CN-51F
705	LG	AVS0.5sq	CN-4F	————	CN-51F
706	VW	AVS0.5sq	CN-4F	————	CN-51F
707	LY	AVS0.5sq	CN-4F	————	CN-51F
708	LR	AVSS0.75sq	CN-4F	————	CN-29F
709	GB	AVSS0.75sq	CN-4F	————	CN-29F
710	Gr	AVSS0.75sq	CN-4F	————	CN-29F
711	GrL	AVSS0.75sq	CN-4F	————	CN-29F
713	BrY	AVSS0.75sq	CN-4F	————	CN-16F
714	WB	AVSS0.75sq	CN-4F	————	CN-56F
715	GW	AVSS0.75sq	CN-7F	————	CN-56F
716	WV	AVSS0.75sq	CN-7F	————	CN-56F
720	PB	AVSS0.75sq	CN-10F	————	CN-30F
738	WG	AVSS0.75sq	CN-6F	————	CN-30F
739	G	AVSS0.75sq	CN-6F	————	CN-30F
740	BO	AVSS0.75sq	CN-5F	————	CN-30F
741	GrR	AVSS0.75sq	CN-5F	————	CN-30F
742	VR	AVSS0.75sq	CN-5F	————	CN-30F
743	GrB	AVSS0.75sq	CN-5F	————	CN-30F
744	BP	AVSS0.75sq	CN-5F	————	CN-30F
745	PW	AVSS0.75sq	CN-5F	————	CN-30F
746	BrG	AVSS0.75sq	CN-5F	————	CN-30F

WIRE NO	WIRE COLOR	WIRE SIZE	FROM	CONNECTION	TO
747	YV	AVSS0.75sq	CN-5F	————	CN-30F
748	VR	AVSS0.75sq	CN-5F	————	CN-30F
749	GrG	AVSS0.75sq	CN-5F	————	CN-30F
750	VW	AVSS0.75sq	CN-5F	————	CN-30F
751	GY	AVSS0.75sq	CN-5F	————	CN-30F
762	GL	AVSS0.75sq	CN-6F	————	CN-45F
780	W	MVVS0.75sq	CN-35M	————	CN-3F
781	R	2 CORES SHIELD	CN-35M	————	CN-3F
SH3	Gr		CN-35M	————	CN-3F
E25	B	AVSS0.75sq	P-4	DOUBLE SPLICE	
E24	B	AVSS0.75sq	P-4	————	CN-64M
900	RB	AVSS0.75sq	CN-1F	————	CN-30F
901	RL	AVSS0.75sq	CN-1F	————	CN-30F
902	W	AVSS0.75sq	CN-1F	————	CN-30F
903	OB	AVSS0.75sq	CN-1F	————	CN-30F
904	OL	AVSS0.75sq	CN-1F	————	CN-30F
905	OW	AVSS0.75sq	CN-1F	————	CN-30F
906	YB	AVSS0.75sq	CN-1F	————	CN-30F
907	YG	AVSS0.75sq	CN-1F	————	CN-30F
908	YL	AVSS0.75sq	CN-1F	————	CN-31M
909	YR	AVSS0.75sq	CN-1F	————	CN-31M
910	WY	AVSS0.75sq	CN-2F	————	CN-30F
911	RG	AVSS0.75sq	CN-2F	————	CN-30F
912	RW	AVSS0.75sq	CN-3F	————	CN-30F
913	RB	AVSS0.75sq	CN-3F	————	CN-31M
914	RL	AVSS0.75sq	CN-3F	————	CN-31M
915	YL	AVSS0.75sq	CN-2F	————	CN-30F
916	YR	AVSS0.75sq	CN-2F	————	CN-30F
917	WR	AVSS0.75sq	CN-1F	————	CN-36M
930	RG	AVS0.5sq	CN-4F	————	CN-51F
950	BrR	AVSS0.75sq	CN-1F	————	CN-30F
951	BL	AVSS0.75sq	CN-1F	————	CN-30F
952	BR	AVSS0.75sq	CN-1F	————	CN-30F
953	BrW	AVSS0.75sq	CN-1F	————	CN-30F
954	BrL	AVSS0.75sq	CN-1F	————	CN-30F
955	Gr	AVSS0.75sq	CN-1F	————	CN-30F
956	GrL	AVSS0.75sq	CN-1F	————	CN-30F
957	Br	AVSS0.75sq	CN-1F	————	CN-30F
958	BY	AVSS0.75sq	CN-1F	————	CN-31M
959	BG	AVSS0.75sq	CN-1F	————	CN-31M
960	BY	AVSS0.75sq	CN-2F	————	CN-30F
961	BW	AVSS0.75sq	CN-2F	————	CN-30F
962	GrG	AVSS0.75sq	CN-3F	————	CN-30F
963	BW	AVSS0.75sq	CN-3F	————	CN-31M
964	BL	AVSS0.75sq	CN-3F	————	CN-31M
965	BrB	AVSS0.75sq	CN-2F	————	CN-30F
966	BrY	AVSS0.75sq	CN-2F	————	CN-30F

WIRE NO	WIRE COLOR	WIRE SIZE	FROM	CONNECTION	TO
967	BW	AVSS0.75sq	CN-1F	————	CN-36M
981	GW	AVS0.5sq	CN-4F	————	CN-51F
982A	BG	AVS0.5sq	CN-51F	————	CN-26F
982B	BG	AVSS0.75sq	CN-32M	————	CN-26F
982C	BG	AVSS0.75sq	CN-30F	————	CN-26F
E1	B	AVS5sq	P-1	DOUBLE SPLICE	CN-33M
E21	B	AVSS1.25sq	P-1	————	CN-62F
E2	B	AVSS0.75sq	CN-5F	DOUBLE SPLICE	CN-30F
E3	B	AVSS0.75sq	CN-5F	————	CN-30F
E4	B	AVSS0.75sq	CN-30F	DOUBLE SPLICE	CN-35M
E5	B	AVSS0.75sq	CN-30F	————	CN-35M
E6	B	AVSS0.75sq	CN-29F	————	CN-28F
E7	B	AVSS0.75sq	CN-36M	————	CN-28F
E8	B	AVSS1.25sq	CN-32M	————	CN-28F
E9	B	AVSS1.25sq	CN-36M	————	CN-28F
E10	B	AVSS1.25sq	CN-43F	————	CN-28F
E11	B	AVSS0.75sq	CN-12F	————	CN-28F
E12	B	AVSS0.75sq	CN-60F	————	CN-28F
E13	B	AVSS1.25sq	M-1	DOUBLE SPLICE	P-3
E17	B	AVS5sq	P-2	DOUBLE SPLICE	P-3
E14	B	AVSS1.25sq	P-2	————	M-2
E15	B	AVSS0.75sq	M-3	————	CN-28F
E16	B	AVSS0.75sq	M-4	————	CN-28F
E18	B	AVSS0.75sq	M-5	————	CN-28F
E22	B	AVSS0.75sq	M-6	————	CN-28F

CONNECTORS SELECTION TABLE

CONNECTOR NAME (PIN NUM.)	MANUFUC.	PART. NUMBER	
		HOUSING	TERMINAL
3FA-CNA	AMP	172132-1	170032-2
2FA-CNA	AMP	172130-1	170032-2
1FA-CNA	AMP	172128-1	170032-2
1MA-CNA	AMP	172127-1	170340-1
2MA-CNA	AMP	172129-1	170340-1
2FA-CNA (L)	AMP	172128-5	170032-2
11FY-090II	YAZAKI	7283-1110	7116-4021
		7322-7616	
4FY-D090A	YAZAKI	7123-7144	7116-1181P
CA104	YAZAKI	7120-8012	7113-1020-02
CB104	YAZAKI	7120-1010	7115-1050-02
5FS-HITSUBA	SUMITOMO	6098-1493	1500-0207
			8240-4242
15FS-ISS	SUMITOMO	6441-6695	8169-6485
		5409-8599	
3MA-D5	AMP	1-353046-3	917803-2
100FA-SAI	AMP	179216-6	175266-2
			175269-1
	YAZKI		7116-2871
34MA-NEWSCCSI	AMP	177511-2	175272-1
			175273-1
32MA-NEWSCCS	AMP	178688-1	917067-5
			175273-1
18MA-NEWSCCS (Gr)	AMP	6-178692-6	175266-2
			175269-1
12FA-070MLI	AMP	176116-6	173631-1
34FA-040IPM	AMP	316022-6	175266-2
28FA-040IPM	AMP	316019-6	175266-2
22FA-040IPM	AMP	316016-6	175266-2
16FA-040IPM	AMP	316013-6	175266-2
16FA-HB	AMP	917981-6	175266-2
			175265-1
26FA-HB	AMP	917992-6	175266-2
			175269-1
22FA-HB	AMP	917982-6	175266-2
			175269-1
6FM-MWP	MITSUBISHI	PF805-06020	MT095-27250
12FA-040IPM	AMP	175965-2	173681-1
16FA-040IPM	AMP	175966-2	173681-1
12FA-070MLI	AMP	173631-1 (PLATING) 173631-2 (GOLD PLATING)	
8FA-070MLI	AMP	173850-1	173631-1

3.7-21 UPPER HARNESS ; LC13E01100P2 (1/2) ASIA




Fig.18 (1/2) Upper harness

3.9-12B INSTRUMENT PANEL LH HARNESS ; LC13E01127P1 KCME

LC09-06323~, YC09-03088~




Fig. 26E Instrument Panel LH Harness

CONNECTORS SELECTION TABLE

CONNECTOR NAME (PIN NUM.)	MANUFUC.	PART. NUMBER	
		HOUSING	TERMINAL
18FA-NEWSCCS (Gr)	AMP	6-178692-6	175266-2
			175269-1
8FA-070MLI	AMP	176113-6	173631-1
			173631-2
2FS-HM090	SUMITOMO	6090-1001	8240-4422
2FA-CNA	AMP	172130-1	170032-2
2FA-CNA (B)	AMP	172130-2	170032-2
20FS-HM090S (Gr)	SUMITOMO	6400-0081	8240-4422
		6409-0255	
6FA-CNA	AMP	171898-1	170032-2
8MA-070MLI	AMP	174931-1	173645-1

WIRE NO	WIRE COLOR	WIRE SIZE	FROM	CONNECTION	TO
4A	Y	AVSS0.75sq	CN-34M	DOUBLE SPLICE	CN-516F
4B	Y	AVSS0.75sq	CN-517F		CN-516F
15	WB	AVSS0.75sq	CN-505F		CN-32F
17	WL	AVSS0.75sq	CN-502F		CN-32F
84	WR	AVSS0.75sq	CN-506F		CN-32F
86	OW	AVSS0.75sq	CN-515F		CN-32F
87A	YV	AVSS0.75sq	CN-508F		CN-505F
87B	YV	AVSS0.75sq	CN-508F		CN-515F
87C	YV	AVSS0.75sq	CN-508F		CN-32F
89	BrL	AVSS0.75sq	CN-501F		CN-32F
91	Y	AVSS0.75sq	CN-502F		CN-32F
151	R	MVVS0.5sq	CN-500F		CN-32F
152	G	4芯シールド	CN-500F		CN-32F
153	W		CN-500F		CN-32F
154	B		CN-500F		CN-32F
SH	Gr		UNCONNECTED	X	CN-32F
329	LrR	AVSS0.75sq	CN-516F		CN-34M
330	Lr	AVSS0.75sq	CN-517F		CN-34M

WIRE NO	WIRE COLOR	WIRE SIZE	FROM	CONNECTION	TO
540	LG	AVSS0.75sq	CN-513F		CN-34M
542	GrG	AVSS0.75sq	CN-507F		CN-32F
543	GO	AVSS0.75sq	CN-512F		CN-34M
562	O	AVSS0.75sq	CN-510F		CN-32F
564	LY	AVSS0.75sq	CN-504F		CN-32F
583	VW	AVSS0.75sq	CN-513F		CN-32F
595	P	AVSS0.75sq	CN-520F		CN-32F
E2	B	AVSS0.75sq	CN-508F		CN-512F
E3	B	AVSS0.75sq	CN-508F		CN-501F
E4	B	AVSS0.75sq	CN-508F		CN-506F
E5	B	AVSS0.75sq	CN-508F		CN-507F
E6	B	AVSS1.25sq	CN-508F		CN-32F
E7	B	AVSS0.75sq	CN-508F		CN-515F
E8	B	AVSS0.75sq	CN-508F		CN-508F
E9	B	AVSS0.75sq	CN-504F		CN-508F
E10	B	AVSS0.75sq	CN-510F		CN-508F
E11	B	AVSS0.75sq	CN-520F		CN-508F

3.15A FUEL PUMP ASSY INSTALL LC08-06201~, YC08-03001~

FUEL PUMP ASSY INSTALL		LC22P00001F1		KCME 35L
ITEM	NAME	PART No.	Q'TY	REMARKS
1	FUEL PUMP ASSY	YT22P00001F5	1	M-11




Fig.50-1 Fuel pump assy install

3.15B FUEL PUMP ASSY INSTALL LC09-06323~, YC09-03088~

FUEL PUMP ASSY		LC22P00002F1		KCME 50L
ITEM	NAME	PART No.	Q'TY	REMARKS
1	FUEL PUMP ASSY	YN22P00011F1	1	
1-1	FUEL PUMP	YN22P00010P1	1	




Fig.50-2 Fuel pump assy install

3.15A-1 FUEL PUMP ASSY

FUEL PUMP ASSY		YT22P00001F5		KCME
ITEM	NAME	PART No.	Q'TY	REMARKS
10	ELECTRIC MOTOR	YT22P00001S010	1	
22	FUSE	YT22P00001S022	1	




Fig.51 Fuel pump assy

2) Flow return

When the front pump delivery pressure P1 or rear pump delivery pressure P2 is lowered, compensating rod (623) is pushed back by the spring force of outer spring (625) and inner spring (626) and lever 1 rotates centered on the E section. Feed back lever 1 (611) rotates putting fulcrum on the D point and spool moves leftward. Consequently the pressure flows into the tank port through C^l port, the pressure of the large bore section of the servo piston is released, servo piston moves leftward, and the pump delivery flow rate is raised.

The movement of servo piston is transmitted to spool with the feed back mechanism, and continues the action until the openings of spool and sleeve are closed.

(5) Low tilt angle (low flow rate) command priority mechanism

As described above, the tilt angle command for the flow rate control and horse power control is transmitted to feed back lever and spool through lever 1 and large bore sections (C,F sections) of lever 2, but the C and F sections are constructed so that pin Ø4 (0.157in) is protruded from large hole Ø8 (0.315in), and the pin (897) comes in contact with the large hole Ø8 (0.315in) of lever which makes the tilt angle smaller, and other large hole Ø8 (0.315in) of the lever in the condition of tilt angle in large radius is free without contact with pin (897). This way, the command for smaller tilt rotation side of flow control and horse power control has a priority according to the mechanical selecting system.

(6) Back-up function

As shown in Fig.1-14, loosen nut (801) and change the position of rod (642). This causes the electric flow control to be switched to the hydraulic control.

In the electric flow control, the secondary pressure Pi of the solenoid proportional reducing valve is admitted to the pilot piston to perform flow control of the pump.

In case the solenoid proportional reducing valve is disabled, the control mode is switched over to the hydraulic control if rod (642) is switched over.

The primary pressure PSV of the solenoid proportional reducing valve is admitted to pin (898) and controlled at a constant power level in a power shifted (reduced power) condition. The pressure of the Pn1 port is admitted to the pilot piston and performs flow control as the pressure goes up and down.

<Note>

Do not use the back-up select rod(642) when the front and rear regulators are fully closed or fully loosened. The pump can not be controlled if the position of the front regulator differs from that of the rear regulator.




Fig.1-16 Switching to back-up function




Fig.1-17 Power shift control

2.3 HYDRAULIC CIRCUIT




Table 2-4

No.	NAME
51	Main passage (P1 side)
52	Bypass circuit (P1 side)
53	Parallel circuit (P1 side)
54	Main passage (P2 side)
55	Bypass circuit (P2 side)
56	Parallel circuit (P2 side)
60	Arm recirculation passage
61	Arm recirculation low pressure passage
62	Arm recirculation cut passage
63	Swing conflux passage
64	Boom outer conflux passage
211	Lock valve selector spool
212	Negative control relief valve block
215	Negative control relief valve block
301	Boom spool
302	Arm spool
303	Swing spool
304	Bucket spool
305	Boom conflux spool
306	Travel spool
307	Travel straight spool
308	Arm conflux spool
309	P1,P2 bypass cut spool
310	Arm recirculation spool
311	Arm T2 spool
511	Poppet (D=25)
512	Poppet (D=20)
514	Lock valve poppet
515	Poppet (with restrictor)
601	Main relief valve
602	Over load relief valve
603	Over load relief valve
22E5	Spool for option valve 1
28E	Spool for option valve 2
N611	Negative control relief valve

Fig. 2-13 Hydraulic circuit

2) Arm out conflux

In operation 1), the oil delivered by pump P1 flows into the bypass circuit (52) through the main passage (51), but since the bypass circuit (52) and the low pressure circuit (D) are blocked by the bypass cut spool (309), it does not run into the low pressure circuit (D). Meanwhile, since the arm conflux spool (308) has now been changed over, the pressure oil of the bypass circuit (52) goes between the outer circumference of the arm conflux spool (308) and the casing.

Part of the delivered oil passes through the parallel circuit (53) and the restrictor, combines with the pressure oil of the bypass circuit (52), pushes the conflux check poppet (511) open, enters port Ba by way of the conflux circuit in the casing and finally combines with the pressure oil on the pump P2 side.





Fig. 2-25 At arm out operation (Bypass cut spool and arm conflux spool)

(10) Operation of over load relief valve

The over load relief valve is located between the cylinder port and the low pressure passage, functions as both a relief valve and an anti cavitation check valve, as mentioned below :

1) Operation as a relief valve

1. The pressurized oil enters the hole A through the clearance between piston (301) and plunger (511) and fills up chamber B. Thus plunger (511) is seated tightly against seat (541).



YN-B74

Fig. 2-37

2. When the hydraulic pressure of the port (P) arrives at a set pressure of the spring (621), it pushes the poppet (611) open, flows on the circumference of the poppet (611) and passes through the hole (C) to (R).




Fig. 2-38

YN-B74

3. When the poppet (611) opens, the hydraulic pressure in chamber B falls which causes the plunger (511) to open and allows the hydraulic pressure of port (P) to flow directly to (R).




Fig. 2-39

YN-B74

2) Operation of anti cavitation check valve

The check valve supplies oil from port (R) when a negative pressure is built up at port (P). When the pressure at (R) gets higher than that of port (P), the push-up force of circuit (R) gets stronger than the pressing force of chamber B.

This causes seat (541) to move to the right. Then the oil passes through the clearance of seat (541) and enters port (P) in sufficient quantity to fill up the vacancy.




Fig. 2-40

YN-B74

- The numbers of the parts of the over load relief valve in this section correspond to those in Fig.2-4.

This page is left blank for editing convenience.

6.2.2 REDUCTION UNIT




Fig6-3 Reduction unit

No.	NAME	Q'TY	No.	NAME	Q'TY	No.	NAME	Q'TY
1	COVER	1	16	THRUST WASHER 2	6	25	SOCKET BOLT ; M18×100	22
4	NEEDLE BEARING	3	17	RING GEAR	1	26	SOCKET PLUG ; PT3/4	2
5	THRUST WASHER 1	6	18	HOUSING	1	27	CARRIER 1	1
6	PLANETARY GEAR 1	3	19	BEARING	2	28	CARRIER PIN 1	3
8	THRUST PLATE	1	20	SHIM	1	29	SPRING PIN ; Ø6×36	3
9	SUN GEAR 1	1	21	LOCK WASHER	2	30	CARRIER 2	1
10	SUN GEAR 2	1	22	SUPPORT RING	1	31	CARRIER PIN 2	3
13	NEEDLE BEARING	3	23	FLOATING SEAL	1	32	SPRING PIN ; Ø10×56	3
14	PLANETARY GEAR 2	3	24	SOCKET BOLT ; M10×25	22			

7.3 CONSTRUCTION




Fig. 7-2 Construction

Table 7-2

No.	NAME	Q'TY	No.	NAME	Q'TY
1	BODY	1	7	O RING ; 1A G95	1
2	STEM	1	8	SOCKET BOLT; M8×20	2
3	THRUST PLATE	1	9	SOCKET BOLT; M8×30	4
5	SEAL ASSY	5	12	PLUG	1
6	SEAL ASSY	2	13	COVER	1




7.4 OPERATION

The swivel joint consists mainly of body(1) and stem(2) that rotate mutually, thrust plate(3) preventing both components from falling off, cover(13) closing one side of body(1), seal(5) that partitions off the circuits and O rings(6) and (7) that prevent external leaks.

Four ports for the travel main circuits are provided on body (1) and stem (2). Further, four oil passing grooves are arranged in the inner surface of body (1), with seal (5) fixed above and below the circumferential groove.

The body (1) and the stem (2) rotate mutually. The oil flowing in from body (1) or stem (2) keeps on flowing to stem (2) or body (1) past the circumferential groove between body (1) and stem (2); the oil flow is never shut off because of rotation. Further, an oil groove for lubrication that connects with the drain port is provided, in order to prevent the body (1) from seizure with the stem (2).

This construction keeps on connecting the circuits between the swing bodies by means of a swivel joint.

File No. Name of part Part No. Use Applicable Machine	Specification	Description												
<p>E-2</p> <p>Alternator</p> <p>ME049321</p> <p>Generator</p> <p>YN23301~,YQ02801~ YN07-30001~,YQ07-03501~ LC08-06201~,YC08-03001~ LC09-06323~,YC09-03088~</p>	<table border="1"> <tr> <td>Type</td> <td>3-phase AC method</td> </tr> <tr> <td>Voltage</td> <td>24V</td> </tr> <tr> <td>Output</td> <td>35A(900W)</td> </tr> <tr> <td>Drive</td> <td>A-Belt drive by pulley</td> </tr> <tr> <td>Speed increasing ratio</td> <td>1.87 (Ø168 / Ø90)</td> </tr> </table>	Type	3-phase AC method	Voltage	24V	Output	35A(900W)	Drive	A-Belt drive by pulley	Speed increasing ratio	1.87 (Ø168 / Ø90)	 <p>TERMINAL : P YAZAKI 7322-2215</p> <p>TERMINAL : E M6X1</p> <p>TERMINAL : B M8X1.25</p> <p>TERMINAL : E M6X1</p> <p>TERMINAL : B M8X1.25</p> <p>CONNECTOR YAZAKI 7322-6223-40</p> <p>FCD90</p>		
Type	3-phase AC method													
Voltage	24V													
Output	35A(900W)													
Drive	A-Belt drive by pulley													
Speed increasing ratio	1.87 (Ø168 / Ø90)													
<p>E-3</p> <p>Hour meter</p> <p>YT58S00006P1</p> <p>Service meter</p> <p>LC08-06201~ YC08-03001~ LC09-06323~ YC09-03088~</p>	<table border="1"> <tr> <td>Maker</td> <td>Hobbs Corp.</td> </tr> <tr> <td>Rated voltage</td> <td>DC 10~32V</td> </tr> </table> 	Maker	Hobbs Corp.	Rated voltage	DC 10~32V									
Maker	Hobbs Corp.													
Rated voltage	DC 10~32V													
<p>E-5,6</p> <p>Horn</p> <p>CM53S00002F2 (HIGH) CM53S00002F1 (LOW)</p> <p>Warning sound</p> <p>LC08-06201~ YC08-03001~ LC09-06323~ YC09-03088~</p>	<table border="1"> <tr> <td>Maker</td> <td>Maruko</td> </tr> <tr> <td>Rated voltage</td> <td>DC24V</td> </tr> <tr> <td>Operating voltage range</td> <td>DC 22~28V</td> </tr> <tr> <td>Sound level</td> <td>113±5 dB/2m</td> </tr> <tr> <td>Basic frequency</td> <td>420±20 Hz high sound 350±20 Hz low sound</td> </tr> <tr> <td>Insulation resistance</td> <td>More than 3MΩ/DC500V</td> </tr> </table> 	Maker	Maruko	Rated voltage	DC24V	Operating voltage range	DC 22~28V	Sound level	113±5 dB/2m	Basic frequency	420±20 Hz high sound 350±20 Hz low sound	Insulation resistance	More than 3MΩ/DC500V	<p>STAMP MARK MR-FH-03 : HIGH MR-FL-03 : LOW</p>
Maker	Maruko													
Rated voltage	DC24V													
Operating voltage range	DC 22~28V													
Sound level	113±5 dB/2m													
Basic frequency	420±20 Hz high sound 350±20 Hz low sound													
Insulation resistance	More than 3MΩ/DC500V													

File No. Name of part Part No. Use Applicable Machine	Specification	Description						
SV-1,2,3,4	<table border="1"> <tr> <td>Rated voltage</td> <td>90kgf/cm² (1280psi)</td> </tr> </table>	Rated voltage	90kgf/cm ² (1280psi)					
Rated voltage	90kgf/cm ² (1280psi)							
Solenoid valve (8 solenoid) Selector valve assy	<table border="1"> <tr> <td>Solenoid selector valve</td> <td>Rated voltage DC 24V</td> </tr> </table>	Solenoid selector valve	Rated voltage DC 24V	<table border="1"> <tr> <td>P1,T,A1 port</td> <td>PF3/8</td> </tr> <tr> <td>A2~A8 port</td> <td>PF1/4</td> </tr> </table>	P1,T,A1 port	PF3/8	A2~A8 port	PF1/4
Solenoid selector valve	Rated voltage DC 24V							
P1,T,A1 port	PF3/8							
A2~A8 port	PF1/4							
Refer to hydraulic symbol A1,A2,A7,A8	<table border="1"> <tr> <td>Solenoid proportional valve</td> <td>Dither current 100Hz,300mA P-P</td> </tr> <tr> <td></td> <td>Coil resistance 17.5±1Ω (at20°C)</td> </tr> </table>	Solenoid proportional valve	Dither current 100Hz,300mA P-P		Coil resistance 17.5±1Ω (at20°C)			
Solenoid proportional valve	Dither current 100Hz,300mA P-P							
	Coil resistance 17.5±1Ω (at20°C)							
YN35V00022F1 YN07-30001~,YQ07-03501~ LQ08-04501~,LL08-03001~ LC06-05501~,YC06-02501~ LC08-06201~,YC08-03001~ LC09-06323~,YC09-03088~	<table border="1"> <tr> <td>Connector specification</td> <td>SUMITOMO DENSO HW : 090 connector M(2P) HOUSING part No. : Equivalent 6181-0070 TERMINAL part No. : Equivalent 1500-0105</td> </tr> </table>	Connector specification	SUMITOMO DENSO HW : 090 connector M(2P) HOUSING part No. : Equivalent 6181-0070 TERMINAL part No. : Equivalent 1500-0105					
Connector specification	SUMITOMO DENSO HW : 090 connector M(2P) HOUSING part No. : Equivalent 6181-0070 TERMINAL part No. : Equivalent 1500-0105							
PSV-A,B,C,D Proportional solenoid valve Refer to hydraulic symbol A3~A6 YN07-30001~ YQ07-03501~ LC06-05501~ YC06-02501~ LC08-06201~ YC08-03001~ LC09-06323~ YC09-03088~								
	<p style="text-align: center;">Hydraulic symbol</p>	<p style="text-align: center;">VIEW Y</p>						






Fig. 2(2/3) Installing air conditioner and heater

HEATER CIRCUIT



AIR CONDITIONER CIRCUIT




Fig. 2(3/3) Installing air conditioner and heater

A/C PIPING				LC20M00020F1			
Tightening torque kgf·m (lbf-ft)	No.	NAME	Q'TY	Tightening torque kgf·m (lbf-ft)	No.	NAME	Q'TY
	1	HOSE ; L=3700	1	5.3 (38.4)	19	WASHER	10
	2	SUPPORT	2		20	WASHER	8
	3	V BELT : B-47.5 COG	1		21	CLIP	2
	4	GROMMET	1		22	TUBE ; L=1200	1
	5	CLIP	4		23	TUBE ; L=350	1
1.7 (12.3)	6	CLIP	6	24	24	CONNECTOR	1
	8	CAPSCREW ; M10×20	2		25	BUSHING	1
	9	CAPSCREW ; M8×30	4		26	CAPSCREW ; M10×30	6
	10	CAPSCREW ; M6×20	2		27	BRACKET	1
	11	CAPSCREW ; M8×16	2		28	CLIP	1
	0.45 (3.3) 2.7 (20)	12	CAPSCREW ; M6×50		6	29	29
13		CAPSCREW ; M8×100	4	30	WASHER		4
14		LOCK WASHER	6	31	HOSE ; L=500		1
15		LOCK WASHER	8	32	TUBE ; L=600		1
16		CLIP	3	33	TUBE ; L=450		1
18		WASHER	9				

2) Replacing the air mix motor actuator

Disconnect the connector connected with the motor actuator.

Separate the rod 67 linking the motor actuator with the lever AM, from the rod holder.

Remove three cross-recessed screws T4×14 (T1) fastening the motor actuator. Then remove the motor actuator with the rod holder and the lever MAL1, from the unit. Remove the rod holder and the lever MAL1 from the motor actuator and install them to a new motor actuator. Assembly is the reverse order of disassembly.




Fig. 23

3) Replacing the inner/outer air select motor actuator

Disconnect the connector connected with the motor actuator.

Separate the motor actuator with lever MAL2 from the unit.

Remove the lever MAL2 from the motor actuator and install it to a new motor actuator, in the reverse order of disassembly.






Fig. 24

[Blower motor does not run.]



[Blower motor speed does not change.]



3. ARM

3.1 REMOVING ARM

- (1) Put the machine in position to remove arm.
Extend the arm cylinder, retract the bucket cylinder and bring the arm down on the ground.




Fig. 3-1 Position to remove arm

- (2) Disconnecting piping of bucket cylinder
Release pressure of hydraulic tank, place oil pan to prepare for oil leaking, and separate pipes.

- ⚠** Plug both section of separated pipes.
ORS Plug : 4-(4)

When the removal of bucket cylinder is not required, skip to procedure (6).






Fig. 3-2 Disconnecting piping of bucket cylinder

- (3) Removing bucket cylinder rod pin (H)
 - 1) Loosen nut (13), remove capscrew M20×180 (12), and push out pin (H).

 : 30mm

- 2) Retract cylinder rod.



After adjustment of shim, the total gap should be within 0.6~1.0mm (0.02~0.04in).






Fig. 3-3 Detail of bucket cylinder rod pin (H)

- (4) Removing cylinder head pin (G)
 - Loosen nut (3), remove capscrew M20×165 (2), and push out pin (G).

 : 30mm



After adjustment of shim, the total gap should be within 0.6~2.0mm (0.02~0.08in).

SECTION A-A

Fig. 3-4 Detail of bucket cylinder head pin (G)

5) After removing cushion bearing (13) and cushion seal (14), separate rod cover (3) from piston rod (2). If it is too hard to slide it, knock the flanged part of rod cover (3) with a plastic mallet. But when drawing it out, lift rod cover (3) by crane and pull it straight horizontally.

⚠ Take care so rod bushing (4) and the lip of packings (6,7,8,9) may not be damaged by thread of the piston rod (2).




Fig. 1-14 Removing rod cover (3)

1.3.3 DISASSEMBLING PISTON ASSY

1) Remove seal ring (16) and back-up ring (17).

⚠ Cut the seal ring (16) by tapping it with a screwdriver or a chisel. Take care not to strike it too hard, otherwise the groove may be damaged.





Fig. 1-15 Removing seal ring (16) and back-up ring (17)

1.9.2 OTHER SPECIAL JIGS
(PREPARED BY SERVICE SHOP)

1) Bushing extraction jig (Symbol J)



MATERIAL : Mild steel




Fig. 40 Bushing extraction jig

Table 9 Unit : mm (inch)

d	D	Cylinder Used
90 (3.54)	105 (4.13)	Bucket
110 (4.33)	125 (4.92)	Arm
110 (4.33)	125 (4.92)	Boom (Rod side)
100 (3.94)	115 (4.53)	Boom (Bottom side)

2) Wrench for piston nut




Fig. 41 Wrench for piston nut

Table 10 Unit : mm (inch)

B	Cylinder Used
135 (5.32)	Arm
110 (4.33)	Boom
115 (4.53)	Bucket

3. BATTERY

3.1 REMOVING

- (1) Open right cover assy.
 - 1) Open it with starter key. (Marked \rightarrow)
 - 2) Open cover assy (7). (Refer to 4. GUARD)
 - 3) Fix it with stay.






Fig. 3-1 Preparation for removing battery

- (2) Remove battery cable
 - 1) Remove cable (C4) [between the ground and battery \ominus]. (Always remove \ominus terminal first and install it at last.)
 - 2) Cable (C2) [between battery \oplus and \ominus]
 - 3) Cable (C3) [between battery \oplus and battery relay]

 : 13mm

-  Follow the battery removal order. Start removing battery from grounding side, and finish attaching to grounding side. If this order is missed, short-circuits may occur.







Fig. 3-2 Removing battery cable

- (3) Remove battery (B1)
 - 1) Remove four nuts (A3) M8.
 : 13mm
 - 2) Remove bracket (A1) and rod (A2).
 - 3) Remove battery (B1).

3.2 INSTALL

- (1) Install the battery in the reverse procedure of removing.
Nut (A3) of battery attaching rod (A2)
 : 13mm,
Tightening torque : 1.1kgf-m (8.0 lbf-ft)

- (2) Installing grounding cable
Install grounding cable last. Especially care must be taken that the grounding face is free from painting, rust, etc.
 : 13mm




Fig. 3-3 Removing battery

(3) Removing other hoses

1) Disconnect hoses of the following ports.

(See Fig. 8-4.)

Port	Tool	Remarks
Pn1	19	P1 pump negative control pressure
Pn2	19	P2 pump negative control pressure
Dr3	19,22	Drain
Psv1	19	Pilot primary pressure P1 side
Psv2	19	Pilot primary pressure P2 side
A3	19,22	Pilot pump delivery
B3	36	Pilot pump suction

2) Attach tags to hoses to identify.

3) Put a plug in the hoses and the pump.

(4) Remove connector

Remove six connectors of all pressure sensors and proportional valves.




Fig. 8-4 Hydraulic pump port




Fig. 8-5 Removing connector

15. MULTI CONTROL VALVE (IF EQUIPPED)

15.1 PREPARATION FOR REMOVAL

- (1) Discharge inner pressure from the hydraulic circuit system.
(Refer to 8. HYDRAULIC PUMP)
- (2) Bleed pressure air in hydraulic tank
(Refer to 7. HYDRAULIC TANK.)




Fig. 15-1 Removing multi control valve

15.2 REMOVAL

- (1) Attach tag on which hose name is entered to the remote control hoses between multi control valve and main control valve, and write numbers C1 to C8 on it.
Remove the hose on the multi valve side and put a plug in each opening.
Refer to LC11 Tool of Plug (3).
- (2) Attach tag on which hose name is entered to the remote control hoses between multi control valve and pilot V, and write numbers P1 to P8 on it.
- (3) Remove hoses P1 to P8 on multi control valve side and plug connection.
Refer to LC11 Tool of Plug (3).
- (4) Take off four capscrews (B8) M8×16. Then remove multi control valve (B1) from the body.




Fig. 15-2 Connection between multi control valve and C/V

15.3 INSTALLATION

- (1) Installing is done in the reverse order of removing
- (2) Relations between pilot valve and multi control valve hose

P/V port	Hose		ISO operation pattern	multi port	mark -ing
	Size	Color			
Right side	1	3/8 Red	Bucket digging	P1	1
	2	3/8 Blue	Bucket dump	P2	2
	3	3/8 Green	Boom up	P3	3
	4	3/8 Gray	Boom down	P4	4
	P	1/4 Black	Pilot primary	—	—
	T	3/8 Black	Drain	—	—
Left side	5	3/8 Gray	Swing left	P5	5
	6	3/8 Red	Swing right	P6	6
	7	3/8 Blue	Arm in	P7	7
	8	3/8 Green	Arm out	P8	8
	P	1/4 Black	Pilot primary	—	—
	T	3/8 Black	Drain	—	—




Fig. 15-3 Connection between P/V and multi control valve

This page is left blank for editing convenience.

1.2 REGULATOR

1.2.1 STRUCTURAL EXPLODED VIEW




Fig. 1-20 Structural exploded view of regulator

Table 1-4


TIGHTENING TORQUE kgf·m (lbf·ft)	No.	NAME	Q'TY	TIGHTENING TORQUE kgf·m (lbf·ft)	No.	NAME	Q'TY
3.0 (22)	412	SOCKET BOLT: M8×50	2		614	FULCRUM PLUG	1
3.0 (22)	413	SOCKET BOLT: M8×70	2		615	ADJUST PLUG	1
0.7 (5.1)	418	SOCKET BOLT: M5×12	2		621	COMPENSATING PISTON	1
1.2 (8.7)	438	SOCKET BOLT: M6×20	10		622	PISTON CASE	1
1.2 (8.7)	439	SOCKET BOLT: M6×35	3		623	COMPENSATING ROD	1
3.7 (27)	466	VP PLUG: PF1/4	1		624	SPRING SEAT (C)	1
3.5 (25)	467	PLUG ; PF3/8×M6	1		625	OUTER SPRING	1
0.9 (6.5)	496	PLUG ; SEAL COATED	12		626	INNER SPRING	1
	541	SEAT	2		627	ADJUST STEM (C)	1
	543	STOPPER 1	2		628	ADJUST SCREW (C)	1
	545	STEEL BALL	2	16 (120)	629	COVER (C)	1
	601	CASING	1		630	LOCK NUT: M30×1.5	1
	611	FEED BACK LEVER	1		631	SLEEVE	1
	612	LEVER (1)	1		641	PILOT COVER	1
	613	LEVER (2)	1		642	ROD	1
					643	PILOT PISTON	1
					644	SPRING SEAT (Q)	1
					645	ADJUST STEM (Q)	1
					646	PILOT SPRING	1
					651	SLEEVE	1
					652	SPOOL	1
					653	SPRING SEAT	1
					654	RETURN SPRING	1
					655	SET SPRING	1
					656	BLOCK COVER	1
					708	O RING : 1B G75	1
					722	O RING : 1B P6	3
					724	O RING : 1B P8	8
					725	O RING : 1B P10	1
					727	O RING : 1B P14	1
					728	O RING : 1B P18	1
					730	O RING : 1B P22	1
					732	O RING : 1B P16	2
					733	O RING : 1B P20	1
					734	O RING : 1B P25	1
					753	O RING : 1B P9	1
					755	O RING : 1B P11	5
					756	O RING : 1B P26	1
					757	O RING : 1B P12	1
					763	O RING : 1B G35	1
1.6 (12)	801	NUT : M8	3		814	SNAP RING	1
	836	SNAP RING	1		858	SNAP RING	2
	874	PIN ; Ø4×11.7L	1		875	PIN ; Ø4×8L	4
	887	PIN	1		897	PIN ; Ø4×19L	1
	898	PIN ; Ø8.5×10L	1		924	SET SCREW: M8×20	1
	925	ADJUST SCREW (Q)	1		079	SOLENOID PROPORTIONAL REDUCING VALVE	1

The codes in a rectangle represent adjust screws. Do not tamper with the adjust screws as much as possible.

(1) Remove option valve block and negative control relief valve

1) Remove P2 side option valve block and negative control relief valve block


Loosen the socket bolts (272) and remove the option valve block (214) and negative control relief valve block (215).

 : 10mm

- ▲ ● Regarding the disassembly of the optional valve block, refer to the Disassembling option valve under (20) on page II-2-17.
- Regarding the disassembly of the negative control relief valve block, refer to the Disassembling option valve under (21) on page II-2-17.

2) Remove P1 side option valve block and negative control relief valve block

Loosen the socket bolts (271) and remove the option valve block (213) and negative control relief valve block (215).

 : 10mm

- ▲ ● Regarding the disassembly of the optional valve block, refer to the Disassembling option valve under (20) on page II-2-17.
- Regarding the disassembly of the negative control relief valve block, refer to the Disassembling option valve under (21) on page II-2-17.




Fig.2-3 Removing optional valve block (OPT-2) and the negative control relief valve block. (The numbers in the parentheses are the ones without an optional valve.)




Fig.2-4 Removing optional valve block (OPT-1) and the negative control relief valve block. (The numbers in the parentheses are the ones without an optional valve.)

(16) Remove check valve

1) Conflux check valve (CCb)

Loosen plug (551) and remove poppet (511) and spring (521).

⌒ : 12mm

Remove the load check valve the same way.

(CP1,LCc,LCb,CCa)

(CP2,LCa,LCs)




Fig. 2-43 Removing check valve

2) Lock valve section (Arm ; CRa, Boom ; CRb)

Loosen plug (556) and remove poppet (514) and spring (524).

⌒ : 12mm

⚠ Exercise care so as not to mistake them as they all differ in kind from 1) above.

3) Travel straight section (CT1)

Remove plug (552). Then remove poppet (515) and spring (522).

⌒ : 10mm

⚠ Poppet (515) is a special poppet for travel straight that is used at one location only. Therefore, be careful so as not to mix it up with others when reassembling it.

4) Main relief valve section (CMR1,CMR2)

Remove plug (552) and remove poppet (512) and spring (522).

⌒ : 10mm

5) Recirculation check valve (CAr)

Remove plug (552) and remove poppet (512) and spring (522).

Remove the load check valve the same way.

⌒ : 10mm

Those plugs that are not mentioned in the foregoing disassembly procedure are blind for extra holes and cast-on holes; do not remove them unless necessary.




Fig. 2-44 Removing poppet in the lock valve section




Fig. 2-45 Removing poppet in the main relief section




Fig. 2-46 Removing arm recirculation check valve

Trouble	Cause	Remedy
<p>3. Excessive natural falls of attachment under its own weight when spool is in neutral.</p>	<p>1) Excessive clearance between casing and spool.</p> <p>2) Spool is not completely in neutral position.</p> <ul style="list-style-type: none"> ● Foreign matter between casing and spool, or sticking spool. ● Broken or deformed spring. ● Clogged pilot circuit. <p>3) Malfunctioning overload relief valve. Refer to item 1. 1) above.</p> <p>4) Malfunctioning anti-cavitation check valve.</p> <ul style="list-style-type: none"> ● Foreign matter between poppet and casing. ● Broken or deformed spring. <p>5) Lock valve function is faulty.</p> <ul style="list-style-type: none"> ● Foreign matter between poppet and casing. ● Poppet is stuck. ● Broken or deformed spring. ● Selector spool is stuck. ● Dirt is included between selector spool and bushing. ● O ring in bushing is worn out. 	<p>1) Replace spool.</p> <p>2) Measure secondary pilot pressure.</p> <ul style="list-style-type: none"> ● Disassemble, clean and smooth sticking part with oil stone. ● Replace spring. ● Remove foreign matter. <p>3) Measure overload relief valve pressure. Refer to item 1. 1) above.</p> <p>4) Checking the overload relief valve</p> <ul style="list-style-type: none"> ● Disassemble and clean. ● Replace spring. <p>5)</p> <ul style="list-style-type: none"> ● Disassemble and clean. In case scratches are excessive, replace casing. ● Correct stuck part with oil stone. ● Replace spring. ● Replace lock valve selector sub assy. ● Replace lock valve selector sub assy. ● Replace lock valve selector sub assy.
<p>4. When raising attachment, at first it drops.</p>	<p>1) Malfunctioning load check valve.</p> <ul style="list-style-type: none"> ● Foreign matter between poppet and casing. ● Sticking poppet. ● Broken or deformed spring. 	<p>1)</p> <ul style="list-style-type: none"> ● Disassemble and clean. If heavily damaged, replace control valve. ● Smooth sticking part with oil stone. ● Replace spring.
<p>5. Bucket, boom, arm or swing does not operate.</p> <p>Slow to start up (or poor power).</p> <p>Slow response.</p>	<p>1) Malfunctioning main spool.</p> <ul style="list-style-type: none"> ● Excessive clearance between casing and spool. ● Foreign matter between casing and spool. ● Sticking spool. ● Broken or deformed return spring. ● Clogged pilot circuit. <p>2) Malfunctioning main relief valve. Refer to item 1. 1) above.</p> <p>3) Malfunctioning overload relief valve. Refer to item 1. 1) above.</p> <p>4) Malfunctioning pilot valve. Refer to Pilot valve section.</p>	<p>1) Measure secondary pilot pressure.</p> <ul style="list-style-type: none"> ● Replace spool. ● Disassemble and clean. ● Smooth stuck part with oil stone. ● Replace spring. ● Remove foreign matter. <p>2) Measure main relief valve pressure. Refer to item 1. 1) above.</p> <p>3) Measure overload relief valve pressure. Refer to item 1. 1) above.</p> <p>4) Refer to Pilot valve section.</p>

4. PILOT VALVE (FOR TRAVEL)

4.1 CONSTRUCTION

(1) Sectional view




Fig.4-1 Sectional view of pilot valve (for travel)

☆Apply Loctite #262

TIGHTENING TORQUE kgf·m (lbf·ft)	NO.	NAME	Q'TY	TIGHTENING TORQUE kgf·m (lbf·ft)	NO.	NAME	Q'TY	
☆1.5 (11)	1	ORIFICE (SHIM)	4	1.0 (7.2)	22	SPRING	4	
	2	SEAT	2		24	PLUG ; PF1/8	3	
	3	ORIFICE (SHIM)	4		25	PLUG ; PF1/4	3	
	4	SPOOL	4		26	SOCKET BOLT ; M10×60	2	
	5	BODY	1		27	FLANGE BOLT	4	
	6	STOPPER	4	1.5 (11)	28	SET SCREW ; M8	4	
	7	SPRING	4		29	WASHER	4	
	8	SPRING	4		30	WASHER	2	
	9	NAME PLATE	1		31	RIVET	2	
	10	SHIM t=0.2	4		32	PIN ; Ø5	4	
	11	SHIM t=0.1	4		1.5 (11)	33	BALL	6
	12	CAM	2			34	BALL	4
	13	BOOTS	2			35	BALL	4
	14	PIN	2			36	BALL	6
		15	COVER		2	37	U PACKING	4
16		PISTON	4	1.5 (11)	38	O RING ; 1A P5	4	
17		GUIDE	4		39	O RING ; 1A P24	4	
18		SLEEVE	4		40	O RING ; 1A P26	4	
19		HOLDER	4		41	O RING ; 1B P8	3	
20		RING	12		42	O RING ; 1B P11	3	
21		ORIFICE (SHIM)	4					

5.2.3 ASSEMBLY

(1) General precautions

- 1) Repair those parts damaged after disassembly and prepare replacement parts beforehand.
- 2) Clean all parts thoroughly in cleaning oil and dry them with jet air.
- 3) Always coat the moving parts with clean hydraulic oil, before assembly.
- 4) Replace such seals as O ring and oil seal in principle.
- 5) Tighten socket bolts and plugs to specified torques, using a torque wrench.

(2) Assembly procedure

The figures in parentheses after part names in this manual represent those item numbers in the Fig. 5-1 and Fig. 5-2.

- 1) Assemble snap ring (432) and bearing spacer (106) into drive shaft (101). Heat the inner race of roller bearing (443) to 100~120°C (212~248°F) and put it into the shaft. Then insert bearing spacer (106) and place snap ring (432).

! Assemble the round corner side of the bearing into the bearing spacer (106) side.

- 2) Heat the inner race of roller bearing (444) to 100~120°C (212~248°F), put it into drive shaft (101), and fit snap ring (433).

! Assemble the round corner side of the bearing into the bearing spacer (106).




Fig.5-11 Fitting roller bearing (443)




Fig.5-12 Fitting roller bearing (444)






5.4 MAINTENANCE STANDARDS

5.4.1 SWING MOTOR

(1) Replacement standards for parts

The following are the standards to determine whether or not parts may be reused from values taken at disassembly. These are only general standards and in case the motor displays poor performance or parts shows extreme damage and discoloration before

disassembly, it is most important to determine which parts should be replaced, depending upon the purpose of disassembly and the remaining service life of the motor.

Item	Standard Dimension mm (in)	Recommended Value for Replacement mm (in)	Remedy
Clearance between piston and cylinder bore (D-d) 	0.032 (0.00126)	0.062 (0.00244)	Replace piston or cylinder.
Gap between piston and caulked part of shoe (σ) 	0	0.3 (0.0112)	Replace piston and shoe assy.
Thickness of shoe (t) 	6 (0.236)	5.8 (0.228)	Replace piston and shoe assy.
Assembled height of retainer plate and spherical bushing (H-h) 	7 (0.276)	6.5 (0.256)	Replace a spherical bushing and a retainer plate as a pair.
Thickness of friction plate 	4 (0.157)	3.6 (0.142)	Replace.

6.3 MAINTENANCE STANDARDS

6.3.1 INSPECTION PROCEDURE AND REMEDY

Table 6-3

Interval	Check Item	Checking Procedure	Remedy
2,000Hrs.	Seal for oil leakage outside	Check oil leakage outside	Replace O ring or dust seal , if any oil leakage can be found.
4,000Hrs. In principle, disassemble and check re- regardless of oil leakage or not.	All sealing parts		Replace all sealing parts such as slipper seal with back-up ring and O ring.
	All sliding parts	Check abnormal wear, scoring or corrosion caused by foreign matters or seizure.	Repair or replace referring to their limit of service.
When disassembled for repair	All parts	Check them for seizure, foreign matters, abnormal wear, and defect of seals.	Repair or replace referring to their limit of service. O rings and dust seal should be replaced.

6.3.2 SERVICE LIMIT OF THE PARTS

Table 6-4

Parts		Maintenance Standards	Remedy
Body, Stem	Sliding surface with sealing sections	Plating worn or peeled due to seizure or contamination.	Replace
	Sliding surface between body and stem other than sealing sections	1) Worn abnormally or damaged more than 0.1mm (0.004in) in depth due to seizure or contamination.	Replace
		2) Damaged less than 0.1mm (0.004in) in depth.	Smooth with oilstone.
	Sliding surface with thrust plate	1) Worn more than 0.5mm (0.02in) or abnormality.	Replace
		2) Worn less than 0.5mm (0.02in).	Smooth
		3) Damage due to seizure or contamination repairable within wear limit 0.5mm (0.02in).	Smooth
Cover	Sliding surface with thrust plate	1) Worn more than 0.5mm (0.02in) or abnormality.	Replace
		2) Worn less than 0.5mm (0.02in).	Smooth
		3) Damage due to seizure or contamination repairable within wear limit 0.5mm (0.02in).	Smooth

- 7) Removing floating seal (12). (Upper roller side)
Take out floating seal (12) from roller (1).




Fig. 3-6 Taking out floating seal

- 8) Removing floating seal (12). (Shaft side)
Remove from collar (3), floating seal (12) that is located on the side from which shaft (2) was disparted.

- ⚠ Collar (3) is press fitted into shaft (2).
Therefore do not disassemble it.




Fig. 3-7 Removing floating seal

- 9) Removing bushing (6)
Since the bushing is thin, machine it on a lathe or scrape it off, exercise care so as not to damage the bore of roller (1).

- (2) Assembly
Assembly of the upper roller is done in the reverse order of disassembly.
- 1) Place upper roller (1) on the top end face of jig (f), with its floating seal setting side facing down.
 - 2) Confirm that the outer surface of bushing (6) is not seized and coat the outer surface of the inserting side of the bushing, with molybdenum disulfide grease.
 - 3) Put jig (i) into bushing (6) and press it in, using the bore of the bushing and the bore of the roller as guides.




Fig. 3-8 Pushing in bushing

- ⚠ If you fail in this operation by pressing the bushing unevenly, the bushing is distorted and gets unserviceable. In that case, do not re-use the bushing as it may develop malfunctioning after assembly.




Fig. 3-9 Fixing floating seal

5) Removing bushing (4)
 With idler (1) mounted on the stand, tap bushing (4) lightly by hammer, while placing the bushing drawing rod (T) against the end face of bushing (4) evenly all round, till it comes out.

6) Removing floating seals (6)
 Take out floating seals (6) from idler (1), collar (2). If you intend to re-use floating seals (6), confirm that there is no scoring and rusting on the contact surface and store the floating seals in pairs by placing card board between the sealing faces.

7) Removing O ring (7)
 Separate O ring (7) from shaft (3).




Fig. 5-8 Removing bushing (2)

(2) Assembly

1) Pressing in bushing (4)
 Align inner hole of idler (1) and bushing (4) and press fit it vertically with press so that jig (V) for bushing press-fitting is inserted into bushing (4).




Fig. 5-9 Pressing in bushing (4)

2) Installing O ring (7)
 Fit O ring (7) to O ring groove on shaft (3).

- Apply grease to O ring

3) Installing collar (2) (See Fig. 5-10)
 Press fit the O ring (7) installed side of shaft (3) into collar (2), and drive pin (5).




Fig. 5-10 Installing collar (2), shaft (3)

4) Installing floating seal (6)
 Fit the half of floating seal (6) on each side of collar (2) and idler (1).

5) Inserting idler (1)
 Insert floating seal (6) fitted side of idler (1) into shaft (3).

6) Installing floating seal (6)
 Fit floating seal (6) on the other side of idler (1).




Fig. 5-11 Inserting idler (1) and installing floating seal (6)

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

1. REMOVAL AND INSTALLATION OF TRAVEL MOTOR UNIT

1.1 CONSTRUCTION OF TRAVEL MOTOR





Fig.1-1 Construction of travel motor

LC08-06261~, LC09-06323~ YC08-03039~, YC09-03088~					LC15V00007F3				
LC08-06201~ YC08-03001~					LC15V00007F1				
T. torque kgf·m(lbf·ft)	Opposing flats mm	No.	NAME	Q'TY	T. torque kgf·m(lbf·ft)	Opposing flats mm	No.	NAME	Q'TY
		1	CASING	1 ←			25	M6 ORIFICE ; Ø0.8	1 ←
		2	REAR COVER	1 ←			26	OIL SEAL	1 ←
		3	CYLINDER BLOCK	1 ←			27	SPRING	3 ←
		4	SHOE RETAINER	1 ←			28	SPRING(CYLINDER)	9 ←
		5	FRICITION PLATE	4 ←			29	SPRING(BRAKE)	14 ←
		6	BRAKE PISTON	1 ←			30	BEARING	1 ←
		7	SEPARATOR PLATE	5 ←			31	REAR BEARING	1 ←
		8	VALVE PLATE	1 ←	33 (240)	14	32	SOCKET BOLT ; M18×50	10 ←
		9	SHAFT	1 ←			33	SHIM	1or2 ←
		10	COUPLING	1 ←			34	PARALLEL PIN ; Ø8×12	1 ←
		11	SHOE PLATE	1 ←			35	O RING ; 1B P6	3 ←
		12	BALL JOINT	1 ←			36	O RING ; 1B P8	2 ←
		13	SPRING RETAINER	1 ←			37	O RING ; 1B P9	3 ←
		14	PISTON ASSY	9 ←			38	O RING ; 1B S10	1 ←
		15	D RING (SMALL)	1 ←			39	O RING ; 215.57×2.62	1 ←
		16	D RING (LARGE)	1 ←	10~12 (72~87)	32	40	OVER LOAD RELIEF VALVE ; M27	2 ←
		17	CHECK VALVE	3 ←			41	PILOT VALVE	1 ←
		18	SNAP RING	1 ←			42	BRAKE VALVE	1 ←
		19	SNAP RING	1 ←			43	PLUG ; NPT 1/16	1 ←
		20	TILTING PISTON	1 ←			44	PLUG ; NPT 1/16 MEC	4 ←
		21	BALL	1 ←			45	EXPANDER	1 ←
		22	PIVOT	2 ←			50	O RING ; Ø200	1 ←
		23	PISTON SEAL	1 ←			51	O RING ; Ø214 B	1 ←
		24	M6 ORIFICE ; Ø0.6	1 ←					

• Over load relief valve



Note) Quantities are worth one overload relief valve.

Tightening torque kgf·m(lbf·ft)	Opposing flats mm	No.	NAME	Q'TY	Tightening torque kgf·m(lbf·ft)	Opposing flats mm	No.	NAME	Q'TY
11 (80)	32	40-1	SOCKET	1			40-8	SHIM	1
		40-2	VALVE	1			40-9	ADJUSTMENT SPRING	1
		40-3	VALVE SEAT	1			40-10	O RING ; 1B P7	1
		40-4	CONNECTING PISTON	1			40-11	BACK UP RING	2
16 (120)	35	40-5	PLUG	1			40-12	O RING ; 1B G25	2
		40-6	PILOT BODY	1			40-13	BACK UP RING	1
		40-7	PISTON	1					

Inspection Item/Method	Criterion and Remedy
<p>(5) Shaft</p> <p>Measure the wear of the shaft seal by means of a roughness meter.</p> <p>(6) Bearing</p> <p>Replace bearing</p>	<p>Allowable stepped wear is up to 0.5mm (0.002in).</p> <p>⚠ When the shaft is to be replaced, replace the oil seal (26) at the same time.</p> <p>When replacing the shaft, the thickness of shims (33) must be adjusted.</p> <p>Replace bearing (30) and bearing (31) within 10,000 hours on the hour meter.</p> <p>⚠ When replacing the bearings, replace the inner race and the outer race at the same time.</p> <p>When the bearings have been replaced, the thickness of shims (33) must be adjusted.</p>
<p>(7) Spline</p> <p>Replace spline if it is worn beyond its allowable limit.</p>	<p>Serviceable stepped wear is up to 0.3mm (0.012in) on the contact surface.</p>
<p>(8) Overload relief valve section</p> <p>This is the overload relief valve section. Pressure can not be checked and regulated without a special test bench.</p>	<p>Replace the sub assembly every 10,000 hours on the hour meter.</p>

1.9 MAINTENANCE STANDARD

1.9.1 INSPECTION BEFORE REASSEMBLY

(1) Thrust washer

- 1) Check to see that there is no seizure, abnormal wear and uneven wear.
- 2) Check that the wear does not exceed an allowable value.

(2) Gears

- 1) There is no pitching and seizure on the gear tooth surface.
- 2) Inspect that the root of gears is not cracked by liquid penetrant examination technique.

(3) Bearing

Turn it by hand and check to see that it turns without unusual sound and resistance.

(4) Floating seal

Inspect that the moving parts and O rings are not scored.

1.9.2 SERVICING PARTS

The following are reference values by which the serviceability of used parts is determined. Since these serve as general reference, it is recommended that the extent of disassembly be decided depending upon performances, excessive damage or discoloration of components, the purpose of disassembly and remaining service life that is expected.




Fig.1-45

Maintenance Standard

Code	Item	Standard value	Allowable value	Remedy
A	Planetary shaft is worn.	To be smooth, no abnormal wear and seizure.	←	Replace 3 shafts as a set.
B	Tooth face and root condition	To be smooth, no abnormal wear and seizure.	No pitching over $\varnothing 1.6\text{mm}$ (0.063) and no crack at root of gear.	Replace 3 planetary gears as a set.
C	Thrust clearance of angular bearing inner race	-0.08mm (0.0032) [Interference] to $+0.02\text{mm}$ (0.0008) [Clearance]	←	Replace shims. [See.1.8 (6)]
D	Thickness of thrust washer 1	$2.7 \pm 0.2\text{mm}$ (0.106 ± 0.008)	Wear 0.1mm (0.004)	Replace
E	Thickness of thrust washer 2	$3.2 \pm 0.2\text{mm}$ (0.126 ± 0.008)	Wear 0.1mm (0.004)	Replace

1.2 HYDRAULIC PRESSURE MEASUREMENT BY SERVICE DIAGNOSIS

(1) Main circuit pressure.

E/G Hi, Full lever, at relief	E/G Hi, No load, at neutral
No.14 PRESS. SENSOR C-1 PUMP P1 3.3V 35M C-1 PUMP P2 3.3V 35M	Main pump P1,P2 0.7V 3.0M 0.7V 3.0M
No.15 PRESS. SENSOR B-16 P1 OPT. 4.5V 3.0M B-17 P2 OPT. 4.5V 3.0M	OPT 0.5V 0.0M 0.5V 0.0M
No.16 PRESS. SENSOR B-16 P1 NEGA-CON 0.5V 0.0M B-17 P2 NEGA-CON 0.5V 0.0M	Negative control P1,P2 3.0V 3.1M 3.0V 3.1M
No.19 PRESS. SENSOR B-15 BACK PRESS.	Back pressure (Nega-con pressure) 0.9V 0.3M

- Conversion for pressure
1MPa=10.2kgf/cm²=145psi

(2) Secondary pilot pressure

(Att. operation No.①~⑧ Travel operation ①~④)

E/G Hi, Full lever, at relief	E/G Hi, No load, at neutral
No.9 PRESS. SENSOR B-1 BOOM RAISE 4.5V 3.0M B-2 BOOM LOWER 4.5V 3.0M	③ ④ 0.5V 0.0M 0.5V 0.0M
No.10 PRESS. SENSOR B-3 ARM OUT 4.5V 3.0M B-4 ARM IN 4.5V 3.0M	⑦ ⑧ 0.5V 0.0M 0.5V 0.0M
No.11 PRESS. SENSOR B-5 BUCKET DIG 4.5V 3.0M B-6 BUCKET DUMP 4.5V 3.0M	① ② 0.5V 0.0M 0.5V 0.0M
No.12 PRESS. SENSOR B-7 SWING (R) 4.5V 3.0M B-8 SWING (L) 4.5V 3.0M	⑥ ⑤ 0.5V 0.0M 0.5V 0.0M
No.13 PRESS. SENSOR B-9 TRAVEL (R) 4.5V 3.0M B-10 TRAVEL (L) 4.5V 3.0M	1,2 3,4 0.5V 0.0M 0.5V 0.0M

LH. control lever		RH. control lever	
⑤	Swing left	①	Bucket digging
⑥	Swing right	②	Bucket dump
⑦	Arm in	③	Boom raise
⑧	Arm out	④	Boom lower

LH. travel lever		RH. travel lever	
③	Travel left reverse	①	Travel right reverse
④	Travel left forward	②	Travel right forward

(3) Solenoid primary pressure

Operation is not working	In operation
No.5 SOL. VALVE F-2 SWING-BRAKE COMP. ON MEAS. ON RELEASE SW OFF	Swing P/B Swing & arm digging OFF indication } 5.0M OFF indication } ON/OFF indication
No.6 SOL. VALVE F-3 1/2-TRAVEL COMP. OFF MEAS. OFF SWITCH OFF	Travel 2-speed select ON indication } 5.0M ON indication } ON/OFF indication
No.7 SOL. VALVE F-1 POWER UP COMP. OFF MEAS. OFF SWITCH OFF	Boost pressure select ON indication } 5.0M ON indication } ON/OFF indication

(4) Solenoid proportional valve secondary pressure


E/G Hi, Full lever * operation	E/G Hi, No load, at neutral
No.20 PROPO-VALVE D-1 P1 BYPASS COMP. 647mA 2.4M MEAS. 642mA 2.4M	P1 bypass cut 350mA 0.6M 345mA 0.6M
No.21 PROPO-VALVE D-2 P2 BYPASS COMP. 647mA 2.4M MEAS. 642mA 2.4M	P2 bypass cut 350mA 0.6M 345mA 0.6M
No.22 PROPO-VALVE D-3 TRAVEL STRAIGHT COMP. 647mA 2.4M MEAS. 642mA 2.4M	Travel straight 350mA 0.6M 345mA 0.6M
No.23 PROPO-VALVE D-6 A-RECIRCULAT COMP. 510mA 1.6M MEAS. 510mA 1.6M	Arm variable recirculation 713mA 2.8M 712mA 2.8M
No.24 PROPO-VALVE E-1 P1 PUMP COMP. 350mA 0.6M MEAS. 345mA 0.6M POWER SHIFT 0mA	P1 pump 770mA 3.0M 770mA 3.0M
No.25 PROPO-VALVE E-2 P2 PUMP COMP. 350mA 0.6M MEAS. 345mA 0.6M POWER SHIFT 0mA	P2 pump 770mA 3.0M 765mA 3.0M
No.42 PROPO-VALVE D-13 SW. PRIORITY COMP. 657mA 2.5M MEAS. 652mA 2.5M	Swing priority 350mA 0.6M 345mA 0.6M

NOTE ; *OPERATION


- No.20 ARM OUT or ARM IN RELIEF OPERATION
- No.21 BOOM RAISE RELIEF OPERATION
- No.22 ARM IN RELIEF OPERATION

- No.23 ARM IN OPERATION LEVER TURNED TO FULL
(At 200mA ARM IN RELIEF)
- No.24 DURING BUCKET DIGGING OPERATION
- No.25 DURING ARM IN OPERATION


(4)-1




(12)-2



(2)-2




(8)-2




(9)



(10)




(5)



Checking condition ; Engine coolant temperature is more than 50°C (122°F).

(6)




Checking condition ; Engine coolant temperature is more than 50°C (122°F).




00012

Be particularly careful not to work in shoes that have oily soles and are slippery. When working as a team of two or more, arrange signals in advance and keep confirming safety. Be careful not to accidentally bump switches or levers.




00014

Check for oil leakage before cleaning the area having the fault otherwise you might miss detecting the leakage. Prepare replacement part(s) beforehand.



00015

Replace oil seals, packing, O-rings and other rubber parts; gaskets and split pins with new parts whenever any of them has been removed. Use only genuine MITSUBISHI replacement parts.




00016

On disassembly, visually inspect all parts for wear and tear, cracks, damage, deformation, degradation, rust, corrosion, smoothness in rotation, fatigue, clogging and any other possible defect.

STRUCTURE AND OPERATION


2. Valve Mechanism



- 1 Exhaust valve
- 2 Inlet valve
- 3 Camshaft
- 4 Tappet
- 5 Push rod
- 6 Rocker shaft
- 7 Rocker shaft spring
- 8 Rocker
- 9 Rocker shaft bracket
- 10 Valve cap
- 11 Valve cotter
- 12 Upper retainer
- 13 Outer valve spring
- 14 Inner valve spring
- 15 Valve stem seal
- 16 Valve guide

- The valve stem seals 15 are fitted onto the valves 1, 2 to control the amount of lubricant flowing onto the sliding surfaces of the valves 1, 2 and valve guides 16.
- The valve springs 13, 14 are unevenly pitched to prevent abnormal vibration at high speeds. To prevent the inner and outer springs from meshing with each other, the springs are wound in opposite directions.
- To facilitate removal and reinstallation of the camshaft from the rear end of the crankcase, the diameter of each bushing is smaller toward the front of the engine.

3. Connecting Rods






◆ Service procedure

2 14 Rocker bushing and rocker shaft

[Inspection]

If any clearance exceeds the specified limit, replace the defective part(s).



Rocker bushing

[Removal]

[Installation]


- Align the oil hole **A** in the rocker bushing **2** with the oil hole **B** in the rocker **5**.
- Position the notch **C** and seam **D** on the rocker bushing **2** as shown.
- Install the rocker bushing **2** into the rocker **5** from the chamfered side **F**.

6 8 to 12 14 Installing rocker shaft brackets and rocker shaft


Rocker shaft brackets

Be sure to fit the rocker shaft brackets **6**, **8**, **12** in their correct positions.

- A**: Oil hole
- B**: Threaded hole (for M8 rocker cover bolt)
- C**: Threaded hole (for M6 set screw)
- D**: No threaded hole



PISTONS, CONNECTING RODS, AND CYLINDER LINERS



◆ Service procedure

● Pre-disassembly inspection


(1) Piston projection from crankcase top surface

NOTE

The piston projections affect engine performance and must therefore be checked.

WARNING ⚠


With 6D16, 16-E, 16-T, 16-TE, 16-TL and 16-TLE engines, the cylinder liners may rise out of position when the crankcase is turned over or the crankshaft is turned. Hold their flanges down using bolts and washers A.



- Measure the projection of each piston at two points and calculate the average of the two values.


A: Front of engine

- If the average value is out of specification, check the clearances between all relevant parts.



(2) Connecting rod end play

- Measure the end play of every connecting rod.
- If any measurement exceeds the specified limit, replace the defective part(s).



(3) Cylinder liner flange projection

If any measurement is out of specification, replace the defective part(s).


B: Flange projection

CAUTION ⚠

If the cylinder liner flange projection is insufficient, bearing pressure on the cylinder head gasket will be too low in the region of the bore, possibly causing gas to leak.

MEMO

CAMSHAFT



18061

● Pre-disassembly inspection

📖 P.11-66

● Disassembly sequence

- 1 Engine speed sensor <models with electric speed sensor>
- 2 Adapter <models with electric speed sensor>
Tachometer drive case <models with mechanical tachometer>
- 3 O-ring

- 4 Pulse rotor <models with electric speed sensor>
Tachometer drive coupling <models with mechanical tachometer>
- 5 Side cover
- 6 Camshaft assembly
- 7 Bolt
- 8 Camshaft gear
- 9 Thrust plate

- 10 Key
- 11 Camshaft
- 12 No. 4 camshaft bushing
- 13 No. 3 camshaft bushing
- 14 No. 2 camshaft bushing
- 15 No. 1 camshaft bushing

*: Crankcase 📖 P.11-72


⊗: Non-reusable part

NOTE

- Do not remove the engine speed sensor 1 unless defects are evident.
- Do not remove the camshaft gear 8 unless defects are evident.


● Assembly sequence

Reverse the order of disassembly.




- Tighten the bolts **8** to the specified torque. Then, turn the bolts further in accordance with the following procedure:
- Turn the holder **C** of the **C** Socket Wrench counter-clockwise to tension the built-in spring.

D: Socket
 E: Rod
 F: Rod (extension)



- Set the socket wrench such that the built-in spring force forces the rod **F** against the crankshaft assembly **12**.
- On the holder **C**, select the inscribed line **G** that is easiest to see.
- Using the selected line as a reference, turn the socket **D** 90° clockwise. (One gradation on the scale **H** represents 5°.)

CAUTION ⚠
 Since the bolts utilize the plastic region tightening method, they must not be tightened further after this procedure.




11 Installing thrust plates

Fit a thrust plate **11** on each side of the main bearing caps **10** and at the rear end of the crankcase **18** such that the oil grooves **A** are on the outside.

B: Locating pin

NOTE


If oversize thrust plates **11** are used, they must be fitted on both sides of the bearing caps **10**. Ensure that the bearing cap rear thrust plates and the rearmost thrust plate in the crankcase **18** are the same size. Note, however, that the front and rear thrust plates on each bearing cap may be of different sizes.



13 Installing front oil seal slinger

Using the **C** Front Oil Seal Slinger Installer, drive the front oil seal slinger **13** onto the crankshaft **16** until the tool's end face **A** is pressed firmly against the guide **B**.

STRUCTURE AND OPERATION




● Turbocharger <6D14-T, 15-T, 16-T, 16-TE, 16-TL, 16-TLE>

- 1 Bearing housing
- 2 Snap ring
- 3 Piston ring
- 4 Bearing

A: From main oil gallery

B: To oil pan

Via an oil pipe, engine oil is delivered from the main oil gallery to the bearing housing 1 to lubricate the inside of the bearing housing. At each end of the turbine wheel shaft, piston ring 3 acts as an oil seal.




● Injection pump

- 1 Injection pump
- 2 Governor
- 3 Air compressor (or injection pump drive)

A: From main oil gallery.

B: To oil pan

Engine oil that has lubricated injection pump 1 and governor 2 returns to the oil pan via the timer case, air compressor 3 (or injection pump drive), and timing gear train.



● Air compressor

- 1 Piston
- 2 Connecting rod
- 3 Crankshaft
- 4 Connecting rod bushing
- 5 Crankcase

A: From main oil gallery

B: To oil pan

Engine oil from the main oil gallery splashes onto connecting rod 2 and lubricates connecting rod bushing 4. Piston 1 and the connecting rod's small end are lubricated by oil that is splashed onto them by the rotation of the crankshaft 3.

Service standards

Unit: mm

Location	Maintenance item	Maintenance item	Standard value (Basic diameter in [])	Limit	Remedy
5, 11	Clearance between drive gear shaft and inner diameter of cover		[20] 0.04 to 0.07	0.15	Replace
5, 6, 11	Clearance between driven gear shaft and inner diameter of case and cover		[20] 0.04 to 0.07	0.15	Replace
6, 11	Clearance between case and tooth tips of each gear		0.10 to 0.19	0.2	Replace
	Difference between height of each gear and depth of case		0.06 to 0.11	0.15	
8	Relief valve opening pressure		980 to 1175 kPa {10 to 12 kgf/cm ² }	—	Replace
9	Relief valve spring load (installed length = 30)		84 N {8.6 kgf}	—	Replace
*b, *c	Backlash between oil pump gear and crankshaft gear	Without PTO	0.08 to 0.18	0.35	Adjust with shims
		With PTO	0.10 to 0.22		

Tightening torque


Unit: N·m {kgf·m}

Location	Parts to be tightened	Tightening torque	Remarks
4	Oil pump cover mounting bolt	25 ± 4.9 {2.5 ± 0.5}	—

Service procedure

Inspection before disassembly


Measure the backlash between oil pump gear *c and crankshaft gear *b. If the amount of backlash exceeds the specified limit, adjust it with shims 12.



Shim thickness	Change in amount of backlash
0.1 mm	0.073 mm
0.2 mm	0.146 mm

NOTE

Shim 12 must have the same thickness on the left and right sides.



5 6 11 Inspection of cover, driven gear assembly, and gear and case assembly

Measure the clearance between each gear shaft and the internal diameters of the cover and case.

SPECIFICATIONS


Injection Pump

Engine model Item	6D14	6D14-T		6D15-T	
	STD	STD	OPT	STD	OPT
Model	Bosch A	Bosch A	Bosch A	Bosch A	Bosch A
Governor type	RSV-type all-speed mechanical governor	RSV-type all-speed mechanical governor	RFD-type minimum-maximum mechanical governor	RSV-type all-speed mechanical governor	RFD-type minimum-maximum mechanical governor
Feed pump type	KE	KE	KE	KE	KE
Automatic timer type	SA-type mechanical timer	SA-type mechanical timer	SA-type mechanical timer	—	—
Manufacturer	DENSO	BOSCH AUTOMOTIVE SYSTEMS	BOSCH AUTOMOTIVE SYSTEMS	BOSCH AUTOMOTIVE SYSTEMS	BOSCH AUTOMOTIVE SYSTEMS

Engine model Item	6D16, 16-E			6D16-T, 16-TE	
	STD	OPT	OPT	STD	OPT
Model	Bosch A	Bosch A	Bosch AD	Bosch AD	Bosch AD
Governor type	RSV-type all-speed mechanical governor	RFD-type minimum-maximum mechanical governor	RSV-type all-speed mechanical governor	RSV-type all-speed mechanical governor	RFD-type minimum-maximum mechanical governor
Feed pump type	KE	KE	KE	KE	KE
Automatic timer type	SA-type mechanical timer	SA-type mechanical timer	—	SA-type mechanical timer	SA-type mechanical timer
Manufacturer	DENSO	BOSCH AUTOMOTIVE SYSTEMS	BOSCH AUTOMOTIVE SYSTEMS	BOSCH AUTOMOTIVE SYSTEMS	BOSCH AUTOMOTIVE SYSTEMS

Engine model Item	6D16-TL	6D16-TLE	
	STD	STD	OPT
Model	Bosch AD	Bosch MD	Bosch MD
Governor type	RFD-type minimum-maximum mechanical governor	RSV-type all-speed mechanical governor	RED-IV-type electronic governor
Feed pump type	KE	KE	KE
Automatic timer type	SA-type mechanical timer	SPG mechanical timer	SPG mechanical timer
Manufacturer	BOSCH AUTOMOTIVE SYSTEMS	BOSCH AUTOMOTIVE SYSTEMS	BOSCH AUTOMOTIVE SYSTEMS

10. Injection Pump Drive



- 1 Pump drive case
- 2 Bearing
- 3 Pump drive gear
- 4 Pump drive shaft
- 5 Coupling


A: Timing gear side
 B: Timer side

The injection pump drive is fitted onto the flywheel housing on the left of the engine. It is driven by the engine timing gear at half the engine speed.

The pump drive shaft 4 drives the injection pump via the coupling 5 on its timer side.

11. Injection Nozzle

<1-spring type>




- 1 Nozzle spring
- 2 Needle valve
- 3 Nozzle
- 4 Adjusting screw
- 5 Nozzle holder

A: To leak-off pipe
 B: From injection pump

Fuel fed from the injection pump enters the nozzle holder 5. When the fuel pressure in the nozzle holder exceeds a preset pressure, it overcomes the nozzle spring 1, pushes up the needle valve 2, and the fuel is sprayed into the cylinder from the orifice at the end of the nozzle 3.

Some of the high-pressure fuel lubricates the needle valve 2 and returns to the fuel tank via the leak-off pipe.

FUEL FILTER



● Disassembly sequence

- | | |
|-----------------|--------------------|
| 1 Eyebolt | 4 Fuel filter |
| 2 Fuel pipe | 5 Fuel filter head |
| 3 Air vent plug | |

● Assembly sequence

Reverse the order of disassembly.

ⓘ Tightening torques

Unit: N·m {kgf·m}

Location	Parts to be tightened	Tightening torque	Remarks
1	Eyebolt	34 {3.5}	—
3	Air vent plug	9.8 ± 2.0 {1 ± 0.2}	—

🔧 Lubricant

Location	Points of application	Specified lubricant	Quantity
4	Gasket between fuel filter and fuel filter head.	Engine oil	As required


Lubricant

Location	Points of application	Specified lubricant	Quantity
16	O-ring	Engine oil	As required


◆ Service procedure

1 Installing injection pump drive assembly

- Bring cylinder No. 1 of the engine to the TDC position of its compression stroke. Gr. 11
- Align the inscribed line **A** on the drive gear **4** of the injection pump drive assembly **1** with the inscribed line **A** on the pump drive case **15**.




- Remove the plug **C** from the flywheel housing **B**, then check that the inscribed line **A** on the drive gear **4** is aligned with the pointer **D**. If the line and pointer are not aligned, remove and refit the injection pump drive assembly.




4 Installing drive gear

- Fit the drive gear **4** such that its "0" alignment mark is aligned with the "0" alignment mark on the shaft **14**. Then, fit the lock washer **3** such that its notch **A** is aligned with the drive gear alignment mark, and tighten the nut **2** to the specified torque.



- When the assembly is complete, bend the lock washer **3** down onto the nut **2**.



INJECTION NOZZLE <2-spring Type: BOSCH AUTOMOTIVE SYSTEMS>


◆ Service procedure

● Pre-disassembly inspection

Fit the injection nozzle assembly 5 onto the nozzle tester A ready for inspection.

NOTE

Before commencing inspection, operate the lever on the nozzle tester A two or three times to bleed all air out of the arrangement.




(1) Checking valve opening pressure

- Push down the lever on the nozzle tester A at a rate of 1–2 seconds per stroke. The pressure gauge reading will gradually rise, then the needle will suddenly deflect. Note the pressure when the needle starts to deflect.
- If the measurement is out of specification, disassemble the nozzle, clean it, and make adjustments using the shims 12, 14.
- If the measurement is still out of specification after adjustment, replace the injection nozzle assembly 5.

WARNING ⚠

Do not touch the spray that comes out of the nozzle.



(2) Inspecting spray condition

- Pump the lever on the nozzle tester A at a rate of about 1–2 seconds per stroke, and maintain a continuous spray.

B: Even spray from all five injection orifices (Good)

C: Even and symmetrical spray (Good)

D: Asymmetrical spray (Bad)

E: Branched spray (Bad)


F: Thin spray (Bad)

G: Irregular spray (Bad)

- If the spray is unsatisfactory, disassemble and clean the injection nozzle assembly 5, then inspect the spray again. If the spray is still unsatisfactory, replace the injection nozzle assembly 5.
- Check that no fuel drips from the nozzle after the spray is complete.

WARNING ⚠

Do not touch the spray that comes out of the nozzle.




(3) Inspecting for leaks

- Slowly increase the nozzle pressure to 1.96 MPa {20 kgf/cm²} below the specified 1st valve opening pressure. Maintain this pressure for 10 seconds and check that no fuel drips from the end of the nozzle.
- If the injection nozzle assembly 5 appears defective, disassemble and clean it, then inspect it again. If the injection nozzle assembly 5 still appears defective, it must be replaced.

2.3 Glow Control


Glow control improves startability when the engine's coolant temperature is low.

Operating modes



(1) Engine coolant temperature higher than 60°C

No preheating is necessary at the time of engine startup, so the heater relay is kept OFF.



(2) Engine coolant temperature 60°C or lower

- "ts" seconds after the starter switch is turned ON, the glow relay is turned ON, causing preglow to begin. The glow lamp illuminates simultaneously.
- When preheating finishes, the glow lamp goes off to indicate that the engine can be started. The glow relay remains ON until the engine is started.
- When the engine is started, the engine ECU determines whether afterglow is necessary in accordance with the engine coolant temperature. If the engine ECU determines that afterglow is not necessary, preglow control is terminated. If it deems that afterglow is necessary, the glow relay remains ON for a certain period after engine startup to cause afterglow.

TROUBLESHOOTING

16 ACCEL. SNSR-2		
Code issue condition [Reset condition]	<p>Diagnostic trouble code 16 indicates short or open circuit in accelerator position sensor 2 harness and faulty sensor proper. (If diagnostic trouble code 16 is issued, inspections for diagnostic trouble code 24 must also be performed.)</p> <p>The code is issued when accelerator position sensor 2 voltage is out of specified limits. [When accelerator position sensor 2 voltage is back within specified limits, a reset is made.]</p>	
Action taken by ECU	<ul style="list-style-type: none"> • Normal control is effected using only non-faulty accelerator pedal position sensor 1. • If accelerator pedal position 1 is also faulty, control is effected using assumptions of 100% with the pedal depressed and 0% with the pedal released. 	
Probable cause and check item	<ul style="list-style-type: none"> • Open or short circuit in harness between ECU and accelerator position sensor 2 • Accelerator position sensor 2 faulty or poorly adjusted • ECU faulty 	<ul style="list-style-type: none"> • Perform checks on basis of Multi-Use Tester-II service data. P13E-24 No. 03, 04: Measurement of throttle opening indicated by accelerator pedal position sensor No. 5: Measurement of accelerator pedal position sensor's output voltage • Inspection of accelerator pedal position sensor • Check of circuit between ECU and accelerator pedal position sensor 2


19 AIR PRES SNSR		
Code issue condition [Reset condition]	<p>Diagnostic trouble code 19 indicates short or open circuit in air pressure sensor harness and faulty air pressure sensor (built in ECU).</p> <p>The code is issued when air pressure sensor voltage is out of specified limits. [When air pressure sensor voltage falls back within specified limits, a reset is made.]</p>	
Action taken by ECU	Air pressure is defaulted to 100 kPa {760 mmHg}.	
Probable cause and check item	<ul style="list-style-type: none"> • Air pressure sensor (built in ECU) faulty. • ECU faulty 	<ul style="list-style-type: none"> • Perform checks on the basis of Multi-Use Tester-II service data. P13E-24 No. 18: Air pressure measurement

21 WTR TEMP SNSR		
Code issue condition [Reset condition]	<p>Diagnostic trouble code 21 indicates open circuit in water temperature sensor harness and faulty sensor proper.</p> <p>The code is issued when water temperature sensor voltage is out of specified limits. [When water temperature sensor voltage falls back within specified limits, a reset is made.]</p>	
Action taken by ECU	Controls are continued assuming that coolant temperature is -20°C when engine is started and 80°C when engine is running.	
Probable cause and check item	<ul style="list-style-type: none"> • Open or short circuit in harness between ECU and water temperature sensor • Water temperature sensor faulty • ECU faulty 	<ul style="list-style-type: none"> • Perform checks on basis of Multi-Use Tester-II service data. P13E-24 No. 16: Measurement of engine coolant temperature • Inspection using ECU connector P13E-27 02: Measurement of resistance of coolant temperature sensor • Inspection of coolant temperature sensor P13E-30: Inspection of Electrical Equipment 262 • Check of circuit between ECU and coolant temperature sensor

GROUP 14 COOLING

SPECIFICATIONS	14-2
STRUCTURE AND OPERATION	
1. Cooling System (Water Flow)	14-2
2. Water Pump	14-3
3. Thermostat	14-3
TROUBLESHOOTING	14-4
ON-VEHICLE INSPECTION AND ADJUSTMENT	
1. Replacing Coolant and Cleaning Coolant System	14-6
2. Air Bleeding of Cooling System	14-8
3. Gas Leak Testing	14-8
RADIATOR	14-9
COOLING FAN AND V-BELT	14-10
WATER PUMP	14-14
THERMOSTAT	14-18

WATER PUMP



©16925

©16926

● Disassembly sequence

- 1 Bolt
- 2 Water pump assembly
- 3 Impeller
- 4 Flange
- 5 Snap ring
- 6 Bearing
- 7 Spacer
- 8 Bearing
- 9 Washer

- 10 Water pump shaft
- 11 Unit seal
- 12 Grease nipple
- 13 Water pump case
- 14 Gasket (pump with cover)
- 15 Cover (pump with cover)
- 16 Gasket

⊗ : Non-reusable part

● Assembly sequence


16 → 15 → 14 → 2 → 1

2 : 13 → 12 → 5 → 11 → 4 → 3
 10 → 9 → 8 → 7 → 6

● Inspection after assembly

📖 P.14-16


<T04E (6D16-TL), TBP4>




- 1 Compressor housing
- 2 Piston ring
- 3 Thrust collar
- 4 Thrust bearing
- 5 Center housing
- 6 Wheel shroud
- 7 Exhaust coupler
- 8 Actuator assembly
- 9 Turbine housing
- 10 Turbine wheel
- 11 Piston ring
- 12 Retaining ring
- 13 Bearing
- 14 Seal ring
- 15 Back plate
- 16 Compressor wheel


18273

TURBOCHARGER <T04E (6D16-TL), TBP4>




(2) Play of turbine wheel in radial direction

- Mount the  Measuring Element to the dial gauge A and insert it from the oil outlet and press it against the shaft of the turbine wheel 23 at right angles.
- Move the shaft of the turbine wheel 23 up and down by both hands to measure the play in the radial direction.
- If the reading exceeds the limit, replace the bearing 33.



(3) Play of turbine wheel in thrust direction

- Set the dial gauge A on the end of the turbine wheel 23 and move the shaft of the turbine wheel in the axial direction to measure the play.
- If the reading exceeds the limit, worn or defective back plate 27, thrust collar 29 and thrust bearing 30 are suspected. Replace.



(4) Measurement of operating pressure of actuator assembly

- Set the dial indicator A on the end of the rod end 7.
(In this case, set the scale of the dial indicator to 0.)
- Extend the rod end 0.38 mm by use of the external air B.)
(The scale of the dial indicator A is 0.38 mm.)
- With the scale of the dial indicator A at 0.38 mm, read the value of the pressure gauge C, and check to ensure that the reading is between 83 and 90 kPa {625 to 675 mmHg}.

(5) Adjustment of operating pressure of actuator assembly

- If the reading of the pressure gauge C is not between 83 and 90 kPa {625 to 675 mmHg}, remove the retaining ring 3, loosen the nut 5, and adjust the length of the rod end 7.

Rod end length adjusting direction

Rod end extending direction → Reduces the pressure.

Rod end retracting direction → Increases the pressure.

CAUTION

When the rod end length is adjusted, if the piston assembly D is rotated, damage to the diaphragm in the actuator assembly 6 will result. Secure the piston assembly through use of a vice, pliers, etc. to make sure that it is not rotated.


GROUP 21 CLUTCH

SPECIFICATIONS	※
STRUCTURE AND OPERATION	
1. Clutch Body	※
2. Bearing Case	※
TROUBLESHOOTING	※
CLUTCH BODY	
<C5>	※
<C8>	※
BEARING CASE	
<PC4: DIRECT COUPLING TYPE>	※
<PC4: LATERAL TRANSMISSION TYPE>	※
<PC8>	※

NOTE ; The parts marked "※" are deleted as they are not applicable to the SK330(N)LC-6E.

STRUCTURE AND OPERATION

<24V-50A>



©34192

- 1 Rectifier
- 2 Rotor assembly
- 3 Stator assembly
- 4 Fan
- 5 Pulley
- 6 Front bearing

- 7 Front bracket
- 8 Field coil
- 9 Rear bracket
- 10 Regulator
- 11 Rear bearing

- A: Neutral point diode
- B: Terminal B
- E: Terminal E
- L: Terminal L
- R: Terminal R


Starter

Defective condition		Starter does not start	Starter starts but engine does not start			Engine does not stop	Engine cannot be preheated	Engine is hard to start	Remarks
			Pinion does not come in mesh with ring gear	Pinion comes in mesh with ring gear but does not rotate	Flywheel rotates but engine does not start				
Possible causes									
Connector incorrectly connected, harness open-circuited, defective grounding		<input type="radio"/>			<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
Blown fuse		<input type="radio"/>							
Insufficient capacity of battery		<input type="radio"/>		<input type="radio"/>					
Starter	Contact of magnet switch binding or deposited	<input type="radio"/>							
	Coil of magnet switch open-circuited	<input type="radio"/>							
	Overrunning clutch in defective operation		<input type="radio"/>						
	Worn or damaged pinion		<input type="radio"/>						
Defective starter relay		<input type="radio"/>							
Defective starter switch		<input type="radio"/>				<input type="radio"/>			
Worn or damaged ring gear of flywheel			<input type="radio"/>						Gr 11

Starter, Preheater


Defective condition		Engine hard to start	Engine cannot be preheated	Remarks
Defective heater relay or glow relay wiring		<input type="radio"/>	<input type="radio"/>	
Defective battery wiring		<input type="radio"/>	<input type="radio"/>	
Defective air heater or glow plug wiring		<input type="radio"/>	<input type="radio"/>	
Defective air heater or glow plug		<input type="radio"/>	<input type="radio"/>	
Defective coolant temperature sensor		<input type="radio"/>		Gr 14
Defective coolant temperature sensor wiring		<input type="radio"/>		

ALTERNATOR <24V-35A>




[Installation]

- Install the brush 12 in the regulator & brush holder 13 in the direction shown.
 - After installation, solder the leads of the brush 12 to the regulator & brush holder 13.
- Thereafter, fit the cover A as before.




[Inspection]

If the length of the brush 12 is near the wear limit B, replace.



13 Removal of regulator & brush holder

- Remove the regulator & brush holder 13 by de-soldering the two illustrated points A.
- For installation, reverse the order of removal.



15 Inspection of rectifier

- Check the rectifier 15 to see if the internal diodes function properly.

Resistance infinite in both cases...Open
Resistance close to Ω in both cases...Short

A, B, C, D: Leads of stator coil connected
E, G: Heat sink portion
F: Regulator connected

- Exchange the \oplus and \ominus sides of the tester and perform checks in both cases.

CAUTION

When a tester is used for the checks, the current that flows out from the tester is feebler than the current that normally flows through the rectifier 15, so the tester may indicate a questionable resistance value. In a low range, this tendency will be stronger. Therefore, it is advisable to use the highest possible range.

MEMO

B. Parts to be provided additionally

- (1) Install two foot-operated pilot valves to the front of the floor plate so as to actuate the jib cylinder and the crusher (nibbler).
- (2) Add two low-pressure sensors to the two pilot valves thus installed additionally.
- (3) Add one stroke end switch and one solenoid valve to protect the bucket cylinder.
- (4) Add a solenoid valve so as to reverse the arm in/out action for backhoe.

Note:

Since the arm cylinder is located under the arm, reverse the cylinder motion so it is the same as the backhoe.

- (5) Add one solenoid valve for crusher (nibbler) rotation and one restrictor $\varnothing 1.5$ (0.06") to the P line.
- (6) Add one jib cylinder to actuate the 2.3M (7ft-7in) inter boom.
- (7) Add one LMN/BH (Crusher / Back-hoe) select switch.
- (8) Add one conflux/single flow select switch.
- (9) Add 3-face guard and skylight wiper to the cab.
- (10) Add three potentiometers to the main boom, front boom and inter-boom.
- (11) Add two slow return check valves to the boom cylinder head, one slow return check valve to the boom cylinder head and one slow return check valve to the arm cylinder head.
- (12) Add one set of auto greaser.
- (13) Add one set of one-way call unit.


Supplement:

Regarding the electric circuit diagram, refer to Electric System in the previous chapter of this manual.


3. CONTROL SYSTEM

The LMN (special demolition machine) is equipped with the below control devices in its cab:

3.1 ARRANGEMENT OF SWITCHES



(1) LMN/BH select switch (SW-18)



● The following control is performed if the select switch is turned to "LMN":

- 1) The machine is started up in the A mode. A and M modes may be selected with the mode select switch. Even in the A mode, however, the engine speed control is the same as in the M mode.
- 2) The stability control device is actuated.
- 3) Since the arm cylinder rod and head are installed oppositely, the solenoid valve is energized by arm in/out actions and the pilot piping systems are reversed.
- 4) In the A mode, the swing speed of LMN (special demolition attachment) is decreased than the swing speed of backhoe.
- 5) Releases the auto acceleration.
- 6) The overheat prevention is activated.
- 7) Releases the attachment boost pressure function.

! WARNING

On the LMN crusher & LMN rotating crusher machine and the backhoe machine, always bring the LMN/BH select switch to "LMN" for special demolition work. It is dangerous to operate the machine in the "BH" shift, because the arm operates in the opposite direction.

- 8) Changes the swing parking brake release to actuate in condition that arm in operation is performed.
- 9) Energizes the solenoid valve when the bucket digging stroke end switch is turned to [ON] and releases the bucket digging pilot pressure to the tank circuit.
- 10) Cuts off the arm sequence conflux flow.
- 11) Cuts off the conflux control in the bucket independent operation.
- 12) Brings the arm variable displacement proportional valve to the normal recirculation position by arm out operation.
- 13) Cuts off the conflux control at arm out operation.
- 14) Minimizes the delivery rate of the P1 pump at crusher rotating independent operation.
- 15) When crusher rotation and P1-side attachment are operated at the same time, the delivery rate of the P1 pump increases. The oil flow is regulated by the restrictor that is located at this side of the crusher rotation solenoid valve.

(3) JIB circuit:

3-1) Jib up operation

[Electric system: LMN/BH switch select action]
Two solenoid valves are added to the standard machine to change the operating circuit.
For the LMN operation, turn the LMN side of the LMN/BH select switch to [ON]. If the LMN side is turned [ON], the arm out / in reverse solenoid (SV-8) is energized which in turn changes over the reverse valve (56). The solenoid (SV-11) is energized at the bucket stroke end to changes over the bucket control valve(63).

[Pedal action and operation]

Operating pedal (LH pedal)	P/V (51) Secondary pressure outlet port	C/V (66) Inlet port	Jib action
Front (toe action)	B	PA	UP

[Pilot circuit]

If the toe of the jib operating pedal is depressed, the secondary pilot proportional pressure flows out of the B port of pilot valve (51), enters the PA port of control valve (66) and changes over the spool. At the same time, the pressure acts on the low-pressure sensor (SE-20).

[Mechatronic controller]

The output voltage of the low-pressure sensor (SE-20) is put into the mechatronic controller that puts out a command current. The command current causes the P1 bypass cut solenoid proportional valve (PSV-D) to send out secondary pressure and changes over the P1 bypass cut valve.

[Main circuit]



- 1) If the P1 bypass cut valve is changed over by the pilot circuit, the oil delivered by the No.1 pump flows out of the P4 port of C/V (50). The oil then enters the P port of the control valve (66) and flows out of the A port. The oil then enters the H side of jib cylinder (60) via ports A and B of holding valve (67) to perform jib up action.
- 2) The oil returning from the R side of the jib cylinder enters the B port of control valve (66) and flows out of the T port. The oil then enters the T3 port of control valve (50) and returns to the tank line.

4.3 HYD. LINES

4.3.1 HYD. LINES DWG. LIST

Gr.	ITEM	DWG. NAME	LMN, ROTARY N&B	REMARKS	Gr.	ITEM	DWG. NAME	LMN, ROTARY N&B	REMARKS
REMOTE CONTROL	1	PUMP CONTROL LINES	LC06H00017F1	Same as STD.	ATT. HYD.	24-3	INTER BOOM HYD. LINES (ROTARY)	LC42H00038F1	
	2	SOL. VALVE CONTROL LINES	LC64H00041F1			25-1	MAIN BOOM HYD. LINES	LC42H00020F2	
	3	P-T BLOCK CONTROL LINES	YN64H00069F3			25-2	BOOM HYD. LINES (SAFETY)	LC42H00068F1	
	4	ATT. REMOTE CONTROL LINES	LC68H00007F1	Same as STD.		25-3	BOOM HYD. LINES (ROTARY)	LC42H00025F1	
	5	TOWER BLOCK CONTROL LINES	LC64H00063F2	Same as STD.					
	6	MAIN C/V CONTROL LINES	LC06H00033F5		CYLINDER	26-1	BUCKET CYL. HYD. LINES	LC43H00010F1	
	7	TRAVEL CONTROL LINES	LC62H00007F1	Same as STD.		26-2	ARM CYL. HYD. LINES	LC42H00067F1	
	8	H/V SAFETY CONTROL LINES	LC64H00017F2	Same as STD.		26-3	JIB CYL. HYD. LINES	LC42H00066F1	
	9	LMN CONTROL LINES	LC68H00042F2			26-4	BOOM CYL. HYD. LINES	LC42H00024F1	
MAUN HYD. LINES	11	PUMP HYD. LINES	LC30H00014F1	Same as STD.	PLUG ASSY	27-1	PLUG ASSY FOR ARM CYL.	24100T800F1	
	12-1	UPPER HYD. LINES	LC03H00014F2	Same as STD.		27-2	PLUG ASSY FOR ARM	24100T790F2	
	12-2	UPPER HYD. LINES (JIB)	LC03H00025F1			27-3	PLUG ASSY FOR JIB	24100T789F2	
	12-3	UPPER HYD. LINES (ROTARY)	LC03H00035F2			27-4	PLUG ASSY FOR FRONT BOOM	24100T788F2	
	12-4	UPPER HYD. LINES (N&B)	LC03H00031F1			27-5	PLUG ASSY FOR INTER BOOM	24100T799F2	
	12-5	UPPER HYD. LINES (SWING PRIORITY)	LC03H00010F1	Same as STD.		27-6	PLUG ASSY FOR MAIN BOOM	LC50T00003F1	
	13	RETURN HYD. LINES	LC32H00015F6			27-7	CONNECTOR ASSY FOR BOOM	LC42H01197F1	
	14	S/J HYD. LINES ; FOR UPPER	LC19H00001F1	Same as STD.		27-8	PLUG ASSY FOR UPPER FRAME	LC50T00002F1	
	15	LOWER HYD. LINES	LC02H00010F1	Same as STD.					
	16	TRAVEL MOTOR HYD. LINES	LC12H00001F1	Same as STD.					
17	S/J HYD. LINES ; FOR LOWER	LC19H00012F1	Same as STD.						
ATT HYD. LINES	21-1	ARM HYD. LINES	LC43H00009F1						
	21-2	ARM HYD. LINES (ROTARY)	LC43H00014F1						
	22-1	JIB HYD. LINES	LC42H00029F1						
	22-2	JIB HYD. LINES (SAFETY)	LC42H00071F1						
	22-3	JIB HYD. LINES (ROTARY)	LC42H00040F1						
	23-1	FRONT BOOM HYD. LINES	LC42H00030F1						
	23-2	FRONT BOOM HYD. LINES (SAFETY)	LC42H00070F1						
	23-3	FRONT BOOM HYD. LINES (ROTARY)	LC42H00039F1						
	24-1	INTER BOOM HYD. LINES	LC42H00031F1						
	24-2	INTER BOOM HYD. LINES (SAFETY)	LC42H00069F1						

(21-1) Arm hyd. lines : LC43H00009F1




- NOTE
- 1 MAKE SURE NOT TO MISS O-RING AT ASSEMBLING.
 - 2 TIGHTENING TORQUE FOR M THREAD.






THREAD SIZE	TORQUE
M8	3.4kef·m (24.6 lbf·ft)
M10	6.7kef·m (48.5 lbf·ft)
M12	11.7kef·m (84.9 lbf·ft)
M14	18.5kef·m (134 lbf·ft)
 - 3 TIGHTENING TORQUE FOR PF, PT THREAD.

THREAD	TORQUE
3/4	16.5kef·m (119 lbf·ft)
1	26.0kef·m (187 lbf·ft)
1 1/4	40.0kef·m (289 lbf·ft)
 - 4 TIGHTENING TORQUES FOR NUTS AND SLEEVES.

TUBE SIZE	TORQUE
φ18×2.5	15.0kef·m (108 lbf·ft)
φ22×3.0	22.0kef·m (159 lbf·ft)
φ35×5.0	45.0kef·m (325 lbf·ft)
 - 5 APPLY LOCTITE #242 TO CLAMP ATTACHING BOLT.



(21-2) Arm hyd. rotary lines : LC43H00014F1






Fig.1 (3/5)

WIRE NO	WIRE COLOR	WIRE SIZE	FROM	CONNECTION	TO
1A	RY	AVSS0.75sq	CN-5F	—————	CN-9M
1B	RY	AVSS0.75sq	CN-9M	—————	CN-27F
1C	RY	AVSS0.75sq	CN-5F	—————	CN-27F
1D	RY	AVSS0.75sq	CN-20F	—————	CN-27F
2A	WY	AVSS0.75sq	CN-9M	—————	CN-26F
2B	WY	AVSS0.75sq	CN-16F	—————	CN-26F
2C	WY	AVSS0.75sq	CN-34F	—————	CN-26F
2D	WY	AVSS0.75sq	CN-29F	—————	CN-26F
2E	WY	AVSS0.75sq	CN-26F	—————	CN-26F
2F	WY	AVSS0.75sq	CN-26F	—————	CN-45F
2G	WY	AVSS0.75sq	CN-26F	—————	CN-65F
3A	G	AVSS0.75sq	CN-9M	—————	CN-35M
3B	R	AVSS0.75sq	CN-9M	—————	CN-35M
4A	Y	AVSS0.75sq	CN-9M	—————	CN-26F
4B	Y	AVSS0.75sq	CN-14F	—————	CN-26F
4C	Y	AVSS0.75sq	CN-14F	—————	CN-26F
4D	Y	AVSS0.75sq	CN-35M	—————	CN-26F
4G	Y	AVSS0.75sq	CN-26F	—————	CN-26F
4E	Y	AVSS0.75sq	CN-26F	—————	CN-44M
4F	Y	AVSS0.75sq	CN-26F	—————	CN-66M
5	YL	AVSS0.75sq	CN-9M	—————	CN-38M
6A	WG	AVSS0.75sq	CN-9M	DOUBLE SPLICE	CN-15F
6B	WG	AVSS0.75sq	CN-15F	—————	CN-15F
7	YR	AVSS0.75sq	CN-9M	—————	CN-42F
8	WV	AVSS1.25sq	CN-9M	—————	CN-30F
9A	YB	AVSS0.75sq	CN-9M	—————	CN-26F
9B	YB	AVSS0.75sq	CN-30F	—————	CN-26F
9C	YB	AVSS0.75sq	CN-54F	—————	CN-26F
9D	YB	AVSS0.75sq	CN-5F	—————	CN-26F
9E	YB	AVSS0.75sq	CN-38M	—————	CN-26F
10	WV	AVSS1.25sq	CN-9M	—————	CN-36M
11	OL	AVSS0.75sq	CN-9M	—————	CN-38M
12A	RG	AVSS1.25sq	CN-9M	—————	CN-27F
12B	RG	AVSS1.25sq	CN-56F	—————	CN-27F
12C	RG	AVSS0.75sq	CN-61F	—————	CN-27F
13A	W	AVSS0.75sq	CN-9M	—————	CN-27F
13B	W	AVSS0.75sq	CN-38M	—————	CN-27F
13C	W	AVSS0.75sq	CN-34F	—————	CN-27F
14A	RB	AVSS1.25sq	CN-9M	—————	CN-27F
14B	RB	AVSS1.25sq	CN-29F	—————	CN-27F
14C	RB	AVSS0.75sq	CN-68F	—————	CN-27F
14D	RB	AVSS0.75sq	CN-37F	—————	CN-27F
15A	WB	AVSS0.75sq	CN-9M	—————	CN-27F
15B	WB	AVSS0.75sq	CN-32M	—————	CN-27F
15C	WB	AVSS0.75sq	CN-34F	—————	CN-27F
16	RW	AVSS1.25sq	CN-9M	—————	CN-16F
17A	WL	AVSS1.25sq	CN-9M	—————	CN-26F
17B	WL	AVSS1.25sq	CN-17F	—————	CN-26F
17C	WL	AVSS0.75sq	CN-17F	—————	CN-26F
17D	WL	AVSS1.25sq	CN-49F	—————	CN-26F
17G	WL	AVSS0.75sq	CN-26F	—————	CN-26F
17E	WL	AVSS0.75sq	CN-26F	—————	CN-49F
17F	WL	AVSS0.75sq	CN-26F	—————	CN-32M

WIRE NO	WIRE COLOR	WIRE SIZE	FROM	CONNECTION	TO
18	WG	AVSS1.25sq	CN-9M	—————	CN-36M
19	RL	AVSS0.75sq	CN-9M	—————	CN-36M
20A	WR	AVSS1.25sq	CN-9M	DOUBLE SPLICE	CN-43F
20B	WR	AVSS1.25sq	CN-62F	—————	CN-43F
30	G	AVSS0.75sq	CN-12F	—————	CN-30F
50	L	AVSS1.25sq	CN-9M	—————	CN-36M
51	W	AVS2sq	CN-9M	—————	CN-30F
52	R	AVS5sq	CN-9M	—————	CN-33M
53	Y	AVS5sq	CN-9M	—————	CN-33M
54	R	AVS2sq	CN-9M	—————	CN-30F
55	WP	AVSS1.25sq	CN-9M	—————	CN-30F
58	P	AVSS0.75sq	CN-30F	—————	CN-14F
59A	W	AVSS0.75sq	CN-30F	—————	CN-27F
59B	W	AVSS0.75sq	CN-46F	—————	CN-27F
59C	W	AVSS0.75sq	CN-12F	—————	CN-27F
60A	WL	AVSS0.75sq	CN-46F	—————	CN-26F
60B	WL	AVSS0.75sq	CN-36M	—————	CN-26F
60C	WL	AVSS0.75sq	CN-45F	—————	CN-26F
60D	WL	AVSS0.75sq	CN-2F	—————	CN-26F
60E	WL	AVSS0.75sq	CN-46F	—————	CN-26F
61A	GrB	AVSS0.75sq	CN-36M	—————	CN-27F
61B	GrB	AVSS0.75sq	CN-2F	—————	CN-27F
61C	GrB	AVSS0.75sq	CN-46F	—————	CN-27F
62	W	AVSS0.75sq	CN-35M	—————	CN-45F
63A	WY	AVSS0.75sq	CN-36M	—————	CN-27F
63B	WY	AVSS0.75sq	CN-30F	—————	CN-27F
63C	WY	AVSS0.75sq	CN-35M	—————	CN-27F
64	LW	AVSS0.75sq	CN-30F	—————	CN-12F
65A	WR	AVSS0.75sq	CN-30F	—————	CN-26F
65B	WR	AVSS0.75sq	CN-2F	—————	CN-26F
65C	WR	AVSS0.75sq	CN-38M	—————	CN-26F
65D	WR	AVSS0.75sq	CN-12F	—————	CN-26F
65E	WR	AVSS0.75sq	CN-42F	—————	CN-26F
67	BG	AVSS0.75sq	CN-14F	—————	CN-35M
80	GrR	AVSS0.75sq	CN-38M	—————	CN-29F
81	GrB	AVSS0.75sq	CN-38M	—————	CN-29F
82	GO	AVSS0.75sq	CN-30F	—————	CN-29F
83	GO	AVSS0.75sq	CN-30F	—————	CN-15F
84A	WR	AVSS0.75sq	CN-15F	—————	CN-27F
84B	WR	AVSS0.75sq	CN-32M	—————	CN-27F
84C	WR	AVSS0.75sq	CN-36M	—————	CN-27F
85A	WB	AVSS1.25sq	CN-16F	—————	CN-26F
85B	WB	AVSS1.25sq	CN-30F	—————	CN-26F
85C	WB	AVSS0.75sq	CN-36M	—————	CN-26F
86A	OW	AVSS0.75sq	CN-27F	—————	CN-30F
86B	OW	AVSS0.75sq	CN-27F	—————	CN-32M
86C	OW	AVSS0.75sq	CN-27F	—————	CN-65F
86D	OW	AVSS0.75sq	CN-27F	—————	CN-67F
87	YV	AVSS0.75sq	CN-32M	—————	CN-7F
89A	BrL	AVSS0.75sq	CN-32M	—————	CN-27F
89B	BrL	AVSS0.75sq	CN-17F	—————	CN-27F
89C	BrL	AVSS0.75sq	CN-49F	—————	CN-27F


WIRE NO	WIRE COLOR	WIRE SIZE	FROM	CONNECTION	TO
90A	RY	AVSS1.25sq	CN-49F	—————	CN-26F
90B	RY	AVSS1.25sq	F-1	—————	CN-26F
90C	RY	AVSS1.25sq	F-2	—————	CN-26F
90D	RY	AVSS0.75sq	F-5	—————	CN-26F
91	Y	AVSS0.75sq	CN-32M	—————	F-3
92A	RW	AVSS0.75sq	CN-17F	—————	CN-26F
92B	RW	AVSS0.75sq	F-4	—————	CN-26F
92C	RW	AVSS0.75sq	F-6	—————	CN-26F
92D	RW	AVSS0.75sq	CN-30F	—————	CN-26F
96	WG	AVSS0.75sq	CN-36M	—————	CN-38M
97	YV	AVSS0.75sq	CN-36M	—————	CN-38M
98	LW	AVSS0.75sq	CN-36M	—————	CN-25F
99	Br	AVSS0.75sq	CN-36M	—————	CN-25F
100	LR	AVSS0.75sq	CN-36M	—————	CN-24F
101	OB	AVSS0.75sq	CN-36M	—————	CN-24F
150	BP	AVSS0.75sq	CN-36M	—————	CN-30F
151	R	MVVS0.75sq	CN-36M	—————	CN-32M
152	G	4 CORES SHIELD	CN-36M	—————	CN-32M
153	W		CN-36M	—————	CN-32M
154	B		CN-36M	—————	CN-32M
SH4	Gr		CN-36M	—————	CN-32M
210	LB	AVSS0.75sq	CN-68F	—————	CN-37F
211	LW	AVSS0.75sq	CN-68F	—————	CN-37F
214	YG	AVSS0.75sq	CN-18F	—————	CN-19F
215	GR	AVSS0.75sq	CN-18F	—————	CN-19F
216	O	AVSS0.75sq	CN-18F	—————	CN-77F
217A	LO	AVSS0.75sq	CN-18F	—————	CN-27F
217B	LO	AVSS0.75sq	CN-41F	—————	CN-27F
217C	LO	AVSS0.75sq	CN-36M	—————	CN-27F
218	P	AVSS0.75sq	CN-19F	—————	CN-77F
219A	GY	AVSS0.75sq	CN-19F	—————	CN-26F
219B	GY	AVSS0.75sq	CN-41F	—————	CN-26F
219C	GY	AVSS0.75sq	CN-44M	—————	CN-26F
220A	LW	AVSS0.75sq	CN-18F	DOUBLE SPLICE	CN-67F
220B	LW	AVSS0.75sq	CN-18F	—————	CN-19F
222	LW	AVSS0.75sq	CN-34F	—————	CN-68F
230	VR	AVSS0.75sq	CN-57F	—————	CN-42F
231	VY	AVSS0.75sq	CN-57F	—————	CN-42F
232	Gr	AVSS0.75sq	CN-57F	—————	CN-42F
233	GrB	AVSS0.75sq	CN-57F	—————	CN-42F
301	Sb	AVSS0.75sq	CN-35M	—————	CN-63F
328	GrR	AVSS0.75sq	CN-35M	—————	CN-65F
329	LgR	AVSS0.75sq	CN-35M	—————	CN-44M
330	Lg	AVSS0.75sq	CN-35M	—————	CN-44M
401	GR	AVSS0.75sq	CN-55F	—————	CN-56F
402	YG	AVSS0.75sq	CN-55F	—————	CN-56F
403	Br	AVSS0.75sq	CN-55F	—————	CN-56F
500	LgR	AVSS0.75sq	CN-1F	—————	CN-30F
501	LgW	AVSS0.75sq	CN-1F	—————	CN-30F
502	LgY	AVSS0.75sq	CN-1F	—————	CN-30F
503	LO	AVSS0.75sq	CN-1F	—————	CN-30F
504	PG	AVSS0.75sq	CN-1F	—————	CN-30F

WIRE NO	WIRE COLOR	WIRE SIZE	FROM	CONNECTION	TO
505	PL	AVSS0.75sq	CN-1F	—————	CN-30F
506	VY	AVSS0.75sq	CN-1F	—————	CN-30F
507	VG	AVSS0.75sq	CN-1F	—————	CN-30F
508	VY	AVSS0.75sq	CN-1F	—————	CN-31M
509	Sb	AVSS0.75sq	CN-1F	—————	CN-31M
510	GR	AVSS0.75sq	CN-2F	—————	CN-30F
511	LY	AVSS0.75sq	CN-2F	—————	CN-30F
512	Sb	AVSS0.75sq	CN-3F	—————	CN-30F
513	LgR	AVSS0.75sq	CN-3F	—————	CN-31M
514	GO	AVSS0.75sq	CN-3F	—————	CN-31M
515	V	AVSS0.75sq	CN-2F	—————	CN-30F
516	L	AVSS0.75sq	CN-2F	—————	CN-30F
517	P	AVSS0.75sq	CN-1F	—————	CN-36M
518	L	AVSS0.75sq	CN-7F	—————	CN-34F
519	V	AVSS0.75sq	CN-7F	—————	CN-34F
524	WR	AVSS0.75sq	CN-7F	—————	CN-34F
540	LG	AVSS0.75sq	CN-7F	—————	CN-44M
542A	GrG	AVSS0.75sq	CN-4F	—————	CN-27F
542B	GrG	AVSS0.75sq	CN-32M	—————	CN-27F
542C	GrG	AVSS0.75sq	CN-36M	—————	CN-27F
545	Lg	AVSS0.75sq	CN-2F	—————	CN-10F
547	GB	AVSS0.75sq	CN-4F	—————	CN-30F
548	GY	AVSS0.75sq	CN-4F	—————	CN-30F
549	Lg	AVSS0.75sq	CN-4F	—————	CN-30F
550	BG	AVSS0.75sq	CN-4F	—————	CN-30F
551	GL	AVSS0.75sq	CN-4F	—————	CN-30F
552	BrL	AVSS0.75sq	CN-4F	—————	CN-30F
553A	VW	AVSS0.75sq	CN-27F	—————	CN-30F
553B	VW	AVSS0.75sq	CN-27F	—————	CN-4F
553C	VW	AVSS0.75sq	CN-27F	—————	CN-20F
556	BrW	AVS0.5sq	CN-4F	—————	CN-51F
557	L	AVSS0.75sq	CN-4F	—————	CN-38M
558	G	AVSS0.75sq	CN-4F	—————	CN-38M
559	PB	AVSS0.75sq	CN-7F	—————	CN-60F


5.8 E/G HARNESS ASSY ; LC16E0005F1
(Same as STD ; Refer to STD page 45)

5.9 FLOOR HARNESS ASSY


FLOOR HARNESS ASSY		YN13E00071F5		ROTARY LMN & B
ITEM	NAME	PART No.	Q'TY	REMARKS
10	CABLE	LE13E01005P1	1	Floor ground
13	HARNESS	YN13E01290P2	1	Under floor
20	HARNESS	LC13E01108P1	1	Instrument panel (RH)
21	HARNESS	LC13E01067P1	1	Instrument panel (LH)





DETAIL OF B




DETAIL OF C




VIEW I



VIEW II



VIEW III



VIEW IV

Fig.18 (1/2) Floor harness assy

5.18 PROXIMITY SWITCH INSTALL

PROXIMITY SWITCH INSTALL		LC50E00001F1		
ITEM	PART NAME	PART NO.	Q'TY	REMARKS
4	SWITCH ; SW-32	2479R2096	1	Proximity sw.




Fig. 47 Proximity switch install

7.7.2 JIB CYLINDER

(1) Structure




Fig.2

T : Tightening torque kgf-m (lbf-ft)

P/No.		2438U1137F2						
NO.	PART NAME	Q'TY	NO.	PART NAME	Q'TY	NO.	PART NAME	Q'TY
1	CYLINDER TUBE	1	12	BACKUP RING	1	23	BALL	1
2	PISTON ROD	1	13	SOCKET BOLT ; M24×80	8	24	CUSHION BEARING	1
3	CYLINDER HEAD	1	14	CUSHION BEARING	1	25	SEAL	1
4	BUSHING	1	15	SEAL	1	26	STOPPER	2
5	SNAP RING	1	16	PISTON	1	27	SNAP RING	1
6	BUFFER RING	1	17	SEAL RING	1	28	BUSHING	2
7	U RING	1	18	RING	2	29	BAND ASSY	1
8	BACKUP RING	1	19	RING	2	30	BAND	1
9	RING	1	20	SHIM	1	31	BOLT	2
10	WIPER RING	1	21	NUT ; M80×2	1	32	WASHER	2
11	O RING ; 1B P14	1	22	SETScrew ; M14×2	1	33	WIPER RING	4

(2) Specification

Unit : mm (ft-in)

Item Name	Cylinder bore / Rod dia	Stroke	Center distance of pins Full extend / Full retract	Cushion	Weight kg (lb)
Jib cylinder	150 / 105 (5.91" / 4.13")	1,630 (5' 4")	3,930 / 2,300 (12' 11" / 7' 6")	With cushion on both sides	320 (705)

Table 1-2

BREAKER

Class	NAME	KCME	ASIA	ASIA (Middle East)	
(1) Upper	Upper structure modification kit No.	Ⓔ ⒫		Ⓖ Ⓒ	
	• Upper frame	—		LC52F00085P1	
	• Modification of the control valve	—		LC30V00002F3	
	• Hydraulic tank assy	[—]		[LC33H00020F2]	
		LC33H00020F5		←	
	• Remote control piping ; P/V	LC68H00041F1		LC68H00040F1	
	• Remote control block	YN64H00069F2		YN64H00141F2	
	• Remote control piping ; C/V	LC06H00033F3		LC06H00028F3	
(2) Boom	Boom modification kit No.	Ⓔ		Ⓔ	
	• 6.5M (21' 4") Boom	LC02B00035F2		←	
	• 6.5M (21' 4") Boom hydraulic piping	LC42H00014F1		←	
(3) Arm	STD	3.3M (10' 10") Arm modification kit No.	Ⓒ	Ⓘ	Ⓜ
		• 3.3M (10' 10") STD Arm	LC12B00040F7	LC12B00035FB	LC12B00040FB
		• 3.3M (10' 10") STD Arm hydraulic piping	LC43H00005F1	←	LC43H00057F1
		• Arm group	LC12B00136F2	←	←
	LONG	4.15M (13' 7") Arm modification kit No.	Ⓕ	—	Ⓢ
		• 4.15M (13' 7") LONG Arm	LC12B00041F9	—	LC12B00041FE
• 4.15M (13' 7") LONG Arm hydraulic piping		LC43H00018F1	—	LC43H00056F1	
	• Arm group	LC12B00136F2	—	LC12B00136F2	
(4) Connector	Kit No. is not given because it is provided after selection	—			
	• Connector assy	YN43H00004F1			
		YN43H00005F1			

• [] shows before modification

NOTE : If kit numbers are the same, the ordered parts are the same, provided the assembly numbers differ in some cases.

Kit No. Ⓔ ; LC32T01007F8
 Ⓕ ; LC32T01001FR
 ⒫ ; LC32T01007FH
 Ⓖ ; LC32T01007F9
 Ⓒ ; LC32T01007FJ
 Ⓢ ; LC32T01007FA

1.2 ADDITIONAL PARTS FOR THE MODIFICATION OF THE BREAKER

(1) UPPER STRUCTUR **KCME**

BREAKER

No.	PART No.	NAME	Q'TY	REMARK	Applicable Machines
⑩	LC32T01007F8	Upper structure modification kit No. BREAKER		Before modification	LC08-06201~, YC08-03001~
⑪	LC32T01007FH	Upper structure modification kit No. BREAKER		After modification	LC09-06323~, YC09-03088~
10-100	LC33H00020F5 YN52V01008R100	• HYDRAULIC TANK ASSY •• REPAIR KIT	1	After modification	LC09-06323~, YC09-03088~, LC09-06323~, YC09-03088~
1	LC68H00041F1	• REMOTE CONTROL PIPING ; P/V			
2	2420R349D090	•• HOSE	1		
3	2444R1120D110	•• HOSE	1		
4	2420R349D360	•• HOSE	1		
5	ZN18C08007	•• NUT	1		
6	PY03M01026P1	•• PIN	1		
7	ZW16X08000	•• WASHER	9		
8	ZS18C08065	•• CAPSCREW	6		
9	YN68H01035P1	•• CLAMP	3		
10	ZS18C08045	•• CAPSCREW	2		
11	ZW16H08000	•• WASHER	2		
12	YN68H01038P1	•• BRACKET	1		
13	2419T3757D6	•• PIN	1		
14	2419R9D4	•• PIN	1		
15	HH35X04004G3	•• ELBOW	1	With filter	
16	ZH32X04000	•• ELBOW	1		
17	YT30V00004F1	•• PILOT VALVE ASSY	1		
18	2416Z566	•• CUSHION RUBBER	1		
19	ZS18C08020	•• CAPSCREW	2		
20	YT30M01002F1	•• LOCK ASSY	1		
21	YN68H01039P2	•• PEDAL	1		
22	YR03M01134P1	•• COVER	1		
23	ZW16X12000	•• WASHER	1		
24	2418T18004	•• PLATE	2		
25	YX52S00010P1	•• PRESSURE SENSOR (LOW PRESSURE)	1		
26	2444Z4239	•• TEE	1		
27	ZH22X04000	•• CONNECTOR	1		
	2444Z2525	•• CONNECTOR	1		
4	YN64H00069F2	• CONTROL BLOCK PIPING			
10	2444Z2336	•• TEE	1		
11	ZH32X04006	•• ELBOW	1		
12	2416N6141	•• BLOCK	1		
13	ZE72X04000	•• PLUG	1		
14	ZE72X06000	•• PLUG	1		
	ZH22X04000	•• CONNECTOR	1		
4	LC06H00033F3	• REMOTE CONTROL PIPING ; C/V			
	ZH32X04000	•• ELBOW	1		

2.3 LAYING OF PIPING

(1) Breaker specification




Fig. 1 Outside view of Breaker-attached machine

(2) Nibbler & Breaker specification




Fig. 2 Outside view of Nibbler & Breaker-attached machine

5.9 UPPER HYDRAULIC PIPING (NIBBLER & BREAKER)



(1) Modification Procedure

Fit the additional parts in Table 11, according to Fig. 12.

UPPER HYDRAULIC PIPING LC03H00031F1					Table 11				
No.	PART No.	NAME	Q'TY	REMARK	No.	PART No.	NAME	Q'TY	REMARK
1	LC03H01063P1	TUBE	1		15	ZS18C10030	CAPSCREW	4	M10×30
2	LC03H01095P1	TUBE	1		16	ZS18C12035	CAPSCREW	8	M12×35
3	LC03H01197P1	TUBE	1		17	ZS18C12090	CAPSCREW	1	M12×90
4	LC03H01025D1	HOSE ; L=1700	1		18	ZS28C12040	CAPSCREW	16	M12×40
5	HH25R16016G2	CONNECTOR	1	PF1	19	ZW16H10000	WASHER	4	M10
6	HH35X16016G1	ELBOW SELECTOR VALVE	1	PF1	20	ZW16H12000	WASHER	9	M12
7	24100P2599F2	SUPPORT	1		21	2418T10357	WASHER	3	
8	LC03H01064P1	SUPPORT	1		22	ZW26K12000	LOCK WASHER	20	M12
9	LC03H01218P1	BRACKET	1		23	ZN18C12010	NUT	1	M12
10	LC03H01194P1	CLAMP	1		24	LC03H01070P1	SUPPORT	1	
11	ZS28C12065	CAPSCREW	4	M12×65	25	YN32H01066P1	CLAMP	2	
12	ZE13X16000	HALF CLAMP	8		26	YN03H01431P1	BUSHING	2	
13	ZD12P03400	O RING	5	1B P34	27	ZS18C12055	CAPSCREW	2	M12×55
14	ZD12A02100	O RING	2	1B A21	28	LC03H01200P1	SUPPORT	1	

Capscrew	
Thread size	Tightening torque kgf·m (lbf·ft)
M10	7.2 (52.1)
M12	12.3 (89.0)

O ring type coupling		Hydraulic hose (30° flare)	
Thread size (PF)	Spanner (mm)	Tightening torque kgf·m (lbf·ft)	Tightening torque kgf·m (lbf·ft)
1	41	26.0 (188)	14.0 (101)



5.10 RETURN HYDRAULIC PIPING N&B

(1) Parts to be disused

Concerning the return hydraulic piping, the parts listed in Table 11 and Fig. 13 is disused from the standard machine.

Table 11				
UPPER HYDRAULIC PIPING LC32H00015F1				
No.	PART No.	NAME	Q'TY	REMARKS
40	ZE72X16000	PLUG	1	With O RING




Fig. 12 Upper hydraulic piping (Nibbler & Breaker)

Fig. 13 Parts to be disused

7.3 HYDRAULIC PIPING FOR 6.5M (21ft-4in) BOOM

(1) Nibbler & Breaker, Breaker

Install the additional parts listed in Table 3 to the 6.5m (21ft-4in) boom modified as shown in Fig. 2.

BOOM HYDRAULIC PIPING		LC42H00014F1		Table 3					
No.	PART No.	NAME	Q'TY	REMARK	No.	PART No.	NAME	Q'TY	REMARK
3	LC42H01062P1	TUBE	1		14	ZD12P03800	O RING	6	1B P38
4	LC42H01063P1	TUBE	1		15	ZS18C12065	CAPSCREW	16	M12×65
5	2444R1166D7	HOSE	2		16	ZS18C10030	CAPSCREW	12	M10×30
6	LC42H01041D1	HOSE	2		17	ZW16H12000	WASHER	16	M12
7	ZE72X16000	PLUG	4		18	ZW16H10000	WASHER	12	M10
8	LS42H01018P1	CLAMP	4		19	ZE13X20001	HALF CLAMP	12	
9	LS42H01019P1	CLAMP	8		20	ZS28C14050	CAPSCREW	24	M14×50
11	LC42H01269P1	CLAMP	8		21	ZW26K14000	LOCK WASHER	24	M14
12	LC42H01020P1	BUSHING	4		22	LC42H01123P1	TUBE	1	
13	LC43H01013P1	BUSHING	6		23	LC42H01124P1	TUBE	1	

NOTE :

- Remove item 7 plug as necessary, and install an accumulator recommended by the breaker maker.

NOTE :

- Pay attention to dropping off O ring at assembling.
- Tightening torque for M-threads

Thread size	Tightening torque
M10	6.70kgf·m (48.5 lbf·ft)
M12	11.7kgf·m (84.8 lbf·ft)
- Tightening torque for ORS joint nut

Thread size	Tightening torque
1 7/16-12UN	21.0kgf·m (152 lbf·ft)
- Apply loctite #242 at the setting bolts of clamp.

(2) Parts to be disused

Table 4

BOOM HYDRAULIC PIPING		LC42H00013F1		STD	
No.	PART No.	NAME	Q'TY	REMARK	
10	LS43H01005P1	CLAMP	8		
13	LC42H01020P1	BUSHING	4		
16	ZS18C1030	CAPSCREW	8		
18	ZW16H10000	WASHER	8		





Fig.2 Hydraulic piping for 6.5M (21ft-4in) boom (Nibbler & Breaker, Breaker)

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL