

# HYDRAULIC EXCAVATOR

**SK330**<sub>VI</sub>

**SK330**<sub>LCVI</sub>

**SK330**<sub>NLCVI</sub>

**SHOP  
MANUAL**

**model**

## INDEX

1	SPECIFICATION SECTION
2	MAINTENANCE SECTION
3	SYSTEM SECTION
4	DISASSEMBLY SECTION
5	TROUBLESHOOTING
6	ENGINE SECTION
7	INSTALLATION PROCEDURES FOR OPTIONAL ATTACHMENT

MAINTENANCE SPECIFICATION

SYSTEM

DISASSEMBLING

TROUBLESHOOTING

E/G

OPT

**KOBELCO**

Book code No. S5LC0007E③

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below




- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.


CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

(7) Unit conversion logarithmic chart


**FORCE**



**TORQUE**



**PRESSURE**



SK330NLC VI

● PROCEDURE (WITH ATTACHMENT)

NOTE :

Lifting machine with wider track shoes will tend to shift the Center of Gravity slightly forward, toward the center of the slewing ring.

Tools name	Remarks
Cable (A)	∅45.0×15.7m 1pc.
Cable (B)	∅45.0×15.5m 1pc.
Spreader bars (C)	4.0m 2pcs.


Unit : mm (ft-in)

Weight : 33,700kg (74,290 lbs)

Arm : 3.3M (10ft-10in)

Shoe : 600mm (24in)

Model : SK330NLC VI



● PROCEDURE (WITHOUT ATTACHMENT)


Tools name	Remarks
Cable (A)	∅45.0×16.4m 1pc.
Cable (B)	∅45.0×15.2m 1pc.
Spreader bars (C)	4.0m 2pcs.

Unit : mm (ft-in)

Weight : 27,600kg (60,870 lbs)


Shoe : 600mm (24in)

Model : SK330NLC VI




## 9. TYPE OF CRAWLER

### 9.1 NORMAL CRAWLER

Shape	Shoe width mm (in)	Overall width of crawler mm (ft-in)	Ground pressure kgf /cm <sup>2</sup> (psi)
Grouser shoe  45 LINKS	600 (24")	3,200 (10'6")	0.69 (9.81)
	800 (32")	3,400 (11'2")	0.53 (7.54)

### 9.2 LONG CRAWLER

Shape			Shoe width mm (in)	Overall width of crawler mm (ft-in)	Ground pressure kgf /cm <sup>2</sup> (psi)
Grouser shoe  48 LINKS	LC		600 (24")	3,200 (10'6")	0.65 (9.28)
			800 (32")	3,400 (11'2")	0.51 (7.25)
			900 (36")	3,500 (11'6")	0.45 (6.53)
	NLC		600 (24")	3,000 (9'10")	0.64 (9.13)
			800 (32")	3,200 (10'6")	0.50 (7.11)

#### NOTE :

Use grouser shoes on rough ground (areas covered with rocks and gravel). If you drive or excavate with other shoes, this may cause shoe bending, shoe bolt looseness, and track assembly (link, roller, etc.) damage.

### 3. BUCKET

#### 3.1 BUCKET DIMENSIONAL DRAWING

##### (1) STD bucket




Fig. 3-1 Hoe bucket dimensional drawing

Table 3-1

No.	NAME	No.	NAME
A	Distance between pin and bracket	G	Outer width of bucket bottom
B	Distance between bucket pin and tooth end	H	Bucket outer width of teeth
C	Inner width of bucket end	I	Pitch between teeth
D	Inner width of lug	I0	Pitch between teeth
E	Inner width of bracket	d1	Outer dia. of bushing
F	Outer width of side cutter	d2	Pin dia.

#### 3.2 BUCKET DIMENSIONAL TABLE





Table 3-2

Unit : mm (ft-in)

Type	STD bucket			
	[STD] 1.40m <sup>3</sup> (1.83cu.yd)	1.20m <sup>3</sup> (1.57cu.yd)	1.60m <sup>3</sup> (2.09cu.yd)	1.80m <sup>3</sup> (2.35cu.yd)
Part No.	LC61B00014F1	LC61B00015F1	LC61B00016F1	LC61B00017F1
A	R513 (20.2")	←	←	←
B	R1,690 (5'6")	←	←	←
C	1,250 (4'1")	1,060 (3'6")	1,430 (4'8")	1,620 (5'4")
D	446 (17.6")	←	←	←
E	382 (15")	←	←	←
F	1,430 (4'8")	1,240 (4'1")	1,610 (5'3")	1,683 (5'6")
G	1,126 (3'8")	936 (36.9")	1,306 (4'3")	1,496 (4'11")
H	1,250 (4'1")	1,060 (3'6")	1,430 (4'8")	1,620 (5'4")
I	284 (11.2")	316 (12.4")	329 (13")	377 (14.8")
I0	284 (11.2")	316 (12.4")	329 (13")	377 (14.8")
d1	Ø105 (4.13")	←	←	←
d2	Ø90 (3.54")	←	←	←

## 6. SPECIAL TOOLS

Table 6-1

No.	Tools name	Tools No.	Shape	Applicable
1	Allen wrench Nominal B : 10 C : 11.3	ZT22A10000	 <p style="text-align: center;">Commercial tool length (L1) - cut length = Required length 40(1.57) - 10(0.39) = 30(1.18)</p>	Pump suction
2	Allen wrench Nominal B : 17 C : 19.1	ZT22A17000	General tools	Pump install
3	Spanner Nominal S : 36	ZT12A36000	 <p style="text-align: center;">Commercial tool outer width (D) - cut length = Required length 81(3.19) - 16(0.63) = 65(2.56)</p>	Swing motor A,B port
4	Plug PF1	ZE72X16000		For slinging the swing motor
5	Eye bolt M12×22	ZS91C01200 or commercial equivalent		For slinging the swing motor & Flare hose

Group	Location	Work to be done	Unit	Remark	SK330(LC)VI SK330NLCVI
03 Swing frame	109 Swivel joint	O/H	1 set	Removing and installing guard	3.6
	Other necessary works	Detach/attach	1 set	Lower piping	0.6
	110 Multi control valve			15. Reference for multi C/V	
	111 • Multi C/V ASSY	Detach/attach	1	After removing guard	1.7
	112 Write hose name on multi C/V connecting hose	Detach/attach	1 set		0.3
	113 • Piping	Detach/attach	1 set		0.5
	114 • Mounting bolt	Detach/attach	1 set		0.3
	115 • Cleaning	Cleaning	1 set		0.2
	Other necessary works	Detach/attach	1 set	Guard	0.4
	120 Main control valve			16. Reference for control valve	
121 Main control valve ASSY	Detach/attach	1 pc.		2.2	
122 • Attach tag to port name of pipe	Preparation	1 pc.		0.6	
123 • Piping	Detach/attach	1 set		1.0	
124 • Bracket mounting bolt	Detach/attach	1 pc.		0.1	
125 • Valve slinging	Detach/attach	1 pc.		0.1	
126 Main control valve ASSY	O/H	1 set		6.0	
Other necessary works	Detach/attach	1 set	Guard	0.4	
130 Valve relation					
131 Solenoid valve ASSY	Detach/attach	1		1.0	
132 • Attach tag to port name of pipe	Preparation	1		0.2	
133 • Piping	Detach/attach	1 set		0.5	
134 • Mounting bolt	Detach/attach	1		0.3	
140 Engine (E/G) mounting relation			13. Reference for engine		
141 Engine ASSY	Detach/attach	1 pc.	After removing pump & radiator	2.7	
142 • Harness connector & grounding & cable connection	Detach/attach	1 pc.		0.3	
143 • Fuel hose	Detach/attach	1 pc.		0.1	
144 • Others	Detach/attach	1 set		0.5	
145 • Mounting bolt	Detach/attach	1 pc.		0.5	
146 • Engine slinging	Detach/attach	1 set		0.3	
147 • Cleaning	Cleaning	1 pc.		0.5	
148 Engine	O/H	1 set	Reference for engine		
Other necessary works	Detach/attach	1 set	Removing and installing guard	0.7	
	Detach/attach	1 set	Removing and installing counter weight	0.9	
	Detach/attach	1 set	Removing and installing pump	2.8	
	Detach/attach	1 set	Removing and installing air cleaner	0.4	
	Detach/attach	1 set	Removing and installing muffler	0.5	
	Detach/attach	1 set	Removing and installing radiator	5.5	
150 Upper frame			21. Reference for upper frame		
151 Upper frame ASSY	Detach/attach	1 pc.	After removing swivel joint	2.0	
152 • Mounting bolt	Detach/attach	1 set		0.4	
153 • Upper frame slinging	Detach/attach	1 pc.		0.6	
154 • Cleaning	Cleaning	1 pc.		0.3	
155 • Sealant	Apply	1 pc.		0.2	
Other necessary works	Detach/attach	1 set	Cab	1.2	
	Detach/attach	1 set	Guard	0.4	
	Detach/attach	1 set	Counter weight	0.9	
	Detach/attach	1 set	Boom	2.1	

NAME OF WORK	NAME OF TROUBLE	MODEL
		6D1 (6D16-TE)
Hydrostatic test of cylinder head. (1 set) (single)	Cylinder head is cracked. Cylinder head is blowholed. Cylinder head system in general is out of order.	1.5
Replacing cylinder head gasket (1 pc.) (On-machine) Incl. : Adjusting engine (A).	Water leaks from cylinder head. Oil leaks from cylinder head. Gas leaks from cylinder head. Cylinder head system in general is out of order.	7.0
Replacing cylinder head gasket. (one side) (On-machine) Incl. : Adjusting engine (A).	Water leaks from cylinder head gasket. Oil leaks from cylinder head gasket. Gas leaks from cylinder head gasket.	—
Retightening cylinder head bolts. (1 unit) (present machine) Incl. : Adjusting valve clearance.		2.3
Replacing pre-combustion chamber. (1 pc.) Excl.: Detaching/attaching head. Incl. : (1) Detaching/attaching and cleaning glow plug (1 pc.). (2) Adjusting nozzle (1 pc.) for each nozzle increased : Medium size 0.4hr. Large size 0.5hr.	Pre-combustion chamber is broken. Water leaks from pre-combustion chamber gasket.	1.0
<b>Rocker cover 03 – 15</b>		
Replacing rocker cover packing. (1 pc.) Increase 0.1hr. as one direct injection increases.	Rocker cover packing is cracked. Oil leaks from rocker cover packing.	0.6
Replacing rocker casing packing. (1 unit) Incl. : (1) Adjusting valve clearance. (2) Detaching/attaching rocker casing.	Oil leaks from rocker casing packing.	—
<b>Cylinder block 03 – 20</b>		
Replacing cylinder block Incl. : (1) Detaching and attaching engine. (2) Conditioning engine (B) and travel test. Excl. : Replacing associated parts		55.0
Replacing cylinder liners. (all Q'y on present vehicle) Incl. : (1) Conditioning engine (A). (2) Adjusting nozzle.		27.0
Replacing side cover packing. (front side)	Oil leaks from side cover gasket.	0.4
Replacing side cover packing. (left)	Oil leaks from side cover gasket.	—
Replacing side cover packing. (right) Increase 2.0hr. where injection pump is tilted.	Oil leaks from side cover gasket.	—

Table 1 (2/2)


Inspection Item	Measuring Position		Standard value	Hi	Lo	Unit	Adjusting Point	Measuring condition
	Position	Screen code						
Secondary pilot pressure circuit  P1 pump proportional valve & P2 pump proportional valve	Gauge cluster C-2 Multi display	Service diagnosis screen No.	No.24 No.25	6 (85)	+1.5 (20)	-1.5 (20)	kgf/cm <sup>2</sup> (psi)	Indicated Current value (mA) MIN 350
			No.24 No.25	32 (460)	+0.5 (7)	-0.5 (7)		MAX 770

Inspection item			Standard value	Unit		
Operating speed	Track link revolution (RH,LH)	M mode	STD	1st speed 30.6~33.8 2nd speed 17.7~19.7	sec / 3 rev	M mode E/G HI idle
			LC	1st speed 32.7~35.9 2nd speed 18.9~20.9		
		Boom		Raise 3.2~3.8 Lower 3.1~3.7		
			Arm	In 5.0~5.8 Out 3.2~3.8		
	Bucket	Digging 2.8~3.4 Dumping 2.2~2.8				
		—	—			
	—	—				
	Swing speed (M mode STD)	Variable speed —		sec / 3 rev		
		STD speed 19.5~21.5				
	Travel speed	1st speed	Rubber — Iron 19.0~24.0	sec / 20m		
			2nd speed		Rubber — Iron 11.7~13.7	
		2nd speed 0~1.2			m / 20m	
Parking brake drift		1 / 5 Gradient 0			mm / 5min	
Performance	Performance of Swing brake Neutral position after 180° full speed swing		55~95	degree		
	Performance of Swing parking brake 1 / 5 Gradient		0	mm (in)		
	ATT amount of drift	Tip of the bucket tooth		120	mm / 5min (At no load)	
		Boom cylinder		4		
		Arm cylinder		6		
Dozer cylinder		—				
Amount of horizontal play at the bucket tooth			25~50	mm		




The port relief valves No.OR1~OR8 on the control section are adjusted to the following operation numbers in advance.

- ① Bucket digging    ② Bucket dumping    ③ Boom raise
- ④ Boom lower    ⑤ Swing left    ⑥ Swing right
- ⑦ Arm in    ⑧ Arm out




(3) Engine control




**NOTE : BACK-UP CABLE ADJUSTING PROCEDURE**


1. Pull knob in the cab about 60mm (2.36in) as far as it comes into contact with stopper while pushing button, and install cables having 0.5mm (0.0197in) clearance with stop bolt on Hi side.
2. Return knob to the original position, and make certain the cable has sufficient slack at governor stop position.




SECTION A-A



SECTION C-C




SECTION B-B



SECTION D-D

Fig. 38 E/G control

## 1.7 ARM OUT CONFLUX CONTROL




### Arm out conflux

- 1) Start arm out operation simultaneously, and arm operation pilot pressure switches arm spool, arm T2 spool, arm conflux spool and is input into low pressure sensor.
- 2) The voltage output of the low pressure sensor enters the mechatro controller, processed internally and put out to the P1 bypass cut proportional valve as command current according to the input voltage.
- 3) The P1 bypass cut solenoid proportional valve puts out the secondary pilot pressure according to the current command from the mechatro controller and changes over the P1 bypass cut valve of the control valve.
- 4) The output voltage of the negative control pressure sensor and the back-pressure sensor is put into the mechatro controller, and negative control signal is processed internally. The controller then puts out current command to the P1/P2 pump solenoid proportional valves according to the input voltage.
- 5) The P1/P2 pump solenoid proportional valves put out secondary pressure for the proportional valves according to the command current levels from the mechatro controller, in order to change the delivery rates of the P1/P2 pumps.
- 6) If the P1 bypass cut valve is changed over, the oil delivered by the P1 pump is combined with the arm line during arm out operation.

(2) Gauge cluster (symbol C-2)

1) General view



2) Connector CN21

No.	Name	Wire color	No.	Name	Wire color
1	TXD 1 (Serial communication)	BrR	5	SHIELD	B
2	RXD 2 (Serial communication)	YR	6	GND	W
3	Engine coolant temp. sensor	R	7	Power supply (+24V)	B
4	Fuel sensor	W	8	GND	—


3) Function

- ① It processes signals by communication between the gauge cluster and the mechatro controller, displays them in lamps, displays them in LCDs and actuates the buzzer.
- ② It puts out coolant temperature signals, fuel level signals and panel switch signals to the mechatro controller through the communication port.


4) Display and summary of actuate item

No.	Item name	Type	
1	Monitor display	LCD dot 128×55	
2	Gauge display (Coolant temp., Fuel level)	Tolerance coil	
3	Mode display (A · M · B)	Lamp display (1.4W)	
4	Warning buzzer	Piezoelectric type	
5	Screen change switch		
6	Back light	For gauge	Lamp (2W)
		For SW, For LCD	LED

(3) Switch assy (SW-2)



(4) Governor motor (Symbol M-2)



CONNECTION DIAGRAM


BROWN (A) RED (B)  
ORANGE (A) YELLOW (B)

LIMIT SWITCH CONNECTOR WIRE TABLE

No.	Lead color	Connection
5	White	COM
6	Red	NO
7	Yellow	NC

MOTOR CONNECTOR WIRE TABLE

No.	Lead color	Connection
1	Brown	A
2	Orange	$\bar{A}$
3	Red	B
4	Yellow	$\bar{B}$



BUCKET CIRCUIT : Bucket digging, Confluence & ATT boost

## 10. COMBINED CIRCUIT

This section describes only the difference in combined operation.

- 1) Boom raise/travel, pilot circuit
- 2) Boom raise/travel, main circuit

### 10.1 BOOM RAISE/TRAVEL, PILOT CIRCUIT

Operation :

<Pilot circuit other than independent operation>  
<Mechatronic>

- 1) If the mechatronic controller processes signals, a current command is put out to two valves; the travel straight solenoid proportional valve (PSV-C) and the P2 bypass cut solenoid proportional valve (PSV-B). These valves put out secondary pressure which acts upon the PTb and the PCa ports of C/V (2).

<Hydraulic>

- 2) Next, the PTb port pressure changes over the travel straight valve.

Meanwhile, the solenoid proportional valve which enters the PCa port of C/V (2) changes over the P2 bypass cut valve.

### 10.2 BOOM RAISE/TRAVEL, MAIN CIRCUIT

Purpose :

To insure straight travel movement during travel operation even if the attachment is operated.

Principle :

The travel action and the attachment action are actuated by separate pumps.

Operation :

- 1) The oil delivered by the P1 and P2 pumps runs into the travel straight section from the P1 and P2 ports of C/V (2). Since the travel straight spool is shifted, the oil delivered by the P2 pump is branched off to the P1 and P2 bypass lines.


In the meantime, the oil delivered by the P1 pump are branched off to the P1 and P2 parallel circuits.

- 2) Next, since the travel right and left actions operate on the bypass circuits, the oil delivered by the P2 pump is used.

Meantime, since the boom spool and other spools operate on the parallel circuits, the oil delivered by the P1 pump is used.

(8) Swing priority pilot lines ; LC64H00013F1 ; EU

(9) Remote control lines for travel ; YN62H0003E



TIGHTENING TORQUE  
1. 9x1.1 (1411-124)  
4 PLACES

NOTE  
PORTS IN 1, 2 INDICATE LOWER SIDE ONE  
ON THE CONTROL VALVE.

TIGHTENING  
TORQUE  
1. 2x1.1 (1241-124)  
2 PLACES

10  
11  
8

10  
11  
8

SCREW	SIZE	QTY
M8	2.0 (20)	2
M10	2.2 (22)	1

SCREW	SIZE	QTY
M8	2.0 (20)	2
M10	2.2 (22)	1

SCREW	SIZE	QTY
M8	2.0 (20)	2
M10	2.2 (22)	1

Applicable Machines  
LC06-05501 ~  
YC06-02501 ~

Revision	Date of Issue	Remarks
First edition	March, 2000	S5LC2307E K

WIRE NO	WIRE COLOR	WIRE SIZE	FROM	CONNECTION	TO	FUNCTION
1A	RY	AVSS0.75sq	CN-5F	-----	CN-8F	MECHATRO CONTROLLER ← FUSE BOX
1B	RY	AVSS0.75sq	CN-53F	-----	CN-8F	J/C-GRAY ← FUSE BOX
1C	RY	AVSS0.75sq	CN-53F	-----	CN-5F	J/C-GRAY ← MECHATRO CONTROLLER
1D	RY	AVSS0.75sq	CN-53F	-----	CN-20F	J/C-GRAY ← RESISTOR
2A	WY	AVSS0.75sq	CN-53F	-----	CN-8F	J/C-GRAY ← FUSE BOX
2B	WY	AVSS0.75sq	CN-53F	-----	CN-16F	J/C-GRAY → WORK LIGHT RELAY
2C	WY	AVSS0.75sq	CN-53F	-----	CN-17F	J/C-GRAY → TRAVEL ALARM RELAY
2D	WY	AVSS0.75sq	CN-53F	-----	CN-29F	J/C-GRAY → WIPER RELAY ASSY
2E	WY	AVSS0.75sq	CN-53F	-----	CN-39F	J/C-GRAY → NIBBLER OPEN RELAY
2F	WY	AVSS0.75sq	CN-53F	-----	CN-49F	J/C-GRAY → OPT WORK LIGHT RELAY
2G	WY	AVSS0.75sq	CN-53F	-----	CN-34F	J/C-GRAY → BUCKET CONTROL RELAY
3	YL	AVSS0.75sq	CN-9M	-----	CN-38M	FUSE BOX → CIGARETTE LIGHTER
4	YR	AVSS0.75sq	CN-9M	-----	CN-36M	FUSE BOX → TUNER AM&FM
5A	WG	AVSS0.75sq	CN-9M	-----	CN-27F	FUSE BOX → 15PAF-J/B
5B	WG	AVSS0.75sq	CN-15F	-----	CN-27F	HORN RELAY ← 15PAF-J/B
5C	WG	AVSS0.75sq	CN-15F	-----	CN-27F	HORN RELAY ← 15PAF-J/B
7	YG	AVSS0.75sq	CN-9M	-----	CN-5F	FUSE BOX → MECHATRO CONTROLLER
8	WV	AVSS0.75sq	CN-9M	-----	CN-38M	FUSE BOX → POWER WINDOW CONTROLLER
9A	YB	AVSS0.75sq	CN-9M	-----	CN-27F	FUSE BOX → 15PAF-J/B
9B	YB	AVSS0.75sq	CN-54F	-----	CN-27F	ROOM LIGHT ← 15PAF-J/B
9C	YB	AVSS0.75sq	CN-36M	-----	CN-27F	TUNER AM&FM ← 15PAF-J/B
9D	YB	AVSS0.75sq	CN-55F	-----	CN-27F	CAREER DATA REC SYSTEM ← 15PAF-J/B
10	WV	AVSS1.25sq	CN-9M	-----	CN-36M	FUSE BOX → KEY SW.
11	OL	AVSS0.75sq	CN-9M	-----	CN-42F	FUSE BOX → AUTO GREASE CONTROLLER
12A	RG	AVSS1.25sq	CN-9M	-----	CN-26F	FUSE BOX → 15PAF-J/B
12B	RG	AVSS0.75sq	CN-17F	-----	CN-26F	TRAVEL ALARM RELAY → 15PAF-J/B
12C	RG	AVSS0.75sq	CN-41F	-----	CN-26F	CAB → 15PAF-J/B
12D	RG	AVSS0.75sq	CN-61F	-----	CN-26F	ONE WAY CALL AMP → 15PAF-J/B
13A	W	AVSS0.75sq	CN-9M	-----	CN-27F	FUSE BOX → 15PAF-J/B
13B	W	AVSS0.75sq	CN-38M	-----	CN-27F	POWER WINDOW CONTROLLER → 15PAF-J/B
13C	W	AVSS0.75sq	CN-38M	-----	CN-27F	CLUSTER GAUGE → 15PAF-J/B
13D	W	AVSS0.75sq	CN-34F	-----	CN-27F	STROKE END PROXIMITY SW → 15PAF-J/B
14A	RB	AVSS1.25sq	CN-9M	-----	CN-26F	FUSE BOX → 15PAF-J/B
14B	RB	AVSS1.25sq	CN-29F	-----	CN-26F	WIPER RELAY ASSY → 15PAF-J/B
14C	RB	AVSS0.75sq	CN-44F	-----	CN-26F	ROOF WIPER SW → 15PAF-J/B
14D	RB	AVSS0.75sq	CN-37F	-----	CN-26F	ROOF WIPER MOTOR → 15PAF-J/B
15A	WB	AVSS0.75sq	CN-53F	-----	CN-9M	J/C-GRAY → FUSE BOX
15B	WB	AVSS0.75sq	CN-53F	-----	CN-32M	J/C-GRAY ← LEVER LOCK SW
15C	WB	AVSS0.75sq	CN-53F	-----	CN-13F	J/C-GRAY ← RESISTOR
15D	WB	AVSS0.75sq	CN-53F	-----	CN-34F	J/C-GRAY → ARM PUSH/PULL PORT SELECT SOL.
16	RW	AVSS1.25sq	CN-9M	-----	CN-16F	FUSE BOX → WORK LIGHT RELAY
17	WL	AVSS1.25sq	CN-49F	-----	CN-9M	OPT WORK LIGHT RELAY → FUSE BOX
18	WG	AVSS1.25sq	CN-9M	-----	CN-36M	FUSE BOX → AIR CONDITIONER AMP.
19	RL	AVSS0.75sq	CN-9M	-----	CN-36M	FUSE BOX → AIR CONDITIONER AMP.
20A	WR	AVSS1.25sq	CN-9M	DOUBLE SPLICE	CN-43F	FUSE BOX → RESERVE
20B	WR	AVSS1.25sq	CN-62F	-----	CN-43F	RESERVE → RESERVE
30	G	AVSS0.75sq	CN-12F	-----	CN-30F	SAFETY RELAY ← ALTERNATOR
50	L	AVSS1.25sq	CN-8F	-----	CN-36M	FUSE BOX ← KEY SW.
51	W	AVS2sq	CN-8F	-----	CN-30F	FUSE BOX ← BATTERY RELAY
52	R	AVS5sq	CN-8F	-----	CN-33M	FUSE BOX ← BATTERY RELAY
53	Y	AVS5sq	CN-8F	-----	CN-33M	FUSE BOX ← BATTERY RELAY
58A	P	AVSS0.75sq	CN-27F	-----	CN-36M	15PAF-J/B ← KEY SW.
58B	P	AVSS0.75sq	CN-27F	-----	CN-40F	15PAF-J/B ← DIODE
58C	P	AVSS0.75sq	CN-27F	-----	CN-30F	15PAF-J/B → GLOW RELAY
59A	W	AVSS0.75sq	CN-30F	-----	CN-26F	BATTERY RELAY ← 15PAF-J/B
59B	W	AVSS0.75sq	CN-46F	-----	CN-26F	DIODE → 15PAF-J/B
59C	W	AVSS0.75sq	CN-12F	-----	CN-26F	SAFETY RELAY → 15PAF-J/B

WIRE NO	WIRE COLOR	WIRE SIZE	FROM	CONNECTION	TO	FUNCTION
60A	WL	AVSS0.75sq	CN-27F	-----	CN-46F	15PAF-J/B → DIODE
60B	WL	AVSS0.75sq	CN-27F	-----	CN-36M	15PAF-J/B ← KEY SW.
60C	WL	AVSS0.75sq	CN-27F	-----	CN-40F	15PAF-J/B ← DIODE
60D	WL	AVSS0.75sq	CN-27F	-----	CN-2F	15PAF-J/B → MECHATRO CONTROLLER
61A	GrB	AVSS0.75sq	CN-26F	-----	CN-36M	15PAF-J/B ← KEY SW.
61B	GrB	AVSS0.75sq	CN-26F	-----	CN-40F	15PAF-J/B → DIODE
61C	GrB	AVSS0.75sq	CN-26F	-----	CN-40F	15PAF-J/B → DIODE
61D	GrB	AVSS0.75sq	CN-26F	-----	CN-2F	15PAF-J/B → MECHATRO CONTROLLER
63	WY	AVSS0.75sq	CN-38M	-----	CN-30F	KEY SW. → STARTER RELAY
64	LW	AVSS0.75sq	CN-12F	-----	CN-30F	SAFETY RELAY ← STARTER RELAY
65A	WR	AVSS0.75sq	CN-26F	-----	CN-30F	15PAF-J/B ← ALTERNATOR
65B	WR	AVSS0.75sq	CN-26F	-----	CN-2F	15PAF-J/B → MECHATRO CONTROLLER
65C	WR	AVSS0.75sq	CN-26F	-----	CN-38M	15PAF-J/B → HOUR METER
65D	WR	AVSS0.75sq	CN-26F	-----	CN-42F	15PAF-J/B → AUTO GREASE CONTROLLER
65E	WR	AVSS0.75sq	CN-26F	-----	CN-12F	15PAF-J/B → SAFETY RELAY
80	GrR	AVSS0.75sq	CN-29F	-----	CN-38M	WIPER RELAY ASSY → WIPER MOTOR
81	GrB	AVSS0.75sq	CN-29F	-----	CN-38M	WIPER RELAY ASSY → WIPER MOTOR
82	GO	AVSS0.75sq	CN-29F	-----	CN-30F	WIPER RELAY ASSY → WASHER MOTOR
83	GO	AVSS0.75sq	CN-30F	-----	CN-15F	HORN LOW ← HORN RELAY
84A	WR	AVSS0.75sq	CN-15F	-----	CN-27F	HORN RELAY → 15PAF-J/B
84B	WR	AVSS0.75sq	CN-36M	-----	CN-27F	HORN SW. ← 15PAF-J/B
84C	WR	AVSS0.75sq	CN-32M	-----	CN-27F	HORN SW. ← 15PAF-J/B
85A	WB	AVSS1.25sq	CN-26F	-----	CN-16F	15PAF-J/B ← WORK LIGHT RELAY
85B	WB	AVSS1.25sq	CN-26F	-----	CN-30F	15PAF-J/B → BOOM WORKING LIGHT LEFT
85C	WB	AVSS0.75sq	CN-26F	-----	CN-31M	15PAF-J/B → SW ASSY (MODE BUZZER STOP)
85D	WB	AVSS0.75sq	CN-26F	-----	CN-36M	15PAF-J/B → AIR CONDITIONER AMP.
85E	WB	AVSS0.75sq	CN-26F	-----	CN-38M	15PAF-J/B → SW ASSY (WIPER WASHER LIGHT)
86A	OW	AVSS0.75sq	CN-30F	-----	CN-26F	TIMER → 15PAF-J/B
86B	OW	AVSS0.75sq	CN-32M	-----	CN-26F	OPERATING LEVER LOCK SOL. → 15PAF-J/B
86C	OW	AVSS0.75sq	CN-46F	-----	CN-26F	DIODE ← 15PAF-J/B
86D	OW	AVSS0.75sq	CN-39F	-----	CN-26F	NIBBLER OPEN RELAY ← 15PAF-J/B
87	YV	AVSS0.75sq	CN-7F	-----	CN-32M	MECHATRO CONTROLLER ← LEVER LOCK SW.
88	PG	AVSS0.75sq	CN-30F	-----	CN-17F	TRAVEL ALARM RELAY → TRAVEL ALARM RELAY
89	BRL	AVSS0.75sq	CN-49F	-----	CN-32M	OPT. WORK LIGHT RELAY → OPT. WORK LIGHT SW.
90A	RY	AVSS1.25sq	F-1	-----	CN-26F	CAB WORKING LIGHT → 15PAF-J/B
90B	RY	AVSS1.25sq	CN-49F	-----	CN-26F	OPT. WORK LIGHT RELAY → 15PAF-J/B
90C	RY	AVSS1.25sq	F-3	-----	CN-26F	CAB WORKING LIGHT LEFT → 15PAF-J/B
90D	RY	AVSS0.75sq	CN-30F	-----	CN-26F	BOOM CYLINDER WORK LIGHT → 15PAF-J/B
98	LW	AVSS0.75sq	CN-36M	-----	CN-25F	TUNER AM&FM → SPEAKER LEFT
99	Br	AVSS0.75sq	CN-36M	-----	CN-25F	TUNER AM&FM ← SPEAKER LEFT
100	LR	AVSS0.75sq	CN-24F	-----	CN-36M	SPEAKER RIGHT → TUNER AM&FM
101	OB	AVSS0.75sq	CN-24F	-----	CN-36M	SPEAKER RIGHT → TUNER AM&FM
150	BP	AVSS0.75sq	CN-36M	-----	CN-30F	AIR CONDITIONER → RECEIVER DRIER
151	R	MVVS0.75sq	CN-36M	-----	CN-32M	AIR CONDITIONER AMP. → AIR CONDITIONER SW.
152	G	4 CORES SHIELD	CN-36M	-----	CN-32M	AIR CONDITIONER AMP. → AIR CONDITIONER SW.
153	W		CN-36M	-----	CN-32M	AIR CONDITIONER AMP. → AIR CONDITIONER SW.
154	B		CN-36M	-----	CN-32M	AIR CONDITIONER AMP. → AIR CONDITIONER SW.
SH4	Gr		CN-36M	-----	CN-32M	AIR CONDITIONER AMP. → AIR CONDITIONER SW.
202	GR	AVSS0.75sq	CN-22F	-----	CN-38M	POWER WINDOW MOTOR → POWER WINDOW CONTROLLER
203	GB	AVSS0.75sq	CN-22F	-----	CN-38M	POWER WINDOW MOTOR → POWER WINDOW CONTROLLER
204	BL	AVSS0.75sq	CN-38M	-----	CN-23F	POWER WINDOW MOTOR → POWER WINDOW CONTROLLER
205	BP	AVSS0.75sq	CN-38M	-----	CN-23F	POWER WINDOW MOTOR → POWER WINDOW CONTROLLER
210	LB	AVSS0.75sq	CN-44F	-----	CN-37F	ROOF WIPER SW. → ROOF WIPER MOTOR
211	LW	AVSS0.75sq	CN-44F	-----	CN-37F	ROOF WIPER SW. → ROOF WIPER MOTOR
214	YG	AVSS0.75sq	CN-18F	-----	CN-19F	REVOLUTION RIGHT RELAY → REVOLUTION LEFT RELAY
215	GR	AVSS0.75sq	CN-18F	-----	CN-19F	REVOLUTION RIGHT RELAY → REVOLUTION LEFT RELAY
216	O	AVSS0.75sq	CN-18F	-----	CN-35F	REVOLUTION RIGHT RELAY → REVOLUTION RIGHT SOL.
217A	LO	AVSS0.75sq	CN-18F	-----	CN-27F	REVOLUTION RIGHT RELAY → 15PAF-J/B
217B	LO	AVSS0.75sq	CN-41F	-----	CN-27F	DIODE → 15PAF-J/B
217C	LO	AVSS0.75sq	CN-36M	-----	CN-27F	REVOLUTION RIGHT SW. ← 15PAF-J/B


WIRE NO	WIRE COLOR	WIRE SIZE	FROM	CONNECTION	TO	FUNCTION
218	P	AVSS0.75sq	CN-19F	-----	CN-35F	REVOLUTION LEFT RELAY → REVOLUTION LEFT SOL.
219A	GY	AVSS0.75sq	CN-27F	-----	CN-19F	15PAF-J/B ← REVOLUTION LEFT RELAY
219B	GY	AVSS0.75sq	CN-27F	-----	CN-41F	15PAF-J/B ← DIODE
219C	GY	AVSS0.75sq	CN-27F	-----	CN-32M	15PAF-J/B → REVOLUTION LEFT SW.
220A	LW	AVSS0.75sq	CN-46F	-----	CN-26F	DIODE → 15PAF-J/B
220B	LW	AVSS0.75sq	CN-18F	-----	CN-26F	REVOLUTION RIGHT RELAY ← 15PAF-J/B
220C	LW	AVSS0.75sq	CN-19F	-----	CN-26F	REVOLUTION LEFT RELAY ← 15PAF-J/B
222	LW	AVSS0.75sq	CN-44F	-----	CN-34F	LW/BH SELECT SW. → ARM PUSH/PULL PORT SELECT SOL.
230	VR	AVSS0.75sq	CN-42F	-----	CN-30F	AUTO GREASE CONTROLLER → GREASE MOTOR
231	VY	AVSS0.75sq	CN-42F	-----	CN-30F	AUTO GREASE CONTROLLER → GREASE MOTOR
232	Gr	AVSS0.75sq	CN-42F	-----	CN-30F	AUTO GREASE CONTROLLER → GREASE MOTOR
233	GrB	AVSS0.75sq	CN-42F	-----	CN-30F	AUTO GREASE CONTROLLER → GREASE MOTOR
233	GrB	AVSS0.75sq	CN-42F	-----	CN-30F	AUTO GREASE CONTROLLER → GREASE MOTOR
401	GR	AVSS0.75sq	CN-41F	-----	CN-40F	FLASHER RELAY → SWING FLASHER 4 REAR WORKING LIGHT
402	YG	AVSS0.75sq	CN-41F	-----	CN-40F	FLASHER RELAY → SWING FLASHER 4 REAR WORKING LIGHT
403	Br	AVSS0.75sq	CN-41F	-----	CN-40F	FLASHER RELAY → SWING FLASHER 4 REAR WORKING LIGHT
500	Lr	AVSS0.75sq	CN-1F	-----	CN-30F	MECHATRO CONTROLLER → PRESS. SENSOR: BUCKET DIGGING
501	Lr	AVSS0.75sq	CN-1F	-----	CN-30F	MECHATRO CONTROLLER → PRESS. SENSOR: BUCKET DUMP
502	Lr	AVSS0.75sq	CN-1F	-----	CN-30F	MECHATRO CONTROLLER → PRESS. SENSOR: BODM RAISING
503	LO	AVSS0.75sq	CN-1F	-----	CN-30F	MECHATRO CONTROLLER → PRESS. SENSOR: BODM LOWERING
504	PG	AVSS0.75sq	CN-1F	-----	CN-30F	MECHATRO CONTROLLER → PRESS. SENSOR: ARM IN
505	PL	AVSS0.75sq	CN-1F	-----	CN-30F	MECHATRO CONTROLLER → PRESS. SENSOR: ARM OUT
506	VY	AVSS0.75sq	CN-1F	-----	CN-30F	MECHATRO CONTROLLER → PRESS. SENSOR: SWING RIGHT
507	VG	AVSS0.75sq	CN-1F	-----	CN-30F	MECHATRO CONTROLLER → PRESS. SENSOR: SWING LEFT
508	VY	AVSS0.75sq	CN-1F	-----	CN-31M	MECHATRO CONTROLLER → PRESS. SENSOR: TRAVEL RIGHT
509	Sb	AVSS0.75sq	CN-1F	-----	CN-31M	MECHATRO CONTROLLER → PRESS. SENSOR: TRAVEL LEFT
510	GR	AVSS0.75sq	CN-2F	-----	CN-30F	MECHATRO CONTROLLER → PRESS. SENSOR: P1 NEGA-CON.
511	LY	AVSS0.75sq	CN-2F	-----	CN-30F	MECHATRO CONTROLLER → PRESS. SENSOR: P2 NEGA-CON.
512	Sb	AVSS0.75sq	CN-3F	-----	CN-30F	MECHATRO CONTROLLER → PRESS. SENSOR: BACK PRESS.
513	Lr	AVSS0.75sq	CN-3F	-----	CN-31M	MECHATRO CONTROLLER → PRESS. SENSOR: P1 OPT.
514	GO	AVSS0.75sq	CN-3F	-----	CN-31M	MECHATRO CONTROLLER → PRESS. SENSOR: P2 OPT.
515	V	AVSS0.75sq	CN-2F	-----	CN-30F	MECHATRO CONTROLLER → PRESS. SENSOR: PUMP P1
516	L	AVSS0.75sq	CN-2F	-----	CN-30F	MECHATRO CONTROLLER → PRESS. SENSOR: PUMP P2
517	P	AVSS0.75sq	CN-1F	-----	CN-36M	MECHATRO CONTROLLER → PRESS. SENSOR: ACCEL POTENTI.D
518	L	AVSS0.75sq	CN-34F	-----	CN-7F	BOOM POTENTI.D → MECHATRO CONTROLLER
519	V	AVSS0.75sq	CN-34F	-----	CN-7F	ARM POTENTI.D → MECHATRO CONTROLLER
520	LO	AVSS0.75sq	CN-2F	-----	CN-31M	MECHATRO CONTROLLER → MAINTENANCE CONNECTOR
524	WR	AVSS0.75sq	CN-34F	-----	CN-7F	INTER BOOM POTENTI.D → MECHATRO CONTROLLER
525	WY	AVSS0.75sq	CN-35F	-----	CN-3F	F/R AND L/R CLINDMETER → MECHATRO CONTROLLER
526	Lr	AVSS0.75sq	CN-35F	-----	CN-3F	F/R AND L/R CLINDMETER → MECHATRO CONTROLLER
541	PL	AVSS0.75sq	CN-2F	-----	CN-31M	MECHATRO CONTROLLER → TWO-SPEED SELECT SW.
542A	GrG	AVSS0.75sq	CN-36M	-----	CN-27F	POWER BOOST SW. → 15PAF-J/B
542B	GrG	AVSS0.75sq	CN-4F	-----	CN-27F	MECHATRO CONTROLLER → 15PAF-J/B
542C	GrG	AVSS0.75sq	CN-32M	-----	CN-27F	POWER BOOST SW. → 15PAF-J/B
544	GB	AVSS0.75sq	CN-1F	-----	CN-30F	MECHATRO CONTROLLER → STEPPING MOTOR

WIRE NO	WIRE COLOR	WIRE SIZE	FROM	CONNECTION	TO	FUNCTION
30	G	AVSS0.75sq	CN-206M		CN-30M	ALTERNATOR → SAFETY RELAY
51A	G	MVVS0.75sq	CN-30M	DOUBLE SPLICE	CN-101M	FUSE BOX ← BATTERY RELAY
51B	R	4 CORES SHIELD	CN-30M		CN-101M	FUSE BOX ← BATTERY RELAY
E2	B		CN-30M			MECHATRO CONTROLLER
E3	W		CN-30M			MECHATRO CONTROLLER
SH3	Gr		UNCONNECTED	X		SHIELD
E18	B	AVSS1.25sq	CN-105F			EARTH ← EARTH
52	R	AVS5sq	CN-33F		CN-102M	FUSE BOX ← BATTERY RELAY
53	Y	AVS5sq	CN-33F		CN-102M	FUSE BOX ← BATTERY RELAY
58	P	AVSS0.75sq	CN-206M		CN-30M	GLOW RELAY ← KEY SW.
59	W	AVSS0.75sq	CN-103F		CN-30M	BATTERY RELAY ← SAFETY RELAY
63	WY	AVSS0.75sq	CN-206M		CN-30M	STARTER RELAY ← KEY SW.
64	LW	AVSS0.75sq	CN-206M		CN-30M	STARTER RELAY ← SAFETY RELAY
65	WR	AVSS0.75sq	CN-206M		CN-30M	ALTERNATOR → SAFETY RELAY
82	GD	AVSS0.75sq	CN-112F		CN-30M	WASHER MOTOR ← WINDOW WASHER MOTOR RELAY
83A	GO	AVSS0.75sq	CN-108F	DOUBLE SPLICE	CN-30M	HORN LOW → HORN RELAY
83B	GO	AVSS0.75sq	CN-108F		CN-106F	HORN LOW → HORN HIGH
85A	WB	AVSS1.25sq	CN-110F	DOUBLE SPLICE	CN-30M	BOOM WORKING LIGHT → WORK LIGHT RELAY
85B	WB	AVSS0.75sq	CN-110F		F-11	BOOM WORKING LIGHT → FRAME WORKING LIGHT RIGHT
86	OW	AVSS0.75sq	CN-116F		CN-30M	OPERATING LEVER LOCK SOL → TIMER
88	PG	AVSS0.75sq	CN-138F		CN-30M	TRAVEL ALARM ← TRAVEL ALARM RELAY
90	RY	AVSS0.75sq	F-14		CN-30M	BOOM CYLINDER WORKING LIGHT → OPT. WORK LIGHT RELAY
150	BP	AVSS0.75sq	CN-133F		CN-30M	RECEIVER DRYER → AIR CON. AMP.
155	BR	AVSS0.75sq	CN-133F		CN-206M	RECEIVER DRYER → A/C CLUTCH
230	VR	AVSS0.75sq	CN-145F		CN-30M	GREASE MOTOR → MECHATRO CONTROLLER
231	VY	AVSS0.75sq	CN-145F		CN-30M	GREASE MOTOR → MECHATRO CONTROLLER
232	Gr	AVSS0.75sq	CN-145F		CN-30M	GREASE MOTOR → MECHATRO CONTROLLER
233	GrB	AVSS0.75sq	CN-145F		CN-30M	GREASE MOTOR → MECHATRO CONTROLLER
401A	GR	AVSS0.75sq	CN-40M	DOUBLE SPLICE	CN-157F	FLASHER RELAY → SWING FLASHER RIGHT REAR WORKING LIGHT
401B	GR	AVSS0.75sq	CN-40M		CN-145F	FLASHER RELAY → SWING FLASHER LEFT REAR WORKING LIGHT
402A	YG	AVSS0.75sq	CN-40M	DOUBLE SPLICE	CN-157F	FLASHER RELAY → SWING FLASHER RIGHT REAR WORKING LIGHT
402B	YG	AVSS0.75sq	CN-40M		CN-145F	FLASHER RELAY → SWING FLASHER LEFT REAR WORKING LIGHT
403A	Br	AVSS0.75sq	CN-40M	DOUBLE SPLICE	CN-157F	FLASHER RELAY → SWING FLASHER RIGHT REAR WORKING LIGHT
403B	Br	AVSS0.75sq	CN-40M		CN-145F	FLASHER RELAY → SWING FLASHER LEFT REAR WORKING LIGHT
500	Lw	AVSS0.75sq	CN-124F		CN-30M	PRESS. SENSOR BUCKET DIGGING → MECHATRO CONTROLLER
501	Lw	AVSS0.75sq	CN-125F		CN-30M	PRESS. SENSOR BUCKET DUMP → MECHATRO CONTROLLER
502	Lw	AVSS0.75sq	CN-126F		CN-30M	PRESS. SENSOR BOOM RAISING → MECHATRO CONTROLLER
503	LO	AVSS0.75sq	CN-127F		CN-30M	PRESS. SENSOR BOOM LOWERING → MECHATRO CONTROLLER
504	PG	AVSS0.75sq	CN-130F		CN-30M	PRESS. SENSOR ARM IN → MECHATRO CONTROLLER
505	PL	AVSS0.75sq	CN-131F		CN-30M	PRESS. SENSOR ARM OUT → MECHATRO CONTROLLER
506	VY	AVSS0.75sq	CN-129F		CN-30M	PRESS. SENSOR SWING RIGHT → MECHATRO CONTROLLER
507	VG	AVSS0.75sq	CN-128F		CN-30M	PRESS. SENSOR SWING LEFT → MECHATRO CONTROLLER
510	GR	AVSSX0.75sq	CN-113F		CN-30M	PRESS. SENSOR P1 NEGA-CON. → MECHATRO CONTROLLER
511	LY	AVSSX0.75sq	CN-115F		CN-30M	PRESS. SENSOR P2 NEGA-CON. → MECHATRO CONTROLLER
512	Sb	AVSS0.75sq	CN-114F		CN-30M	PRESS. SENSOR BACK PRESS. → MECHATRO CONTROLLER
515	V	AVSSX0.75sq	CN-139F		CN-30M	PRESS. SENSOR PUMP P1 → MECHATRO CONTROLLER
516	L	AVSSX0.75sq	CN-140F		CN-30M	PRESS. SENSOR PUMP P2 → MECHATRO CONTROLLER
544	GB	AVSS0.75sq	CN-134F		CN-30M	STEPPING MOTOR → MECHATRO CONTROLLER
547	GB	AVSS0.75sq	CN-206M		CN-30M	ENG. WATER TEMP. SW. → MECHATRO CONTROLLER
548	GY	AVSS0.75sq	F-15		CN-30M	ENG. OIL PRESS. SW. → MECHATRO CONTROLLER
549	Lw	AVSS0.75sq	F-12		CN-30M	AIR FILTER RESTRICTION SW. → MECHATRO CONTROLLER
550	BG	AVSS0.75sq	CN-143F		CN-30M	ENG. OIL LEVEL SW. → MECHATRO CONTROLLER
551	GL	AVSS0.75sq	CN-132F		CN-30M	ENG. COOLANT LEVEL SW. → MECHATRO CONTROLLER
552	BrL	AVSS0.75sq	CN-137F		CN-30M	HYD. FLUID LEVEL SW. → MECHATRO CONTROLLER
553	VW	AVSS0.75sq	CN-104F		CN-30M	FUEL SENSOR → MECHATRO CONTROLLER

WIRE NO	WIRE COLOR	WIRE SIZE	FROM	CONNECTION	TO	FUNCTION	
563	O	AVSS0.75sq	F-13		CN-30M	HYD. FLUID TEMP SW → MECHATRO CONTROLLER	
566	LW	AVSS0.75sq	CN-156F		CN-56M	ENG. OIL FILTER SW → MECHATRO CONTROLLER	
580	R	MVVS0.75sq	CN-136F		CN-30M	ENG. REVOLUTION SENSOR → MECHATRO CONTROLLER	
581	W	2 CORES SHIELD	CN-136F		CN-30M	ENG. REVOLUTION SENSOR → MECHATRO CONTROLLER	
SH2	Gr		UNCONNECTED	X		CN-30M	SHIELD
600	YR	AVSS0.75sq	CN-206M		CN-30M	COOLANT THERMO SENSOR → CLUSTER GAUGE CONTROLLER	
601	BrR	AVSS0.75sq	CN-104F		CN-30M	FUEL SENSOR → CLUSTER GAUGE CONTROLLER	
700	WG	AVSS0.75sq	CN-103F		CN-30M	BATTERY RELAY → MECHATRO CONTROLLER	
702	LwB	AVSS0.75sq	CN-122F		CN-30M	TWO-SPEED SELECT SOL → MECHATRO CONTROLLER	
703	P	AVSS0.75sq	CN-117F		CN-30M	POWER BOOST SOL → MECHATRO CONTROLLER	
720	PB	AVSS0.75sq	CN-123F		CN-30M	SWING PARKING BRAKE SOL → SWING PARKING RELEASE SW	
740	BO	AVSS0.75sq	CN-118F		CN-30M	P2 BY-PASS CUT PROPORTIONAL SOL → MECHATRO CONTROLLER	
741	GrR	AVSS0.75sq	CN-118F		CN-30M	P2 BY-PASS CUT PROPORTIONAL SOL → MECHATRO CONTROLLER	
742	VR	AVSS0.75sq	CN-119F		CN-30M	TRAVEL PRIORITY PROPORTIONAL SOL → MECHATRO CONTROLLER	
743	GrB	AVSS0.75sq	CN-119F		CN-30M	TRAVEL PRIORITY PROPORTIONAL SOL → MECHATRO CONTROLLER	
744	BP	AVSS0.75sq	CN-120F		CN-30M	P1 BY-PASS CUT PROPORTIONAL SOL → MECHATRO CONTROLLER	
745	PW	AVSS0.75sq	CN-120F		CN-30M	P1 BY-PASS CUT PROPORTIONAL SOL → MECHATRO CONTROLLER	
746	BrG	AVSS0.75sq	CN-121F		CN-30M	ARM VARIABLE REGENERATION PROPORTIONAL SOL → MECHATRO CONTROLLER	
747	YV	AVSS0.75sq	CN-121F		CN-30M	ARM VARIABLE REGENERATION PROPORTIONAL SOL → MECHATRO CONTROLLER	
756	BrY	AVSSX0.75sq	CN-141F		CN-30M	PUMP P1 PROPORTIONAL SOL → K. P. S. S. MODE RELEASE SW.	
757	RY	AVSSX0.75sq	CN-141F		CN-30M	PUMP P1 PROPORTIONAL SOL → K. P. S. S. MODE RELEASE SW.	
758	BrB	AVSSX0.75sq	CN-142F		CN-30M	PUMP P2 PROPORTIONAL SOL → K. P. S. S. MODE RELEASE SW.	
759	RL	AVSSX0.75sq	CN-142F		CN-30M	PUMP P2 PROPORTIONAL SOL → K. P. S. S. MODE RELEASE SW.	
771	G	MVVS0.75sq	CN-135F		CN-30M	STEPPING MOTOR → MECHATRO CONTROLLER	
772	B	4 CORES SHIELD	CN-135F		CN-30M	STEPPING MOTOR → MECHATRO CONTROLLER	
773	R		CN-135F		CN-30M	STEPPING MOTOR → MECHATRO CONTROLLER	
774	W		CN-135F		CN-30M	STEPPING MOTOR → MECHATRO CONTROLLER	
SH1	Gr		UNCONNECTED	X		CN-30M	SHIELD
900	RB	AVSS0.75sq	CN-124F		CN-30M	PRESS. SENSOR BUCKET DIGGING → MECHATRO CONTROLLER	
901	RL	AVSS0.75sq	CN-125F		CN-30M	PRESS. SENSOR BUCKET DUMP → MECHATRO CONTROLLER	
902	W	AVSS0.75sq	CN-126F		CN-30M	PRESS. SENSOR BOOM RAISING → MECHATRO CONTROLLER	
903	OB	AVSS0.75sq	CN-127F		CN-30M	PRESS. SENSOR BOOM LOWERING → MECHATRO CONTROLLER	
904	OL	AVSS0.75sq	CN-130F		CN-30M	PRESS. SENSOR ARM IN → MECHATRO CONTROLLER	
905	OW	AVSS0.75sq	CN-131F		CN-30M	PRESS. SENSOR ARM OUT → MECHATRO CONTROLLER	
906	YB	AVSS0.75sq	CN-129F		CN-30M	PRESS. SENSOR SWING RIGHT → MECHATRO CONTROLLER	
907	YG	AVSS0.75sq	CN-128F		CN-30M	PRESS. SENSOR SWING LEFT → MECHATRO CONTROLLER	
910	WY	AVSSX0.75sq	CN-113F		CN-30M	PRESS. SENSOR P1 NEGA-CON. → MECHATRO CONTROLLER	
911	RG	AVSSX0.75sq	CN-115F		CN-30M	PRESS. SENSOR P2 NEGA-CON. → MECHATRO CONTROLLER	
912	RW	AVSS0.75sq	CN-114F		CN-30M	PRESS. SENSOR BACK PRESS. → MECHATRO CONTROLLER	
915	YL	AVSSX0.75sq	CN-139F		CN-30M	PRESS. SENSOR PUMP P1 → MECHATRO CONTROLLER	
916	YR	AVSSX0.75sq	CN-140F		CN-30M	PRESS. SENSOR PUMP P2 → MECHATRO CONTROLLER	
950	BrR	AVSS0.75sq	CN-124F		CN-30M	PRESS. SENSOR BUCKET DIGGING → MECHATRO CONTROLLER	
951	BL	AVSS0.75sq	CN-125F		CN-30M	PRESS. SENSOR BUCKET DUMP → MECHATRO CONTROLLER	
952	BR	AVSS0.75sq	CN-126F		CN-30M	PRESS. SENSOR BOOM RAISING → MECHATRO CONTROLLER	
953	BrW	AVSS0.75sq	CN-127F		CN-30M	PRESS. SENSOR BOOM LOWERING → MECHATRO CONTROLLER	
954	BrL	AVSS0.75sq	CN-130F		CN-30M	PRESS. SENSOR ARM IN → MECHATRO CONTROLLER	
955	Gr	AVSS0.75sq	CN-131F		CN-30M	PRESS. SENSOR ARM OUT → MECHATRO CONTROLLER	
956	GrL	AVSS0.75sq	CN-129F		CN-30M	PRESS. SENSOR SWING RIGHT → MECHATRO CONTROLLER	
957	Br	AVSS0.75sq	CN-128F		CN-30M	PRESS. SENSOR SWING LEFT → MECHATRO CONTROLLER	
960	BY	AVSSX0.75sq	CN-113F		CN-30M	PRESS. SENSOR P1 NEGA-CON. → MECHATRO CONTROLLER	
961	BW	AVSSX0.75sq	CN-115F		CN-30M	PRESS. SENSOR P2 NEGA-CON. → MECHATRO CONTROLLER	

WIRE NO	WIRE COLOR	WIRE SIZE	FROM	CONNECTION	TO	FUNCTION
962	GrG	AVSS0.75sq	CN-114F		CN-30M	PRESS. SENSOR BACK PRESS. → MECHATRO CONTROLLER
965	BrB	AVSSX0.75sq	CN-139F		CN-30M	PRESS. SENSOR PUMP P1 → MECHATRO CONTROLLER
966	BrY	AVSSX0.75sq	CN-140F		CN-30M	PRESS. SENSOR PUMP P2 → MECHATRO CONTROLLER
E1	B	AVS5sq	P-11		CN-33F	EARTH → INST. PANEL
E4	B	AVSS0.75sq	CN-104F		CN-105F	FUEL SENSOR → 11PAF-GND
E5	B	AVSS0.75sq	M-11		CN-105F	FRAME WORKING LIGHT → 11PAF-GND
E6	B	AVSS0.75sq	CN-107F		CN-105F	HORN HIGH → 11PAF-GND
E7	B	AVSS0.75sq	CN-109F		CN-105F	HORN LOW → 11PAF-GND
E8	B	AVSS0.75sq	CN-103F		CN-105F	BATTERY RELAY → 11PAF-GND
E9	B	AVSS0.75sq	CN-116F		CN-111F	OPERATING LEVER LOCK SOL → 11PAF-GND
E10	B	AVSS0.75sq	CN-117F		CN-111F	POWER BOOST SOL → 11PAF-GND
E11	B	AVSS0.75sq	CN-122F		CN-111F	TWO-SPEED SELECT SOL → 11PAF-GND
E12	B	AVSS0.75sq	CN-123F		CN-111F	SWING PARKING BRAKE SOL → 11PAF-GND
E13	B	AVSS0.75sq	M-12		CN-111F	AIR FILTER RESTRICTION SW. → 11PAF-GND
E14	B	AVSS0.75sq	CN-138F		CN-105F	TRAVEL ALARM → 11PAF-GND
E15	B	AVSS0.75sq	CN-112F		CN-111F	WASHER MOTOR → 11PAF-GND
E16	B	AVSS0.75sq	CN-132F		CN-111F	ENG. COOLANT LEVEL SW. → 11PAF-GND
E17	B	AVSS0.75sq	CN-134F		CN-111F	STEPPING MOTOR → 11PAF-GND
E19	B	AVSS0.75sq	CN-143F		CN-111F	ENG. OIL LEVEL SW. → 11PAF-GND
E20	B	AVSS0.75sq	CN-137F		CN-105F	HYD. FLUID LEVEL SW. → 11PAF-GND
E24	B	AVSS0.75sq	CN-157F		CN-105F	SWING FLASHER RIGHT REAR WORKING LIGHT → 11PAF-GND
E25	B	AVSS0.75sq	CN-145F		CN-111F	SWING FLASHER LEFT REAR WORKING LIGHT → 11PAF-GND
E30	B	AVSS0.75sq	M-14		CN-105F	BOOM CYLINDER WORKING LIGHT → 11PAF-GND
E31	B	AVSS0.75sq	F-16		CN-111F	HYD. FLUID TEMP. SW. → 11PAF-GND

3.8.14 INSTRUMENT PANEL LH HARNESS : YN13E01204P1, EU



CONNECTORS SELECTION TABLE

CONNECTOR NAME (PIN NUM.)	MANUFUC.	PART. NUMBER	
		HOUSING	TERMINAL
18PAF-SCC	AMP	6-178692-6	175266-2 175269-1
8PAF-070	AMP	176113-6	173631-1 173631-2
8PAM-0701	AMP	174931-1	173645-1
2PAF	YAZAKI	7123-2228	7116-2090
J/C-GREEN	SUMITOMO	6400-0013	8240-4422
		6409-0072	
2PAF-HM	SUMITOMO	6090-1001	8240-4422
6PAF	YAZAKI	7123-2262	7116-2090

WIRE NO	WIRE COLOR	WIRE SIZE	FROM	CONNECTION	TO	FUNCTION
15A	WB	AVSS0.75sq	CN-508F	•	CN-32F	J/C-GREEN ← FUSE BOX
15B	WB	AVSS0.75sq	CN-508F	•	CN-505F	J/C-GREEN → LEVER LOCK SW.
15C	WB	AVSS0.75sq	CN-508F	•	CN-503F	J/C-GREEN → EXTRA & BREAKER SW.
17	WL	AVSS0.75sq	CN-44M	•	CN-502F	FUSE BOX → ROTARY LIGHT SW.
84	WR	AVSS0.75sq	CN-506F	•	CN-32F	HORN SW ← HORN RELAY
86	DW	AVSS0.75sq	CN-515F	•	CN-32F	TIMER → OPERATING LEVER LOCK SW.
87A	YV	AVSS0.75sq	CN-508F	•	CN-505F	J/C-GREEN → LEVER LOCK SW.
87B	YV	AVSS0.75sq	CN-508F	•	CN-515F	J/C-GREEN → TIMER
87C	YV	AVSS0.75sq	CN-508F	•	CN-32F	J/C-GREEN → MECHATRO CONTROLLER
89	BrL	AVSS0.75sq	CN-501F	•	CN-32F	CAB WORK LIGHT SW. ← DPT. WORK LIGHT RELAY
91	Y	AVSS0.75sq	CN-44M	•	CN-502F	LOTARY LIGHT → ROTARY LIGHT SW.
94	RL	AVSS0.75sq	CN-44M	•	CN-503F	EXTRA SW. → EXTRA & BREAKER SW.
151	R	MVVS0.5sq	CN-500F	•	CN-32F	AIR CONDITIONER SW. ← AIR CONDITIONER AMP
152	G	4 CORES SHIELD	CN-500F	•	CN-32F	AIR CONDITIONER SW. → AIR CONDITIONER AMP
153	W		CN-500F	•	CN-32F	AIR CONDITIONER SW. → AIR CONDITIONER AMP
154	B		CN-500F	•	CN-32F	AIR CONDITIONER SW. ← AIR CONDITIONER AMP
SH	Gr		UNCONNECTED	•	CN-32F	SHIELD ← AIR CONDITIONER AMP

WIRE NO	WIRE COLOR	WIRE SIZE	FROM	CONNECTION	TO	FUNCTION
540	LG	AVSS0.75sq	CN-44M	•	CN-513F	MECHATRO CONTROLLER → OVER LOAD ALARM SELECT SW.
541	PL	AVSS0.75sq	CN-44M	•	CN-511F	MECHATRO CONTROLLER → TWO-SPEED SELECT SW.
542	GrG	AVSS0.75sq	CN-507F	•	CN-32F	ATT BOOST SW. ← MECHATRO CONTROLLER
543	GO	AVSS0.75sq	CN-44M	•	CN-512F	MECHATRO CONTROLLER → HEAVY LIFT SW.
562	O	AVSS0.75sq	CN-44M	•	CN-514F	SW BOX ASSY → WARM-UP SW.
564	LY	AVSS0.75sq	CN-504F	•	CN-32F	CONFLUX/SINGLE SELECT SW. ← SW. BOX ASSY
583	VW	AVSS0.75sq	CN-44M	•	CN-513F	OVERLOAD ALARM DETECT SW. → OVER LOAD ALARM SELECT SW.
982A	BG	AVSS0.75sq	CN-508F	•	CN-504F	J/C-GREEN ← CONFLUX/SINGLE SELECT SW.
982B	BG	AVSS0.75sq	CN-508F	•	CN-514F	J/C-GREEN ← WARM-UP SW.
982C	BG	AVSS0.75sq	CN-508F	•	CN-32F	J/C-GREEN ← SW BOX ASSY
E2	B	AVSS0.75sq	CN-508F	•	CN-511F	J/C-GREEN ← TWO-SPEED SELECT SW.
E3	B	AVSS0.75sq	CN-508F	•	CN-501F	J/C-GREEN ← CAB WORK LIGHT SW.
E4	B	AVSS0.75sq	CN-508F	•	CN-506F	J/C-GREEN ← HORN SW.
E5	B	AVSS0.75sq	CN-508F	•	CN-507F	J/C-GREEN ← POWER BOOST SW.
E6	B	AVSS0.75sq	CN-508F	•	CN-512F	J/C-GREEN ← HEAVY LIFT SW.
E7	B	AVSS1.25sq	CN-508F	•	CN-32F	J/C-GREEN → EARTH
E8	B	AVSS0.75sq	CN-508F	•	CN-515F	J/C-GREEN → TIMER

Fig.20E Instrument panel left harness

Applicable Machines  
LC06-05501~  
YC06-02501~

Revision	Date of Issue	Remarks
First edition	March, 2000	S5LC2407E K
First revision	April, 2001	S5LC2407E① K

#### 1.3.4 CAUSES OF FAULT RESULTING FROM REGULATOR

When trouble due to this regulator occurs, Disassemble and inspect it referring to "Chapter LC33".

- (1) When the engine is overloaded,  
Load every unit of pump, and check on pumps on the right and left sides for possible damages. When pumps on both sides are failed, check on them for the following failures 1), 2). When pump on the one side is failed, start checking from par. 3).
  - 1) Check that the power shift command current  $I$  is normal.
  - 2) The power shift pressure is low.
    - Check the dither of amp.
    - Replace solenoid proportional reducing valve.
  - 3) Stick of compensating piston and compensating rod
    - Disassemble and clean it.
  - 4) Stick of pin (898)
    - Disassemble and clean it.
- (2) The max. flow rate is not delivered.
  - 1) Check that pilot differential pressure  $P_i$  is normal.
  - 2) Stick of pilot piston
    - Disassemble and clean it.
  - 3) Stick of spool
    - Disassemble and clean it.

Note : When the damage of part is severe, replace the part with new one.

1) Adjusting the Outer Spring (See Fig. 1-9)  
(At back-up control)

Adjust it by loosening lock nut (630) and by tightening adjust screw C (628) (or loosening it). Tightening the adjust screw shifts the control chart to the right and increases the input horsepower, as indicated in Fig.1-18.

Since turning the adjust screw C by N turns changes the setting of the inner spring, return the adjust screw (925) by 2.2N turns at first.

Adjust screw No.	628
No. of turns for tightening	1/4
Increase in delivery pressure kgf/cm <sup>2</sup> (psi)	17.8 (250)
Increase in input torque kgf·m (ft·lbs)	4.7 (34)

2) Adjusting the Inner Spring (See Fig. 1-9)  
(At back-up control)

Adjust it by loosening nut (801) and by adjust screw (925) (or loosening it). Tightening the adjust screw increases the flow and then the input horsepower, as indicated in Fig.1-19. And the input torque raises.

Adjust screw No.	925
No. of turns for tightening	1/4
Increase in flow ℓ/min (gal/min)	18.4 (4.9)
Increase in input torque kgf·m (ft·lbs)	3.2 (23)

(4) Adjusting the flow control characteristics (See Fig. 1-9)

Adjust them by loosening nut (801) and socket screw (924) (or loosening it). Socket screw causes the control chart to move to the right as shown in Fig.1-20. Socket screw raises the flow control start pilot pressure. And the delivery rate increases.

Adjust screw No.	924
No. of turns for tightening	1/4
Increase Pilot pressure Pi kgf/cm <sup>2</sup> (psi)	1.3 (18)
Increase input current I mA	21mA
Increase in delivery flow ℓ/min (gal/min)	13.0 (3.4)




Fig.1-20 Adjusting the input horsepower (1)




Fig.1-21 Adjusting the input horsepower (2)




Fig.1-22 Adjusting the flow control characteristics

## 2.4 OPERATION

### (1) Control valve in neutral

#### Purpose :

To reduce the pump flow rate by means of the negative control signal.

#### Principle :

The negative control signal pressure is output when the flow rate at the extreme down stream is raised.

#### Operation :

The oil delivered from the hydraulic pump P1 flows into P1 port of the control valve, passes through the travel spool (307) and main passage (51), is led into bypass circuit which passes through the travel right, bucket and boom control sections and P1 bypass cut spool (309).

The oil delivered passes through P1 bypass cut spool (309) and flows into negative control relief valve (N611) located in negative control relief valve block (212) because P1 bypass cut spool (309) is not switched.

The poppet section of negative control relief valve (N611) has many small holes, and the oil delivered passes these holes and returns into the tank port (T). Consequently the rise of flow rate causes the rise of Pn1 pressure and the negative control signal is output through Pn1 port or Pn1' port. When the pressure of the negative control valve rises higher than the specified pressure, the poppet opens and the oil is led into the tank port (T).

The oil delivered from the hydraulic pump P2 also passes through main passage (54) and is led into bypass circuit (55) which passes through the travel left, boom conflux and arm control sections and P2 bypass cut spool (309) like the oil delivered from the hydraulic pump P1. The oil delivered flows into negative control relief valve (N611) like P1 side, causes the rise of Pn2 pressure, and the negative control signal is output through Pn2 port or Pn2' port.




Fig. 2-14 Functions at neutral

3) When the arm is in (under light load)

Operation	C/V Port name		
	Pilot secondary pressure side	Solenoid proportional secondary pressure side	Main pressure oil supply side
Arm in (under light load)	PAa PLC2 —	— — Pis	Ab

Purpose :

Speed up of in operation and prevention of cavitation when operating the arm at light load.

Principle :

The return oil from the arm cylinder (R) side is recirculated into the cylinder (H) side in the C/V.

If the arm in operation is performed, the secondary pilot pressure coming out of port ④ of the pilot valve acts upon the PAa port of the control valve and the PLC2 port of the lock valve selector. This causes the arm spool (302) to move to the right and changes the lock valve selector spool (211).

The pressure oil delivered by the pump P2 flows into the bypass circuit (55) past the main passage (54), but since the bypass circuit (55) is blocked by the arm spool (302), the oil pressure pushes the check valve (CP2) open, flows into the parallel circuit (56), pushes the load check valve LCa (511) open, goes between the outer circumference of the arm spool (302) and the casing through the U-shaped passage and is supplied to the arm cylinder (H) side via port (Aa).

Meanwhile, the oil which has returned from the arm cylinder (R) enters the control valve through the port (Ba).

The lock valve poppet CRa (514) is located just before arm spool (302), but since the pilot secondary pressure acts on PLC2 port and the lock valve selector spool is switched, lock valve poppet (514) opens and the pressure is led into chamber AR. In addition, the return oil has sufficient pressure because of the weight of the arm, etc., consequently the secondary pressure is led in the arm spool.

Consequently, the return oil from the arm cylinder (R) side passes through the inside of arm spool and notches on the arm spool, and flows through recirculation circuit and led in arm recirculation spool (310).

In that case, the secondary pressure of the solenoid proportional valve (Pis) is acting on the Pis port of the control valve and the arm recirculation spool is in position (II). Therefore, the oil pressure enters the passage (61) through the inside of the arm recirculation spool (310), pushes open the arm recirculation check valve poppet (512) and is supplied once again to the arm cylinder (H) as the operating oil for arm digging operation.

Part of the hydraulic oil admitted to arm recirculation spool (310) flows into tank port (T) from low pressure circuit (D) and returns to the hydraulic oil tank.


### 3. PILOT VALVE (ATT)

#### 3.1 OUTLINE


##### (1) Outside view

The adjust nut (opposing flats : 22) :  
 Fix adjust nut (opposing flats : 22) when the lever is installed by means of spanner or the like. Then tighten the mating lock nut to  $4.2 \pm 0.3 \text{ kgf}\cdot\text{m}$  ( $30 \pm 2.2 \text{ ft}\cdot\text{lbs}$ ).

SINGLE OPERATION ANGLE (PORT 2,4) :  $25^\circ$   
 SINGLE OPERATION ANGLE (PORT 1,3) :  $19^\circ$




5-PF3/8  
 $T=5 \pm 0.5 (36 \pm 4)$



PF1/4  
 $T=3 \pm 0.2 (22 \pm 1)$

T=Tightening torque :  $\text{kgf}\cdot\text{m}$  (ft·lbs)



Hydraulic symbol

##### (2) Specification

Table 3-1

Item	Specification
Part No.	YT30V00008F2
Model	PV48K1008
Operating torque	Refer to the Fig. 3-1
Max. primary pressure	50kgf/cm <sup>2</sup> (710psi)
Primary pressure	50kgf/cm <sup>2</sup> (710psi)
Rated flow	20 ℓ /min (5.3gal/min)
Weight	Approx. 2kg (4 lbs)

##### (3) Performance characteristics





Fig. 3-1

## (2) Specification

Swing motor unit part No.		LC15V00006F1	
Hydraulic motor	Part No.	LC15V00003F1	
	Type	M2X210CHB-10A-39M/280-197	
	Displacement	cm <sup>3</sup> (cu.yd)	197 (260)
	Working pressure	kgf/cm <sup>2</sup> (psi)	300 (4270)
	Max. pressure	kgf/cm <sup>2</sup> (psi)	350 (4980)
	Working flow	ℓ /min (gal/min)	253 (67)
	Braking torque	kgf·m (ft·lbs)	89 <sup>+25</sup> <sub>0</sub> (1270 <sup>+360</sup> <sub>0</sub> )
	Release pressure (Stroke end)	kgf/cm <sup>2</sup> (psi)	29 <sup>+5</sup> <sub>0</sub> (410 <sup>+71</sup> <sub>0</sub> )
	Relief set pressure	kgf/cm <sup>2</sup> (psi)	280 (3980)
	Weight	kg (lbs)	74.5 (164)
	Swing shockless valve block	Part No.	YN22V00014F4
		Type	2KAR6P72/240-712
		Weight	kg (lbs)
Hydraulic motor assy weight	kg (lbs)	77 (170)	
Reduction unit	Part No.	—	
	Speed reduction type	Planetary 2-stage	
	Reduction ratio	23.385	
	Lubricate oil	Gear oil SAE90 (API class GL-4 grade)	
	Lubricate oil volume	(gal)	21.51 (5.7)
	Grease	Extreme pressure multipurpose grease	
	Grease volume	A small amount	
	Weight	kg (lbs)	411 (906)
Total weight	kg (lbs)	488 (1080)	

(5) Brake valve

1) Spool

If the spool (2) is shifted, the oil discharged from the hydraulic motor is shut off and throttled automatically. The hydraulic motor performs holding, acceleration, stop and counterbalance actions.

2) Check valve (built in the spool)

It is the oil feeding passage to the hydraulic motor and locks the exhaust oil. Therefore, the check valve serves as the suction valve and the holding valve for the hydraulic motor.

3) Relief valve (built in the hydraulic motor)

When the pressure in the oil supply / discharge passage of the hydraulic motor reaches a set pressure value, it is relieved to the other low pressure passage to act as a safety valve of the circuit.

Spool select pressure 6.0~10kgf/cm<sup>2</sup> (85~140psi)

Check valve cracking pressure 0.1kgf/cm<sup>2</sup> (1.4psi)




Fig. 6-5 Brake valve

No.	NAME	Q'TY	No.	NAME	Q'TY
1	BODY	1	9	SPRING	2
2	SPOOL ASSY	1	10	PLUG	2
3	SPRING SEAT	2	11	O RING ; 1B P11	4
4	SPRING	2	12	CAPSCREW ; M12×45	8
5	O RING ; 1B G40	2	13	O RING ; 1B G35	2
6	O RING ; 1B P9	3	14	CAPSCREW ; M12×80	6
7	COVER	2	15	PLUG	2
8	RESTRICTOR VALVE	2	17	O RING ; 1B P10	1

## 8.2 CONSTRUCTION

### (1) Boom cylinder

T=Tightening torque ; kgf·m (ft.lbs)










Fig. 8-2 Construction of boom cylinder  
(The figure shows the right-hand cylinder.)

No.	NAME	QTY	No.	NAME	QTY	No.	NAME	QTY
1	CYLINDER TUBE	1	12	SOCKET BOLT ; M18x80	12	23	STEEL BALL	1
2	PISTON ROD	1	13	CUSHION BEARING	1	24	PIN BUSHING	1
3	ROD COVER	1	14	CUSHION SEAL	1	25	WIPER RING	2
4	BUSHING	1	15	PISTON	1	26	PIN BUSHING	1
5	SNAP RING	1	16	SEAL RING	1	27	WIPER RING	2
6	BUFFER RING	1	17	BACKUP RING	2	28	BAND ASSY	1
7	U RING	1	18	SLIDE RING	2	29	BAND	1
8	BACKUP RING	1	19	SLIDE RING	2	30	CAPSCREW; M10	2
9	WIPER RING	1	20	SHIM	1	31	WASHER	2
10	O RING ; 1B G135	1	21	PISTON NUT ; M75xP2	1			
11	BACKUP RING	1	22	SET SCREW ; M14	1			

File No. Name of part Part No. Use Applicable Machine	Specification		Description																																																																																																																																		
D-1,2,5~11  Diode  YN02D01001P1  Key switch relay  YX01001~, YV00101~ YH00101~, YY00101~ YF01-00101~, YU01-00101~ YN07-30001~, YQ07-03501~ LQ08-04501~, LL08-03001~ LC06-05501~, YC06-02501~	Maker's part No.  Peak reverse voltage  Mean output current  Surge current	7321-9822  400V  3A  200A																																																																																																																																			
D-3,4  Diode  2475R132  Starter relay Glow relay  YX01001~, YV00101~ YH00101~, YY00101~ YF01-00101~, YU01-00101~ YN07-30001~, YQ07-03501~ LQ08-04501~, LL08-03001~ LC06-05501~, YC06-02501~	Part No.  Rated current	7321-9332-60  2.5A																																																																																																																																			
E-1  Fuse box  YN73E00007F1 (EU)  Fuse	<table border="1"> <thead> <tr> <th colspan="3">Fuse capacity and circuit name</th> </tr> <tr> <th>No.</th> <th>Capacity</th> <th>Name of circuit</th> </tr> </thead> <tbody> <tr><td>①</td><td>20A</td><td>Mechatro controller</td></tr> <tr><td>②</td><td>5A</td><td>Wiper / washer relay</td></tr> <tr><td>③</td><td>10A</td><td>Cigarette lighter</td></tr> <tr><td>④</td><td>10A</td><td>Converter</td></tr> <tr><td>⑤</td><td>10A</td><td>Horn</td></tr> <tr><td>⑥</td><td>—</td><td>—</td></tr> <tr><td>⑦</td><td>5A</td><td>Controller back-up, Hour meter back-up</td></tr> <tr><td>⑧</td><td>20A</td><td>Fuel suply pump</td></tr> <tr><td>⑨</td><td>5A</td><td>Room lamp, Controller back-up</td></tr> <tr><td>⑩</td><td>20A</td><td>Key switch</td></tr> <tr><td>⑪</td><td>—</td><td>—</td></tr> <tr><td>⑫</td><td>20A</td><td>Flasher, Work light, Alarm</td></tr> <tr><td>⑬</td><td>5A</td><td>Gauge cluster, (Power window)</td></tr> <tr><td>⑭</td><td>20A</td><td>Wiper, Washer</td></tr> <tr><td>⑮</td><td>10A</td><td>Solenoid valve, Lever lock</td></tr> <tr><td>⑯</td><td>20A</td><td>Work light (front)</td></tr> <tr><td>⑰</td><td>20A</td><td>Cab</td></tr> <tr><td>⑱</td><td>20A</td><td>Air conditioner, Heater (option)</td></tr> <tr><td>⑲</td><td>5A</td><td>Air conditioner</td></tr> <tr><td>⑳</td><td>20A</td><td>Spare</td></tr> </tbody> </table>		Fuse capacity and circuit name			No.	Capacity	Name of circuit	①	20A	Mechatro controller	②	5A	Wiper / washer relay	③	10A	Cigarette lighter	④	10A	Converter	⑤	10A	Horn	⑥	—	—	⑦	5A	Controller back-up, Hour meter back-up	⑧	20A	Fuel suply pump	⑨	5A	Room lamp, Controller back-up	⑩	20A	Key switch	⑪	—	—	⑫	20A	Flasher, Work light, Alarm	⑬	5A	Gauge cluster, (Power window)	⑭	20A	Wiper, Washer	⑮	10A	Solenoid valve, Lever lock	⑯	20A	Work light (front)	⑰	20A	Cab	⑱	20A	Air conditioner, Heater (option)	⑲	5A	Air conditioner	⑳	20A	Spare	<table border="1"> <tr> <td>8</td><td>7</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1B</td><td>1A</td> </tr> <tr> <td>WV</td><td>YG</td><td>WG</td><td>OL</td><td>YL</td><td>WY</td><td>RY</td><td>RY</td> </tr> <tr> <td>20</td><td>19</td><td>18</td><td>17</td><td>16</td><td>15</td><td>14</td><td>13</td><td>12</td><td>9</td> </tr> <tr> <td>1.25</td><td>1.25</td><td>1.25</td><td>1.25</td><td>1.25</td><td>1.25</td><td>1.25</td><td>1.25</td><td>1.25</td><td>1.25</td> </tr> <tr> <td>WR</td><td>RL</td><td>WG</td><td>WL</td><td>RW</td><td>WB</td><td>RB</td><td>W</td><td>RG</td><td>YB</td> </tr> </table> <p>18PAF-HD SUMITOMO HOUSING : 6098-0257 TERMINAL : 8240-4422</p>  <table border="1"> <tr> <td>53</td><td>—</td><td>52</td> </tr> <tr> <td>5V</td><td>—</td><td>5R</td> </tr> <tr> <td>10</td><td>—</td><td>51</td><td>50</td> </tr> <tr> <td>1.25</td><td>—</td><td>1.25</td><td>1.25</td> </tr> <tr> <td>WV</td><td>—</td><td>2W</td><td>L</td> </tr> </table> <p>7PAF-HD SUMITOMO HOUSING : 6950-1030 TERMINAL : 8230-4050 8232-4238</p>	8	7	5	4	3	2	1B	1A	WV	YG	WG	OL	YL	WY	RY	RY	20	19	18	17	16	15	14	13	12	9	1.25	1.25	1.25	1.25	1.25	1.25	1.25	1.25	1.25	1.25	WR	RL	WG	WL	RW	WB	RB	W	RG	YB	53	—	52	5V	—	5R	10	—	51	50	1.25	—	1.25	1.25	WV	—	2W	L
Fuse capacity and circuit name																																																																																																																																					
No.	Capacity	Name of circuit																																																																																																																																			
①	20A	Mechatro controller																																																																																																																																			
②	5A	Wiper / washer relay																																																																																																																																			
③	10A	Cigarette lighter																																																																																																																																			
④	10A	Converter																																																																																																																																			
⑤	10A	Horn																																																																																																																																			
⑥	—	—																																																																																																																																			
⑦	5A	Controller back-up, Hour meter back-up																																																																																																																																			
⑧	20A	Fuel suply pump																																																																																																																																			
⑨	5A	Room lamp, Controller back-up																																																																																																																																			
⑩	20A	Key switch																																																																																																																																			
⑪	—	—																																																																																																																																			
⑫	20A	Flasher, Work light, Alarm																																																																																																																																			
⑬	5A	Gauge cluster, (Power window)																																																																																																																																			
⑭	20A	Wiper, Washer																																																																																																																																			
⑮	10A	Solenoid valve, Lever lock																																																																																																																																			
⑯	20A	Work light (front)																																																																																																																																			
⑰	20A	Cab																																																																																																																																			
⑱	20A	Air conditioner, Heater (option)																																																																																																																																			
⑲	5A	Air conditioner																																																																																																																																			
⑳	20A	Spare																																																																																																																																			
8	7	5	4	3	2	1B	1A																																																																																																																														
WV	YG	WG	OL	YL	WY	RY	RY																																																																																																																														
20	19	18	17	16	15	14	13	12	9																																																																																																																												
1.25	1.25	1.25	1.25	1.25	1.25	1.25	1.25	1.25	1.25																																																																																																																												
WR	RL	WG	WL	RW	WB	RB	W	RG	YB																																																																																																																												
53	—	52																																																																																																																																			
5V	—	5R																																																																																																																																			
10	—	51	50																																																																																																																																		
1.25	—	1.25	1.25																																																																																																																																		
WV	—	2W	L																																																																																																																																		

File No. Name of part Part No. Use Applicable Machine	Specification	Description										
SE-22,23  Pressure sensor (low pressure)  LC52S00001P1  P1 pump, P2 pump  YX01001~ YN07-30001~ YQ07-03501~ LQ08-04501~, LL08-03001~ LC06-05501~, YC06-02501~	<table border="1"> <tr> <td>Pressure range</td> <td>0~500kgf/cm<sup>2</sup> (0~7110psi)</td> </tr> <tr> <td>Max. allowable press.</td> <td>270kgf/cm<sup>2</sup>(3840psi)</td> </tr> <tr> <td>Operating source voltage</td> <td>5±0.5V DC</td> </tr> <tr> <td>Load resistance</td> <td>10KΩ MIN</td> </tr> <tr> <td>Insulation resistance</td> <td>More than 100MΩ</td> </tr> </table>	Pressure range	0~500kgf/cm <sup>2</sup> (0~7110psi)	Max. allowable press.	270kgf/cm <sup>2</sup> (3840psi)	Operating source voltage	5±0.5V DC	Load resistance	10KΩ MIN	Insulation resistance	More than 100MΩ	 <p>CONNECTOR MODEL HW090 3-P (T-TYPE) 3 (SUMITOMO DENSO)</p> <p>CONNECTOR TERMINAL ARRANGEMENT TERMINAL No. 1 — POWER SUPPLY (+) 2 — OUTPUT (+) 3 — COMMON</p> <p>TIGHTENING TORQUE 7.5kgf-m (54ft-lbs)</p>
Pressure range	0~500kgf/cm <sup>2</sup> (0~7110psi)											
Max. allowable press.	270kgf/cm <sup>2</sup> (3840psi)											
Operating source voltage	5±0.5V DC											
Load resistance	10KΩ MIN											
Insulation resistance	More than 100MΩ											
SE-26,27  Pressure sensor  YN52S00016P1  P1 negative control P2 negative control  YN07-30001~ YQ07-03501~ LQ08-04501~, LL08-03001~ LC06-05501~, YC06-02501~	<table border="1"> <tr> <td>Pressure range</td> <td>50kgf/cm<sup>2</sup> (710psi)</td> </tr> <tr> <td>Max. allowable press.</td> <td>525kgf/cm<sup>2</sup>(7470psi)</td> </tr> <tr> <td>Operating source voltage</td> <td>5±0.5V DC</td> </tr> <tr> <td>Load resistance</td> <td>10KΩ MIN</td> </tr> <tr> <td>Insulation resistance</td> <td>More than 100MΩ</td> </tr> </table>	Pressure range	50kgf/cm <sup>2</sup> (710psi)	Max. allowable press.	525kgf/cm <sup>2</sup> (7470psi)	Operating source voltage	5±0.5V DC	Load resistance	10KΩ MIN	Insulation resistance	More than 100MΩ	 <p>CONNECTOR MODEL HW090 3-P (T-TYPE) 3 (SUMITOMO DENSO)</p> <p>CONNECTOR TERMINAL ARRANGEMENT TERMINAL No. 1 — POWER SUPPLY (+) 2 — OUTPUT (+) 3 — COMMON</p> <p>TIGHTENING TORQUE 3.7kgf-m (27ft-lbs)</p>
Pressure range	50kgf/cm <sup>2</sup> (710psi)											
Max. allowable press.	525kgf/cm <sup>2</sup> (7470psi)											
Operating source voltage	5±0.5V DC											
Load resistance	10KΩ MIN											
Insulation resistance	More than 100MΩ											
SV-11  Solenoid valve  YN35V00010F1  Extra breaker  YN07-30001~ YQ07-03501~ LQ08-04501~ LL08-03001~ LC06-05501~ YC06-02501~	<table border="1"> <tr> <td>Rated voltage</td> <td>DC 24V</td> </tr> <tr> <td>Working pressure</td> <td>50kgf / cm<sup>2</sup></td> </tr> <tr> <td>Max. flowrate</td> <td>16 ℓ / min</td> </tr> </table>	Rated voltage	DC 24V	Working pressure	50kgf / cm <sup>2</sup>	Max. flowrate	16 ℓ / min	 <p>HYDRAULIC SYMBOL</p> <p>3-PF1/4 (O RING SEAL)</p> <p>SUMITOMO DENSO CONNECTOR HW090 2PM HOUSING M (6181-0070) RETAINER (6918-0323) TERMINAL M (1500-0105) RUBBER PLUG (7165-0119)</p> <p>FURUKAWA ER500 AWG18 (TO BE SET PROTECTION TUBE)</p> <p>VIEW A</p> <p>GROUND (-) COLOR OF: BLACK POWER (+) COLOR OF: RED</p>				
Rated voltage	DC 24V											
Working pressure	50kgf / cm <sup>2</sup>											
Max. flowrate	16 ℓ / min											

1.2 PIPING

NOTE :

1. Apply oil for refrigerant R134a to the O rings at all air-conditioner hose fittings.
2. Refrigerant volume :  $1050 \pm 100\text{g}$
3. T : Tightening torque





Fig. 2(1/2) Installing air conditioner and heater

## 4.2 REMOVAL AND INSTALLATION OF THE UNIT

### (1) Removing the blower unit

- 1) Remove the connectors connected to the inner/outer air select motor actuator, the blower motor and the blower controller. Also remove the harness from the blower casing.




Fig. 14

- 2) Draw out the inner air filter from the intake casing. Remove four cross-recessed screws T5×14 (T1) from the top of the intake casing, using a screwdriver. Then remove the intake casing.
- 3) Remove three cross-recessed screws T5×14 (T1) fastening the blower casing with the unit casing. Then separate the blower unit from the air-conditioner unit.




Fig. 15

### (2) Replacing the blower motor

- 1) Disconnect the cooling hose that is connected between the blower motor and the blower casing.
- 2) Remove three cross-recessed screws N5×16 (W) fixed from the bottom of the blower unit casing. Then draw out the blower motor.

- Do not separate the fan from the blower motor.

- 3) Assembly is the reverse order of disassembly.

### (3) Replacing the blower controller

- 1) Remove two cross-recessed screws T4×14 (T1) fixed from the bottom of the blower unit casing and draw out the blower controller.
- 2) Install a new blower controller in the reverse order of removal.




Fig. 16

- Do not disassemble the blower controller in any circumstances.

## 6.2 INSPECTING FUNCTIONAL PARTS

### (1) Relay (24-4PE)

- 1) Coil resistance :  $320\Omega$  (across 1 and 2)
- 2) Operating voltage : DC20~30V
- 3) The coil of the relay has polarity : Care is needed.
- 4) Turn on and off the power to the blower motor by controlling the controller.
- 5) Check: Check conductance across 3 and 4 in the following condition :  
 Apply 20~30V across terminals 1 and 2 : continue  
 No voltage applied across terminals 1 and 2 : not continue




Fig. 33 Relay

### (2) Inner air sensor (C44)

Resistance across terminals :

at  $0^{\circ}\text{C}$  ( $32^{\circ}\text{F}$ ) :  $7.2\text{K}\Omega$

at  $25^{\circ}\text{C}$  ( $77^{\circ}\text{F}$ ) :  $2.2\text{K}\Omega$

The inner air temperature sensor is installed to the sensor bracket under the operator's seat. The temperature in the cab is sensed by the thermistor. Changes in the resistance according to temperature variations are transmitted to the controller.




Fig. 34 Inner air temperature sensor

### (3) Blower controller

The blower controller changes output voltages for the motor according to signals emitted by the controller.




Fig. 35 Blower controller

### (4) Motor actuator

1) Operating voltage : DC20~30V

2) Operating temperature range :  
 $-30^{\circ}\text{C}$  ( $-22^{\circ}\text{F}$ ) to  $+75^{\circ}\text{C}$  ( $167^{\circ}\text{F}$ )

The motor is controlled by signals (pulses) put out by the controller.





Fig. 36 Motor actuator


(21) Upper frame LC33- I -40

Upper frame assy .....	FIG 010-01
Upper frame assy .....	FIG 010-50




(4) Front idler LC34- I -18

Crawler idler assy .....	FIG 298-01
Idler assy .....	FIG 306-01
Idler adjust assy .....	FIG 314-01




1.3

下部旋回体  
UNDER CARRIAGE




(1) Crawler LC34- I -1

Shoe assy .....	FIG 338-01
Shoe assy (Long crawler) .....	FIG 340-01




(5) Sprocket LC34- I -27

Low group .....	FIG 278-01
Low group (Long crawler) .....	FIG 280-01




(2) Upper roller LC34- I -5

Upper roller assy .....	FIG 330-01
-------------------------	------------




(6) Travel motor LC34- I -30

Low hyd lines .....	FIG 354-01
Low hyd lines (Long crawler) .....	FIG 356-01




(3) Lower roller LC34- I -11

Track roller assy .....	FIG 326-01
-------------------------	------------



(7) Swing bearing LC34- I -32

Slewing ring assy .....	FIG 282-01
-------------------------	------------



# 1. CYLINDER

## 1.1 PREPARATION BEFORE DISASSEMBLY

Before assembly, secure a dust free workshop and necessary equipment and facilities.

### 1.1.1 WORKING SPACE

The work space must satisfy the following requirements.

(1) Enough space is obtained.

Before disassembling the hydraulic cylinder, the piston rod must be pulled out of the cylinder tube. First, the essential condition is to have enough space, and in addition the facility required for disassembly, cleaning, measuring, etc. is to be placed in a crosswise direction, to secure enough space to carry out the works.

(2) Optimum work environment

The hydraulic cylinder is manufactured in precision, using rubber and plastic products for seal, packing, etc. Check that it is free from dust, dirt, etc. especially sand, chip, weld slug, etc. which will adhere to cylinder.

If the cylinder tube, piston, etc. are installed without removing hard particles, the tube inner surface and rod surface may be damaged, resulting in making the operation impossible.

Particles may flaw the seal material and rod seal of piston, and causes the oil leak. So the work space is to be located at a distance from the grinding work shop to keep the space clean.

### 1.1.2 FACILITY

The following facilities are required for disassembly.

(1) Hoist or crane

Prepare the hoist or crane which has a capacity to carry the cylinder assy, and moves horizontally and linearly slinging the object to push/pull the piston rod in/out of the tube.

(2) Work bench

Prepare the work bench of which the length is equal to the retracted cylinder length or larger, and which has the strength and stiffness to withstand the reaction force against the tightening torque of cylinder head, piston nut, etc. The width is to be wider because a vise is attached on this work bench to carry out the disassembly and assembly.

(3) Support

Prepare the support to protect bushing, seal, etc. from damaging due to the rod weight when pulling the piston rod out of the installing pin side.

(4) Hydraulic pressure source

This pressure is used to disassemble and assemble the cylinder head, piston nut, etc. and also when carrying out the leak test after assembly.

(5) Compressed air source

This compressed air is used to remove oil on the surface of cylinder and to dry it after cleaning.

(6) Wash bath, Wash oil, detergent


(7) Oil pan, oil sump


Prepare an oil pan and an oil sump to pour the oil in the cylinder and to preserve the oil spilled on the bench and the waste oil.

(8) Others

Prepare a hose to drain oil, supporter, waste cloth, and saw dust to clean the spilled oil on the floor.

- 3) Turn up socket bolt (12). Match the bolt holes of the rod cover flange to the tapped holes in the cylinder assy, and screw in socket bolts (12) one by one. Tighten the bolts to a specified torque, taking care so the bolts may not be tightened unevenly.


 :14mm,  
 Tightening torque :  
 37.4kgf·m (270ft·lbs)

-  Take care so as not to damage the rod surface by accidentally slip a wrench. Covering the rod surface with rag is recommended to prevent damage to it. For the tightening torques, refer to "(II-1-16)".

## 1.6 INSPECTION AFTER ASSEMBLY

### (1) No-load functional test


Place the cylinder level at no load, operate the piston rod 5 to 6 strokes by the directional valve and make certain that it operates without fault.

- 
  - Do not raise the hydraulic pressure above the maximum pressure of  $385\text{kg/cm}^2$  (5470psi) for the cylinder of the machine.
  - Grease coated on the O rings and the seals of the rod cover may ooze out. Wipe it off and retest the rod cover in such a case.

### (2) Leak test (See Fig. 1-35)

- 1) Apply a test pressure to the retracting and extending sides of the cylinder for three minutes independently, and check that the rod section and the welds have external leaks and permanent deformation. For an internal leak test, connect the cylinder with a test unit.

- 2) After completing the test, apply a plug to each port and store it (Fig. 1-36).

-  For storage, place the cylinder on wooden V-blocks and bring the cylinder to the most retracted condition.




Fig. 1-33 Tightening socket bolts (12)




Fig. 1-34 External leak test




Fig. 1-35 Internal leak test





Fig. 1-36 How to store the cylinder

- (4) Remove guard (10)
- 1) Remove four sems bolts (36) M12×30.
  - 2) Remove guard (10).
-  : 19mm  
Weight : 11kg (24 lbs)





Fig. 4-5 Removeing guard (10)

- (5) Remove stay (29)
- 1) Remove two sems bolts (35) M12×25.
  - 2) Remove two sems bolts (37) M12×35.
  - 3) Remove stay (29)
-  : 19mm  
Weight : 11kg (24 lbs)






Fig. 4-6 Removing stay (29)

- (6) Remove cover assy (7), guard (8)
- 1) Remove one of the sems bolts (35) M12×25 that fasten the guard (8) with the fuel tank.
  - 2) Unlock the lock of cover assy (7) and open the cover.
  - 3) Disconnect three connectors for the right-hand deck light and for the battery relays.
  - 4) Remove four sems bolts (37) M12×35.
-  : 19mm
- 5) Remove cover assy (7) and guard (8) together as a set.
  - 6) Remove two sems bolts (35) M12×25 that fasten guard (8) with cover assy (7). Then separate guard (8) from cover assy (7).
-  : 19mm  
Weight : Cover assy (7) : 33kg (72 lbs)  
Guard (8) : 7kg (15 lbs)





Fig. 4-7 Removing cover assy (7), guard (8)

- (7) Remove panel assy (3)
- 1) Unlock the lock of panel assy (3) and open.
  - 2) Remove four nuts (41) M10.
  - 3) Remove panel assy (3).
-  : 17mm  
Weight : 17kg (37 lbs)





Fig. 4-8 Removing panel assy (3)


(6) Installing the pump  
Lift the pump with bracket (1). Place coupling (5) in the groove of element (5-1) so as to receive aluminum insert (5-3).

(7) Coat twelve nut (3) with Locktite #262 and put them in place.


 : 17mm,

Tightening torque : 4.0kgf·m (29ft·lbs)

(8) Fasten hoses (5), (6) on the discharge side with half clamp (10) and eight socket bolts (16) M10×35. (Refer to Fig.8-3.)

 : 8mm


(9) Install suction hose (7) with four socket bolts M12×30. (See Fig. 8-3.)

 : 10mm,

Tightening torque : 8.5kgf·m (61ft·lbs)

(10) Install the hydraulic piping by referring to "HYDRAULIC SYSTEM".


(11) Installing the hose

Port	 Tool	Tightening torque kgf·m (ft·lbs)
Cap nut Pn1,2	19	3.0 (22)
Cap nut Dr3	19,22	5.0 (36)
Cap nut Psv1,2	19	3.0 (22)
Cap nut A3	19,22	3.0 (22)
Cap nut B3	36	12 (87)

(12) Installing pressure sensor connector and proportional valve connector.

(13) Remove suction stopper


(14) Install suction strainer

 When the pump is replaced, replenish more than 1ℓ (0.26gal) of hydraulic oil from the drain port (Dr).

(15) Start engine and check it for oil leakage and noise.

(16) Bleed air in pump

Bleed air by loosening the oil filling port Dr.

 Run the engine at low idling speed.

(17) Check hydraulic oil level.

(18) Attach drain down pipe under engine muffler.

(19) Install guards

(See Fig. 8-2) (See Fig. 4-13)

Tightening position	Tool	Tightening torque kgf·m (ft·lbs)
Sems bolt (35), (36)	19	8.5 (61)

T=Tightening torque





Fig. 8-7 Installing hydraulic pump




Fig. 8-8 Bleed air port (Dr) in pump


## 16. CONTROL VALVE

### 16.1 PREPARATION FOR REMOVAL

- (1) Remove guard (12), (23) (Refer to 4. GUARD)
- (2) Discharge inner pressure from the hydraulic circuit system.  
(Refer to 8. HYDRAULIC PUMP)
- (3) Install the suction stopper to the hydraulic tank.
- (4) Remove the hoses located at the below ports :

**⚠** Mark each hose with a port name before removing it.

### 16.2 REMOVAL

- (1) Remove four capscrews (3) M12×35.  
 : 19mm
- (2) Remove the control valve (A) with brackets (1), (2)  
 Weight : Approx. 175kg (386 lbs)





Fig. 16-1 Removing control valve

### 16.3 INSTALLATION

- (1) Installing is done in the reverse order of remove.  
 : 19mm, Apply locktite #262  
 Tightening torque : 12.3kgf·m(89ft·lbs)
- (2) Check for oil leakage and operation.

Functions	Ports	Ports on upper sides (on machine)	Ports	Functions
Opt.2 port	PA02	LEFT SIDE ← PA02 PA01 → RIGHT SIDE	PA01	Opt.1 port
Opt.2 relief vlv	—		—	Opt.1 relief valve
Arm variable recirculation	PiS	Pis	PCb	P1 bypass cut
Arm in	PAa	PAa	—	Boom (H) relief valve
Arm (H) relief valve	—	PB1	PAb	Boom up
Boom confluent	PB1	PAS	Drc	Boom lock drain
Swing left	PAS	PAL	PLC1	Boom down lock release
Travel left forward	PAL		PAc	Bucket dump
			—	Bucket (R) relief valve
			PAr	Travel right forward
			—	Main relief valve
		Ports on rear sides (on machine)		
		LEFT SIDE ←		
Swing motor boost circuit	T2	T2	P1	P1 pump
Tank return	T	T	P2	P2 pump



1.2 REGULATOR  
1.2.1 STRUCTURAL EXPLODED VIEW

Applicable machines :  
LC06-05501~05644  
YC06-02501~02604





Table 1-4

TIGHTENING TORQUE kgf·m (ft·lbs)	No.	NAME	Q'TY	TIGHTENING TORQUE kgf·m (ft·lbs)	No.	NAME	Q'TY
3.0 (22)	412	SOCKET BOLT: M8×50	2		614	FULCRUM PLUG	1
3.0 (22)	413	SOCKET BOLT: M8×70	2		615	ADJUST PLUG	1
	418	SOCKET BOLT: M5×12	2		621	COMPENSATING PISTON	1
	436	SOCKET BOLT: M6×50	5		622	PISTON CASE	1
1.2 (8.7)	438	SOCKET BOLT: M6×20	4		623	COMPENSATING ROD	1
1.2 (8.7)	439	SOCKET BOLT: M6×40	4		624	SPRING SEAT	1
3.7 (27)	466	VP PLUG: PF1/4	3		625	OUTER SPRING	1
7.5 (54)	467	PLUG ; PF3/8×M8	1		626	INNER SPRING	1
0.9 (6.5)	496	PLUG	18		627	ADJUST STEM (C)	1
	541	SEAT	2		628	ADJUST SCREW (C)	1
	543	STOPPER 1	2		629	COVER (C)	1
	545	STEEL BALL	2	16 (120)	630	LOCK NUT: M30	1
	601	CASING	1		631	SLEEVE (For PF)	1
	611	FEEDBACK LEVER	1		641	PILOT COVER	1
	612	LEVER (1)	1		642	ROD	1
	613	LEVER (2)	1		643	PILOT PISTON	1
					644	SPRING SEAT (Q)	1
					645	ADJUST STEM (Q)	1
					646	PILOT SPRING	1
					651	SLEEVE	1
					652	SPOOL	1
					653	SPRING SEAT	1
					654	RETURN SPRING	1
					655	SET SPRING	1
					656	PORT PLATE	1
					708	O RING : 1B G75	1
					722	O RING : 1B P6	2
					724	O RING : 1B P8	12
					725	O RING : 1B P10	1
					727	O RING : 1B P14	1
					728	O RING : 1B P18	1
					730	O RING : 1B P22	1
					732	O RING : 1B P16	2
					733	O RING : 1B P20	2
					734	O RING : 1B P25	1
					753	O RING : 1B G9	1
					755	O RING : 1B P11	6
					756	O RING : 1B P26	2
					763	O RING : 1B G35	1
1.6 (12)	801	NUT : M8	3		814	SNAP RING	1
					836	SNAP RING	1
					858	SNAP RING	2
					874	PIN ; Ø4×11.7L	1
					875	PIN ; Ø4×8L	4
					887	PIN	1
					897	PIN ; Ø4×19L	1
					898	PIN ; Ø6.5×9L	1
					924	SOCKET BOLT: M8×20	1
					925	ADJUST SCREW (Q1)	1
					079	SOLENOID PROPORTIONAL REDUCING VALVE	1

The codes in a rectangle represent adjust screws.  
Do not tamper with the adjust screws as much as possible.

Fig. 1-31 Structural exploded view of regulator

- 8) Remove seal cover (F)  
Remove socket bolt (406) and seal cover F (261).

 : 5mm

- The seal cover (F) may be drawn out with ease if it is taken out by tightening bolts in the tapped holes (M6 tap) of the seal cover (F).
- An oil seal is fitted to seal cover (F). Therefore, use care so as not to score the oil seal.




Fig. 1-6 Removing seal cover F (261)

- 9) Separating the swash plate support and the pump casing

Knock lightly on the mounting flange of swash plate support (251) from the pump casing (271) side and separate the swash plate support from the pump casing.




Fig. 1-7 Separating the swash plate (251) support and the pump casing (271)

- 10) Remove shoe and swash plate

Draw out shoe plate (211) and swash plate (212) from pump casing (271).




Fig. 1-8 Removing shoe (211) and swash plate (212)

- 11) Drawing out the shaft

Tap lightly the shaft end (111, 113) by means of a plastic hammer and draw out the shaft from the swash plate support.




Fig. 1-9 Drawing out the shaft (111), (113)




Fig. 1-27 Removing adjust plug (614) [2]

- 10) Remove lever  
 Remove lever 2 (613).  
 Do not draw out pin (875).

- The work is eased if tweezers is used.




Fig. 1-28 Removing lever (613)

- 11) Remove feedback lever  
 Draw out pin (874) and remove feedback lever (611).

- Push out pin (874) [pin dia :  $\varnothing 4\text{mm}$  (0.157in)] from above with a slender steel rod so as not to interfere with lever (612).




Fig. 1-29 Removing feedback lever (611) [1]





Fig. 1-30 Removing feedback lever (611) [2]

- (5) Disassembling the boom spool
- 1) Loosen socket bolts (273) and remove spring cover (201) for boom and O ring (261).

 : 6mm





Fig. 2-14 Removing spring cover (201)

- 2) Draw out the assy of boom spool (301), spring seat (331), springs (321), (322), stopper (336) and bolt (333) from casing B (102).

 When drawing out the spool assy, take care so as not to score casing B (102).

- 3) Fix the boom spool assy with vise via a protective plate (aluminum plate, etc.) and remove bolt (333). Then separate spring seat (331), springs (321), (322) and stopper (336) from boom spool (301).

302(321,323,331,333,336) 102





Fig. 2-15 Drawing out boom spool assy

- 4) Do not disassemble arm spool (301) further unless there is special reason. In case it must be disassembled for indispensable reason, do as follows :

- a) Place the middle of boom spool (301) in a vise fitted with mouth pieces and remove plug 1 (B352) and plug 2 (B353).

 : 24mm

- b) Take out plunger 1 (B315), plunger 2 (B316), plunger 3 (B317), spring B1 (B320), spring B2 (B330) and spring B3 (B340) from boom spool (301).





Fig. 2-16 Disassembling boom spool assy

 Take care so as not to distort boom spool (301) by overtightening it in the vise.





Fig. 2-17 Disassembling boom spool (301)

### 2.3.1 ASSEMBLING VALVES AND SPOOLS

#### (1) Assembling check valve

- 1) Load check valve, conflux check valve, etc.

Fit poppet (511) and spring (521), put O ring (164) in plug (551) and fasten it to the specified torque. (8 places)


 : 12mm,

Tightening torque :

22~26kgf·m (160~190ft·lbs)


#### 2) Lock valve

Fix poppet (514) and spring (524), put O ring (164) in plug (556) and fasten it to the specified torque. (2 places)

 : 12mm,


Tightening torque :

22~26kgf·m (160~190ft·lbs)

 Plugs 1) and 2) look similar; use care of the parts combination and assembling position.


#### 3) Travel straight and main relief sections

Fit poppets (512), (515) and spring (522), put O ring (562) in plug (552) and fasten it to the specified torque. [(512) four places and (515) one place limited]

 : 10mm,


Tightening torque :

12~16kgf·m (87~120ft·lbs)

 Use care so special poppet (515) for travel straight is fixed in a correct position.


#### (2) Installing relief valve

- 1) Tighten main relief valve (601) and port relief valves (602), (603) to the specified torques in correct positions.

 : 32mm,

Tightening torque :


7~8kgf·m (51~58ft·lbs)

 ● Overload relief valves (602) and (603) are the same in outer appearance. Therefore, reassemble them in correct positions by looking at tags attached at disassembly.

● Regarding the reassembly of the relief valve, refer to the (14), (15) on page II-2-14.


#### (3) Assembling arm conflux spool

- 1) Put a protective plate (aluminum plate, etc.) in a vise. Hold the middle of arm conflux spool (308) in the vise, set spring seat (332), springs (325), (326) and stopper (337) and tighten bolts (334) to the specified torque.

 : 10mm,


Tightening torque :

1.6~1.8kgf·m (12~13ft·lbs)


 ● Before tightening bolts (334), coat them with Locktite #262.

● Be careful so as not to distort arm conflux spool (308) by overtightening it in the vise.

- 2) Fix the arm conflux spool assy in par. 1) into casing B (102).

 Fix the arm conflux spool assy into casing B (102) slowly and carefully and never force it in.

- 3) Attach spring cover (204) with O ring (262) to the spring side of the arm conflux spool assy. Then fasten socket bolts (273) to the specified torque.

 : 6mm,

Tightening torque :

2.5~3.5kgf·m (18~25ft·lbs)

(2) Exploded view





Fig. 3-2 Pilot valve (for ATT)

7. Assembly


- Clean and degrease parts before assembly. In particular, clean the body with a nylon brush. Foreign matter intruded into the valve causes functional faults to occur.
- Prepare new seals (O rings and U packings) and coat the surface with hydraulic oil or a thin film of grease.

8. Assembling the shuttle. (See Fig.4-7.)

- (1) Put two balls (36) into body (5).
- (2) Coat the screwed part of seat (2) with Locktite#262 and fit two of them to body (5).


 : 5mm, Tightening torque :  $1.5 \pm 0.1 \text{ kgf}\cdot\text{m} (11 \pm 0.7 \text{ ft}\cdot\text{lbs})$

- (3) Set O rings (42) to socket plugs (25) and fasten two plugs to body (5).

 : 6mm, Tightening torque :  $2.5 \pm 0.2 \text{ kgf}\cdot\text{m} (18 \pm 1.4 \text{ ft}\cdot\text{lbs})$

9. Assembling the reducing valve spool assy (See Fig. 4-5.)


- (1) Fix spool (4) in a vise. (Put protective plates against the mouth.) Set washer (29), shims (10), (11), spring (8) and sleeve (18), in that order, and tighten them with four socket flange bolts (27).

 : 3mm, Tightening torque :  $0.5 \pm 0.1 \text{ kgf}\cdot\text{m} (3.6 \pm 0.7 \text{ ft}\cdot\text{lbs})$

- On that occasion, pair parts with the disassembled parts as sets, before performing assembly work. Incorrect pairing may change the secondary pressure.

10. Assembling the reducing valve (See Fig.4-8.)

- (1) Fit four O rings (38), (40), parallel pins (32) and springs (7) to body (5).
- (2) Fit four reducing valve spool assemblies and stoppers (6). On that occasion, use care as stopper (6) has a direction in which it should be installed; Place it so the concave surface of it faces down (reducing valve spool side).
- (3) Set O rings (41) to socket plugs (24). Fasten three plugs to body (5).

 : 5mm, Tightening torque :  $1 \pm 0.1 \text{ kgf}\cdot\text{m} (7.2 \pm 0.7 \text{ ft}\cdot\text{lbs})$

11. Assembling the damper (See Fig.4-3.)

- (1) Fit four U packings (37) to cover (15).
  - On that occasion, place the cover so the lip of the U packing faces down (damper chamber side).

- (2) Insert four piston assemblies (44) into cover (15).

- In that case, make sure that each piston is set in the same hole where it was before disassembly.

The performances of the piston are not affected at all if it is placed in any direction on the circumference.

- (3) Fit O ring (39) to guide (17). Install four guides to cover (15).

- Fix the guide in the same hole where it was set before disassembly.




Fig. 4-7 Assembling the shuttle







Fig. 4-8 Assembling the reducing valve

### 5.3 DISASSEMBLY AND ASSEMBLY OF SWING REDUCTION UNIT

#### 5.3.1 TOOLS

Code	Tool name	Remarks
A	Jig (for press fitting bearing )	Material : SS41 
B	Snap ring plier	For shaft
C	Oil seal fitting jig	Material : SS41 
D	Torque wrench	Class 10kgf·m (72ft·lbs), 30kgf·m (220ft·lbs)
E	Plastic hammer (Wooden hammer)	
F	Press	Class 50ton (110000 lbs )
H	Flat screwdriver	
I	Metal bar	3 pcs. 
J	General tools	Allen wrench and steel rod
K	Screw lock compound	Loctite #242
	Sealing compound	Loctite #515

#### 5.3.2 DISASSEMBLY

The numbers in parentheses correspond to the ones in construction drawings (Fig. 5-2).

##### (1) Preparation

- 1) Before disassembly, clean the outside of the reduction unit thoroughly and check for no damage and scoring.
- 2) Drain gear oil from the reduction unit.
- 3) Disconnect the drain hose.
- 4) Matching Mark  
To facilitate the reassembly of the unit, put matching mark on the joining parts of the housing before disassembly.

## 5.5 TROUBLESHOOTING

### 5.5.1 SWING MOTOR

#### (1) Hydraulic motor does not rotate.

Trouble	Cause	Remedy
Pressure does not rise.	<ol style="list-style-type: none"> <li>1. Relief valve pressure in circuit is not adjusted correctly.</li> <li>2. Malfunction of relief valve.               <ol style="list-style-type: none"> <li>2-1. Sticking plunger.</li> <li>2-2. Orifice on plunger is clogged.</li> </ol> </li> <li>3. Plunger seat is faulty.</li> <li>4. Swing shockless valve seat is faulty.</li> </ol>	<ol style="list-style-type: none"> <li>1. Set to correct value.</li> <li>2.               <ol style="list-style-type: none"> <li>2-1. Correct the stuck areas or replace the plunger.</li> <li>2-2. Disassemble and clean.</li> </ol> </li> <li>3. Check the seat surface and replace the plunger if scored.</li> <li>4. Replace the swing shockless valve cartridge or block.</li> </ol>
Pressure rises.	<ol style="list-style-type: none"> <li>1. Overload.</li> <li>2. Moving parts are seized.</li> <li>3. Brake release pressure is not working on the motor</li> <li>4. Brake piston is stuck.</li> <li>5. Friction plate is seized.</li> </ol>	<ol style="list-style-type: none"> <li>1. Lighten overload.</li> <li>2. Inspect and repair piston, shoe and cylinder valve plate.</li> <li>3. Check circuit and correct it.</li> <li>4. Disassemble and check.</li> <li>5. Disassemble, check and repair. Replace one that is seized.</li> </ol>

#### (2) Rotating direction is opposite.

Trouble	Cause	Remedy
Rotating direction is opposite.	<ol style="list-style-type: none"> <li>1. Motor's assembling direction is reversed.</li> <li>2. Piping inlets and outlets are reversed.</li> </ol>	<ol style="list-style-type: none"> <li>1. Assemble correctly.</li> <li>2. Pipe correctly.</li> </ol>



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below




- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

## 4. LOWER ROLLER (TRACK ROLLER)

### 4.1 LOWER ROLLER ASSY

ROLLER	STD	LC64D00004F1	↓		
ASSY	LC	LC64D00004F2		↓	
ITEM	NAME		Q'TY		REMARKS
1	LOW ROLLER		14	16	LC64D00005F1
2	CAPSCREW		56	64	M22×105



2 Apply Locktite #262  
T=74.5kgf·m (540ft·lbs)

Fig. 4-1 Lower roller assy

### 4.2 REMOVAL

#### (1) Preparation for removal

- 1) Loosen the tension of the crawler, lift up the lower frame by the front attachment and stop the engine in that condition.
- 2) Place a safety block (wooden) at the front and back of the lower frame.




Fig. 4-2 Preparation for removal

#### (2) Removing track guide (See Fig. 4-3)

Remove capscrews (8) M24×60 and remove track guide (5).

: 36mm

Weight of track guide : Approx. 50kg (110 lbs)

#### (3) Remove lower roller

Remove capscrews (2) and remove lower roller (1).

: 32mm

Weight of lower roller : Approx. 57kg (126 lbs)




Fig. 4-3 Installing lower roller

### 4.3 INSTALLATION

#### (1) Installation of lower roller

Coat mounting capscrews (2) with Locktite #262 and fasten all four capscrews temporarily. Then tighten them to a specified torque.

: 32mm

Tightening torque : 74.5kgf·m (540ft·lbs)

#### (2) Installation of track guide

Capscrews (8) with Locktite #262 and fasten all four capscrews temporarily. Then tighten them to a specified torque.

: 36mm

Tightening torque : 95kgf·m (690ft·lbs)

#### (3) Adjusting tension of crawler.

Tighten grease nipple and fill it with grease.

: 19mm,

Tightening torque : 6kgf·m (43ft·lbs)

Table 4-1 Track guide part list

LOWER GROUP	SK330M	STD	LC01F0001F1	↓				
		HD	LC01F0001F2		↓			
	SK330LCM	STD	LC01F0003F1			↓		
		HD	LC01F0003F2				↓	
	SK330NLCM	STD	LC01F0002F1					↓
		HD	LC01F0002F2					
No.	NAME		Q' TY					
5	TRACK GUIDE : LC63DE00002F1		2	6	2	6	2	6
8	CAPSCREW; M24×60		8	24	8	24	8	24
9	CAPSCREW; M24×40		16	—	16	—	16	—
12	WASHER		16	—	16	—	16	—

## 6. SPROCKET

### 6.1 REMOVING

#### (1) Preparation for removal

Remove crawler referring to Section 2. "Crawler", lift up crawler frame with attachment, and put it on square timbers to float and stabilize.





Fig. 6-1 Preparation for removal

#### (2) Removing sprocket

Loosen twenty six capscrews (3) M20×55, for the attaching of the sprocket by means of a socket and remove the sprocket (1).

Weight of sprocket : 77kg (170 lbs)

 : 30mm




Fig. 6-2 Removing sprocket

### 6.2 INSTALLING

#### (1) Check before installing


Check the mating portion of the travel reduction unit and the sprocket, eliminate burrs and contamination thoroughly and install the sprocket.

#### (2) Securing sprocket temporarily

Coat the sprocket attaching capscrews (3) with Locktite #262 and fasten the sprocket temporarily.

#### (3) Securing sprocket completely

Remove the wooden blocks under the truck frame, bring the machine down on the ground and tighten the sprocket.

 : 30mm,

Tightening torque : 55kgf·m (400ft·lbs)





Fig. 6-3 Securing sprocket temporarily

2) Disassembling the motor

- ① Place the motor shaft level and remove socket bolts (32) except two vertically diagonal ones.

 : 14mm

- ② Loosen two remaining bolts slowly at the same time.
- ③ Remove rear cover (2) and spring (29), taking care so cylinder block (3) does not come off with rear cover (2).



In that case, do not drop valve plate (8), brake spring (29) or O ring (36).  
If the cylinder block (3) comes to stick to the rear cover (2), use a stick of 5 ~ 8mm (0.2 ~ 0.3in) with a rounded point and, through the rear cover (2) oil hole, push on the cylinder block (3) (being careful not to damage the area) and pull off the rear cover (2).

- ④ Remove valve plate (8) so cylinder block (3) does come off together.



Put a matching mark on valve plate (8) and rear cover (2) so they are reassembled correctly. (so the face and the back are not reversed.)

- ⑤ Push in cylinder block (3), using removed socket bolt (32) in the holding-down metal so the cylinder block is not damaged, till the inner race of rear bearing (31) sticks out.
- ⑥ Remove the inner race of rear bearing (31) by putting the gear (bearing) puller in the inner race.




Fig.1-4 Removing the rear cover





Fig.1-5 Removing the rear bearing

## 1.7 REDUCTION UNIT DISASSEMBLY

### 1.7.1 TOOLS

Before removal and installation, prepare tools, jigs and measuring instruments.

No.	Tools	Application
1	Torque wrench	0~50kgf.m
2	Allen wrench	Opposing flats 8mm, 14mm
3	Stand	
4	Micro depth meter	0~15mm
5	Caliper	0~150mm
6	Eye bolt	M10、 M18 3pcs. each
7	Pin	Spring pin $\varnothing 3.5 \times 75$ , $\varnothing 7 \times 55$
8	Press machine	It is used to insert the angular bearing and fix the lock washer. Capacity 3 tons (6610 lbs)
9	Others	Cleaning oil, Detergent, Gear oil, Grease, Loctite#242, #515, Seal tape, rag and others

### 1.7.2 DISASSEMBLY

#### (1) Preparation before removal

- 1) The travel unit removed from the machine has dust and mud. Wash them with cleaning oil.
- 2) Loosen drain or oil filling plug (26) and drain the oil out of the reduction unit.



When oil is hot, pressure is built up inside. Take care as the oil gushes out in some cases.

#### 3) Putting matching marks

Put a matching mark on the outside of each matching surface so it may be installed where it was.


- The numbers in the parentheses after part names correspond to those in the assembly drawing on page II-2.

# 1. OUTLINE

Troubleshooting provides process locating for the cause of trouble in the order that trouble occurred. This manual describes how to solve the specific phenomenon systematically as early as possible. For troubleshooting concerning the inside of equipment, refer to troubleshooting for each manual of equipment.

## 1.1 JUDGMENT OF ACTUAL THING AT SITE

(1) Get to the site as quickly as possible.  
Verify model, serial number, situation of trouble and field, and notify person of arrival time.




YR-B76

Attending the field to verify actual thing.

(2) Verify background of trouble occurred

- 1) Model name and serial number
- 2) Kind of attachment  
Check that the combination of attachment is proper or that the operating method is not unreasonable.
- 3) Operating time by hour-meter
- 4) History of trouble occurred and additional works.
- 5) Recurrence of past trouble, or problems on the additional works.




YR-B76

Verifying background of trouble occurred.

(3) How to diagnose trouble

- 1) Verify defective part
- 2) Make the condition of trouble again
- 3) Where defective parts can not be verified, surmise causes systematically.
- 4) Verify reasons for surmise
- 5) Report methods, procedure, and period for repairing to user.



YT-B87

Confirm the symptoms of the trouble.

(4) Explanation of the cause of trouble


- 1) Explain the cause of trouble to clients. For example, oil leak through piston is caused by flaws on the piston rod. And the method of using the machines should be explained so that the same kind of trouble does not reoccur.
- 2) Treatment of damaged parts  
The damaged parts to be claimed and returned are evidence so they should be handled with care. Protect them from entry of water, soils, etc. into port of hydraulic unit, etc. and return them. And also use care not to flaw and damage those surfaces.




YR-B76

Diagnosing fail by means troubleshooting.

(1)-2




(4)-3





(2)-4



(13)

Swing P/B can not be held on a slope.

Are the voltages between 2P connectors for swing parking solenoid 24V?

YES

To hydraulic troubleshooting.

NO (Diagnosis No.5)

Is the display of "COMP" in service diagnosis screen "ON" ?

YES

Is the display of "MEAS" in service diagnosis screen "ON" ?

YES

Replace mechatro controller.

NO

NO

Replace swing parking SOL.

(Diagnosis No.9,10,12)

NG

Are the low pressure sensors for swing, arm in, arm out and boom raise actions normal?

Neutral: 0.4~0.5V  
Full lever: more than 4.5V

YES

Inspect harness between mechatro controller and SOL

Replace mechatro controller.

NO

Replace faulty sensor.

NG

(14)

Swing fine operation can not be performed.

(Service diagnosis No.16)

Is the P2 negative control pressure reading during engine high idle neutral operation 30 to 40kgf/cm<sup>2</sup> (430 to 570psi) in both service diagnosis and actual measurements?

YES

NO

Is the service diagnosis reading and actual values nearly the same under the conditions specified on the left?

YES

To (※1).

NO

Replace P2 negative control sensor.

NG

(Diagnosis No.25)

Check electric wiring.

Is the current reading of P2 pump proportional valve normal or approx. 770mA or over in high idle neutral condition?

YES

NO

Is the electric wiring for the P2 pump proportional valve normal?

NO

Correct electric wiring.

YES

Replace P2 pump proportional valve.

NG

(Diagnosis No.19, No.16)

Replace mechatro controller.

Service diagnosis with the key ON indicates :  
Back pressure sensor voltage: 0.4~0.5V  
P2 negative control sensor: 0.4~0.5V

YES

NO

Replace faulty sensor.

NG

Check electric wiring.

(※1)

In the action normal if connector of P2 bypass cut proportional valve is pulled out?

NO

To hydraulic troubleshooting.

YES (Diagnosis No.9,10,11,12,13)

Are all low pressure sensor readings (boom, arm, bucket, swing, travel and OPT) 0.4 to 0.5V at neutral?

YES

NO

Replace faulty sensor.

NG

Inspect electric wiring of faulty sensor or pilot valve.

Is the electric wiring to P2 bypass cut proportional valve all right?

YES

NO

Correct electric wiring.

Replace proportional valve.

NG

Replace mechatro controller.

# 6D1

## diesel engine

# Shop Manual

(for industrial use)

### FOREWORD

This Shop Manual is published for the information and guidance of personnel responsible for maintenance of Mitsubishi 6D1 series diesel engine, and includes procedures for adjustment and maintenance services.

We earnestly look forward to seeing that this manual is made full use of in order to perform correct service with no wastage.

For more details, please consult your nearest authorized Mitsubishi dealer or distributor.

Kindly note that the specifications and maintenance service figures are subject to change without prior notice in line with improvement which will be effected from time to time in the future.

#### Applicable models

6D16-TLE1	-----	ASIA, OCEANIA
6D16-TLUA	-----	EU
6D16-TLEB	-----	KAI

### GROUP INDEX

#### HOW TO READ THIS MANUAL


GENERAL .....	<b>00</b>
ENGINE .....	<b>11</b>
LUBRICATION .....	<b>12</b>
FUEL AND ENGINE CONTROL ...	<b>13</b>
COOLING .....	<b>14</b>
INTAKE AND EXHAUST .....	<b>15</b>
ELECTRICAL SYSTEM .....	<b>54</b>

# PRECAUTIONS FOR MAINTENANCE OPERATION

In order to determine the condition of the vehicle adequately, attend the vehicle beforehand to find and keep record of the accumulated mileage, operating condition, what the customer's demand is, and other information that may be necessary. Prepare the steps to be taken and perform efficient and wasteless maintenance procedure.



Determine where the fault exists and check for the cause to see whether removal or disassembly of the part is necessary. Then follow the procedure specified by this manual.




Perform maintenance work at a level area.  
Prepare the following.

- Prepare general and special tools necessary for the maintenance work.

**WARNING** 


**Do not attempt to use tools other than special tools where use of special tools is specified in this manual. This will avoid injury or damage.**



Pay special attention to safety when removing or installing heavy items such as engines, transmissions.

When lifting up heavy items using cables, pay special attention to the following points:

- Check the mass of the item to be lifted and use a cable capable of lifting that mass.




- If you do not have the specified lifting hanger, secure the item using cable taking the point-of-balance of the item into consideration.

- You must work in a position where you will not be injured even if the cable comes undone and the lifted item falls.

## Cylinder Head and Crankcase

<Engines with wet type cylinder liners: 6D14, 14-T, 15-T>




- 1 Connecting plate
- 2 Glow plug
- 3 Cylinder liner
- 4 O-ring
- 5 Crankcase
- 6 Water jacket
- 7 Piston
- 8 Injection nozzle
- 9 Cylinder head

A: Cylinder liner size mark: A, B, C

- The cylinder liners **3** are a removable wet type liners. They are press-fitted into the top of the crankcase **5** and the bottom of the water jacket **6**.
- The O-rings **4** are provided to prevent the ingress of coolant.
- The cylinder liners **3** and pistons **7** have size marks. The liner and piston that are paired should be of the same size mark.

<Engines with dry type cylinder liner: 6D16, 16-T, 16-TL>



- 1 Connecting plate
- 2 Glow plug
- 3 Cylinder liner
- 4 Crankcase
- 5 Water jacket
- 6 Piston
- 7 Injection nozzle
- 8 Cylinder head

A: Cylinder liner size mark


Outer diameter mark: 1, 2, 3

Inner diameter mark: A, B

- The cylinder liners **3** are a dry type liners that are easier to remove than wet liners. Liners are press-fitted into the crankcase **4**.
- The cylinder liners **3**, crankcase **4**, and pistons **6** have size marks. They should be combined as specified according to the size marks. P.11-35

# CYLINDER HEAD AND VALVE MECHANISM

## Rocker and Bracket Assembly



### ● Disassembly sequence

- 1 Rocker assembly
- 2 Rocker bushing
- 3 Lock nut
- 4 Adjusting screw
- 5 Rocker
- 6 No. 6 rocker shaft bracket
- 7 Set screw
- 8 No. 5 rocker shaft bracket
- 9 No. 4 rocker shaft bracket
- 10 No. 3 rocker shaft bracket
- 11 No. 2 rocker shaft bracket
- 12 No. 1 rocker shaft bracket
- 13 Rocker shaft spring
- 14 Rocker shaft

### ● Assembly sequence

Reverse the order of disassembly.

### Service standards

Unit: mm

Location	Maintenance item	Standard value (Basic diameter in [ ])	Limit	Remedy
2, 14	Rocker bushing-to-rocker shaft clearance	[24] 0.01 to 0.08	0.12	Replace

### ⓘ Tightening torques

Unit: N · m {kgf · m}


Location	Parts to be tightened	Tightening torque	Remarks
3	Adjusting screw lock nut	34 (3.5)	—
7	Rocker shaft set screw	3.9 (0.4)	—

### 🔧 Oils

Location	Points of application	Kinds	Quantity
2	Rocker bushing inner surface	Engine oil	As required

### 🛠️ Special tools

Unit: mm

Location	Tool name and shape	Part No.	Application
2	Rocker Bushing Puller  01951	MH061777	Removing and installing rocker bushings

**Tightening torques**

Unit: N·m {kgf·m}






Location	Parts to be tightened	Tightening torque	Remarks
1	Bolt (connecting rod installation)	29 {3} + 90° ± 5°	Wet

**Oils**


Location	Points of application	Kinds	Quantity
1	Bolt threads	Engine oil	As required
2, 4	Connecting rod bearing inside surface	Engine oil	As required
6	Cylinder liner outside surface	Engine oil	As required

**Special tools**

Unit: mm

Location	Tool name and shape	Part No.	Application								
5	<p>Socket Wrench</p>  <p>01984</p>	MH061560	Installing piston and connecting rod assembly								
5	<p>Piston Guide</p> <table border="1"> <tr> <td></td> <td>A dimension</td> </tr> <tr> <td>6D14, 14-T</td> <td>φ 110</td> </tr> <tr> <td>6D15-T</td> <td>φ 113</td> </tr> </table>  <p>01980</p>		A dimension	6D14, 14-T	φ 110	6D15-T	φ 113	<p>&lt;6D14, 14-T&gt; 30091-08200</p> <p>&lt;6D15-T&gt; MH061327</p>	Installing piston and connecting rod assembly		
		A dimension									
6D14, 14-T	φ 110										
6D15-T	φ 113										
<p>A: Piston Guide Clamp B: Piston Guide Lever</p>  <p>01981</p>	<p>&lt;6D16, 16-T, 16-TL&gt; A: MH061760 B: MH061658</p>										
6	<p>Cylinder Liner Extractor</p> <table border="1"> <tr> <td></td> <td>C dimension</td> </tr> <tr> <td>6D14, 14-T</td> <td>φ 109.5</td> </tr> <tr> <td>6D15-T</td> <td>φ 112.5</td> </tr> <tr> <td>6D16, 16-T, 16-TL</td> <td>φ 117.5</td> </tr> </table>  <p>01982</p>		C dimension	6D14, 14-T	φ 109.5	6D15-T	φ 112.5	6D16, 16-T, 16-TL	φ 117.5	<p>&lt;6D14, 14-T&gt; A: MH061719</p> <p>&lt;6D15-T&gt; B: MH062003</p> <p>&lt;6D16, 16-T, 16-TL&gt; B: MH061761</p>	Removing cylinder liners
		C dimension									
6D14, 14-T	φ 109.5										
6D15-T	φ 112.5										
6D16, 16-T, 16-TL	φ 117.5										
<p>Cylinder Liner Installer</p> <table border="1"> <tr> <td></td> <td>A dimension</td> </tr> <tr> <td>6D15-T</td> <td>φ 112.5</td> </tr> <tr> <td>6D16, 16-T, 16-TL</td> <td>φ 117.5</td> </tr> </table>  <p>01983</p>		A dimension	6D15-T	φ 112.5	6D16, 16-T, 16-TL	φ 117.5	<p>&lt;6D15-T&gt; MH062002</p> <p>&lt;6D16, 16-T, 16-TL&gt; MH061771</p>	Installing cylinder liners (dry type)			
	A dimension										
6D15-T	φ 112.5										
6D16, 16-T, 16-TL	φ 117.5										

# PISTONS, CONNECTING RODS, AND CYLINDER LINERS



## (2) Piston ring-to-piston ring groove clearance

- If any measurement exceeds the specified limit, replace the defective part(s).
- Measure the 1st compression ring 5 clearance with a thickness gauge H while pressing the ring against the piston 8 with a straight edge G.

### NOTE

- Remove any carbon deposits from the ring groove of the piston 8 and measure the clearance around the piston's entire periphery.
- Piston rings 5, 6, 7 must be replaced as a set. Never replace piston rings individually.

## Service standards

Unit: mm

Location	Maintenance item		Standard value (Basic diameter in [ ])	Limit	Remedy
—	Gear backlash	Between No. 1 idler gear and crankshaft gear	0.08 to 0.15	0.35	Replace
		Between No. 1 idler gear and No. 2 idler gear	0.07 to 0.15	0.35	Replace
		Between No. 1 idler gear and drive gear	0.07 to 0.15	0.35	Replace
		Between No. 2 idler gear and camshaft gear	0.08 to 0.16	0.35	Replace
2, 3	No. 1 idler shaft-to-gear bushing clearance		[37] 0.01 to 0.05	0.2	Replace
4, 12	Idler gear end play		0.05 to 0.15	0.3	Replace
11, 13	No. 2 idler gear bushing-to-shaft clearance		[32] 0.01 to 0.05	0.2	Replace

## ① Tightening torques


Unit: N·m {kgf·m}

Location	Parts to be tightened	Tightening torque	Remarks
1	No. 1 idler gear mounting bolt	88 {9}	—
5	Collar mounting nut	82 {8.4}	—
9	No. 2 idler gear mounting bolt	95 {9.7}	—

## 🔧 Oils


Location	Points of application	Kinds	Quantity
6, 8	O-ring	Engine oil	As required

# CAMSHAFT



[Installation]

- Fit the camshaft gear 8 onto the camshaft 11 in the direction illustrated.
- Do not forget to fit the key 10.



## 11 Inspecting camshaft

### (1) Cam lift

If any base circle-to-lobe height difference is less than the required value, replace the camshaft 11.


#### NOTE

Since the cams are tapered, they must be measured at the position A shown in the diagram.

B: Lobe height

C: Base circle diameter

D: Front of engine




### (2) Camshaft bend

Support the camshaft 11 at its No. 1 journal E and No. 4 journal F, then take measurements at the No. 2 journal G and No. 3 journal H. If either measurement exceeds the specified limit, replace the camshaft.

#### NOTE

Turn the camshaft 11 through one revolution. One-half of the dial indicator reading represents the camshaft's bend.



## 11 to 15 Camshaft and camshaft bushings

[Inspection]

If any clearance exceeds the specified limit, replace the defective part(s).

#### NOTE

Measure the camshaft bushings 12 to 15 with the camshaft installed in the crankcase\*.

# GROUP 12 LUBRICATION

<b>SPECIFICATIONS</b> .....	<b>2</b>
<b>STRUCTURE AND OPERATION</b> .....	<b>3</b>
<b>TROUBLESHOOTING</b> .....	<b>11</b>
<b>ON-VEHICLE INSPECTION AND ADJUSTMENT</b>	
• <b>Oil Filter Replacement</b> .....	<b>12</b>
• <b>Engine Oil Replacement</b> .....	<b>15</b>
• <b>Oil Pressure Measurement</b> .....	<b>16</b>
<b>OIL PAN, OIL JET, AND OIL LEVEL SENSOR</b> .....	<b>18</b>
<b>OIL PUMP AND OIL STRAINER</b> .....	<b>20</b>
<b>OIL FILTER</b> .....	<b>24</b>
<Spin-on Type> .....	<b>24</b>
<Replaceable-element Type> .....	<b>26</b>
<b>OIL COOLER</b> .....	<b>28</b>
<b>REGULATOR VALVE</b> .....	<b>30</b>


# ON-VEHICLE INSPECTION AND ADJUSTMENT

<Replaceable-element type>

## ① Tightening torques

Unit: N·m {kgf·m}

Location	Parts to be tightened	Tightening torque	Remarks
1	Oil filter drain valve	29 ± 4.9 {3.0 ± 0.5}	—
4	Center bolt	54 ± 4.9 {5.5 ± 0.5}	—



### WARNING ⚠

- Wipe up any spilled engine oil since it can cause a fire.
- Do not touch oil when the engine is hot since it can inflict severe burns.


### CAUTION ⚠

When pouring oil into the engine, take care not to spill any on the V-belts. Contact with oil could make the V-belts slip, rendering the cooling system less effective.

With a downward-facing oil filter, loosen drain valve plug 1 and air plug 2 in that order, then drain the oil out of filter 3.

[Removal]

- 4 Center bolt
- 5 O-ring
- 6 Filter case
- 7 O-ring
- 8 Set spring
- 9 Element
- 10 Filter bracket




[Installation]

Wash all components other than the element in cleaning solvent, then fit the filter in the opposite order from that in which it was removed.

### CAUTION ⚠

- If O-ring 7 is twisted when fitted, it may be severed.
- Element 9 cannot be washed and reused.



### ◆ Service procedure

#### 9 Inspection of engine oil bypass alarm switch


Carry out the following inspections and replace the engine oil bypass alarm switch 9 if the results are unsatisfactory:

- With no air pressure **A** applied to engine oil bypass alarm switch 9, check that there is no electrical continuity between the terminal ① and body ② of the engine oil bypass alarm switch.
- Starting with pressure of 0 kPa {0 kgf/cm<sup>2</sup>}, gradually increase the air pressure **A** on engine oil bypass alarm switch 9. Note the air pressure when electrical continuity appears between the terminal ① and body ②. Verify that this pressure conforms with the specified standard value.

**B**: Air pressure gauge


# STRUCTURE AND OPERATION

<RFD Type>



18227

- |                       |                          |
|-----------------------|--------------------------|
| 1 Stop lever          | 12 Stroke adjusting bolt |
| 2 Governor housing    | 13 Idling spring         |
| 3 Governor spring     | 14 Torque spring         |
| 4 Control rack        | 15 Smoke set assembly    |
| 5 Swivel lever        | 16 Damper spring         |
| 6 Camshaft            | 17 Start spring          |
| 7 Speed control lever | 18 Floating lever link   |
| 8 Flyweight           | 19 Tension lever         |
| 9 Sliding lever       | 20 Guide lever           |
| 10 Sleeve             | 21 Governor cover        |
| 11 Floating lever     |                          |



### ● No-load minimum speed

[Inspection]

Confirm that the load control lever 7 is touching the idling set bolt 6. Then check that the minimum speed is up to specification.

A: Idling position

[Adjustment]

If the minimum speed is out of specification, adjust it using the idling set bolt 6.

### ● No-load maximum speed

[Inspection]

Move the load control lever 7 to the full-load position B. Then, check that the maximum speed is up to specification.

[Adjustment]

If the maximum speed is out of specification, adjust position of the speed control lever 8 using the maximum speed stopper bolt 9 and stopper bolt 10.

### NOTE


- Do not alter the position of the full-load stopper bolt 11.
- Check that the engine does not stall and that no hunting occurs when the load control lever 7 is moved quickly from the full-load position to the idling position. If any abnormality is apparent, make adjustments within the specified range.

## Cleaning Fuel Feed Pump Gauze Filter

### ① Tightening torques


Unit: N·m {kgf·m}

Location	Parts to be tightened		Tightening torque	Remarks
1	Eyebolt	Zexel	20 to 29 {2 to 3}	—
		Nippondenso	15 to 20 {1.5 to 2}	—



- Remove the eyebolt 1 from the suction port side of the fuel feed pump.
- Remove the gauze filter 2 from the eyebolt 1.
- Clean the gauze filter 2.
- Refit the gauze filter 2 and eyebolt 1 in the opposite order to their removal.
- Bleed all air out of the fuel system.
- Start the engine and check for fuel leaks.

# INJECTION NOZZLE <1-spring Type>



## (2) Inspecting spray condition

- Pump the lever on the nozzle tester **A** at a rate of about 1–2 seconds per stroke, and maintain a continuous spray.

**B**: Even spray from all five injection orifices (Good)

**C**: Even and symmetrical spray (Good)

**D**: Asymmetrical spray (Bad)

**E**: Branched spray (Bad)


**F**: Thin spray (Bad)

**G**: Irregular spray (Bad)

- If the spray is unsatisfactory, disassemble and clean the injection nozzle assembly **5**, then inspect the spray again. If the spray is still unsatisfactory, replace the injection nozzle assembly **5**.
- Check that no fuel drips from the nozzle after the spray is complete.

### WARNING

Do not touch the spray that comes out of the nozzle.



## (3) Inspecting for leaks



- Slowly increase the nozzle pressure to 1.96 MPa {20 kgf/cm<sup>2</sup>} below the specified valve opening pressure. Maintain this pressure for 10 seconds and check that no fuel drips from the end of the nozzle.
- If the injection nozzle assembly **5** appears defective, disassemble and clean it, then inspect it again. If the injection nozzle assembly **5** still appears defective, it must be replaced.

## 5 Injection nozzle assembly

[Disassembly]

### CAUTION

- Do not touch the sliding parts **A** of the needle valve **7**.
- Do not change the needle valve **13** and nozzle **12** combination on each cylinder.



[Cleaning]

Wash the needle valve **13** and nozzle **12** in gas oil, then use the Cleaning Tool Set to remove any carbon deposits in accordance with the following procedure.

- Remove carbon from the end of the needle valve **13** using the Cleaning Bar of the Cleaning Tool Set.

### CAUTION

Do not use a wire brush or any hard metallic object for cleaning.

---

**MEMO**

---

# SPECIFICATIONS

---

## Air cleaner element

Item	Specifications	
Type	Cyclone type, filter paper type	Cartridge type, filter paper type
Manufacturer	Nihon Donaldson	

## Dust indicator

Item	Specifications
Type	Mechanical type
	Electrical type

## Turbocharger

Item	Specifications		
Type	T04B	T04E	TF07
Manufacturer	Garret turbo		Mitsubishi Heavy Industries

## Intercooler


Item	Specifications
Type	Tube & corrugated fin air cooled type

---

**MEMO**

---

# TURBOCHARGER <T04E (6D16-TL)>




## 22 Compressor wheel

[Removal]

- Hold the 2a Holding Fixture in a vice, and slowly insert the center housing & rotating assembly 20.
- Using the 2b T-handle, remove the lock nut 21 and slowly withdraw the compressor wheel 22 upward.

**CAUTION** ⚠

Use care to prevent bending the shaft of the turbine wheel 23.




[Installation]

- Hold the shaft of the turbine wheel 23 and center housing 35 by hand, and slowly insert them into the 2a Holding Fixture.

**CAUTION** ⚠


- When they are inserted, use care to prevent damage to the blades of the turbine wheel 23.
- Do not release the shaft before insertion, as the turbine wheel 23 falls down.



- Hold the 2a Holding Fixture in a vice and slowly insert the compressor wheel 22.
- Using the 2b T-handle, tighten the lock nut 21 to the specified torque, and then turn it down 90° to 110° further from that position.

**CAUTION** ⚠


Use care to prevent bending the shaft of the turbine wheel 23.



## 23 25 Turbine wheel, wheel shroud


[Removal]

Place the back plate 27 of the center housing 35 on the compressor housing 18 removed beforehand, and remove the turbine wheel 23 and wheel shroud 25.



[Installation]

After installation, lightly rotate the turbine wheel 23 by hand to check whether it continues to rotate. If it does not rotate lightly, re-perform the disassembly and reassembly procedures.



● **Disassembly sequence**

- 1 Cover
- 2 Nut
- 3 Exhaust manifold
- 4 Gasket

\*: Cylinder head Gr.11

ⓧ: Non-reusable part

● **Reassembly sequence**

Reverse the order of disassembly.

ⓘ **Tightening torque**


Unit: N · m {kgf · m}

Location	Parts to be tightened	Tightening torque	Remarks
2	Nut (for mounting exhaust manifold)	41 {4.2}	—

◆ **Service procedure**


4 **Installation of gasket**

Install the gasket 4 with the grommet fold-back portion **A** toward the cylinder head.



# STRUCTURE AND OPERATION


## Charging Circuit



16739


- 1 Battery
- 2 Battery relay
- 3 Ammeter
- 4 Fuse box
- 5 Alternator
- 6 Safety relay <Circuit without charge lamp>
- 7 Charge lamp <Circuit with charge lamp>
- 8 Starter switch

- A: To starter relay terminal B
- B: Terminal B
- E: Terminal E
- L: Terminal L
- R: Terminal R




**When engine is automatically stopped**


- When the oil pressure abnormally falls or the coolant temperature abnormally rises while the engine is running, engine oil pressure switch 11 or coolant temperature sensor (thermo switch) 12 turns on and current flows as described below.



- At this point, the current from terminal A of the solenoid relay 1 is flowing the internal circuit, the switch in the relay is activated and the current flows as follows:




- As a result, solenoid 3 is activated and pulls the stop lever A in direction D to stop the engine.
- Even after losing the generating voltage from the alternator 2, the internal capacitor of the solenoid relay 1 keeps the solenoid 3 in position.



**When engine is manually stopped**

- Position of stop switch 9: ON


Irrespective of the generating voltage of the alternator 2, current from stop switch 9 flows to the internal circuit via ST-terminal of the solenoid relay 1 to activate the internal switch of the relay, and the current flows as follows:



- As a result, engine is stopped in the same way as the automatic stop.


# ON-VEHICLE INSPECTION AND ADJUSTMENT

Even when stop switch 9 is set to ON, engine does not stop.




When oil pressure is abnormally low or coolant temperature abnormally high, engine does not stop.

\* Measure while engine is running.



After engine has stopped, solenoid 3 is not caused to be OFF.




---

**M E M O**


---

# STARTER <24V-5kW>




## 27 Installation of lever

Install the lever 27 in the illustrated direction on the overrunning clutch 38.




## 30 Installation of front bearing


- Before the front bearing 30 is press-fitted, install the dust seal 31.
- Press-fit the front bearing 30 in the front bracket with a press, using the pipe-like tool A.



- Stake the front bracket 32 side.

**CAUTION**  **Avoid staking the previously staked points B.**


C: Staking points (4 places)



## 38 Inspection of overrunning clutch

Perform the following checks. If there is anything wrong, replace the overrunning clutch 38.

- Check to ensure that when the shaft A is made to rotate in the direction B, it rotates smoothly.
- Check to ensure that when the shaft A is made to rotate in the direction C, it is locked.



## ◆ Service procedure

### 1 Solenoid relay

Wire as shown at left and perform the following checks.

- F: Power supply
- G: Switch
- J: Solenoid (or coil load:  $30 \pm 3A$ )
- K: Switch
- L: Switch

#### (1) Inspection of operation of solenoid relay 1 and delay time

- Check to ensure that when the switches G and L are set to ON, the solenoid J operates.
- Set the switch L to OFF and simultaneously measure the time required before the solenoid J is deactivated.



#### (2) Inspection of relay holding time

- Set the switches G and L to ON. After the solenoid J has operated, set the switch K to ON.
- Set the switch L to OFF and check to ensure that the solenoid J stays in the operating state for more than 30 seconds.
- After checking that the solenoid J is in the operating state, set the switch K to OFF to check that the solenoid is deactivated.

### 2 Solenoid

[Installation]

- Install the ball joint 14 to the rod 13 and temporary tighten with lock nut 12.
- Check to ensure that the ball joint 14 moves smoothly.
- Install the solenoid 2 to the engine.
- With the stop lever 15 in the stop position, install the rod 13. Adjust the rod length by turning it.




[Adjustment]

- Remove the cover of the solenoid 2.
- Apply the specified voltage to solenoid 2 and energize the solenoid.
- Check that the clearance A between the pointers of the solenoid is within the standard value.

● 3 PIECE DEMOLITION ATT.

3.33M (10ft-11in) MAIN BOOM+4.485M (14ft-9in) FRONT BOOM+2.3M (7ft-7in) INTER BOOM+5.85M (19ft-2in) ARM+ WITH KR850PR-2 CRUSHER (NIBBLER)



Unit : mm (ft-in)

ITEM	FUNCTION	STD VALUE
A	MAX. WORKING REACH	15,880 (52'1")
※※ A'	MAX. WORKING REACH IN SAFETY	11,500 (37'9")
※ C	MAX. WORKING HEIGHT	17,400 (57'1")
C'	REACH OF MAX. WORKING HEIGHT	3,750 (12'4")
D	MIN. SWING RADIUS	3,060 (10'10")
※ E	REACH OF MIN. SWING RADIUS	10,010 (32'10")
LIMIT WEIGHT OF CRUSHER		2,450kg (5,400 lb)

NOTE :

- The dimensions of mark ※ does not indicate the shoe lug height [37mm (1.46in)].
- This drawing shows the values when Japanese standard crusher (nibbler : KR850PR-2) is attached.

**CAUTION**

The values of mark ※※ shows the max. working reach on the flat and hard ground, and the operation on the area for the area larger than the values are unstable and may cause turning over.

- Stop valves attached to the attachment

1. LMN (Special demolition attachment)


Open the stop valves attached on the back face of the main boom, the back face of the insert boom and the back face of the arm as follows :

2. Backhoe

Open the stop valves located at the tip of the boom as follows :

Turn the stop valves ① to the specified position (⊖) by mean of a spanner.

Tool used : Spanner (24mm)



### 3.5 AUTO GREASER

(SEE OPERATION MANUAL SECTION III)

- Construction

The auto greaser consists of a grease pump assembly (including the grease cartridge) located at the front right of the slewing frame, a controller located at the inner rear part of the cab and distributors.

- Operation

1. Automatic operation


If the engine is started, the controller is powered. All the indicating lamps light for several seconds. Part of the display flickers, and all lamps except the power lamp go out. Then the controller begins integrating the lubrication intervals.

When the operating time of the machine reaches a preset lubrication interval, the grease pump starts automatically and performs a cycle consisting of pressurize, pressure hold (lubrication) and depressurize (filling grease into distributor for next lubrication). The pump stops automatically after greasing for a preset time.

2. Voluntary operation

The grease pump starts at a desired time the moment the controller start switch is pressed (regardless of the integrated time) and stops automatically after one cycle of greasing is completed.

In that case, the operating time being integrated is cancelled. Time integration is resumed the moment the grease pump has stopped automatically.



- (5) LMN (Special demolition ATT. with rotating crusher) circuit : Crusher rotating action  
 [Electric system :  
 ATT operating lever grip switch action]

Switch operation	Crusher rotating direction
Press the RH lever rotating switch.	RH
Press the LH lever rotating switch.	LH

If the rotation switch is turned [ON], LH or RH rotation solenoid (SV-7 or SV-6) is energized.

This changes over the control valve (55) with a separate 1-stack solenoid.

[Mechatronic controller]


If the rotation switch is turned [ON], the mechatronic controller detects it and energizes the P1 bypass cut solenoid proportional valve. Secondary pressure flows out of the solenoid proportional valve and switches over the P1 bypass cut valve.

[Main circuit]


- 1) If the P1 bypass cut valve is switched over, the oil flow of the P1 pump flows out of the P4 port of control valve (50) and is led to the P port of the separate 1-stack control valve (55). If the solenoid valve (SV-7 or SV-6) is switched over, the oil is supplied to the crusher (nibbler) rotating motor (57) from the A or B port of the 1-stack control valve.
- 2) The oil returning from the crusher (nibbler) rotating motor (57) returns directly to the tank by way of the 1-stack control valve (55).

(10) ATT safety control lines

(10-1) Boom hyd. lines ; LC42H00068F1



(10-2) Insert boom hyd. lines ; LC42H00069F1



NOTE

- 1 TIGHTENING TORQUE FOR M THREAD.


THREAD SIZE	TORQUE
M8	3.4kaf·m (24.6lbf·ft)
M10	6.7kaf·m (48.5lbf·ft)
M12	11.7kaf·m (84.6lbf·ft)

- 2 TIGHTENING TORQUES FOR NUTS AND SLEEVES.

TUBE SIZE	TORQUE
φ15×2.0	12.0kaf·m (86.8lbf·ft)
φ22×3.0	22.0kaf·m (159lbf·ft)


- 3 MAKE SURE NOT TO MISS O-RING AT ASSEMBLING.
- 4 APPLY LOCTITE #242 TO CLAMP ATTACHING BOLT.

(1) ROTATING LMN & B ATT. HYD. LINES  
 (1-1) LMN & B arm hyd. lines ; LC43H00009F1




- NOTE
- 1 MAKE SURE NOT TO MISS O-RING AT ASSEMBLING.
  - 2 TIGHTENING TORQUE FOR M THREAD.  
 THREAD SIZE TORQUE  
 M12 11.7k<sub>ef</sub>·m (84.6lbf·ft)  
 M14 18.5k<sub>ef</sub>·m (134lbf·ft)
  - 3 TIGHTENING TORQUE FOR PF. PT THREAD.  
 THREAD TORQUE  
 1 26.0k<sub>ef</sub>·m (187lbf·ft)  
 1" 1/4 40.0k<sub>ef</sub>·m (289lbf·ft)
  - 4 TIGHTENING TORQUES FOR NUTS AND SLEEVES.  
 TUBE SIZE  
 #35x5.0 45.0k<sub>ef</sub>·m (325lbf·ft)
  - 5 APPLY LOCTITE #242 TO CLAMP ATTACHING BOLT.

(1-2) Inter boom (JIB) hyd. lines ; LC42H00029F1



# 5. ELECTRIC SYSTEM

ELECTRIC CIRCUIT DIAGRAM ; LC03Z00010P1  
APPLICABLE MACHINE YC06-02501 ~





WIRE NO	WIRE COLOR	WIRE SIZE	FROM	CONNECTION	TO	FUNCTION
545	Lg	AVSS0.75sq	CN-2F		CN-10F	MECHATRO CONTROLLER → SWING PARKING RELEASE SW.
546A	PG	AVSS0.75sq	CN-26F		CN-2F	ISPAF-J/B → MECHATRO CONTROLLER
546B	PG	AVSS0.75sq	CN-26F		CN-13F	ISPAF-J/B → RESISTOR
546C	PG	AVSS0.75sq	CN-26F		CN-11F	ISPAF-J/B → KPSS MODE RELEASE SW.
546D	PG	AVSS0.75sq	CN-26F		CN-11F	ISPAF-J/B → KPSS MODE RELEASE SW.
547	GB	AVSS0.75sq	CN-4F		CN-30F	MECHATRO CONTROLLER → ENG. WATER TEMP. SW.
548	GY	AVSS0.75sq	CN-4F		CN-30F	MECHATRO CONTROLLER → ENG. OIL PRESS. SW.
549	Lg	AVSS0.75sq	CN-4F		CN-30F	MECHATRO CONTROLLER → AIR FILTER RESTRICTION SW.
550	BG	AVSS0.75sq	CN-4F		CN-30F	MECHATRO CONTROLLER → ENG. OIL LEVEL SW.
551	GL	AVSS0.75sq	CN-4F		CN-30F	MECHATRO CONTROLLER → ENG. COOLANT LEVEL SW.
552	BrL	AVSS0.75sq	CN-4F		CN-30F	MECHATRO CONTROLLER → HYD. FLUID LEVEL SW.
553A	VW	AVSS0.75sq	CN-27F		CN-30F	ISPAF-J/B → FUEL SENSOR
553B	VW	AVSS0.75sq	CN-27F		CN-4F	ISPAF-J/B → MECHATRO CONTROLLER
553C	VW	AVSS0.75sq	CN-27F		CN-20F	ISPAF-J/B → RESISTOR
556	BrW	AVSS0.5sq	CN-4F		CN-51F	MECHATRO CONTROLLER → SW. BOX ASSY
557	L	AVSS0.75sq	CN-4F		CN-38M	MECHATRO CONTROLLER → WIPER MOTOR
558	G	AVSS0.75sq	CN-4F		CN-38M	MECHATRO CONTROLLER → WIPER MOTOR
559	PB	AVSS0.75sq	CN-60F		CN-7F	WIPER INTERLOCK SW. → MECHATRO CONTROLLER
560	LgY	AVSS0.75sq	CN-7F		CN-45F	MECHATRO CONTROLLER → SWING FRASHER SW.
562	O	AVSS0.5sq	CN-52F		CN-32M	SW. BOX ASSY → WARN-UP SW.
563	O	AVSS0.75sq	CN-30F		CN-7F	HYD. FLUID TEMP SW. → MECHATRO CONTROLLER
564	LY	AVSS0.5sq	CN-52F		CN-32M	SW. BOX ASSY → CONFLUX/SINGLE SELECT SW.
565	GR	AVSS0.5sq	CN-34F		CN-52	SW. TO WASH THE LOWER PART OF WIPER → SW. BOX ASSY
566	LW	AVSS0.75sq	CN-6F		CN-30F	MECHATRO CONTROLLER → ENGINE OIL FILTER
568	LgR	AVSS0.5sq	CN-52F		CN-34F	SW. BOX ASSY → STROKE-END PROXIMITY SW.
569	LO	AVSS0.5sq	CN-52F		CN-39F	SW. BOX ASSY → NIBBLER OPEN SW.
570	YB	AVSS0.5sq	CN-52F		CN-39F	SW. BOX ASSY → NIBBLER CLOSE SW.
571	YG	AVSS0.5sq	CN-52F		CN-30F	SW. BOX ASSY → NIBBLER STOP SW.
572	GrG	AVSS0.5sq	CN-52F		CN-31M	SW. BOX ASSY → SW. ASSY (MODE BUZZER STOP)
573	V	AVSS0.5sq	CN-52F		CN-31M	SW. BOX ASSY → SW. ASSY (MODE BUZZER STOP)
574	PL	AVSS0.5sq	CN-52F		CN-38M	SW. BOX ASSY → SW. ASSY (WIPER WASH. LIGHT)
575	LgB	AVSS0.5sq	CN-52F		CN-38M	SW. BOX ASSY → SW. ASSY (WIPER WASH. LIGHT)
576	LB	AVSS0.5sq	CN-52F		CN-38M	SW. BOX ASSY → SW. ASSY (WIPER WASH. LIGHT)
580	R	MVSS0.75sq	CN-2F		CN-30F	MECHATRO CONTROLLER → ENG. REVOLUTION SENSOR
581	W	2 CORES SHIELD	CN-2F		CN-30F	MECHATRO CONTROLLER → ENG. REVOLUTION SENSOR
SH2	Gr	2 CORES SHIELD	CN-2F		CN-30F	MECHATRO CONTROLLER → ENG. REVOLUTION SENSOR
582	W	MVSS0.75sq	CN-4F		CN-38M	MECHATRO CONTROLLER → CLUSTER GAUGE
770	R	3 CORES SHIELD	CN-4F		CN-38M	MECHATRO CONTROLLER → CLUSTER GAUGE
980	B	3 CORES SHIELD	CN-4F		CN-38M	MECHATRO CONTROLLER → CLUSTER GAUGE
SH3	Gr	3 CORES SHIELD	CN-4F		CN-38M	MECHATRO CONTROLLER → CLUSTER GAUGE
583	VW	AVSS0.75sq	CN-32M		CN-30F	OVER LOAD ALARM SELECT SW. → OVER LOAD SW.
584	Br	AVSS0.75sq	CN-3F		CN-34F	MECHATRO CONTROLLER → STROKE-END PROXIMITY SW.
590	LY	AVSS0.5sq	CN-21F		CN-52F	HEAVY LIFT SW. → SW. BOX ASSY
600	YR	AVSS0.75sq	CN-38M		CN-30F	CLUSTER GAUGE → COOLANT THERMO SENSOR
601	BrR	AVSS0.75sq	CN-38M		CN-30F	CLUSTER GAUGE → FUEL SENSOR
610A	GrL	AVSS0.75sq	CN-27F		CN-7F	ISPAF-J/B → MECHATRO CONTROLLER
610B	GrL	AVSS0.75sq	CN-27F		CN-55F	ISPAF-J/B → DIODE
610C	GrL	AVSS0.75sq	CN-27F		CN-55F	ISPAF-J/B → DIODE
611	Lg	AVSS0.75sq	CN-4F		CN-34F	MECHATRO CONTROLLER → ARM PUSH/PULL PORT SELECT SOL.
700	WG	AVSS0.75sq	CN-5F		CN-30F	MECHATRO CONTROLLER → BATTERY RELAY
701	V	AVSS0.75sq	CN-5F		CN-10F	MECHATRO CONTROLLER → SWING PARKING RELEASE SW.
702	LgB	AVSS0.75sq	CN-5F		CN-30F	MECHATRO CONTROLLER → TWO-SPEED SELECT SOL.
703	P	AVSS0.75sq	CN-5F		CN-30F	MECHATRO CONTROLLER → POWER BOOST SOL.
704	LgR	AVSS0.5sq	CN-4F		CN-51F	MECHATRO CONTROLLER → SW. BOX ASSY
705	Lg	AVSS0.5sq	CN-4F		CN-51F	MECHATRO CONTROLLER → SW. BOX ASSY
706	VW	AVSS0.5sq	CN-4F		CN-51F	MECHATRO CONTROLLER → SW. BOX ASSY
707	LY	AVSS0.5sq	CN-4F		CN-51F	MECHATRO CONTROLLER → SW. BOX ASSY
708	LR	AVSS0.75sq	CN-4F		CN-29F	MECHATRO CONTROLLER → WIPER RELAY ASSY

WIRE NO	WIRE COLOR	WIRE SIZE	FROM	CONNECTION	TO	FUNCTION
709	GB	AVSS0.75sq	CN-4F		CN-29F	MECHATRO CONTROLLER → WIPER RELAY ASSY
710	Gr	AVSS0.75sq	CN-4F		CN-29F	MECHATRO CONTROLLER → WIPER RELAY ASSY
711	GrL	AVSS0.75sq	CN-4F		CN-29F	MECHATRO CONTROLLER → WIPER RELAY ASSY
713	BrY	AVSS0.75sq	CN-4F		CN-16F	MECHATRO CONTROLLER → WORK LIGHT RELAY
714	WB	AVSS0.75sq	CN-41F		CN-4F	FLASHER RELAY → MECHATRO CONTROLLER
715	GW	AVSS0.75sq	CN-41F		CN-7F	FLASHER RELAY → MECHATRO CONTROLLER
716	WV	AVSS0.75sq	CN-41F		CN-7F	FLASHER RELAY → MECHATRO CONTROLLER
718	OL	AVSS0.75sq	CN-7F		CN-34F	MECHATRO CONTROLLER → BUCKET CONTROL RELAY
720	PB	AVSS0.75sq	CN-10F		CN-30F	SWING PARKING RELEASE SW. → SWING PARKING RELEASE SW.
738	WG	AVSS0.75sq	CN-6F		CN-30F	MECHATRO CONTROLLER → SWING PRIORITY PROPORTIONAL VALVE
739	G	AVSS0.75sq	CN-6F		CN-30F	MECHATRO CONTROLLER → SWING PRIORITY PROPORTIONAL VALVE
740	BD	AVSS0.75sq	CN-5F		CN-30F	MECHATRO CONTROLLER → P1 ST-PASS CUT PROPORTIONAL SOL.
741	GrR	AVSS0.75sq	CN-5F		CN-30F	MECHATRO CONTROLLER → P2 ST-PASS CUT PROPORTIONAL SOL.
742	VR	AVSS0.75sq	CN-5F		CN-30F	MECHATRO CONTROLLER → STRAIGHT TRAVEL PROPORTIONAL SOL.
743	GrB	AVSS0.75sq	CN-5F		CN-30F	MECHATRO CONTROLLER → STRAIGHT TRAVEL PROPORTIONAL SOL.
744	BP	AVSS0.75sq	CN-5F		CN-30F	MECHATRO CONTROLLER → P1 ST-PASS CUT PROPORTIONAL SOL.
745	PW	AVSS0.75sq	CN-5F		CN-30F	MECHATRO CONTROLLER → P1 ST-PASS CUT PROPORTIONAL SOL.
746	BrG	AVSS0.75sq	CN-5F		CN-30F	MECHATRO CONTROLLER → ARM VALVABLE RECIRCULATION PSY
747	YV	AVSS0.75sq	CN-5F		CN-30F	MECHATRO CONTROLLER → ARM VALVABLE RECIRCULATION PSY
748	VR	AVSS0.75sq	CN-5F		CN-11F	MECHATRO CONTROLLER → KPSS MODE RELEASE SW.
749	GrG	AVSS0.75sq	CN-5F		CN-11F	MECHATRO CONTROLLER → KPSS MODE RELEASE SW.
750	VW	AVSS0.75sq	CN-5F		CN-11F	MECHATRO CONTROLLER → KPSS MODE RELEASE SW.
751	GY	AVSS0.75sq	CN-5F		CN-11F	MECHATRO CONTROLLER → KPSS MODE RELEASE SW.
758	BrY	AVSS0.75sq	CN-11F		CN-30F	KPSS MODE RELEASE SW. → PUMP P1 PROPORTIONAL SOL.
757	RY	AVSS0.75sq	CN-11F		CN-30F	KPSS MODE RELEASE SW. → PUMP P1 PROPORTIONAL SOL.
758	BrB	AVSS0.75sq	CN-11F		CN-30F	KPSS MODE RELEASE SW. → PUMP P2 PROPORTIONAL SOL.
759	RL	AVSS0.75sq	CN-11F		CN-30F	KPSS MODE RELEASE SW. → PUMP P2 PROPORTIONAL SOL.
760	G	AVSS0.75sq	CN-7F		CN-39F	MECHATRO CONTROLLER → NIBBLER OPEN RELAY
761	GL	AVSS0.75sq	CN-7F		CN-39F	MECHATRO CONTROLLER → NIBBLER CLOSE RELAY
771	G	MVSS0.75sq	CN-5F		CN-30F	MECHATRO CONTROLLER → STEPPING MOTOR
772	B	4 CORES SHIELD	CN-5F		CN-30F	MECHATRO CONTROLLER → STEPPING MOTOR
773	R	4 CORES SHIELD	CN-5F		CN-30F	MECHATRO CONTROLLER → STEPPING MOTOR
774	W	4 CORES SHIELD	CN-5F		CN-30F	MECHATRO CONTROLLER → STEPPING MOTOR
SH1	Gr	4 CORES SHIELD	CN-5F		CN-30F	MECHATRO CONTROLLER → STEPPING MOTOR
900	RB	AVSS0.75sq	CN-1F		CN-30F	MECHATRO CONTROLLER → PRESS. SENSOR: BUCKET DIGGING
901	RL	AVSS0.75sq	CN-1F		CN-30F	MECHATRO CONTROLLER → PRESS. SENSOR: BUCKET DUMP
902	W	AVSS0.75sq	CN-1F		CN-30F	MECHATRO CONTROLLER → PRESS. SENSOR: BOOM RAISING
903	OB	AVSS0.75sq	CN-1F		CN-30F	MECHATRO CONTROLLER → PRESS. SENSOR: BOOM LOWERING
904	OL	AVSS0.75sq	CN-1F		CN-30F	MECHATRO CONTROLLER → PRESS. SENSOR: ARM IN
905	OW	AVSS0.75sq	CN-1F		CN-30F	MECHATRO CONTROLLER → PRESS. SENSOR: ARM OUT
906	YB	AVSS0.75sq	CN-1F		CN-30F	MECHATRO CONTROLLER → PRESS. SENSOR: SWING LIGHT
907	YG	AVSS0.75sq	CN-1F		CN-30F	MECHATRO CONTROLLER → PRESS. SENSOR: SWING LEFT
908	YL	AVSS0.75sq	CN-1F		CN-31M	MECHATRO CONTROLLER → PRESS. SENSOR: TRAVEL RIGHT
909	YR	AVSS0.75sq	CN-1F		CN-31M	MECHATRO CONTROLLER → PRESS. SENSOR: TRAVEL LEFT
910	WY	AVSS0.75sq	CN-2F		CN-30F	MECHATRO CONTROLLER → PRESS. SENSOR: P1 MEGA-COM.
911	RG	AVSS0.75sq	CN-2F		CN-30F	MECHATRO CONTROLLER → PRESS. SENSOR: P2 MEGA-COM.
912	RW	AVSS0.75sq	CN-3F		CN-30F	MECHATRO CONTROLLER → PRESS. SENSOR: BACK PRESS.
913	RB	AVSS0.75sq	CN-3F		CN-31M	MECHATRO CONTROLLER → PRESS. SENSOR: P1 OPT.
914	RL	AVSS0.75sq	CN-3F		CN-31M	MECHATRO CONTROLLER → PRESS. SENSOR: P2 OPT.
915	YL	AVSS0.75sq	CN-2F		CN-30F	MECHATRO CONTROLLER → PRESS. SENSOR: PUMP P1
916	YR	AVSS0.75sq	CN-2F		CN-30F	MECHATRO CONTROLLER → PRESS. SENSOR: PUMP P2
917	WR	AVSS0.75sq	CN-1F		CN-36M	MECHATRO CONTROLLER → PRESS. SENSOR: ACCEL POTENTIAL
918	RG	AVSS0.75sq	CN-34F		CN-7F	BOOM POTENTIAL → MECHATRO CONTROLLER
930	RG	AVSS0.5sq	CN-4F		CN-51F	MECHATRO CONTROLLER → SW. BOX ASSY
932	RL	AVSS0.75sq	CN-3F		CN-35F	MECHATRO CONTROLLER → F/R AND L/R CLINOMETER
950	BrR	AVSS0.75sq	CN-1F		CN-30F	MECHATRO CONTROLLER → PRESS. SENSOR: BUCKET DIGGING
951	BL	AVSS0.75sq	CN-1F		CN-30F	MECHATRO CONTROLLER → PRESS. SENSOR: BUCKET DUMP
952	BR	AVSS0.75sq	CN-1F		CN-30F	MECHATRO CONTROLLER → PRESS. SENSOR: BOOM RAISING

WIRE NO	WIRE COLOR	WIRE SIZE	FROM	CONNECTION	TO	FUNCTION
953	BrW	AVSS0.75sq	CN-1F		CN-30F	MECHATRO CONTROLLER → PRESS. SENSOR: BOOM LOWERING
954	BrL	AVSS0.75sq	CN-1F		CN-30F	MECHATRO CONTROLLER → PRESS. SENSOR: ARM IN
955	Gr	AVSS0.75sq	CN-1F		CN-30F	MECHATRO CONTROLLER → PRESS. SENSOR: ARM OUT
956	GrL	AVSS0.75sq	CN-1F		CN-30F	MECHATRO CONTROLLER → PRESS. SENSOR: SWING RIGHT
957	Br	AVSS0.75sq	CN-1F		CN-30F	MECHATRO CONTROLLER → PRESS. SENSOR: SWING LEFT
958	BY	AVSS0.75sq	CN-1F		CN-31M	MECHATRO CONTROLLER → PRESS. SENSOR: TRAVEL RIGHT
959	BG	AVSS0.75sq	CN-1F		CN-31M	MECHATRO CONTROLLER → PRESS. SENSOR: TRAVEL LEFT
960	BY	AVSS0.75sq	CN-2F		CN-30F	MECHATRO CONTROLLER → PRESS. SENSOR: P1 MEGA-COM.
961	BW	AVSS0.75sq	CN-2F		CN-30F	MECHATRO CONTROLLER → PRESS. SENSOR: P2 MEGA-COM.
962	GrG	AVSS0.75sq	CN-3F		CN-30F	MECHATRO CONTROLLER → PRESS. SENSOR: BACK PRESS.
963	BW	AVSS0.75sq	CN-3F		CN-31M	MECHATRO CONTROLLER → PRESS. SENSOR: P1 OPT.
964	BL	AVSS0.75sq	CN-3F		CN-31M	MECHATRO CONTROLLER → PRESS. SENSOR: P2 OPT.
965	BrB	AVSS0.75sq	CN-2F		CN-30F	MECHATRO CONTROLLER → PRESS. SENSOR: PUMP P1
966	BrY	AVSS0.75sq	CN-2F		CN-30F	MECHATRO CONTROLLER → PRESS. SENSOR: PUMP P2
967	BW	AVSS0.75sq	CN-1F		CN-36M	MECHATRO CONTROLLER → PRESS. SENSOR: ACCEL POTENTIAL
968	BL	AVSS0.75sq	CN-7F		CN-34F	MECHATRO CONTROLLER → BOOM POTENTIAL
970	BP	AVSS0.75sq	CN-3F		CN-35F	MECHATRO CONTROLLER → F/R AND L/R CLINOMETER
981A	GW	AVSS0.75sq	CN-4F		CN-27F	MECHATRO CONTROLLER → ISPAF-J/B
981B	GW	AVSS0.75sq	CN-38M		CN-27F	SW. ASSY (WIPER WASH. LIGHT) → ISPAF-J/B
981C	GW	AVSS0.75sq	CN-31M		CN-27F	SW. ASSY (MODE BUZZER STOP) → ISPAF-J/B
981D	GW	AVSS0.75sq	CN-31M		CN-27F	SW. ASSY (MODE BUZZER STOP) → ISPAF-J/B
982A	BG	AVSS0.5sq	CN-51F		CN-26F	SW. BOX ASSY → ISPAF-J/B
982B	BG	AVSS0.75sq	CN-32M		CN-26F	CONFLUX/SINGLE SELECT SW. → ISPAF-J/B
982C	BG	AVSS0.75sq	CN-39F		CN-26F	NIBBLER OPEN SW. → ISPAF-J/B
982D	BG	AVSS0.75sq	CN-30F		CN-26F	POWER SPLIT SW. → ISPAF-J/B
982E	BG	AVSS0.75sq	CN-34F		CN-26F	STROKE-END PROXIMITY SW. → ISPAF-J/B
E1	B	AVSS0.5sq	P-1	DOUBLE SPLICE	CN-33M	EARTH → EARTH
E15	B	AVSS0.75sq	P-1	DOUBLE SPLICE	CN-60F	EARTH → WIPER INTERLOCK SW.
E2	B	AVSS0.75sq	CN-5F		CN-30F	MECHATRO CONTROLLER → EARTH
E3	B	AVSS0.75sq	CN-5F		CN-30F	MECHATRO CONTROLLER → EARTH
E4	B	AVSS0.75sq	CN-31M		CN-28F	INST-PANEL R → 11PAF-GND
E5	B	AVSS1.25sq	CN-32M		CN-28F	INST-PANEL L → 11PAF-GND
E6	B	AVSS0.75sq	CN-44F		CN-28F	INST-PANEL L → 11PAF-GND
E7	B	AVSS0.75sq	CN-12F		CN-28F	SAFETY RELAY → 11PAF-GND
E9	B	AVSS0.75sq	CN-42F		CN-28F	AUTO GREASE CONTROLLER → 11PAF-GND
E10	B	AVSS0.75sq	CN-11F		CN-28F	KPSS MODE RELEASE SW. → 11PAF-GND
E11	B	AVSS0.75sq	CN-11F		CN-28F	KPSS MODE RELEASE SW. → 11PAF-GND
E12	B	AVSS0.75sq	CN-29F		CN-28F	WIPER REALY ASSY → 11PAF-GND
E14	B	AVSS1.25sq	CN-36M		CN-28F	AIR CONDITIONER AMP. → 11PAF-GND
E16	B	AVSS1.25sq	M-2		CN-28F	CAB WORKING LIGHT LEFT → 11PAF-GND
E19	B	AVSS1.25sq	CN-43F	DOUBLE SPLICE	CN-28F	RESERVE → 11PAF-GND
E22	B	AVSS1.25sq	CN-43F		CN-62F	RESERVE → RESERVE
E17	B	AVSS0.75sq	CN-37F	DOUBLE SPLICE	P-2	ROOF WIPER MOTOR → EARTH
E13	B	AVSS0.5sq	P-3	DOUBLE SPLICE	P-2	EARTH → EARTH
E18	B	AVSS1.25sq	P-3		M-1	EARTH → EARTH
E21	B	AVSS0.75sq	P-4	DOUBLE SPLICE	CN-61F	EARTH → ONE WAY CALL AMP.
E23	B	AVSS0.75sq	M-3		CN-61F	ROTARY LIGHT → ONE WAY CALL AMP.



7.2 SOLENOID VALVE : FOR CRUSHER (NIBBLER) ROTATING (YN30V00013F1)



SPECIFICATIONS


Main relief valve set pressure	kgf/cm <sup>2</sup> (psi) 1pc.	350 (4980) at 20ℓ/min (5.3gal/min)
Over load relief valve set pressure	kgf/cm <sup>2</sup> (psi) 2pcs.	210 (2990) at 20ℓ/min (5.3gal/min)
Rated flow	ℓ/min	20~30 (5.3~7.9gal/min)
Rated voltage	V	DC24

TIGHTENING TORQUE : kgf·m (bf·ft)

NO. 1,2	8~10 (58~72)
---------	--------------

NO.	PART NAME	Q'TY	NO.	PART NAME	Q'TY
100	MANIFOLD	1	2	OVER LOAD RELIEF VALVE	2
101	SPACER	2	4	SOLENOID	1
102	STOPPER	2	6	NAME PLATE	1
1	MAIN RELIEF VALVE	1	7	RIVET	2

## 8. SAFETY DEVICE



Alarm and safety protecting device

### 8.1 SUMMARY

The safety devices consist of an alarm device and a safety protection device.

(1) The buzzer of the alarm device sounds as below :

- 1) Fall down alarm device  
The buzzer sounds if the attachment goes beyond its safe operation limit range.
- 2) Bucket cylinder stroke end alarm device  
The buzzer sounds 50mm (1.97in) before the stroke end.

(2) The safe protection device operates as below :

- 1) Bucket cylinder protector  
A protector is provided to prevent the bucket cylinder rod from being damaged.
- 2) Debris redirector  
A redirector is provided to prevent debris from falling on the back of the boom.
- 3) LMN/BH select switch  
The switch that selects LMN (long mount crusher) and BH (backhoe) is located on the control stand at the left of the cab.

- 4) 3-face guard  
A protective guard is mounted to the front and the skylight of the cab to protect the operator from falling fragments.
- 5) Skylight wiper  
A wiper is installed in the skylight of the cab to get a clear view of the attachment.
- 6) One-way call device  
A microphone and speaker system is provided to enable the operator to communicate with outside people during operation.

No.	PART No.	NAME	Q'TY	REMARK	Applicable Machines
3	LC03H01037D1	•• HOSE	1		
4	LC03H01025D1	•• HOSE	1		
5	HH25R16016G2	•• CONNECTOR	1		
6	2444Z3203	•• ELBOW	1		
7	24100P2599F1	•• SELECTOR VALVE	1		
8	LC03H01064P1	•• SUPPORT	1		
9	LC03H01051P1	•• BRACKET	1		
10	LC03H01046P1	•• CLAMP	1		
11	LC03H01022D2	•• SPACER	1		
12	ZE13X16000	•• HALF CALMP	8		
13	ZD12P03400	•• O RING	5		
14	ZD12A02100	•• O RING	2		
15	ZS18C10030	•• CAPSCREW	4		
16	ZS18C12035	•• CAPSCREW	6		
17	ZS18C12070	•• CAPSCREW	1		
18	ZS28C12040	•• CAPSCREW	16		
19	ZW16H10000	•• WASHER	4		
20	ZW16H12000	•• WASHER	6		
21	2418T10357	•• WASHER	3		
22	ZW26K12000	•• LOCK WASHER	20		
23	ZN18C12010	•• NUT	1		
24	LC03H01070P1	•• SUPPORT	1		
25	YN32H01066P1	•• CLAMP	1		
26	YN03H01431P1	•• BUSHING	1		
27	ZS18C12055	•• CAPSCREW	1		
28	ZS28C12065	•• CAPSCREW	4		
38	YN17M00010FK 2479U1190F32	• INSTRUMENT PANEL ASSY •• SWITCH	1	Single/conflux select	
15	YN22T00167F2	• INSTALL OF THE NAME PLATE			
16	YY20T01039P1	•• LABEL	1		
16	PY20T01062P1	•• LABEL	1		
17	YT20T01054P1	•• LABEL	1		
18	YN20T01414P1	•• LABEL	1		

## BREAKER

No.	PART No.	NAME	Q'TY	REMARK	Applicable Machines
	LC06H00001F3	• REMOTE CONTROL PIPING (MAIN)			
2	ZH22X04006	•• CONNECTOR	1		
5	ZH32X04006	•• ELBOW	1		
9	2444Z2336	•• TEE	1		
32	2444R1120D035	•• HOSE	1		
	LC03H00009F1	• UPPER HYDRAULIC PIPING			
1	LC03H01063P1	•• TUBE	1		
2	LC03H01071P1	•• TUBE	1		
3	LC03H01025D1	•• HOSE	1		
4	2444Z3203	•• ELBOW	1		
5	HH25R16016G2	•• CONNECTOR	1		
6	YN32H01066P1	•• CLAMP	1		
7	YN03H01431P1	•• BUSHING	1		
8	LC03H01064P1	•• SUPPORT	3		
9	LC03H01072P1	•• BRACKET	1		
10	LC03H01046P1	•• CLAMP	2		
11	LC03H01022D2	•• SPACER	1		
12	ZE13X16000	•• HALF CLAMP	4		
13	ZD12P03400	•• O RING	3		
14	ZD12A02100	•• O RING	2		
15	ZS18C12075	•• CAPSCREW	1		
16	ZS18C12035	•• CAPSCREW	6		
17	ZS18C12070	•• CAPSCREW	1		
18	ZS28C12040	•• CAPSCREW	12		
19	ZS18C12055	•• CAPSCREW	1		
20	ZW16H12000	•• WASHER	7		
21	2418T10357	•• WASHER	4		
22	ZW26K12000	•• LOCK WASHER	12		
23	ZN18C12010	•• NUT	2		
24	LC03H01070P1	•• SUPPORT	1		
25	YN42H01078P1	•• CLAMP	1		
26	ZE13Q16000	•• PLUG	1		
	YN22T00165F1	• INSTALL OF THE NAME PLATE			
18	YN20T01414P1	•• LABEL	1		

(2) Hydraulic circuit for Nibbler & Breaker at breaker operating **OCEANIA & ASIA**




Fig. 4 Hydraulic circuit for Nibbler & Breaker at breaker operating

- (3) Breaker
- 1) Nibbler & breaker pedal operation  
If the operation is switched to the breaker mode (B mode) and the nibbler & breaker pedal is stepped on, secondary pilot pressure enters the low-pressure sensor (SE-11). The output voltage of the low-pressure sensor enters the mechatronic controller. The mechatronic controller then processes the pilot signal and puts out a command to the solenoid proportional valve for the P2 bypass cut valve according to the input voltage. Then the secondary pressure of the solenoid proportional valve changes the P2 bypass cut valve of the control valve.
  - 2) Pilot circuit  
If the nibbler & breaker pilot valve (53) is pressed by the toe, pressure enters from the B port to the PA02 port of the control valve to change the spool of the option valve.
  - 3) Main circuit  
The oil delivered by the P2 pump comes out of the A02 port of the control valve and is supplied to the breaker to give impact to the breaker. The oil returned from the breaker returned directly to the hydraulic tank via the control valve because the selector valve(51) is changed.  
In the single breaker operation, the rate of the P2 pump rises only to a value set in the breaker mode.

Where the breaker and other attachments requires limitation to the maximum flow :

- Flow adjusting mode operation :

- 1) The flow adjusting mode is available if the starter switch is turned "ON" after the engine stops, the mode is turned to the B mode and the screen change switch is pressed for 3 to 10 seconds
- 2) If the engine is started, the flow reads 210ℓ/min. in the initial stage. It is stored and indicated from next time. If the mode switch is pushed one time, the flow increased by 10ℓ/min. If the buzzer stop switch is pressed, the flow decreases to 30ℓ/min.
- 3) To release the adjust mode, turn the screen select switch to "ON".

(2) Modification procedure (N&B) EU

Install the additional parts listed in Table 15,  
as shown in Fig. 14.

Table 15

No.	PART No.	NAME	Q'TY	REMARK
2	ZH22X04006	CONNECTOR	1	PF1/4-PF3/8
5	ZH32X04006	ELBOW	1	PF1/4-PF3/8

Thread size (PF)	Spanner (mm)	O ring type coupling	
		Tightening torque (kgf-m (lb-ft))	Hydraulic hose (30° flare) Tightening torque (kgf-m (lb-ft))
1/4	19	3.67 (26.8)	3.00 (21.7)
3/8	22	7.50 (54.2)	




Fig. 14

This page is left blank for editing convenience.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL