

SHOP
MANUAL

KOMATSU
12V170-1
SERIES ENGINE



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

	Type 1	Type 2
Connection	<ul style="list-style-type: none"> Hold the mouthpiece of the tightening portion and push body (2) in straight until sliding prevention ring (1) contacts contact surface a of the hexagonal portion at the male end to connect it.  <p>The diagram shows a hand holding a coupler assembly. An arrow labeled '2' points to the left, indicating the direction of the push body. A circular inset shows a close-up of the sliding prevention ring (1) making contact with surface 'a' of a hexagonal portion. The reference code CWP06391 is located at the bottom right of the diagram.</p>	<ul style="list-style-type: none"> Hold the mouthpiece of the tightening portion and push body (2) in straight until sliding prevention ring (1) contacts contact surface a of the hexagonal portion at the male end to connect it.  <p>The diagram shows a hand holding a coupler assembly. An arrow labeled '2' points to the left, indicating the direction of the push body. A circular inset shows a close-up of the sliding prevention ring (1) making contact with surface 'a' of a hexagonal portion. The reference code CWP06392 is located at the bottom right of the diagram.</p>

kgm to ft. lb


1 kgm = 7.233 ft. lb

	0	1	2	3	4	5	6	7	8	9
0	0	7.2	14.5	21.7	28.9	36.2	43.4	50.6	57.9	65.1
10	72.3	79.6	86.8	94.0	101.3	108.5	115.7	123.0	130.2	137.4
20	144.7	151.9	159.1	166.4	173.6	180.8	188.1	195.3	202.5	209.8
30	217.0	224.2	231.5	238.7	245.9	253.2	260.4	267.6	274.9	282.1
40	289.3	296.6	303.8	311.0	318.3	325.5	332.7	340.0	347.2	354.4
50	361.7	368.9	376.1	383.4	390.6	397.8	405.1	412.3	419.5	426.8
60	434.0	441.2	448.5	455.7	462.9	470.2	477.4	484.6	491.8	499.1
70	506.3	513.5	520.8	528.0	535.2	542.5	549.7	556.9	564.2	571.4
80	578.6	585.9	593.1	600.3	607.6	614.8	622.0	629.3	636.5	643.7
90	651.0	658.2	665.4	672.7	679.9	687.1	694.4	701.6	708.8	716.1
100	723.3	730.5	737.8	745.0	752.2	759.5	766.7	773.9	781.2	788.4
110	795.6	802.9	810.1	817.3	824.6	831.8	839.0	846.3	853.5	860.7
120	868.0	875.2	882.4	889.7	896.9	904.1	911.4	918.6	925.8	933.1
130	940.3	947.5	954.8	962.0	969.2	976.5	983.7	990.9	998.2	1005.4
140	1012.6	1019.9	1027.1	1034.3	1041.5	1048.8	1056.0	1063.2	1070.5	1077.7
150	1084.9	1092.2	1099.4	1106.6	1113.9	1121.1	1128.3	1135.6	1142.8	1150.0
160	1157.3	1164.5	1171.7	1179.0	1186.2	1193.4	1200.7	1207.9	1215.1	1222.4
170	1129.6	1236.8	1244.1	1251.3	1258.5	1265.8	1273.0	1280.1	1287.5	1294.7
180	1301.9	1309.2	1316.4	1323.6	1330.9	1338.1	1345.3	1352.6	1359.8	1367.0
190	1374.3	1381.5	1388.7	1396.0	1403.2	1410.4	1417.7	1424.9	1432.1	1439.4

SA12V170-1 (FOR D575A-2SD)

Flywheel horsepower: 858 KW (1,150 HP)/1,800 rpm
Maximum torque: 5,658 Nm (577 kgm)/1,300 rpm

618001



SAE00238


WEIGHT TABLE

Unit: kg


No.	Item	Component	SA12V170-1		
			D575A-2	D575A-2SD	
1	Turbocharger	KTR130	35 x 2 (Water cooled turbo)	35 x 2 (Water cooled turbo)	
		KTR150	—	—	
2	Cylinder head assembly	Cylinder head, valve and valve spring	37	37	
3	Cylinder block assembly	Cylinder block, main bearing cap and cylinder liner	1500	1500	
4	Gear case cover		106	106	
5	Timing gear case		80	80	
6	Oil pan		90	90	
7	Flywheel assembly	Flywheel and ring gear	99	99	
8	Flywheel housing		147	147	
9	Crankshaft assembly	Crankshaft	419	419	
10	Camshaft assembly	Camshaft, cam gear and thrust plate	33	33	
11	Piston and connecting rod assembly	Piston, piston ring, piston pin and connecting rod	21	21	
12	Oil pump		45	45	
13	Fuel injection pump		L row 47 R row 30	L row 47 R row 30	
14	Water pump		33	33	
15	Alternator		13	13	
16	Starting motor		20 x 2	20 x 2	
17	Air compressor		26	26	
18	After cooler		—	—	
19	Oil cooler		148	148	
20	Vibration damper		115	115	
21	Fan		123	123	
22	Filter bracket		127	127	
23	Front support		—	21	
24	Rear support		—	68	
25	Crank pulley		—	29	
26	Tension pulley assembly		—	38	

618001

VALVE SYSTEM



618001




F6166012

OIL FILTER


FULL FLOW FILTER (with safety valve)

SA12V170-1 (For D575A-2, D575A-2SD, HD1200-1, HD1200M-1)




F6166024

(For EG1100-1)



- 1. Filter bracket
- 2. Filter case [Cartridge]
- 3. Filter element [Cartridge]
- 4. Safety valve (for EG1100)
- a. Oil (from oil cooler)
- b. Oil (to engine each component)

F6166025



Section A-A

Full flow


- Filtration area: 0.84 m² x 4 sets

Safety valve (for EG1100)

- Cracking pressure (difference pressure):
0.2 ± 0.02 MPa (2.0 ± 0.2 kg/cm²)

618001

FUEL INJECTION NOZZLE



- 1. Nozzle holder
 - 2. Nozzle spring
 - 3. Nozzle
 - 4. Retaining cap
 - 5. Adjustment shim
- a. Fuel inlet
 - b. Return-fuel outlet

6162F134 A

618001


Fuel injection nozzle

- Maker: ZEXEL
- Type: Bosch DLL-S type, multiple hole type
- Nozzle cracking pressure:
29.4 MPa (300 kg/cm²)

Nozzle cracking pressure

- Adjustment of nozzle cracking pressure is adjusted by upper side shim (5) on nozzle spring (2) after removing retaining cap (4).


STRUCTURAL DRAWING (2/2)



1. Gear cover assembly
2. Motor assembly
3. Cable clamp
4. Cable assembly
5. Gear case assembly

618001

SA12V170-1 (For D575A-2SD)



SAE00246

- 1. Fan pulley
- 2. Fan belt
- 3. Crank pulley
- 4. Tension pulley
- 5. Grease nipple
- 6. Bracket


• Pulley outside diameter

Model	Pulley outside diameter (mm)		
	Fan pulley	Crank pulley	Tension pulley
D575A-2SD	480	221	157

CHECKING AND ADJUSTING ALTERNATOR BELT TENSION


1. Testing

Push the belt (4) at mid-point between the alternator and alternator drive pulley with a force of approx. 58.8 N (6 kg) and measure the distance that the belt sags.



2. Adjusting

- 1) Loosen alternator mounting bolts (2) and adjustment bolt (1).
- 2) Shift the alternator (3) upward with a bar and tighten adjustment bolt (1) while checking the belt tension. Then tighten alternator mounting bolt (2) to the proper belt tension.




618001

For D575A-2SD


1. Testing

Push a point midway between the alternator pulley and the drive pulley at a pressure of approx. 98.1 N (10 kg) and check deflection **a** of the belt. For details, see STANDARD VALUE TABLE.




2. Adjusting

- 1) Loosen bolts and nuts (1), (2) and (3).
- 2) Turn the turnbuckle (4) so that the belt tension is in standard value.
- 3) After adjusting, tighten bolts (1), (2) and (3) securely.



DATA FOR INJECTION PRESSURE ADJUSTMENT SHIMS

Engine model	Shim contour	Shim thickness (Range)	Shim thickness (Interval)
SA12V170-1	 <p>a = 4.5 mm b = 11.5 mm</p>	0.50 – 1.54 mm	0.02 mm

Part No.	Thickness (mm)	Part No.	Thickness (mm)
DK150523-5000	0.50	DK150523-7700	1.04
DK150523-5100	0.52	DK150523-7800	1.06
DK150523-5200	0.54	DK150523-7900	1.08
DK150523-5300	0.56	DK150523-8000	1.10
DK150523-5400	0.58	DK150523-8100	1.12
DK150523-5500	0.60	DK150523-8200	1.14
DK150523-5600	0.62	DK150523-8300	1.16
DK150523-5700	0.64	DK150523-8400	1.18
DK150523-5800	0.66	DK150523-8500	1.20
DK150523-5900	0.68	DK150523-8600	1.22
DK150523-6000	0.70	DK150523-8700	1.24
DK150523-6100	0.72	DK150523-8800	1.26
DK150523-6200	0.74	DK150523-8900	1.28
DK150523-6300	0.76	DK150523-9000	1.30
DK150523-6400	0.78	DK150523-9100	1.32
DK150523-6500	0.80	DK150523-9200	1.34
DK150523-6600	0.82	DK150523-9300	1.36
DK150523-6700	0.84	DK150523-9400	1.38
DK150523-6800	0.86	DK150523-9500	1.40
DK150523-6900	0.88	DK150523-9600	1.42
DK150523-7000	0.90	DK150523-9700	1.44
DK150523-7100	0.92	DK150523-9800	1.46
DK150523-7200	0.94	DK150523-9900	1.48
DK150523-7300	0.96	DK150530-0000	1.50
DK150523-7400	0.98	DK150530-0100	1.52
DK150523-7500	1.00	DK150530-0200	1.54
DK150523-7600	1.02		

618001

PERFORMANCE TEST CRITERIA

Engine model	Applicable machine	Test item	Specified value (fully equipped)	Engine speed (rpm)	Dynamometer (N (kg))
					Arm length 716 mm
SA12V170-1	D575A-2	Flywheel horsepower	783kW/1800rpm (1050HP/1800rpm)	1800 ± 5	6335 – 6707 (646 – 684)
		Max. torque	5001Nm/1300rpm (510kgm/1300rpm)	1300 ± 50	7266 – 7688 (741 – 784)
		High idling speed	2000 ± 50 rpm	2000 ± 50	—
		Low idling speed	650 ± 50 rpm	650 ± 50	—
	D575A-2SD	Flywheel horsepower	863kW/1800rpm (1157HP/1800rpm)	1800 ± 5	6590 – 6894 (672 – 703)
		Max. torque	5658Nm/1300rpm (577kgm/1300rpm)	1300 ± 50	7844 – 8384 (804 – 855)
		High idling speed	2000 ± 50 rpm	2000 ± 50	—
		Low idling speed	650 ± 50 rpm	650 ± 50	—
	HD1200-1	Flywheel horsepower	962kW/2100rpm (1290HP/2100rpm)	2100 ± 5	6237 – 6374 (636 – 650)
		Max. torque	5197Nm/1400rpm (530kgm/1400rpm)	1400 ± 100	7178 – 7325 (732 – 747)
		High idling speed	2350 ± 50 rpm	2350 ± 50	—
		Low idling speed	650 ± 50 rpm	650 ± 50	—

TROUBLESHOOTING

Points to remember when troubleshooting	20-102
Method of using troubleshooting chart	20-103
S- 1 Starting performance is poor (Starting always takes time)	20-108
S- 2 Engine does not start	
(1) Engine does not turn	20-109
(2) Engine turns but no exhaust smoke comes out (Fuel is not being injected)	20-110
(3) Exhaust smoke comes out but engine does not start (Fuel is being injected)	20-111
S- 3 Engine does not pick-up smoothly (Follow-up is poor)	20-112
S- 4 Engine stops during operations	20-113
S- 5 Engine does not rotate smoothly (Hunting)	20-114
S- 6 Engine lacks output (No power)	20-115
S- 7 Exhaust smoke is black (Incomplete combustion)	20-116
S- 8 Oil consumption is excessive (Or exhaust smoke is blue)	20-117
S- 9 Oil becomes contaminated quickly	20-118
S-10 Fuel consumption is excessive	20-119
S-11 Oil is in cooling water, or water spurts back, or water level goes down	20-120
S-12 Oil pressure caution lamp lights up (Drop in oil pressure)	20-121
S-13 Oil level rises	20-122
S-14 Water temperature becomes too high (Overheating)	20-123
S-15 Abnormal noise is made	20-124
S-16 Vibration is excessive	20-125

618001

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

S-13 Oil level rises

★ If there is oil in the cooling water, carry to troubleshooting for "Oil is in cooling water".

General causes why oil level rises

- Water in oil (cloudy white)
- Fuel in oil (diluted, and smells of diesel fuel)
- Entry of oil from other component

Legend


- : Possible causes (judging from Questions and check items)
- ⊙ : Most probable causes (judging from Questions and check items)
- △ : Possible causes due to length of use (used for a long period)
- : Items to confirm the cause.

Cause
Broken oil cooler core, O-ring
Defective nozzle holder sleeve
Broken cylinder head, head gasket
Clogged water pump breather hole, head gasket
Worn, damaged rear seal, defective seal
Defective nozzle holder
Defective part inside injection pump
Defective feed pump seal
Damaged liner O-ring, holes made by pitting
Cracks inside cylinder block


	Questions	Check items										Troubleshooting	Remedy			
		1	2	3	4	5	6	7	8	9	10					
	Confirm recent repair history															
	Degree of use of machine	Operated for long period		△		△	△						△			
	There is oil in radiator cooling water		⊙	○	○								○	○		
	Exhaust smoke is white		⊙							○						
	When engine is first started, drops of water come from muffler		○													
	Leave radiator cap open. When engine is run at idling, an abnormal number of bubbles appear, or water spurts back				○								○			
	Water pump breather hole is clogged with mud					○										
	When water pump breather hole is cleaned, water comes out						○									
	Oil level goes down in clutch, TORQFLOW transmission, or damper chamber							○								
	Engine oil smells of diesel fuel								○	○	○					
	Pressure-tightness test of oil cooler shows there is leakage		●													Replace
	Pressure-tightness test of cylinder head shows there is leakage			●												Replace
	When compression pressure is measured, it is found to be low				●											Replace
	When water pump is removed and inspected directly, it is found to be abnormal					●										Correct
	When rear seal is inspected directly, it is found to be abnormal						●									Replace
	When nozzle holder is removed and inspected directly, it is found to be abnormal							●								Correct
	Remove injection pump and check directly								●							Replace
	When feed pump is inspected directly, it is found to be abnormal									●						Replace
	Remove oil pan and check directly										●					Replace

618001


5) Disconnect drain tubes (7).



6) Lift off left bank turbocharger assembly (8).




7) Lift off right bank turbocharger assembly (9).



618001


29. Oil pan

- 1) Sling engine, set with oil pan horizontal on the block.
- 2) Remove mounting bolts then remove oil pan (1).




30. Air vent tubes

- Remove right and left bank air vent tubes (1) and (2).




31. Thermostat assembly

- 1) Remove bracket (1).
- 2) Remove tube (2).



- 3) Remove left and right thermostats (3).
- 4) Remove brackets (12).




618001

- 6) Push the piston and connecting rod assembly from the oil pan side with a wooden stick. Hold piston (3) in your hand and remove it from the cylinder head side. During removal, take care not to damage the inner surface of the liner with the connecting rod.

★ Rotate the crankshaft until the connecting rod does not contact balancer (4), then remove.

★ Keep the connecting rods and caps together, then store them with their corresponding bearings in order to avoid confusion during reassembly.




★ Disassemble the piston and connecting rod assembly as follows.

i) Remove snap ring.


ii) Pull out piston pin (2) while holding connecting rod (1) in your hand, and separate connecting rod from piston (3).

★ If the piston pin does not come out, leave in hot water, then try again.



iii) Remove piston rings (4) using piston ring tool E.

★ Store the piston, connecting rod, connecting rod bearings, piston rings, and piston pin for every cylinder.




58. Crankshaft

- 1) Turn the cylinder block, then set the crankshaft upward.

★ If necessary, measure the end play of the crankshaft with dial gauge (1) before removing the crankshaft.

- 2) Remove side bolts (1) of main bearing cap.




- 15) Coat the thread and washer of the side bolt (1) with engine oil (SAE #30).

★ Tighten the side bolt as follows.


 Side bolt:

Nm (kgm)


Step	Target	Range
1st	274.6 (28)	245.2—304.0 (25—31)
2nd	559.0 (57)	529.6—588.4 (54—60)
3rd	Loosen completely	
4th	186.3 (19)	156.9—215.7 (16—22)
5th	372.7 (38)	343.2—402.1 (35—41)
6th	559.0 (57)	529.6—588.4 (54—60)




- 16) Measuring starting torque of crankshaft
- Screw bolt in center bolt hole, and measure rotating weight of crankshaft.
 - ★ Standard value:
 - Max. 27.5 Nm (2.8 kgm)
 - ★ Check that the crankshaft rotates smoothly.




- 17) Measure end play of crankshaft with dial gauge ①.
- ★ End play: 0.140 — 0.32 mm
 - ★ Lever the area between the counterweight bolts when measuring the end play.
 - ★ If it is not within the standard value, adjust according to the maintenance standard.




- 18) Checking position of counterweight
- Set the counterweight of the cylinder No. to be measured in the position shown in the diagram on the right.
 - When measuring, use a feeler gauge to measure the clearance between the side surface of the counterweight and the finished surface of the cylinder block at two positions, A and B, of the counterweight.
 - Measure the counterweight of the other cylinders in the same way.
 - Standard clearance: Min. 1.1 mm
 - Difference between dimensions A and B:
 - Max. 0.6 mm




- 7) Align mark "G" of gear (13), then set in position.
- 8) Tighten bolt (12).


 **Mounting bolt:** 274.6 – 308.9 Nm
(28.0 – 31.5 kgm)




- 9) Coat thread of center bolt with engine oil (SAE30), and tighten bolts.


- 10) Install idler gear (3) for compressor, and tighten center bolts.

 **Mounting bolt:** 274.6 – 308.9 Nm
(28.0 – 31.5 kgm)




- 11) Align match mark "D", then install idler gear (2) for timer, and tighten bolts.

 **Mounting bolt:** 274.6 – 308.9 Nm
(28.0 – 31.5 kgm)





- 12) Align match mark "E", then install idler gear (1) for timer and tighten bolts.

 **Mounting bolt:** 274.6 – 308.9 Nm
(28.0 – 31.5 kgm)




- 5) Align pointer (1) with "TOP R1" line on vibration damper, and install.

★ Set dial gauge (1) in position, rotate the crankshaft in the normal direction to set the crankshaft where the piston of right No. 1 cylinder is at the highest position, then align with the "TOP R1" line.





24. Piston cooling valve

- Assemble piston cooling valve as follows.
 - i) Assemble plunger (4) and spring (3) in body (5), then fit O-ring and install plug (2).
- ★ Check that there is no dirt or dust between the plunger and body when assembling.




- 1) Fit grommet to cooling valve and oil cooler mounting plate, and install piston cooling valve (1).

 Mounting bolt: $65.7 \pm 6.8 \text{ Nm}$
($6.7 \pm 0.7 \text{ kgm}$)




25. Oil cooler assembly


- Assemble oil cooler as follows.
 - i) Fit gasket and O-ring to cover (3), then install cores (8), (7) and (6) and tighten with nuts.



- 2) Fit O-ring and insert water manifold (2) in rocker housing.


 O-ring: Rubber lubricant (FR-1) or soapy water.


★ Never coat the O-ring with oil. When assembling, coat with rubber lubricant or soapy water.



P6164261

- 3) Install rocker housing (1).

 Mounting bolt: $98.1 \pm 4.9 \text{ Nm}$
($10.0 \pm 0.5 \text{ kgm}$)




P6164087

34. Push rod

Install push rod (1).

★ Check that the push rod is fitted securely in the cam follower.




P6164086

35. Rocker arm assembly

- Assemble the rocker arm as follows.
 - i) Align shaft hole of bushing, and knock in rocker arm (7).
 - ii) Assemble adjustment screw (6) and locknut (5) to rocker arm.
 - iii) Coat rocker shaft with engine oil (SAE #30), and set so that end with plug is facing left (EX end).




P6164084



P6164085

618001


- 2) Install brackets (1) for exhaust pipe.



F6166206

52. Exhaust manifold

- 1) Install gaskets to exhaust plates (1) of left and right banks.
 - ★ Stick the gasket to the plate.
- 2) Tighten exhaust shield plate (1) to rocker case temporarily.
 - ★ Set the gasket surface facing the rocker case when installing.




P6164275

- 3) Fit gasket to right bank exhaust manifold, then tighten (1) – (8) in order.


- Manifold connection:
Anti-friction compound (LM-P)
- Mounting bolt:
Anti-friction compound (LM-P)

- ★ After installing manifold, tighten to the specified torque in the tightening order. For the other manifolds, tighten after installing all.
- ★ Order for tightening exhaust manifold



P6164053

- ★ Heat resistant bolts are used (they have a 660 mark on the head), so be careful to keep the tightening torque.



F6166207


Mounting bolts:

1st step	49.0 ± 9.8 Nm (5 ± 1 kgm)
2nd step	83.3 ± 4.9 Nm (8.5 ± 0.5 kgm)

F6166115-1A

618001


KTR150 (For EG1100-1)



F6166056 Unit: mm


No.	Check item	Criteria				Remedy	
1	End play	Standard		Repair limit		Replace parts	
		0.08 — 0.13		0.18			
2	Radial play	0.25 — 0.43		0.60		Replace parts	
3	Outside diameter of journal bearing. Inner diameter of center housing.	Standard size	Tolerance		Repair limit		
			Shaft	Hole	Shaft	Hole	
		30	-0.060 -0.080	+0.020 0	29.89	30.04	
4	Inner diameter of journal bearing. Outside diameter of wheel shaft.	20	-0.030 -0.045	+0.015 0	19.95	20.05	Replace
	Curvature of wheel shaft	Repair limit: 0.010 (total deflection of indicator)					
5	Thickness of thrust bearing	Standard size	Tolerance		Repair limit		
			Shaft	Hole	Shaft	Hole	
		6	-0.08 -0.11	+0.02 0	5.86	6.04	
6	Thickness of seal ring	3	-0.08 -0.10	-0.03 -0.04	2.85	3.05	
7	Clearance between blower housing and impeller	Tolerance: (min.) 0.20				Replace parts	
8	Tightening torque of blower impeller locknut	93.2 ± 4.9 Nm {9.5 ± 0.5 kgm}				Tighten	
9	Tightening torque of insert bolt	66.2 ± 7.4 Nm {6.75 ± 0.75 kgm}					
10	Tightening torque of bolt	56.4 ± 2.5 Nm {5.75 ± 0.25 kgm}					
—	Tightening torque of V-band locknut	8.8 ± 1.0 Nm {0.9 ± 0.1 kgm}					

CRANKSHAFT



Tightening order of vibration damper mounting bolt

F6166064




F6166065

Unit: mm

No.	Check item	Criteria			Remedy
		Size	Standard size	Tolerance	
1	Outside diameter of main journal	S.T.D.	162.00	0 -0.020	161.98
		0.25 US	161.75		161.73
		0.50 US	161.50		161.48
		0.75 US	161.25		161.23
		1.00 US	161.00		160.98
	Main journal roundness	Standard		Repair limit	Repair or replace
		0 - 0.010		0.010	

CYLINDER HEAD




618001

F6164091


1. Valve guide
2. Crosshead guide
3. Fuel injection nozzle sleeve
4. O-ring
5. Cylinder head
6. O-ring
7. Pushrod tube
8. Valve seat insert

4. Calking the sleeve seat face

- 1) Fit the sleeve seat with sleeve holder E.

 Tightening torque for sleeve holder:
19.6 Nm {2 kgm}.


- 2) Install punch bushing F and insert sleeve driver D.
- 3) Place support ③ under the cylinder head to allow the bolt of the sleeve holder to move out.
- 4) Hit the sleeve driver with a hammer to calk the seat surface.
★ Lightly hit with a hammer several times.
- 5) Remove the sleeve holder and punch bushing.



6162F511

5. Roll-fit the bottom hole of sleeve


- Using sleeve rolling tool G, roll-fit bottom hole (P) of sleeve (1).
 - ★ Adjust the roll-fitting height with bearing collar ④ so that the shaft of the rolling tool will protrude a little from the bottom hole.
 - ★ Install the rolling tool to a radial drilling machine or upright drilling machine to roll-fit with its own weight.
 - ★ Rotating speed: 200 to 300 rpm



6162F512

6. Roll-fitting the taper section of sleeve

- Using sleeve expander H, roll-fit the taper section of the sleeve.
 - ★ Set the roll-fitting amount with stopper ⑤ of the expander.
 - ★ Install the expander to a radial drilling machine or upright drilling machine to roll-fit with its own weight.
 - ★ Rotating speed: 200 to 300 rpm



6162F513

618001

2. Grinding counterbore

After grinding the top surface of the cylinder block, measure the depth of the counterbore. If it is not within the standard dimension, or if there are blackened portions on the cylinder liner contact surface of the counterbore (particularly in the front-to-rear direction), or there is speckled wear, and these portions extend over more than half of the contact width of the deck, correct the counterbore depth L within the repair limit. After correcting, if the counterbore depth is within 14.05 — 15.525 mm, combine with shims and adjust so that the liner protrusion is 0.07 — 0.15 mm.


- ★ Counterbore depth L:
Standard dimension $14 + \begin{matrix} 0.05 \\ 0 \end{matrix}$ mm
Repair limit: 15.525 mm
- ★ Protrusion of cylinder liner l :
Standard value: 0.07 — 0.15 mm
- ★ Roughness of counterbore: Max. 12.5S
- ★ Machined shape: In accordance with detail diagram for portion a

For the extra amount for counterbore depth L, decide a machining amount that will bring the protrusion of the cylinder liner within the standard value.

When grinding within the repair limit in cases where the counterbore depth L exceeds the standard dimension, set the machining amount so that one shim can be used for each cylinder as shown in the table below.


[Reference] Adjustment shims for counterbore depth
Unit: mm

Part No.	T	t	Weight (kg)	Remarks
6162-29-2260	1.50	0.025	0.004	
6162-29-2250	0.80	0.025	0.002	
6162-29-2240	0.50	0.025	0.001	
6162-29-2230	0.26	0.025	0.001	
6162-29-2220	0.20	0.020	0.001	
6162-29-2210	0.16	0.016	0.001	




Detail b

F6164120



Detail a

F6164121



Shim

Unit: mm



F6164122

618001

2) When using a work clamp jig for polishing
(When a special polishing machine is not available)

Use a work clamp jig such as shown in the diagram on the right.

i) Use a crankshaft grinding machine under the following polishing conditions.


Paper: No. 800

Machining oil: Honing oil

Work speed: 40 rpm

ii) The polishing time for one journal is approx. 6 minutes. Move the clamp the amount of play of the clamp and journal width (approx. 5 mm), and move up and down the journal in the axial direction. After completing the honing of one journal, replace the paper with new paper.


When honing the pin journal, it is safer to carry out the work with the pin journal at the rotation center.



F6164133

3) Assembly of work clamp jig and method of use

i) Jig for pin journal and jig for main journal
Assemble the clamp jig as shown in the diagram on the right. For details of the component parts, see the drawings on separate pages.



F6164134

618001

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL