

SHOP MANUAL

4D92E, 4D94E, 4D98E **DIESEL ENGINE**

ENGINE MODEL

MACHINE MODEL

4D92E

FD10/14/15/18-16

622001 and up

4D94E

FD20/23/25/28/30-12

538001 and up

4D98E

FD20H/25H/30H-12

538001 and up

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below




- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

0.3 Sectional View of Engine 2

Horizontal Sectional View of 4D92E/4D94E/4D98E Engine



1.5 Oversize pistons

The oversize pistons (including rings) in the sizes listed below are available for measuring cylinders and pistons during engine overhauling. (See 3.4, Cylinder Blocks.)


| 1. 4D92E | Standard | 0.25S | 0.50S | 1.00S |
|------------------------|----------------|----------------|----------------|----------------|
| Piston assembly | YM129904-22080 | YM129904-22900 | YM129904-22920 | YM129904-22940 |
| Piston | YM129904-22010 | YM129904-22700 | YM129904-22720 | YM129904-22740 |
| Ring assembly | YM129904-22050 | YM129904-22950 | YM129904-22970 | YM129904-22990 |
| 1st ring | YM129904-22100 | YM129904-22750 | YM129904-22850 | YM129904-22650 |
| 2nd ring | YM129904-22110 | YM129904-22760 | YM129904-22860 | YM129904-22660 |
| Oil ring | YM129904-22200 | YM129904-22770 | YM129904-22870 | YM129904-22670 |
| Applicable head gasket | YM129901-01331 | YM129901-01331 | YM129901-01331 | YM129901-01331 |

| 2. 4D94E | Standard | 0.25S | 0.50S | 1.00S |
|------------------------|---------------------------|----------------|----------------|----------------|
| Piston assembly | YM129901-22080 | YM129901-22900 | YM129901-22920 | YM129901-22940 |
| Piston | YM129901-22010 | YM129901-22700 | YM129901-22720 | YM129901-22740 |
| Ring assembly | YM129901-22050 | YM129901-22950 | YM129901-22970 | YM129901-22990 |
| 1st ring | YM129901-22100 | YM129901-22750 | YM129901-22850 | YM129901-22650 |
| 2nd ring | YM129900-22110 | YM129900-22760 | YM129900-22860 | YM129900-22660 |
| Oil ring | YM129900-22160 | YM129900-22770 | YM129900-22870 | YM129900-22670 |
| Applicable head gasket | YM129901-01330 (Standard) | | YM129901-01340 | |

| 3. 4D98E | Standard | 0.25S | 0.50S | 1.00S |
|------------------------|----------------|----------------|----------------------|-------|
| Piston assembly | YM129903-22080 | YM129903-22900 | No setting specified | |
| Piston | YM129903-22010 | YM129903-22700 | | |
| Ring assembly | YM129903-22050 | YM129903-22950 | | |
| 1st ring | YM129902-22100 | YM129903-22750 | | |
| 2nd ring | YM129902-22110 | YM129902-22760 | | |
| Oil ring | YM129902-22160 | YM129902-22770 | | |
| Applicable head gasket | YM129903-01330 | YM129903-01330 | | |

b) Measurement of seat width



| mm (in) | | Standard | Limit |
|---------|---------|----------------|----------------|
| Width | Intake | 1.3 (0.051) | 2.0 (0.079) |
| | Exhaust | 2.2 (0.087) | 3.0 (0.118) |



(ii) Intake/exhaust valve and valve guide

- 1) When the intake/exhaust valve shaft is bent or greatly worn, replace it together with the valve guide.
- 2) Measurement of the outer diameter of the valve shaft and inner diameter of the valve guide


| mm (in) | | Standard | Limit |
|---------|------------|------------------------------------|------------------|
| Intake | Valve O.D. | 7.965 – 7.980 (0.3138 – 0.3144) | 7.915 (0.312) |
| | Guide I.D. | 8.015 – 8.030 (0.3158 – 0.3164) | 8.100 (0.319) |
| | Clearance | 0.035 – 0.065 (0.001 – 0.003) | 0.185 (0.007) |
| Exhaust | Valve O.D. | 7.955 – 7.970 (0.313 – 0.314) | 7.905 (0.311) |
| | Guide I.D. | 8.015 – 8.030 (0.3158 – 0.3164) | 8.100 (0.319) |
| | Clearance | 0.045 – 0.075 (0.002 – 0.003) | 0.195 (0.008) |



(iii) Valve spring

- 1) Replace it if it has any abnormality such as damage, corrosion.
- 2) Measurement of free length, inclination, and spring tension


| | Standard | Limit |
|---|------------------------|----------------|
| Free length mm (in) | 47.5 (1.872) | - |
| Inclination mm (in) | - | 1.2 (0.047) |
| 1 mm (0.04 in) compression load N (kgf)<lb> | 22.1 (2.257)<4.977> | - |




(iv) Locker arm, shaft, spring, push rod, valve head protector, and valve clearance adjusting screw

- 1) Replace them if they have any abnormality such as damage, corrosion. Pay additional attention to the contact area between the locker arm and valve head protector, corrosion and damage of the spring, bent of the push rod, and contact of both ends.

| Bent of Push Rod | |
|------------------|----------------------|
| Standard mm (in) | 0.03 (0.001) or less |



(2) Disassembly and Assembly of Cylinder Block**(3) Disassembly Procedure**

Disassemble in order of the numbers shown in the drawing.

- ① Take the cylinder head disassembly procedural steps ① through ⑪.
- ② Take the gear train disassembly procedural steps ① through ⑫.
- ③ Remove the oil pan. (Note 1)
- ④ Remove the lubricant suction pipe.
- ⑤ Remove the piston W/rod. (Note 2)
- ⑥ Remove the flywheel housing. (Note 3)
- ⑦ Remove the metal cap. (Note 4)
- ⑧ Remove the crank shaft. (Note 5)
- ⑨ Remove the tappet.
- ⑩ Remove the piston pin and ring. (Note 6)
- ⑪ Remove the oil filter assembly. (Note 7)
- ⑫ Remove the oil seal from the flywheel housing. (Note 8)

(4) Assembly Procedure



Assemble in the reverse order of disassembly.

(6) Honing

- 1) When satisfactory repair cannot be done only by honing, judging from the conditions of local eccentric wear, damage, and so on, perform boring first.
- 2) Prepare a flexible hone (code No. 129400-92430), electric drill, and honing liquid (mixed liquid of the engine oil and light oil).
- 3) Apply the honing liquid to the flexible hone. Running the electric drill at 300 to 1,200 rpm, insert it into the cylinder bore and move up and down the flexible hone to hone the cylinder bore at 30 to 40°.

IMPORTANT

- 1) Do not run the drill at a higher rpm because it will lead to a breakage.
- 2) Do not put in/out the flexible hone in its stopping state. The cylinder will be damaged.
- 3) Each grinding allowance should be about 1/1,000 mm (1/25,000 in).




(7) Replacement of Cam Shaft Bushing and Connecting Rod Bushing

Replace them by using their respective special purpose tools.

(8) Replacement of Oil Seal

- 1) Draw out the used oil seal.
- 2) Use an oil seal inserting tool to set a new oil seal.
- 3) Apply lithium grease.



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below




- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL


FUEL INJECTION/SPEED CONTROLLER SYSTEM

| | |
|--|-------------|
| 6.1 Fuel Injection Pump/Speed Controller System | 6- 4 |
| 6.2 Fuel Injection Nozzle | 6-26 |
| 6.3 Fuel Filter | 6-29 |




Feed Pump(Vane Type)

The feed pump is to pump up the fuel oil from the tank and feeds it into the pump chamber. The feed pump consists of the rotor, blades, and liner. The rotor is driven by the drive shaft. The liner is set eccentrically to the rotation center of the rotor and there are four blades between the rotor and liner. When the rotor starts rotating, the blades are pushed against the inner wall of the liner by a centrifugal force and the volume of each chamber changes according to rotation. Therefore, when the volume of this chamber increases, the fuel oil is pumped up from the fuel tank, and when it decreases, the fuel oil is compressed and fed into the pump chamber.




Regulating Valve

The regulating valve is to regulate the oil feed pressure of the feed pump so that the fuel oil pressure in the pump chamber will be always within a specified pressure range. When the rpm of the injection pump increases and the oil feed pressure of the feed pump becomes higher, the fuel oil compresses the regulating valve spring to push up the piston. Then, the fuel oil is returned to the intake side of the feed pump as indicated by the arrows in the left figure. Therefore, the pump chamber internal pressure can be regulated by changing the setting force of the regulating valve spring.



The left figure shows an example of the relations between the pump's rpm and pump chamber internal pressure. A hydraulic timer controls the injection timing by directly making use of this pump chamber internal pressure.

When Controlling Full-load Maximum Rotation



VE2015


When the accelerator pedal is fully pressed and the control lever comes into contact with the maximum speed stopper bolt, the tension of the governor spring is maximized and the tension lever is fixed at a position where the press-fit pin M3 comes into contact with the pump housing.

When this is done, the idle spring is also completely contracted, the start lever and tension lever are integrated at the point-A, and the control sleeve is kept at a full-load position. At this time, the flyweight is pushed by the governor sleeve and fully closed.

STARTING SYSTEM


| | |
|---|------|
| 7.1 Structure and Function | 7- 2 |
| 7.2 Starter Component Parts List and Drawing | 7- 4 |
| 7.3 Disassembly and Assembly | 7- 5 |
| 7.4 Maintenance and Inspection | 7- 8 |
| 7.5 Pinion Push-out Amount by Magnetic Switch | 7-11 |
| 7.6 Maintenance Standard | 7-12 |
| 7.7 Troubleshooting (Starter) | 7-13 |
| 7.8 Specification | 7-14 |

- (c) Checking brush movement
When the brushes do not work properly, check whether or not the brush holder is bent or its slideway is dirty. If necessary, repair and clean.
- (d) Checking for continuity between the brush holder and grounding.
Check for continuity between the insulated brush holder (+) and brush holder assembly base (-, grounding). If there is continuity, replace the brush holder, because it is grounded.



Brush Holder Grounding Test

7.5 Pinion Push-out Position by Magnetic Switch




Dimension "ℓ"
0.3 ~ 1.5 mm (0.012 ~ 0.059 in)

Dimension Measurement

$\ell=0.3 - 1.5 \text{ mm (0.012 - 0.059 in)}$

- When the pinion is pushed out by the magnetic switch, a pinion's stroke ℓ in the thrust direction (gap between a pinion stopper and clutch inner) is normally as mentioned above. Using slide calipers or depth gauge, measure the difference between the nose position of the pinion when the plunger is sucked in and the pinion is pushed out by the shift lever, and when the pinion is pulled out in the arrow-indicated direction by fingers. This becomes the dimension ℓ .
- When the dimension ℓ is beyond the above-mentioned limits, insert an adjusting plate as shown in the figure. There are two kinds of adjusting plates; 0.5 mm (0.02 in) and 0.8 mm (0.03 in) thick.



Adjusting Plate
(0.5 mm, 0.8 mm)
(0.02 in, 0.03 in)

Adjusting Plate Inserting Position




Fig.11

- c) Rotor coil continuity test
Use a tester to check for continuity between the slip rings.

<When there is no continuity>
The rotor coil is disconnected.
Replace the rotor.

Rotor coil resistance: 3.45Ω at 20°C




Fig.12

- d) Rotor coil insulation test
Use a tester to check for continuity between the slip ring and rotor core or shaft.

<When there is continuity>
The rotor coil is short-circuited.
Replace the rotor.




Fig.13

- e) Checking the ball bearing
Check the ball bearing on the rear side. If it does not rotate smoothly or emits an abnormal sound, replace the ball bearing.












Fig.14

(3) Stator

- a) Stator coil continuity test
Use a tester to check for continuity between each terminal of the stator coil.

<When there is no continuity>
The stator coil is disconnected.
Replace the stator.

Stator coil resistance:
0.108Ω/phase at 20°C
0.216Ω between U and V

| No. | Tool Name | Application | Sketch | |
|-----|------------------------|--|--|--|
| 10 | Torque wrench | This is used to tighten bolts and nuts by a specified torque. |  | |
| 11 | Thickness gauge | This is to measure a gap between a ring and a ring groove, that of a shaft joint, and so on. |  | |
| 12 | Cap tester | This is to check for a leak of pure water. |  | |
| 13 | Battery coolant tester | This is to check density of an antifreezing solution and the charging condition of battery liquid. |  | |
| 14 | Nozzle tester | This is to check the spraying condition and injection pressure of the fuel injection valve. |  | |
| 15 | Digital thermometer | This is to measure a temperature at each part. |  <p>Detecting Part</p> | |
| 16 | Tachometer | Contact type | This is brought into contact with the mortise of the rotating shaft to measure rpm. |  |
| | | Photoelectric type | Affix a reflection mark to the outer circumference of the rotating part to measure rpm. |  <p>Rotating Part</p> <p>Reflection Mark</p> |

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL