

SHOP MANUAL

CK20-1

CRAWLER SKID-STEER LOADER

SERIAL NUMBER

CK20-1 F00003 and up

KOMATSU
Utility


CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below




- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL




2. TIGHTENING TORQUE FOR NUTS OF FLARED



Use these torques for nut part of flared.

Thread diameter of nut part (mm)	Width across flats of nut part (mm)	TIGHTENING TORQUE	
		kgm	Nm
1/2" - 20	17	2.6±0.5	25.5±4.9
9/16" - 18	17	4±0.5	39.2±4.9
3/4" - 16	22	6.7±2	65.7±19.6
7/8" - 14	27	8±2	78.5±19.6
1.1/16 - 12	32	9.7±3	95.15±29.4
1.5/16 - 12	38	17±3	166.7±29.4
1.5/8 - 12	50	20±5	196.2±49
22	27	8±2	78.5±19.6
33	41	20±5	196.2±49



Use these torques for nut part of flared.

Thread diameter of nut part (mm)	Width across flats of nut part (mm)	TIGHTENING TORQUE	
		kgm	Nm
9/16" - 18	17	2.3–2.5	23–25
11/16" - 16	22	3.4–3.9	33–38
13/16" - 16	24	5.2–5.8	51–57
1" - 14	30	8.2–9.2	80–90
1.3/16 - 12	36	12.2–13.3	120–130
1.7/16 - 12	41	15.3–17.3	150–170
1.11/16 - 12	50	18.4–20.4	180–200
2" - 12	57	20.4–24.4	200–240


From Nm to kgm

1 Nm = 0.102 kgm

	0	1	2	3	4	5	6	7	8	9
0	0	0.102	0.204	0.306	0.408	0.510	0.612	0.714	0.816	0.918
10	1.020	1.222	1.224	1.326	1.428	1.530	1.632	1.734	1.836	1.938
20	2.040	2.142	2.244	2.346	2.448	2.550	2.652	2.754	2.856	2.958
30	3.060	3.162	3.264	3.366	3.468	3.570	3.672	3.774	3.876	3.978
40	4.080	4.182	4.284	4.386	4.488	4.590	4.692	4.794	4.896	4.998
50	5.100	5.202	5.304	5.406	5.508	5.610	5.712	5.814	5.916	6.018
60	6.120	6.222	6.324	6.426	6.528	6.630	6.732	6.834	6.936	7.038
70	7.140	7.242	7.344	7.446	7.548	7.650	7.752	7.854	7.956	8.058
80	8.160	8.262	8.364	8.466	8.568	8.670	8.772	8.874	8.976	9.078
90	9.180	9.282	9.384	9.486	9.588	9.690	9.792	9.894	9.996	10.098
100	10.200	10.302	10.404	10.506	10.608	10.710	10.812	10.914	11.016	11.118
110	11.220	11.322	11.424	11.526	11.628	11.730	11.832	11.934	12.036	12.138
120	12.240	12.342	12.444	12.546	12.648	12.750	12.852	12.954	13.056	13.158
130	13.260	13.362	13.464	13.566	13.668	13.770	13.872	13.974	14.076	14.178
140	14.280	14.382	14.484	14.586	14.688	14.790	14.892	14.994	15.096	15.198
150	15.300	15.402	15.504	15.606	15.708	15.810	15.912	16.014	16.116	16.218
160	16.320	16.422	16.524	16.626	16.728	16.830	16.932	17.034	17.136	17.238
170	17.340	17.442	17.544	17.646	17.748	17.850	17.952	18.054	18.156	18.258
180	18.360	18.462	18.564	18.666	18.768	18.870	18.972	19.074	19.176	19.278
190	19.380	19.482	19.584	19.686	19.788	19.890	19.992	20.094	20.196	20.298

LOWER IDLER ROLLER


2-LIP TYPE



RKS04180

- | | |
|-------------|--------------|
| 1. Roller | 4. Shaft |
| 2. Shoulder | 5. Gasket |
| 3. Bushing | 6. Snap ring |

3-LIP TYPE




RKS04190

- | | |
|-------------|--------------|
| 1. Roller | 4. Shaft |
| 2. Shoulder | 5. Gasket |
| 3. Bushing | 6. Snap ring |

**HST PUMP LPV45 +45 (STANDARD FLOW AND HIGH FLOW)
FUNCTION**

- The rotation and torque transmitted to the pump shaft is converted into hydraulic energy, and pressurised oil is discharged according to the load.
- It is possible to change the discharge amount by changing the swash plate angle (plus, zero and minus)




- | | | |
|-------------------|-------------------|-------------------------|
| 1. Shaft | 6. Slider | 11. Main bearing |
| 2. Case | 7. Shoe | 12. Spline |
| 3. Cradle bearing | 8. Piston | 13. Sub bearing |
| 4. Rocker cam | 9. Cylinder block | 14. Charge pump |
| 5. Control piston | 10. Valve plate | 15. Work equipment pump |

STRUCTURE

- Cylinder block (9) is supported to shaft (1) by a spline (12), and shaft (1) is supported by the front and rear bearings (11), (13).
- The tip of piston (8) is a concave ball, and shoe (7) is caulked to it to form one unit. Piston (8) and shoe (7) form a spherical bearing.
- Rocker cam (4) has flat surface **A**, and shoe (7) is always pressed against this surface while sliding in a circular movement. There is a cradle bearing (3) between cradle and rocker cam (4) which is secured to the case. Rocker cam (4) sways on cradle bearing.
- Piston (8) carries out relative movement in the axial direction inside each cylinder chamber of cylinder block (9).
- The cylinder block seals the pressurised oil to valve plate (10) and carries out relative rotation. This surface is designed so that the oil pressure balance is maintained at a suitable level. The oil inside each cylinder chamber of cylinder block (9) is sucked in and discharged through valve plate (10).

CHARGE PUMP




1. Slide plate
2. Coupling
3. Shaft
4. Outer ring
5. Case
6. Inner roter
7. Outer roter

FUNCTION


- HST charge pump is built-in the HST pump and driven with HST pump at the same time.
- The pressurised oil generated by the charge pump is sent to safety valve in the charge circuit and to AS valve.
- Charge pump sucks oil from hydraulic tank.

SPECIFICATIONS


- Type: trochoid pump
- Theoretical delivery: 32 cm³/rev




Section A - A




Section B - B



Section C - C



Section AA-AA



Section BB-BB

- 1. Main relief valve
- 2. Suction valve (bucket bottom side)
- 3. Plug
- 4. Plug
- 5. Series - parallel circuit switching valve
- 6. Spool (lift arm)

- 7. Spool (bucket)
- 8. Spool (attachment)
- 9. Flow divider
- 10. Check valve (circulating circuit)
- 11. Combination circulating valve
- 12. Leveling circulating valve

RKS04400

CLSS

1. OUTLINE


Features

CLSS stands for Closed centre Load Sensing System, and has the following characteristics.

- Controlability, not influenced by load;
- Controllable digging force at fine control range;
- Easy simultaneous operation by spool opening proportional flow dividing function.


2. PRESSURE COMPENSATION CONTROL

- A valve (pressure compensation valve) is installed to the inlet port side of the control valve to balance the load. When there is compound operation of the actuators, this valve acts to make pressure difference ΔP constant for the upstream flow (inlet port) and downstream flow (outlet port) of the notch of each spool. In this way, the flow of oil from the pump is divided in proportion to area of opening **S1** and **S2** of each valve.



RKS00691


**SOLENOID VALVE ST3
OVERRIDE CONTROL**




RKS04490

1. SV4 - Backhoe boom lockout


- a. T port - To transmission
- b. Port 1 - From transmission
- c. T1 port - Boom lockout cylinder




Section A - A




Section B - B



Section C - C



Section D - D



Section E - E

RKS00810

- 1. Spool
- 2. Metering spring
- 3. Centering spring
- 4. Piston
- 5. Disc

- 6. Nut
- 7. Joint
- 8. Cover
- 9. Stopper
- 10. Body

3. During fine control (when the lever is returned) (fine control → neutral)

When disc (5) starts to be returned, spool (1) is pushed up by the force of centering spring (3) and the pressure at port **P1**.

When this happens, fine control hole **f** is connected to drain chamber **D** and the pressure oil at port **P1** is released.

If the pressure at port **P1** drops too far, spool (1) is pushed down by metering spring (2), and fine control hole **f** is shut off from drain chamber **D**.

At almost the same time, it is connected to pump pressure chamber **PP**, and the pump pressure is supplied until the pressure at port **P1** recovers to a pressure that corresponds to the lever position.

When control valve spool returns, oil goes back into port **D**, through fine control hole **f**, into port **B** of the spool opposite the active spool. Oil flows through port **P2** and into port **B** to maintain the fill level (Fig. 3).






Fig. 3

RKS00840

ELECTRICAL DIAGRAM (FRAME LINE STANDARD) (2/3)



ELECTRICAL DIAGRAM (CABIN LINE OPTIONAL) (1/7)




RKS03310

ELECTRICAL DIAGRAM (TOP-CABIN LIGHT LINE HOMOLOGATION) (2/2)

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18

----- = Parts not included in the wiring



RKS03550

COMPONENTS

- GND4** Ground ø6 terminal
- GND6** Ground ø8 terminal
- H1** Beacon light
- H4** Left low beam
- H5** Left side light
- H6** Right low beam
- H7** Right side light
- H8** Left rear lamp
- H9** Right rear lamp
- H10** Left rear work light
- H11** Right rear work light
- H12** Plate light
- HA2** Horn
- X108** Front low beam 2 way connector

- X109** Front low beam 2 way connector
- X110** Rear work lights 2 way connector
- X111** Rear work lights 2 way connector
- X115** Front traffic lights 1 way connector
- X116** Front traffic lights 1 way connector
- X117** Front traffic lights 1 way connector
- X118** Front traffic lights 1 way connector
- X119** Front traffic lights 1 way connector
- X120** Front traffic lights 1 way connector
- X121** Rear traffic lights 1 way connector
- X122** Rear traffic lights 1 way connector
- X123** Rear traffic lights 1 way connector
- X124** Rear traffic lights 1 way connector
- X125** Rear traffic lights 1 way connector
- X126** Rear traffic lights 1 way connector

- X127** Rear traffic lights 1 way connector
- X128** Rear traffic lights 1 way connector
- X129** Plate light connector
- X130** Plate light connector
- XP1** Current intake 12v, beacon light
- XP1A** Current intake 12v, beacon light

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

**PAGE INTENTIONALLY
LEFT BLANK**

6 - After you have loosened the check nuts for the pump (6) and the screws (7), rotate the injection pump (5) outwards or towards the engine.

- To ADVANCE injection, rotate pump (4) outwards.
- To DELAY injection rotate the pump (4) towards the cylinder block.


★ Check the extent of the movement on the scale (8).

7 - Lock the nuts (6) that fasten the pump to its block.

★ After adjustment of the fuel injection timing:

8 - Connect the fuel delivery tubes (5) to the pump and replace the clamp (3).


9 - Bleed any air from the fuel circuit.




- **Pressure adjustment at high pressure**

1 - Loosen the nut (3), and adjust the operating pressure of the AS valve (with the engine at 2690 ± 30) using the following procedure:

- To INCREASE pressure, turn the screw (4) in a CLOCKWISE direction.
- To REDUCE pressure, turn the screw (4) in a COUNTER-CLOCKWISE direction.
- ★ Rotating the screw by one turn (4) will vary pressure by 2.55 bar.



3 - Tighten the nut (3) and check that the working pressure remains within permissible limits.


 Nut: 34.3–58.8 Nm

30 REMOVAL AND INSTALLATION

HOW TO READ THE MANUAL	3	FUEL TANK	31
PRECAUTIONS TO BE TAKEN WHILE WORKING	4	• Removal.....	31
ENGINE HOOD.....	5	• Installation.....	32
• Removal	5	ENGINE-PUMP GROUP	33
• Installation	5	• Removal.....	33
CAB	6	• Installation.....	36
• Dump.....	6	COMPLETE HYDRAULIC PUMP	37
• Removal	10	• Removal.....	37
• Installation	13	• Installation.....	39
BATTERY	14	GEAR PUMP.....	40
• Removal	14	• Removal.....	40
• Installation	14	• Installation.....	40
STARTING MOTOR	15	ENGINE-PUMP COUPLING	41
• Removal	15	• Removal.....	41
• Installation	15	• Installation.....	41
ALTERNATOR	16	CONTROL VALVE.....	42
• Removal	16	• Removal.....	42
• Installation	16	• Installation.....	42
AIR INTAKE FILTER	17	PPC VALVES.....	43
• Removal	17	• Removal.....	43
• Installation	17	• Installation.....	43
MUFFLER	18	LIFT CYLINDER	44
• Removal	18	• Removal.....	44
• Installation	19	• Installation.....	44
VALVE COVER	20	BUCKET CYLINDER	45
• Removal	20	• Removal.....	45
• Installation	20	• Installation.....	46
INJECTORS.....	21	WORK EQUIPMENT CYLINDERS	47
• Removal	21	• Disassembly	47
• Installation	21	• Assembly	49
INJECTION PUMP.....	22	COMPLETE WORKING EQUIPMENT	53
• Removal	22	• Removal.....	53
• Installation	24	• Installation.....	54
CYLINDER HEAD.....	25	WORKING EQUIPMENT SUPPORT FRAME	55
• Removal	25	• Removal.....	55
• Installation	27	• Installation.....	55
COOLANT LIQUID PUMP	28	HEATING SYSTEM BLOWER FAN	56
• Removal	28	• Removal.....	56
• Installation	28	• Installation.....	57
RADIATOR GROUP	29	TRACK.....	58
• Removal	29	• Removal.....	58
• Installation	30	• Installation.....	59


With front door

7 - Remove the straps (11) retaining the hoses.




8 - Disconnect the heating system's delivery (12) and return (13) hoses from the engine and drain any engine coolant from the hoses.


- ★ Mark the hoses to avoid mixing them during installation.



9 - Remove strap (14) and disconnect hose (16) from tank (15).



10 - Disconnect the accelerator lever cable (18) from the engine (17). [*2]



INJECTORS


Removal

- 1 - Remove air suction filter (1).
(For details, see "AIR INTAKE FILTER".)
- 2 - Remove the valve cover.
(For details, see "VALVE COVER").

- 3 - Loosen the five screws (1) and remove the fuel pipe (2)..

- ★ Take care to not damage the five gasket (3).


[*1]



- 4 - Loosen the screws (4) and remove the four bracket (5).

[*2]


- 5 - Remove the nozzle (6).




Installation

- To install, reverse the removal procedure.

[*1]

 Screw: 7.8-9.8 Nm


[*2]

 Screws: 22.6-28.4 Nm


FUEL TANK

Removal

- ★ Drain the fuel.




- 1 - Remove screws (1) and loosen screws (2), without removing them. [*1]




- 2 - Disconnect the connector (3) from the level sensor and disconnect the connector from the reverse gear chime, if installed.


- 3 - Loosen the screw (4) and disconnect the level sensor harness (5) from the tank.



- 4 - Disconnect the delivery (8) and return (9) lines from the settler (6) and filter (7).



- 5 - Loosen the screw (10) and remove the support (11).



ENGINE-PUMP COUPLING

Removal

- ⚠** Completely raise the attachment and tilt the cab.
(For details, see "CAB").

- 1 - Remove the pump.
(For details, see "COMPLETE HYDRAULIC PUMP")

Half sleeve on pump

- 2 - Loosen security dowels (1) on half sleeve (2) in multiple sequences and in an alternate manner. [*1]

- ★ Heat the dowels at 85–100°C.


- 3 - Remove the pump half sleeve (2).

- ★ If necessary, use a puller.

Half sleeve on flywheel

- 4 - Remove screws (3) and remove drive flange (4).


[*2]




Installation


- To install, reverse the removal procedure.

[*1]

 Pump half-sleeve clamping screw: Loctite.....

 Pump half-sleeve clamping screw:.....Nm

[*2]

 Drive flange screw: Loctite 262

 Drive flange screw: 50 Nm


- 1 - Fill the tank up to maximum level.

- ⚠** Bleed the air from the piston pump while filling the tank. (For details, see "20 TESTING AND ADJUSTMENTS").


- 2 - Start the engine to circulate the oil and check that there are no leaks.


- 3 - Stop engine and top up as necessary.


6 - Mount the complete piston (6).



7 - Mount the nut (5) that secures the piston and tighten it with the socket wrench **E** and the dynamometric tool with a multiplier **D**.

 Nut: Loctite 262

 Nut: 1127±112 Nm




4. Cylinder assembly


1 - Mount the tools **A** onto the apparatus **B**.

2 - Position the bushing (20) and mount it onto the cylinder (2).


★ Leave the cylinder in position, ready for the next assembly operation.



3 - Lubricate the threading and the first part of the cylinder (2).

 Cylinder: Lithium EP NLGI 2

4 - Mount the two halves of the tool **M**, adapted to the diameter, onto the mouthpiece of the cylinder (2).




IDLER WHEELS

Removal


⚠ Disconnect the cable from the accumulator negative (-) terminal.

- 1 -Remove track on disassembly side. (For details, see "TRACK").
- 2 -Attach the front idler roller (1) to some hoisting tackle and apply a slight tension to the cables.



- 3 -Unfasten and remove the 2 screws (2). [*1]

- ★ To assist screw removal, loosen inner screw first to neutralise the action of the thread locker, then tighten again and loosen the outer screw.



- 4 -Remove the complete idler wheel (1).



Front idler wheel: 48 kg
Rear idler wheel: 32 kg

Installation


- To install, reverse removal procedure.

[*1]


 Screws: Loctite 242

 Screws 574 Nm

17 -Pull out springs (19) and spring seats (20) (1 on each side).



18 -Extract spool (21) from cylinder head (22).



19 -Remove plug (23).

- ★ Check the condition of the O-ring and put in a new one if necessary.




20 -Extract spool (24) and spring (25).




9 -Install pistons (54) to disc (55).


- ★ Pay attention to the orientation of disc (55) in relation to the pistons.




10 -Install pistons (54) to cylinder block (51).




11 -Install the complete cylinder block (51) to the flanged hub (41).



12 -Install one friction disc (47) first, and then one steel disc (50), and continue in this sequence until brake pack is complete. The brake pack consists of 3 friction discs and 2 steel discs.



50 -Install cover (4) and lock in place using snap ring (3).




51 -Install the plugs (1) and their seals (2) without tightening.


52 -Mount the final drive on frame and fill up with final drive oil.



Final drive: approx. 1.3 ℓ of SAE 10W-30



AS VALVE




RKS01450

Unit: mm

No.	Check item	Criteria					Remedy
		Standard size			Repair limit		
		Free length	Installed length	Installed load	Free length	Installed load	
1	Spring	38.1	30	52 N	-	41.1 N	Replace
2	Spring	25.9	23	16.7 N	-	13.7 N	
3	Spring	38.5	34.9	88.2 N	-	70.6 N	

SUPER HIGH-FLOW VERSION



RKS04310

View Z

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL