

# Shop Manual

# D75S-2

## DOZER SHOVEL

**SERIAL NUMBER D75S-2 1004 and up**

This material is proprietary to Komatsu America Corp. and is not to be reproduced, used, or disclosed except in accordance with written authorization from Komatsu America Corp.

It is our policy to improve our products whenever it is possible and practical to do so. We reserve the right to make changes or improvements at any time without incurring any obligation to install such changes on products sold previously.

Due to this continuous program of research and development, revisions may be made to this publication. It is recommended that customers contact their distributor for information on the latest revision.

Copyright 2012 Komatsu  
Printed in U.S.A.  
Komatsu America Corp.

July 1992

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below




- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

# SPECIFICATIONS

CAPACITIES	COOLING WATER	49 liters (13 U. S. Gal.)
	FUEL TANK	320 liters (85 U. S. Gal.)
	ENGINE	45 liters (12 U. S. Gal.)
	TORQUE CONVERTER	37 liters (9.8 U. S. Gal.)
	TRANSMISSION	
	BEVEL GEAR DRIVE	75 liters (20 U. S. Gal.)
	STEERING CASE	
	FINAL DRIVE CASE (each)	25 liters (6.6 U. S. Gal.)
	HYDRAULIC OIL	120 liters (32 U. S. Gal.)
	UNDERCARRIAGE RECOIL SPRING CASE (each)	10 liters (2.6 U. S. Gal.)

Specifications are subject to change without notice.



# GENERAL INSTRUCTIONS

WEIGHT · TORQUE LIMIT

## WEIGHT DATA

Unit : kg (lb)

Engine assembly (excl. pre-cleaner and exhaust pipe)	1300 (2,866.0)	Front idler assembly	240 (529.1)
Fuel tank (when fuel is filled up to level)	380 (837.8)	Track roller assembly	79 (174.2)
Radiator assembly	100 (220.5)	Carrier roller assembly	41 (90.4)
Battery	61 (152.1)	Track assembly (each side)	1345 (2,965.2)
Torque converter	170 (374.8)	Suspension assembly	210 (463.0)
Transmission (planetary gear)	510 (1,124.4)	Radiator guard assembly	170 (374.8)
Steering case and main frame assembly	1800 (3,968.3)	Rear frame	90 (198.4)
Steering clutch and brake assembly (each side)	70 (154.3)	Engine lower guard	102 (224.9)
Brake assembly (excl. brake band)		Lower (front) guard	58 (127.9)
Bevel gear and bevel gear shaft	45 (99.2)	Lower (rear) guard	70 (154.3)
Sprocket	130 (286.6)	Bonnet	32 (70.6)
Final drive case	94 (207.2)	Hydraulic tank assembly (incl. control valve)	164 (361.6)
Final drive gear and hub assembly	150 (330.7)	Lift cylinder	128 (282.2)
Track group assembly (excl. track chain)	1980 (4,365.1)	Dump cylinder	80 (176.4)
Track frame	580 (1,280.7)	Bucket	1130 (2,491.2)
Track roller guard, outer	63 (138.9)	Shovel link assembly	1620 (3,571.5)
Track roller guard, inner	44 (97.0)	Hydraulic oil filter assembly	55 (121.3)
Idler cushion assembly	270 (595.2)	Hydraulic oil pump assembly	32 (70.6)
		Side frame assembly	740 (1,631.4)

## TORQUE LIMIT CHART



Material		S 45-1, SMn 40CH, SCM3 or equivalent	
Nominal Size mm	Pitch mm (in)	Torque	
		kg·m	(ft·lb)
6 (0.236)	1 (0.039)	1.0~1.5	(7~11)
8 (0.314)	1.25 (0.049)	2.5~3.5 (19~25)	
		5.5~7.5 (40~54)	
10 (0.394)	1.5 (0.059)	9.5~12.5 (69~90)	
	1.25 (0.049)	11.0~14.5 (80~105)	
12 (0.472)	1.75 (0.069)	15.0~20.0 (108~145)	
	1.5 (0.059)	17.0~22.5 (123~163)	
14 (0.551)	2 (0.079)	23.5~31.5 (170~228)	
	1.5 (0.059)	25.5~34.5 (184~250)	
16 (0.630)	2 (0.079)	32.5~43.5 (235~315)	
	1.5 (0.059)	38.5~52.0 (278~376)	
18 (0.709)	2.5 (0.098)	45.5~62.0 (329~448)	
	1.5 (0.059)	53.5~72.5 (387~524)	
20 (0.787)	2.5 (0.098)	64.5~84.5 (467~611)	
	1.5 (0.059)	71.0~96.0 (518~694)	
22 (0.866)	3 (0.118)	79.0~105 (571~759)	
	1.5 (0.059)	94.0~125 (680~964)	
24 (0.945)	1.5 (0.059)	110~150 (796~1,085)	
27 (1.063)	3 (0.118)	145~195 (1,049~1,410)	
30 (1.181)		190~250 (1,374~1,808)	
33 (1.299)		230~310 (1,664~2,242)	
36 (1.417)			

## ENGINE

### ENGINE (including the TORQUE CONVERTER)

### RE-MOUNTING

- (3) Tighten the engine mounting bolts equally and gradually, passing the wrench from one mount to another until each bolt is equally tightened to the specified torque limit.



- (4) Connect the universal joint between the torque converter shaft and the torqueflow transmission.
- (5) Connect all pipings on the oil cooler.
- (6) Connect all pipings on the torque converter. (Refer to "TORQUE CONVERTER DISASSEMBLING AND ASSEMBLING".)
- (7) Connect the electrical wires to their respective positions on the engine, making sure each wire is installed with a rubber cap in place. (Refer to "SIDE FRAME DISASSEMBLING AND ASSEMBLING".)
- (8) Install the air cleaner in position, being sure there is no air leakage at the connection between the air cleaner and the flange for intake connector.
- (9) Connect the compression release lever knob and fuel control lever rod properly.
- (10) Connect the rubber hose to the fuel filter. This hose leads to the float tank. Connect the fuel return pipe to the return fuel rubber hose on the side of the engine. (Refer to step 3, "ENGINE REMOVAL".)
- (11) Connect the pipe to the engine by-pass filter. This pipe leads to the engine. (Refer to step 11, "ENGINE REMOVAL".)
- (12) Mount the radiator assembly. (Refer to "RADIATOR INSTALLATION".)
- (13) Install all floor plates, and connect the knob to the compression release lever. (Refer to step 3, "ENGINE REMOVAL".)
- (14) Connect the battery cords. (Refer to step 4, "ENGINE REMOVAL".)
- (15) Fill the hydraulic oil tank with hydraulic oil up to the specified level.
- (16) Open the fuel valve on the bottom of the fuel tank. Run the engine at an idling speed for a while. Operate the hydraulic control lever to drive all air out of the hydraulic line through the filler cap. Be sure to open the filler cap slowly to relieve oil pressure in the tank gradually. Shut down the engine. Check the oil level in the hydraulic tank and, if necessary, replenish the oil to the level. Check the level of the cooling water in the radiator if the water is filled to the level.
- (17) Draw out the safety pin and lower the bucket to the ground securely.

# TRANSMISSION

## INDEX

<b>POWER TRANSMITTING GROUP</b> .....05-01	<b>DISASSEMBLING (TRANSMISSION)</b> ...05-17
A. Operating Principles of the Planetary Gearing .....05-01	
B. Construction and Function .....05-04	
C. Selective Paths of Power through Transmission .....05-05	
	<b>CLEANING AND INSPECTION (TRANSMISSION)</b> .....05-24
<b>CONTROL VALVE</b> .....05-10	<b>RE-ASSEMBLING (TRANSMISSION)</b> ...05-24
A. Valve Functions .....05-11	
B. Hydraulic Oil Flows .....05-11	
C. Torque Converter Inlet Relief Valve .....05-13	<b>DISASSEMBLING (CONTROL VALVE)</b> .....05-25
D. Transmission Lubrication Relief Valve .....05-14	
<b>REMOVAL (TRANSMISSION)</b> .....05-15	<b>CLEANING AND INSPECTION (CONTROL VALVE)</b> .....05-27


# TRANSMISSION

## POWER TRANSMITTING GROUP


## DESCRIPTION

### (5) Reverse Second

Refer to the accompanying sketch on the right. The transmission has its No. 1 clutch and No. 3 clutch engaged, to guide the flow of power as in the first half of REVERSE FIRST and as in the last half of FORWARD SECOND.



Reverse 2nd



Engine Just Stopped

1. Speed Valve
2. Directional Valve
3. Safety Valve
4. Torque Converter Relief Valve
5. Modulation Relief Valve
6. Quick Return Valve
7. Transmission Lubricating Relief Valve

- |                               |                  |
|-------------------------------|------------------|
| Pressure oil                  | Lubricating oil  |
| Torque converter oil (relief) | Drain oil        |
| Back pressure (1)             | Non-pressure oil |
| Back pressure (2)             |                  |

# TRANSMISSION

## DISASSEMBLING

1. Bolt	8-8. Planetary gear	19. Clutch disc	26. Clutch disc
2. Lock	8-9. Bearing	20. Rear cushion plate	27. Rear cushion plate
3. Holder	9. Spring	21. Ring gear	28. Range transmission shaft
4. "O" ring	10. Transmission shaft	22-1. Piston	29. Ring gear
5. Bolt	11. Clutch disc	22-2. Seal ring	30-1. Housing
6-1. Bearing cage	12. Rear cushion plate	22-3. Seal ring	30-2. Piston
6-2. "O" ring	13. Pin	22-4. Spacer	30-3. Seal ring
6-3. Retainer	14-1. Housing	22-5. Piston	30-4. Seal ring
6-4. Seal ring	14-2. Piston	22-6. Seal ring	31. Spring
6-5. Snap ring	14-3. Seal ring	22-7. Seal ring	32. Clutch disc
6-6. Coupling	14-4. Seal ring	22-8. Snap ring	33. Rear cushion plate
6-7. Oil seal	15. Spring	22-9. Housing	34. Ring gear (D)
6-8. Snap ring	16. Bolt	22-10. Bearing	35. Snap ring
6-9. Bearing	17. Lock	22-11. Carrier (C)	36-1. Carrier (D)
7. Bolt	18-1. Snap ring	22-12. Roll pin	36-2. Roll pin
8-1. Front plate	18-2. Ring gear	22-13. Shaft	36-3. Bearing
8-2. Ring gear	18-3. Carrier (B)	22-14. Washer	36-4. Washer
8-3. Snap ring	18-4. Roll pin	22-15. Planetary gear	36-5. Planetary gear
8-4. Carrier (A)	18-5. Shaft	22-16. Bearing	36-6. Bearing
8-5. Roll pin	18-6. Washer	23. Retainer	37. Snap ring
8-6. Shaft	18-7. Planetary gear	24. Spring	38. Bearing
8-7. Thrust washer	18-8. Bearing	25. Pin	

# RANGE TRANSMISSION

## INDEX

### DESCRIPTION

- A. Construction of Range  
Transmission .....06-01
- B. Shifter Fork .....06-03
- C. Interlock.....06-04

### REMOVAL

(RANGE TRANSMISSION) .....06-05

### DISASSEMBLING

(RANGE TRANSMISSION) .....06-06

### CLEANING AND INSPECTION

(RANGE TRANSMISSION) .....06-08

### RE-ASSEMBLING

(RANGE TRANSMISSION) .....06-08

REMOVAL (SHIFTER) .....06-09

DISASSEMBLING (SHIFTER).....06-10

### CLEANING AND INSPECTION

(SHIFTER) .....06-12

RE-ASSEMBLING (SHIFTER).....06-12

RE-MOUNTING .....06-12



# RANGE TRANSMISSION

## SHIFTER

REMOVAL


### REMOVAL

1. Remove all floor plates. (Refer to "ENGINE REMOVAL".)
2. Dismount the operator's seat, battery, fuel tank and rear frame assembly. (Refer to "SIDE FRAME REMOVAL" procedure.)
3. Remove the steering brake control rods (1), steering control rods (2) and range shift control rod (3).
4. Disconnect the range transmission control rod (1). (Refer to "TORQFLOW TRANSMISSION REMOVAL".)
5. Remove the flange (1), loosen the bolts (2), and dismount the range transmission shifter assembly (3).




# BEVEL GEAR & BEVEL GEAR SHAFT


## CLEANING AND INSPECTION



- 9 Remove the bearing inner race (20), using the bearing puller. Remove the other bearing inner race in the same way.



- (10) Remove the flange (21) and bushing (22). Take the bevel gear (26) out of the shaft (27) by removing the nuts (23), washers (24) and reamer bolts (25) in place.



## CLEANING AND INSPECTION


- 1 Clean the bevel gear thoroughly. Check it for gear tooth wear, spalling or any other damage.
- (2) Check the bevel gear shaft for fitness. Also check it for any sign of malcondition.

## STEERING SYSTEM

REMOVAL

NOTE: The bolts securing the steering clutch drum and final drive line as a unit are to be removed in the following manner:

Disconnect the track chain and spread the track on the floor. Lift the machine to permit the sprockets to turn freely. Loosen the bolts, one by one, while rotating the drum. If it is not practicable to disconnect and spread out the track, the drum may be rotated just a little at a time by driving the machine to permit removal of the securing bolts.



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.


CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

# FINAL DRIVE

DESCRIPTION

## FINAL DRIVE

### DESCRIPTION



Final Drive

- |                     |                  |                        |
|---------------------|------------------|------------------------|
| 1. Floating seal    | 7. Sprocket      | 13. Bearing cage       |
| 2. Cap              | 8. Floating seal | 14. Flange             |
| 3. Sprocket shaft   | 9. Cover         | 15. 1st reduction gear |
| 4. Bearing          | 10. Cover        | 16. 2nd reduction gear |
| 5. Bearing retainer | 11. 2nd pinion   | 17. Hub                |
| 6. Bearing cage     | 12. 1st pinion   |                        |

# STEERING CONTROLS

## INDEX

### DESCRIPTION

- A. Steering Brake.....10-01
- B. Steering Control Valve.....10-03
- C. Steering Control Linkage and  
Hydraulic Components .....10-05
- D. Fuel Controls .....10-07


### ADJUSTMENTS AND INSPECTION

- A. Steering Control Linkage.....10-09
- B. Hydraulic Drive for Steering  
Clutches .....10-10
- C. Idling Adjustment .....10-10
- D. Full-throttle Adjustment .....10-10

### ADJUSTMENTS AND INSPECTION


#### A. Steering Control Linkage

- (1) Steering clutch pedals should return to the same height upon releasing. This requirement is to be satisfied by adjusting the stoppers (19R-not shown) and (19L).



- (2) Clutch rod adjustment: With pedals (1) (2) fixed in released condition, pull clutch rods (2R) (2L) fully toward front side without straining the control valve springs (preload of control valve springs is 10 kg (22 lb), a force large enough to present a strong resistance to hand pulling), and adjust the lengths of rods (2R) (2L) for proper connection with levers (20R) (20L), as shown. With these rods so adjusted, elongate them by turning each just one rotation (equivalent to 1.5 mm (0.06 in) of length) and then secure them to levers (20R) (20L). This will provide a clearance of about 1 mm (0.04 in) between lever and plunger. This clearance shows up as a play of steering clutch pedal 3 mm (0.12 in). The pedal is required to have an initial ineffective stroke (play) of about 3 mm (0.12 in) before its downward movement becomes effective in actuating the control valve. The effective pedal stroke for clutch control is about 54 mm (2.13 in).


- (3) Brake rod adjustment: With pedals (1) (2) secured in released condition, pull brake rods (3R) (3L) all the way toward rear side (counter to the direction of applying brake); adjust their lengths



for proper connection with levers (21R) (21L); and make connections right there. The brake should begin to apply when the pedal is depressed about 90 mm (3.5 in).

CAUTIONS: a) The steering clutch pedals are required to have a play mentioned above.

b) Make sure the brake applies within the pedal stroke range from 90 mm (3.5 in) to 130 mm (5.1 in). Brake rod must be re-adjusted whenever it is noted that the pedal has to be depressed very close to the floor or as much as 147 mm (5.79 in) or thereabout.



# UNDERCARRIAGE

## FRONT IDLERS

DESCRIPTION · REMOVAL

be so positioned as to stagger ring gaps.  
(3) When positioning the grease fitting on the adjusting cylinder, be sure to point its nipple toward the inspection opening provided in the cover, so as to make the nipple accessible to a charging nozzle through the opening.


(4) After the recoil spring has been re-assembled in place on the track frame, add the specified amount of engine oil into its spring chamber formed by the cover. This oil serves to prevent the spring from rusting.

## FRONT IDLERS

### A. Description

The supports (or bearings) on both sides of each front idler are so constructed that they are capable of sliding, as guided, in fore-aft direction on the frame without jumping out of the bifurcated forward portion of the track frame.

The shaft upon which the front idler rotates is held rigidly by the supports, and the running clearance between the bore of idler hub and this shaft is filled with lubricant, there being sealing rings of floating type fitted to both ends of this bore to contain the lubricant hermetically.



- Idler
- |                        |                  |                |                |
|------------------------|------------------|----------------|----------------|
| 1. Shim                | 4. Floating seal | 6. Idler       | 8. Bushing     |
| 2. Guide               | 5. Bushing       | 7. Idler shaft | 9. Track frame |
| 3. Idler shaft bearing |                  |                |                |

# UNDERCARRIAGE

## SUSPENSION

### INSPECTION • RE-MOUNTING


#### C. Inspection

- (1) Check the equalizer bar for cracks, damage or any signs of fatigue.
- (2) Check the bushing (in which the pivot pin is held) for wear.
- (3) Check the resting face at each end of the equalizer bar for wear or galling.

#### D. Re-mounting

Reverse the removal procedure to re-mount the equalizer bar, by following the instruction outlined below:

- (1) Note that the pivot pin is to be inserted into the bushing from the rear side.
- (2) Check the bolts for tightness. Replace excessively worn bolts.



Equalizer Bar

- |                     |                 |
|---------------------|-----------------|
| 1. Center pivot pin | 4. Cushion seat |
| 2. Equalizer bar    | 5. Track frame  |
| 3. Main frame       |                 |

# **FUEL TANK**

## **INDEX**

**DESCRIPTION .....14-01**

**REMOVAL .....14-02**

**DISASSEMBLING .....14-02**

**INSPECTION AND CLEANING.....14-03**

**RE-ASSEMBLING .....14-03**



# **DRAWBAR**


## **INDEX**

**DESCRIPTION** .....16-01

**INSPECTION** .....16-01



DISASSEMBLING



(The parts are enumerated in the sequence of removal.)


Bucket Group

- |                  |   |                   |   |
|------------------|---|-------------------|---|
| 1. Bolt          | 6. Remove the left side part in the same manner.  | 15. Bolt          | 20. Remove the left side part in the same manner. |
| 2. Spring washer | 7. Nut  | 16. Spring washer | 21. Roll pin                                      |
| 3. Lock plate    | 8. Bolt   | 17. Lock plate    | 22. Shaft   |
| 4. Shaft         | 9. Shaft  | 18. Shaft         | 23-1. Dust seal                                   |
| 5-1. Spacer      | 10. Nut   | 19-1. Dust seal   | 23-2. Bushing                                     |
| 5-2. Spacer      | 11. Bolt  | 19-2. Dust seal   | 23-3. Lever                                       |
| 5-3. Dust seal   | 12. Shaft   | 19-3. Bushing     | 24-1. Dust seal                                   |
| 5-4. Dust seal   | 13. Bucket  | 19-4. Dust seal   | 24-2. Dust seal                                   |
| 5-5. Bushing     | 14. Remove the left side part in the same manner. | 19-5. Dust seal   | 24-3. Bushing                                     |
| 5-6. Dust seal   |   | 19-6. Bushing     | 24-4. Lift arm                                    |
| 5-7. Dust seal   |   | 19-7. Rod         |   |
| 5-8. Bushing     |   |                   |   |
| 5 9. Rod         |   |                   |   |






# HYDRAULIC SYSTEM


## CONTROL VALVE

## DESCRIPTION



Lift cylinder: Raise  
Tilt cylinder: Hold

-  Pump pressure
-  Line pressure
-  Holding pressure
-  Return circuit
-  Drain circuit




Tilt cylinder: Tilt  
Lift cylinder: Hold

# HYDRAULIC SYSTEM


## LIFT CYLINDER

### DISASSEMBLING

- (3) Remove the bolts (1), take off the plate key (2) and pull out the pin (3) so that the side frame (4) may be separated from the lift cylinder (5).
- (4) Take down the lift cylinder. Drain out all oil remaining in the cylinder.



### C. Disassembling




(The parts are enumerated in the sequence of removal.)

#### Lift Cylinder


- |                    |                   |                  |                      |
|--------------------|-------------------|------------------|----------------------|
| 1. Bolt            | 6. U-ring holder  | 14. Piston ring  | 17-3. Snap ring      |
| 2. Spring washer   | 7. U-ring         | 15. Piston       | 17-4. Packing header |
| 3-1. Dust seal     | 8. Nylon heel     | 16-1. Dust seal  | 17-5. U-ring         |
| 3-2. Dust seal     | 9. Piston ring    | 16-2. Dust seal  | 17-6. Nylon heel     |
| 3-3. Bushing       | 10. Stopper       | 16-3. Bushing    | 17-7. Wiper ring     |
| 3-4. Lift cylinder | 11. U-ring holder | 16-4. Piston rod | 17-8. Bushing        |
| 4. Nut             | 12. U-ring        | 17-1. "O" ring   | 17-9. Cylinder head  |
| 5. Stopper         | 13. Nylon heel    | 17-2. Ring       |                      |

## SIDE FRAMES


### REMOVAL



(5) Remove the bolts (1) and disconnect the tubes leading to the hydraulic oil tank.




(6) Detach the flange (1) and rubber hoses (2) (3). Also, disconnect the control-linkage components including the valve actuating rods (4), range mission control rod (5), clutch control valve rods (6), and steering brake control rods (6), and steering brake control rods (7).



(4) Loosen the clips (1) (2) and disconnect the rubber hose (3).

(7) Remove the bolts (1) (2) (3) (4) (5) securing the side frame in place.



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL