

SHOP MANUAL

KOMATSU

PC1600-1

MACHINE MODEL SERIAL No.

PC1600-1 10001 and up

- This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you may require. Materials and specifications are subject to change without notice.
- PC1600-1 mount the SA6D140 engine.
For details of the engine, see the 6D140-1 Series Engine Shop Manual.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

HOISTING INSTRUCTIONS



! Heavy parts (25 kg or more) must be lifted with a hoist etc. In the **Disassembly and Assembly** section, every part weighing 25 kg or more is indicated clearly with the symbol kg

1. If a part cannot be smoothly removed from the machine by hoisting, the following checks should be made:
 - Check for removal of all bolts fastening the part to the relative parts.
 - Check for existence of another part causing interference with the part to be removed.

2. Wire ropes


- 1) Use adequate ropes depending on the weight of parts to be hoisted, referring to the table below:

Wire ropes (Standard "Z" or "S" twist ropes without galvanizing)	
Rope diameter (mm)	Allowable load (tons)
10	1.0
11.2	1.4
12.5	1.6
14	2.2
16	2.8
18	3.6
20	4.4
22.4	5.6
30	10.0
40	18.0
50	28.0
60	40.0

The allowable load value is estimated to be one-sixth or one-seventh of the breaking strength of the rope used.

- 2) Sling wire ropes from the middle portion of the hook.

Slinging near the edge of the hook may cause the rope to slip off the hook during hoisting, and a serious accident can result. Hooks have maximum strength at the middle portion.



FS0064


- 3) Do not sling a heavy load with one rope alone, but sling with two or more ropes symmetrically wound on to the load.

! Slinging with one rope may cause turning of the load during hoisting, untwisting of the rope, or slipping of the rope from its original winding position on the load, which can result in a dangerous accident.

- 4) Do not sling a heavy load with ropes forming a wide hanging angle from the hook.

When hoisting a load with two or more ropes, the force subjected to each rope will increase with the hanging angles. The table below shows the variation of allowable load (kg) when hoisting is made with two ropes, each of which is allowed to sling up to 1000 kg vertically, at various hanging angles.


When two ropes sling a load vertically, up to 2000 kg of total weight can be suspended. This weight becomes 1000 kg when two ropes make a 120° hanging angle. On the other hand, two ropes are subjected to an excessive force as large as 4000 kg if they sling a 2000 kg load at a lifting angle of 150°.




FS0065

RADIATOR AND OIL COOLER

The fan is driven by a V-belt between the fan pulley and the engine pulley. The fan is a suction type which sucks in the outside air through the radiator core and oil cooler and sends it forcibly to the engine.



- 1. Radiator outlet tube
- 2. Fan pulley
- 3. Radiator inlet hose
- 4. Fan guard
- 5. Pressure valve
- 6. Fan
- 7. Radiator upper tank
- 8. Radiator core
- 9. Oil cooler inlet tube
- 10. Oil cooler core
- 11. Oil cooler outlet tube
- 12. Radiator lower tank
- 13. Radiator drain valve




Section A - A

21TAF01003

021TA1

TRAVEL AND BRAKE SYSTEM


1. TRAVEL CONTROL CIRCUIT



021TA1

21TAF01007

5. TRAVEL BRAKE VALVE



Section A - A

21TAF01009

1. Spool switching spring
2. Counterbalance valve spool
3. Housing
4. Check valve spring
5. Check valve

FUNCTION

This valve prevents the speed of the motor from being increased by the weight of the machine when going downhill.

The brake valve consists of the counterbalance valve, the check valve and the safety valve.

Rated flow: 420 ℓ/min.

Safety valve set pressure: $330 \begin{smallmatrix} + 5 \\ 0 \end{smallmatrix} \text{ kg/cm}^2$


(at 5 ℓ/min.)

Spool switching pressure: $13 \pm 2 \text{ kg/cm}^2$

(Cracking pressure)

021TA1

4. SWING MOTOR (WITH MECHANICAL BRAKE) AND SAFETY VALVE ASSEMBLY



021TA1

21TAF01012

1. Swing motor
2. Swing mechanical brake


OPERATION

Stopping with normal swing

- If swing switch (acting also as the swing mechanical brake switch) (1) is moved to the ON position, the electrical circuit is opened, solenoid valve (3) is deactivated, and the pressurized oil from the charging pump to connection valve (4) is stopped.

When this happens, spool (4a) of connection valve (4) is pushed back to the left by return spring (4b). As a result, the swing circuit and swing shadow valve (5) are not connected.

- In this condition, if the swing stop control is operated when the upper structure is swinging, the pressurized oil from the swing motor return side is stopped by the swing control valve (closed center). Therefore, the oil pressure relieved from the safety valve inside the swing motor acts as a hydraulic brake to stop the swing.



F20903021

Stopping with free swing


- If free swing switch (1) is set to the OFF position, the electrical circuit is closed, so solenoid valve (3) is excited and spool (3a) is switched.

When this happens, the pressurized oil from the charging pump acts on the pilot port of connection valve (4) and switches spool (4a). As a result, the swing circuit and swing shadow valve (5) are connected.

- In this condition, if the swing stop control is operated when the upper structure is swinging, the pressurized oil from the swing motor return side is stopped by the swing control valve. However, the swing shadow valve connected to the swing circuit is open center, so the oil from the return side of the motor passes through the inside of the swing shadow valve and flows to the motor supply side.

As a result, there is no hydraulic brake effect, so the swing is stopped by inertia.


- If foot brake switch (2) is depressed at this time, the electrical circuit is opened and solenoid valve (3) is deactivated. This shuts off the swing circuit and swing shadow valve, so the hydraulic brake is actuated.



F20903022

021TA1

2. ACCUMULATOR



021TA1

209F3201

- 1. Valve
- 2. Body
- 3. Plug
- 4. Check valve

Volume: 32,500 cc
Operating pressure: 300 kg/cm²

FUNCTION OF EQUIPMENT

- Greasing switch
When greasing, turn the switch on to actuate the grease pump.
- Solenoid valve
The electrical signal from the greasing switch opens or closes the air circuit, thereby opening or closing the supply of air to the grease pump.
- Grease pump
This is a reciprocal type pump which is driven by air. It generates a grease pressure forty times the air pressure.
 - ★ During greasing, the grease pressure gauge should read 50 – 200 kg/cm².
 - ★ If it is below 50 kg/cm², it means that the grease can is empty.
 - ★ If it reads more than 200 kg/cm², check the indicator of main distributor **A** at the top of the boom foot. If the plunger is out, the line is clogged.
- Stop valve
When the grease can is being used to pump in grease, this tighten this valve to cut the automatic greasing line.
 - ★ When not using the grease gun, always set to OPEN.
- Hose reel
This is used to store the grease can hose (automatic wind-in).
- Grease gun
This is used for greasing (pins around bucket, parts of radiator fan, track tension, etc.).
- Distributor
This is a valve to distribute the grease coming from the pump to each line. The amount of grease sent to each port is fixed by the internal spool.
 - ★ The spool is a sequential action type (the grease does not flow simply to the low pressure areas, but a fixed amount of grease is supplied properly to each line). So if the line to even one point becomes clogged, the pressure in that line will rise and the system will stop.

1. Accumulator
2. Safety lock valve
3. Pilot relief valve
4. R.H. PPC valve (Bucket)
5. Boom and bucket PPC shuttle valve
6. Line oil filter
7. Engine
8. PTO
9. No. 2 or No. 4 pump
 - 9a. Front pump
 - 9b. Rear pump
10. No. 1 or No. 3 pump
 - 10a. Front pump
 - 10b. Rear pump
11. Charging pump
12. Pilot of filter
13. Check valve
14. Return oil filter
15. Oil cooler
16. Check valve
17. Hydraulic tank
18. Bucket cylinder
19. Slow-return valve
20. 4-spool control valve (V1 or V3)
 - 20a. Main relief valve
 - 20b. Bucket-Hi control valve
21. 5-spool control valve (V2 or V4)
 - 21a. Main relief valve
 - 21b. Bucket

OPERATION

1) Bucket control lever operated to CURL:

- When the bucket control lever is operated to the CURL position, the spool of PPC valve (4) inter-connected with the control lever is actuated. Pilot pressure oil flows from charging pump (11) to the pilot case at the spool end of bucket-Lo control valve (21b) and bucket-Hi control valve (20b), and moves the spool.

- The pressurized oil from No. 2 (or No. 4) rear pump (9b) and No. 1 (or No. 3) rear pump (10b) merges, then passes through bucket-Lo control valve (21b) and enters the bottom end of bucket cylinder (18).

At the same time, the pressurized oil from No. 2 (or No. 4) front pump (9a) and No. 1 (or No. 3) front pump (10a) merges, then enters bucket-Hi control valve (20b), but the circuit is closed, so the oil does not flow.

- The flow of oil returning from the head end of bucket cylinder (18) is controlled by slow-return valve (19). It flows to bucket-Lo control valve (21b) and bucket-Hi control valve (20b), passes through return oil filter (14) and hydraulic oil cooler (15), and is then drained to hydraulic tank (17).

2) Bucket control lever operated to DUMP:

- When the bucket control lever is operated to the DUMP position, the spool of PPC valve (4) inter-connected with the control lever is actuated. Pilot pressure oil flows from charging pump (11) to the pilot case at the spool end of bucket-Lo control valve (21b) and bucket-Hi control valve (20b), and moves the spool.


- The pressurized oil from No. 2 (or No. 4) rear pump (9b) and No. 1 (or No. 3) rear pump (10b) merges, then passes through bucket-Lo control valve (21b) and enters the head end of bucket cylinder (18).

At the same time, the pressurized oil from No. 2 (or No. 4) front pump (9a) and No. 1 (or No. 3) front pump (10a) merges, then passes through bucket-Hi control valve (20b) and flows also to the head end of bucket cylinder (18).

- All the oil returning from the bottom end of bucket cylinder (18) flows to bucket-Lo control valve (21b), passes through return oil filter (14) and hydraulic oil cooler (15), and is then drained to hydraulic tank (17).

MAIN PUMP

1. No. 2, 4 PUMP ASSEMBLY (HPV90 + 90 WITH TVC VALVE AND CO • NC VALVE ASSEMBLY)



1. Front pump
2. Front pump servo unit assembly
3. Rear pump servo unit assembly
4. Rear pump

OUTLINE


- No. 2, 4 pump assemblies consist of two variable-displacement swash-plate piston pumps, front servo unit assembly, rear servo unit assembly and impeller pump (built in between the front pump and the rear pump).
- The front pump serves 4-spool control valve.
- The rear pump serves 5-spool control valve.

021TA1

209F3056A

● **SERVO VALVE**
For No. 2, 4 PUMP and SWING PUMP


★ The diagram shows the servo valve for the No. 2 front pump.



021TA1

209F3064

3. PILOT OIL FILTER



1. Bracket
2. Cartridge
3. Element


OUTLINE

The pilot oil filter is installed to the discharge side of the charging pump. It protects the PPC valves and other pilot pressure equipment.

209F3074

021TA1

4. DRAIN OIL FILTER



1. Bracket
2. Safety valve
3. Cartridge
4. Element

OUTLINE

The filter is installed between the swing motor, travel motor, and hydraulic tank. It acts to remove the dirt and foreign matter in the oil coming from the drain port of each motor.


- Safety valve set pressure: 1.05 kg/cm²

209F3205-1

Operation

- 1) **When the main pump (or the swing pump) discharge pressure is lower than the relief pressure:**

Since spool (2) is pushed downward by the force of spring (1), port a and port b are open to each other and TVC valve output pressure P_e is equal to the CO valve output pressure. CO valve output pressure P_{ec} is then maximized and the main pump (or the swing pump) discharge is also increased to the maximum with the rocker cam angle maximized by the operation of the servo valve.




209F3088

- 2) **When the main pump (or the swing pump) discharge is higher than the relief pressure:**


When the main pump (or the swing pump) discharge pressure P_A comes close to the relief pressure owing to an increase in the load, piston (3) is pushed by main pump (or swing pump) discharge pressure P_A and at the same time piston (4) is pushed by CO valve output pressure P_{ec} . When the force of spring (1) is overcome by the pressing force of the piston (2), spool (2) moves upward.

As a result, the spool land restricts the oil flow from port a to port b and at the same time the opening areas of port b and port c (drain port) are made larger.


With rocker cam angle reduced by the operation of the servo valve, the main pump (or the swing pump) discharge is reduced.




209F3089




Section A - A




Section B - B




Section C - C



Section D - D



Section E - E




Section F - F

- 1. Main relief valve
- 2. Spool (R.H. travel)
- 3. Spool (Boom-Lo)
- 4. Spool (Bucket-Hi)
- 5. Spool (Arm-Hi)
- 6. Spool return spring
- 7. Body

- 8. Jet sensor orifice
- 9. Jet sensor relief valve
- 10. Check valve
- 11. Check valve spring
- 12. Straight-travel valve (see 10-17)
- 13. Suction valve
- 14. Safety-suction valve

21TAF01036

FOR TRAVEL CONTROL




021TA1

209F3100

HYDRAULIC CYLINDER


● BACK HOE

1. BOOM CYLINDER




F21TA01023

2. ARM CYLINDER



F21TA01024


3. BUCKET CYLINDER



F21TA01025

021TA1


iv) Coolant temperature sensor



21TAF01050

- | | |
|--|--------------|
| 1. Thermister (bead type) | 3. Wire |
| 2. Plug (Tightening torque: 4 ± 1 kgm) | 4. Connector |






v) Fuel level sensor



021TA1

- | |
|------------------------|
| 1. Float |
| 2. Variable resistance |
| 3. Contact face |
| 4. Connector |

21TAF01051

Classification	Item	Conditions	Unit	Standard value	Permissible value
Travel	Travel deviation	Travel posture ● BACK HOE  205F2409 ● LOADING SHOVEL  21NF01205 ● Engine speed: High idling ● Oil temp.: 45 – 55°C ● On a flat surface, make an approach run of at least 10 m, then travel another 20 m. Measure the travel deviation.  205F2402 * Measure dimension l .	mm	Max. 200	Max. 220
		 F20703007 ● Engine: Stopped ● Oil temp.: 45 – 55°C ● On a slope of 12°, stop the machine with the sprocket sections on the upper side of the slope. ● Wait 5 minutes, then measure the distance the machine moves.	mm	0	0
		 Lock pin F20703008 ● Engine speed: High idling ● Oil temp.: 45 – 55°C ● Relieve oil in travel circuit with lock track shoe.	ℓ/min	Max. 25	30

021TA1

System	Component	Connector No.	Testing method	Judgement table	Measurement conditions				
Electric and electronic OLSS	Prolix circuit resistor (For 3-mode selector OLSS)	CNC7 (male) [Front engine] CNC11 (male) [Rear engine] pins (1), (2)	Measuring resistance	<table border="1"> <tr> <td>Resistance between connector (male) pins (1) – (2)</td> <td>Approx. 10 – 30Ω</td> </tr> </table>	Resistance between connector (male) pins (1) – (2)	Approx. 10 – 30Ω	1) Turn starting switch OFF		
	Resistance between connector (male) pins (1) – (2)	Approx. 10 – 30Ω							
	Mode selector switch	CNH38 (male) (1), (2), (3), (4) (Check for continuity between CNH38 (male) (1) – (2), (4) (3) – (2), (4))	Continuity	Input signal normal if it satisfies Tables 1 – 3. Table 1 <table border="1"> <tr> <td>Between CNH38 (male) (1) – CNH38 (male) (2)</td> <td rowspan="2">No continuity</td> </tr> <tr> <td>Between CNH38 (male) (3) – CNH38 (male) (4)</td> </tr> </table>	Between CNH38 (male) (1) – CNH38 (male) (2)	No continuity	Between CNH38 (male) (3) – CNH38 (male) (4)	1) Turn starting switch OFF 2) Turn mode selector switch to H mode	
				Between CNH38 (male) (1) – CNH38 (male) (2)	No continuity				
				Between CNH38 (male) (3) – CNH38 (male) (4)					
	Table 2 <table border="1"> <tr> <td>Between CNH38 (male) (1) – CNH38 (male) (2)</td> <td>No continuity</td> </tr> <tr> <td>Between CNH38 (male) (3) – CNH38 (male) (4)</td> <td>Continuity</td> </tr> </table>	Between CNH38 (male) (1) – CNH38 (male) (2)	No continuity	Between CNH38 (male) (3) – CNH38 (male) (4)	Continuity	1) Turn starting switch OFF 2) Turn mode selector switch to S mode			
Between CNH38 (male) (1) – CNH38 (male) (2)	No continuity								
Between CNH38 (male) (3) – CNH38 (male) (4)	Continuity								
Table 3 <table border="1"> <tr> <td>Between CNH38 (male) (1) – CNH38 (male) (2)</td> <td rowspan="2">Continuity</td> </tr> <tr> <td>Between CNH38 (male) (3) – CHN38 (male) (4)</td> </tr> </table>	Between CNH38 (male) (1) – CNH38 (male) (2)	Continuity	Between CNH38 (male) (3) – CHN38 (male) (4)	1) Turn starting switch OFF 2) Turn mode selector switch to L mode					
Between CNH38 (male) (1) – CNH38 (male) (2)	Continuity								
Between CNH38 (male) (3) – CHN38 (male) (4)									
Auto-deceleration	Hydraulic pressure switch for arm, boom, bucket and travel pick-up	CNC12 (male) pins (1), (2)	Short connector	1) When using the short connector, the following results show that the sensor is defective. <table border="1"> <tr> <td>Short connector connected</td> <td>Deceleration works normally</td> </tr> <tr> <td>CNC12 disconnected</td> <td>Deceleration does not work</td> </tr> </table>	Short connector connected	Deceleration works normally	CNC12 disconnected	Deceleration does not work	1) Start engine 2) Fuel lever FULL
			Short connector connected	Deceleration works normally					
CNC12 disconnected	Deceleration does not work								
Continuity	1) When carrying out a continuity test, the following results show that the sensor is normal. <table border="1"> <tr> <td>Each control lever at neutral</td> <td>Continuity</td> </tr> <tr> <td>Any lever in operating position</td> <td>No continuity</td> </tr> </table>	Each control lever at neutral	Continuity	Any lever in operating position	No continuity	1) Turn starting switch OFF 2) Start engine			
Each control lever at neutral	Continuity								
Any lever in operating position	No continuity								

021TA1

ADJUSTING FUEL INJECTION TIMING

1. Rotate crankshaft in normal direction to align 28° IJ line on crankshaft pulley (1) with pointer (2) correctly.

★ When stamp line of coupling end is not in foreground, rotate crankshaft one more turn.

2. Disconnect fuel injection pipe (3) of No. 1 cylinder.

3. Remove delivery valve holder (4), then remove delivery valve (5), spring (6) and spring seat, and install delivery valve holder (4) again.

4. Place fuel control lever at "Full" position.


5. Remove cover, and loosen nuts (7) in oblong hole of mount flange of injection pump.

6. Operating the priming pump, rotate flange on injection pump side little by little until no fuel flows out of delivery valve holder.


★ Injection timing is **ADVANCED** when flange on injection pump side rotate to cylinder block, and **RETARD** when flange on injection pump side rotate to outside.






7. Tighten nut (7) in oblong hole of mounting flange of fuel injection pump.

8. Remove delivery valve holder (4), assemble spring seat, delivery valve (5) and spring (6), then install delivery valve holder (4) again.

 Delivery valve holder: 11.5 ± 0.5 kgm


9. Connect fuel injection pipe (3).

 Sleeve nut: 2.4 ± 0.1 kgm



021TA1

INSIDE CAB BASE, PILOT PIPING CONNECTION DIAGRAM



021TA1

* The letters of the alphabet show the letter stamped on the connection hose.

21TAF01092

6. Slowly open valve (6) of the nitrogen cylinder further and charge the accumulator with nitrogen gas.

- ★ Close valve (6) of the nitrogen cylinder from time to time and take the reading of pressure gauge (7) of the charging valve assembly when it is steady.

7. When nitrogen gas has been added to the specified pressure, close valve (6) of the nitrogen cylinder firmly.

- ★ Specified pressure: 135 kg/cm²
- ★ If the nitrogen goes above the specified pressure, turn valve (4) to the left and release the gas gradually until it is the specified pressure.


8. Turn valve (4) to the left until it closes, then turn valve (5) to the left to open it and release the pressure remaining inside the hose and tool **A**.

9. Remove tool **A** and install plug (3).

10. Using handle (209-98-11140), tighten stop valves (2) and (1).

021TA1


SWING PARKING BRAKE AND SWING BRAKE SYSTEM





021TA1

21TAF01104

CN-C13 (Bucket EPC solenoid)
ECONOSEAL connector 2 pins




CN-C15 (Bottom dump solenoid)
ECONOSEAL connector 3 pins
CN-C16 (Free swing solenoid)
ECONOSEAL connector 2 pins
CN-C18 (Swing parking brake solenoid)
ECONOSEAL connector 2 pins



021TA1



21TAP01031

CN-C20 (Front engine TVC solenoid)
ECONOSEAL connector 2 pins
CN-C23 (Rear engine TVC solenoid)
ECONOSEAL connector 2 pins











21TAP01032

CN-C21 (Auto-deceleration solenoid B terminal)
ECONOSEAL connector 2 pins
CN-C22 (Auto-deceleration solenoid A terminal)
ECONOSEAL connector 3 pins



21TAP01033

021TA1

① No. of pins	② MIC CONNECTORS	
	③ Female connector (socket)	④ Male connector (pin)
5	 <p>142F410</p>	 <p>142F411</p>
13	 <p>142F412</p>	 <p>142F413</p>
17	 <p>142F414</p>	 <p>142F415</p>
21	 <p>142F416</p>	 <p>142F417</p>

Example Failure mode (machine deviates excessively)

Step 1 Does the self-testing display indicate any abnormality?

Check the red and green LEDs on the control box to see if the self-testing display indicates any abnormality.

Failure mode	Check self-testing display							Troubleshooting chart
	Power supply	Control box	TVC solenoid system	Engine speed sensor system	Potentiometer system	Auto-deceleration solenoid A system	Auto-deceleration solenoid B system	
	1. Is location of abnormality displayed? (● flashing twice per second)							Go to E-1 (Δ) for abnormalities in electrical system; go to H-1 (○) for abnormalities in hydraulic or mechanical system
	Red ● OFF Green ● OFF	Red ● ON Green ● ON	Red ● Flashing Green ● OFF	Red ● Flashing Green ● Flashing	Red ● ON Green ● OFF	Red ● ON Green ● Flashing	Red ● ON Green ● Flashing	
6 Speeds for work equipment, swing and travel are all extremely slow, or there is no power	1) Run engine at low idling. * If the ● marks in the table below indicate some additional abnormality, this means that two or more abnormalities have occurred at the same time.							1) S mode 2) Other than deceleration * The situation during normal deceleration is displayed in item 2 on the right during deceleration.
	Is there any display of abnormality? YES: NO (Troubleshooting tables 8, 9) NO (Troubleshooting tables 1, 7): NO (Troubleshooting tables 6, 12, 13)							
	●	●	●	●	●	●	●	E-1

Judgement

If the abnormality display corresponds to the ● mark in the above table → abnormality in electrical system. Go to troubleshooting table E-1.
 If NORMAL display appears in other than S mode and during deceleration → checks next ● mark (checking by switching to prolix circuit).

Step 2 Checking by switching to prolix circuit

Operate to prolix circuit switch, operate in the same way as when the failure symptom appears, and check that the same symptoms appears.

Judgement If symptoms do not appear → abnormality in electrical circuit. Go to E-1 step 9.

If symptoms appears → abnormality in hydraulic or mechanical systems. Go to H-1.

Checking by switching prolix circuit	Troubleshooting chart
3 Does problem disappear when prolix circuit switch is operated?	Go to E-1 for abnormalities in electrical system; go to H-1 for abnormalities in hydraulic or mechanical system
1: Engine at half throttle or above	
●	E-1 H-1


021TA1

Cause	Remedy
Control box defective. (circuit between CNC8 (6), (7) and inside of box)	Replace
Disconnection in wiring harness, defective contact or contact between chassis ground and CNE9 (1), (2) – CNA18 (10), (9) – CNC8 (6), (7).	Clean (defective contact) or replace.
Potentiometer defective or mounting defective.	Adjust or replace.
Disconnection in wiring harness, defective contact or contact between chassis ground CNE9 (1), (2) – CNA18 (10), (8) – CNC8 (6), (8).	Clean (defective contact) or replace.
Control box defective. (circuit between CNC8 (6), (8) and inside of box)	Replace


021TA1

E-1 Related electrical circuit diagram

(2) For rear




E-3 Related electrical circuit diagram
(2) For rear



021TA1

E-7 Related electrical circuit diagram




021TA1

Troubleshooting Chart No. H-5 (3-Stage mode selector OLSS)

Failure mode: Work equipment, travel, and swing start suddenly during fine control operations.

★ The judgement values in the troubleshooting are the values for H mode.

021TA1



Troubleshooting tools	Oil pressure gauge (60 kg/cm ²)	Sleeve nut, plug
	Thermistor kit	—

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL


- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

021TA1



Cause	Remedy
Defective swing motor	Replace
Defective swing motor parking brake	Replace
Defective swing brake solenoid valve	Replace
Drop in set pressure of swing control valve main relief valve	Adjust, replace
Defective swing motor	Replace
Defective CO · NC valve	Replace
Defective orifice of jet sensor relief valve	Replace
Defective check valve	Replace
Defective safety valve	Replace
Defective control valve	Replace
Defective left swing PPC valve	Replace
Defective control valve	Replace

Troubleshooting Chart No. W-1

Failure mode: In ARC digging mode (horizontal selector switch OFF), machine carries out horizontal digging or bucket angle compensation.

- ★ When disconnecting connectors to connect the T-adapter (or socket adapter), always turn the starting switch OFF.
- ★ When connecting the T-adapter, connect the connector specified in () to the side specified; if there is no connector specified in (), connect to both the male and female.
- ★ After checking, connect disconnected connectors immediately.





Table 1

Work equipment control box power source switch	ON	Continuity
	OFF	No continuity

Table 2

Work equipment control box power source switch	ON	Approx. 24V
	OFF	0V


W-1 Related electrical circuit diagram



Troubleshooting Chart No. W-3

Failure mode: In horizontal digging mode (bucket angle compensation switch OFF), machine carries out bucket angle compensation.


- ★ When disconnecting connectors to connect the T-adapter (or socket adapter), always turn the starting switch OFF.
- ★ When connecting the T-adapter, connect the connector specified in () to the side specified; if there is no connector specified in (), connect to both the male and female.
- ★ After checking, connect disconnected connectors immediately.



Table

Bucket angle compensation switch	ON	24V
	OFF	0V


W-3 Related electrical circuit diagram



021TA1


a) - 5) **Abnormality in boom potentiometer system**

Abnormality in boom potentiometer system




Table

CN-J5	CN-J1	Voltage V
(1) ~ (3)	(1) ~ (3)	7.3 ~ 7.35
(1) ~ (2)	(2) ~ (3)	0.5 ~ 4.7




a) - 6) **Abnormality in arm potentiometer system**

Abnormality in arm potentiometer system




Table

CN-F1	CN-J6	CN-J1	Voltage V
(1) - (3)	(1) - (3)	(4) - (6)	7.3 - 7.35
(1) - (2)	(1) - (2)	(5) - (6)	0.5 - 4.7



021TA1


e)  (Coolant level) flashes.





Cause	Remedy
Defective coolant level sensor system	Replace if any defective after checking according to reference value table.
Defective monitor	Replace
Disconnection in wiring harness, or defective contact between CNJ4 (1) - CNA11 (10) - CNBA2 (8) - CNA2 (8) - CNP1 (female) (12).	Clean (defective contact) or replace
Disconnection in wiring harness, or defective contact between CNJ4 (female) (2) - CNA11 (3) - chassis ground.	Clean (defective contact), or replace, or testing, adjusting

Troubleshooting tools	Tester	Short connector
	T-adapter or socket adapter (for DLI)	T-adapter or socket adapter (for ECONOSEAL)

M-3 Related electrical circuit diagram for item e)




f)  (Engine oil level) flashes.



Cause	Remedy
Defective engine oil level sensor system	Replace if any defective after checking according to reference value table.
Defective monitor	Replace
Disconnection in wiring harness, or defective contact between CNE5 (female) (1) - CNJ3 (1) - CNA11 (8) - CNBA2 (7) - CNA2 (7) - CNP1 (female) (14).	Clean (defective contact) or replace
Disconnection in wiring harness, or defective contact between CNE5 (female) (2) - CNJ3 (2) - CNA11 (3) - chassis ground.	Clean (defective contact) or replace

Troubleshooting tools	Tester	Short connector
	T-adapter or socket adapter (for DLI)	T-adapter or socket adapter (for ECONOSEAL)


M-3 Related electrical circuit diagram for item f)



Troubleshooting Chart No. M-7

Failure mode: When starting switch is turned ON (engine stopped), buzzer does not sound for 1 sec. Caution items are flashing, but buzzer does not sound.

- ★ When disconnecting connectors to connect the T-adaptor (or socket adapter), always turn the starting switch OFF.
- ★ When connecting the T-adaptor, connect the male and female; when connecting the socket adapter, connect to the connector specified in ().
- ★ After checking, connect disconnected connectors immediately.




- 1) Connect T-adaptor to CNH45 (female).
2) Turn starting switch ON.

Troubleshooting tools	Tester	Short connector
	T-adaptor or socket adaptor (for DLI)	T-adaptor or socket adaptor (for Econoseal)

Troubleshooting Chart No. M-8

Failure mode: There is no abnormal display on monitor, but buzzer sounds.


- ★ When disconnecting connectors to connect the T-adaptor (or socket adapter), always turn the starting switch OFF.
- ★ When connecting the T-adaptor, connect the male and female; when connecting the socket adapter, connect to the connector specified in ().
- ★ After checking, connect disconnected connectors immediately.



- 1) Remove CNP2.
2) Turn starting switch ON.


Troubleshooting tools	Tester	Short connector
	T-adaptor or socket adaptor (for DLI)	T-adaptor or socket adaptor (for Econoseal)

M-7, M-8 Related electrical circuit diagram




SERVO VALVE (for No. 2, 4 F pumps) Removal and Installation	30-164	BOOM CYLINDER (BACKHOE) Removal	30-194
		Installation	30-196
SERVO VALVE (for No. 2, 4 R pumps) Removal and Installation	30-164	ARM CYLINDER (BACKHOE) Removal and Installation	30-198
SERVO VALVE (for swing pump) Removal and Installation	30-166	BUCKET CYLINDER (BACKHOE) Removal	30-200
SERVO VALVE (for No. 2, 4 F pumps with TVC) Removal and Installation	30-166	Installation	30-202
CO • NC VALVE (for No. 2, 4 R pumps) Removal and Installation	30-168	HYDRAULIC CYLINDER (BACKHOE) Disassembly	30-204
CO • NC VALVE (for swing pump) Removal and Installation	30-168	Assembly	30-208
TVC VALVE (for No. 2, 4 pump) Removal and Installation	30-170	BUCKET (BACKHOE) Removal and Installation	30-212
TRAVEL PPC VALVE Removal and Installation	30-172	BUCKET (LOADING SHOVEL) Removal and Installation	30-214
Disassembly and Assembly	30-172	ARM (BACKHOE) Removal	30-216
PPC VALVE Removal and Installation	30-174	Installation	30-218
Disassembly and Assembly	30-174	ARM (LOADING SHOVEL) Removal and Installation	30-220
BOOM CYLINDER (LOADING SHOVEL) Removal	30-176	BOOM (BACKHOE) Removal	30-222
Installation	30-178	Installation	30-224
ARM CYLINDER (LOADING SHOVEL) Removal and Installation	30-180	BOOM (LOADING SHOVEL) Removal and Installation	30-226
BUCKET CYLINDER (LOADING SHOVEL) Removal and Installation	30-182	BUCKET, ARM (BACKHOE) Removal	30-228
BOTTOM CYLINDER (LOADING SHOVEL) Removal and Installation	30-184	Installation	30-230
HYDRAULIC CYLINDER (LOADING SHOVEL) Disassembly	30-186	WORK EQUIPMENT Removal	20-232
Assembly	30-190	Installation	20-236


P1



P6




P7




P2




P3




P4




P5



P1




P2




P3




P4




P5




P6




P7




P8




P9




P10




P1




P2




P3




P4




F1




P5



P6




F1




209F3301

P4




205P2104

P5




205P2105

P6




205P2106

P1




205P2101

P2




208P1007

P7




205P2107

P8




205P2108

P3




205P2103

P9




205P2109

F1




P2



P21TA01030


P3

P4




021TA1

P1




P5


F3




F2




P1




P5



P2




P6




021TA1


P3




F1



P7




P4




21TAPO1153

P1




21TAPO1184

P2




21TAPO1185

P3



21TAPO1186

P4




21TAPO1187


021TA1

021TA1


P1




F1




P6




P7




P2




P3




F3




F2




P8




P9




P4




P5



P10




P11




021TA1


P1




P2




P8




P9




P3




P4




P10




P11




F1




P5




P12




P13




P6



P7




P14




021TA1

P1




P21TA01056

P4




21TAP01200

P5




21TAP01201

F1




209F098

P6




P21TA01058

P2




21TAP01199

F2




209F099A

P3












P21TA157

F3




F21T01055




021TA1


F1




P1



P2











P3




021TA1


021TA1







P1



F1




021TA1




021TA1


P1




P2



F1




F2




021TA1

021TA1


P1




P2




P3




F1




F2



P1




P2




021TA1

F1




209F3313

P1




209P3098

P7




209P3094

P2




209P3106

P3




209P3107

P4




209P3097

P5



209P3096


P6




209P3095

021TA1


P1




F1




P2




P3




P4




P1




F1




P2




P3



P4




P5




021TA1


P1




P2




P3




P4




P5




P1




P6




P2




P7




P3




P8




P4



P5




P9



021TA1

TRAVEL SHUTTLE VALVE





209F3153A

021TA1

Unit: mm

No.	Check item	Criteria				Remedy	
		Standard size		Repair limit			
		Free length x O.D.	Installation length	Installation load	Free length	Installation load	
1	Spool return spring	-	20	3.56 kg	-	-	Replace spring if any damages or deformations are found

TRACK FRAME








021TA1

21TAF01063

Unit: mm

No.	Check item		Criteria			Remedy
			Standard size	Tolerance	Repair limit	
1	Vertical width of idler guide	Track frame	227.5	227.5^{+3}_{-2}	235	Rebuild
		Idler support	225	225 ± 0.5	218	
2	Horizontal width of idler guide	Track frame	420	420^{+5}_{-2}	430	Rebuild
		Idler support	416	—	405	Replace

V1 CONTROL VALVE



021TA1

21TAF01070

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL