

SHOP

MANUAL

KOMATSU

PC20MRX-1

MACHINE MODEL

SERIAL NUMBER

PC20MRX-1

10001 and up

- This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you may require. Materials and specifications are subject to change without notice.
- PC20MRX-1 mount the 3D74E-N3A engine.
For details of the engine, see the 68E-88E Series Engine Shop Manual.



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

	Type 1	Type 2
<p>Connection</p>	<ul style="list-style-type: none"> Hold the mouthpiece of the tightening portion and push body (2) in straight until sliding prevention ring (1) contacts contact surface a of the hexagonal portion at the male end to connect it.  <p>The diagram shows a hand holding a coupling device. An arrow labeled '2' points to the left, indicating the direction of the push body. A circular inset shows a close-up of the sliding prevention ring (1) making contact with surface 'a' of a hexagonal portion.</p> <p style="text-align: right;">CWP06391</p>	<ul style="list-style-type: none"> Hold the mouthpiece of the tightening portion and push body (2) in straight until sliding prevention ring (1) contacts contact surface a of the hexagonal portion at the male end to connect it.  <p>The diagram shows a hand holding a coupling device. An arrow labeled '2' points to the left, indicating the direction of the push body. A circular inset shows a close-up of the sliding prevention ring (1) making contact with surface 'a' of a hexagonal portion.</p> <p style="text-align: right;">CWP06392</p>

kgm to ft. lb

1 kgm = 7.233 ft. lb

	0	1	2	3	4	5	6	7	8	9
0	0	7.2	14.5	21.7	28.9	36.2	43.4	50.6	57.9	65.1
10	72.3	79.6	86.8	94.0	101.3	108.5	115.7	123.0	130.2	137.4
20	144.7	151.9	159.1	166.4	173.6	180.8	188.1	195.3	202.5	209.8
30	217.0	224.2	231.5	238.7	245.9	253.2	260.4	267.6	274.9	282.1
40	289.3	296.6	303.8	311.0	318.3	325.5	332.7	340.0	347.2	354.4
50	361.7	368.9	376.1	383.4	390.6	397.8	405.1	412.3	419.5	426.8
60	434.0	441.2	448.5	455.7	462.9	470.2	477.4	484.6	491.8	499.1
70	506.3	513.5	520.8	528.0	535.2	542.5	549.7	556.9	564.2	571.4
80	578.6	585.9	593.1	600.3	607.6	614.8	622.0	629.3	636.5	643.7
90	651.0	658.2	665.4	672.7	679.9	687.1	694.4	701.6	708.8	716.1
100	723.3	730.5	737.8	745.0	752.2	759.5	766.7	773.9	781.2	788.4
110	795.6	802.9	810.1	817.3	824.6	831.8	839.0	846.3	853.5	860.7
120	868.0	875.2	882.4	889.7	896.9	904.1	911.4	918.6	925.8	933.1
130	940.3	947.5	954.8	962.0	969.2	976.5	983.7	990.9	998.2	1005.4
140	1012.6	1019.9	1027.1	1034.3	1041.5	1048.8	1056.0	1063.2	1070.5	1077.7
150	1084.9	1092.2	1099.4	1106.6	1113.9	1121.1	1128.3	1135.6	1142.8	1150.0
160	1157.3	1164.5	1171.7	1179.0	1186.2	1193.4	1200.7	1207.9	1215.1	1222.4
170	1129.6	1236.8	1244.1	1251.3	1258.5	1265.8	1273.0	1280.1	1287.5	1294.7
180	1301.9	1309.2	1316.4	1323.6	1330.9	1338.1	1345.3	1352.6	1359.8	1367.0
190	1374.3	1381.5	1388.7	1396.0	1403.2	1410.4	1417.7	1424.9	1432.1	1439.4


WEIGHT TABLE

! This weight table is a guide for use when transporting or handing components.

Unit: kg

Machine model	PC20MRX-1	
	Canopy specification	Cab specification
Serial number	10001 and up	
Engine assembly		
• Engine	115	115
• Engine mount	7	7
• P.T.O	5.5	5.5
• Hydraulic pump	19	19
Radiator assembly	14.4	14.4
Revolving frame	195.3	195.3
Operator's cab	—	130
Canopy assembly	70.3	—
Operator's seat	10.7	10.7
Fuel tank	3.2	3.2
Hydraulic tank	23.6	23.6
Main control valve assembly	33.2	33.2
Counterweight (with x-type weight)	355	355
Swing motor, swing machinery	28	28
Center swivel joint	7	7


TRACK FRAME



- 1. Idler
- 2. Track frame
- 3. Shoe plate
- 4. Travel motor

- 5. Sprocket
- 6. Track roller
- 7. Idler cushion
- 8. Track shoe

1. MAIN PUMP




SDP02967

- 1. Shaft
- 2. Oil seal
- 3. Case (acts also as cradle)
- 4. Rocker cam
- 5. Shoe
- 6. Piston
- 7. Cylinder block
- 8. Valve plate
- 9. Spring
- 10. Servo piston (acts also as TCC valve)


- For example, after balancing at an area of opening 1/4 of the control valve, if the system is operated to 3/4 of the area of opening of the control valve, LS differential pressure ΔPLS will drop momentarily.
As a result, the LS valve is actuated and the pump discharge amount is increased, but when the pump swash plate angle rises to 3/4, the LS differential pressure ΔPLS rises to 1.6 MPa {16 kg/cm²}, so it is balanced in this position.

(4/7)



- | | |
|---|---|
| 1. Unload valve | 11. Pressure compensation valve R (boom) |
| 2. Pressure compensation valve F (swing) | 12. Pressure compensation valve R (arm) |
| 3. Pressure compensation valve F (R.H. travel) | 13. Pressure compensation valve piston
(boom swing, blade) |
| 4. Pressure compensation valve F (L.H. travel) | 14. Pressure compensation valve R
(boom swing, blade) |
| 5. Pressure compensation valve F
(boom swing, blade) | 15. Pressure compensation valve R (L.H. travel) |
| 6. Spool (breaker) | 16. Pressure compensation valve R (R.H. travel) |
| 7. Pressure compensation valve F (arm) | 17. Pressure compensation valve R (swing) |
| 8. Pressure compensation valve F (boom) | 18. LS bypass plug |
| 9. Pressure compensation valve F (bucket) | 19. Back-pressure check valve |
| 10. Pressure compensation valve R (bucket) | |

- 3) When the control valve is being operated and the demand flow for the actuator becomes greater than the pump discharge from the minimum swash plate angle, the flow of the oil out to tank circuit **T** is shut off, and all the pump discharge amount **Q** flows to the actuator circuit.



SDP02996

OPERATION

Control valve operated


- When the control valve is operated to a larger stroke, LS pressure **PLS** is generated and acts on area **S3** at the right end of spool (1). When this happens, the area of the opening of the control valve spool is large, so the difference between LS pressure **PLS** and pump discharge pressure **PP** is small.
- For this reason, the difference in pressure between pump discharge pressure **PP** and LS pressure **PLS** does not reach the load of spring (2) (2.9 MPa {30 kg/cm²}), so spool (1) is pushed to the left by spring (2).
- As a result, pump circuit **PP** and tank circuit **T** are shut off, and all the pump discharge amount **Q** flows to the actuator circuit.

- PP:** Pump circuit
- PLS:** LS circuit
- T:** Tank circuit
- A:** To valves
- B:** To pump LS valve

8. Swing holding brake cancel system

Function

- The system uses the swing PPC pressure and the arm IN PPC pressure as a signal to cancel the shaft brake of the swing motor.




SWP07364

Operation

- The left and right swing PPC pressure and the arm IN PPC pressure each pass through check valve (2) inside spring case (1), are output to port **Br**, and the swing holding brake is canceled. (The highest pressure is output to port **Br**.)
- The arm and swing are connected by the pilot circuit inside the control valve.


4) When actuators are operated simultaneously (example: boom and arm)



SWP06176

PPC VALVE

FOR BOOM, ARM, BUCKET, SWING




SBP04416

P: From PPC control valve
T: To tank

P1: Left: Arm IN / Right: Boom RAISE
P2: Left: Arm OUT / Right: Boom LOWER
P3: Left: Swing right / Right: Bucket DUMP
P4: Left: Swing left / Right: Bucket CURL

ELECTRICAL WIRING DIAGRAM



SWP06085


- | | |
|------------------------------------|-------------------------------|
| 1. Working lamp | 9. Engine oil pressure switch |
| 2. Battery | 10. Fuel feed pump |
| 3. Fusible link | 11. 2-spool solenoid valve |
| 4. Fuel level sensor | 12. Boost pedal |
| 5. Horn switch | 13. PPC lock switch |
| 6. Alternator | 14. Horn |
| 7. Engine water temperature sensor | 15. Engine stop solenoid |
| 8. Starting motor | |

Applicable model				PC20MRX-1		
Category	Item	Measurement conditions	Unit	Standard value for new machine	Service limit value	
Operating effort of control levers	Boom control lever	<ul style="list-style-type: none"> • Engine at full throttle • Oil temperature: 45 – 55°C • Fit push-pull scale to center of control lever knob to measure • Fit push-pull scale to tip of pedal to measure • Measure max. value to end of travel 	N {kg}	13.7 ± 2.94 {1.4 ± 0.3}	13.7 ± 2.94 {1.4 ± 0.3}	
	Arm control lever			13.7 ± 2.94 {1.4 ± 0.3}	13.7 ± 2.94 {1.4 ± 0.3}	
	Bucket control lever			12.7 ± 2.94 {1.3 ± 0.3}	12.7 ± 2.94 {1.3 ± 0.3}	
	Swing control lever			12.7 ± 2.94 {1.3 ± 0.3}	12.7 ± 2.94 {1.3 ± 0.3}	
	Boom swing control lever			41.2 ± 14.7 {4.2 ± 1.5}	41.2 ± 29.4 {4.2 ± 3.0}	
	Blade control lever			32.4 ± 14.7 {3.3 ± 1.5}	32.4 ± 29.4 {3.3 ± 3.0}	
	Travel control lever			14.7 ± 4.90 {1.5 ± 0.5}	12.7 ± 2.94 {1.3 ± 0.3}	
	Fuel control lever			Min. → Max.	22.6 ± 4.9 {2.3 ± 0.5}	22.6 ± 4.9 {2.3 ± 0.5}
				Max. → Min.	22.6 ± 4.9 {2.3 ± 0.5}	22.6 ± 4.9 {2.3 ± 0.5}
Hydraulic pressure	Unload pressure	<ul style="list-style-type: none"> • Oil temperature: 45 – 55°C • Engine at full throttle • All levers at neutral • Pump outlet port pressure 	MPa {kg/cm ² }	Max. 3.4 {Max. 35}	Max. 3.4 {Max. 35}	
	Boom	<ul style="list-style-type: none"> • Oil temperature: 45 – 55°C • Engine at full throttle • Pump outlet port pressure • Relieve only circuit to be measured 		20.59 ^{+0.49} ₀ {210 ⁺⁵ ₀ }	20.59 ^{+0.49} ₀ {210 ⁺⁵ ₀ }	
	Arm			20.59 ^{+0.49} ₀ {210 ⁺⁵ ₀ }	20.59 ^{+0.49} ₀ {210 ⁺⁵ ₀ }	
	Bucket			20.59 ^{+0.49} ₀ {210 ⁺⁵ ₀ }	20.59 ^{+0.49} ₀ {210 ⁺⁵ ₀ }	
	Swing			12.75 ^{+0.49} ₀ {130 ⁺⁵ ₀ }	12.75 ^{+0.49} ₀ {130 ⁺⁵ ₀ }	
	Boom swing			20.59 ^{+0.49} ₀ {210 ⁺⁵ ₀ }	20.59 ^{+0.49} ₀ {210 ⁺⁵ ₀ }	
	Blade			20.59 ^{+0.49} ₀ {210 ⁺⁵ ₀ }	20.59 ^{+0.49} ₀ {210 ⁺⁵ ₀ }	
	Travel			20.59 ^{+0.49} ₀ {210 ⁺⁵ ₀ }	20.59 ^{+0.49} ₀ {210 ⁺⁵ ₀ }	
	Control pump			2.94 ^{+0.49} ₀ {30 ⁺⁵ ₀ }	2.94 ^{+0.49} ₀ {30 ⁺⁵ ₀ }	
	LS differential pressure				<ul style="list-style-type: none"> • Oil temperature: 45 – 55°C • Engine at full throttle ★ LS differential pressure = Pump outlet port pressure – LS pressure 	All levers at hold
			Travel under no load, travel lever at half-way position	1.57 {16}	1.57 {16}	

TOOLS FOR TESTING, ADJUSTING, AND TROUBLESHOOTING

Check or measurement item	Symbol	Part No.	Part Name	Remarks	
Engine speed	A	1	799-203-9000	Multi-tachometer	Digital display L: 60 – 2,000 rpm H: 60 – 19,999 rpm
		2	• 799-203-8901	• Clamp set	
Coolant and oil temperatures	B	799-101-1502	Digital temperature gauge	–99.9 — +1,299°C	
Oil pressure	1	799-101-5002	Hydraulic tester	Pressure gauge: 2.5,5.9,39.2,58.8 MPa {25,60,400,600 kg/cm ² }	
		790-261-1203	Digital hydraulic tester	Pressure gauge: 68.6MPa(700 kg/cm ²)	
	2	• 799-101-5160	• Nipple	PT1/8	
		799-101-5220	Nipple	10 × 1.25	
		07002-11023	O-ring		
	3	• 790-261-1340	• Adapter	10 × 1.25 (female PT 1/8) for both male and female	
		• 790-261-1311		14 × 1.5 (female PT 1/8) for both male and female	
		• 790-261-1321		18 × 1.5 (female PT 1/8) for both male and female	
		• 790-261-1331		22 × 1.5 (female PT 1/8) for both male and female	
	4	790-401-2320	Hydraulic gauge	1.0 MPa {10 kg/cm ² }	
	5	799-401-2701	Differential pressure gauge		
Compression pressure	D	1	795-502-1205	Compression gauge	0 – 6.9 MPa {0 – 70 kg/cm ² }
		2	795-111-1120	Adapter	
			795-111-1110		
	3	• 795-101-1571	• Joint		
Valve clearance	E	Commercially available	Feeler gauge		
Exhaust color	F	1	799-201-9000	Handy Smoke Checker	Discoloration 0 – 70% (with standard color) (Discoloration % × 1/10 = Bosch index)
		2	Commercially available	Smoke meter	
Operating effort	G	Commercially available	Push-pull scale		
Stroke, hydraulic drift	H	Commercially available	Scale		
Work equipment speed	J	Commercially available	Stop watch		
Measuring voltage and resistance values	K	Commercially available	Tester		
Troubleshooting of wiring harnesses and sensors	L	799-601-8000	T-adapter kit		
Measuring wear of sprocket	M	796-127-1111	Wear gauge		

MEASURING SPROCKET WEAR



TLP01303

1. Remove the track shoe assembly.
 - ★ For details, see DISASSEMBLY AND ASSEMBLY, REMOVAL OF RUBBER SHOE ASSEMBLY or REMOVAL OF STEEL SHOE ASSEMBLY.
2. Align wear gauge **M** with the sprocket.
 - ★ Align the standard line, then align the wave shape of the sprocket with the wave shape of the wear gauge.
3. Judge the sprocket wear.
 - ★ If the wave shape of the sprocket is above the wear limit line: It is possible to continue to use the sprocket.
 - ★ If the wave shape of the sprocket has reached the wear limit line: Replace the sprocket with a new part.

RELEASING REMAINING PRESSURE FROM HYDRAULIC CIRCUIT

⚠ There is no accumulator installed, so the remaining pressure in the piping between the control valve and hydraulic cylinder or swing motor cannot be released by operating the control levers.

When the above piping is removed, be careful of the following points.

1. Run the engine at low idling, operate the hydraulic cylinders so that as far as possible the pressure is not relieved at the end of the stroke, lower the work equipment to the ground, then stop the engine.
 - ★ If the engine is stopped with the hydraulic circuit relieved and the hydraulic cylinder at the end of its stroke, do not carry out any work for 5 to 10 minutes.
2. When removing the piping, loosen the piping sleeve nut gradually to release the pressure remaining in the piping slowly, then remove the piping after the oil stops spurting out.

RELEASING REMAINING PRESSURE FROM HYDRAULIC TANK

⚠ The hydraulic tank is a sealed type, so it is pressurized.


When removing the hoses or plugs installed to the hydraulic tank, release the remaining pressure in the hydraulic tank as follows.

1. Lower the work equipment to the ground and stop the engine.
2. Loosen the hydraulic tank oil filler plug slowly to release the pressure inside the hydraulic tank.

PRESSURIZING HYDRAULIC TANK

★ If the oil filler plug of the hydraulic tank has been removed, pressurize the hydraulic tank as follows.

1. Run the engine at low idling and set the work equipment to the pressurizing posture.
2. Stop the engine, open the hydraulic tank oil filler plug, then tighten it again.
 - ★ This operation pressurizes the hydraulic tank.
3. Start the engine and lower the work equipment to the ground.




- **Drying wiring harness**


If there is any oil or dirt on the wiring harness, wipe it off with a dry cloth. Avoid washing it in water or using steam. If the connector must be washed in water, do not use high-pressure water or steam directly on the wiring harness.

If water gets directly on the connector, do as follows.


- ① Disconnect the connector and wipe off the water with a dry cloth.
 - ★ If the connector is blown dry with compressed air, there is the risk that oil in the air may cause defective contact, so remove all oil and water from the compressed air before blowing with air.













- ② Dry the inside of the connector with a dryer. If water gets inside the connector, use a dryer to dry the connector.
 - ★ Hot air from the dryer can be used, but regulate the time that the hot air is used in order not to make the connector or related parts too hot, as this will cause deformation or damage to the connector.



- ③ Carry out a continuity test on the connector. After drying, leave the wiring harness disconnected and carry out a continuity test to check for any short circuits between pins caused by water.
 - ★ After completely drying the connector, blow it with contact restorer and reassemble.



No. of pins	M type connector	
	Male (female housing)	Female (male housing)
2	 <p>BLP00038</p>	 <p>BLP00039</p>
3	 <p>TEW00243</p>	 <p>TEW00244</p>
4	 <p>TEW00245</p>	 <p>TEW00246</p>
6	 <p>TEW00247</p>	 <p>TEW00248</p>
8	 <p>BLP00040</p>	 <p>BLP00041</p>

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

E-1 Engine does not start

a) When starting motor does not turn (starting system)

- ★ Check that fuse 5 is normal (if it is blown, check for a short circuit with the ground in the circuits related to fuse 5).
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.




TABLE OF FAILURE MODES AND CAUSES

Failure mode		Parts causing failure		Hydraulic pump							Control valve				
				Damper	Strainer	PC valve	LS valve	Servo piston	Piston pump	Gear pump	Spool	Unload valve	Main relief valve	Self pressure reducing valve	Sequence valve
All work equipment, travel, swing	Speeds of all work equipment, swing, travel are slow or lack power			●		●	●	●			●	●	●	●	
	There is excessive drop in engine speed, or engine stalls			●		●	●				●				
	No work equipment, travel, swing move	●						●	●				●		
	Abnormal noise generated (around pump)		●					●							
	Fine control ability is poor or response is poor			●	●	●	●				●				
Work equipment	Boom is slow or lacks power									●					
	Arm is slow or lacks power									●					
	Bucket is slow or lacks power									●					
	Boom swing is slow or lacks power									●					
	Blade is slow or lacks power									●					
	Boom does not move									●					
	Arm does not move									●					
	Bucket does not move									●					
	Excessive hydraulic drift	Boom									●				
		Arm									●				
		Bucket									●				
		Boom swing									●				
Blade										●					
Excessive time lag															
In compound operations, work equipment with larger load is slow															
Travel system	Travel deviation	Deviation during normal travel									●				
		Deviation when starting													
	Travel speed is slow or lacks power			●		●					●				
	Steering does not turn easily									●					
	Travel speed does not switch														
Travel does not move (one side only)															
Swing system	Swing speed is slow or lacks power	Both left and right								●					
		One direction only									●				
	Does not swing	Both left and right								●					
		One direction only									●				
	Swing acceleration is poor	Both left and right									●				
		One direction only									●				
	Excessive overrun when stopping swing	Both left and right									●				
		One direction only									●				
Excessive shock when stopping swing (one direction only)										●					
Excessive abnormal noise when stopping swing															
Excessive hydraulic drift of swing															

H-13 Excessive time lag (engine at low idling)

★ When the work equipment speed is normal.


	Cause	Remedy
	Defective suction valve	Repair or replace

H-14 In compound operations, work equipment with larger load is slow

	Cause	Remedy
	Defective operation of pressure compensation valve on side where load is light	Replace

	Combination for compound operation	Side with larger load	Side with lighter load
1	Boom RAISE + arm IN	Boom RAISE	Arm IN
2	Boom RAISE + arm OUT	Arm OUT	Boom RAISE
3	Boom RAISE + bucket CURL	Boom RAISE	Bucket CURL
4	Arm OUT + bucket CURL	Arm OUT	Bucket CURL
5	Boom LOWER + arm OUT	Arm OUT	Boom LOWER

ELECTRICAL CIRCUIT DIAGRAM FOR M MODE RELATED PARTS




TJP01959


M-11 Abnormality in fuel gauge

- ★ When the fuel level is normal.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.

a) Level does not rise from segment E or all segments go out



b) Level does not go down from segment F



SPECIAL TOOL LIST


- ★ Necessity: ■ Cannot be substituted, should always be installed (used)
 ● Extremely useful if available, can be substituted with commercially available part

Device	Symbol	Part No.	Part Name	Necessity	Qty	New/Modified	Sketch	Details of work, Remarks
Disassembly and assembly of idler assembly	L	1	790-101-5201	Push tool kit B	●	1		Press-fitting of bearing
			• 790-101-5231	• Plate		1		
			• 790-101-5221	• Grip		1		
			• 01010-51225	• Bolt		1		
	2	790-201-2720	Spacer	●	1		Press-fitting of oil seal	
Disassembly and assembly of track roller assembly	L	3	790-101-5001	Push tool KIT A	●	1		Press-fitting of bushing
			• 790-101-5051	• Plate		1		
			• 790-101-5021	• Grip		1		
			• 01010-50816	• Bolt		1		
	4	790-434-1660	Installer	■	1		Press-fitting of floating seal	
Disassembly and assembly of recoil spring	M	792-371-1400	Sleeve	■	1			
Disassembly and assembly of hydraulic cylinder assembly	U	1	790-502-1003	Unit repair stand	■	1		Disassembly and assembly of hydraulic cylinder
			790-101-1102	Hydraulic pump	■	1		
		2	790-330-1100	Wrench assembly	■	1		Fastening and unfastening of cylinder head
		3	790-302-1480	Socket (Width across flats : 41mm)	■	1		Fastening and unfastening of boom and blade cylinder piston nut
			790-102-1520	Adapter	■	1		
			Commercial item	Socket (Width across flats : 36mm)	■	1		Fastening and unfastening of bucket cylinder piston nut
			790-102-1520	Adapter	■	1		
			790-302-1390	Socket (Width across flats : 46mm)	■	1		Fastening and unfastening of arm and swing cylinder piston nut
			790-102-1520	Adapter	■	1		
			790-102-1500	Push tool KIT	■	1		INSTALLATION of dust seal, Boom, arm, cylinder, bucket, blade cylinder, offset cylinder
			• 790-102-1550	• Plate		1		
			• 790-201-1540	• Plate		1		
			• 790-201-1530	• Plate		1		
		• 790-101-5021	• Grip		1			
			• 01010-50816	• Bolt		1		
		4	790-720-1000	Expander	●	1		Installation of piston ring
		5	796-720-1630	Ring	●	1		Offset, bucket cylinder
			07281-00709	Clamp	●	1		
			796-720-1740	Ring	●	1		Boom, arm, blade cylinder
			07281-00809	Clamp	●	1		

INSTALLATION OF ENGINE REAR SEAL


- When installation the engine rear seal, reverse the removal procedures.

※ 1

 Seal mounting face of seal case and oil seal lip : **Engine oil (EO30-CD)**


- ★ Press fit the oil seal until it comes to the same level as the seal case.

※ 2

 Seal case mounting face :
Gasket sealant (LG-7)



※ 3

- ★ Tighten the flywheel mounting bolts in the order shown in the drawing on the right.

 Flywheel mounting bolt :
85.75±2.45 Nm {8.75±0.25 kgm}

After mounting the flywheel, measure facial runout and radial runout of the flywheel using with dial gauge ①.

- Facial runout : max 0.20mm.
- Radial runout : max 0.20mm.



REMOVAL OF CENTER SWIVEL JOINT ASSEMBLY




⚠ Stop the machine on a flat ground, lower the work equipment completely to the ground and disconnect the negative (-) terminal of the battery.

1. Remove the swing motor and swing machinery assembly. For details, see REMOVAL OF SWING MOTOR AND SWING MACHINERY ASSEMBLY.
2. Drain hydraulic oil.



Hydraulic oil : approx 25 ℓ.

3. Disconnect the hose (1) between the solenoid valves.
4. Disconnect the hoses (2) (right travel), (3) (left travel) and (4) (blade) between the control valves.
5. Disconnect the tube (5) between the hydraulic tanks.
6. Disconnect the hoses (6) (right travel), (7) (blade) and (8) (left travel) between the control valves.
 - ★ Attach tags to removed hoses.
7. Remove the stopper (9).
8. Disconnect the hose (10) (return) between the right and left travel motors.
9. Disconnect the hoses (11) and (12) between the left travel motors.
10. Disconnect the hose (13) between the blade cylinders.
11. Disconnect two pieces of the hose (14) (acceleration) between the right and left travel motors.
12. Disconnect the hoses (15) and (16) between the right travel motors.
13. Disconnect the hose (17) between the blade cylinders.
14. Remove 4 pieces of the mounting bolt (18) and then the swivel joint assembly (19).




INSTALLATION OF CENTER SWIVEL JOINT ASSEMBLY


- When installing the assembly, reverse the removal procedures.
- **Refilling with oil (Hydraulic Tank)**
Supply oil to the specified level, start the engine to circulate the oil in the pipe and check the oil level again.





Hydraulic oil : 25 ℓ (EO10-W-CD)

- **Bleeding air**
Bleed the air from the hydraulic circuit. For details, see TESTING AND ADJUSTING, Bleeding air.






- 10. Install spring (15) and spring holder (18).
★ Install the sperical portion of the spring holder in the swash plate hole.




- 11. Assemble cylinder barrel assembly (4) to body S (1).




DISASSEMBLY OF IDLER ASSEMBLY

1. Idler

- 1) Remove the cylinder assembly (1).
- 2) Remove the support (2).




- 3) Remove the oil seal (3).
- 4) Remove the snap ring (4) and then the shaft (5).
- 5) Remove two pieces of the bearing (6) from the idler (7).



2. Cylinder

- 1) Remove the valve (8) from the cylinder (9).
- 2) Remove the piston (10) from the cylinder.
- 3) Take off the snap ring (11) and then remove the spacer (12), the dust seal (13), the backup ring (14) and the O-ring (15) in this order.




REMOVAL OF HYDRAULIC OIL COOLER ASSEMBLY

⚠ Stop the machine on a flat ground, lower the work equipment completely to the ground and disconnect the negative (-) terminal of the battery.

1. Remove the machine cover and the counterweight. For details, see REMOVAL OF ENGINE AND HYDRAULIC PUMP ASSEMBLY.

2. Drain hydraulic oil.

 Hydraulic oil : 25 ℓ

3. Remove the grease gun holder (1).

4. Disconnect the hose (2) to the hydraulic oil filter.



5. Disconnect the hose (3) between the check valve and the assembly and the hose (4) from the control valve.

6. Remove the air intake hose bracket (5).

★ The bracket has been tightened together with the hydraulic oil cooler.

7. Remove the hydraulic oil cooler assembly (6).

★ Lift the assembly and disconnect it from the hose (4).




INSTALLATION OF HYDRAULIC OIL COOLER ASSEMBLY

- When installing the assembly, reverse the removal procedures.

- **Refilling with oil (Hydraulic Tank)**





Supply oil to the specified level, start the engine to circulate the oil in the pipe and check the oil level again.


 Hydraulic oil : 25 ℓ (EO10-W-CD)

- **Bleeding air**

Bleed the air from the hydraulic circuit. For details, see TESTING AND ADJUSTING, Bleeding air.

ASSEMBLY OF CONTROL VALVE ASSEMBLY

1. Set the O-ring (24) to each block valve.
2. Set the O-ring (23) to the block valves (16) (swing), (15) (right/left travel), (14) (swing) and (13) (blade).
3. Set the O-ring to the block (18).
4. Set the O-rings (21), (20) and (19) to the block valve (17) (body valve), (16) (swing), (15) (right/left travel), (14) (swing), (13) (blade), (12) (arm), (11) (boom) and (10) (bucket).
 - ★ The O-ring (20) is not necessary to the valve body (17).
5. Set the ring (9) to the block valve (10) (bucket).
6. Assemble the valve body and tighten the bolts (8) and (7).
 -  Mounting bolts (8) and (7) :
29.4 – 34.3Nm {3.0 – 3.5kgm}
7. Set the O-ring to the plug (6) and screw the plug in the cover (1).
 -  Plug (6) : **19.6 – 24.5Nm {2.0 – 2.5kgm}**
8. Set the O-ring to the plug (5) and screw the plug in the cover (1).
 -  Plug (5) : **34.3 – 44.1Nm {3.5 – 4.5kgm}**
9. Set the O-ring backup rings (4) and (3) to the plug (2) and screw the plug in the cover (1).
 -  Plug (2) : **34.3 – 44.1Nm {3.5 – 4.5kgm}**



REMOVAL OF BOOM CYLINDER ASSEMBLY

⚠ Start the engine, extend the arm cylinder and the bucket cylinder fully and lower the work equipment completely to the ground.

1. Sling the boom cylinder assembly and remove the pin (1) from the head side. ※ 1

★ When shims are used, check the number and the positions beforehand.


⚠ Start the engine, retract the piston rod and tie the piston rod with wire so that it does not come off.




⚠ Relieve remaining pressure from the hydraulic circuit. For details, see TESTING AND ADJUSTING, releasing remaining pressure from hydraulic circuit.

2. Disconnect two pieces of the hose (2).


3. Remove the pin (3) from the bottom side and lift the boom cylinder assembly (4) to remove it.

★ When shims are used, check the number and the positions beforehand. ※ 2

 Boom cylinder assembly : 20kg




- 4) Disassemble the piston assembly as per the procedures below:
- i) Remove the wear ring (7) from the piston (8).
 - ii) Remove the piston ring (9).




4. Cylinder Head Assembly

- 1) Remove the cylinder head assembly from the piston rod (6).




- 2) Disassemble the cylinder head assembly as per the procedures below:

- i) Take off the O-ring (11) and the backup ring (12) from the cylinder head (14).
- ii) Take off the O-ring (13).
- iii) Rake off the rod packing (15).
- iv) Take off the snap ring (16) using the snap ring pliers.
- v) Take off the dust seal (17).
- vi) Take off the bushing (18) using the tool **U4**.



- 3) Disassemble the boom, arm, blade and offset cylinder assembly as per the procedures below:

- i) Take off the O-ring (19) and the backup ring (20) from the cylinder head (21).
- ii) Take off the O-ring (22).
- iii) Take off the snap ring (24) using the snap ring pliers.
- iv) Take off the dust seal (24).
- v) Take off the rod packing (25).





INSTALLATION OF ARM ASSEMBLY

- Carry out installation in the reverse order to removal.

※ 1

⚠ When aligning the position of the pin hole, never insert your fingers in the pin hole.


 Pin, sliding surface when assembling :
Molybdenum disulphide grease (LM-P)


 Greasing after assembling pin :
Molybdenum disulphide grease (LM-G)

- ★ Adjust the shim thickness so that the clearance "a" between the head of arm cylinder and arm is below 1 mm.
 - Shim thickness : 1 mm

※ 2

⚠ When aligning the position of the pin hole, never insert your fingers in the pin hole.

 Pin, sliding surface when assembling :
Molybdenum disulphide grease (LM-P)

 Greasing after assembling pin :
Molybdenum disulphide grease (LM-G)

- ★ Adjust the shim thickness so that the clearance "b" between arm and boom is below 1 mm.
 - Shim thickness : 1 mm

- **Refilling with oil (hydraulic tank)**



Add oil through the oil filler to the specified level.

- ★ Run the engine to circulate the oil through the system. Then check the oil level again.

- **Bleeding air**

Bleed the air from the bucket cylinder.

For details, see TESTING AND ADJUSTING, Bleeding air.



REMOVAL OF SEAT AND BRACKET ASSEMBLY

⚠ Stop the machine on a flat ground, lower the work equipment completely to the ground and disconnect the negative (-) terminal of the battery.

1. Remove the exterior parts referring to the Paragraph REMOVAL OF COUNTERWEIGHT ASSEMBLY.
2. Remove the wiring connector cover (1).
3. Remove two pieces of the floor plate (2).
4. Remove the console box (3) and place it in front of the machine.
5. Remove the side covers (4) and (5).
6. Sling the canopy assembly (6), remove the mounting bolts and lift the assembly to remove it.






Canopy assembly : 23kg

7. Sling the seat and bracket assembly (7).
8. Remove the mounting bolts and lift the assembly to remove it.



Seat and bracket assembly : 67 kg







INSTALLATION OF SEAT AND BRACKET ASSEMBLY

- When installing the assembly, reverse the removal procedures.

HYDRAULIC PUMP


PVK-0B-22



SDP03269

PPC VALVE

FOR BOOM, ARM, BUCKET, SWING



SBP00434

Unit: mm

No.	Check item	Criteria				Remedy	
		Standard size		Repair limit			
		Free length × O.D.	Installed length	Installed load	Free length	Installed load	
1	Centering spring (for P3, P4)	50.4 × 15.5	34	55.9 N {5.7 kg}	—	45.1 N {4.6 kg}	When damage or deformation is found, replace the spring
2	Centering spring (for P1, P2)	44.4 × 15.5	34	29.4 N {3.0 kg}	—	23.5 N {2.4 kg}	
3	Metering spring	26.5 × 8.2	24.9	16.7 N {1.7 kg}	—	13.7 N {1.4 kg}	

90 OTHERS

Hydraulic circuit diagram	90- 3
Electrical circuit diagram	90- 5

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL