

SHOP MANUAL

KOMATSU

PC340LC, 340NLC-7K

MACHINE MODEL

PC340LC-7K

PC340NLC-7K

SERIAL NUMBER

K40001 AND UP

K40001 AND UP

- This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you may require. Materials and specifications are subject to change without notice.
- PC340LC/NLC-7K mount the SAA6D114E engine.
For details of the engine, see the 114 Series Engine Shop Manual.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL


- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

| Machine model | | | PC340LC-7 | PC340NLC-7 | | |
|----------------------------|---|--|---|--|---|----------------------|
| Serial Number | | | 40001 and up | | | |
| Engine | Model Type | | SAA6D114E 4-cycle, water-cooled, in-line, vertical, direct injection, with turbo charger and aftercooler | | | |
| | No. of cylinders - bore x stroke Piston displacement | | mm l {cc} | 6 - 114 x 135 8.27 {8,270} | | |
| | Performance | Flywheel horsepower | kW/rpm {HP/rpm} | 180.3/1,900 {242/1,900} | | |
| | | Max. torque | Nm/rpm {kgm/rpm} | 1,079/1,400 {110/1,400} | | |
| | | Max. speed at no load | rpm | 2,160 | | |
| Min. speed at no load | | rpm | 900 | | | |
| Min. fuel consumption | | g/kWh {g/HPh} | 205 {153} | | | |
| Starting motor | | | 24V, 7.5 kW | | | |
| Alternator | | | 24V, 35 A | | | |
| Battery | | | 12V, 126 Ah x 2 | | | |
| Radiator core type | | | CF19-4 | | | |
| Under-carriage | Carrier roller | | 2 on each side | | | |
| | Track roller | | 7 on each side | 8 on each side | | |
| | Track shoe | | Assembly-type triple grouser, 45 on each side | Assembly-type triple grouser, 48 on each side | | |
| Hydraulic system | Hydraulic pump | Type x No. Delivery Set pressure | l/min MPa (kg/cm ²) | HPV125+125, variable displacement, Piston type x2 267.5 x 2 37.8 {380} | | |
| | | Control valve | Type x No. Control method | | 6-spool type + 1-spool type x 1 Hydraulic | |
| | Hydraulic motor | | Travel motor Swing motor | | HMF160ADT-2, Piston type (with brake valve, parking brake): x 2 KMF230ABE-5, Piston type (with safety valve, holding brake): x 1 reverse rotation check valve | |
| | | Hydraulic cylinder | Type | | Boom | Arm |
| | | | | Double acting piston | Double acting piston | Double acting piston |
| | Inside diameter of cylinder | | mm | 140 | 160 | 140 |
| | Diameter of piston rod | | mm | 100 | 110 | 100 |
| | Stroke | | mm | 1,480 | 1,825 | 1,285 |
| Max. distance between pins | mm | | 3,525 | 4,255 | 3,155 | |
| Min. distance between pins | mm | 2,045 | 2,430 | 1,870 | | |
| Hydraulic tank | | | Closed box type | | | |
| Hydraulic filter | | | Tank return side | | | |
| Hydraulic cooler | | | CFT-1 (Air cooled) | | | |



1. Level plug
2. Drain plug
3. No. 1 planetary gear (No. of teeth: 42)
4. No. 1 sun gear (No. of teeth: 11)
5. No. 2 sun gear (No. of teeth: 19)
6. No. 1 planetary carrier
7. No. 2 planetary carrier
8. Cover
9. Ring gear (No. of teeth: 97)
10. Hub
11. Sprocket
12. Floating seal
13. Travel motor
14. No. 2 planetary gear (No. of teeth: 38)

SPECIFICATIONS

Reduction ratio:


$$-\left(\frac{11+97}{11}\right) \times \left(\frac{19+97}{19}\right) = -58.943$$

SJP08992

Unit: mm

| No. | Check item | Criteria | | Remedy |
|-----|---|--------------------|-----------------|--------------------|
| | | Standard clearance | Clearance limit | |
| 15 | Backlash between No. 1 sun gear and No. 1 planetary gear | Standard clearance | Clearance limit | Replace |
| | | 0.12 ~ 0.44 | 0.90 | |
| 16 | Backlash between No. 1 planetary gear and ring gear | 0.18 ~ 0.62 | 1.20 | |
| 17 | Backlash between No. 2 planetary carrier and motor | 0.06 ~ 0.25 | — | |
| 18 | Backlash between No. 2 sun gear and No. 2 planetary gear | 0.15 ~ 0.51 | 1.00 | |
| 19 | Backlash between No. 2 planetary gear and ring gear | 0.19 ~ 0.66 | 1.30 | |
| 20 | Backlash between No. 2 planetary carrier and No. 2 sun gear | 0.39 ~ 0.80 | 1.60 | |
| 21 | Amount of wear on sprocket tooth | Repair limit: 6 | | Rebuild or replace |
| 22 | Width of sprocket tooth | Standard size | Repair limit | |
| | | 87 | 84 | |


TRACK ROLLER



SJP08999


Unit: mm

| No. | Check item | Criteria | | | | Remedy |
|-----|---|---------------------|--------------|------|--|-------------------------|
| | | Standard size | Repair limit | | | |
| 1 | Outside diameter of flange | 216 | — | | Rebuild or replace | |
| 2 | Outside diameter of tread | 180 | 168 | | | |
| 3 | Thickness of tread | 44.5 | 38.5 | | | |
| 4 | Overall width | 225 | — | | | |
| 5 | Inside width | 85 | — | | | |
| 6 | Width of tread | 49 | 55 | | | |
| 7 | Width of flange | 27 | — | | | |
| 8 | Clearance between shaft and bushing | Standard size 65 | Tolerance | | Standard clearance 0.186 ~ 0.536 | Clearance limit 1.5 |
| | | | Shaft | Hole | | |
| 9 | Interference between roller and bushing | Standard size 72 | Tolerance | | Standard interference 0.014 ~ 0.144 | Interference limit — |
| | | | Shaft | Hole | | |



SJP09037

- | | |
|------------------|-------------------|
| 1. Shaft (Front) | 7. Cylinder block |
| 2. Cradle | 8. Valve plate |
| 3. Case (Front) | 9. End cap |
| 4. Rocker cam | 10. Shaft (Rear) |
| 5. Shoe | 11. Case (Rear) |
| 6. Piston | 12. Servo piston |



SXP09143

(2) PC Valve

1) When pump controller is normal


a. When the load on the actuator is small and pump pressures PP1 and PP2 are low

① Movement of PC-EPC solenoid (1)

- The command current from the pump controller flows to PC-EPC solenoid (1). This command current acts on the PC-EPC valve and outputs the signal pressure. When this signal pressure is received, the force pushing piston (2) is changed.
- On the opposite side to the force pushing this piston (2) is the spring set pressure of springs (4) and (6) and pump pressure **PP1** (self pressure) and **PP2** (other pump pressure) pushing spool (3). Piston (2) stops at a position where the combined force pushing spool (3) is balanced, and

- the pressure (pressure of port C) output from the PC valve changes according to this position.
- The size of command current **X** is determined by the nature of the operation (lever operation), the selection of the working mode, and the set value and actual value for the engine speed.
- ★ Other pump pressure
This is the pressure of the pump at the opposite end.
For the F pump, it is the R pump pressure
For the R pump, it is the F pump pressure

VARIABLE VOLUME VALVE



SJP09051

- 1. Block
- 2. Plug
- 3. Spring
- 4. Piston


PM: To PC valve
 PT: To tank
 PEPC: From self-reducing pressure valve

| No. | Check item | Criteria | | | | | Remedy |
|-----|---------------------------|--------------------------------|------------------|--------------------|--------------|--------------------|--|
| | | Standard size | | | Repair limit | | |
| | | Free length x Outside diameter | Installed length | Installed load | Free length | Installed load | |
| 18 | Regeneration valve spring | 31.5 x 10.3 | 19.5 | 6.2 N {0.6 kg} | — | 4.9 N {0.5 kg} | If damaged or deformed, replace spring |
| 19 | Piston return spring | 48.1 x 10.8 | 28 | 17.5 N {1.8 kg} | — | 14.0 N {1.4 kg} | |
| 20 | Piston return spring | 36.9 x 11.1 | 28 | 29.4 N {3 kg} | — | 23.5 N {2.4 kg} | |

Basic principle


1) Control of pump swash plate

- The pump swash plate angle (pump discharge amount) is controlled so that LS differential pressure ΔPLS (the difference between pump pressure **PP** and control valve outlet port LS pressure **PLS**) (load pressure of actuator) is constant.
 (LS pressure $\Delta PLS =$ Pump discharge pressure **PP** - LS pressure **PLS**)



SBP03454

- If LS differential pressure ΔPLS becomes lower than the set pressure of the LS valve (when the actuator load pressure is high), the pump swash plate moves towards the maximum position; if it becomes higher than the set pressure of the LS valve (when the actuator load pressure is low), the pump swash plate moves towards the minimum position.




SAP03455

Operation of swing lock

1. When swing lock solenoid valve is deactivated

When the swing lock solenoid valve is deactivated, the pressurized oil from the main pump is shut off and port **B** is connected to the tank circuit.


As a result, brake piston (7) is pushed down by brake spring (1), discs (5) and plates (6) are pushed together, and the brake is applied.



2. When swing lock solenoid valve is excited

When the swing lock solenoid valve is excited, the valve is switched and the pressure oil from the main pump enters port **B** and flows to brake chamber **a**.

The pressure oil entering chamber **a** overcomes brake spring (1) and pushes brake piston (7) up. As a result, discs (5) and plates (6) are separated and the brake is released.



OPERATION OF BRAKE VALVE

- The brake valve consists of check valve, counterbalance valve, and safety valve in a circuit as shown in the diagram on the right. (Fig. 1)
- The function and operation of each component is as given below.


1) Counterbalance valve, check valve

Function

- When traveling downhill, the weight of the machine makes it try to travel faster than the speed of the motor.

As a result, if the machine travels with the engine at low speed, the motor will rotate without load and the machine will run away, which is extremely dangerous.

To prevent this these valves act to make the machine travel according to the engine speed (pump discharge amount).




(Fig. 1)

SXP09155

Operation when pressure oil is supplied

- When the travel lever is operated, the pressurized oil from the control valve is supplied to port PA. It pushes open suction safety valve (18a) and flows from motor inlet port MA to motor outlet port MB. However, the motor outlet port is closed by suction safety valve (18b) and spool (19), so the pressure at the supply side rises. (Fig. 2)




(Fig. 2)

SXP09156


- The pressurized oil at the supply side flows from orifice E1 and E2 in spool (19) to chamber S1. When the pressure in chamber S1 goes above the spool switching pressure, spool (19) is pushed to the right in the direction of the arrow.

As a result, port MB and port PB are connected, the outlet port side of the motor is opened, and the motor starts to rotate. (Fig. 3)



(Fig. 3)

SXP09157



SXP09168

3) Fine control (control lever returned)


When lever (5) starts to be returned, spool (1) is pushed up by the force of centering spring (3) and the pressure at port **P1**.

Because of this, fine control hole **f** is connected to drain chamber **D**, and the pressurized oil at port **P1** is released.

If the pressure at port **P1** drops too much, spool (1) is pushed up by metering spring (2), so fine control hole **f** is shut off from drain chamber **D**. At almost the same time, it is connected to pump pressure chamber **PP**, so the pressure at port **P1** supplies the pump pressure until the pressure recovers to a pressure equivalent to the position of the lever.

When the control valve returns, oil in drain chamber **D** flows in from fine control hole **f** of the valve on the side that is not moving.

It passes through port **P2** and goes to chamber **B** to charge the oil. (Fig. 3)




(Fig. 3)

SBP03499


4) At full stroke

Lever (5) pushes down piston (4), and retainer (9) pushes down on spool (1). Fine control hole **f** is shut off from drain chamber **D**, and is connected to pump pressure chamber **PP**. Therefore, the pilot pressure oil from the main pump passes through fine control hole **f** and flows to chamber **A** from port **P1** to push the control valve spool. The return oil from chamber **B** passes from port **P2** through fine control hole **f** and flows to drain chamber **D**. (Fig. 4)



SBP03495

PPC ACCUMULATOR



1. Gas plug
2. Shell
3. Poppet
4. Holder
5. Bladder
6. Oil port


SPECIFICATIONS

Gas capacity:300 cc (for PPC)

SBP00290

2. Arm at HOLD

The oil that has flowed through orifice **a** in valve (2) is closed by pilot piston (1). At the same time, the hold pressure at the bottom end of the arm acts in the right direction on ring-shaped area **C** (= Area of $\varnothing d1$ - Area of $\varnothing d2$) because of the difference in the outside diameter **d1** of valve (2) and seat diameter **d2**. Valve (2) is closed by the total of this force and the force of spring (3), so port **A** and port **B** are shut off.



SXP09173


Unit: mm

| No. | Model | PC340LC-7, PC340NLC-7 |
|-----|---------------------------|---|
| 1 | | $\phi 100 \begin{matrix} +0.1 \\ 0 \end{matrix} / \begin{matrix} -0.036 \\ -0.071 \end{matrix}$ |
| 2 | | $119.3 \begin{matrix} +1.5 \\ 0 \end{matrix} / 116 \pm 1.2$ |
| 3 | | $320 \begin{matrix} +0.5 \\ 0 \end{matrix} / 316 \begin{matrix} -0.3 \\ -0.8 \end{matrix}$ |
| 4 | | $\phi 110 \begin{matrix} 0 \\ -0.5 \end{matrix} / \begin{matrix} -0.036 \\ -0.090 \end{matrix}$ |
| 5 | | 470.6 ± 1 |
| 6 | | 236.5 ± 0.5 |
| 7 | | 1022.4 ± 1 |
| 8 | | $3,178 \pm 3$ |
| 9 | | $2,975.6 \pm 1$ |
| 10 | | 472.5 |
| 11 | | 731.0 ± 0.2 |
| 12 | | 728.0 ± 0.5 |
| 13 | | 513.6 |
| 14 | | $1,670$ |
| 15 | | $\phi 90 \begin{matrix} +0.2 \\ 0 \end{matrix} / \begin{matrix} -0.036 \\ -0.090 \end{matrix}$ |
| 16 | | 345.0 ± 0.5 |
| 17 | | $\phi 90 \begin{matrix} +0.2 \\ 0 \end{matrix} / \begin{matrix} -0.036 \\ -0.090 \end{matrix}$ |
| 18 | Arm as individual part | $330 \begin{matrix} 0 \\ -0.5 \end{matrix}$ |
| | When pressfitting bushing | 345 |
| 19 | Min. | $1,870$ |
| | Max. | $3,155$ |

Input and output signals

| CN-1 | | | CN-2 | | | CN-3 | | |
|---------|---|--------------|---------|------------------------------------|--------------|---------|---------------------------------|--------------|
| Pin No. | Signal name | Input/output | Pin No. | Signal name | Input/output | Pin No. | Signal name | Input/output |
| 1 | — | | 1 | NC | Output | 1 | VB (controller power) | Input |
| 2 | R pump pressure sensor | | 2 | Swing emergency switch | Input | 2 | VIS (solenoid power) | Input |
| 3 | — | Input | 3 | NC | Input | 3 | SOL_COM (solenoid common gnd) | |
| 4 | Signal GND | Input | 4 | 232C_RxD | Input | 4 | Battery relay drive | Output |
| 5 | Abnormality in auto-greasing controller | Input | 5 | Overload sensor (ON/OFF) | Input | 5 | Governor motor A phase (+) | Output |
| 6 | NC | Input | 6 | Overload alarm valid switch | Input | 6 | LS-EPC | Output |
| 7 | Overload sensor (analog) | Input | 7 | Model selection 4 | Input | 7 | Travel junction SOL | Output |
| 8 | F boom pressure sensor | Input | 8 | Attachment circuit selector signal | Output | 8 | Engine stop solenoid (Pull) | Output |
| 9 | — | | 9 | NC | Output | 9 | Bucket CURL pressure SW | Input |
| 10 | Signal GND | Input | 10 | NC | Input | 10 | Boom RAISE pressure SW | Input |
| 11 | Knob SW | Input | 11 | NC | Output | 11 | VB (controller power) | Input |
| 12 | NC | Input | 12 | CAN shield | | 12 | VIS (solenoid power) | Input |
| 13 | Governor motor FB potentiometer | Input | 13 | Model selection 5 | Input | 13 | SOL_COM (solenoid common gnd) | |
| 14 | — | | 14 | 232C_TxD | Output | 14 | KEY_SIG | Input |
| 15 | NC | Input | 15 | NC | Input | 15 | Governor motor A phase (-) | Output |
| 16 | SENS_PWR | Output | 16 | Travel steering signal pressure SW | Input | 16 | PC-EPC | Output |
| 17 | Key Switch (Terminal C) | Input | 17 | Model selection 3 | Input | 17 | Pump merge/divider solenoid | Output |
| 18 | NC | Input | 18 | — | | 18 | Heater relay drive | Output |
| 19 | Throttle potentiometer | Input | 19 | NC | Output | 19 | Bucket DUMP pressure switch | Input |
| 20 | NC | Input | 20 | NC | Input | 20 | Boom LOWER pressure switch | Input |
| 21 | GND (analog GND) | | 21 | S_NET | Input/output | 21 | GND (controller GND) | |
| 22 | POT_PWR | Output | 22 | CAN0_L | Input/output | 22 | VIS (solenoid PWR) | Input |
| 23 | Key switch (terminal ACC) | Input | 23 | CAN1_L | Input/output | 23 | SOL_COM (solenoid common gnd) | |
| 24 | — | | 24 | — | | 24 | KEY_SIG | Input |
| | | | 25 | NC | Input | 25 | Governor motor B phase (+) | Output |
| | | | 26 | NC | Input | 26 | Service flow adjustment EPC (1) | Output |
| | | | 27 | Model selection 2 | Input | 27 | Travel Hi/Lo selector solenoid | Output |
| | | | 28 | NC | Input | 28 | 2-stage relief solenoid | Output |
| | | | 29 | GND (pulse GND) | | 29 | Swing pressure switch | Input |
| | | | 30 | NC | Input | 30 | Arm IN pressure switch | Input |
| | | | 31 | GND (S_NET GND) | Input | 31 | GND (controller GND) | |
| | | | 32 | CAN0_H | Input/output | 32 | GND (controller GND) | |
| | | | 33 | CAN1_H | Input/output | 33 | GND (controller GND) | |
| | | | 34 | GND (232C GND) | | 34 | NC | |
| | | | 35 | Service valve pressure switch | Input | 35 | Governor motor B phase (-) | Output |
| | | | 36 | NC | Input | 36 | NC | Output |
| | | | 37 | Model selection switch 1 | Input | 37 | Swing parking brake solenoid | Output |
| | | | 38 | Swing lock switch | Input | 38 | NC | Output |
| | | | 39 | GND (pulse GND) | | 39 | Travel pressure switch | Input |
| | | | 40 | Engine speed sensor | Input | 40 | Arm OUT pressure switch | Input |

2. Pump/Valve control function




SJP09129

Function

- The machine is matched to various types of work properly with the 2-stage relief function to increase the digging force, etc.

7. Travel control function






SJP09134

FUNCTION

- The pumps are controlled and the travel speed is changed manually or automatically, to secure proper travel performance matched to the type of work and jobsite during travel.

MONITOR ITEMS AND DISPLAY

| Symbol | Display item | Display method | | | | | | | | | | | | | | | | |
|---|---|--|------------------------------------|------------------------------------|--------------------|---|-------------------------|---------|-------------------|-----|----|-----|----|---------|----|----|----|--|
|  <p>SAT00098</p> | Swing lock | <table border="1"> <thead> <tr> <th data-bbox="606 340 839 421">Swing lock switch</th> <th data-bbox="868 340 1203 421">Swing holding brake release switch</th> <th data-bbox="1203 340 1465 421">Swing lock monitor</th> </tr> </thead> <tbody> <tr> <td data-bbox="606 421 839 465">OFF</td> <td data-bbox="868 421 1203 465">OFF</td> <td data-bbox="1203 421 1465 465">OFF</td> </tr> <tr> <td data-bbox="606 465 839 510">ON</td> <td data-bbox="868 465 1203 510">OFF</td> <td data-bbox="1203 465 1465 510">ON</td> </tr> <tr> <td data-bbox="606 510 839 555">OFF</td> <td data-bbox="868 510 1203 555">ON</td> <td data-bbox="1203 510 1465 555">Flashes</td> </tr> <tr> <td data-bbox="606 555 839 622">ON</td> <td data-bbox="868 555 1203 622">ON</td> <td data-bbox="1203 555 1465 622">ON</td> </tr> </tbody> </table> | Swing lock switch | Swing holding brake release switch | Swing lock monitor | OFF | OFF | OFF | ON | OFF | ON | OFF | ON | Flashes | ON | ON | ON | |
| Swing lock switch | Swing holding brake release switch | Swing lock monitor | | | | | | | | | | | | | | | | |
| OFF | OFF | OFF | | | | | | | | | | | | | | | | |
| ON | OFF | ON | | | | | | | | | | | | | | | | |
| OFF | ON | Flashes | | | | | | | | | | | | | | | | |
| ON | ON | ON | | | | | | | | | | | | | | | | |
|  <p>SAP00526</p> | Preheating | <table border="1"> <thead> <tr> <th data-bbox="606 723 1034 768">Continuous set time</th> <th data-bbox="1034 723 1465 768">Preheating monitor status</th> </tr> </thead> <tbody> <tr> <td data-bbox="606 768 1034 824">Up to 30 sec.</td> <td data-bbox="1034 768 1465 824">ON</td> </tr> <tr> <td data-bbox="606 824 1034 880">From 30 sec. to 40 sec.</td> <td data-bbox="1034 824 1465 880">Flashes</td> </tr> <tr> <td data-bbox="606 880 1034 925">More than 40 sec.</td> <td data-bbox="1034 880 1465 925">OFF</td> </tr> </tbody> </table> | Continuous set time | Preheating monitor status | Up to 30 sec. | ON | From 30 sec. to 40 sec. | Flashes | More than 40 sec. | OFF | | | | | | | | |
| Continuous set time | Preheating monitor status | | | | | | | | | | | | | | | | | |
| Up to 30 sec. | ON | | | | | | | | | | | | | | | | | |
| From 30 sec. to 40 sec. | Flashes | | | | | | | | | | | | | | | | | |
| More than 40 sec. | OFF | | | | | | | | | | | | | | | | | |
|  <p>SJP08778</p> | Power Max. | <table border="1"> <thead> <tr> <th data-bbox="606 1025 1034 1070">Power Max. switch status</th> <th data-bbox="1034 1025 1465 1070">Power max. monitor status</th> </tr> </thead> <tbody> <tr> <td data-bbox="606 1070 1034 1149">Being pressed</td> <td data-bbox="1034 1070 1465 1149">Lights up but goes out after approx. 9 sec. when kept pressed</td> </tr> <tr> <td data-bbox="606 1149 1034 1205">Not being pressed</td> <td data-bbox="1034 1149 1465 1205">Flashes</td> </tr> </tbody> </table> | Power Max. switch status | Power max. monitor status | Being pressed | Lights up but goes out after approx. 9 sec. when kept pressed | Not being pressed | Flashes | | | | | | | | | | |
| Power Max. switch status | Power max. monitor status | | | | | | | | | | | | | | | | | |
| Being pressed | Lights up but goes out after approx. 9 sec. when kept pressed | | | | | | | | | | | | | | | | | |
| Not being pressed | Flashes | | | | | | | | | | | | | | | | | |
| | <table border="1"> <tbody> <tr> <td data-bbox="411 1261 545 1339">Engine water temperature</td> <td data-bbox="577 1261 1497 1464" rowspan="3">See gauge display on the next page</td> </tr> <tr> <td data-bbox="411 1339 545 1417">Hydraulic oil temperature</td> </tr> <tr> <td data-bbox="411 1417 545 1464">Fuel level</td> </tr> </tbody> </table> | Engine water temperature | See gauge display on the next page | Hydraulic oil temperature | Fuel level | | | | | | | | | | | | | |
| Engine water temperature | See gauge display on the next page | | | | | | | | | | | | | | | | | |
| Hydraulic oil temperature | | | | | | | | | | | | | | | | | | |
| Fuel level | | | | | | | | | | | | | | | | | | |

MAINTENANCE FUNCTION

When the maintenance time for replacement, inspection, or filling has approached for the 10 maintenance items, press maintenance switch (1) and the caution display (yellow or red) appears on the monitor display for 30 seconds after the key is turned ON to remind the operator to carry out lubrication maintenance.

★ Maintenance items


| No. | Item | Replacement interval (hours) |
|-----|-------------------------|------------------------------|
| 01 | Engine oil | 500 |
| 02 | Engine oil filter | 500 |
| 03 | Fuel filter | 500 |
| 04 | Hydraulic filter | 1000 |
| 05 | Hydraulic tank breather | 500 |
| 06 | Corrosion resistor | * (1000) |
| 07 | Damper case oil | 1000 |
| 08 | Final case oil | 2000 |
| 09 | Machinery case oil | 1000 |
| 10 | Hydraulic oil | 5000 |

* Option, so not set


★ The above replacement intervals are set for each item, and the time remaining to maintenance is reduced as the machine is operated.

The content of the caution display differs according to the remaining time. The relationship is as shown in the table below.

| Display | Condition |
|--|---|
| None | Remaining time for maintenance for all items is more than 30 hours |
| Notice display (black symbol displayed on yellow background) | There is one or more items with less than 30 hours remaining time for maintenance |
| Warning display (wiper symbol displayed on red background) | There is one or more items with less than 0 hours remaining time for maintenance |




Fuel level sensor






- 1. Float
- 2. Connector
- 3. Cover
- 4. Variable resistor

SEP02590

Air cleaner clogging sensor



SXP08415


| Applicable model | | | | PC340LC,340NLC-7 | |
|-----------------------------------|--|--|--|----------------------------|----------------------------|
| Category | Item | Measurement Condition | Unit | Standard value | Permissible value |
| Work equipment | Time lag |  <ul style="list-style-type: none"> Hydraulic oil temperature: Within operation range Engine running at low idling Working mode: A mode Time required from dumping stroke end till bucket stops momentarily after control lever is tilted to digging and starts to move again | sec. | PC340LC,340NLC Max. 3.0 | PC340LC,340NLC Max. 3.6 |
| | |  <ul style="list-style-type: none"> Hydraulic oil temperature: Within operation range Engine running at low idling Working mode: A mode Time required from dumping stroke end till bucket stops momentarily after control lever is tilted to digging and starts to move again | | Max. 3.0 | Max. 5.0 |
| | Internal leakage | Cylinders | <ul style="list-style-type: none"> Hydraulic oil temperature: Within operation range Engine running at high idling | cc/min | 4.5 |
| Center swivel joint | <ul style="list-style-type: none"> Leakage amount for one minute with cylinder or travel to be measured in relief condition | 10 | 50 | | |
| Performance in compound operation | Swerving amount in simultaneous operation of work equipment and travel | <ul style="list-style-type: none"> Hydraulic oil temperature: Within operation range Engine at high idling Working mode: A mode Traveling speed: Lo Flat and level ground Swerving amount (X) when traveling 20 m after initial trial run of 10 m  | mm | Max. 400 | Max. 440 |
| Performance of hydraulic pump | Hydraulic pump delivery | See next page | l/min | See next page | |

MEASUREMENT OF BLOW-BY PRESSURE

★ Blow-by pressure measurement tools

| Mark | Part No. | Part Name |
|------|----------|-------------------------------|
| F | 1 | 799-201-1504 Blow-by Kit |
| | 2 | 795-790-3300 Tool (Nozzle) |

1. Remove the engine under cover.
2. Fit tool **F2** to blow-by hose and connect it with gauge ① of blow-by kit **F1**.



3. Start the engine and keep it running until the engine cooling water temperature rises to the operating range.
4. Measure the blow-by pressure at high idling and under the following conditions.
 - Working mode: A mode
 - Swing lock switch: ON (High pressure relief)
 - Work equipment, swing and travel:
 - Arm IN relief
- ★ Read off the blow-by pressure value, when the needle of the gauge steadies itself.




5. Detach the measurement tools after the measurement, and make sure that the machine is back to normal condition.

Adjustment


★ The unload valve cannot be adjusted.

1. Adjustment of main relief pressure

- ★ If relief pressure in the work equipment and travel circuits is not normal, adjust the high pressure setting side of main relief valves (3) and (4) in the following manner.
 - Main relief valve (3): For the front hydraulic pump circuit
 - Main relief valve (4): For the rear hydraulic pump circuit
- ★ The main relief valve adjusts the relief pressure of high pressure. (When the relief pressure of low pressure is adjusted, the relief pressure of high pressure is also adjusted automatically)
- ★ The relief pressure of low pressure is such condition that the 2-stage relief solenoid valve is in the OFF position and no pilot pressure is applied to the switching port.



- 1) Disconnect the pilot hose.
- 2) Loosen lock nut (5) and adjust the pressure by turning holder (6).
 - ★ If the holder is turned to the right, the pressure rises.
 - If the holder is turned to the left, the pressure falls.
 - ★ Adjustment amount per turn of holder:
Approx. 20.5 MPa{approx. 209 kg/cm²}
- 3 Lock nut:
49.0–58.8 Nm{5–6 kgm}




- 3) Check the pressure again after the adjustment, following the aforementioned steps for measurement.


★ When measuring the pressure, connect the pilot hose.

2. Adjustment of relief pressure in boom LOWER (High pressure setting side)

- ★ If the relief pressure of high pressure in boom LOWER is not normal, adjust the high pressure setting side of safety and suction valve (7) for boom LOWER in the following manner.
- ★ The relief pressure of high pressure is such condition that the machine push-up switch is in the ON position, and the switching port and the pilot pressure do not function.



- 1) Disconnect pilot hose.
- 2) Loosen lock nut (8) and adjust the pressure by turning holder (9).
 - ★ If the holder is turned to the right, the pressure rises.
 - If the holder is turned to the left, the pressure falls.
 - ★ Adjustment amount per turn of holder:
Approx. 21.8 MPa{approx. 222 kg/cm²}
- 3 Lock nut:
93–123 Nm{9.5–12.5 kgm}



MEASUREMENT OF SOLENOID VALVE OUTPUT PRESSURE

★ Solenoid valve output pressure measurement tools



| Mark | Part No. | Part Name |
|------|--------------|-------------------------------|
| 1 | 799-101-5002 | Hydraulic Tester |
| | 790-261-1203 | Digital Type Hydraulic Tester |
| 2 | 799-401-2910 | Nipple (Size 02) |
| | 07002-*1423 | O-ring |
| 3 | 799-401-2920 | Nipple (Size 03) |
| | 07002-*1823 | O-ring |

- ★ Measure solenoid valve output pressure after confirming that control circuit original pressure is normal.
- k Lower the work equipment to the ground and stop the engine. After the engine stops, operate the control lever several times to release the remaining pressure in the piping. Then loosen the oil filler cap to release the pressure inside the hydraulic tank.


1. Disconnect the hoses of solenoid valve to be measured at the outlet side.

| No. | Solenoid valve to be measured |
|-----|--|
| 1 | PPC lock solenoid valve |
| 2 | Travel interconnection solenoid valve |
| 3 | Merge/divide solenoid valve |
| 4 | Travel speed shifting solenoid valve |
| 5 | Swing and parking brake solenoid valve |
| 6 | Machine push-up solenoid valve |
| 7 | 2-stage relief solenoid valve |

★ Hose (1) is installed at the rear of operator's cab, and hoses (2) through (7) are installed at the center of revolving frame.



2. Fix nipple **N2** or **N3** and connect the disconnected hose again.
3. Fit fitting ① of hydraulic tester **N1** and connect it to oil pressure gauge ②.
 - ★ Use an oil pressure gauge with the capacity of 5.9 MPa{60 kg/cm²}.



4. Start the engine and keep it running until the hydraulic oil temperature rises to the operating range.




3. Air bleeding from swing motor

- 1) Start the engine and run it at low idling.
- 2) Bleed air from the motor by swinging the upper structure slowly.

4. Air bleeding from travel motor

- 1) Start the engine and run it at low idling.
- 2) Loosen air bleeding plug (2) and confirm that oil seeps out from the plug.
- 3) If the oil seepage is confirmed, tighten air bleeding plug (2).


- 3 Air bleeding plug:
27.5–35.3 Nm{2.8–3.6 kgm}



| User Code No. | Service Code | | Failure Code | | | Failure Classification |
|---------------|--------------|---|--------------|------------------------------------|-----------------------------|------------------------|
| | Code No. | Content | Code No. | Location | Phenomenon | |
| E05 | E308 | Abnormality in throttle potentiometer | DK10KZ | Throttle potentiometer | Malfunctioning | Electrical system |
| - | E314 | Disconnection in engine stop solenoid relay | DY45KA | Engine stop solenoid relay | Disconnection | |
| - | E315 | Short circuit in battery relay output | D110KB | Battery relay | Short circuit | |
| - | E316 | Abnormality in governor motor step-out | DY10K4 | Governor motor | Out of control | |
| E05 | E317 | Disconnection in both governor motors A and B | DY10KA | Governor motor | Disconnection | |
| E05 | E318 | Short circuit in both governor motors A and B | DY10KB | Governor motor | Short circuit | |
| - | None | Engine high idling out of rate | A000N1 | Engine | Overrunning | Mechanical system |
| - | None | Engine low idling out of rate | A000N2 | Engine | Low idling out of rate | |
| - | None | Air cleaner clogged | AA10NX | Air cleaner element | Clogging | |
| - | None | Charging voltage abnormally low | AB00KE | Alternator | Insufficient charging | |
| - | None | Engine oil pressure abnormally low | B@BAZG | Engine oil | Oil pressure lowered | |
| - | None | Engine oil level abnormally low | B@BAZK | Engine oil | Oil level lowered | |
| - | None | Engine cooling water overheated | B@BCNS | Engine cooling water | Overheating | |
| - | None | Radiator water level abnormally low | B@BCZK | Engine cooling water | Cooling water level lowered | |
| - | None | Hydraulic oil overheated | B@HANS | Hydraulic oil | Overheating | |
| - | None | Auto-lubrication system abnormal | DA80MA | Auto-lubrication system controller | Malfunction | |

- ★ This table is arranged in the sequence of Service Code No.
- ★ In case there is no number assigned in the column of User Code No., or in case "none" is described in the column of Code No. of Service Code, the corresponding service code or failure code is not shown in the display of ordinary items, even if some abnormality occurs. It is recorded only in the failure history (either in electrical system or mechanical system) of Service Menu.
- ★ History Classification indicates that a specific failure is classified as belonging to either electrical system or mechanical system, when it is recorded in Service Menu.
- ★ "E" at the head of Code No. of Service Code means the following status of a specific failure.
 - With "E": The failure is yet to be dissolved and continues.
 - Without "E": The failure has already been dissolved.


- 4) Set contents of individual items
- ①: Default: The maintenance time set in the monitor (recommended by the manufacturer and cannot be changed).
 - ②: Set: Maintenance time that can be freely set. The maintenance mode program functions based on this maintenance time. (The maintenance time can be increased or decreased by 50 hours with [△] or [▽] switch)
 - ③: On: Maintenance display function with this instruction becomes effectual.
 - ④: Off: Maintenance display with this instruction becomes ineffectual.
- ★ The lowest maintenance time is 50 h.
- 5) Set contents of "Use Default Values"
When selecting this menu and depressing the switch [✓], all individual time settings are reduced to the initial settings.



4. Monitoring code display function


The input signals from the sensors to each component and the output signals to drive the solenoid can be checked in real time with the monitoring code. When the following operations are carried out, the monitoring code Nos. are displayed on the 3rd to 5th digits from the left on service meter display (2) and the monitoring data are displayed on digital meter display (1).

- 1) Method of displaying monitoring codes
 - i) To switch to the monitoring code, do as follows.
 - ① Keep [Buzzer cancel switch (8)] + [Auto-deceleration switch (7)] pressed for at least 2.5 seconds.
 - ② Press [Buzzer cancel switch (8)] + [Working mode selector (UP) switch (3)] (or [Working mode selector (DOWN) switch (4)]) and set so that [02] is displayed in the 2nd and 3rd digits from the left on service meter display (2).
 - ③ Press [Setting switch (5)].




- (1) Digital meter display (5) Setting switch
- (2) Service meter display (6) Travel speed switch
- (3) Working mode selector (UP) switch (7) Auto-deceleration switch
- (4) Working mode selector (DOWN) switch (8) Buzzer cancel switch

Example 1: When a numeric display monitoring code (engine speed: 2050 rpm) is displayed



Example 2: When bit pattern display monitoring code No. 20 (switch input condition (1)) is displayed

- ii) To go on to the next monitoring code display, press [Buzzer cancel switch (8)] + [Working mode selector (UP) switch (3)].
- iii) To go back to the previous service code display, press [Buzzer cancel switch (8)] + [Working mode selector (DOWN) switch (4)].
- iv) To finish using the monitoring code display mode, keep [Buzzer cancel switch (8)] + [Auto-deceleration switch (7)] pressed for at least 2.5 seconds.





Pm - Tune up Service

| Model | Serial No. | Service meter reading |
|--|------------|-----------------------|
| <input type="checkbox"/> PC300-7 <input type="checkbox"/> LC <input type="checkbox"/> PC350-7 | | h |

| User's name | Implemented on: | Inspected by: |
|-------------|-----------------|---------------|
| | / / | |

| Specifications | | |
|---|---|---|
| Work equipment | Attachment | Shoe width |
| Boom <input type="checkbox"/> Standard <input type="checkbox"/> () Arm <input type="checkbox"/> Standard <input type="checkbox"/> () Bucket <input type="checkbox"/> Standard <input type="checkbox"/> () | <input type="checkbox"/> Breaker <input type="checkbox"/> () | <input type="checkbox"/> 600 mm <input type="checkbox"/> 700 mm <input type="checkbox"/> () |

| Oil and cooling water level check | | |
|--|--|--|
| <input type="checkbox"/> Radiator water <input type="checkbox"/> Engine oil <input type="checkbox"/> Hydraulic oil | As required <input type="checkbox"/> Damper case oil <input type="checkbox"/> Machinery case oil | <input type="checkbox"/> Final drive case oil <input type="checkbox"/> () |

| Max. range of engine cooling water temperature | Max. range of hydraulic oil temperature | Ambient temperature |
|--|---|---------------------|
| BWP10817 | BWP10818 | °C |
| | | Elevation |
| | | m |

| |
|--------------------|
| Operator's comment |
| |

| |
|------------------------|
| Result of visual check |
| |

| Failure code history | | | |
|---|---|---|---------------------------|
| Electrical system | | Mechanical system | |
| <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> | h | | |
| Content: | | | |
| <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> | h | A000N1 Engine rotation at high idling out of rate | Frequency |
| Content: | | A000N2 Engine rotation at low idling out of rate | SMR at initial occurrence |
| <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> | h | B@BCNS Engine cooling water overheated | <input type="text"/> |
| Content: | | B@BAZG Engine oil pressure abnormally low | <input type="text"/> |
| <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> | h | B@BAZK Engine oil level abnormally low | <input type="text"/> |
| Content: | | B@HANS Hydraulic oil overheated | <input type="text"/> |
| <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> | h | B@BCZK Radiator water level abnormally low | <input type="text"/> |
| Content: | | AA10NX Air cleaner clogged | <input type="text"/> |
| <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> | h | AB00KE Charging voltage abnormally low | <input type="text"/> |
| Content: | | DA80MA Auto-lubrication system abnormal | <input type="text"/> |

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL




• **Connecting connectors**


- 1) Check the connector visually.
 - 1) Check that there is no oil, dirt, or water stuck to the connector pins (mating portion).
 - 2) Check that there is no deformation, defective contact, corrosion, or damage to the connector pins.
 - 3) Check that there is no damage or breakage to the outside of the connector.
 - ★ If there is any oil, water, or dirt stuck to the connector, wipe it off with a dry cloth. If any water has got inside the connector, warm the inside of the wiring with a dryer, but be careful not to make it too hot as this will cause short circuits.
 - ★ If there is any damage or breakage, replace the connector.

- 2) Fix the connector securely.
Align the position of the connector correctly, then insert it securely.
For connectors with lock stopper, push in the connector until the stopper clicks into position.


- 3) Correct any protrusion of the boot and any misalignment of the wiring harness
For connectors fitted with boots, correct any protrusion of the boot. In addition, if the wiring harness is misaligned, or the clamp is out of position, adjust it to its correct position.
 - ★ If the connector cannot be corrected easily, remove the clamp and adjust the position.









- 4) If the connector clamp has been removed, be sure to return it to its original position. Check also that there are no loose clamps.















BWP10916





| No. of pins | SWP type connector | | |
|-------------|---|--|--------------------|
| | Male (female housing) | Female (male housing) | T-adapter Part No. |
| 6 |  <p>BWP04707</p> |  <p>BWP04708</p> | 799-601-7050 |
| | Part No.: 08055-10681 | Part No.: 08055-10691 | |
| 8 |  <p>BWP04709</p> |  <p>BWP04710</p> | 799-601-7060 |
| | Part No.: 08055-10881 | Part No.: 08055-10891 | |
| 12 |  <p>BWP04711</p> |  <p>BWP04712</p> | 799-601-7310 |
| | Part No.: 08055-11281 | Part No.: 08055-11291 | |
| 14 |  <p>BWP04713</p> |  <p>BWP04714</p> | 799-601-7070 |
| | Part No.: 08055-11481 | Part No.: 08055-11491 | |

| No. of pins | KES 1 (Automobile) connector | | |
|-------------|---|--|--------------------|
| | Male (female housing) | Female (male housing) | T-adapter Part No. |
| 2 |  <p>BWP04775</p> |  <p>BWP04776</p> | — |
| | Part No.: 08027-10210 (Natural color) 08027-10220 (Black) | Part No.: 08027-10260 (Natural color) 08027-10270 (Black) | |
| 3 |  <p>BWP04777</p> |  <p>BWP04778</p> | — |
| | Part No.: 08027-10310 | Part No.: 08027-10360 | |
| 4 |  <p>BWP04779</p> |  <p>BWP04780</p> | — |
| | Part No.: 08027-10410 (Natural color) 08027-10420 (Black) | Part No.: 08027-10460 (Natural color) 08027-10470 (Black) | |
| 6 |  <p>BWP04781</p> |  <p>BWP04782</p> | — |
| | Part No.: 08027-10610 (Natural color) 08027-10620 (Black) | Part No.: 08027-10660 (Natural color) 08027-10670 (Black) | |


[The pin No. is also marked on the connector (electric wire insertion end)]

| No. of pins | DTM Series connector | | |
|-------------|---|--|--------------------|
| | Body (plug) | Body (receptacle) | T-adapter Part No. |
| 2 |  <p style="text-align: center;">BWP05049</p> |  <p style="text-align: center;">BWP05050</p> | 799-601-9010 |
| | <p>Part No.: 08192-02200</p> | | |

[The pin No. is also marked on the connector (electric wire insertion end)]


| No. of pins | DTHD Series connector | | |
|-------------|--|--|--------------------|
| | Body (plug) | Body (receptacle) | T-adapter Part No. |
| 2 |  <p style="text-align: center;">BWP05051</p> |  <p style="text-align: center;">BWP05052</p> | — |
| | <p>Part No.: 08192-31200 (Contact size#12) 08192-41200 (Contact size #8) 08192-51200 (Contact size #4)</p> | | |

Electric Circuit Diagram for Monitor Panel Windshield Wiper Motor




BWP10402

Electrical Circuit for Travel Interlocking Solenoid in Governor • Pump Controller




BJP10919

Electrical Circuit Diagram for Travel Interlocking Solenoid in Governor • Pump Controller




BJP10919

Electrical Circuit Diagram for Model Selecting Connector in Governor • Pump Controller



BJP10924

Electrical Circuit Diagram for Sensor Power Source in Governor • Pump Controller




BWP10925

**Service Code in Electrical System E246
(Disconnection in attachment oil flow rate adjusting EPC) (Multi-monitor only)**

| | | | | |
|---------------------------------|---|---------------|--------------------|--|
| User Code | Service Code | Failure Code | Failure phenomenon | Disconnection in attachment oil flow rate adjusting EPC (in governor • pump controller system) |
| — | E246 | DXE4KA | | |
| Failure content | • No current flow to the attachment oil flow rate adjusting EPC solenoid circuit. | | | |
| Response from controller | • None in particular (The solenoid does not work, as there is no current flowing to it) • If the failure cause disappears, the EPC solenoid circuit returns to normalcy of itself. | | | |
| Phenomenon occurring on machine | • The attachments do not move. | | | |
| Relative information | • In this code, a failure is diagnosed only when the setting mode is "with ATT". (Check the setting mode shown in the monitor panel) • It can be confirmed in the monitor function how power (ampere) is supplied to the attachment oil flow rate adjusting EPC solenoid circuit. (Code No. 017: Service solenoid current) | | | |


| Cause | | Standard value in normalcy and references for troubleshooting | | | |
|---|---|---|---|------------------|------------------|
| Presumed cause and standard value in normalcy | 1 | Attachment oil flow rate adjusting EPC defective (Internal short-circuiting or grounding fault) | ★ Turn the engine starting switch OFF for the preparations, and hold it in the OFF position during the troubleshooting. | | |
| | | | V30 (male) | | Resistance value |
| | | | Between ① and ② | | 7 – 14 Ω |
| | 2 | Disconnection of wiring harness (Disconnection or defective contact with connector) | ★ Turn the engine starting switch OFF for the preparations, and hold it in the OFF position during the troubleshooting. | | |
| | | | Between wiring harness between C03 (female) ⑳ and V30 (male) ① and grounding | Resistance value | Below 1 Ω |
| | | | Between wiring harness between C03 (female) ③ ⑬ ㉓ and V30 (male) ② and grounding | Resistance value | Below 1 Ω |
| | 3 | Short-circuiting of wiring harness (Contact with 24 V circuit) | ★ Turn the engine starting switch OFF for the preparations, and hold it in the ON position during the troubleshooting. | | |
| | | | Between wiring harness between C03 (female) ⑳ and V30 (female) ① and grounding | Voltage | Below 1 V |
| | 4 | Governor • pump controller defective | ★ Turn the engine starting switch OFF for the preparations, and hold it in the OFF position during the troubleshooting. | | |
| | | | C03 (female) | | Resistance value |
| | | | Between ㉖ and ③ ⑬ ㉓ | | 7 – 14 Ω |

Electrical Circuit Diagram for Attachment Oil Flow Rate Adjusting EPC Solenoid in Governor • Pump Controller



BWP10419

Electrical Circuit Diagram for Engine Stop Solenoid and Relay in Monitor Panel




BWP10929

Failure Code in Mechanical System AA10NX (Air cleaner clogging)

| | | | | |
|---------------------------------|---|---------------|--------------------|--|
| User Code | Service Code | Failure Code | Failure phenomenon | Air cleaner clogged (in mechanical system) |
| — | — | AA10NX | | |
| Failure content | • While the engine was running, the signal circuit in the air cleaner clogging switch was opened (i.e. disconnected from grounding circuit). | | | |
| Response from controller | • None in particular | | | |
| Phenomenon occurring on machine | • There is a possibility that the engine is damaged, if it is used continuously without corrective action. | | | |
| Relative information | • This Failure Code is recorded, when the air cleaner clogging caution symbol is displayed in the monitor panel while the engine is running. • Input from the air cleaner clogging switch (ON or OFF) can be confirmed in the monitor panel. (Code No. 046: Monitor input 2) | | | |

| Cause | Standard value in normalcy and references for troubleshooting | | | |
|-------|---|---|---|------------------|
| | 1 | Air cleaner clogged (when the system is in normal condition) | ★ Check the air cleaner for clogging. If it is clogged, clean or replace it with new one. | |
| 2 | Air cleaner clogging switch defective (Internal disconnection) | ★ Turn the engine starting switch OFF for the preparations, and keep the engine running during the troubleshooting. | | |
| | | A31 (male) | Air cleaner | Resistance value |
| | | Between ① and ② | When in normal condition | Below 1 Ω |
| | | When clogged | Above 1 MΩ | |
| 3 | Disconnection of wiring harness (Disconnection or defective contact with connector) | ★ Turn the engine starting switch OFF for the preparations, and hold it running during the troubleshooting. | | |
| | | Wiring harness between P02 (female) ⑤ and A31 (female) ① | Resistance value | Below 1 Ω |
| | | Between wiring harness A31 (female) ② and grounding | Resistance value | Below 1 Ω |
| 4 | Monitor panel defective | ★ Turn the engine starting switch OFF for the preparations, and keep the engine running during the troubleshooting. | | |
| | | P02 | Air cleaner | Voltage |
| | | Between ⑤ and grounding | When in normal condition | Below 1 V |
| | | When clogged | 20 – 30 V | |

Electrical Circuit for Air Cleaner Clogging Switch in Monitor Panel



BWP10428


E-1 Engine does not start

| | |
|-------------------------|--|
| Failure information (1) | <ul style="list-style-type: none"> The engine does not start (the engine does not rotate). |
| Relative information | <ul style="list-style-type: none"> The following two engine start locking mechanisms are provided in the engine starting circuit. <ol style="list-style-type: none"> Engine start locking by means of password in the monitor panel (※) Engine start locking by means of safety lock lever |

※: The multi-monitor specification machine only.

| Cause | | Standard value in normalcy and references for troubleshooting | | | |
|---|---|---|---|------------------------|--------------------------------------|
| Presumed cause and standard value in normalcy | 1 | Shortage in battery capacity | Battery voltage | | Battery electrolyte specific gravity |
| | | | Above 24 V | | Above 1.26 |
| | 2 | Fuse Nos. 3 and 18 and Fusible Link A35 fault | When a fuse or fusible link is blown, there is a big possibility that grounding fault occurred in the circuit. If a monitor lamp does not light up in the monitor panel, check the power source circuit between the battery and the specific fuse. | | |
| | 3 | Engine starting switch fault (Internal disconnection) | ★Turn the engine starting switch OFF for the preparations, and hold it in the OFF position during the troubleshooting. | | |
| | | | H15 (male) | Position | Resistance value |
| | | | Between ① and ④ | OFF | Above 1 MΩ |
| | Start | Below 1 Ω | | | |
| 4 | Safety lock switch fault (Internal short-circuiting) | ★Turn the engine starting switch OFF for the preparations, and hold it in the OFF position during the troubleshooting. | | | |
| | | S14 (female) | Lock lever | Resistance value | |
| | | Between ① and ③ | Release | Below 1 Ω | |
| LOCK | Above 1 MΩ | | | | |
| 5 | Engine starting motor cut relay, R11 and R13 defective (Internal disconnection or short-circuiting) | ★Turn the engine starting switch OFF for the preparations, and hold it in the OFF position during the troubleshooting. | | | |
| | | R11 (female) & R13 (male) | | Resistance value | |
| | | Between ① and ② | | 100 – 500 Ω | |
| | | Between ③ and ⑤ | | Above 1 MΩ | |
| 6 | Engine starting motor fault (Internal disconnection or damage) | ★Turn the engine starting switch OFF for the preparations, and keep the engine running during the troubleshooting. (If all of the power source, grounding (GND), generation signal and engine start input are normal and yet the engine start output is not normal, the engine starting motor relay is defective) | | | |
| | | Engine starting motor | | Engine starting switch | |
| | | Power source: B terminal and grounding | | Start | 20 – 30 V |
| | | Engine start input: C terminal and grounding | | | 20 – 30 V |
| 7 | Alternator fault (Internal short-circuit) | ★Turn the engine starting switch OFF for the preparations, and hold it in the ON position or running during the troubleshooting. | | | |
| | | Alternator | | Voltage | |
| | | R terminal and grounding | | Below 1 V | |

Electrical Circuit Diagram for Engine Stop




BWP10929

E-13 Fuel level monitor red lamp lights up while engine is running

| | |
|----------------------|--|
| Failure information | <ul style="list-style-type: none"> The fuel level monitor red lamp lighted up while the engine was running. |
| Relative information | <ul style="list-style-type: none"> If the fuel gauge shows in a red range on the monitor panel, the fuel level monitor lamp lights up red. (5) Input signal from the fuel level sensor (voltage) can be confirmed in the monitor function. (Code No. 042: Fuel level sensor) |

| Presumed cause and standard value in normalcy | Cause | | Standard value in normalcy and references for troubleshooting | | | |
|---|--|---|---|---|--------------------|------------------|
| | 1 | Fuel level lowered (system in normal condition) | ★ Refill fuel. | | | |
| 2 | | | Fuel level sensor fault (Internal disconnection) | ★ Turn the engine starting switch OFF for the preparations, and hold it in the OFF position during the troubleshooting. | | |
| | | | | A60 (male) | Fuel level | Resistance value |
| | | | | Between ① and grounding | FULL (Upper limit) | Approx. 12 Ω |
| | | | EMPTY (Lower limit) | 85 – 110 Ω | | |
| 3 | Grounding fault of wiring harness (Contact with grounding (GND) circuit) | ★ Turn the engine starting switch OFF for the preparations, and hold it in the OFF position during the troubleshooting. | | | | |
| | | Wiring harness between P02 (female) ② and A60 (female) ① | Resistance value | Below 1 Ω | | |
| 4 | Monitor panel defective | ★ Turn the engine starting switch OFF for the preparations, and hold it in the OFF position during the troubleshooting. | | | | |
| | | P02 (female) | Fuel level | Resistance value | | |
| | | Between ② and grounding | FULL (Upper limit) | Approx. 12 Ω | | |
| | | | EMPTY (Lower limit) | 85 – 110 Ω | | |

Electrical Circuit Diagram for Fuel Level Sensor




BWP10434

E-21 "Boom RAISE" is not correctly displayed in monitor function

| | |
|----------------------|---|
| Failure information | • "Boom RAISE" is not correctly displayed in the monitor function on the monitor panel. |
| Relative information | — |


| Cause | | Standard value in normalcy and references for troubleshooting | | |
|--|---|---|--------------------|------------------|
| Presumed cause and standard value in normalcy | 1 Boom RAISE PPC hydraulic switch fault (Internal disconnection or short-circuiting) | ★ Turn the engine starting switch OFF for the preparations, and keep the engine running during the troubleshooting. | | |
| | | S06 (male) | Boom control lever | Resistance value |
| | | Between ① and ② | NEUTRAL | Above 1 MΩ |
| | RAISE | | Below 1 Ω | |
| | 2 Disconnection of wiring harness (Disconnection or defective contact with connector) | ★ Turn the engine starting switch OFF for the preparations, and hold it in the OFF position during the troubleshooting. | | |
| Wiring harness between C03 (female) ⑩ and S06 (female) ② | | Resistance value | Below 1 Ω | |
| Wiring harness between S06 (female) ① and grounding | | Resistance value | Below 1 Ω | |
| 3 Grounding fault of wiring harness (Contact with grounding (GND) circuit) | ★ Turn the engine starting switch OFF for the preparations, and hold it in the OFF position during the troubleshooting. | | | |
| | Between wiring harness between C03 (female) ⑩ and S06 (female) ② and grounding | Resistance value | Above 1 MΩ | |
| 4 Short-circuiting of wiring harness (Contact with 24 V circuit) | ★ Turn the engine starting switch OFF for the preparations, and hold it in the ON position during the troubleshooting. | | | |
| | Between wiring harness between C03 (female) ⑩ and S06 (female) ② and grounding | Voltage | Below 1 V | |
| 5 Governor • pump controller defective | ★ Turn the engine starting switch OFF for the preparations, and hold it in the ON position during the troubleshooting. | | | |
| | C03 | Boom control lever | Voltage | |
| | Between ⑩ and grounding | NEUTRAL | 20 – 30 V | |
| RAISE | | Below 1 V | | |

Electrical Circuit Diagram for Boom RAISE PPC Hydraulic Switch



BJP10939

Electrical Circuit Diagram for Travel PPC hydraulic Switch and Travel Alarm



INFORMATION CONTAINED IN TROUBLESHOOTING TABLE

★ Troubleshooting Table and Related Circuit Diagram collectively carry the following information. Carry out troubleshooting work after fully grasping their contents.

| | |
|----------------------|--|
| Failure information | Phenomena occurring on machine |
| Relative information | Information on occurred failures and troubleshooting |

| Presumed cause and standard value in normalcy | Cause | | Standard value in normalcy and references for troubleshooting | |
|---|-------|--|---|--|
| | 1 | Cause for presumed failure (The attached No. for filing and reference purpose only. It does not stand for any priority) | <Contents> <ul style="list-style-type: none"> • The standard values in normalcy by which to judge "good" or "no good" about presumed causes. • References for making judgement of "good" or "no good" | |
| | 2 | | | |
| | 3 | | | |
| | 4 | | | |
| | 5 | | | |

H-15 In compound operation, work equipment with larger load moves slowly

| | |
|----------------------|--|
| Failure information | • In a compound operation, work equipment with larger load tends to move slowly. |
| Relative information | — |

| Presumed cause and standard value in normalcy | Cause | | Standard value in normalcy and references for troubleshooting | |
|---|-------|---|---|--|
| | 1 | Malfunctioning of pressure compensation valve for work equipment with larger load | The pressure compensation valve for the work equipment with larger load is presumed to malfunction. Check the valve itself. | |
| Combination of compound operation | | | Work equipment with larger load | |
| Boom RAISE + arm DIGGING | | | Boom RAISE | |
| Boom RAISE + arm DUMPING | | | Arm DUMPING | |
| Boom RAISE + bucket DIGGING | | | Boom RAISE | |
| Arm DUMPING + bucket DIGGING | | | Arm DUMPING | |
| Boom LOWER + arm DUMPING | | | Arm DUMPING | |

H-16 In swing + boom RAISE operation, boom moves slowly

| | |
|----------------------|--|
| Failure information | • In a compound operation of swing + boom RAISE, the boom tends to move slowly. |
| Relative information | • If the boom moves slowly in the single operation of boom RAISE, carry out the H-7 check first. |

| Presumed cause and standard value in normalcy | Cause | | Standard value in normalcy and references for troubleshooting | |
|---|-------|---|--|--|
| | 1 | Malfunctioning of LS select valve or seal defective | The LS select valve is presumed to malfunction, or the seal is suspected to be defective. Check the valve and seal themselves. | |

H-17 In swing + travel, travel speed drops sharply


| | |
|----------------------|--|
| Failure information | • In a compound operation of swing + travel, the travel speed drops sharply. |
| Relative information | • If the travel speed is slow in the single operation of travel, carry out the H-19 check first. |


| Presumed cause and standard value in normalcy | Cause | | Standard value in normalcy and references for troubleshooting | |
|---|-------|--|---|--|
| | 1 | Malfunctioning of LS shuttle valve (left travel and swing) | The LS shuttle valve in the left travel control valve or the swing control valve is presumed to malfunction. Check both of them directly. | |

30 DISASSEMBLY AND ASSEMBLY


| | | | |
|--|-------|------------------------------|-------|
| HOW TO READ THIS MANUAL | 30-3 | CARRIER ROLLER ASSEMBLY | 30-49 |
| Removal and Installation of Assemblies | 30-3 | Special Tools | 30-49 |
| Disassembly and Assembly of Assemblies | 30-4 | Assembly | 30-49 |
| PRECAUTIONS WHEN PERFORMING OPERATION | 30-5 | TRACK ROLLER ASSEMBLY | 30-50 |
| STARTING MOTOR ASSEMBLY | 30-7 | Special Tools | 30-50 |
| Removal | 30-7 | Assembly | 30-50 |
| Installation | 30-7 | IDLER ASSEMBLY | 30-51 |
| FUEL INJECTION PUMP ASSEMBLY | 30-8 | Special Tools | 30-51 |
| Special Tools | 30-8 | Disassembly | 30-51 |
| Removal | 30-8 | Assembly | 30-52 |
| Installation | 30-10 | RECOIL SPRING ASSEMBLY | 30-54 |
| ENGINE FRONT SEAL | 30-12 | Special Tools | 30-54 |
| Removal | 30-12 | Disassembly | 30-54 |
| Installation | 30-12 | Assembly | 30-55 |
| ENGINE REAR SEAL | 30-13 | SPROCKET | 30-56 |
| Removal | 30-13 | Removal | 30-56 |
| Installation | 30-13 | Installation | 30-56 |
| CYLINDER HEAD ASSEMBLY | 30-15 | TRACK SHOE ASSEMBLY | 30-57 |
| Special Tools | 30-15 | Special Tools | 30-57 |
| Removal | 30-15 | Expansion of Track Shoe | 30-57 |
| Installation | 30-18 | Assembly | 30-58 |
| RADIATOR ASSEMBLY | 30-21 | SWING CIRCLE ASSEMBLY | 30-59 |
| Removal | 30-21 | Removal | 30-59 |
| Installation | 30-22 | Installation | 30-59 |
| HYDRAULIC OIL COOLER ASSEMBLY | 30-23 | REVOLVING FRAME ASSEMBLY | 30-60 |
| Removal | 30-23 | Removal | 30-60 |
| Installation | 30-24 | Installation | 30-62 |
| ENGINE AND HYDRAULIC PUMP ASSEMBLIES | 30-25 | CENTER SWIVEL JOINT ASSEMBLY | 30-63 |
| Special Tools | 30-25 | Removal | 30-63 |
| Removal | 30-25 | Installation | 30-64 |
| Installation | 30-28 | DISASSEMBLY AND ASSEMBLY | |
| FINAL DRIVE ASSEMBLY | 30-29 | Special Tools | 30-65 |
| Removal | 30-29 | Disassembly | 30-65 |
| Installation | 30-29 | Assembly | 30-65 |
| DISASSEMBLY AND ASSEMBLY | | HYDRAULIC TANK ASSEMBLY | 30-66 |
| Special Tools | 30-30 | Removal | 30-66 |
| Disassembly | 30-30 | Installation | 30-67 |
| Assembly | 30-33 | CONTROL VALVE ASSEMBLY | 30-68 |
| Sketches Of Special Tools | 30-39 | Removal | 30-68 |
| SWING MOTOR, SWING MACHINERY ASSEMBLY | 30-40 | Installation | 30-70 |
| Removal | 30-40 | DISASSEMBLY AND ASSEMBLY | |
| Installation | 30-40 | Special Tools | 30-71 |
| DISASSEMBLY AND ASSEMBLY | | Assembly | 30-72 |
| Special Tools | 30-41 | HYDRAULIC PUMP ASSEMBLY | 30-73 |
| Disassembly | 30-41 | Special Tools | 30-73 |
| Assembly | 30-43 | Removal | 30-73 |
| Sketches Of Special Tools | 30-48 | Installation | 30-75 |
| | | OIL SEAL IN HYDRAULIC PUMP | |
| | | INPUT SHAFT | 30-76 |
| | | Removal | 30-76 |
| | | Installation | 30-76 |


- 3) Install the fuel injection pump assembly (27) and secure it with four nuts (26).


 **N·m** Securing nut:
 $44 \pm 6 \text{ Nm}$ { $4.49 \pm 0.61 \text{ kgm}$ }



- 4) Install washer (24) and temporarily secure it with nut (23).
- ★ When installing the nut and washer, be careful not to let them fall into the case.

 Tighten the nut temporarily to the following torque. Take care not to damage the timing pin.

 **N·m** Nut:
 $178 \pm 13 \text{ Nm}$ { $18.2 \pm 1.3 \text{ kgm}$ }



- 5) Disengage the fuel injector pump timing pin (on the timing gear side) from protrusion a, and return the pin to its original position.
- Air bleeding
 Bleed air from the fuel injection system.

REMOVAL AND INSTALLATION OF RADIATOR ASSEMBLY

REMOVAL

1. Drain the engine coolant.




Engine coolant: Approx. 32 l

2. Lift off engine hood (1) temporarily.
 - ★ Be careful not to damage the rubber seal when lifting the engine hood.
 - ★ Support the engine hood with an appropriate sling and lifting device.




3. Remove engine hood mounting bolt to remove pin (2).
4. Lift off engine hood (1).



5. Disconnect reservoir tank hose (3).
 - ★ Disconnect the hose on the radiator side.
6. Disconnect radiator hose (4).
7. Remove fan guards (5) and (6).


8. Remove fan cover (7).
 - ★ First remove the clamp for mounting the after-cooler hose which is tightened together and then remove the fan cover.




9. Disconnect radiator hose (8).



10. Lift off radiator assembly, using two slings b.



- ii) Remove thrust washer (7), gear (8), bearing (9), and thrust washer (10).




5. No. 1 sun gear shaft

Remove No. 1 sun gear shaft (11).


6. No. 2 sun gear

Remove No. 2 sun gear (12).




7. Thrust washer

Remove thrust washer (13).




8. Ring gear

Using eyebolts d, remove ring gear (14).



9. No. 2 carrier assembly

- 1) Remove No. 2 carrier assembly (15)




- 2) Disassemble No. 2 carrier assembly as follows.

- i) Push in pin (16) and pull out shaft (17) from carrier (18).

★ After removing the shaft, remove pin (16).

- ii) Remove thrust washer (19), gear (20), bearing (21), and thrust washer (22).



DISASSEMBLY AND ASSEMBLY OF SWING MOTOR, SWING MACHINERY ASSEMBLY

SPECIAL TOOLS

| Mark | Part No. | Part Name | Necessity | Qty | Distinction* | Sketch | |
|------|----------|---------------|---------------|-----|--------------|--------|--|
| E | 1 | 796T-626-1110 | ● | 1 | | ○ | |
| | 2 | 790-101-5401 | Push tool kit | ■ | 1 | | |
| | | 790-101-5531 | • Plate | | 1 | | |
| | | 790-101-5421 | • Grip | | 1 | | |
| | | 01010-51240 | • Bolt | | 1 | | |

*Distinction between new and existing part.

DISASSEMBLY

1. Draining oil

Loosen the drain plug and drain oil from the swing machinery case.




Swing machinery case: Approx. 13.4 l

2. Swing motor assembly

- Place swing motor and swing machinery assembly on block b.
- Remove the six mounting bolts to disconnect swing motor assembly (1).




Swing motor assembly: 70 kg




3. No. 1 Sun gear

- Remove No. 1 sun gear (2).




4. No. 1 carrier assembly

- Disassemble No. 1 carrier assembly (3).



- Disassemble the No. 1 carrier assembly in the following manner.

Remove snap ring (4) first and then remove shaft (5), gear (6), bearing (7), thrust washer (8) and plate (9).




DISASSEMBLY AND ASSEMBLY OF IDLER ASSEMBLY

SPECIAL TOOLS

| Mark | Part No. | Part Name | Necessity | Qty | Distinction* | Sketch |
|------|--------------|-----------|-----------|-----|--------------|--------|
| H | 796-570-1020 | Installer | ■ | 1 | | |
| | 791-601-1000 | Oil pump | ■ | 1 | | |

*Distinction between new and existing part.

DISASSEMBLY




1. Remove dowel pin (1) and then support (2).
2. Remove floating seal (3) from support (2) and idler (4).

3. Detach idler (4) from shaft (5) and support assembly (7).


★ The idler contains 230 ± 10 cc of oil. Drain the oil at this stage of disassembly. Take care and spread a cloth on the floor to prevent smearing the floor with flushing oil.

4. Remove floating seal (6) on the opposite side of idler (4), shaft (5) and support assembly (7).




5. Remove dowel pin (8) to detach support (7) from shaft (5).


6. Remove bushings (9) and (10) from idler (4).





9. Remove plates (7) and (8).
10. Remove U bolt (9) and plate (10) to disconnect after-cooler tube (11).
 - ★ If any other parts may interfere with the slings, remove them before lifting the assembly.



11. Disconnect seven hoses (12) through (18).
 - (12): Center swivel joint (D port) - Swing motor (T port)
 - (13): Center swivel joint (D port) - Hydraulic tank
 - (14): Center swivel joint (E port) - Solenoid valve
 - (15): Center swivel joint (B port) - Left travel control lever (B2 port)
 - (16): Center swivel joint (D port) - Right travel control lever (B5 port)
 - (17): Center swivel joint (A port) - Left travel control lever (A2 port)
 - (18): Center swivel joint (C port) - Right travel control lever (A5 port)
12. Pull out pin (19) on the side of center swivel joint and detach turning stopper plate from center swivel joint.



13. Sling revolving frame assembly (20) then remove 40 mounting bolts and lift off revolving frame assembly.  1
 - ★ Use two lever blocks.
 - ★ Leave the two mounting bolts at the front and rear and adjust the center of gravity with the lever blocks while lifting off. Remove the mounting bolts afterwards..

 When removing the revolving frame assembly, take care so that it will not bump the center swivel joint assembly



Revolving frame assembly: 7,800 kg



DISASSEMBLY AND ASSEMBLY OF CONTROL VALVE ASSEMBLY

★ This chapter deals only with precautions to be followed when disassembling and reassembling the control valve assembly.

SPECIAL TOOLS


| Mark | Part No. | Part Name | Necessity | Qty | Distinction* | Sketch |
|------|-----------------------------------|-----------|-----------|-----|--------------|--------|
| 1 | 796-946-1310 | Guide | | 1 | | |
| | (For 723-46-40100 & 723-46-40601) | | | | | |
| | 796-946-1810 | Guide | | | | |
| | (For 723-46-43100 & 723-46-43400) | | | | | |
| | 796-946-2110 | Guide | | | | |
| | (For 723-46-44100) | | | | | |
| M 2 | 796-946-2210 | Guide | | 1 | | |
| | (For 723-46-45100) | | | | | |
| | 796-946-1320 | Guide | | | | |
| | (For 723-46-40100 & 723-46-40601) | | | | | |
| | 796-946-1820 | Guide | | | | |
| | (For 723-46-43100 & 723-46-43400) | | | | | |
| 3 | 796-946-2120 | Guide | | 1 | | |
| | (For 723-46-44100) | | | | | |
| | 796-946-2220 | Guide | | | | |
| | (For 723-46-45100) | | | | | |
| | 796-946-1330 | Sleeve | | | | |
| | (For 723-46-40100 & 723-46-40601) | | | | | |
| 3 | 796-946-1830 | Sleeve | | 1 | | |
| | (For 723-46-43100 & 723-46-43400) | | | | | |
| | 796-946-2130 | Sleeve | | | | |
| | (For 723-46-44100) | | | | | |
| 3 | 796-946-2230 | Sleeve | | 1 | | |
| | (For 723-46-45100) | | | | | |

*Distinction between new and existing part.

Procedures for replacing pressure compensation valve seal


- Remove the seal from pressure compensation valve.
 - ★ Clean the pressure compensation valve thoroughly. Install the seal using a tool, as indicated in the diagram.
- Install the O-ring onto piston (1).
- Place tool **M1** onto piston (1) and push it in slowly by hand so that seal (2) spreads out evenly.

★ The seal may be also installed by pushing it down to the flat surface of the tool and then pushing it in with the tool fitted to the piston.



- Likewise, set tool **M2** to piston (1) in the same direction and push it slowly by hand so that the other seal (3) may be spread out evenly.


★ The seal may be fitted by pushing it down to the flat surface of the tool and then pushing it in with the tool fitted to the piston.




- Keep compensation tool **M3** fitted to piston (1) for about one minute so that seal (2) and (3) will become well adapted.
 - ★ Check that there is no protrusion or cut on the seal.

3. Disassembly of cylinder head assembly

- 1) Remove O-ring and backup ring (15).
- 2) Remove snap ring (16), then remove dust seal (17).
- 3) Remove rod packing (18).
- 4) Remove buffer ring (19).
- 5) Remove bushing (20).


**ASSEMBLY**

- ★ Be careful not to damage the packing, dust seals, and O-rings.
- ★ Clean each part, then cover the piping ports and pin-inserting hole to prevent dust from entering them.
- ★ Do not try to force the backup ring into position. Warm it in warm water (50 - 60°C) before installing it.


**1. Assembly of head assembly**

- 1) Using tool N5, press fit bushing (20).
- 2) Assemble buffer ring (19).
- 3) Assemble rod packing (18).

- 4) Using tool N6, install dust seal (17), and secure with snap ring (16).
- 5) Install backup ring and O-ring (15).



**2. Assembly of piston assembly**


- 1) Using tool N3, expand piston ring (13).
 - ★ Set the piston ring on tool N3, and turn the handle 8 - 10 times to expand the ring.
- 2) Set tool N4 in position, and compress piston ring (13).



REMOVAL AND INSTALLATION OF COUNTERWEIGHT ASSEMBLY

REMOVAL

1. Attach eyebolts b to counterweight assembly (1), and sling.
2. Remove 4 mounting bolts (2) 
 - ★ Take note of where shims were inserted.
3. Lift off counterweight (1) horizontally with wire or chain block. 
 - ★ Be careful not to hit the engine, radiator or cooler.


 Counterweight assembly: 5,500 kg




INSTALLATION

- Install in reverse order of removal.



 Thread of counterweight mounting bolt:
Thread tightener (LT-2)

 Counterweight mounting bolt:
 $1,814.1 \pm 98.1 \text{ Nm}$ { $185 \pm 10 \text{ kgm}$ }



- ★ Installing and adjusting counterweight
 - 1) Adjust clearance on the upper and lower sides with shims.
 - 2) Install counterweight in such a way that clearance between the door and counterweight as well as clearance between the revolving frame and counterweight become $10 \pm 5 \text{ mm}$.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL