

# Shop Manual

COMPACT HYDRAULIC EXCAVATOR

**PC45MR-5E0** SERIAL NUMBERS F20001 and up

**PC55MR-5E0** SERIAL NUMBERS F40001 and up

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

## ABBREVIATION LIST


- This list of abbreviations includes the abbreviations used in the text of the shop manual for parts, components, and functions whose meaning is not immediately clear. The spelling is given in full with an outline of the meaning.
- Abbreviations that are used in general society may not be included.
- Special abbreviations which appear infrequently are noted in the text.
- This list of abbreviations consists of two parts. The first part is a list of the abbreviations used in the text of the manual, and the second part is a list of the abbreviations used in the circuit diagrams.

### List of abbreviations used in the text

Abbreviation	Actual word spelled out	Purpose of use (major applicable machine (*1), or component/system)	Explanation
ABS	Antilock Brake System	Travel and brake (HD, HM)	This is a function that releases the brake when the tires skid (tires are not rotated). This function applies the brake again when the tires rotate.
AISS	Automatic Idling Setting System	Engine	This is a function that automatically sets the idle speed.
AJSS	Advanced Joystick Steering System	Steering (WA)	This is a function that performs the steering operations with a lever instead of using a steering wheel. This function performs gear shifting and changing forward and reverse direction.
ARAC	Automatic Retarder Accelerator Control	Travel and brake (HD, HM)	This is a function that automatically operates the retarder with a constant braking force when letting go of the accelerator pedal on the downhill.
ARSC	Automatic Retarder Speed Control	Travel and brake (HD, HM)	This is a function that automatically operates the retarder to ensure that the machine speed does not accelerate above the speed set by the operator when letting go of the accelerator pedal on the downhill.
ASR	Automatic Spin Regulator	Travel and brake (HD, HM)	This is a function that drives both wheels automatically using the optimum braking force when the tire on one side spins on the soft ground surfaces.
ATT	Attachment	Work equipment	A function or component that can be added to the standard specification.
BCV	Brake cooling oil control valve	BRAKE (HD)	This is a valve that bypasses a part of the brake cooling oil to reduce the load applied to the hydraulic pump when the retarder is not being used.
CAN	Controller Area Network	Communication and electronic control	This is one of communication standards that are used in the network on the machine.
CDR	Crankcase Depression Regulator	Engine	This is a regulator valve that is installed to KCCV ventilator. It is written as CDR valve and is not used independently.
CLSS	Closed-center Load Sensing System	Hydraulic system	This is a system that can actuate multiple actuators simultaneously regardless of the load (provides better combined operation than OLSS).

**REMARK**

When slinging a load with 2 or more ropes, the force subjected to each rope increases with the hanging angle. The figure below shows the variation of allowable load in kN {kg} when slinging is made with 2 ropes, each of which is allowed to sling up to 9.8 kN {1000 kgf} vertically, at various hanging angles. When the 2 ropes sling a load vertically, they can sling up to 2000 kg of total weight. This weight is reduced to 1000 kg when the 2 ropes make a hanging angle of 120°. If the 2 ropes sling a 2000 kg load at a hanging angle of 150°, each rope is subjected to a force as large as 39.2 kN {4000kgf}.




- When installing wire ropes to an angular load, apply pads to protect the wire ropes. If the load is slippery, apply proper material to prevent the wire rope from slipping.
- Use the specified eye bolts and fix wire ropes, chains, etc. to them with shackles, etc.
- Apply wire ropes to the middle part of the hook.

**⚠ Do not use hooks if it does not have a latch system.**

**⚠ Slinging near the tip of the hook may cause the rope to slip off the hook during hoisting.**

**REMARK**


The strength of the hook is maximum at its central part.



- Never use a wire rope which has breaks in strands (A), reduced diameter (B), or kinks (C). There is a danger that the rope may break during the towing operation.

**Precautions for slinging up**

- Wind in the crane slowly until wire ropes are stretched. When settling the wire ropes with the hand, do not grasp them but press them from above. If you grasp them, your fingers may be caught.
- After the wire ropes are stretched, stop the crane and check the condition of the slung load, wire ropes, and pads.



- If the load is unstable or the wire rope or chains are twisted, lower the load and lift it up again.
- Do not lift up the load at an angle.

**Precautions for slinging down**

- When slinging down a load, stop it temporarily at 30 cm above the floor, and then lower it slowly.
- Check that the load is stable, and then remove the sling.
- Remove kinks and dirt from the wire ropes and chains used for the sling work, and put them in the specified place.


**Precautions for using mobile crane****REMARK**

Read Operation and Maintenance Manual of the crane carefully in advance and operate the crane safely.

**Precautions for using overhead traveling crane**


**⚠ When raising a heavy component (heavier than 25 kg), use a hoist or crane.**

**Introduction of parts for the disassembly of the face seal type hoses and tubes**



Nominal No.	Hose side	Pipe joint side	O-ring (3)
	Plug (1)	Nut (2)	
02	07376-70210	02789-00210	02896-11008
03	07376-70315	02789-00315	02896-11009
04	07376-70422	02789-00422	02896-11012
05	07376-70522	02789-00522	02896-11015
06	07376-70628	02789-00628	02896-11018

**Introduction of parts for the disconnection of the taper seal type hoses and tubes**




Nominal No.	Hose side	Pipe joint side
	Plug (1)	Nut (2)
02	07376-50210	07222-00210
03	07376-50315	07222-00312
04	07376-50422	07222-00414
05	07376-50522	07222-00515
06	07376-50628	07222-00616
10	07376-51034	07222-01018
12	07376-51234	07222-01219
14	07376-51443	07222-01422

- After inserting the hose in the mating adapter perfectly, pull it back to check the connecting condition.

**REMARK**


When the hose fitting is pulled back, the rubber cap moves approximately 3.5 mm toward the hose, but it is not a problem.




## METHOD FOR DISCONNECTING AND CONNECTING TYPE 2 PUSH-PULL TYPE COUPLER

### Disconnection

- Hold the tightening adapter part and push body (2) straight until sliding prevention ring (1) contacts contact surface (a) of the hexagonal part at the male end.




- While keeping the condition of step 1, turn lever (3) to the right (clockwise).



- While keeping the conditions of steps 1 and 2, pull out whole body (2) to disconnect it.


**REMARK**

Provide a container to receive a quantity of hydraulic oil which may flow out.



**Method for disconnecting connector with lock to push (AMP-3)**

While pressing lock (E), pull out connector (5) in the direction of the arrow.

**Method for connecting connector with lock to push (AMP-3)**


Insert it straight until it clicks.

**Method for disconnecting connector with lock to push (SUMITOMO-3)**

While pressing lock (E), pull out connector (5) in the direction of the arrow.

**REMARK**


Pull up the connector straight.

**Method for connecting connector with lock to push (SUMITOMO-3)**

Insert it straight until it clicks.

**Method for disconnecting connector with lock to push (SUMITOMO-4)**

While pressing lock (D), pull out connector (4) in the direction of the arrow.


**Method for connecting connector with lock to push (SUMITOMO-4)**

Insert it straight until it clicks.

## Table of tightening torque for O-ring boss piping joints

### REMARK

Tighten the pipe joint for O-ring boss to the torque shown in the table below unless otherwise specified.




Nominal No.	Thread diameter (mm)	Width across flats (mm)	Tightening torque (Nm {kgfm} )	
			Range	Target
02	14	Varies depending on type of connector.	35 to 63 {3.5 to 6.5}	44 {4.5}
-	18		59 to 98 {6.0 to 10.0}	78 {8.0}
03, 04	20		84 to 132 {8.5 to 13.5}	103 {10.5}
05, 06	24		128 to 186 {13.0 to 19.0}	157 {16.0}
10, 12	33		363 to 480 {37.0 to 49.0}	422 {43.0}
14	42		746 to 1010 {76.0 to 103}	883 {90.0}

## Table of tightening torque for O-ring boss plugs

### REMARK

Tighten the plug for O-ring boss to the torque shown in the table below unless otherwise specified.



Nominal No.	Thread diameter (mm)	Width across flats (mm)	Tightening torque (Nm {kgfm} )	
			Range	Target
08	8	14	5.88 to 8.82 {0.6 to 0.9}	7.35 {0.75}
10	10	17	9.8 to 12.74 {1.0 to 1.3}	11.27 {1.15}
12	12	19	14.7 to 19.6 {1.5 to 2.0}	17.64 {1.8}
14	14	22	19.6 to 24.5 {2.0 to 2.5}	22.54 {2.3}
16	16	24	24.5 to 34.3 {2.5 to 3.5}	29.4 {3.0}

## ABBREVIATION LIST

- This list of abbreviations includes the abbreviations used in the text of the shop manual for parts, components, and functions whose meaning is not immediately clear. The spelling is given in full with an outline of the meaning.
- Abbreviations that are used in general society may not be included.
- Special abbreviations which appear infrequently are noted in the text.
- This list of abbreviations consists of two parts. The first part is a list of the abbreviations used in the text of the manual, and the second part is a list of the abbreviations used in the circuit diagrams.

### List of abbreviations used in the text

Abbreviation	Actual word spelled out	Purpose of use (major applicable machine (*1), or component/system)	Explanation
ABS	Antilock Brake System	Travel and brake (HD, HM)	This is a function that releases the brake when the tires skid (tires are not rotated). This function applies the brake again when the tires rotate.
AISS	Automatic Idling Setting System	Engine	This is a function that automatically sets the idle speed.
AJSS	Advanced Joystick Steering System	Steering (WA)	This is a function that performs the steering operations with a lever instead of using a steering wheel. This function performs gear shifting and changing forward and reverse direction.
ARAC	Automatic Retarder Accelerator Control	Travel and brake (HD, HM)	This is a function that automatically operates the retarder with a constant braking force when letting go of the accelerator pedal on the downhill.
ARSC	Automatic Retarder Speed Control	Travel and brake (HD, HM)	This is a function that automatically operates the retarder to ensure that the machine speed does not accelerate above the speed set by the operator when letting go of the accelerator pedal on the downhill.
ASR	Automatic Spin Regulator	Travel and brake (HD, HM)	This is a function that drives both wheels automatically using the optimum braking force when the tire on one side spins on the soft ground surfaces.
ATT	Attachment	Work equipment	A function or component that can be added to the standard specification.
BCV	Brake cooling oil control valve	BRAKE (HD)	This is a valve that bypasses a part of the brake cooling oil to reduce the load applied to the hydraulic pump when the retarder is not being used.
CAN	Controller Area Network	Communication and electronic control	This is one of communication standards that are used in the network on the machine.
CDR	Crankcase Depression Regulator	Engine	This is a regulator valve that is installed to KCCV ventilator. It is written as CDR valve and is not used independently.
CLSS	Closed-center Load Sensing System	Hydraulic system	This is a system that can actuate multiple actuators simultaneously regardless of the load (provides better combined operation than OLSS).

## SPECIFICATIONS

### SPECIFICATIONS: PC45MR-5E0

Item	Unit	PC45MR-5E0	
		Canopy specifications	Cab specifications
Bucket capacity	m <sup>3</sup>	0.14	
Machine weight			
Rubber shoe specification	kg	4750	4870
Steel shoe specification		4820	4940
<b>Performance</b>			
<b>Working ranges</b>			
Maximum digging depth	mm	3625	
Maximum vertical wall digging depth	mm	3070	
Maximum digging reach	mm	6040	
Maximum digging reach at ground level	mm	5895	
Maximum digging height	mm	5730	
Maximum dumping height	mm	4000	
Offset of bucket (Left side/right side)	mm	630/880	
Maximum raising distance of the blade	mm	430	
Maximum lowering distance of the blade	mm	330	
Maximum digging force	kN {kg}	33.9 {3460}	33.9 {3460}
Continuous swing speed	rpm	9.0	9.0
Swing operation max. slope angle	Degrees	19.0	19.0
Travel speed (Lo/Hi)			
Rubber shoe specification	km/h	2.6/4.6	2.6/4.6
Steel shoe specification		2.4/4.3	2.4/4.3
Gradeability	Degrees	30	30
Ground pressure			
Rubber shoe specification	kPa {kg/cm <sup>2</sup> }	26.6 {0.27}	27.3 {0.28}
Steel shoe specification		27.4 {0.28}	28.1 {0.29}
<b>Dimensions</b>			
Overall length (for transport)	mm	5330	5330
Overall width	mm	1960	1960
Overall height (for transport)	mm	2550	2590
Ground clearance of upper structure bottom	mm	608	608
Minimum ground clearance	mm	290	290







## TABLE OF FUEL, COOLANT, AND LUBRICANTS

For details of notes (Note 1, Note 2...) in the table, see "Operation and Maintenance Manual".

Reservoir	Fluid type	Recommended Komatsu Fluids	Ambient temperature	
			°C	
			Min	Max
Engine oil pan	Engine oil	EO10W30-LA (KES Diesel Engine Oil)	-20	40
		EO15W40-LA CK4 (KES Diesel Engine Oil)	-15	50
		EO30-DH (KES Diesel Engine Oil)	0	40
Final drive case	Power train oil	TO30 (KES)	-30	50
Hydraulic system	Hydraulic oil	HO56-HE (KES)	-20	50
		HO46-HM (KES)	-10	50
	Power train oil	TO10 (KES)	-10	50
Grease fitting	Hyper grease (Note.1)	G2-TE (KES)	-20	50
	Lithium EP grease	G2-LI (KES)	-10	50
Cooling system	Non-Amine Engine Coolant (AF-NAC) (Note.2)	AF-NAC (KES)	-30	50
Fuel tank	Diesel fuel	EN 590 Class2	-30	20
		EN 590 Grade D	0	50

Unit: ℓ

Places to supply oil, coolant, etc.	Specified amount	Refill capacity
Engine oil pan	8.1	7.5
Final drive case (each on right and left sides)	0.7	0.7
Hydraulic oil system	55	20
Cooling system	8.8	-
Fuel tank	65	-

Status	Elapsed time (*1)	Machine monitor					Engine de-ration (*4)
		Message of NOx control system Information	Caution lamp (Action level)	Tone of audible alert	Failure code for abnormality (*2)	Failure code for Inducement strategy status (*3)	
2 Low-Level Inducement (Inducement 1)	64 hours	3: EGR system inspection and maintenance.	Red  APP14416	Intermittently	#B1675	AS00R3 (Inducement 1 (NOx Control Device Abnormality))	Torque reduction rate: 25% or more
			Red  G0004354				
			Red  APP14414				
4 Severe Inducement (Inducement 2)	Until abnormality is repaired	4: Engine power is under heavy deration.	Red  APP14416	Continuously	#B1675	AS00R4 (Inducement 2 (NOx control Device Abnormality))	Torque: over 50% or more Engine speed reduction rate: Min. 60%
			Red  G0004354				
			Red  APP14413				

\*1:Elapsed time of each stage describes an accumulated time advancing to the next stage after starting “Warning” stage is started.

\*2: These failure codes are displayed on “Current Abnormality” in the operator mode, or “Abnormality Record” in the service mode. The failure code shown here is an example of failure code which is displayed on the machine monitor when an abnormality occurs. For the failure codes, see TROUBLESHOOTING.

\*3:These failure codes are displayed on “Current Abnormality” in the operator mode, or “Abnormality Record” in the service mode.


\*4: These percentages show a torque reduction ratio from the full torque curve, and a speed reduction ratio from the rated speed.

**INDUCEMENT STRATEGY FOR ABNORMALITY RECURRENCE**

- The NOx control system continuously monitors its operation conditions and stores information on inappropriate operations including malfunctions.
- The stored information is utilized to monitor recurrences of abnormalities. Those information are required by the authorities. The abnormality counting spans 40 hours and it monitors the abnormalities that trigger Inducement.

# AUTO-DECELERATION SYSTEM

## AUTO-DECELERATION SYSTEM DIAGRAM



A4P16721

### Input and output signals

- |                               |                                    |
|-------------------------------|------------------------------------|
| a: CAN signal                 | e: 1st throttle signal             |
| b: CAN signal                 | f: Fuel supply pump control signal |
| c: Oil pressure sensor signal | g: Various sensor signals          |
| d: Oil pressure switch signal |                                    |
| 1: Machine controller         | 8: Oil pressure sensor             |
| 2: Engine controller          | 9: Main pump                       |
| 3: Machine monitor            | 10: Control valve                  |
| 4: Fuel control dial          | 10a: Merge-divider valve           |
| 5: Fuel supply pump           | 11: PPC lock solenoid valve        |
| 6: Various sensors            | 12: Swing motor                    |
| 7: Oil pressure switch        | 12a: Swing parking brake           |


### FUNCTION OF AUTO-DECELERATION SYSTEM

- When all the control levers are set to NEUTRAL positions while waiting for a dump truck or next work, the engine speed decreases to the control speed automatically to improve the fuel economy and reduce the noise.
- If any control lever is operated, the engine speed returns immediately to the speed set with the fuel control dial.

## COMPONENT PARTS OF CONTROL SYSTEM

### MACHINE MONITOR

#### FUNCTION OF MACHINE MONITOR






APP16731

- The machine monitor has monitor display function and mode selection function.
- CPU (Central Processing Unit) is installed inside the machine monitor, and it processes, displays, and outputs the information.
- The monitor system monitors the machine state by obtaining the information with the sensors and switches installed in various parts of the machine, processes the information instantly. It displays the information on the machine monitor to inform the operator of the machine condition.  
The followings are categories which contents displayed on the machine monitor are broadly divided into.
  - Alarms when the machine has a trouble
  - Machine state (engine coolant temperature, fuel level, etc.)
- The switches on the machine monitor have functions to control the machine.

Pin No.	Signal name	Input and output signals
16	Service pressure sensor 2	Input
17	Starting switch ACC signal	Input
18	(*1)	-
19	(*1)	-
20	(*1)	-
21	Work equipment PPC pressure sensor	Input
22	PPC lock lever cancel signal	Input
23	Starting switch C signal	Input
24	External starting signal	Input
25	(*1)	-
26	CAN_L_0	Input and output
27	(*1)	-
28	(*1)	-
29	Travel PPC pressure sensor	Input
30	R.H. attachment lever sub	Input
31	(*1)	-
32	GND (analog signal)	Input
33	Terminating resistor	Input and output
34	Terminating resistor	Input and output
35	Service pressure sensor 1	Input
36	Breaker switch (main)	Input
37	(*1)	-
38	(*1)	-
39	(*1)	-
40	(*1)	-
41	PPC lock lever signal	Input
42	Working lamp switch	Input
43	(*1)	-
44	(*1)	-
45	CAN_H_1	Input and output
46	GND (analog signal)	Input
47	GND (analog signal)	Input
48	Swing parking brake cancel PPC pressure	Input
49	(*1)	-
50	(*1)	-
51	GND (analog signal)	Input
52	GND (analog signal)	Input
53	(*1)	-

- In mode P, E, ATT/P, or ATT/E, B, the engine speed is kept around the matching point set in each mode.
- As the load of the pump increases, and the pump discharged pressure increases, the engine speed decreases.
- The machine controller raises the engine speed to near the matching point in order to reduce the discharged volume of the pump.
- As the load of the pump decreases and the pump discharged pressure decreases, the pump discharged volume increases until the engine speed comes to near the matching point.



**Control function when pump secondary drive switch is ON**


When the main pump does not operate normally, and machine does not work due to an abnormality occurring in the controller, etc., operate the pump drive secondary switch (1). With this operation, temporary work can be performed with absorption torque to mode E. At this time, only PC-EPC valve senses the oil pressure since a constant current flows from the battery to PC-EPC valve.

**REMARK**

Pump drive secondary switch (1) is an alternative type. If the machine is operated with this switch at emergency (a) position while the machine is normal, action level L03 appears on the display.

a: Emergency (when abnormal)

b: Normal (when normal)




- |             |   |
|-------------|---|
| 1: Lever    | 10: Lock nut                                |
| 2: Spool    | 11: Spring (LS valve)                       |
| 3: Plug     | 12: PC-EPC valve                            |
| 4: Sheet    | 13: Spool                                   |
| 5: Piston   | 14: Ball                                    |
| 6: Sleeve   | 15: Plug                                    |
| 7: PC valve | 16: PC mode selector power supply connector |
| 8: LS valve | 17: Spring (PC valve)                       |
| 9: Plug     | 18: Retainer                                |

**OPERATION OF MAIN PUMP SERVO VALVE**

**Action of spring**


1. The spring force of spring (2) in PC valve is determined by the position of the swash plate.
2. If servo piston (6) moves to the right, spring (2) is compressed through lever (1), and the spring force changes. The spring has characteristics that the spring constant changes into 2 stages depending on the height of the spring.

**Operation when pump pressure (PAVE) is low (load is light)**



A4P16711

Sectional views (F-F, G-G, H-H, J-J, AK-AK, AN-AN)




A4P16483

**R.H. travel valve**

1: Pressure compensation valve (\*2) (right travel)


### When operating the work equipment with fine control



A4P16802

1. When operating the work equipment with fine control, LS pressures of (PLS1) and (PLS2) are generated and they act on the right side of spool (1).
2. The differential pressure between LS pressures of (PLS1) and (PLS2) and pump discharged pressures of (P1) and (P2) is large since the open area of the control valve spool is small.
3. The differential pressure between pump discharged pressures of (P1) and (P2) and LS pressures of (PLS1) and (PLS2) reaches the set pressure of spring (2).
4. Spool (1) moves to the right, and pump circuits (P1) and (P2) are connected to tank circuit (T).
5. Pump discharged pressures of (P1) and (P2) are set to the set pressure of spring (2) + LS pressures of (PLS1) and (PLS2).
6. LS differential pressure ( $\Delta PLS$ ) becomes the set pressure of spring (2).

## OPERATION OF LOGIC VALVE OF CONTROL VALVE



### Operation in dividing mode

1. Only travel PPC pressure acts on port (b).
2. Travel PPC pressure acts on output port (c) of the merge-divider valve as it is.
3. This pressure sets the merge-divider valve to the dividing mode.

### Operation in merging mode

1. Work equipment PPC pressure (excluding the swing pressure) acts on port (a).
2. The pressure in output port (c) of the merge-divider valve is connected through spool (1) to spring chamber (d) and used as seal drain pressure.
3. The merge-divider valve is not changed but kept in the merging mode.

### REMARK

Even if travel PPC pressure acts while work equipment PPC pressure (excluding the swing pressure) is acting, spool (1) is kept pressed and the merge-divider valve is kept in the merging mode.

When the work equipment is operated, the pilot pressures of the boom, arm, bucket, boom swing, blade, and attachment are outputted to auto-deceleration sensor port (PW) through the check valves and shuttle valves in their respective spring cases.

## **TRAVEL PILOT PRESSURE DETECTION CIRCUIT OF CONTROL VALVE**

### **FUNCTION OF TRAVEL PILOT PRESSURE DETECTION CIRCUIT OF CONTROL VALVE**

This circuits collects the pilot pressures for R.H. travel and L.H. travel, and outputs oil pressure signals through the auto-deceleration sensor port.

## WORK EQUIPMENT AND TRAVEL AUTOMATIC LOCK SYSTEM

### FUNCTION OF WORK EQUIPMENT AND TRAVEL AUTOMATIC LOCK SYSTEM

This function automatically sets the lock lever in the same state as when it is locked to prevent the work equipment or the machine continues its operation when the lock lever is unlocked while the work equipment control lever or the travel lever is operated.

### OPERATION OF WORK EQUIPMENT AND TRAVEL AUTOMATIC LOCK SYSTEM

This system recognizes an abnormality when either one or more of the oil pressure switches or sensors detect the pressure higher than specified pressure (D), or if the attachment drive signal is input in time period (C) after the lock lever is canceled (A).

The machine controller outputs the lock lever automatic lock relay drive signal to shut off the current to PPC lock solenoid and set the machine to lock state (B).


A: Lock lever is canceled

B: Lock lever automatic lock is in operation

C: Within 0.4 seconds

D: 5 kPa

E: 0.1 seconds



#### REMARK

The pressure may not increase within time (C) and the lock lever automatic lock control may not operate when the hydraulic oil temperature is low or high-viscosity hydraulic oil used.

### Control when lock lever automatic lock cancel switch is “ON”

you can operate the machine by operating lock lever automatic lock cancel switch (1) if an abnormality occurs in the controller, etc., and the main pump does not operate normally, and machine does not work.


At this time, the lock lever automatic lock control function does not work.

a: Emergency (when abnormal)

b: Normal (when normal)

#### REMARK

- Lock lever automatic lock cancel switch (1) is an alternate type switch. The lock lever automatic lock cancel pilot lamp lights up on the display if it is set to “EMERGENCY (a)” position when PPC lock lever is in the free state.
- The following failure code is displayed when this switch is “ON”.



Action level	Failure code	Failure (displayed on screen)
L00	DDNS0 0	Lock Lever Auto Lock Release SW On


### BOOM SWING PPC VALVE

#### PPC

Abbreviation for Proportional Pressure Control

### STRUCTURE OF BOOM SWING PPC VALVE

#### General view and sectional view



P: From pilot pump

P1: Control valve (to boom swing right port)

1: Spool

P2: Control valve (to boom swing left port)

T: To hydraulic tank


2: Piston

## SWING PARKING BRAKE OF SWING MOTOR

### OPERATION OF SWING PARKING BRAKE OF SWING MOTOR


#### Operation when swing or arm control lever are in NEUTRAL

1. Brake piston (1) is pushed up by brake spring (2) since PPC output pressure is 0 MPa {0 kgf/cm<sup>2</sup>} .
2. Disc (3) and plate (4) are pressed, and the brake operates.




#### Operation when swing or arm control lever are operated

1. PPC output pressure flows through port (B) into brake chamber (a).
2. The pressurized oil in chamber (a) presses down brake spring (2).
3. Brake piston (1) moves downward and disc (3) and plate (4) are separated, and the brake is released.



## Structure

- Swash plate (1) has 2 planes of x and y, and is supported on ball (2).
- The travel speed is changed by setting the angle of swash plate (1) to the maximum or minimum with the pressurized oil from control chamber (a) which acts on control piston (3).



## SPECIFICATIONS OF TRAVEL MOTOR

Model: PHV-4B-60C-PT-9480Z3

Theoretical displacement (Lo): 24.7 cm<sup>3</sup>/rev

Theoretical displacement (Hi): 14.3 cm<sup>3</sup>/rev

Rated speed (Lo): 2227 rpm

Rated speed (Hi): 3846 rpm

Brake releasing pressure: 1.13 MPa {11.5 kgf/cm<sup>2</sup>}

Travel speed selector pressure: 0.86 MPa {8.8 kgf/cm<sup>2</sup>}

Automatic gear shift selecting pressure (Lo→Hi): 21.6 MPa {221 kgf/cm<sup>2</sup>}

Automatic gear shift selecting pressure (Hi→Lo): 23.1 MPa {236 kgf/cm<sup>2</sup>}

Reduction ratio: 63.80

## FUNCTION OF TRAVEL MOTOR

The travel motor converts the fluid energy of hydraulic oil into rotational mechanical energy, and travels the machine.

**FUNCTION OF WORK EQUIPMENT**

- The boom is operated by the boom cylinder. The boom moves the whole work equipment upward and downward.
- The arm is operated by the arm cylinder. The boom pulls in or pushes out the bucket.
- The bucket is operated by the bucket cylinder and the bucket link.
- The bucket link increases the moving range of the bucket.
- The blade is operated by the blade cylinder.
- The boom swing bracket can swing the boom swing direction to the right or left by the boom swing cylinder.

# STANDARD VALUE TABLE FOR ENGINE

## STANDARD VALUE TABLE FOR ENGINE: PC45MR-5E0

### Performance

Machine model			PC45MR-5E0	
Engine			4D88E-7	
Item	Measurement condition	Unit	Standard value for new machine	Repair limit
Engine speed at high idle	<ul style="list-style-type: none"> <li>Engine coolant temperature: 60 to 100 °C</li> <li>Hydraulic oil temperature: 45 to 55 °C</li> <li>Fuel control dial: MAX (High idle) position</li> <li>Working mode: P (Power Mode)</li> <li>Travel speed: Hi</li> <li>Auto-deceleration switch: OFF</li> </ul>	rpm	2550±50 (When the maximum value for turning and traveling)	2550±50 (When the maximum value for turning and traveling)
			2430±50 (When the position of the operating lever is in neutral)	2430±50 (When the position of the operating lever is in neutral)
Engine speed at low idle	<ul style="list-style-type: none"> <li>Engine coolant temperature: 60 to 100 °C</li> <li>Hydraulic oil temperature: 45 to 55 °C</li> <li>Fuel control dial: MIN (Low idle) position</li> <li>Working mode: P (Power Mode)</li> <li>Auto-deceleration switch: OFF</li> </ul>	rpm	1225±50	1225±50

### Air intake and exhaust system

Machine model			PC45MR-5E0	
Engine			4D88E-7	
Item	Measurement condition	Unit	Standard value for new machine	Repair limit
Exhaust gas color	<ul style="list-style-type: none"> <li>Engine coolant temperature: 60 to 100 °C</li> <li>After keeping it at normal condition for 5 seconds</li> <li>Fuel control dial: MAX (High idle) position</li> <li>Auto-deceleration switch: OFF</li> </ul>	Bosch index	Max. 0.5	Max. 1.5
Valve clearance	Engine coolant temperature: Normal temperature	Intake valve	0.20±0.05	0.20±0.05
		Exhaust valve	0.20±0.05	0.20±0.05

### Main body

Machine model			PC45MR-5E0	
Engine			4D88E-7	
Item	Measurement condition	Unit	Standard value for new machine	Repair limit
Compression pressure	<ul style="list-style-type: none"> <li>Engine coolant temperature: 40 to 60 °C</li> <li>At cranking (engine speed): 250 rpm (reference)</li> </ul>	MPa {kg/cm <sup>2</sup> }	3.14 to 3.43 {32 to 35}	2.45 to 2.65 {25 to 28}

## Work equipment speed

Machine model			PC45MR-5E0	
Engine			4D88E-7	
Item	Measurement condition	Unit	Standard value for new machine	Repair limit
Boom speed	<ul style="list-style-type: none"> <li>Hydraulic oil temperature: 45 to 55 °C</li> <li>Fuel control dial: MAX (High idle) position</li> <li>Working mode: P (Power Mode)</li> <li>Time required to move bucket teeth from ground to RAISE stroke end</li> <li>Measurement posture: See "MACHINE POSTURE AND PROCEDURE FOR MEASURING PERFORMANCE", "Fig. 8".</li> </ul>	RAISE	2.8±0.3	Max. 3.4
		LOWER	2.8±0.3	Max. 3.4
Arm speed	<ul style="list-style-type: none"> <li>Hydraulic oil temperature: 45 to 55 °C</li> <li>Fuel control dial: MAX (High idle) position</li> <li>Working mode: P (Power Mode)</li> <li>Time required for operation between dump stroke end and arm IN stroke end</li> <li>Measurement posture: See "MACHINE POSTURE AND PROCEDURE FOR MEASURING PERFORMANCE", "Fig. 9".</li> </ul>	Arm IN	3.0±0.3	Max. 3.6
		DUMP	2.5±0.3	Max. 3.0
Bucket speed	<ul style="list-style-type: none"> <li>Hydraulic oil temperature: 45 to 55 °C</li> <li>Fuel control dial: MAX (High idle) position</li> <li>Working mode: P (Power Mode)</li> <li>Time required for operation between dump stroke end and arm IN stroke end</li> <li>Measurement posture: See "MACHINE POSTURE AND PROCEDURE FOR MEASURING PERFORMANCE", "Fig. 10".</li> </ul>	Bucket CURL	2.9±0.3	Max. 3.5
		DUMP	2.0±0.3	Max. 2.4

## Work equipment speed


Machine model			PC55MR-5E0	
Engine			4D88E-7	
Item	Measurement condition	Unit	Standard value for new machine	Repair limit
Boom speed	<ul style="list-style-type: none"> <li>Hydraulic oil temperature: 45 to 55 °C</li> <li>Fuel control dial: MAX (High idle) position</li> <li>Working mode: P (Power Mode)</li> <li>Time required to move bucket teeth from ground to RAISE stroke end</li> <li>Measurement posture: See "MACHINE POSTURE AND PROCEDURE FOR MEASURING PERFORMANCE", "Fig. 8".</li> </ul>	RAISE	2.9±0.3	Max. 3.5
		LOWER	2.8±0.3	Max. 3.4
Arm speed	<ul style="list-style-type: none"> <li>Hydraulic oil temperature: 45 to 55 °C</li> <li>Fuel control dial: MAX (High idle) position</li> <li>Working mode: P (Power Mode)</li> <li>Time required for operation between dump stroke end and arm IN stroke end</li> <li>Measurement posture: See "MACHINE POSTURE AND PROCEDURE FOR MEASURING PERFORMANCE", "Fig. 9".</li> </ul>	Arm IN	3.1±0.3	Max. 3.7
		DUMP	2.5 (+0.4/-0.2)	Max. 3.0
Bucket speed	<ul style="list-style-type: none"> <li>Hydraulic oil temperature: 45 to 55 °C</li> <li>Fuel control dial: MAX (High idle) position</li> <li>Working mode: P (Power Mode)</li> <li>Time required for operation between dump stroke end and arm IN stroke end</li> <li>Measurement posture: See "MACHINE POSTURE AND PROCEDURE FOR MEASURING PERFORMANCE", "Fig. 10".</li> </ul>	Bucket CURL	2.8±0.3	Max. 3.4
		DUMP	2.0±0.3	Max. 2.4

TEST AND ADJUST OIL PRESSURE IN PUMP LS CONTROL CIRCUIT .....	30-67
METHOD FOR TESTING LS DIFFERENTIAL PRESSURE BY MACHINE MONITOR .....	30-67
METHOD FOR TESTING LS DIFFERENTIAL PRESSURE BY TESTING TOOL .....	30-68
METHOD FOR ADJUSTING LS VALVE.....	30-70
TEST OUTLET PRESSURE OF SOLENOID VALVE .....	30-71
METHOD FOR TESTING OUTLET PRESSURE OF SOLENOID VALVE BY MACHINE MONITOR.....	30-71
METHOD FOR TESTING OUTLET PRESSURE OF SOLENOID VALVE BY TESTING TOOL .....	30-72
OPERATING CONDITION OF SOLENOID VALVE .....	30-73
TEST PPC VALVE OUTLET PRESSURE .....	30-74
METHOD FOR TESTING OUTLET PRESSURE OF PPC VALVE BY MACHINE MONITOR.....	30-74
METHOD FOR TESTING OUTLET PRESSURE OF PPC VALVE BY TESTING TOOL.....	30-77
ADJUST WORK EQUIPMENT AND SWING PPC VALVES .....	30-80
METHOD FOR ADJUSTING PLAY OF WORK EQUIPMENT AND SWING PPC VALVES.....	30-80
TEST SWING PARKING BRAKE RELEASE PRESSURE .....	30-81
METHOD FOR TESTING SWING PARKING BRAKE RELEASE PRESSURE WITH MACHINE MONI- TOR.....	30-81
METHOD FOR TESTING SWING PARKING BRAKE RELEASE PRESSURE BY TESTING TOOL.....	30-81
TEST AND ADJUST TRAVEL DEVIATION .....	30-83
METHOD FOR TESTING TRAVEL DEVIATION .....	30-83
METHOD FOR ADJUSTING TRAVEL DEVIATION.....	30-83
TEST THE PARTS CAUSING HYDRAULIC DRIFT IN WORK EQUIPMENT.....	30-86
METHOD FOR TESTING THE PARTS CAUSING HYDRAULIC DRIFT OF BOOM CYLINDER AND BUCKET CYLINDER.....	30-86
METHOD FOR TESTING THE PARTS CAUSING HYDRAULIC DRIFT OF ARM CYLINDER.....	30-86
METHOD FOR TESTING THE PARTS CAUSING HYDRAULIC DRIFT OF PPC VALVE .....	30-87
TEST OIL LEAKAGE .....	30-88
METHOD FOR TESTING OIL LEAKAGE FROM BOOM CYLINDER .....	30-88
METHOD FOR TESTING OIL LEAKAGE FROM ARM CYLINDER .....	30-88
METHOD FOR TESTING OIL LEAKAGE FROM BUCKET CYLINDER.....	30-89
METHOD FOR TESTING OIL LEAKAGE FROM BLADE CYLINDER.....	30-89
BLEED AIR FROM HYDRAULIC CIRCUIT .....	30-91
METHOD FOR BLEEDING AIR FROM HYDRAULIC CIRCUIT .....	30-92
PRESSURIZE HYDRAULIC TANK .....	30-94
METHOD FOR PRESSURIZING HYDRAULIC TANK.....	30-94
CAB AND ITS ATTACHMENTS .....	30-95
METHOD FOR OPENING AND CLOSING FLOOR UNIT.....	30-95
METHOD FOR OPENING FLOOR UNIT .....	30-96
METHOD FOR CLOSING FLOOR UNIT.....	30-101
ELECTRICAL SYSTEM.....	30-105
SET AND OPERATE MACHINE MONITOR.....	30-105
OPERATOR MODE .....	30-108
CHECKING FUNCTION BY LCD (LIQUID CRYSTAL DISPLAY) .....	30-108
CHECKING FUNCTION OF SERVICE METER .....	30-108
METHOD FOR SETTING USAGE LIMITATION AND CHANGING PASSWORD .....	30-108
SERVICE MODE.....	30-111
METHOD FOR OPERATING SERVICE MODE .....	30-111
METHOD FOR CHECKING PRE-DEFINED MONITORING INFORMATION .....	30-113
METHOD FOR CHECKING SELF-DEFINE MONITORING INFORMATION .....	30-116
ABNORMALITY RECORD MENU.....	30-123
METHOD FOR CONFIRMING MAINTENANCE RECORD .....	30-126
METHOD FOR OPERATING MAINTENANCE MODE SETTING.....	30-127
METHOD FOR OPERATING PHONE NUMBER ENTRY SETTING .....	30-131
DEFAULT MENU.....	30-133
DIAGNOSTIC TESTS MENU.....	30-139
ADJUSTMENT MENU .....	30-147
METHOD FOR OPERATING BATTERY DISCONNECT SWITCH SETTING.....	30-155


### SKETCH OF TOOLS FOR TESTING AND ADJUSTING

Note: Komatsu does not take any responsibility for special tools manufactured according to these sketches.

Sensor adapter



Wiring harness




## BLEED AIR FROM FUEL SYSTEM

**⚠** Place the machine on a level ground, lower the work equipment to the ground so that it is stable, set the lock lever to LOCK position, and stop the engine.

**⚠** Immediately after the engine is stopped, its parts and oil are still very hot, and may cause burn injury. Accordingly, wait until all parts have cooled down before starting the work.

Air bleeding route of fuel system

fuel tank → prefilter → feed pump → main filter → fuel cooler → fuel tank





B4P34464

For bleeding air from fuel system to perform troubleshooting or periodic maintenance, refer to this section.

## METHOD FOR BLEEDING AIR FROM FUEL SYSTEM

In the following cases, bleed air according to this procedure.

- When the fuel filter is replaced
  - When fuel has run out
1. Fill the fuel tank with fuel.
  2. Open the cover at the rear right of the machine.
  3. Set filter vale (1) as shown in the figure.
  4. Loosen air bleeding bolt (2) of the fuel prefilter by 2 to 3 turns.
  5. Tighten air bleeding bolt (2) when the fuel including no air bubbles comes out from air bleeding bolt (2).
-  bleeder bolt (2):  
2.5±0.5 Nm {0.25±0.05 kgfm}
6. Turn the engine starting switch to ON position.



BPP34114

3. Extend the arm cylinder and bucket cylinder to the end (to the maximum CURL position) or retract them to the end (to the maximum DUMP position), and lower the work equipment to the ground.

**REMARK**

Since the anti-drop valve is attached to boom cylinder bottom side, hydraulic oil on bottom side of boom cylinder is drained when work equipment is lowered to the ground, and remaining pressure drops.

4. Turn the starting switch to OFF position.
5. Loosen the oil filler cap of the hydraulic tank gradually, and release the air in the tank.

**REMARK**

Leave the oil filler cap of the hydraulic tank removed.

6. Release the remaining pressure in hydraulic cylinder circuit
  - 1) Turn the starting switch to ON position.
  - 2) Set the lock lever to FREE position, and operate the right and left work equipment control levers forward, backward, rightward, and leftward.

**REMARK**

The work equipment is operated by the pressure in PPC accumulator. Pressure in PPC accumulator is lost by operating the work equipment control levers 2 or 3 times.

- 3) Set the lock lever in LOCK position.
- 4) Start the engine and run it with the fuel control dial at MIN (Low idle) position for approximately 10 seconds to increase the pressure in PPC accumulator.
7. Repeat steps 1) and 4) 4 or 5 times to release the remaining pressure from the hydraulic cylinder circuit.

**⚠ When disassembling the anti-drop valve, loosen anti-drop valve mounting bolts gradually. Make sure that hydraulic oil pressure is released, then disassemble.**




### Method for releasing remaining pressure from machine with anti-drop valve for arm in arm maximum IN posture

**⚠ Place the machine on a level ground.**


**⚠ When disassembling the anti-drop valve, always release the remaining pressure in the cylinder circuit.**

The following is the procedure for releasing the remaining pressure in the arm maximum IN posture.


1. Check the function of PPC accumulator
  - 1) Retract arm cylinder and bucket cylinder to the stroke ends (to set the machine in maximum reach posture), and hold the work equipment at height (a) above the ground.  
(a) : 1.5 m
  - 2) Keep the arm cylinder and bucket cylinder retracted to the stroke ends, turn the starting switch to OFF position, and stop the engine.
  - 3) Turn the starting switch to ON position.
  - 4) Set the lock lever to FREE position.



- Remove the cover (1).




- Remove the plug of pump discharge pressure pickup port (P1) or (P2).
- Install nipple C to pump discharged pressure pickup port (P1) or (P2), and connect the coupling (2) or (3) of sensor adapter F.




**REMARK**


- Connector (P11) side is displayed by monitoring code: 01141 "Service Press. Sens1".
- Connector (P12) side is displayed by monitoring code: 01142 "Service Press. Sens2".



- Open the floor. For details, see TESTING AND ADJUSTING, "METHOD FOR OPENING AND CLOSING FLOOR".
- Connect the connector (P04) of the sensor adapter F to the service pressure connector (P04).
- Close the floor. For details, see TESTING AND ADJUSTING, "METHOD FOR OPENING AND CLOSING FLOOR".
- Start the engine.



- Select and display (12/14) "Predefined Mon" or following monitoring item on "SET AND OPERATE MACHINE MONITOR".  
Monitoring code: 01141 "Service Press. Sens1"  
Monitoring code: 01142 "Service Press. Sens2"
- Adjust the hydraulic oil temperature within the specified range.
- Set the working mode to P ("Power Mode").
- Depress the boom swing control pedal, and move the boom swing cylinder to the stroke end.



- Turn the fuel control dial in MAX (High idle) position and check the oil pressure at swing relief.




4. Install nipple C to pilot pump pressure output port (1), and connect gauge A1 of hydraulic tester A.

**REMARK**

Gauge in digital hydraulic tester B can also be used in place of gauge A1.

5. Set working mode to P ("Power Mode"), turn off auto-deceleration.
6. Start the engine to increase the hydraulic oil temperature to 45 to 55 °C.
7. Set the fuel control dial to MAX (High idle) position and check the oil pressure when all the control levers and pedals are in NEUTRAL.


For standard values, see STANDARD VALUE TABLE, "STANDARD VALUE TABLE FOR MACHINE".



After finishing the test, remove the testing tools and restore the machine.

**METHOD FOR ADJUSTING OIL PRESSURE OF CONTROL CIRCUIT**

If the oil pressure in the control circuits is abnormal, adjust control relief valve (2) according to the following procedure.



1. Tilt open the floor frame. For details, see "HOW TO OPEN AND CLOSE FLOOR".

- 3. R.H. PPC valve
- 4. L.H. PPC valve
- 5: Boom swing PPC valve
- 6: Blade PPC valve
- 7: Attachment 1 EPC valve
- 8: Attachment 2 EPC valve
- 9: Junction block

**PPC valve piping table**


Circuit testing and operation	Port names on control valve side	Band color
L.H. travel (forward)	PA1	Brown/Yellow
L.H. travel (reverse)	PB1	Orange/Yellow
R.H. travel (forward)	PA2	Black/Yellow
R.H. travel (reverse)	PB2	Green/Yellow
Boom LOWER	PA3	Black
Boom RAISE	PB3	Yellow
Arm OUT	PA4	Orange
Arm IN	PB4	Green
Bucket DUMP	PA5	Red
Bucket CURL	PB5	Blue
Boom swing RIGHT	PA6	White/Blue
Boom swing LEFT	PB6	White/Red
Blade RAISE	PA7	Red/Yellow
Blade LOWER	PB7	Blue/Yellow
Turn LEFT	PA8	White
Turn RIGHT	PB8	Brown
Attachment 1 LEFT	PA9	White/White
Attachment 1 RIGHT	PB9	Red/Red
Attachment 2 LEFT	PA10	White
Attachment 2 RIGHT	PB10	Red

The travel PPC valve outlet pressure can be monitored on the machine monitor.

Select and display (14/14) “Predefined Mon” or monitoring code: 07101 “Travel PPC Pressure” in “SET AND OPERATE MACHINE MONITOR”, and perform testing.

**REMARK**

PPC valve outlet pressures other than the travel PPC valve outlet pressure can be monitored by using the sensor adapter D. For the method of using sensor adapter D, see the following procedure.



1. Release the remaining pressure in the hydraulic cylinder circuit. See “RELEASE REMAINING PRESSURE FROM HYDRAULIC SYSTEM”.
2. Open the floor. See “METHOD FOR OPENING AND CLOSING FLOOR”.
3. Disconnect the hoses of PPC circuit to be tested on PCC valve side or control valve side.

**METHOD FOR TESTING THE PARTS CAUSING HYDRAULIC DRIFT OF PPC VALVE**

Measure the hydraulic drift of the work equipment when the lock lever is in LOCK and FREE positions with the accumulator charged fully.

In case there is a difference of hydraulic drift between LOCK and FREE positions, the PPC valve is defective (internal defect).

**NOTICE**


**Operate the lock lever when the starting switch is turned to ON position.**

**REMARK**


If the accumulator pressure decreases, run the engine for approximately 10 seconds to accumulate the pressure.

**METHOD FOR OPENING FLOOR UNIT: CAB SPEC**


1. Remove the triangle cover fixing bolts (1) (M10, 3 pieces), and remove the triangle cover (2).



2. Remove the floor tilt fixing bolts (3) (M14, 2 pieces).



3. Pull the engine rear cover (4) backward to open it.  
Open the engine rear cover (4) fully and it is secured by rod (5).




4. Remove the floor tilt fixing bolts (6) (M14, 4 pieces).


**REMARK**

If the floor tilt fixing bolts (6) are hard to be removed, remove the bolts (A) of air cleaner mounting bracket to move the air cleaner downward.

5. Close the engine rear cover (4).



6. Open the inspection window (7).



## SERVICE MODE

### METHOD FOR OPERATING SERVICE MODE


To change the mode of the machine monitor to the service mode from the operator mode, perform the following operation.

This operation is always required when you use the service mode.

1. While displaying the standard screen, press the function switch F8 to select following switches (F8 + F1 → F2 → F3).

**REMARK**

Switch operations which use SERVICE MODE are accepted only while the standard screen is displayed.



2. When “Service Menu” screen is displayed, the service mode is selected. Select a service menu you use.


F1: Moves the selection down by one item

F2: Moves the selection up by one item

F3: Returns the screen to the “standard” screen (operator mode)

F4: Enters the selection

F8: Changes the screen to Code Input screen.



**REMARK**

- If you press the function switch and input the code on Input Code screen, the menu is selected directly.

F1: Decreases the number by 1

F2: Increases the number by 1


F3: Cancels the input and returns the screen to “Service Menu” screen

F4: Enters the input code

F6: Moves the input position leftward

F7: Moves the input position rightward

- Items with 2-digit codes are the menus displayed on “Service Menu” screen. The items on the right are the menus on the next hierarchy.



The following shows the items selectable with “Service Menu” (including some items which need special switching operations).

**The menu items which can be selected in “Service Menu”**

Code	Item	Reference page
01	Pre-defined Monitoring	METHOD FOR CHECKING PRE-DEFINED MONITORING INFORMATION
02	Self-define Monitoring	METHOD FOR CHECKING SELF-DEFINE MONITORING INFORMATION

## ABNORMALITY RECORD MENU

### METHOD FOR CONFIRMING ABNORMALITY RECORD (MECHANICAL SYSTEMS)

The machine monitor logs the failures that occurred in the past and is occurring currently. It classifies them into the mechanical system abnormality and electrical system abnormality.


Check the information about “Mechanic Sys Error Record” by performing the following procedures.

For the failure code list, see “FAILURE CODES TABLE” for troubleshooting.

1. Select “Abnormality Record” on “Service Menu” screen.

**REMARK**

For the selection method, see “Operating method of service mode” in “SERVICE MODE”.



B4P34179

2. On “Abnormality Record” screen, select “Mechanic Sys Error Record” with the function switch.


F1: Moves the selected item down by one item

F2: Moves the selected item up by one item

F3: Returns the display to the “Service Menu” screen

F4: Enters the selected item

F8: Moves to the code entry screen



B4P34180

3. Check the following information on “Mechanic Sys Error Record” screen.

a: Occurrence order from the latest one/ Total number of records

b: Failure code

c: Detail of failure

d: Number of occurrences (displayable range: 0 to 65535 times)


e: Service meter reading at the first occurrence

f: Service meter reading at the last occurrence

F1: Moves the selected item down by one item

F2: Moves the selected item up by one item

F3: Returns to “Abnormality Record” screen



B4P34181

- On "Default" screen, select "With/Without Attachment" with the function switch.

F1: Moves the selected item down by one item  
 F2: Moves the selected item up by one item  
 F3: Returns the display to the "Service Menu" screen  
 F4: Enters the selected item  
 F8: Moves to the code entry screen

**REMARK**

Attachment function does not appear on the screen except for machine equipped with proportional lever.



- On "With/Without Attachment" screen, select a setting with the function switch.

Without attachment: When attachment is not installed  
 With 1 attachment: When 1 attachment is installed  
 With 2 attachment: When 2 attachment is installed

F1: Moves the selected item down by one item  
 F2: Moves the selected item up by one item  
 F3: Cancels the selection and returns the screen to "Default" screen  
 F4: Enters the selected item and returns the screen to "Default" screen

**REMARK**

When an attachment is installed, if this setting is not configured correctly, the attachment setting in the operator mode cannot be performed. As a result, the attachment may not work normally or the hydraulic components may be damaged.



**METHOD FOR SETTING WITH DEFAULT SETTING MENU (AUTO IDLE STOP TIMER FIXING)**


Default menu is used to check or change default values of the machine monitor and machine.

Auto idle stop timer fixing function sets the selectable time on "Auto Idle Stop Timer Set" in the operator mode.

- Select "Default" from the "Service Menu" screen.


**REMARK**

For the selection method, see "Operating method of service mode" in "SERVICE MODE".



- On "Default" screen, select "Auto Idle Stop Time Fixing" with the function switch.

F1: Moves the selected item down by one item  
 F2: Moves the selected item up by one item  
 F3: Returns the display to the "Service Menu" screen  
 F4: Enters the selected item  
 F8: Moves to the code entry screen




## ADJUSTMENT MENU

### METHOD FOR ADJUSTING WITH ADJUSTING MENU (PUMP ABSORPTION TORQUE)

Adjustment menu is used to check the various settings of the machine or to adjust the value.

Function of Pump Absorption Torque adjusts the absorption torque of the main pump.


1. Select "Adjustment" on "Service Menu" screen.



2. On "Adjustment" screen, use the function switch to select "Pump Absorption Torque".

**REMARK**

Method of selecting is similar to "Service Menu" screen.




3. After the "Pump Absorption Torque" screen is displayed, select the desired value at the right side by using the function switches.

Set value: For the actual torque adjustment value, see table.

F1: Decreases the set value

F2: Increases the set value

F4: Checks and enters setting. Returns to "Adjustment" screen.




**REMARK**

The 3-digit number in the left column does not change since it is the code of this function.

**Relation between set value and torque adjustment value**

Code	Set value	Torque adjustment value
021	000	+14.7 Nm {+1.5 kgfm}
	001	+9.8 Nm {+1 kgfm}
	002	+4.9 Nm {+0.5 kgfm}
	003	0 Nm {0 kgfm}
	004	-4.9 Nm {-0.5 kgfm}
	005	-9.8 Nm {-1 kgfm}
	006	-14.7 Nm {-1.5 kgfm}


3. Display the phone number and IMSI.  
 F3: Returns the screen to “KOMTRAX Settings” screen



### METHOD FOR DISPLAYING SERVICE MESSAGE

Special messages for the technician sent from KOMTRAX base station (a distributor, etc.) can be checked with this function.

1. Select “Service Message” on “Service Menu” screen.



2. Displaying message


- Displaying message (read only)

If there is a message, its contents are displayed. If there is no message, “No message.” is displayed.

F1: Moves to the next page (when a message is more than 2 pages long)

F2: Moves to the previous page (when a message is more than 2 pages long)


F3: Returns the screen to “Service Menu” screen




#### REMARK

- The message is different from that sent to the operator in the operator mode.
- This message is only for the technician. Even if a message is received, the message monitor is not displayed in the same way as the display in the operator mode.
- Display of message (with message return function)

When the guidance icon of F4 is displayed, press F4 and display the message reply screen.




FAILURE CODE [DAF9KQ].....	40-141
FAILURE CODE [DAFGMC] .....	40-142
FAILURE CODE [DAFLKA] .....	40-143
FAILURE CODE [DAFLKB] .....	40-145
FAILURE CODE [DAFQKR] .....	40-147
FAILURE CODE [DB2QKR] .....	40-148
FAILURE CODE [DBH0MC] .....	40-152
FAILURE CODE [DBH2KK].....	40-153
FAILURE CODE [DBH5KP].....	40-155
FAILURE CODE [DBH5KP].....	40-157
FAILURE CODE [DBH9KQ] .....	40-159
FAILURE CODE [DBHLKA].....	40-161
FAILURE CODE [DBHLKB].....	40-163
FAILURE CODE [DBHQKR].....	40-165
FAILURE CODE [DDNRKA].....	40-170
FAILURE CODE [DDNRKY].....	40-172
FAILURE CODE [DDNS00].....	40-174
FAILURE CODE [DDWLKA].....	40-176
FAILURE CODE [DDWLKB].....	40-178
FAILURE CODE [DFB1KZ] .....	40-180
FAILURE CODE [DFB2KZ] .....	40-182
FAILURE CODE [DFB3L8].....	40-184
FAILURE CODE [DFB4L8].....	40-187
FAILURE CODE [DFB5KZ] .....	40-190
FAILURE CODE [DFB6KZ] .....	40-192
FAILURE CODE [DHS1MA].....	40-194
FAILURE CODE [DHS5MA].....	40-196
FAILURE CODE [DHX1MA].....	40-198
FAILURE CODE [DKULKA].....	40-200
FAILURE CODE [DKULKB].....	40-202
FAILURE CODE [DKULKY].....	40-204
FAILURE CODE [DV00KB] .....	40-206
FAILURE CODE [DV20KB] .....	40-207
FAILURE CODE [DV50KB] .....	40-209
FAILURE CODE [DV50KY] .....	40-211
FAILURE CODE [DW43KA] .....	40-213
FAILURE CODE [DW43KB] .....	40-215
FAILURE CODE [DW43KY] .....	40-217
FAILURE CODE [DW4CKY].....	40-218
FAILURE CODE [DXA8KA] .....	40-220
FAILURE CODE [DXA8KB] .....	40-222
FAILURE CODE [DXE7KA] .....	40-224
FAILURE CODE [DXE7KB] .....	40-226
FAILURE CODE [DXE7KY] .....	40-228
FAILURE CODE [DXE8KA] .....	40-230
FAILURE CODE [DXE8KB] .....	40-232
FAILURE CODE [DXE8KY] .....	40-234
FAILURE CODE [DXE9KA] .....	40-236
FAILURE CODE [DXE9KB] .....	40-238
FAILURE CODE [DXE9KY] .....	40-240
FAILURE CODE [DXEAKA] .....	40-242
FAILURE CODE [DXEAKB] .....	40-244
FAILURE CODE [DXEAKY] .....	40-246
TRUBLESHOOTING OF ELECTRICAL SYSTEM (E-MODE) .....	40-248
E-1 ENGINE DOES NOT START (ENGINE DOES NOT CRANK) .....	40-248
E-2 ENGINE DOES NOT START (FUEL FEED PUMP SYSTEM) .....	40-254
E-3 AUTOMATIC PREHEATING SYSTEM DOES NOT WORK .....	40-256





B4W18488

- Check of gauges and monitors for abnormality  
Check gauges and monitors in the operator's cab for abnormality. If any abnormality is found, replace it with a new one.  
Clean up the surfaces.
- Check of seat belt and mounting hardware  
Check the hook, the lock, and hook mounting part for damage. If any abnormality is found, repair it.

4. Hold outer element (6), rock it lightly up and down and to the right and left, and pull it out while turning it clockwise and counterclockwise.
5. After removing outer element (6), cover the air connector side at the bottom of air cleaner body (7) with a clean cloth or tape to prevent dirt or dust from entering.
6. Clean dust sticking inside air cleaner body (7) and on cover (5) by using a clean cloth or brush.
7. If any dust is attached to vacuator valve (8) installed to cover (5), remove it.
8. When outer element (6) has been cleaned 5 times or used for 1 year, replace it.
9. Blow dry compressed air (max. 0.2 MPa {max. 2.1 kgf/cm<sup>2</sup>}) from the inside of outer element (6) along the pleats.
10. Blow along the pleats from the outside, then blow again from the inside.



11. After cleaning, illuminate the inside of the element with an electric bulb to check.  
If any holes or thin places are found, replace the outer element with a new one.
12. Remove the cover of cloth or tape attached to the air connector side at the bottom of air cleaner body (7).




#### NOTICE

- Do not use the outer element with damaged pleats or a damaged gasket or seal.
  - If the outer element and O-ring are cleaned and used again after they are used for more than 1 year, it will cause problems. Do not use them again.
13. Check the seal of cleaned or new outer element (6) for adhesion of dusts and oil.  
If there is adhesion of dusts and oil, wipe them off.

#### NOTICE

- Be sure to install the air cleaner element facing in the correct direction. Install so that the bottom of the air cleaner element (a) (face where no hole is drilled) comes to cover (5) end.  
If it is installed in wrong direction, it may cause breakage of the air cleaner element or serious damage to the engine.
- When inserting the element into the body, if the rubber at the tip is swollen or the outer element is not pushed in straight, and cover (5) is installed by force with hook (4), there is a danger that hook (4) and air cleaner body may be damaged, so be careful when installing.



14. Push outer element (6) straight into air cleaner body (7) with your hand.


- 11) Close dirt cover (6).
6. Set rod (4) to FREE position (F), and close cooling cover (3).
7. Close engine rear cover (1).

## CHECK HYDRAULIC OIL STRAINER


**⚠ Immediately after the engine is stopped, its parts and oil are still very hot, and may cause burn injury. Accordingly, wait until all parts have cooled down before starting the work.**

**⚠ When removing the oil filler cap, the oil may spout out. Turn it slowly to release the internal pressure, then remove it.**


1. Open dirt cover (1).  
Open dirt cover (1) fully and it will be secured by cover support lever (2).



2. Loosen bolt (3) of the hydraulic tank, move plate (4) on oil filler port (F), turn the cap of oil filler port (F) slowly to remove it, and release the internal pressure.





3. Loosen bolts (5) at the bottom of hydraulic tank, and remove undercover (6).



3. Connect the adapter for troubleshooting to connector CP01 (3) and connector CP02 (4).


**REMARK**

Pull up lever (5) of connector CP01 (3) and connector CP02 (4) in the direction of the arrow while pressing hook (b).




**KOMTRAX terminal**

1. Remove bolts (1), and remove cover (2).  
(For the canopy spec)




(For the operator's cab spec)



Connector No.	Connector type	Number of pins	Location	Three-dimensional drawing address
F21	M	2	Cab revolving lamp (cab) (if equipped)	Q-9, AU-9
F22	M	2	Intermediate connector (cab)	P-9, AS-9
F22A	DT	2	Cab travel lamp (cab)	AD-6, BH-6
F22B	DT	2	Additional working lamp/Cab additional lamp (cab) (if equipped)	Z-8, BD-8
F23	M	3	Intermediate connector (cab)	O-9, AT-9
F24	M	3	Intermediate connector (cab)	Q-9, AU-9
F25	DT-A	8	Intermediate connector	N-1, AR-1
F26	DT-A	12	ATT switch lever (if equipped)	M-6, AQ-6
F27	DT	4	Wiper motor and switch (cab)	Z-1, BD-1
F28	YAZAKI	2	Buzzer	M-6, AQ-6
F29	DT-T	12	Attachment switch lever	AV-5
F31	-	2	Speaker (left) (cab)	AD-4, BH-4
F32	-	2	Speaker (right) (cab)	AD-3, BH-3
F37	DT	12	Service connector	Q-1, AU-1
F38	DT	2	Travel speed increase switch	M-5, AQ-5
F50	YAZAKI	2	Buzzer	AV-5
F51	DT	2	Quick coupler valve	AR-1
F52	DT	2	Revolving lamp	AU-9
F53	YAZAKI	2	Optional power supply	AR-9
FB1	Terminal	15	Fuse box	Q-1, AU-1
HI PRESS PUMP	-	2	SUPPLY PUMP	BK-2
INJECTOR#1	-	2	Injector #1	BK-8
INJECTOR #2	-	2	Injector #2	BL-8
INJECTOR #3	-	2	Injector #3	BM-8
INJECTOR #4	-	2	Injector #4	BN-7
INTAKE THROTTLE	-	6	Intake throttle	BI-3
J01	J	20	Junction connector	R-2, AV-2
J02	J	20	Junction connector	R-2, AV-2
J03	J	20	Junction connector	R-2, AV-2
M01	Y 090 2	2	Horn	I-1, AL-1
M01	YAZAKI PA	9	Radio (if equipped)	AC-2, AL-1
M01A	-	3	Radio (if equipped)	AB-1, BF-1
M01B	M	3	AUX jack (if equipped)	AD-5, AD-5
M02	KES	2	Window washer motor (cab)	D-7, AH-7
M05	L	2	Fusible link	F-9, AJ-9
M06	SDD	3	Fuel level sensor	G-9, AK-9

9/11 (canopy specifications, quick coupler specifications)



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL


Part No.	Part name	Number of pins	ID marking	T-adapter kit						Non-kit part
				799-A65-4600	799-902-9300					
799-601-4620	Adapter for controller (ENG-T4)	4	799-601-4620	•						
799-601-4630	Adapter for controller (ENG-T4)	2	799-601-4630	•						
799-601-4640	Adapter for controller (ENG-T4)	2	799-601-4640	•						
799-601-4651	Adapter for controller (ENG-T4)	24	799-601-4651	•						
799-601-4660	Adapter for controller (ENG-T4)	3	799-601-4660	•						
799-902-9310	Adapter for control box	19	799-902-9310		•					
799-902-9320	Adapter for IMU	10	799-902-9320		•					
799-902-9330	Adapter for MS cylinder	6	799-902-9330		•					
799T-601-4611	KDPF differential pressure sensor short socket adapter	4	799T-601-4611	•						
799T-601-4670	KDPF outlet pressure sensor short socket adapter	4	799T-601-4670	•						
799T-601-4680	KDPF dummy temperature sensor	4	799T-601-4680	•						

Failure code	Failure (Displayed on screen)	Applicable component	Action level	History category	Remarks
#B1467	Actuator Drive Circuit 3 Short to Ground	ENG	L01	Electrical system	*1
#B1469	AD Converter Error 1	ENG	L04	Electrical system	*1
#B1470	AD Converter Error 2	ENG	L04	Electrical system	*1
#B1471	External Monitoring IC and CPU Error 1	ENG	L04	Electrical system	*1
#B1472	External Monitoring IC and CPU Error 2	ENG	L04	Electrical system	*1
#B1473	ROM Error	ENG	L04	Electrical system	*1
#B1474	Shutoff Path Error 1	ENG	L04	Electrical system	*1
#B1475	Shutoff Path Error 2	ENG	L04	Electrical system	*1
#B1476	Shutoff Path Error 3	ENG	L04	Electrical system	*1
#B1477	Shutoff Path Error 4	ENG	L04	Electrical system	*1
#B1478	Shutoff Path Error 5	ENG	L04	Electrical system	*1
#B1479	Shutoff Path Error 6	ENG	L04	Electrical system	*1
#B1480	Shutoff Path Error 7	ENG	L04	Electrical system	*1
#B1481	Shutoff Path Error 8	ENG	L04	Electrical system	*1
#B1482	Shutoff Path Error 9	ENG	L04	Electrical system	*1
#B1483	Shutoff Path Error 10	ENG	L04	Electrical system	*1
#B1484	Recognition Error of Engine Speed	ENG	L04	Electrical system	*1
#B148A	EGR Stuck Open Valve Error	ENG	L03	Electrical system	*1
#B1562	Charge Switch Open Circuit	ENG	L01	Electrical system	*1
#B1568	Charge Alarm	ENG	L03	Mechanical system	*1
#B1608	Excessive Voltage of Supply 1	ENG	L04	Electrical system	*1
#B1609	Sensor Supply Voltage Error 1	ENG	L01	Electrical system	*1
#B160E	EEPROM Memory Read Error	ENG	L03	Electrical system	*1

**FAILURE CODE [AS00R4]**

Action level	Failure code	Failure	Inducement 2 (NOx Device Abnormality) (Engine controller system)
L04	AS00R4		
Detail of failure	<ul style="list-style-type: none"> <li>• A certain time has passed since [AS00R3] occurs.</li> <li>• An abnormality of NOx devices has occurred again within a certain time since abnormality repair of NOx device.</li> </ul>		
Action of controller	<ul style="list-style-type: none"> <li>• Displays the information related to this failure code on the monitor screen.</li> <li>• Derate engine power for operation largely.</li> </ul>		
Phenomenon on machine	<ul style="list-style-type: none"> <li>• Engine output is lowered, work equipment speed and travel speed are lowered.</li> </ul>		
Related information	<ul style="list-style-type: none"> <li>• From the machine monitor, it is possible to perform a "Temporary restoration from inducement" to cancel engine deration temporarily.</li> <li>• This failure code is detected during engine operation.</li> <li>• If this failure code remains displayed after NOx devices are repaired and the engine controller is shut down, run the engine for 1 minute to clear the failure code.</li> <li>• After this failure code is cleared, engine power deration continues until the starting switch is turned to OFF position.</li> </ul>		
No.	Cause	Procedure, measuring location, criteria and remarks	
1	NOx devices has an abnormality (EGR system)	Since the failure code of NOx device abnormality is displayed, perform troubleshooting for that failure code.	
2	Abnormal engine system	If any other failure codes than NOx device abnormality are displayed, perform troubleshooting for the displayed failure code.	

Circuit diagram related to CAN2 communication



**FAILURE CODE [DAFQKR]**

Action level	Failure code	Failure	CAN 2 Defective Communication (Monitor) (KOMTRAX system)
-	DAFQKR		
Detail of failure	KOMTRAX terminal does not recognize machine monitor through CAN communication 2 line.		
Action of controller			
Phenomenon on machine	System may not operate normally.		
Related information	<ul style="list-style-type: none"> <li>After completion of repair, check if the failure code is cleared by the following procedure. Procedure: Turn the starting switch to ON position.</li> <li>ACC signal of starting switch is the command to start CAN communication for each controller.</li> <li>Failure code is transmitted to and displayed on machine monitor by CAN communication. If CAN communication with machine monitor fails, failure code [DAFQKR] is not displayed on machine monitor. It can be observed only through KOMTRAX system.</li> <li>Since each controller and machine monitor are connected directly to the battery, they are supplied with power even after the starting switch is turned to OFF position.</li> <li>Since signal of active CAN communication line is pulse voltage, it cannot be measured by using multimeter.</li> </ul>		


No.	Cause	Procedure, measuring location, criteria and remarks
1	Defective power supply to machine monitor	Perform troubleshooting for "When starting switch is turned to ON position, machine monitor displays nothing" of E mode.
2	Defective CAN communication	Perform checks on cause 4 and subsequent causes in troubleshooting for failure code [DBHQKR].

## FAILURE CODE [DBH9KQ]

Action level	Failure code	Failure	Model Selection Signal Mismatch (Machine Controller) (Machine controller system)
L01	DBH9KQ		
Detail of failure	Model code signal for model which is not registered in controller is input.		
Action of controller	Controls machine by regarding it as default model (PC55MR standard specification machine). Even if cause of failure disappears, machine does not become normal until the starting switch is turned to OFF position.		
Phenomenon on machine	No problem appears if machine is PC55MR standard specification machine.		
Related information	<ul style="list-style-type: none"> <li>Part number of machine controller assembly can be checked with monitoring function. (Code: 20294)</li> <li>Signal state (ON/OFF) of model selection signal can be checked with monitoring function. (Code: 02201)</li> <li>PC55MR-5</li> </ul> Model selection signal 1: ON Model selection signal 2: OFF <ul style="list-style-type: none"> <li>PC45MR-5</li> </ul> Model selection signal 1: OFF Model selection signal 2: ON <ul style="list-style-type: none"> <li>After completion of repair, check if the failure code is cleared by the following procedure. Procedure: Turn the starting switch to ON position.</li> </ul>		


No.	Cause	Procedure, measuring location, criteria and remarks		
1	Defective model selection connector (Internal open or short circuit) (PC55MR-5)	1. Turn starting switch to OFF position. 2. Disconnect connector S30, and connect T-adapter to female side.		
		Resistance	Between S30 (female) (A) and (C)	Max. 1 Ω
			Between S30 (female) (A) and (B)	Min. 1 MΩ
			Between S30 (female) (B) and (C)	Min. 1 MΩ
2	Defective model selection connector (Internal open or short circuit) (PC45MR-5)	1. Turn starting switch to OFF position. 2. Disconnect connector S30, and connect T-adapter to female side.		
		Resistance	Between S30 (female) (B) and (C)	Max. 1 Ω
			Between S30 (female) (A) and (B)	Min. 1 MΩ
			Between S30 (female) (A) and (C)	Min. 1 MΩ
3	Open circuit in wiring harness (Wire breakage or defective contact of connector) (PC55MR-5)	1. Turn starting switch to OFF position. 2. Disconnect connector CP01 and connect T-adapter to female side.		
		Resistance	Between CP01 (female) (63) and ground	Max. 1 Ω
4	Open circuit in wiring harness (Wire breakage or defective contact of connector) (PC45MR-5)	1. Turn starting switch to OFF position. 2. Disconnect connector CP01 and connect T-adapter to female side.		
		Resistance	Between CP01 (female) (57) and ground	Max. 1 Ω

Circuit diagram related to PPC lock switch




B4P34214

Circuit diagram related to service lever potentiometer 2



No.	Cause	Procedure, measuring location, criteria and remarks	
5	Defective PPC pressure sensor for swing parking brake release	<ol style="list-style-type: none"> <li>Turn the starting switch to OFF position.</li> <li>Insert the T-adaptor into connector P03.</li> <li>Turn the starting switch to ON position.</li> </ol>	
		<table border="1" data-bbox="529 407 1474 443"> <tr> <td data-bbox="529 407 683 443">Voltage</td> <td data-bbox="683 407 1321 443">Between P03 (2) and (1)</td> <td data-bbox="1321 407 1474 443">0.5 to 4.5 V</td> </tr> </table> <p><b>REMARK</b> If power supply voltage is normal and sensor output voltage is abnormal, it is difficult to determine the failure between ground fault and hot short circuit in wiring harness. Check as follows.</p> <ol style="list-style-type: none"> <li>Turn the starting switch to OFF position.</li> <li>Replace connector P03 with connector of another PPC pressure sensor.</li> <li>Turn the starting switch to ON position and display the Electrical Sys Abnormality Record screen of machine monitor.</li> <li>If E mark is not displayed again in this failure code column, swing parking brake release PPC pressure sensor is defective.</li> </ol> <p><b>REMARK</b> After the troubleshooting, always restore the connector.</p>	Voltage
Voltage	Between P03 (2) and (1)	0.5 to 4.5 V	
6	Defective machine controller	If no failure is found by preceding checks, work equipment controller is defective. (Since this is an internal defect, troubleshooting cannot be performed.)	

**Circuit diagram related to swing PPC pressure sensor**




## FAILURE CODE [DV20KB]

Action level	Failure code	Failure	Travel Alarm Short Circuit (Machine controller system)
L01	DV20KB		
Detail of failure	Abnormal current flows when driving the travel alarm circuit.		
Action of controller	<ul style="list-style-type: none"> <li>Stops driving the travel alarm circuit.</li> <li>Even if cause of failure disappears, machine does not become normal until starting switch is set to OFF position.</li> </ul>		
Phenomenon on machine	Travel alarm does not sound.		
Related information	As T-adapter for machine controller connector is "socket-type box", operating voltage cannot be measured at machine controller connector.		


No.	Cause	Procedure, measuring location, criteria and remarks			
1	Defective travel alarm (Internal defect)	1. Turn the starting switch to OFF position. 2. Disconnect connector M08, and connect T-adapter to female side. 3. Turn the starting switch to ON position. 4. Perform troubleshooting by control of travel lever. <b>⚠ When driving machine, do not measure under the machine.</b> <b>REMARK</b> <ul style="list-style-type: none"> <li>When travel lever is set to the travel position, voltage is applied usually to the travel alarm connector before machine moves off.</li> <li>If the following voltage is normal but travel alarm does not sound, travel alarm is defective.</li> </ul>			
		Voltage	Between M08 (female) (1) and (2)	Travel lever: Neutral	Max. 1 V
				Travel lever: Operated	10 to 15 V
2	Ground fault in wiring harness (Contact with ground circuit)	1. Turn the starting switch to OFF position. 2. Disconnect connectors CP02 and M08, and connect T-adapter to either female side.			
		Resistance	Between CP02 (female) (86) and ground, or M08 (female) (1) and ground	Min. 1 MΩ	
3	Defective machine controller	1. Turn the starting switch to OFF position. 2. Disconnect connector M08, and connect T-adapter to female side. 3. Turn the starting switch to ON position. 4. Perform troubleshooting by control of travel lever. <b>⚠ When driving machine, do not measure under the machine.</b>			
		Voltage	Between M08 (female) (1) and (2)	Travel lever: Neutral	Max. 1 V
				Travel lever: Operated	10 to 15 V

Circuit diagram related to PPC lock switch




B4P34214

### Circuit diagram related to ATT flow rate adjustment EPC




**Circuit diagram related to ATT flow rate adjustment EPC**




G0117449

CIRCUIT DIAGRAM (ELECTRIC FUEL FEED PUMP SWITCH)



B4P34258

Circuit diagram related to fuel level sensor




## E-21 SERVICE METER IS NOT DISPLAYED, WHILE STARTING SWITCH IS IN OFF POSITION

Failure	Service meter is not displayed while starting switch is in OFF position.	
Related information	<ul style="list-style-type: none"> <li>The following switch operation with the starting switch set to OFF position displays a service meter in the middle of the screen. Operation of switches: [F2]+[F3] (pressed simultaneously)</li> </ul>	
No.	Cause	Procedure, measuring location, criteria and remarks
1	Defective backup power supply system	<p>When starting switch is turned to ON position and machine monitor displays nothing, backup power supply system may be defective and perform the following troubleshooting:</p> <ul style="list-style-type: none"> <li>E-mode "WHEN STARTING SWITCH IS TURNED TO ON POSITION, MACHINE MONITOR DISPLAYS NOTHING"</li> </ul>
2	Defective machine monitor	<p>If failure code still displays after above checks on Cause 1, machine monitor may be defective. (In case of an internal defect, troubleshooting is impossible as an assembly. Replace whole assembly.)</p>


No.	Cause	Procedure, measuring location, criteria and remarks		
7	Ground fault in wiring harness (Contact with ground circuit)	If fuse is not blown out, this check is not required. 1. Turn the starting switch to OFF position. 2. Remove fuse FB1-5. 3. Disconnect connectors F26, R03, and M01, and connect T-adaptor to each female side.		
		Resistance	Between ground and F26 (female) (6) or R03 (female) (3)	Min. 1 MΩ
			Between ground and F26 (female) (7) or R03 (female) (1)	Min. 1 MΩ
			Between ground and R03 (female) (5) or M01 (female) (1)	Min. 1 MΩ
8	Defective horn (internal defect)	If no failure is found by above checks, horn may be defective.		

**Circuit diagram related to horn (for proportional lever spec)**



B4P34263

Circuit diagram related to working lamp, travel lamp, and additional lamp



## H-2 ALL WORK EQUIPMENTS OR TRAVEL DOES NOT OPERATE

Failure	All work equipments or travel does not operate
Related information	<ul style="list-style-type: none"> <li>• Set working mode to power mode (P), and perform all troubleshooting with power mode (P).</li> <li>• Check that the oil level in hydraulic tank is correct.</li> <li>• Perform troubleshooting with the hydraulic oil temperature at 45 to 55 °C.</li> <li>• Check that swing and blade operations are normal.</li> </ul>

No.	Cause	Procedure, measuring location, criteria and remarks	
1	Improper adjustment or malfunction of main relief valve	When pressure cannot be adjusted to normal level, main relief valve may malfunction or may have internal defect. Check it.	
		Be ready with engine stopped, then perform troubleshooting with engine at high idle.	
		Main relief pressure	<ul style="list-style-type: none"> <li>• Arm IN relief</li> <li>• Travel hydraulic relief</li> </ul>
2	Defective piston pump	Disconnect the discharge hose of main pump and crank the engine with starting motor, and check if the oil flows out from the discharge port. <b>REMARK</b> No-Injection cranking is required. For details of procedure, see TESTING AND ADJUSTING, "TEST COMPRESSION PRESSURE".	

## H-13 ALL WORK EQUIPMENTS AND BLADE SPEED OR POWER IS LOW

Failure	All work equipments and blade speed or power is low
Related information	<ul style="list-style-type: none"> <li>Set working mode to power mode (P), and perform all troubleshooting with power mode (P).</li> <li>Check that the oil level in hydraulic tank is correct.</li> <li>Perform troubleshooting with the hydraulic oil temperature at 45 to 55 °C.</li> <li>Check that travel and swing operations are normal.</li> <li>It is not abnormal that the phenomenon disappears by increasing the engine speed.</li> </ul>

No.	Cause	Procedure, measuring location, criteria and remarks		
1	Malfunction of centralized safety valve	Be ready with engine stopped, then perform troubleshooting with engine at high idle.		
		Main pump relief pressure	<ul style="list-style-type: none"> <li>Work equipment control lever: Both directions</li> <li>Boom swing control pedal: Right swing</li> </ul>	26.5 ± 0.98 MPa {270 ± 10 kgf/cm <sup>2</sup> }
		Swing and blade pump relief pressure	Blade control lever: LOWER	21.6 (+0.98/-0.49) MPa {220 (+10/-5) kgf/cm <sup>2</sup> }
		If the oil pressure in all hydraulic circuits is low in all the preceding checks, centralized safety valve may be defective. Check it. <b>REMARK</b> Centralized safety valve works on both sides of head and bottom for boom, arm, and bucket, and it works on head side for swing, and bottom side for blade.		

### H-23 HYDRAULIC DRIFT OF BOOM IS LARGE

Failure	Hydraulic drift of boom is large.		
Related information	<ul style="list-style-type: none"> <li>Set working mode to power mode (P), and perform all troubleshooting with power mode (P).</li> <li>Perform troubleshooting with the hydraulic oil temperature at 45 to 55 °C.</li> </ul>		
No.	Cause	Procedure, measuring location, criteria and remarks	
1	Defective boom cylinder	Be ready with engine stopped, then perform troubleshooting with engine at high idle.	
		Leakage of boom cylinder	Boom RAISE relief  10 cc/min
2	Malfunction of boom control valve (lock valve)	<ul style="list-style-type: none"> <li>Check that pilot piston and puppet are seated on body in position (they should not be stuck halfway).</li> <li>Check if pilot piston and puppet are stuck or seized with lock valve body (they should move smoothly).</li> <li>Remove pilot piston and puppet from valve body, and check them for flaw and sticking of dirt.</li> <li>Check puppet spring for fatigue and deformation.</li> <li>When restoring, be careful about the dirt to enter.</li> </ul>	
3	Malfunction of boom control valve (spool)	Release the remaining pressure from hydraulic tank and pipes, and then perform troubleshooting with engine stopped.	
		<ul style="list-style-type: none"> <li>Check if boom spool is stuck or seized with control valve body. (Spool should move smoothly.)</li> <li>Remove boom spool from valve body, and check it for flaw and sticking of dirt.</li> </ul> When restoring, be careful about the dirt to enter.	
4	Malfunction of centralized safety valve	Be ready with engine stopped, then perform troubleshooting with engine at high idle.	
		Boom relief pressure	<ul style="list-style-type: none"> <li>Boom RAISE relief</li> <li>Boom LOWER relief</li> </ul> 26.5 ± 0.98 MPa {270 ± 10 kgf/cm <sup>2</sup> }
		If oil pressure does not become normal after adjustment, check safety valve for malfunction (fatigued spring), internal defect (defective valve seat or entry of dirt), etc.	

## H-32 TRAVEL SPEED IS LOW

Failure	Travel speed is slow.
Related information	<ul style="list-style-type: none"> <li>Set working mode to power mode (P), and perform all troubleshooting with power mode (P).</li> <li>Check that the oil level in hydraulic tank is correct.</li> <li>Perform troubleshooting with the hydraulic oil temperature at 45 to 55 °C.</li> <li>Check that machine has no travel deviation.</li> <li>Travel PPC pressure can be checked on the monitor as well. Code: 07101)</li> </ul>

No.	Cause	Procedure, measuring location, criteria and remarks	
1	Malfunction of R.H. travel PPC valve	Be ready with engine stopped, then perform troubleshooting with engine at high idle.	
		R.H. travel PPC valve outlet pressure	R.H. travel lever: NEUTRAL 0 MPa {0 kgf/cm <sup>2</sup> }
		R.H. travel lever: FORWARD/REVERSE	2.94(+0.49/-0.1) MPa {30(+5/-1) kgf/cm <sup>2</sup> }
	Difference between R.H. and L.H. of PPC valve outlet pressure	Travel lever: FORWARD/REVERSE	Within. 0.4 MPa {Within. 4 kgf/cm <sup>2</sup> }
2	Malfunction of L.H. travel PPC valve	Be ready with engine stopped, then perform troubleshooting with engine at high idle.	
		L.H. PPC valve outlet pressure	L.H. travel lever: NEUTRAL 0 MPa {0 kgf/cm <sup>2</sup> }
		L.H. travel lever: FORWARD/REVERSE	2.94(+0.49/-0.1) MPa {30(+5/-1) kgf/cm <sup>2</sup> }
	Difference between R.H. and L.H. of PPC valve outlet pressure	Travel lever: FORWARD/REVERSE	Within. 0.4 MPa {Within. 4 kgf/cm <sup>2</sup> }
3	Malfunction of merge-divider main spool	Release remaining pressure from hydraulic tank and piping, and then perform troubleshooting with engine stopped. <ul style="list-style-type: none"> <li>Check for stuck or seized main spool in merge-divider valve body (spool should move smoothly).</li> <li>Remove main spool from valve body and check it for defects and dirt.</li> </ul> When restoring, be careful about the dirt, etc. to enter.	
4	Malfunction of unload valve	Be ready with engine stopped, then perform troubleshooting with engine at high idle.	
		Unload pressure	All control levers in NEUTRAL 2.9±0.49 MPa {30±5 kgf/cm <sup>2</sup> }

## H-39 SWING ACCELERATION PERFORMANCE IS POOR OR SWING SPEED IS SLOW IN ONLY ONE DIRECTION

Failure	Swing acceleration performance is poor or swing speed is slow in only one direction.
Related information	<ul style="list-style-type: none"> <li>Set working mode to power mode (P), and perform all troubleshooting with power mode (P).</li> <li>Check that the oil level in hydraulic tank is correct.</li> <li>Perform troubleshooting with the hydraulic oil temperature at 45 to 55 °C.</li> <li>Swing PPC pressure can be checked with monitoring function. (Code: 09000)</li> <li>If blade speed is slow, perform troubleshooting for "SWING AND BLADE SPEED IS LOW OR POWER IS LOW" in H mode first.</li> </ul>

No.	Cause	Procedure, measuring location, criteria and remarks	
1	Malfunction of swing PPC valve	Be ready with engine stopped, then perform troubleshooting with engine at high idle.	
		Swing PPC valve outlet pressure	L.H. work equipment control lever: In NEUTRAL 0 MPa {0 kgf/cm <sup>2</sup> } L.H. work equipment control lever: In swing RIGHT/LEFT direction 2.94(+0.49/-0.1) MPa {30(+5/-1) kgf/cm <sup>2</sup> }
2	Malfunction of swing control valve (spool)	Swing PPC circuit pressure	L.H. work equipment control lever: Operate swing RIGHT/LEFT direction 2.94 (+0.49/-0.1) MPa {30 (+5/-1) kgf/cm <sup>2</sup> }
		If no failure is found by preceding checks, the spool of swing control valve may malfunction. Check it.	
3	Defective seat of swing motor (suction valve)	Replace the suction valves of R.H. and L.H. swing motor, and check whether failure symptom changes to make judgment. When taking out the valve, check it for sticking and flaw.	
4	Defective sealing of swing motor (check valve)	Replace the check valves of R.H. and L.H. swing motor, and check whether failure symptom changes to make judgment. When taking out the valve, check it for sticking and flaw.	
5	Malfunction of load check valve in the spool of control valve	Load check valve in the control valve may be defective. Check it.	

No.	Cause	Point to check, remarks	Remedy
13	A crack on the EGR cooler (Reference: coolant contained in exhaust)	Disconnect the inlet and outlet gas piping of EGR cooler to check if water containing coolant is draining. <b>REMARK</b> Moisture in exhaust gas may be condensed, but this is not a failure. Check if it is coolant or not.	After EGR cooler replacement, drain the water in the engine cylinder.
14	Defective injector	<ul style="list-style-type: none"> <li>Some cylinder is found to be cool when exhaust manifolds are touched by hand immediately after engine is started.</li> <li>Perform cylinder cutout mode operation to identify cylinder that does not change in speed (see "TESTING AND ADJUSTING", "HANDLING CYLINDER CUTOFF MODE OPERATION").</li> </ul>	Replace injector.
15	Defective engine controller	In case of an internal defect, troubleshooting is impossible as an assembly. Replace whole assembly.	Engine controller replacement
16	Defective contact of valve and valve seat	<ul style="list-style-type: none"> <li>Measure compression pressure (See Standard value table). (Reference: See Testing and adjusting, "Testing compression pressure".)</li> <li>Check valve clearance (Reference: See Testing and adjusting, "Testing and adjusting valve clearance").</li> </ul>	Valve or valve seat repair or replacement
17	Defective piston ring	<ul style="list-style-type: none"> <li>Check exhaust gas color.(Reference: See "TESTING AND ADJUSTING", "Checking exhaust gas color").</li> <li>Measure compression pressure (See standard value table). (Reference: See "TESTING AND ADJUSTING", "Testing compression pressure".)</li> <li>Check piston ring and piston ring groove.</li> </ul>	Piston ring and piston replacement

## S-14 OIL PRESSURE DROPS

Failure	Oil pressure drops.
Related information	<ul style="list-style-type: none"> <li>If any failure code is displayed, perform troubleshooting for that code first.</li> <li>Check if machine is operated on slopes steeper than angle specified in Operation and Maintenance Manual.</li> </ul>

No.	Cause	Point to check, remarks	Remedy
1	Insufficient oil in oil pan	Oil level in oil pan is insufficient. Oil pressure monitor indicates low oil pressure on slopes.	Oil refilling
2	Defective oil pressure sensor or wiring harness	Check oil pressure sensor, wiring harness, and connectors	Oil pressure sensor, wiring harness, and connectors replacement
3	Fuel mixed in oil	<ul style="list-style-type: none"> <li>Perform oil analysis and check for mixing of oil</li> <li>Oil smells of diesel fuel.</li> </ul>	If fuel is mixed into oil, perform troubleshooting of "FUEL MIXES INTO ENGINE OIL" in S mode, and take corrective action.
4	Water mixed in oil	<ul style="list-style-type: none"> <li>Perform oil analysis and check for mixing of water</li> <li>Oil is milky.</li> </ul>	If water is mixed into oil, perform troubleshooting of "WATER MIXES INTO ENGINE OIL (MILKY)" in S mode, and take corrective action.
5	Clogged oil filter	<ul style="list-style-type: none"> <li>Check oil filter.</li> </ul> (Reference: Oil filter is used for more than specified period, oil is deteriorated badly, etc.) <ul style="list-style-type: none"> <li>Oil filter may be blocked by water.</li> </ul>	Oil filter replacement
6	Clogged oil strainer	Check oil strainer.	Oil strainer cleaning
7	Flattened or clogged hydraulic piping	Hydraulic piping is flattened or clogged.	Hydraulic piping replacement
8	Defective oil pump	<ul style="list-style-type: none"> <li>Check oil pump (for wear or breakage of gear)</li> <li>Oil pump is heavy in turning or has play.</li> </ul>	Oil pump replacement
9	Defective regulator valve	Check whether the valve spring is deformed and damaged	Regulator valve exchange
10	Defective oil pump relief valve	Valve and spring of oil pump relief valve are weakening and damaged.	Oil pump relief valve exchange
11	Cracking in oil pump suction piping	Check around oil pump suction piping (for cracking in piping).	Oil pump suction piping replacement
12	Defective seal between oil pump and oil pump suction piping	Check sealing portion.	Seal replacement
13	Leakage from EGR hydraulic piping	Check EGR hydraulic piping.	EGR hydraulic piping replacement
14	Wear of main journal bearing	<ul style="list-style-type: none"> <li>Check main journal bearing.</li> <li>Metal particles are contained in oil drained from oil pan.</li> </ul>	Bearing of main journal replacement

## ABBREVIATION LIST

- This list of abbreviations includes the abbreviations used in the text of the shop manual for parts, components, and functions whose meaning is not immediately clear. The spelling is given in full with an outline of the meaning.
- Abbreviations that are used in general society may not be included.
- Special abbreviations which appear infrequently are noted in the text.
- This list of abbreviations consists of two parts. The first part is a list of the abbreviations used in the text of the manual, and the second part is a list of the abbreviations used in the circuit diagrams.

### List of abbreviations used in the text

Abbreviation	Actual word spelled out	Purpose of use (major applicable machine (*1), or component/system)	Explanation
ABS	Antilock Brake System	Travel and brake (HD, HM)	This is a function that releases the brake when the tires skid (tires are not rotated). This function applies the brake again when the tires rotate.
AISS	Automatic Idling Setting System	Engine	This is a function that automatically sets the idle speed.
AJSS	Advanced Joystick Steering System	Steering (WA)	This is a function that performs the steering operations with a lever instead of using a steering wheel. This function performs gear shifting and changing forward and reverse direction.
ARAC	Automatic Retarder Accelerator Control	Travel and brake (HD, HM)	This is a function that automatically operates the retarder with a constant braking force when letting go of the accelerator pedal on the downhill.
ARSC	Automatic Retarder Speed Control	Travel and brake (HD, HM)	This is a function that automatically operates the retarder to ensure that the machine speed does not accelerate above the speed set by the operator when letting go of the accelerator pedal on the downhill.
ASR	Automatic Spin Regulator	Travel and brake (HD, HM)	This is a function that drives both wheels automatically using the optimum braking force when the tire on one side spins on the soft ground surfaces.
ATT	Attachment	Work equipment	A function or component that can be added to the standard specification.
BCV	Brake cooling oil control valve	BRAKE (HD)	This is a valve that bypasses a part of the brake cooling oil to reduce the load applied to the hydraulic pump when the retarder is not being used.
CAN	Controller Area Network	Communication and electronic control	This is one of communication standards that are used in the network on the machine.
CDR	Crankcase Depression Regulator	Engine	This is a regulator valve that is installed to KCCV ventilator. It is written as CDR valve and is not used independently.
CLSS	Closed-center Load Sensing System	Hydraulic system	This is a system that can actuate multiple actuators simultaneously regardless of the load (provides better combined operation than OLSS).

## SPECIAL TOOLS LIST

### How to read the tool list

- Part No.  
Tools with part number 79\*T-\*\*\*-\*\*\*\* are not supplied (to be locally manufactured).
- Necessity:
  - : Tools not substituted, must always be equipped.
  - : Very useful tools which can be substituted with commercially available tools.
- New/Redesign:
  - N: Tools with new part numbers, newly developed for this model.
  - R: Tools, with advanced part numbers, developed by improving existing tools for other models.
  - Blank: Tools already available for other models that can be used without any modification.
- Sketch:
  - : Tools marked with ○ in the sketch column have the sketches.
 Sketches are introduced in "SKETCHES OF SPECIAL TOOLS", and all sketches of "79\*T-\*\*\*-\*\*\*\*" are described.

#### Tools for removal and installation of supply pump assembly

Symbol	Part No.	Part name	Necessity	Q'ty	New/Redesign	Sketch	Remarks
A	Commercially available	Puller	■	1			Removal of gear

#### Tools for removal and installation of travel motor and final drive assembly


Symbol	Part No.	Part name	Necessity	Q'ty	New/Redesign	Sketch	Remarks
A	Commercially available	Block	●	2			Removal and installation of travel motor and final drive assembly
B	Commercially available	Lifting tool	●	1			


#### Tools for removal and installation of swing motor and swing machinery assembly

Symbol	Part No.	Part name	Necessity	Q'ty	New/Redesign	Sketch	Remarks
A	Commercially available	Forcing screw	■	2			Removal of swing motor and swing machinery assembly


**Cooling**

21. Fasten clamps (5) and (6) to install hose (7).


 Clamp (5):  
5.9±0.49 Nm {0.6±0.05 kgfm}

 Clamp (6):  
4.4±0.49 Nm {0.45±0.05 kgfm}

22. Install clamp (4).



23. Install fan guard (3) with bolts (2) (4 pieces).



**Counterweight assembly**

24. Install the counterweight assembly. For details, see “REMOVE AND INSTALL COUNTERWEIGHT ASSEMBLY”.


**Refilling radiator with coolant**

25. Refill the radiator with coolant to the specified level through the coolant filler port. Run the engine to circulate the coolant, and then check the coolant level again.


 Radiator:  
8.9 ℓ

**Air conditioner condenser assembly (machine with air conditioner only)**

13. Remove bolts (25) (2 pieces), and move receiver drier (26) aside so that it does not hinder the work.




14. Remove bolts (27) (4 pieces), and move air conditioner condenser assembly (29) so that it does not hinder the work.




**Hydraulic oil cooler assembly, fuel cooler assembly**


15. Remove bolts (27a) (2 pieces), and remove fuel cooler assembly (28).




16. Remove clamp (30), and disconnect hose (31).



17. Remove bolts (32) (3 pieces), and remove bracket (33).




4. Install exhaust pipe (82) with clamp (81).
5. Fix exhaust pipe (82) with nuts (80) (4 places) and U-bolt.




**Hydraulic hose**


6. Connect suction hose (79) with bolts (78) (4 pieces).




7. Connect hoses (76) and (77).



8. Connect hoses (74) and (75).



9. Connect hoses (73), (72) and (71).



# POWER TRAIN

## REMOVE AND INSTALL TRAVEL MOTOR AND FINAL DRIVE ASSEMBLY

Tools for removal and installation of travel motor and final drive assembly

Symbol	Part No.	Part name	Necessity	Q'ty	New/Redesign	Sketch	Remarks
A	Commercially available	Block	•	2			Removal and installation of travel motor and final drive assembly
B	Commercially available	Lifting tool	•	1			

- ⚠ Place the machine on a level ground, and lower the work equipment to the ground in a stable posture.
- ⚠ Set the lock lever to LOCK position.
- ⚠ Disconnect (-) terminal of the battery after 2 minutes or more of engine stop or after checking that the system operation lamp goes off.
- ⚠ Release the remaining pressure in the hydraulic system. For details, see TESTING AND ADJUSTING, "RELEASE REMAINING PRESSURE FROM HYDRAULIC SYSTEM".


### METHOD FOR REMOVING TRAVEL MOTOR AND FINAL DRIVE ASSEMBLY

Track shoe assembly


1. Separate the track shoe assembly. For details, see "SEPARATION AND CONNECTION OF TRACK ASSEMBLY".

Sprocket

2. Set block (A) under the track frame.
3. Remove bolts (1) (12 pieces), and remove sprocket (2).



4. Remove bolts (3) (3 pieces), and remove cover (4).





Swing machinery case:

Approximately 1.3 ℓ (TO10)


**Swing motor assembly**

16. Fit the O-ring, and install swing motor assembly (1).



Mounting bolt:


98 to 123 Nm {10 to 12.5 kgfm}



6. Remove floating seals (5) (2 pieces) from roller (6).


**REMARK**

- Clean, completely degrease and dry O-ring and the contacting surfaces of O-rings.
- Apply engine oil (EO30-CD) to the sliding surface of the floating seal, and take care that dust does not stick to it.



**Bushing**


7. Remove bushings (7) (2 pieces) from roller (6).



**METHOD FOR ASSEMBLING TRACK ROLLER ASSEMBLY**

**Bushing**

1. Press fit bushings (7) (2 pieces) to roller (6) by using push tool (A).




**Floating seal**


2. Install floating seals (5) (2 pieces) to roller (6) by using installer (B).

**REMARK**


- Clean, completely degrease and dry O-ring and the contacting surfaces of O-rings.
- Apply engine oil (EO30-CD) to the sliding surface of the floating seal, and take care that dust does not stick to it.



3. Install additional counterweight (29) with bolts (28) (2 pieces). (machine with additional counterweight only)

 Additional counterweight (29):


250 kg

 Bolt (28):

455 to 565 Nm {46.5 to 58 kgfm}



4. Sling bracket (27), and install it with bolts (26) (4 pieces).

 Bracket (27):


70 kg

 Bolt (26):


Liquid adhesive (LT-2)

 Bolt (26):


785 to 980 Nm {80 to 100 kgfm}




5. Install cover (25) with bolts (24) (2 pieces).




6. Install bracket (23) with bolts (22) (2 pieces).




7. Install bracket (21) with bolt (20). (machine with air conditioner only)




- 6. Remove clamps (6) (2 places).
- 7. Disconnect hose (7), and remove sub-tank (8).




- 8. Remove clamp (9).
- 9. Loosen clamp (10), and disconnect hose (11).




- 10. Remove bolts (12) (3 pieces), and remove chamber (13).




- 11. Remove bolts (14) (2 pieces), and remove cover (15).




- 12. Remove clamp (16), and disconnect hose (17).




5. Remove the bolts (7) (2 pieces), and remove the clamp (8).
6. Move the hose aside so that it does not hinder the work.



7. Remove the nuts (9) (2 pieces), and remove U-bolt (10).



8. Remove the accumulator (11).




## METHOD FOR REMOVING ACCUMULATOR ASSEMBLY (NORTH AMERICA SPECIFICATION, FOR MACHINE WITH QUICK COUPLER)

### Accumulator assembly

1. Release the remaining pressure from the hydraulic tank. See TESTING AND ADJUSTING, "METHOD FOR RELEASING REMAINING PRESSURE FROM HYDRAULIC TANK".
2. Remove the bolts (1) (3 pieces), and remove the cover (2).




- Disconnect the hoses (20), (21), (22), (23), (24), (25), (26), (27), (28), and (29) (10 pieces in total). (For the machines ready for installation of quick coupler)



**Work equipment assembly**

- Sling boom cylinder (13), and hold it.

 Boom cylinder (13):  
45 kg



- Remove plate (14), and remove head side pin (15).

**REMARK**


Lower the boom cylinder onto block, etc.


- Sling work equipment assembly (19), and hold it.

- Remove plate (17), and remove boom foot pin (18).




- Sling work equipment assembly (19), and remove it from the machine body.

 Work equipment assembly (19):  
510 kg



## CAB AND ITS ATTACHMENTS

### REMOVE AND INSTALL OPERATOR'S CAB ASSEMBLY (CAB SPEC)



- ⚠ Place the machine on a level ground, and lower the work equipment to the ground in a stable posture.
- ⚠ Set the lock lever to LOCK position.
- ⚠ Disconnect (-) terminal of the battery after 2 minutes or more of engine stop or after checking that the system operation lamp goes off.
- ⚠ If you drain the radiator coolant when it is still hot, you may be scalded. Accordingly, wait for the coolant temperature to drop before draining.
- ⚠ If refrigerant gas (R134a) gets in your eyes, you may lose your sight. If it touches your skin, you may suffer from frostbite. Accordingly, put on the protective eyeglasses, gloves and working clothes with long sleeves while you are collecting or filling the refrigerant.

#### NOTICE

- Never release the refrigerant to the atmosphere.
- Ask a qualified person for collecting, adding and filling operations of the refrigerant (air conditioner gas: R134a).
- Check the connector numbers and installed positions before disconnecting wiring and hoses, and write them down.
- When disconnecting the wiring and hoses, take extreme care not to damage or deform the wiring and hoses.

### METHOD FOR REMOVING OPERATOR'S CAB ASSEMBLY (CAB SPEC)

#### Collecting refrigerant

1. Collect the refrigerant (air conditioner gas: R134a) from the air conditioner circuit (machine with air conditioner).  
Quantity of refrigerant to be collected: 550±50 g

#### Draining

2. Loosen drain valve (1), and drain the coolant.




Radiator:


8.9 ℓ

#### REMARK


Check that the coolant is completely drained, and tighten drain plug (1).



14. Sling canopy (2), hold it, and install right and left mounting bolts (3) (8 pieces).
15. Close the floor. For details, see TESTING AND ADJUSTING, "METHOD FOR OPENING AND CLOSING FLOOR".




16. Install floor mat (1).



#### Refilling with oil (hydraulic tank)

17. Refill the hydraulic tank with Komatsu genuine oil to the specified level through the oil filler port. Start the engine to circulate the oil through the piping, and check the oil level again.


5. Hold the handles, remove the latches, and remove front window assembly (6).




## METHOD FOR INSTALLING FRONT WINDOW ASSEMBLY

### Front window assembly


1. Install front window assembly (6), hold the handles to lock the assembly with latches.



2. Install pull-up link (5) jumping up toward the ceiling and sash with bolts (4).



3. Install rollers (3) (right and left) on the lower side of the sash.




3. Install mounting bolts (3) (4 pieces).

**REMARK**


Move the operator's seat forward, and install mounting bolts (2 pieces) at the rear.

4. Pull lever (1) backward and move operator's seat (2) to the original position.




**REMARK**

For the cab specification, connect connector (3) on the back side of cover (1).



# POWER TRAIN


## MAINTENANCE STANDARD OF SWING CIRCLE



Unit: mm

No.	Item	Judgment criteria		Remedy
		Standard clearance	Allowable clearance	
1	Clearance in bearing	0.20 to 0.70	1.7	Replace

**MAINTENANCE STANDARD OF ROAD LINER**




Unit: mm

No.	Item	Judgment criteria		Remedy
		Standard dimension	Repair limit	
1	Height	35	17	Replace

Unit: mm

No.	Item	Judgment criteria					Remedy
1	Tightening torque of suction safety valve and suction valve plug	39.2 to 49.0 Nm {4.0 to 5.0 kgfm}					Retighten
2	Tightening torque of main relief valve	49.0 to 58.8 Nm {5.0 to 6.0 kgfm}					
3	Tightening torque of suction valve plug	6.9 to 9.8 Nm {0.7 to 1.0 kgfm}					
4	Suction valve spring	Standard dimension			Repair limit		Replace (Replace spring if damaged or deformed as well)
		Free height x outside diameter	Installed height	Load at installed height	Free height	Load at installed height	
		39.2 x 4.45	33.5	5.1 N {0.52 kf}	-	4.10 N {0.42 kf}	
5	Cooler by pass valve spring	27.2x13.2	21.0	78.8 N {8.04 kf}	-	63.0 N {6.43 kf}	
6	Spool return spring	29 x 17.5	28.5	22.6 N {2.3 kf}	-	18.1 N {1.84 kf}	
7	Spool return spring	27.2 x 16.6	26.7	30.2 N {3.08 kf}	-	24.2 N {2.46 kf}	
8	Spool return spring	29 x 17.5	28.5	21.6 N {2.2 kf}	-	17.3 N {1.76 kf}	

### MAINTENANCE STANDARD OF BOOM SWING PPC VALVE



Unit: mm

No.	Item	Judgment criteria					Remedy
		Width of boss		Width of hinge		Standard clearance	
		Standard dimension	Tolerance	Standard dimension	Tolerance		
17	Joint of revolving frame and boom swing bracket	276	0 -0.5	278.5	+0.5 0	2.5 to 3.5	Adjust the clearance to Max. 0.5 mm by using shims.
		U17: Insert the shim of 0.8 mm thickness (1) L17: Insert the shims of 0.8 mm thickness (2) and 0.5 mm thickness (2)					
18	Joint of boom swing bracket and boom	250	-0.5 -1.0	250	+0.5 0	0.5 to 1.5	Adjust the clearance to Max. 0.5 mm by using shims.
		L18: Insert the shim of 0.5 mm thickness (1) R18: -					
19	Joint of boom swing cylinder and swing bracket	60	0 -0.5	60	+1.5 +0.5	0.5 to 2.0	Adjust the clearance to Max. 1.0 mm by using shims.
		L19: - R19: Insert the shim of 1.0 mm thickness (1)					
20	Joint of revolving frame and boom swing cylinder	60	0 -0.5	64.5	+2.0 0	4.5 to 7.0	Adjust the clearance to Max. 0.5 mm by using shims.
		L20: - R20: Insert the shims of 1.0 mm thickness (4) and 0.5 mm thickness (1)					
21	Joint of boom swing bracket and boom cylinder	60	0 -0.5	60	+1.5 +0.5	0.5 to 2.0	Adjust the clearance to Max. 1.0 mm by using shims.
		L21: Insert the shim of 1.0 mm thickness (1) R21: -					
22	Joint of boom and boom cylinder	60	0 -0.5	60.5	+1.0 0	0.5 to 2.0	Adjust the clearance to Max. 0.5 mm by using shims.
		L22: - R22: Insert the shim of 1.0 mm thickness (1)					
23	Joint of boom and arm	163	-0.3 -1.0	163	+0.5 0	0.3 to 1.5	Adjust the clearance to Max. 0.5 mm by using shims.
		L23: - R23: Insert the shim of 0.5 mm thickness (1)					
24	Joint of boom and arm cylinder	55	0 -0.5	55.5	+1.0 0	0.5 to 2.0	Adjust the clearance to Max. 1.0 mm by using shims.
		L24: - R24: Insert the shim of 1.0 mm thickness (1)					
25	Joint of arm cylinder and arm	55	0 -0.5	55.5	+1.0 0	0.5 to 2.0	Adjust the clearance to Max. 1.0 mm by using shims.
		L25: Insert the shim of 1.0 mm thickness (2) R25: -					

Unit: mm

No.	Item	Judgment criteria	Remedy
4	Tightening torque of cylinder head	863±86.5 Nm {88±8.8 kgfm}	Retighten
5	Tightening torque of cylinder piston nut	1.08±0.11 kNm {110±11.0 kgfm} (Width across flats: 50 mm)	

## AIR CONDITIONER SYSTEM

### PRECAUTIONS FOR REFRIGERANT

- ⚠ If refrigerant gas (air conditioner gas: R134a) gets in your eyes, you may lose your sight. And if it touches your skin, you may suffer from frostbite. Put on protective eyeglasses, gloves and working clothes with long sleeves while collecting the refrigerant or filling the air conditioner circuit with the refrigerant.
- ⚠ When replacing the air conditioner unit, air conditioner compressor, condenser or receiver drier, etc., collect the refrigerant (air conditioner gas: R134a) from the air conditioner circuit before disconnecting the air conditioner hoses.


#### NOTICE

- Never release the refrigerant (air conditioner gas: R134a) to the atmosphere.
- Ask a qualified person for collecting, adding and filling operations of the refrigerant (air conditioner gas: R134a).

## RECEIVER DRIER

### STRUCTURE OF RECEIVER DRIER

#### General view and sectional view



A: Refrigerant inlet (from condenser)

B: Refrigerant outlet (to air conditioner unit)

### SPECIFICATIONS OF RECEIVER DRIER

Effective capacity: : 240 cc

Weight of desiccating agent: : 100 g

### FUNCTION OF RECEIVER DRIER

- The receiver drier temporarily stores the high pressure and high temperature liquid refrigerant from the condenser so that it can be supplied to the evaporator corresponding to the need of cooling.
- Even if bubbles are mixed in the refrigerant, depending on the heat radiation condition of the condenser, the refrigerant can be liquefied perfectly by sending out the accumulated refrigerant from the bottom to the evaporator.
- The built-in filter and desiccating agent remove foreign material in the circulation circuit and moisture contained in the refrigerant.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL