

Shop Manual

HYDRAULIC
EXCAVATOR

PC700LC-11
PC700LC-11E0

SERIAL NUMBERS 80001 and up

KOMATSU

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL



- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Before starting work, shut down the engine. When working on or around a rotating part, in particular, shut down the engine. When checking the machine without shutting down the engine (measuring oil pressure, revolving speed, temperature, etc.), take extreme care not to get caught in rotating parts or moving parts.
- When raising a heavy component (heavier than 20kg), use a hoist or crane. Before starting work, check that the slings (wire ropes, webbing slings, chains, and hooks) are free from damage. Always use slings which have ample capacity and install them to proper places. Operate the hoist or crane slowly to prevent the component from hitting any other part. Do not work with any part still raised by the hoist or crane.
- When removing a part which is under internal pressure or under reaction force of a spring, always leave 2 bolts in diagonal positions. Loosen those 2 bolts gradually and alternately to release the pressure, and then remove the part.
- When removing components, do not break or damage the electrical wiring. Damaged wiring may cause a fire.
- When removing piping, do not spill the fuel or oil. If any fuel or oil drips onto the floor, wipe it off immediately. Fuel or oil on the floor can cause you to slip and can even cause fires.




- Do not use gasoline to wash parts as a general rule. Do not use gasoline to clean electrical parts, in particular.
- Install the disassembled parts again to the original position. Replace the damaged parts or the parts that cannot be used again with new ones. Before you connect the hoses or wiring harnesses, make sure that they do not touch and give damage to other parts when you operate the machine.

REMARK


When you replace the removed or disassembled parts with new ones, refer the parts book to find out the part number.

- When installing high pressure hoses and tubes, make sure that they are not twisted. Damaged hoses and tubes are dangerous, so be extremely careful when installing hoses and tubes for high pressure circuits. In addition, check that high pressure hoses and tubes are correctly installed.
- When assembling or installing parts, always tighten them to the specified torques. When installing protective parts such as guards, or parts which vibrate violently or rotate at high speed, check again that they are installed correctly.
- Never insert your fingers or hand when aligning 2 holes. Be careful not to get your fingers caught in a hole.
- Check that the measuring tools are correctly installed when measuring hydraulic pressure.
- Take care when removing or installing the tracks of track-type machines. Since the track shoe may separate suddenly when you remove it, never let anyone stand at either end of the track shoe.
- If the engine is operated for a long time in a closed place with poor ventilation, it may cause gas poisoning. Open the windows and doors to ventilate the place well.



Connection


Hold the tightening adapter part, and push body (2) straight until sliding prevention ring (1) contacts contact surface (a) of the hexagonal part at the male end.




How to Disconnect and Connect Type 3 Push-Pull Type Coupler

Disconnection

1. Hold the tightening adapter part and push body (2) straight until sliding prevention ring (1) contacts contact surface (a) of the hexagonal part at the male end.




2. While keeping the condition of step 1, push cover (3) straight until it contacts contact surface (a) of the hexagonal portion on the male side.



3. While keeping the conditions of steps 1 and 2, pull out whole body (2) to disconnect it.

REMARK

Provide an container to receive a quantity of hydraulic oil which may flow out.



1 ℓ = 0.21997 U.K.Gal

	0	1	2	3	4	5	6	7	8	9
30	6.599	6.819	7.039	7.259	7.479	7.699	7.919	8.139	8.359	8.579
40	8.799	9.019	9.239	9.459	9.679	9.899	10.119	10.339	10.559	10.778
50	10.998	11.281	11.438	11.658	11.878	12.098	12.318	12.528	12.758	12.978
60	13.198	13.418	13.638	13.858	14.078	14.298	14.518	14.738	14.958	15.178
70	15.398	15.618	15.838	16.058	16.278	16.498	16.718	16.938	17.158	17.378
80	17.598	17.818	18.037	18.257	18.477	18.697	18.917	19.137	19.357	19.577
90	19.797	20.017	20.237	20.457	20.677	20.897	21.117	21.337	21.557	21.777

kgfm to lbft


1 kgfm = 7.233 lbft

	0	1	2	3	4	5	6	7	8	9
0	0	7.2	14.5	21.7	28.9	36.2	43.4	50.6	57.9	65.1
10	72.3	79.6	86.8	94.0	101.3	108.5	115.7	123.0	130.2	137.4
20	144.7	151.9	159.1	166.4	173.6	180.8	188.1	195.3	202.5	209.8
30	217.0	224.2	231.5	238.7	245.9	253.2	260.4	267.6	274.9	282.1
40	289.3	296.6	303.8	311.0	318.3	325.5	332.7	340.0	347.2	354.4
50	361.7	368.9	376.1	383.4	390.6	397.8	405.1	412.3	419.5	426.8
60	434.0	441.2	448.5	455.7	462.9	470.2	477.4	484.6	491.8	499.1
70	506.3	513.5	520.8	528.0	535.2	542.5	549.7	556.9	564.2	571.4
80	578.6	585.9	593.1	600.3	607.6	614.8	622.0	629.3	636.5	643.7
90	651.0	658.2	665.4	672.7	679.9	687.1	694.4	701.6	708.8	716.1
100	723.3	730.5	737.8	745.0	752.2	759.5	766.7	773.9	781.2	788.4
110	795.6	802.9	810.1	817.3	824.6	831.8	839.0	846.3	853.5	860.7
120	868.0	875.2	882.4	889.7	896.9	904.1	911.4	918.6	925.8	933.1
130	940.3	947.5	954.8	962.0	969.2	976.5	983.7	990.9	998.2	1005.4
140	1012.6	1019.9	1027.1	1034.3	1041.5	1048.8	1056.0	1063.2	1070.5	1077.7
150	1084.9	1092.2	1099.4	1106.6	1113.9	1121.1	1128.3	1135.6	1142.8	1150.0
160	1157.3	1164.5	1171.7	1179.0	1186.2	1193.4	1200.7	1207.9	1215.1	1222.4
170	1129.6	1236.8	1244.1	1251.3	1258.5	1265.8	1273.0	1280.1	1287.5	1294.7
180	1301.9	1309.2	1316.4	1323.6	1330.9	1338.1	1345.3	1352.6	1359.8	1367.0
190	1374.3	1381.5	1388.7	1396.0	1403.2	1410.4	1417.7	1424.9	1432.1	1439.4

kgf/cm² to lb/in²

1 kgf/cm² = 14.2233 lb/in²

	0	1	2	3	4	5	6	7	8	9
0	0	14.2	28.4	42.7	56.9	71.1	85.3	99.6	113.8	128.0
10	142.2	156.5	170.7	184.9	199.1	213.4	227.6	241.8	256.0	270.2
20	284.5	298.7	312.9	327.1	341.4	355.6	369.8	384.0	398.3	412.5



12: DEF tank heating valve
13: DEF filler port

14: DEF suction hose
15: DEF return hose


Battery Isolator

Function of Battery Isolator

(O): OFF position

(I): ON position

- Usually, battery isolator switch (1) is used instead of disconnecting the cable from the negative terminal of the battery in the following cases.
 - When storing the machine for a long period (1 month or longer)
 - When servicing or repairing the electrical system
 - When performing electric welding
 - When handling the battery
 - When replacing the fuse, etc.
- When battery isolator switch (1) is turned to OFF position (the contact is opened), all the continuous power supplies for the components, including the starting switch B terminal and controllers, are all cut out, and the condition is the same as the condition when the battery is not connected. Accordingly, all of the electrical system of the machine does not operate.



NOTICE

- **Do not turn battery isolator switch (1) to OFF position while the system operating lamp is lit.**
If battery isolator switch (1) is turned to OFF position while the system operating lamp is lit, the data in the controller may be lost and the controller may be damaged seriously.
- **Do not turn battery isolator switch (1) to OFF position while the engine is running or immediately after the engine is stopped.**
If battery isolator switch (1) is turned to OFF position while the alternator is generating power, the generated current has nowhere to go, leading to overvoltage in the electrical system of the machine, which may cause serious damage to the electrical system, including the electric devices and controllers.

REMARK


- The system operating lamp lights up while the controller is in operation or DEF pump is in operation. It lights up when KOMTRAX is performing communication, even if the starting switch is set to OFF position.
- If battery isolator switch (1) has been at OFF position for a long period, the machine monitor and the clock of the radio may be initialized. In this case, re-setting is required.

Nozzle Ring (Open) State

1. During high speed operation (rotation), exhaust gas inlet passage (P) is wide (L2).
2. As the engine speed increases and the turbine inlet pressure (exhaust gas pressure) increases exhaust gas inlet passage (P) is widened (L2) so that the exhaust gas acts on turbine impeller (11) efficiently.


REMARK

- Nozzle ring (7), vanes (6), and push rod (8) are made in one unit, and it slides only and does not rotate.
- Hydraulic actuator (3) is equipped with VGT position sensor. VGT position sensor is calibrated together with the variable mechanism of VGT and the result is written in the memory in VGT position sensor. Accordingly, if any of hydraulic actuator (3), VGT position sensor, and VGT unit fails, whole VGT must be replaced.



Operation of Hydraulic Actuator

1. Hydraulic actuator (1) is operated by the oil pressure controlled by EPC valve (3) installed to EGR valve (2).
2. The hydraulic pressure supplied by engine boost oil pump (4) is used for this purpose.
3. The position of hydraulic actuator (1) is fed back to engine controller by the signals from VGT position sensor (5).



EGR System

EGR

Abbreviation for Exhaust Gas Recirculation

Layout Drawing of EGR System


REMARK

The shape is subject to machine models.

Cooling Fan Motor

Structure of Cooling Fan Motor

General View



A4P12642










P: From fan pump

TC: To hydraulic tank

T: To oil cooler


1: Cooling fan reverse solenoid valve

2: Cooling fan speed sensor

Symbol	Item to be displayed	Range and method for display			Remarks
 9JC01178	One-touch power maximizing	One-touch power maximizing switch	Monitor display		Display of the state of one-touch power maximizing function
		ON	Lit (Goes out approximately 8.5 seconds after, if held down)		
		OFF	Not lit		
 9JC01179	Swing lock	Swing lock switch	Swing parking brake cancel switch	Monitor display	Displays the operation state of swing lock.
		OFF	OFF	Not lit	
		ON	OFF	Lit	
		OFF	ON	Flashing	
ON	ON	Flashing			
 9JC01180	Wiper	INT: Intermittent operation ON: Continuous operation Goes out: Stopped			Displays the operation state of front window wiper.
 9JC01175	Air conditioner	Lit: ON Not lit: OFF			Indicates the operation state of air conditioner and blower.
 9JC01181	Seat belt is not fastened.	Lit: Not fastened Not lit: Fastened			Displays whether seat belt is fastened.
 9JC01182	Engine stop	Lit: When engine is stopped Not lit: When engine is running			Displays the operation state of engine.
 9JC01183	Aftertreatment devices regeneration	Lit: When the aftertreatment devices regeneration is in progress Not lit: Aftertreatment devices regeneration has been completed.			Indicates the regeneration state of aftertreatment devices.
 9JC01184	Aftertreatment devices regeneration disable	Lit: When the aftertreatment devices regeneration is disabled Not lit: Aftertreatment devices regeneration disable is canceled			<ul style="list-style-type: none"> Indicates the regeneration state of aftertreatment devices. The KDPF soot accumulation caution lamp lights up when the manual stationary regeneration is necessary.
 9JC01185	Message (Unread)	Lit: There is an unread message Not lit: No message			Indicates the state of messages.

3: Knob


Function of Fuel Control Dial



When knob (3) is turned, the shaft of potentiometer (1) rotates. The resistance of variable resistor in the potentiometer (1) varies according to this rotation, and throttle signals are sent to the controller.


REMARK

The hatched area in the following graph is the abnormality detection area. The engine speed is set to low idle when the throttle voltage is in this area.



General View

No. 2 main pump



P1: Front pump pressure port

P2: Rear pump pressure port

PSV1: Servo valve source pressure port

PSV1A: Servo piston output port


PSV1B: Servo valve output port

PSV2: Servo valve source pressure port

PSV2A: Servo piston output port

PSV2B: Servo valve output port

Sectional Views (E-E, F-F, G-G, H-H)



A4P17720

- | | |
|----------------------------|------------------------|
| 1: Check valve | 10: Spool (boom Hi) |
| 2: Check valve spring | 11: Suction valve |
| 3: Spool (left TRAVEL) | 12: Suction valve |
| 4: Spool (straight-travel) | 13: Suction valve |
| 5: Spool (swing priority) | 14: Check valve spring |
| 6: Spool (swing) | 15: Check valve spring |
| 7: Suction valve | 16: Return spring |
| 8: Spool (boom Lo) | 17: Return spring |
| 9: Check valve | 18: Return spring |


PPC Lock System

PPC

Abbreviation for Proportional Pressure Control

System Diagram of PPC Lock

PPC: Abbreviation for Proportional Pressure Control



G0076364

Input and output signals

- a: PPC lock signal
 - b: PPC lock signal
 - c: Lock lever automatic lock cancel switch signal
 - d: Lock lever automatic lock relay drive signal
 - e: PPC lock solenoid valve drive signal
 - f: Oil pressure sensor signal
 - g: Oil pressure switch signal
- 1: Battery isolator switch
 - 2: Battery
 - 3: Battery relay
 - 4: Circuit breaker
 - 5: Fuse box
 - 6: Starting switch
 - 7: Lock lever
 - 8: PPC lock switch
 - 9: Pump controller
 - 10: Work equipment automatic lock relay
 - 11: PPC lock solenoid valve
 - 12: Control valve
 - 13: Main pump
 - 14: Control pump
 - 15: Lock lever automatic lock cancel switch


Function of PPC Lock System

- PPC lock switch is interlocked with the lock lever. When the lock lever is set to LOCK position, PPC lock switch is turned "OFF".
- When PPC lock switch is turned OFF, the current flowing into PPC lock solenoid valve is cut out, and the work equipment and machine body do not move even if any control lever or pedal is operated.

Operation of Check Valve, Shuttle Valve, and 2-Stage Swing Relief Valve of Swing Motor


When Swing System Starts

1. When swing RIGHT operation is performed, the pressurized oil from the pump flows through control valve into port (MA).
2. The pressure in port (MA) increases, starting torque is generated, and the motor starts rotating.
3. The oil from the motor outlet returns to the tank through port (MB) and control valve.




When Swing Operation Stops

1. When the swing control lever is returned to NEUTRAL position, the supply of the pressurized oil from the pump to port (MA) stops.
2. The return circuit of the oil from the motor output to the tank is closed by control valve. The pressure in port (MB) increases.
3. Rotational resistance occurs in the motor, and the brake starts working.
4. The pressure in port (MA) exceeding that in port (MA) pushes (4) of the shuttle valve (A).
5. The pressure in chamber (C) becomes the same with port (MB) and increases to the set pressure of relief valve (1).
6. High braking torque acts on the motor, and the motor stops.
7. The relieved oil and the oil from back pressure valve are supplied to port (MA) through check valve (3) while relief valve (1) is in operation.
8. Cavitation in port (MA) is prevented.



Sectional View



- 1: Plate
- 2: Case
- 3: Piston

- 4: Seal
- 5: Spool
- 6: Damper

Operating Force of Control Lever and Pedal

Machine model			PC700LC-11	
Engine			SAA6D140E-7	
Item	Measurement condition	Unit	Standard value for new machine	Repair limit
Boom control lever	<ul style="list-style-type: none"> • Hydraulic oil temperature 45 to 55 °C • Fuel control dial: MAX (High idle) position • Control lever: At center of grip • Pedal: At tip of pedal • Read the maximum value when the lever is operated to the stroke end 	N {kg}	15.7 to 3.9 {1.6 to 0.4 }	24.5 or less {2.5 or less}
Arm control lever			15.7 to 3.9 {1.6 to 0.4 }	24.5 or less {2.5 or less}
Bucket control lever			12.7 to 2.9 {1.3 to 0.3 }	21.6 or less {2.2 or less}
Swing control lever			12.7 to 2.9 {1.3 to 0.3 }	21.6 or less {2.2 or less}
Travel control lever			24.5 to 5.9 {2.5 to 0.6 }	39.2 or less {4.0 or less}
Travel control pedal			74.5 to 18.6 {7.6 to 1.9 }	107.6 or less {11 or less}

Oil leakage

Machine model			PC700LC-11E0	
Engine			SAA6D140E-7	
Item	Measurement condition	Unit	Standard value for new machine	Repair limit
Oil leakage from cylinder	<ul style="list-style-type: none"> Hydraulic oil temperature 45 to 55 °C Fuel control dial: MAX (High idle) position Measure the leakage for 1 minute while relieving the travel motor or cylinder to be measured 	ml/min	5 or less	20 or less
Center swivel joint			10 or less	100 or less

Cooling Fan

Machine model			PC700LC-11E0	
Engine			SAA6D140E-7	
Item	Measurement condition	Unit	Standard value for new machine	Repair limit
Cooling fan speed	<ul style="list-style-type: none"> Hydraulic oil temperature 45 to 55 °C Fuel control dial: MAX (High idle) position Fixed the fan speed to the maximum. (See "SET AND OPERATE MACHINE MONITOR") 	rpm	1430 to 50	1430 to 50

Pump Performance

Machine model			PC700LC-11E0	
Engine			SAA6D140E-7	
Item	Measurement condition	Unit	Standard value for new machine	Repair limit
Main pump performance	<ul style="list-style-type: none"> Pump speed (rpm) 2000 rpm TVC current 400 mA Test pump discharge pressure (MPa {kg/cm²}): P1 Other pump discharged pressure (MPa {kg/cm²}): P2 Average discharge pressure (MPa {kg/cm²): $P = (P1 + P2) / 2$ 	ℓ/min	Q (See graph)	Q (See graph)

Examine Exhaust Gas Color

Tools to Examine Exhaust Gas Color

Symbol	Part No.	Part name	Q'ty	Remarks
A	799-201-9002	Handy smoke checker	1	
B	-	Commercially available	Smoke meter	1
	1	Commercially available	Probe	1

⚠ Place the machine on a level ground, lower the work equipment completely to the ground in a stable posture, set the lock lever to LOCK position, and then stop the engine.

⚠ Immediately after the engine is stopped, its parts and oil are still very hot and may cause burn injury. Wait for the temperature to go down, and then start the work.

Check this item under the following conditions.


Engine coolant temperature: 60 to 100 °C

If an air source and an electric power source are not available in the field, use the handy smoke checker A. Use the smoke meter B when recording the official data, etc.


For testing of exhaust gas color to perform troubleshooting, refer to this section.

How to Examine Exhaust Gas Color with the Handy Smoke Checker

1. Open the cover on the left side of the machine.
2. Remove the cover (1).



3. Remove the plug (2).





How to Replace Fan Belt

The auto-tensioner is provided for the fan belt. Therefore, testing and adjusting is usually unnecessary.

Disconnect the air conditioner compressor belt before replacing the fan belt.

Place the machine on a level ground and lower the work equipment to the ground.

1. Set the wrench to portion "A" (width across the flats: 12.7 mm) of the tensioner assembly (3), and turn the wrench in the direction opposite to the winding-up direction to decrease the fan belt (2) tension.
2. Firmly set the wrench on tensioner assembly (3) at portion "A" before applying turning force to the wrench. (If you try to rotate the wrench before it is fully inserted due to strong spring force of tensioner assembly (3), it can disengage and cause serious physical injuries.)
3. After removing fan belt (2), slowly and carefully restore tensioner assembly (3).
4. Be careful not to catch your fingers between the pulley and fan belt (2) during work.
5. Replace fan belt (2).
6. Check each pulley for breakage and crack.



Examine DEF Tank Heater Valve

Tools to Examine DEF Tank Heater Valve

Symbol	Part No.	Part name	Q'ty	Remarks
A	799-601-9020	T-adapter	1	
B	799-601-2600	T-box	1	
C	Commercially available	Multimeter	1	

⚠ Place the machine on a level ground, lower the work equipment with a stable posture to the ground, set the lock lever in LOCK position, and stop the engine.

NOTICE


If KOMNET communication error remains less than 1 second, engine controller is unable to detect it, and the test may be continued while the machine monitor does not continue the test (standard screen). In that case, once the starting switch is turned to OFF position, system operating lamp goes out, and the engine controller shuts down to reset the test.

“DEF Tank Heater Valve Test” is a function to actuate DEF tank heater valve at any timing, and to check electrical action.


For testing of DEF tank heater valve to perform troubleshooting or others, refer to this section.

How to Examine DEF Tank Heater Valve

1. Check that the system operating lamp is not lit. Turn the battery isolator switch to OFF position.
2. Remove the undercover (1).



3. Disconnect the connector (V41) to be tested.



How to Release Remained Pressure from Swing Motor Circuit

Release the remaining pressure from the circuit according to the following procedure before disconnecting piping between the swing motor and control valve.


Perform steps 1. to 5. by referring to the “Releasing the remaining pressure from the hydraulic cylinder circuit when disconnecting the bucket and arm cylinder hydraulic circuits”.

REMARK

Perform the lever operation only with swing operation.

How to Release Remained Pressure from Travel Motor Circuit

- Release the remaining pressure from the piping according to the following procedure before disconnecting piping between the travel motor and control valve.
 - The control valve spool of the travel circuit is an open type circuit, so the remaining pressure can be released by performing the same operation as that described in “METHOD FOR RELEASING REMAINING PRESSURE FROM HYDRAULIC TANK”.
1. Lower the work equipment to the ground in a stable posture, and stop the engine.
 2. Loosen the oil filler cap (1) of the hydraulic tank gradually to release the air in the tank.



(2) CO Cancel Operation Table

Operating condition of solenoid valve		Operating state of solenoid valve
Working mode	P1-mode, E-mode	OFF (De-energized)
	P0-mode, L mode	ON (Energized)
One-touch power maximizing switch	ON	
Swing lock switch	ON	
Travel lever	When operated	

(3) 2-Stage Relief Solenoid Valve Operation Table

Operating condition of solenoid valve		Operating state of solenoid valve
Working mode	L mode	ON (Energized)

(4) Operation Table of Machine Push-up Solenoid Valve

Operating condition of solenoid valve		Operating state of solenoid valve
Machine push-up and power maximizing switch	ON	OFF (De-energized)
	OFF	ON (Energized)



(5) Operation Table of Travel Speed Selector Solenoid Valve

Operating condition of solenoid valve		Operating state of solenoid valve
Travel speed switch	Lo	OFF (De-energized)
	Hi	ON (Energized)

(6) Swing Parking Brake Solenoid Valve Operation Table

Operating condition of solenoid valve			Operating state of solenoid valve
Swing lock switch	ON	Approx. 10 seconds passes after the work equipment and swing control levers are set to NEUTRAL position	OFF (De-energized)
	OFF	When operating the work equipment control lever and swing control lever	ON (Energized)

- Adjust the stay (1).
 Installing position (2): 776 mm
 Installing position (3): 47 °



- Adjust the mirror (4).


REMARK

Install the mirror (4) so that “Komatsu” logo comes to the right side of the machine.

Tightening torque of the mounting bolt (5): 6.0 to 7.0 Nm {0.61 to 0.71 kgfm}


Installing position (6): 102 mm

Installing position (7): 10 °




NOTICE

- Tighten the bolts on the right and left sides of the brackets alternately so that the clearance on the left (L) and the clearance on the right (R) are equal.
- If tightening the mounting bolts of mirror and stay, the bracket may be broken. Tighten them with the specified torque.



Set the mirror so that the machine side is reflected in the mirror as shown in the figure.

Adjustment is completed when you can recognize a person at the rear right end of the machine body.



REMARK

- If no abnormality is recorded, “No Abnormality Record” is displayed.
- In the mechanical systems abnormality record screen, up to 50 cases currently stored are displayed.
- If the number of occurrence is 1 (first occurrence), the service meter reading at the first occurrence and that at the last occurrence are the same. When the latest service meter reading is recovered, the value at the recovery time is displayed, thus the above readings may not be the same.
- If “E” is displayed on the left of a failure code, the abnormality is still occurring or correction of it is not confirmed.
- For all of the failure codes that the machine monitor can record, see “40 Troubleshooting”, “Failure Code Table”.
- If the characters in the failure are many, the character strings display is scrolled.
- The contents of an abnormality record of the mechanical system cannot be deleted.

How to See Abnormality Record (Electrical Systems)

The machine monitor logs the failures that occurred in the past and is occurring currently and classifies them into the mechanical system abnormality and electrical system abnormality.


To check “Electrical Sys Abnormality Record”, perform the following procedures.

For all of the failure codes that the machine monitor can record, see TROUBLESHOOTING, “Failure code list”.

1. Select “Abnormality Record” on “Service Menu” screen.

REMARK

For selecting method, see “How to Operate Service Mode” in “Service Mode”.




2. On “Abnormality Record” screen, select “Electrical Sys Abnormality Record” with the function switches or numeral input switches.

F3: Moves the selection downward.

F4: Moves the selection upward.

F5: Returns the screen to “Service Menu” screen.

F6: Enters the selection.




REMARK

Input a code (2-digit) by using the numeral input switches to directly select the item, and then press F6 to enter the selection.

3. On “Electrical Sys Abnormality Record” screen, the following information is displayed.

- a: Occurrence order of abnormalities from latest one/ Total number of records
- b: Failure code
- c: Detail of failure
- d: Number of occurrences (displayable range: 0 to 65535 times)
- e: Service meter reading at the first occurrence



Adjust each device by referring to “ADJUST KomVision RELATED DEVICES”.


No-Injection Cranking Operation

If the engine is operated after long storage of the machine, it may be worn or damaged because of insufficient lubrication with oil. To prevent this, the machine has a function to crank the engine without injecting fuel to lubricate the engine before starting it.

Setting of No-Injection cranking to be performed while the engine is stopped.


No-Injection cranking does not function while the engine is running.

This function can be selected even when the engine is running. However, if you execute No-Injection cranking, “Engine is running. Please turn the key off once.” is displayed on the screen.



Even if the confirmation screen is displayed and No-Injection cranking is operated, the function does not become effective in the following cases. Turn the starting switch OFF once to operate.


- The communication between the machine monitor and engine controller is not normal.
- An engine start operation has been performed before the message “No-injection cranking is possible” is displayed.



1. Select “No-Injection Cranking” on “Service Menu” screen.

REMARK


For selecting method, see “How to Operate Service Mode” in “SERVICE MODE”.



2. When “No-Injection Cranking” screen is displayed, confirmation for the execution of No-Injection cranking is displayed. Select the action with the function switch.

F5: Does not implement (returns the screen to “Service Menu”).


F6: Executes.



- Select "KomVision Adjustment" with the function switches or numeral input switches on "Adjustment" screen.

REMARK

See "How to Operate Service Mode" in "SERVICE MODE" for selecting method.



B4P37854

- Select "Camera Calibration" with the function switches on "KomVision Adjustment Menu" screen.


F1: The screen returns to "Service Menu" screen.

F3: Moves the selection downward.

F4: Moves the selection upward.

F5: Selection is canceled. The screen returns to "Adjustment" screen.

F6: Enters the selected item.



B4P37234

- Select "01 Angle Calibration" with the function switches on "CAMERA CALIBRATION" screen.


F1: The screen returns to "Service Menu" screen.

F3: Moves the selection downward.

F4: Moves the selection upward.

F5: Selection is canceled. The screen returns to "KomVision Adjustment Menu" screen.

F6: Enters the selected item.



B4P37235

- Select the camera to be adjusted with the function switches on "Camera Selection(Angle Calibration)" screen.


F1: The screen returns to "Service Menu" screen.

F3: Moves the selection downward.

F4: Moves the selection upward.

F5: Selection is canceled. The screen returns to "CAMERA CALIBRATION" screen.

F6: Enters the selected item.



B4P37236


REMARK

"Bird's-eye Image Rate" and "Camera Image Size Rate" can be adjusted with the function switches.

- Check that the angle setting calibration marker A installed in Step 1 is displayed in the box (b) when the angle calibration screen for the selected camera is displayed.

REMARK

Adjust the position of the angle setting calibration marker A or the angle of the camera if the angle setting calibration marker A is not displayed.



B4P35611

Machine model			PC700LC-11			Good	No good
Engine			SAA6D140E-7				
Item	Testing conditions		Unit	Standard value for new machine	Repair limit	Measured value	
F pump TVC valve outlet pressure	<ul style="list-style-type: none"> Hydraulic oil temperature 45 to 55 °C Working mode: P (Power Mode) Fuel control dial: MAX (High idle) position 	All control levers and control pedals: When levers are returned from fine control to NEUTRAL	MPa {kgf/cm ² }	2.05 to 2.45 {21 to 25}	1.76 or more {18 or more}		
		Work equipment operation: Boom RAISE relief		0.57 to 1.30 {5.8 to 13.2}	0.52 to 1.25 {5.3 to 12.7}		
		Operation of work equipment: Boom RAISE relief + One-touch power maximizing function is actuated		0.90 to 1.40 {9.1 to 14.3}	0.85 to 1.35 {8.6 to 13.8}		
R pump TVC valve outlet pressure	<ul style="list-style-type: none"> Hydraulic oil temperature 45 to 55 °C Working mode: P (Power Mode) Fuel control dial: MAX (High idle) position 	All control levers and control pedals: When levers are returned from fine control to NEUTRAL	MPa {kgf/cm ² }	2.05 to 2.45 {21 to 25}	1.76 or more {18 or more}		
		Work equipment operation: Boom RAISE relief		0.57 to 1.30 {5.8 to 13.2}	0.52 to 1.25 {5.3 to 12.7}		
		Operation of work equipment: Boom RAISE relief + One-touch power maximizing function is actuated		0.90 to 1.40 {9.1 to 14.3}	0.85 to 1.35 {8.6 to 13.8}		

Failure Code [CA3254].....	40-522
Failure Code [CA3255].....	40-526
Failure Code [CA3256].....	40-529
Failure Code [CA3311].....	40-532
Failure Code [CA3312].....	40-535
Failure Code [CA3313].....	40-538
Failure Code [CA3314].....	40-539
Failure Code [CA3315].....	40-540
Failure Code [CA3316].....	40-543
Failure Code [CA3317].....	40-544
Failure Code [CA3318].....	40-545
Failure Code [CA3319].....	40-548
Failure Code [CA3321].....	40-549
Failure Code [CA3322].....	40-550
Failure Code [CA3419].....	40-553
Failure Code [CA3421].....	40-555
Failure Code [CA3497].....	40-557
Failure Code [CA3498].....	40-558
Failure Code [CA3543].....	40-559
Failure Code [CA3545].....	40-564
Failure Code [CA3547].....	40-566
Failure Code [CA3558].....	40-567
Failure Code [CA3559].....	40-569
Failure Code [CA3562].....	40-571
Failure Code [CA3563].....	40-573
Failure Code [CA3567].....	40-576
Failure Code [CA3568].....	40-579
Failure Code [CA3571].....	40-583
Failure Code [CA3572].....	40-585
Failure Code [CA3574].....	40-587
Failure Code [CA3575].....	40-590
Failure Code [CA3577].....	40-592
Failure Code [CA3578].....	40-594
Failure Code [CA3582].....	40-596
Failure Code [CA3583].....	40-602
Failure Code [CA3596].....	40-604
Failure Code [CA3649].....	40-607
Failure Code [CA3681].....	40-610
Failure Code [CA3682].....	40-615
Failure Code [CA3713].....	40-621
Failure Code [CA3717].....	40-624
Failure Code [CA3718].....	40-625
Failure Code [CA3725].....	40-626
Failure Code [CA3748].....	40-629
Failure Code [CA3751].....	40-631
Failure Code [CA3755].....	40-633
Failure Code [CA3866].....	40-635
Failure Code [CA3867].....	40-639
Failure Code [CA3868].....	40-642
Failure Code [CA3899].....	40-646
Failure Code [CA3911].....	40-649
Failure Code [CA3912].....	40-653
Failure Code [CA3932].....	40-655
Failure Code [CA3933].....	40-657
Failure Code [CA3934].....	40-659
Failure Code [CA3935].....	40-662
Failure Code [CA3936].....	40-664
Failure Code [CA4151].....	40-666

Test in Accordance with Testing Procedure


Examine Fuel Level and Type

⚠ Fuel is highly flammable and dangerous. Keep fire away.



⚠ When adding fuel, be careful not to overflow it.

⚠ Wipe off any spilled fuel. If fuel spills over soil or sand, remove all the fuel and soil or sand together.

1. Turn the engine starting switch to ON position and check the fuel level with the fuel gauge (1) on the monitor panel.
After checking, turn the switch back to OFF position.
2. If the fuel level is low, open fuel filler cap (F) of the fuel tank and add fuel through the fuel filler port to the necessary level, referring to the position of float gauge (G).




3. After adding fuel, push float gauge (G) straight down with fuel filler cap (F), and tighten fuel filler cap (F) securely while taking care the float gauge (G) is not caught in tab (2) of fuel filler cap (F).




REMARK

If breather hole (3) in the oil filler cap is clogged, the pressure in the tank decreases and fuel may not be supplied. To prevent this, clean the breather hole.




- 3. Hold the connector body (black portions on the male and female sides) and disconnect the connector.
- How to connect connector
Insert the connector straight until it clicks.



















9JC01244

AMP-81 and DELPHE-96 connectors







- Disconnection and connection of connector
Disconnect the connector by moving in the order of (a) to (c), and connect in the order of (d) to (f) as shown in the figure.
- Disconnection: (a) Unlock (b) Slide the lever (c) Disconnect the connector
- Connection: (d) Position the connector (e) Slide the lever (f) Engage the lock



BWP14228

No. of pins	SWP type connector		Testing connection use special tool Part No.
	Male (female housing)	Female (male housing)	
6	  <p>BWP04707</p>	  <p>BWP04708</p>	799-601-7050 (T-adapter)
	Part No. : 08055-10681	Part No. : 08055-10691	
8	  <p>BWP04709</p>	  <p>BWP04710</p>	799-601-7060 (T-adapter)
	Part No. : 08055-10881	Part No. : 08055-10891	
12	  <p>BWP04711</p>	  <p>BWP04712</p>	799-601-7310 (T-adapter)
	Part No. : 08055-11281	Part No. : 08055-11291	
14	  <p>BWP04713</p>	  <p>BWP04714</p>	799-601-7070 (T-adapter)
	Part No. : 08055-11481	Part No. : 08055-11491	

B4D18191

SUMITOMO connector for engine			
No. of pins	PCV (125, 140 engine)		
	Valve side (plug)	Harness side (receptacle)	Testing connection use special tool Part No.
2			799-601-9430 (Socket) (Kit: 799-601-4101) (Kit: 799-601-4201)
	-	-	
No. of pins	Fuel supply pump (95 engine)		
	Valve side (plug)	Harness side (receptacle)	
2			-
	-	-	
No. of pins	Variable flow turbocharger, EGR valve (95 engine)		
	Sensor (motor) side (plug)	Harness side (receptacle)	
8			-
	-	-	


B4W21624

Failure code	Failure (Shown on screen)	Applicable equipment	Action level	History category	Remarks
CA731	Engine Backup Speed Sensor Phase Error	ENG	L01	Electrical system	
CA778	Engine Backup Speed Sensor Error	ENG	L01	Electrical system	
CA1117	Engine Controller Partial Data Lost Error	ENG	L04	Electrical system	
CA1664	KDOC Abnormality	ENG	L03	Electrical system	
CA1669	DEF Level Sensor Voltage High Error	ENG	L01	Electrical system	
CA1673	DEF Level Low Error 3	ENG	L03	Electrical system	
CA1677	DEF Temperature Sensor Low Error	ENG	L01	Electrical system	
CA1678	DEF Temperature Sensor High Error	ENG	L01	Electrical system	
CA1682	DEF Pump Priming Error	ENG	L01	Electrical system	
CA1683	DEF Tank Heating Valve Voltage High Error	ENG	L01	Electrical system	
CA1684	DEF Tank Heating Valve Voltage Low Error	ENG	L01	Electrical system	
CA1686	DEF Quality Sensor Voltage High Error	ENG	L01	Electrical system	
CA1691	Defective Regeneration	ENG	L03	Electrical system	
CA1694	SCR Outlet NOx Sensor In Range Error	ENG	L01	Electrical system	
CA1695	Sensor 5 Supply Voltage High Error	ENG	L03	Electrical system	
CA1696	Sensor 5 Supply Voltage Low Error	ENG	L03	Electrical system	
CA1712	DEF Tank Thawing Error	ENG	L01	Electrical system	
CA1713	DEF Tank Heater Valve Open Stuck Error	ENG	L01	Electrical system	
CA1714	DEF Quality Sensor Out of Calibration Error	ENG	L01	Electrical system	
CA1715	DEF Quality Sensor Internal Circuit Error	ENG	L01	Electrical system	
CA1776	Sensor Supply Relay Voltage High Error	ENG	L01	Electrical system	
CA1777	Sensor Supply Relay Voltage Low Error	ENG	L01	Electrical system	
CA1843	Crankcase Pressure Sensor High Error	ENG	L01	Electrical system	


Failure Code [989L00]

Action level	Failure code	Failure	Engine Controller Lock Caution 1 (Machine monitor system)
-	989L00		
Detail of failure	Engine controller lock error is detected (factor 1).		
Action of controller	<ul style="list-style-type: none"> • None in particular • If cause of failure disappears, machine becomes normal by itself. 		
Phenomenon on machine	Engine does not start.		
Related information	<ul style="list-style-type: none"> • When this failure code is displayed after replacement of monitor controller, user password must be replaced with one before replacement of controller • After completion of repair, check if the failure code is cleared by the following procedure. Procedure: Turn the starting switch to ON position. 		
No.	Cause	Procedure, measuring location, criteria and remarks	
1	Machine monitor re-placed	This failure may occur due to machine monitor replacement.	

Circuit Diagram of Engine Oil Level



Circuit Diagram of Charge Air Temperature Sensor



Failure Code [CA325]

Action level	Failure code	Failure	Injector #6 (L#6) Open Circuit Error or Short Circuit Error (Engine controller system)
L03	CA325		
Details of failure	Open or short circuit is detected in #6 injector circuit.		
Action of controller	None in particular		
Phenomenon on machine	<ul style="list-style-type: none"> • Engine power deration • Engine does not run stably. 		
Related information	<ul style="list-style-type: none"> • After repairing, check if the failure code is cleared by the following procedure. Procedure: Start engine. • If ground fault or hot short circuit is detected, failure codes [CA323], [CA325] and [CA332] appear simultaneously. • While engine is running normally, approximately 65 V of pulse voltage is supplied to injector (+) side. Because it is pulse voltage, it cannot be measured by using multimeter. 		

No.	Cause	Procedure, measuring location, criteria and remarks		
1	Defective wiring harness connector	1. See descriptions of wiring harness and connectors in “Electrical equipment” in “CHECKS BEFORE TROUBLESHOOTING” of “RELATED INFORMATION ON TROUBLESHOOTING”, and check it. 2. Start the engine.		
		If this failure code is cleared, wiring harness connector is defective.		
2	Defective injector #6	1. Turn starting switch to OFF position. 2. Disconnect connector CN6, and connect T-adapter to male side.		
		Resistance	Between CN6 (male) (1) and (2)	0.4 to 1.1 Ω
			Between CN6 (male) (1) and ground	Min. 1 MΩ
3	Open circuit or ground fault in wiring harness	1. Turn starting switch to OFF position. 2. Disconnect connector J1, and connect T-adapter to female side.		
		Resistance	Between J1 (female) (51) and (75)	0.4 to 1.1 Ω
			Between J1 (female) (51) and ground	Min. 1 MΩ
4	Open circuit in wiring harness (wire breakage or defective contact of connector)	If failure code is still displayed after above checks on cause 3, this check is not required. 1. Turn starting switch to OFF position. 2. Disconnect connectors J1 and CN6, and connect T-adapter to each female side.		
		Resistance	Between J1 (female) (51) and CN6 (female) (1)	Max. 1 Ω
			Between J1 (female) (75) and CN6 (female) (2)	Max. 1 Ω

Failure Code [CA555]

Action level	Failure code	Failure	Crankcase Pressure High Error 2 (Engine controller system)
L01	CA555		
Details of failure	High pressure error (level 1) in crankcase pressure is detected.		
Action of controller	None in particular		
Phenomenon on machine	None in particular		
Related information	<ul style="list-style-type: none"> Signal voltage from crankcase pressure sensor can be checked by monitoring function. (Code: 48401 (V)) Pressure in crankcase pressure sensor can be checked by monitoring function. (Code: 48400 (kPa)) This failure code is cleared when failure code [CA1942] is displayed. After repairing, check if the failure code is cleared by the following procedure. Procedure: Start engine. 		


No.	Cause	Procedure, measuring location, criteria and remarks
1	Clogged KCCV filter	Replace the KCCV filter.
2	Blocked KCCV gas piping	If an error persists after replacement of the KCCV filter and emulsions are detected inside KCCV, blocked emulsions may be suspected in KCCV blow by gas piping. Check that there is no coolant leakage.
3	Defective crankcase pressure sensor	Crankcase pressure sensor system may be defective. Perform troubleshooting for failure codes [CA1843] and [CA1844].
4	Increase of blowby gas	The error does not disappear after replacing KCCV filter, and "Crankcase Pressure High Error 1" or "Crankcase Pressure High Error 2" is also displayed, piston ring may be worn or broken, or oil from VGT may be leaked, valve guide and stem seal may be worn or damaged. Perform troubleshooting "TROUBLESHOOTING OF ENGINE (S MODE)", "Engine oil consumption is excessive".

Failure Code [CA1677]

Action level	Failure code	Failure	DEF Temperature Sensor Low Error (Engine controller system)
L01	CA1677		
Detail of failure	Failure of DEF temperature sensor (Short circuit of thermistor for temperature measurement)		
Action of controller	Advances to Inducement strategy. (EU Specification)		
Phenomenon on machine	<ul style="list-style-type: none"> • Failure to measure DEF level. • Engine power deration according to inducement strategy. (EU Specification) 		
Related information	<ul style="list-style-type: none"> • The DEF temperature sensor is one of the DEF tank sensors integrated with the DEF level sensor and DEF quality sensor performs CAN communication with the engine controller. • If the thermistor for temperature measurement shorts, this failure code is sent to the engine controller via CAN communication and displayed. • After repairing, check if the failure code is cleared by the following procedure. Procedure: Turn starting switch to ON position. 		

No.	Cause	Procedure, measuring location, criteria and remarks
1	Defective wiring harness connector	<ol style="list-style-type: none"> 1. See descriptions of wiring harness and connectors in “Electrical equipment” in “CHECKS BEFORE TROUBLESHOOTING” of “RELATED INFORMATION ON TROUBLESHOOTING”, and check it. 2. Turn starting switch to ON position. <p>If this failure code is cleared, wiring harness connector is defective.</p>
2	Defective DEF tank sensor	<ol style="list-style-type: none"> 1. Check the sensor connector for contamination and damage. 2. Turn starting switch to OFF position. 3. Replace the DEF tank sensor. 4. Turn starting switch to ON position. <p>If this failure code is cleared, any internal parts in the original DEF tank sensor is defective. (In case of an internal defect, troubleshooting is impossible as an assembly. Replace whole assembly.)</p>
3	Defective engine controller	If no failure is found by above checks, engine controller is defective. (Since this is an internal defect, troubleshooting cannot be performed.)

Circuit Diagram of Sensor Power Supply Relay



G0076368


Failure Code [CA1924]

Action level	Failure code	Failure	Fuel Doser Solenoid 1 Low Error (Engine controller system)
L03	CA1924		
Details of failure	Abnormal low voltage occurs in fuel doser solenoid valve 1(shut off valve).		
Action of controller	Regeneration control stops.		
Phenomenon on machine	<ul style="list-style-type: none"> Automatic regeneration is not performed. Manual stationary regeneration cannot be performed. 		
Related information	<p>⚠ Exhaust connector and KDPF become hot (Min. 500 °C). Be careful not to get burn injury.</p> <ul style="list-style-type: none"> If connector DSOV1 is disconnected, failure code [CA1923] is displayed. See failure code [CA1925]. This failure code is cleared after implementing fuel doser solenoid valve 1drive again turning the starting switch from OFF to ON after abnormality repair. After repairing, check if the failure code is cleared by the following procedure. Procedure: Start engine. 		

No.	Cause	Procedure, measuring location, criteria and remarks		
1	Defective wiring harness connector	<ol style="list-style-type: none"> See descriptions of wiring harness and connectors in “c: Electrical equipment” in “Checks before troubleshooting” of “Related information on troubleshooting”, and check it. Start engine. 		
		If this failure code is cleared, wiring harness connector is defective.		
2	Defective dosing fuel solenoid valve 1 (shut-off valve)	<ol style="list-style-type: none"> Turn starting switch to OFF position. Disconnect connector DSOV1, and connect T-adapter to male side. 		
		Resistance	Between DSOV1 (male) (2) and (1)	4 to 6 Ω
			Between DSOV1 (male) (1) and ground (DSOV body)	Min. 1 MΩ
3	Open or short circuit in wiring harness	<ol style="list-style-type: none"> Turn starting switch to OFF position. Disconnect connector J1, and connect T-adapter to female side. 		
		Resistance	Between J1 (female) (8) and (30)	4 to 6 Ω
4	Ground fault in wiring harness (contact with ground circuit)	<ol style="list-style-type: none"> Turn starting switch to OFF position. Disconnect connectors J1 and DSOV1, and connect T-adapter to either female side. 		
		Resistance	Between ground (frame) and J1 (female) (9) or DSOV1 (female) (1)	Min. 1 MΩ
5	Short circuit in wiring harness	<ol style="list-style-type: none"> Turn starting switch to OFF position. Disconnect connectors J1 and DSOV1, and connect T-adapter to female side of J1. 		
		Continuity	Between J1 (female) (8) and each pin other than pin (8)	No continuity (no sound is heard)
6	Defective dosing fuel solenoid valve 1 (shut-off valve)	Replace dosing fuel solenoid valve 1 (shut-off valve).		

No.	Cause	Procedure, measuring location, criteria and remarks		
6	Hot short circuit in wiring harness	1. Turn starting switch to OFF position. 2. Disconnect connector SEGR and connect T-adapter to female side. 3. Turn starting switch ON (with connector SEGR disconnected).		
		Voltage	Between SEGR (female) (3) or (4) and (2)	Max. 1 V
7	Defective engine controller	If no failure is found by above checks, engine controller is defective. (Since this is an internal defect, troubleshooting cannot be performed.)		
		Reference		
		1. Turn starting switch to OFF position. 2. Insert T-adapter into connector J1. 3. Turn starting switch to ON position.		
		Voltage	Between J1 (88) and (57)	1.0 to 4.0 V

Circuit Diagram of EGR Valve Lift Sensor




Failure Code [CA2732]

Action level	Failure code	Failure	Fuel Doser Solenoid 2 High Error (Engine controller system)
L03	CA2732		
Detail of failure	Abnormal high voltage occurs in fuel doser solenoid valve 2 (drain valve).		
Action of controller	Regeneration control stops.		
Phenomenon on machine	<ul style="list-style-type: none"> Automatic regeneration is disabled. Manual stationary regeneration is disabled. 		
Related information	<p>⚠ Since exhaust connector and KDPF are heated to 500°C or above, be careful not to get burn injury.</p> <ul style="list-style-type: none"> If failure code [CA1923] is also displayed, the ground line may have open circuit. If connector DSOV2 is disconnected, this failure code is displayed. See failure code [CA1963]. After repairing, check if the failure code is cleared by the following procedure. Procedure: Turn starting switch to ON position. 		

No.	Cause	Procedure, measuring location, criteria and remarks		
1	Defective wiring harness connector	<ol style="list-style-type: none"> See descriptions of wiring harness and connectors in “c: Electrical equipment” in “CHECKS BEFORE TROUBLESHOOTING” of “RELATED INFORMATION ON TROUBLESHOOTING”, and check it. Turn starting switch to ON position. 		
		If this failure code is cleared, wiring harness connector is defective.		
2	Defective dosing fuel solenoid valve 2 (drain valve)	<ol style="list-style-type: none"> Turn starting switch to OFF position. Disconnect connector DSOV2, and connect T-adapter to male side. 		
		Resistance	Between DSOV2 (male) (2) and (1)	4 to 6 Ω
3	Open or short circuit in wiring harness	<ol style="list-style-type: none"> Turn starting switch to OFF position. Disconnect connector J1, and connect T-adapter to female side. 		
		Resistance	Between J1 (female) (6) and (30) Resistance is the same as resistance of dosing fuel solenoid valve 2.	4 to 6 Ω
4	Open circuit in wiring harness (wire breakage of ground line or defective contact of connector)	If failure code is still displayed after above checks on cause 3, this check is not required.		
		<ol style="list-style-type: none"> Turn starting switch to OFF position. Disconnect connectors J1 and DSOV2 and connect T-adapters to each female side. 		
		Resistance	Between J1 (female) (6) and DSOV2 (female) (1)	Max. 1 Ω
			Between J1 (female) (30) and DSOV2 (female) (2)	Max. 1 Ω
5	Hot short circuit in wiring harness	<ol style="list-style-type: none"> Turn starting switch to OFF position. Disconnect connector DSOV2, and connect T-adapter to female side. Turn starting switch to ON position. 		
		Voltage	Between DSOV2 (female) (1) and (2)	Max. 4.7 V

Circuit Diagram Related to KDPF Outlet Pressure Sensor



No.	Cause	Procedure, measuring location, criteria and remarks		
6	Defective KDPF temperature sensor	If all of 6 failure codes of [CA2771], [CA3232], [CA3868], [CA3911], [CA4151], and [CA4152] are displayed. 1. Turn starting switch to OFF position. 2. Disconnect KDPF temperature sensor (E26). 3. Turn starting switch to ON position.		
		If any of these 6 codes disappeared, the sensor which has been disconnected is defective.		
7	Defective DEF tank sensor	If all 6 failure codes of [CA2771], [CA3232], [CA3868], [CA3911], [CA4151], and [CA4152] are displayed 1. Turn starting switch to OFF position. 2. Disconnect DEF tank sensor (P63). 3. Turn starting switch to ON position.		
		Displaying less than 6 failure codes indicates the disconnected sensor is defective.		
8	Open circuit in wiring harness (power supply circuit)	1. Turn the starting switch to OFF position. 2. Check that system operating lamp is turned off, and then turn the battery isolator switch to OFF position. 3. Disconnect connectors R52 and E31 and connect T-adapter to each female side.		
		Resistance	Between R52 (female) (6) and E31 (female) (1)	Max. 1 Ω
			Between E31 (female) (4) and ground	Max. 1 Ω
9	Defective CAN terminating resistor	1. Turn starting switch to OFF position. 2. Disconnect connector K10 and D_RES and connect T-adapter to male side.		
		Resistance	Between K10 (male) (A) and (B)	Approx. 120 Ω
			Between D_RES (male) (A) and (B)	Approx. 120 Ω
10	Open circuit in wiring harness (CAN communication line)	1. Turn the starting switch to OFF position. 2. Check that system operating lamp is turned off, and then turn the battery isolator switch to OFF position. 3. Disconnect connectors J2, E36, K10, and D_RES, and connect T-adapter to each female side.		
		Resistance	Between J2 (female) (21) and E31 (female) (3)	Max. 1 Ω
			Between J2 (female) (45) and E31 (female) (2)	Max. 1 Ω
			Between K10 (female) (A) and E31 (female) (3)	Max. 1 Ω
			Between K10 (female) (B) and E31 (female) (2)	Max. 1 Ω
			Between D_RES (female) (A) and E31 (female) (3)	Max. 1 Ω
			Between D_RES (female) (B) and E31 (female) (2)	Max. 1 Ω

No.	Cause	Procedure, measuring location, criteria and remarks
3	Oil leakage into turbo-charger exhaust connector	<ol style="list-style-type: none"> 1. Remove the turbocharger exhaust connector. 2. Check if oil or fuel is not attached to inside of the turbocharger exhaust connector. <p>NOTICE</p> <ul style="list-style-type: none"> • If it is attached, visually check the EGR valve and turbocharger for oil leakage. Repair them if an abnormality is found. • Remove oil or fuel from the piping thoroughly.
4	Oil leakage into exhaust connector or duct to KDPF	<p>Check the exhaust system between the turbocharger and KDPF for entry of oil or fuel.</p> <ul style="list-style-type: none"> • If oil or fuel is attached, remove it thoroughly. • If a mark of oil or fuel flowing into KDPF is found, check KDPF, and then clean or replace it if required.
5	Defective installation of KDOC outlet temperature sensor	For details, see Disassembly and Assembly, "Remove and Install KDPF Assembly" and "DISASSEMBLE AND ASSEMBLE OF KDPF ASSEMBLY". Repair as necessary.
6	Defective KDPF temperature sensor	If the failure code is not cleared after performing above-mentioned troubleshooting, replace KDPF temperature sensor.
7	Defective engine controller	If no failure is found by above checks, engine controller is defective. (Since this is an internal defect, troubleshooting cannot be performed.)

Loaded Diagnostics Operation to Clear Failure Code

Check if the repair has been completed with the following procedure:

(Make sure this failure code is cleared after this procedure.)

1. Turn the starting switch from OFF to ON and leave it there for 1 minute.
2. Start the engine and run it at low idle speed for 15 minutes.

NOTICE

If the failure code is cleared, repair work is complete. Otherwise, perform the following:

REMARK

If failure code is not cleared after preceding steps 1 and 2 are performed, following temperature conditions are requirements for clearing the failure code. Steps 4 and 6 are required to satisfy temperature requirements.

- KDOC outlet temperature 200 °C or above
- KDPF outlet temperature 200 °C or above

3. Display KDOC outlet temperature and KDPF outlet temperature with monitoring function.
4. Raise one side by work equipment.
5. Set the swing lock to ON and the working mode to P.
6. Set the fuel control dial to MAX position and travel to Hi and drive for 15 minutes with one side idle running.

NOTICE

When the KDOC outlet temperature or KDPF outlet temperature does not exceed 200 °C, perform "Loaded Diagnostics Operation To Clear failure Code" [CA1883].

7. If the the failure code is cleared, repair work is complete.


Failure Code [CA3497]

Action level	Failure code	Failure	DEF Level Low Error 1 (Engine controller system)
-	CA3497		
Detail of failure	The DEF tank level lowered. (The tank capacity becomes 10 % or less)		
Action of controller	Advances to Inducement strategy.		
Phenomenon on machine	None in particular		
Related information	<ul style="list-style-type: none"> • The failure codes of DEF level low are as follows: When DEF level is 10 % or less [CA3497] When DEF level is 5 % or less [CA3498] When DEF level is 2.5 % or less [CA1673] When DEF level is 0.0 % or less [CA3547] • CA3498 is displayed if usage is continued without refilling DEF and the DEF level becomes 5 % or less. • After repairing, check if the failure code is cleared by the following procedure. Procedure: Turn starting switch to ON position. 		

No.	Cause	Procedure, measuring location, criteria and remarks
1	Low DEF level	<ol style="list-style-type: none"> 1. Turn starting switch to OFF position. 2. Check the sight gauge to confirm that there is sufficient amount of DEF in the DEF tank. 3. Refill DEF if the level is low. 4. Turn starting switch to ON position. <p>If this failure code is cleared, DEF has been insufficient.</p>
2	Defective DEF tank sensor	<ol style="list-style-type: none"> 1. Check the sensor connector for contamination and damage. 2. Turn starting switch to OFF position. 3. Replace the DEF tank sensor. 4. Turn starting switch to ON position. <p>If this failure code is cleared, any internal parts in the original DEF tank sensor is defective. (In case of an internal defect, troubleshooting is impossible as an assembly. Replace whole assembly.)</p>
3	Defective engine controller	If no failure is found by above checks, engine controller is defective. (Since this is an internal defect, troubleshooting cannot be performed.)

No.	Cause	Procedure, measuring location, criteria and remarks		
5	Ground fault in wiring harness (contact with ground circuit)	1. Turn starting switch to OFF position. 2. Disconnect MB02, and connect T-adapter to female side or insert T-adapter to connector J2.		
		Resistance	Between MB02 (female) (3) or J2 (16) and ground	Min. 1 MΩ
6	Defective DEF pressure sensor	1. Turn starting switch to OFF position. 2. Insert T-adapter into connector J2 or MB02. 3. Turn starting switch to ON position.		
		Voltage	Between J2 (female) (16) and (32), or between MB02 (female) (3) and (4)	Sensor output
7	Defective engine controller	If no failure is found by above checks, engine controller is defective. (Since this is an internal defect, troubleshooting cannot be performed.)		

Circuit Diagram of DEF Pump Pressure Sensor



B4P30508

Failure Code [CA3682]

Action level	Failure code	Failure	Turbo Outlet NOx Sensor Power Voltage Error (Engine controller system)
L01	CA3682		
Detail of failure	Turbo outlet NOx sensor does not display the value due to defective power supply of turbo outlet NOx sensor.		
Action of controller	<ul style="list-style-type: none"> Operates the engine by referring to the model NOx value. Activates Inducement strategy (EU specification). 		
Phenomenon on machine	<ul style="list-style-type: none"> DEF injection becomes inappropriate and the NOx emission may increase, or ammonia may be discharged. Engine output is reduced based on Inducement strategy (EU specification). 		

No.	Cause	Procedure, measuring location, criteria and remarks	
6	Hot short circuit in wiring harness	If failure code (no open circuit) is still displayed after above checks in cause 2, measure resistance at any one place in Hi line and Lo line. 1. Turn starting switch to OFF position. 2. Check that system operating lamp does not light up, and then turn battery isolator switch to OFF position. 3. Insert T-adapter into one of the related connectors. 4. Set battery isolator switch to ON position. 5. Turn starting switch to ON position.	
		Voltage	Between one of J2(21), K10(A), D_RES (A), E31(3), E32(2), E26(3), E34(3), E36(3), or P63(2) and ground 1 to 4 V
			Between one of J2(45), K10(B), D_RES (B), E31(2), E32(3), E26(2), E34(2), E36(2), or P63(3) and ground 1 to 4 V
7	Defective DEF tank sensor	1. Turn starting switch to OFF position. 2. Replace DEF tank sensor (P63). 3. Turn starting switch to ON position.	
		If this failure code is cleared, the original sensor is defective. (In case of an internal defect, troubleshooting is impossible as an assembly. Replace whole assembly.)	
8	Defective engine controller	If no failure is found by above checks, engine controller is defective. (Since this is an internal defect, troubleshooting cannot be performed.)	

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL


- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Circuit Diagram of SCR System CAN Communication



G0076368

No.	Cause	Procedure, measuring location, criteria and remarks		
9	Hot short circuit in wiring harness (DEF pump heater circuit)	1. Turn the starting switch to OFF position. 2. Disconnect connector MB02 and connect T-adapter to female side. 3. Turn the starting switch to ON position.		
		REMARK Check for ambient temperature of 10 °C or above (condition under which DEF pump heater is not working).		
		Voltage	Between MB02 (female) (5) and (6)	Max. 1 V
10	Defective DEF pump	If no failure is found by above checks, DEF pump is defective. (Since this is an internal defect, troubleshooting cannot be performed.)		
11	Defective DEF pump temperature sensor	If no failure is found by above checks, DEF pump temperature sensor is defective. (Since this is an internal defect, troubleshooting cannot be performed.)		
12	Defective engine controller	If no failure is found by above checks, engine controller is defective. (Since this is an internal defect, troubleshooting cannot be performed.)		

Loaded Diagnostics Operation to Confirm Failure Correction

Check if the repair has been completed with the following procedure:

(Make sure this failure code is not displayed after this procedure.)

1. Turn the starting switch to ON position (Do not start the engine).
2. Check if monitoring code 19136 "DEF Pump Temperature" is 42 °C or less and 19107"DEF Pump Heater 1 Command" is "0" on the "Pre-defined Monitoring" screen.
3. Wait for 10 minutes.
4. If the DEF Pump Temperature rises 12 °C or less after the starting switch is turned to ON, repair will be completed.
5. After the repair is completed, see "Procedure for Troubleshooting" to clear the failure code and make sure that the failure code has been cleared from the Abnormality Record screen.

REMARK

If the increase of "DEF Pump Temperature" is 12 °C or more after the starting switch is turned to ON, return to troubleshooting.

No.	Cause	Procedure, measuring location, criteria and remarks
2	Contaminated DEF	<ol style="list-style-type: none"> 1. Drain more than 1 ℓ of DEF to check that it is not contaminated with foreign material, etc. 2. If the drained DEF is contaminated, drain all of the DEF and refill with fresh DEF. 3. If it is heavily contaminated with sand, dirt, etc., clean the DEF tank. 4. If the “DEF concentration” is in 29 to 36 % after the work finished, perform “Loaded Diagnostics Operation To Clear Failure Code”. 5. If the “DEF concentration” is out of the normal range, proceed to the next troubleshooting.
3	Foreign matter adhered to the sensing part of the DEF tank sensor	<ol style="list-style-type: none"> 1. Remove the DEF level sensor so that you can reach the DEF concentration detection part (end of sensor). 2. Clean up the DEF concentration detection part with dry and clean cloth, and install the DEF level sensor. 3. If DEF concentration is within the range from 29 to 36 % on “Pre-defined Monitoring” screen, perform “Loaded Diagnostics Operation to Clear Failure Code” to complete the repair work. 4. If DEF concentration is out of the normal range, proceed to the next troubleshooting. <p>REMARK</p> <ul style="list-style-type: none"> • If the new DEF has not been added as described in Cause “Contaminated DEF”, and if it takes time to remove the sensor, drain the total amount of DEF, refill with new DEF again, and check the sensor output. • For details of removing DEF tank sensor, see Disassemble and Assembly, “Remove and Install DEF Tank Sensor Flange Assembly”.
4	Defective DEF tank sensor (internal defect)	<ol style="list-style-type: none"> 1. Replace the DEF tank sensor. 2. If the “DEF concentration” displayed on the Pre-defined Monitoring screen falls in the range of 29 to 36%, perform “Loaded Diagnostics Operation To Clear Failure Code” topics to complete the repair. 3. If the “DEF concentration” falls outside of this range, proceed to the next troubleshooting.
5	Defective engine controller	<ol style="list-style-type: none"> 1. Replace the engine controller. 2. Perform “Loaded Diagnostics Operation To Clear Failure Code”. 3. If this failure code is displayed, perform troubleshooting again.

Loaded Diagnostics Operation to Clear Failure Code

Check if the repair has been completed with the following procedure:

(Make sure this failure code is cleared after this procedure.)


1. Turn the starting switch to OFF position, and shut down the engine controller.
2. Turn the starting switch to ON position.
3. Wait for 60 minutes. (It is not necessary to start the engine.)
4. If this failure code is cleared, repair is completed.

Failure Code [CA5179]


Action level	Failure code	Failure	Engine Room Temperature Sensor High Error (Engine controller system)
L01	CA5179		
Detail of failure	A high voltage error occurs in signal circuit of engine room temperature sensor.		
Action of controller	Run the engine by using the default value of the engine room temperature (25 °C).		
Phenomenon on machine	<ul style="list-style-type: none"> DEF line stops thawing. NOx emission may increase because DEF line stops thawing. 		
Related information	<ul style="list-style-type: none"> This failure code is displayed when the engine room temperature sensor connector is removed. After repairing, check if the failure code is cleared by the following procedure. Procedure: Turn starting switch to ON position. 		

No.	Cause	Procedure, measuring location, criteria and remarks			
1	Defective wiring harness connector	1. See descriptions of wiring harness and connectors in “Electrical equipment” in “CHECKS BEFORE TROUBLESHOOTING” of “RELATED INFORMATION ON TROUBLESHOOTING”, and check it. 2. Turn starting switch to ON position.			
		If this failure code is cleared, the wiring harness connector is defective.			
2	Defective engine room temperature sensor	1. Turn starting switch to OFF position. 2. Disconnect connector P66 and connect socket to male side. REMARK If a resistance value of the engine room temperature sensor ranges from 280 Ω to 382 kΩ, the engine room temperature sensor is considered to be normal.			
		Resistance	Between P66 (male) (A) and (B)	-40 °C	291 to 382 kΩ
				-20 °C	85 to 109 kΩ
				0 °C	29 to 36 kΩ
				30 °C	7.3 to 8.8 kΩ
				60 °C	2.3 to 2.7 kΩ
				90 °C	860 to 970 Ω
				130 °C	280 to 320 Ω
3	Open or short circuit in wiring harness	1. Turn starting switch to OFF position. 2. Disconnect connector J2, and connect T-adaptor to female side. REMARK Use an engine room temperature sensor resistance characteristics table for check on cause 2 as a resistance value.			
		Resistance	Between J2 (female) (65) and (32)	280 Ω to 382 kΩ	

Circuit Diagram of CAN Communication 1



Circuit Diagram of CAN2 Communication




Failure Code [DHACMA]

Action level	Failure code	Failure	KDPF Outlet Pressure Sensor Frozen (Engine controller system)
-	DHACMA		
Detail of failure	Signal voltage from KDPF differential pressure sensor does not show a correct value when ambient temperature is low because of frozen KDPF differential pressure sensor. (Signal voltage is within "normal" or "operating" range.)		
Action of controller	Normal operation		
Phenomenon on machine	No		
Related information	<p>⚠ Since KDOC and KDPF are heated to Min. 500 °C or above, be careful not to get burn injury.</p> <ul style="list-style-type: none"> The cause of this failure code is solved after freeze is solved. Troubleshooting is not necessary. If the ambient temperature is not freezing point when this failure code is displayed on abnormality record, identify the cause according to the following procedures. KDPF differential pressure sensor and KDPF outlet pressure sensor are provided as a unit. Signal voltage from KDPF outlet pressure sensor can be checked with monitoring function. (Code: 47001 (V)) Pressure detected by KDPF outlet pressure sensor can be checked with monitoring function. (Code: 47000 (kPa)) Temperature in KDOC inlet temperature sensor can be checked by monitoring function. (Code: 47300 (°C)) Temperature in KDOC outlet temperature sensor can be checked by monitoring function. (Code: 47400 (°C)) Temperature in KDPF outlet temperature sensor can be checked by monitoring function. (Code: 47200 (°C)) For details of access to KDPF differential pressure sensor, wiring harness and tube, see "Chapter 50 DISASSEMBLY AND ASSEMBLY, "REMOVE AND INSTALL KDPF ASSEMBLY" and "DISASSEMBLE AND ASSEMBLE OF KDPF ASSEMBLY". The KDOC inlet temperature sensor, KDOC outlet temperature sensor, and KDPF outlet temperature sensor are integrated into one sensor controller which provides CAN communication with the engine controller. After turning starting switch to OFF position, engine controller performs DEF purge (for Max. 6 minutes) and then stops. To restart engine, wait until system operating lamp goes off after turning starting switch to OFF position, and then turn starting switch to ON position. Mass air flow sensor and intake air temperature sensor are provided as a unit. 		

No.	Cause	Procedure, measuring location, criteria and remarks
1	Defective KDPF differential pressure sensor tube	If failure code [CA3135] is displayed on the abnormality record screen, perform troubleshooting for failure code [CA3135] first.
2	Ambient temperature sensor installation error	Check the installation of the ambient temperature sensor. If there is a defective installation, install it again correctly.
3	Defective intake air temperature sensor	Check the installation of the intake air temperature sensor, if there is a defective installation, install it again correctly.

Circuit Diagram of Bucket DUMP PPC Pressure Sensor




Failure Code [DR20KA]


Action level	Failure code	Failure	Disconnection of Camera 2 NTSC Input (KomVision controller system)
L01	DR20KA		
Detail of failure	Image signal of the camera 2 cannot be detected.		
Action of controller	None in particular		
Phenomenon on machine	Display area of the R.H. camera and the single camera images are displayed in black.		
Related information	After completion of repair, check that the failure code is cleared by the following operation. Procedure: Turn the starting switch to ON position and display a Bird's Eye View		

No.	Cause	Procedure, measuring location, criteria and remarks		
1	Open circuit in wiring harness	1. Turn the starting switch to OFF position. 2. Disconnect the connectors CA01 and A77, and connect the T-adapter to each female side.		
		Resistance	Between CA01 (female) (25) and A77 (female) (1)	Max. 1 Ω
			Between CA01 (female) (23) and A77 (female) (2)	Max. 1 Ω
			Between CA01 (female) (42) and A77 (female) (4)	Max. 1 Ω
2	Ground fault in wiring harness	1. Turn the starting switch to OFF position. 2. Disconnect the connectors CA01 and A77, and connect the T-adapter to either female side.		
		Resistance	Between ground and either CA01 (female) (23) or A77 (female) (2)	Min. 1 M Ω
3	Hot short circuit in wiring harness	1. Turn the starting switch to OFF position. 2. Disconnect the connector A77, and connect the T-adapter to female side. 3. Turn the starting switch to ON position.		
		Voltage	Between A77 (female) (2) and (4)	Max. 9 V
			Between A77 (female) (4) and ground	Max. 9 V
4	Defective camera	1. Turn the starting switch to OFF position. 2. Replace the R.H. camera. 3. Turn the starting switch to ON position.		
		If failure code is not displayed, camera has internal defect.		
5	Defective KomVision controller	If no failure is found by above checks, KomVision controller is defective. (Since this is an internal defect, troubleshooting cannot be performed).		

Circuit Diagram Related to CO Cancel Solenoid



Circuit Diagram of Swing C/O Solenoid System




Failure Code [F311KA]

Detail of failure	The voltage of Centralized Warning Lamp Signal 1 Open Circuit signal output line from the gateway function controller is 3.83V or more and less than 5.67V while the command is OFF. So, an open circuit is found.
Action level	-
Action of controller	<ul style="list-style-type: none"> Does not turn ON the Centralized Warning Lamp Signal 1 Open Circuit signal. Even if the cause of the failure is removed, the machine does not go back to the correct state until the start switch is turned to the OFF position one time.
Phenomenon on machine	KOMTRAX system does not operate correctly.
Related information	


No.	Check item	Procedure of troubleshooting	Judgment and remedy	
1	Wiring harness, connector	<ol style="list-style-type: none"> Examine the wiring harnesses and connectors. For details, see "RELATED INFORMATION FOR TROUBLESHOOTING", "CHECKS BEFORE TROUBLESHOOTING", "Electrical Equipment". Are the wiring harness and connectors in the correct state? 	YES	<ul style="list-style-type: none"> The wiring harnesses and connectors are correct. Go to the next check item.
			NO	<ul style="list-style-type: none"> A wiring harness or a connector is defective. Repair or replace the defective wiring harness or connector. Go to "Confirmation of repair".
2	Open circuit in wiring harness	<ol style="list-style-type: none"> Turn the start switch to the OFF position. Disconnect the connectors CK05 and N08. Connect a T-adaptor to the female side of CK05 or the male side of N08. Measure the resistance. Does the troubleshooting result agree with the standard value? 	YES	<ul style="list-style-type: none"> Open circuit in wiring harness does not occur. Go to the next check item.
		Item		
		Resistance	Between CK05 (female) (66) and N08 (male) (5)	Max. 1Ω

No.	Check item	Procedure of troubleshooting	Judgment and remedy	
4	Confirmation of repair	1. Turn the starting switch to the OFF position. 2. Connect all the component parts. 3. Turn the starting switch to the ON position to troubleshoot. 4. Is this failure code shown?	YES	Go back to the first check item.
			NO	The repair is completed.

Circuit Diagram of Gateway Function Controller



Circuit Diagram of Engine Preheating




G0076371

E-25 When Auto-Decelerator Switch is Operated, Auto-Decelerator Monitor Does Not Come On or Does Not Go Out

Failure	When auto-deceleration switch is operated, auto-deceleration monitor does not light up or does not go off.	
Related information	<ul style="list-style-type: none">State of auto-deceleration switch signal can be checked with monitoring function. (Code: 04504)	
No.	Cause	Procedure, measuring location, criteria and remarks
1	Defective machine monitor	Machine monitor may be defective. (Because this is an internal defect, troubleshooting cannot be performed.)

Circuit Diagram of Horn



Troubleshooting for Hydraulic and Mechanical Systems (H Mode)

H-1 All Work Equipment, Swing and Travel Do Not Work

Failure	All of work equipment, travel, and turn do not work.
Related information	Perform all troubleshooting with working mode set in power mode (P).

No.	Cause	Procedure, measuring location, criteria and remarks		
1	Internal defect of PTO (main pump drive system)	Be ready with engine stopped, then perform the troubleshooting in that condition.		
		Disconnect the coupler for measuring the oil pressure of main pump, and turn the crankshaft. When the oil flows out the coupler hole, it is normal.		
2	Internal defect of PTO (control pump drive system)	Be ready with engine stopped, then perform the troubleshooting in that condition.		
		Disconnect the outlet hose of control pump, and turn the crankshaft. When the oil flows out the pump outlet, it is normal.		
3	Internal defect of control pump	Internal defect of control pump is suspected. Check if there is metallic powder, etc. in the pilot filter.		
4	Improper adjustment or malfunction of control relief valve	Be ready with engine stopped, then perform the troubleshooting with engine at high idle.		
		Control relief pressure	Control lever: All levers in NEUTRAL	3.14(+0.39/0) MPa {32(+4/0) kgf/cm ² }
		If the oil pressure is not normal after adjustment, perform the test on cause 5. If the test result is normal in check on cause 5, malfunction of control relief valve is suspected. Check it directly.		
5	Internal oil leakage of control system component	Be ready with engine stopped, then perform the troubleshooting with engine at high idle.		
		Control relief pressure	Control lever: All levers in NEUTRAL	3.14(+0.39/0) MPa {32(+4/0) kgf/cm ² }
6	Malfunction of PPC lock solenoid valve	Be ready with engine stopped, then perform the troubleshooting with engine at high idle.		
		Solenoid valve outlet pressure	When the work equipment lock lever is in FREE position	Min. 2.74 MPa {Min. 28 kgf/cm ² }
			When the work equipment lock lever is in LOCK position	0 MPa {0 kgf/cm ² }

H-26 Upper Structure Swings Only to Right or Left

Failure	Upper structure swing only to the right or left.
Related information	<ul style="list-style-type: none"> Perform all troubleshooting with working mode set in power mode (P). Left swing PPC pressure can be checked with monitoring function. (Code: 09001) Right swing PPC pressure can be checked with monitoring function. (Code: 09002)

No.	Cause	Procedure, measuring location, criteria and remarks	
1	Malfunction of swing PPC valve	Be ready with engine stopped, then perform the troubleshooting with engine at high idle.	
		PPC valve output pressure	When the L.H. work equipment control lever is moved in full stroke to swing LEFT and swing RIGHT Min. 2.74 MPa {Min. 28 kgf/cm ² }
2	Malfunction of control valve (spool)	If failure code still displays after above checks and upper structure does not swing when swing control lever is operated with pump pressure at approximately 4 MPa, spool may be stuck near NEUTRAL position.	
3	Defective seat of swing motor (suction valve)	Switch the suction valve of the right and left swing motors between each other and make judgment based on the changes in phenomena. Then, remove them and check stick, defect, etc. of the valves.	
4	Defective sealing of swing motor (check valve)	Switch the check valve of the right and left swing motors between each other and make judgment based on the changes in phenomena. Then, remove them and check stick, defect, etc. of the valves.	

S-13 Oil is in Coolant (or Coolant Spurts Back or Coolant

Failure	Oil is in coolant (or coolant spurts back or coolant level goes down)
Related information	If any failure code is displayed, perform troubleshooting for that code first.

No.	Cause	Point to check, remarks	Remedy
1	Engine oil is milky.	Engine oil is increasing and milky.	Perform troubleshooting of "WATER MIXES INTO ENGINE OIL (MILKY)" in S mode, and take corrective action.
2	Breakage of oil cooler element	Check oil cooler element.	Oil cooler element replacement
3	Breakage of cylinder head	<ul style="list-style-type: none"> There are many bubbles in radiator and coolant blows back. Disassemble engine and check cylinder head for abnormality by pressure test. 	Cylinder head replacement
4	Breakage of head gasket	<ul style="list-style-type: none"> Many bubbles and blow-back are found in radiator. Disassemble and inspect engine. Check cylinder head gasket for failure. 	Cylinder head gasket replacement
5	Cracking or hole caused by pitting in cylinder block	<ul style="list-style-type: none"> Engine oil is increasing and milky. Disassemble engine and check inside of cylinder block for cracking or hole caused by pitting. 	Cylinder block replacement

Molybdenum Disulfide Lubricant

Komatsu code	Part No.	Volume	Container	Main features and applications
LM-P	-	200 g	Tube	<ul style="list-style-type: none"> Use to prevent galling and seizure of press-fitting portions, shrink-fitted portions, and threaded portion. Use to lubricate linkages, bearings, etc.
LM-S	-	190 g	Container	<ul style="list-style-type: none"> Spray type Thin molybdenum disulfide films are made on metal surfaces to prevent the metals from galling. Use for drive shaft splines, needle bearings, various link pins, bolts, etc.


Seizure Prevention Compound

Komatsu code	Part No.	Volume	Container	Main features and applications
LC-G NEVER-SEEZ	-	-	Container	<ul style="list-style-type: none"> Feature: Seizure and galling prevention compound with metallic super-fine-grain, etc. Use for the mounting bolt in the high temperature area of the exhaust manifold and the turbocharger, etc.

Grease


Komatsu code	Part No.	Volume	Container	Main features and applications
G2-LI G0-LI (*) *: For cold regions	SYG2-400LI SYG2-350LI SYG2-400LI-A SYG2-160LI SYGA-160CNLI SYG0-400LI-A (*) SYG0-16CNLI (*)	Various	Various	<ul style="list-style-type: none"> Lithium grease with extreme pressure lubrication performance, general purpose type.
Grease that includes molybdenum disulfide LM-G (G2-M)	SYG2-400M SYG2-400M-A SYGA-16CNM	400 g×10 400 g×20 16 kg	Bellows-type container Container	<ul style="list-style-type: none"> Use for parts under heavy load. Caution: DO NOT use this grease for roller bearings, such as swing circle bearings, etc. or splines. Caution: Use this grease for work equipment pins only when installing them, but do not use it afterwards.
Hyper white grease G2-T G0-T (*) *: For cold regions	SYG2-400T-A SYG2-16CNT SYG0-400T-A (*) SYG0-16CNT (*)	400 g 16 kg	Bellows-type container Container	<ul style="list-style-type: none"> Higher seizure resistance, heat resistance, and waterproof than molybdenum disulfide grease Not conspicuous on machine since color is white.

11. Remove the bolts (10a), (10b), and (10c).
12. Remove the bolts (11) (4 pieces), and remove the bracket (12).



Tube, EGR oil tube

13. Disconnect the fuel tube (13).
14. Remove the bolts (4 pieces), and remove the fuel filter assembly (14).
15. Remove the dipstick pipe (15).
16. Disconnect the connectors PCV1 (16), PCV2 (17), and G (18).




Fuel high-pressure pipe

17. Remove the fuel spray prevention caps (19a), (19b), (20a), and (20b) of the fuel high-pressure pipes (19) and (20), loosen the sleeve nut, and disconnect the fuel high-pressure pipes (19) and (20).

REMARK


Loosen the sleeve nut on the common rail side, as well.

18. Disconnect the fuel tubes (21), (22), (23), and (24).
19. Disconnect the oil tubes (25) and (26).




Supply pump assembly

20. Remove the bolts (27) (4 pieces), and remove the supply pump assembly (28).



Hose, bracket


58. Loosen the clamp of the hose (76).
59. Remove the bolts (77) (2 pieces), and remove the bracket (78) together with the boost connector (79) as a unit.
60. Remove the coolant outlet connector bracket (80).




61. Remove KCCV outlet piping (80a).




62. Loosen the clamps of the hoses (80b) and (80c).
63. Remove the joint (80d), and remove the tubes (80e) and (80f).
64. Remove the joint (80g) and clamp (80h), and remove the tube (80j).
65. Remove the bolt, and remove the connector (80k).



66. Loosen the clamp of the hose (80m), remove the bolts (80n) (4 pieces), and then remove the connector (80p).


**Exhaust elbow**


67. Remove the bolts (81) (4 pieces), and remove the cover (82).
68. Remove the clip (1 place each), and remove the coolant tubes (83), (84), (85), and (86).
69. Remove the clip (1 place), and remove VGT lubrication oil tube (87).
70. Remove the bolts (88) (4 pieces), and remove the cover (89).
71. Remove the bolts (90) (6 pieces), and remove the heat insulation cover (91).



EGR cooler assembly

- 23. Remove the bolts (39) (2 pieces), and remove the coolant return tube (40).
- 24. Remove the bolts (41) (2 pieces), and remove the coolant supply tube (42).
- 25. Remove the bolts (43) (4 pieces), sling EGR cooler assembly (44), and remove it.


 EGR cooler assembly (44):
80 kg



How to Install EGR Cooler Assembly

EGR cooler assembly

- 1. Sling the EGR cooler assembly (44), hold it, and tighten the bolts (43) (4 pieces).

 EGR cooler assembly (44):
80 kg

- 2. Install the coolant supply tube (42) with the bolts (41) (2 pieces).


REMARK

Replace the gasket to be installed to the coolant tube flange surface with a new one.

- 3. Install the coolant return tube (40) with the bolts (39) (2 pieces).


REMARK

Replace the gasket to be installed to the coolant tube flange surface with a new one.





Tube

- 4. Connect the coolant tube (38), and install the clamp (36) and joint bolt (37).

 Joint bolt (37):
24.5 to 34.3 Nm {2.5 to 3.5 kgfm}

- 5. Connect the coolant tube (35), and install the clamps (33) (2 places) and joint bolt (34).

 Joint bolt (34):
19.6 to 29.6 Nm {2 to 3 kgfm}




Bracket


- 6. Install the bracket (31) with the bolts (30) (3 pieces).

REMARK

1 place of bolt (30) of bracket (31) is tightened together with spacer (32).


 Bolt (30) of bracket (31) (exhaust elbow mount bracket side):
Seizure prevention compound

- 7. Install the bracket (29) with the bolts (28) (4 pieces).




R.H. engine hood


3. Remove the bolts (4) (6 pieces), and remove the cover (5).




4. Remove the bolts (6) (9 pieces), and remove the cover (7).




5. Remove the bolts (8) (14 pieces), and remove the covers (9) (2 places).




6. Remove U-bolts (10) (2 places).




7. Open the cover (11).




4. Connect the hoses (71) (3 pieces).
5. Connect the air conditioner hoses (70) (2 pieces).




6. Connect the connectors P44 (66), M37 (67), CE03 (69), and ground cable T12 (68).
7. Install the clamps (65) (5 places).




8. Install the undercover (64) with the bolts (63) (5 pieces).




9. Remove the fan guard (82) with the bolts (81) (2 pieces).




10. Connect the hoses (62) (2 pieces).
11. Install the hose (61) and MIKALOR clamps (60) (4 places) according to the following procedure.




15. Connect the connector P24 (21) on the under surface of the reservoir tank.




16. Install the clamp (18) and clips (19) (2 places), and connect the hoses (20) (2 pieces).




17. Install the engine oil filter (17) with the bolts (16) (6 pieces).





18. Close the cover (15).




19. Install the clamp (14) with the bolts (13) (2 pieces).




- 7) Check that the convex part (i) of the boot (6) is securely set in the convex part (m) of the sensor body.



- 8) Check that the sensor is set in the tip part (j) by moving the tip part (j) of the boot (4) by hand.



- 9) Check that the opening (n) of the boot top is 2.5 mm or below .




9. Temporarily assemble the differential pressure sensor Lo piping (26), differential pressure sensor Hi piping (27), and clamps (18), (19), and (20) (3 places).
10. Install the piping connectors (22) and (23) to the differential pressure sensor (21).

REMARK

Check that "locking" sound is heard when the piping connectors (22) and (23) are inserted.

11. Position the differential pressure sensor Lo piping (26) and differential pressure sensor High piping (27), and check that they are not unnecessarily stressed.
12. Tighten the band (29) to the specified torque.

 Band (29) mounting bolt:
6.3 to 8.3 Nm {0.64 to 0.85 kgfm}


NOTICE

The band (29) is made of stainless steel, accordingly never use an impact wrench.

REMARK

Mounting nut (width across flats) of band (29): 11.1 mm {7/16 in}


13. Tighten the nut (24) of the differential pressure sensor Lo piping to the specified torque.

 Nut (24):
13.6 to 19.0 Nm {1.39 to 1.94 kgfm}

REMARK

Nut (24) (width across flats): 15.88 mm {5/8 in}


14. Tighten the nut (25) of the differential pressure sensor Hi piping to the specified torque.


 Nut (25):
24.5 to 36.5 Nm {2.5 to 3.7 kgfm}

REMARK

Nut (25) (width across flats): 17.46 mm {11/16 in}



15. Tighten the clamps (18), (19), (20) to the specified torque.

 Mounting bolts of clamps (18) and (20):
10.8 to 26.0 Nm {1.1 to 2.7 kgfm}


 Clamp (19) mounting bolt:
11.8 to 14.7 Nm {1.2 to 1.5 kgfm}

REMARK


- Mounting bolts (width across flats) of clamps (18) and (20) 14 mm
- Mounting bolt (width across flats) of clamp (19) 10 mm




- Remove the bolts (5) (5 pieces), and remove the partition plate (6).



- Remove the bolts (7) (8 pieces), and remove the partition plates (8) (2 places).




- Install the restraint jig (A) to the bellows pipe (9) with the nuts (10) (4 pieces).


 Nut (10):
14.8 Nm {1.5 kgfm}

NOTICE


Installation of the restraint jig (A) is not required when exchanging the bellows pipe (9) with a new one.



- Remove the nuts (12) (2 pieces), and remove U-bolt (11).




- Remove the nuts (14) (2 pieces), and remove U-bolt (13).



2. Install DEF injector (7) according to the following procedure.

1) Apply seizure prevention compound to the bolt (6).

 Threaded portion of bolt (6):
Seizure prevention compound (LC-G)

2) Temporarily assemble the gasket (8) and bolts (6) (3 pieces) to DEF injector (7), and install them to DEF mixing tube (9).


NOTICE

Use a new gasket.


REMARK

Before tightening the bolts (6), install them so that no clearance is created between the gasket (8) and DEF mixing tube (9) and between the gasket (8) and DEF injector (7).

3) Tighten the bolt (6) in the order of a, b, and c.

 Bolt (6):
7±1 Nm {0.7±0.1 kgfm}

4) Tighten the bolt (6) again in the order of a, b, and c.

 Bolt (6):
7±1 Nm {0.7±0.1 kgfm}






NOTICE

- After tightening the bolts (6) to the specified torque, tighten all the bolts to the specified torque again.
- Be careful not to damage DEF inlet and the coolant inlet/outlet connector parts by hitting them to the parts around them, etc.

Hose, connector

3. Connect the connector MB03 (5) according to the following procedure.

1) Remove the connector cover (F).



Remove and Install Air Conditioner Condenser Assembly

- ⚠ Place the machine on a level ground, lower the work equipment completely to the ground in a stable posture, set the lock lever to LOCK position, and then stop the engine.
- ⚠ Stop the engine, and turn the battery isolator switch to OFF position. (For details, see Testing and Adjusting, “Handle Battery Isolator Switch”.)
- ⚠ If refrigerant gas (air conditioner gas: R134a) gets in your eyes, you may lose your sight. And if it touches your skin, you may suffer from frostbite. Put on protective eyeglasses, gloves, and working clothes with long sleeves while collecting the refrigerant or filling the air conditioner circuit with the refrigerant.

NOTICE

- Never release the refrigerant (air conditioner gas: R134a) to the atmosphere.
- Ask a qualified person for collecting, adding and filling operations of the refrigerant. (Only qualified persons can work.)


How to Remove Air Conditioner Condenser Assembly

Collecting the refrigerant

1. Collect the refrigerant (air conditioner gas: R134a) from the air conditioner circuit.
Quantity of refrigerant to be collected: 1150±50 g

Cover

2. Remove the bolts (1) (7 pieces), and open the cover (2).




Air conditioner condenser assembly

3. Remove the bolts (3) (2 pieces), and disconnect the air conditioner hoses (4) (2 pieces).

NOTICE


- Plug the hose to prevent dust and water from entering.
- Be careful not to damage or lose O-ring.



4. Remove the bolts (5) (4 pieces), and remove the air conditioner condenser assembly (6).

NOTICE

When removing, take care not to damage the core part.



Refilling with hydraulic oil

12. Refill the hydraulic tank with Komatsu genuine oil to the specified level through the oil filler port. Start the engine to circulate the oil through the piping, and check the oil level again. (For details, see Structure and Function, "Table of Fuel, Coolant, and Lubricants".)

Bleeding air from hydraulic circuit

13. Bleed air from the hydraulic pump circuit. (For details, see Testing and Adjusting, "Bleed Air from Hydraulic System".)

How to Install Idler and Idler Cushion Assembly

Idler and idler cushion assembly

1. Install the idler cushion assembly (4) to the idler assembly (3).



Idler assembly (3):

350 kg



Idler cushion assembly (4):

460 kg



Mounting bolt:

824 to 1030 Nm {84 to 105 kgfm}

2. While slinging the idler and idler cushion assembly (2), install it to the track frame.



NOTICE

Be careful when slinging the idler and idler cushion assembly (4). It slants when it is slung at the slinging position, since the center of gravity of the idler cushion assembly (4) is at the rear.




Idler and idler cushion assembly (2):

800 kg



Track shoe assembly

3. Install the lubricator (1).
4. Install the track shoe assembly. See "Separate and Connect Track Assembly".




Suction tube, connector

3. Connect the suction tube (25).


REMARK

Do not remove MIKALOR clamp of the suction hose (SH).


- If the hose is disconnected, see “Remove and Install Hydraulic Pump Assembly”, INSTALL SUCTION HOSE (SH).




4. Connect the hoses (16), (17), (18), (19), (20), (21), and (22) from the rear of the hydraulic tank (27).



5. Install the overflow hose clamp (15).
6. Connect the hoses (9), (10), (11), (12), (13), and (14) from the rear inside of the hydraulic tank (27).
7. Install the undercover.



8. Install the hoses (5), (6), (7), and (8) from under the hydraulic oil filter (F).



Remove and Install Arm Cylinder Assembly

Tools for Removal and Installation of the Arm Cylinder Assembly

Symbol	Part No.	Part name	Necessity	Q'ty	New/Redesign	Sketch	Remarks
A	Commercially available	Puller	■	1			Removal and installation of arm cylinder assembly
B	Commercially available	Block	●	1			

⚠ **Extend the arm cylinder piston rod to approximately 200 mm before the arm IN stroke end, lower the work equipment to the ground in a stable posture, and set the lock lever to LOCK position, and then stop the engine.**

⚠ **Stop the engine, turn the battery isolator switch to OFF position. (For details, see Testing and Adjusting, "Handle Battery Isolator Switch".)**

⚠ **Release the remaining pressure in the hydraulic circuit. See Testing and Adjusting, "Release Remained Pressure in Hydraulic Circuit".**

⚠ **Never insert your fingers into the pin holes when aligning their positions.**

NOTICE

Install a plug or flange in the place where a hydraulic hose is disconnected to prevent oil from flowing out.

How to Remove Arm Cylinder Assembly

Pin on the head side



1. Set the block (B) between the arm cylinder and boom.
2. Disconnect the lubrication hose (1).
3. Pull out the pin (2) on the head side.

REMARK

If the pin on the head side cannot be pulled out, use the puller (A) to pull out the pin.




Pin (2):
35 kg



Arm cylinder assembly

4. Start the engine, retract the piston rod, and tie the piston rod by using a wire, etc. so that it is not pulled out.
5. Disconnect the hose (3).


5. Remove the wiring harness (4) through the space between the cover (5) and duct (6).




6. Remove the bolts (5 pieces), and lift the box (7).




7. Disconnect the hose (8), and remove the box (7).




8. Remove the bolts (3 pieces), and lift the box (9).



9. Disconnect the connectors M13A (10) and M13B (11), and remove the box (9).




6. A return load of 58.8 N {6 kg} is applied to the pull-up assist cable (10) in the direction of the rear side of the operator's cab. When disconnecting the cable, remove the pin (9) with extreme care.



REMARK


- When the pin (9) is removed, the plate (11) at the tip of the pull-up assist cable (10) is removed.
- Place the plate (11) on the mounting screw (5) (also using washer (6)) of the L.H. corner bracket (3), and fix it.



7. Lower the front window assembly (1) completely with extreme care to prevent the front window assembly (1) from contacting with the machine monitor (12).



8. Carefully slide the front window assembly (1), bring out the upper part of the front window assembly (1) downward from the bracket removal areas (rail opening areas) at the R.H. and L.H. corners where the brackets were removed in step 2.



How to Install Operator Seat

Operator's seat

1. Install the operator's seat (2).




Operator's seat (2):

25 kg

REMARK

Since the crane cannot be used, install the operator's seat (2) by 2 persons.



2. Connect the connector M35 (9), and bind the cable tie (8).





3. Connect the connector S19 (6).
4. Install the bolts (5) (2 pieces) and reinforcing plates (7) (2 pieces).



Bolt (5):

25.5 Nm {2.6 kgfm}






- 1) Press wiper switch (37) 3 times continuously, and check that wiper arm (27) swings one round-trip, and then is stored in the part (e) of the R.H. stay.
- 2) Perform the step 1) again.

NOTICE

Between the steps 1) and 2), the rotation direction of the motor crank is different. Therefore, check the operation 2 times.

- 3) When the tip of the wiper blade (35) is at the highest position by pressing the wiper switch (37), check that the clearance (b) between the trim seal (38) and wiper is the following dimension.


Dimension (b): 130 mm or less




6. Remove the bolts (11) (2 pieces), and remove SCR temperature sensor (12).


REMARK

Bolt (11) (width across flats): 10 mm

**How to Install SCR Temperature Sensor****SCR temperature sensor**


1. Install SCR temperature sensor (12) with the bolts (11) (2 pieces).

 Bolt (11):
11.8 to 14.7 Nm {1.2 to 1.5 kgfm}


 Threaded portion of bolt (11):
Seizure prevention compound (LC-G)


REMARK

Bolt (11) (width across flats): 10 mm





2. Insert the metal portions (a) of SCR outlet temperature sensor (9) and SCR inlet temperature sensor (10) straight in the direction of the arrow, and tighten the nuts (7) and (8).

 Nut (7):
35 to 41 Nm {3.6 to 4.2 kgfm}

 Nut (8):
22 to 28 Nm {2.2 to 2.8 kgfm}


REMARK

- SCR outlet temperature sensor (9) mounting nut (width across flats) 17 mm
- SCR inlet temperature sensor (10) mounting nut (width across flats) 17 mm




29. Cut the bands (34) (2 pieces).

Tool: Nippers




30. Remove the gateway controller wiring harness (35).




Reference: How to Remove Connector Cover (1)


1. Cut the band (2).
2. Move the lever (3) upward.



3. Lightly press the part (A) on both sides of the connector cover (1) to release the claw (B).
4. Remove the connector cover (1) around the claw (C) along the arc line.




Maintenance Standard for Sprocket



Unit: mm

No.	Item	Judgment criteria		Remedy
		Standard dimensions	Repair limit	
1	Wear of tooth tip	350.1	338.1	Repair by build-up welding or replace
2	Thickness of tooth bottom	24.4	18.4	
3	Width of tooth	104	101.5	
4	Wear of tooth profile	Repair limit: 6 (Use "Full-scale drawing of sprocket profile" for judgment)		


Maintenance Standard for Variable Back Pressure Valve



A4P17976

Unit: mm

No.	Item	Judgment criteria					Remedy
		Free height	Installed height	Load at installed height	Free height	Load at installed height	
1	Valve return spring	165.8 x 38.5	133	785 kN {80 kg}	-	628 kN {64 kg}	Replace the spring if damaged or deformed



A: Front vents

B: Rear vents

C: Foot vents

1: Compressor

2: Condenser

3: Receiver drier

4: Hot water piping

5: Hot water return piping

6: Refrigerant piping

7: Dual pressure switch

D: Defroster vents

E: Recirculation air inlet

F: Fresh air inlet

8: Sight glass

9: Air conditioner controller

10: Air conditioner unit

11: Recirculation air filter

12: Fresh air filter

13: Machine monitor


14: Sunlight sensor

AC03: Air conditioner compressor connector




Connector Layout of Outside Temperature Sensor

P18: Outside air temperature sensor connector



Circuit Diagram Related to Refrigerant (Dual) Pressure Switch




Electrical Circuit Diagram (11/12) (Machine with KOMTRAX Terminal) (Oceania Spec)

PC700LC-11

REMARK


This figure covers the equipment and devices that are unavailable as optional items in some areas.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P



(FROM 10/12) ①

(FROM 9/12) ②



(FROM 10/12) ③

(FROM 9/12) ④

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL