

SHOP MANUAL

PC95R-2

HYDRAULIC EXCAVATOR

SERIAL NUMBER

PC95R-2 21D5210001 and up

PC95R-2 21D5220001 and up



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL


- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

HOISTING INSTRUCTIONS




⚠ Heavy parts (25 kg or more) must be lifted with a hoist etc. In the **Disassembly and Assembly** section, every part weighing 25 kg or more is clearly indicated with the symbol .

1. If a part cannot be smoothly removed from the machine by hoisting, the following checks should be made:
 - Check for removal of all bolts fastening the part to the relative parts.
 - Check for any part causing interference with the part to be removed.
2. **Wire ropes**
 - 1) Use adequate ropes depending on the weight of parts to be hoisted, referring to the table below:

| WIRE ROPES (Standard «S» or «Z» twist ropes without galvanizing) | |
|--|-----------------------|
| Rope diameter (mm) | Allowable load (tons) |
| 10.0 | 1.0 |
| 11.2 | 1.4 |
| 12.5 | 1.6 |
| 14.0 | 2.2 |
| 16.0 | 2.8 |
| 18.0 | 3.6 |
| 20.0 | 4.4 |
| 22.4 | 5.6 |
| 30.0 | 10.0 |
| 40.0 | 18.0 |
| 50.0 | 28.0 |
| 60.0 | 40.0 |

The allowable load value is estimated to be one-sixth or one-seventh of the breaking strength of the rope used.

- 2) Sling wire ropes from the middle portion of the hook. Slinging near the edge of the hook may cause the rope to slip off the hook during hoisting, and a serious accident can result.



- 3) Do not sling a heavy load with one rope alone, but sling with two or more ropes symmetrically wound on to the load.

⚠ Slinging with one rope may cause turning of the load during hoisting, untwisting of the rope, or slipping of the rope from its original winding position on the load, which can cause dangerous accidents.

- 4) Do not sling a heavy load with ropes forming a wide hanging angle from the hook.


When hoisting a load with two or more ropes, the force subjected to each rope will increase with the hanging angles.

The table below shows the variation of allowable load (kg) when hoisting is made with two ropes, each of which is allowed to sling up to 1000 kg vertically, at various hanging angles.

When two ropes sling a load vertically, up to 2000 kg of total weight can be suspended.

This weight becomes 1000 kg when two ropes make a 120° hanging angle.

On the other hand, two ropes are subjected to an excessive force as large as 4000 kg if they sling a 2000 kg load at a lifting angle of 150°



From liter to U.S. Gall.

1 ℓ = 0.2642 U.S. Gall.



| | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 |
|----|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|
| 0 | 0 | 0.264 | 0.528 | 0.793 | 1.057 | 1.321 | 1.585 | 1.849 | 2.113 | 2.378 |
| 10 | 2.642 | 2.906 | 3.170 | 3.434 | 3.698 | 3.963 | 4.227 | 4.491 | 4.755 | 5.019 |
| 20 | 5.283 | 5.548 | 5.812 | 6.076 | 6.340 | 6.604 | 6.869 | 7.133 | 7.397 | 7.661 |
| 30 | 7.925 | 8.189 | 8.454 | 8.718 | 8.982 | 9.246 | 9.510 | 9.774 | 10.039 | 10.303 |
| 40 | 10.567 | 10.831 | 11.095 | 11.359 | 11.624 | 11.888 | 12.152 | 12.416 | 12.680 | 12.944 |
| 50 | 13.209 | 13.473 | 13.737 | 14.001 | 14.265 | 14.529 | 14.795 | 15.058 | 15.322 | 15.586 |
| 60 | 15.850 | 16.115 | 16.379 | 16.643 | 16.907 | 17.171 | 17.435 | 17.700 | 17.964 | 18.228 |
| 70 | 18.492 | 18.756 | 19.020 | 19.285 | 19.549 | 19.813 | 20.077 | 20.341 | 20.605 | 20.870 |
| 80 | 21.134 | 21.398 | 21.662 | 21.926 | 22.190 | 22.455 | 22.719 | 22.983 | 23.247 | 23.511 |
| 90 | 23.775 | 24.040 | 24.304 | 24.568 | 24.832 | 25.096 | 25.361 | 25.625 | 25.889 | 26.153 |

From liter to U.K. Gall.

1 ℓ = 0.21997 U.K. Gall.

| | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 |
|----|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|
| 0 | 0 | 0.220 | 0.440 | 0.660 | 0.880 | 1.100 | 1.320 | 1.540 | 1.760 | 1.980 |
| 10 | 2.200 | 2.420 | 2.640 | 2.860 | 3.080 | 3.300 | 3.520 | 3.740 | 3.950 | 4.179 |
| 20 | 4.399 | 4.619 | 4.839 | 5.059 | 5.279 | 5.499 | 5.719 | 5.939 | 6.159 | 6.379 |
| 30 | 6.599 | 6.819 | 7.039 | 7.259 | 7.479 | 7.699 | 7.919 | 8.139 | 8.359 | 8.579 |
| 40 | 8.799 | 9.019 | 9.239 | 9.459 | 9.679 | 9.899 | 10.119 | 10.339 | 10.559 | 10.778 |
| 50 | 10.998 | 11.281 | 11.438 | 11.658 | 11.878 | 12.098 | 12.318 | 12.528 | 12.758 | 12.978 |
| 60 | 13.198 | 13.418 | 13.638 | 13.858 | 14.078 | 14.298 | 14.518 | 14.738 | 14.958 | 15.178 |
| 70 | 15.398 | 15.618 | 15.838 | 16.058 | 16.278 | 16.498 | 16.718 | 16.938 | 17.158 | 17.378 |
| 80 | 17.598 | 17.818 | 18.037 | 12.257 | 18.477 | 18.697 | 18.917 | 19.137 | 19.357 | 19.577 |
| 90 | 19.797 | 20.017 | 20.237 | 20.457 | 20.677 | 20.897 | 21.117 | 21.337 | 21.557 | 21.777 |


TRACK FRAME



RKP10790

- | | |
|-------------------|-------------------|
| 1. Idler | 5. Track roller |
| 2. Track frame | 6. Track shoe |
| 3. Carrier roller | 7. Guard |
| 4. Sprocket | 8. Final drive |
| 5. Track roller | 9. Idler cushion |
| | 10. Recoil spring |

HYDRAULIC DIAGRAM WITH 2-PIECE BOOM



RKP12371

**PAGE INTENTIONALLY
LEFT BLANK**

a) Action of PC-EPC solenoid


- The command current from resistor flows to **PC-EPC** solenoid (1).
This command current acts on the **PC-EPC** valve and outputs the signal pressure.
When this signal pressure is received, the force pushing piston (2) is changed.
- On the opposite side to this force pushing piston (2) is the spring set pressure of springs (4) and (6) and pump pressure **PP** pushing spool (3). Spool (3) stops at a position where the combined force pushing spool (3) is balanced, and the pressure (pressure of port **C**) output from the **CP** valve.

| | | |
|-----|-----------|--|
| a. | P1 Port | - From servocontrol feed unit (P2 Port) and pump (PPLS Port) |
| b. | P2 Port | - From gear pump (PGA Port) |
| c. | A1 Port | - To swing motor (MA Port) |
| d. | B1 Port | - To swing motor (MB Port) |
| e. | A2 Port | - To swivel joint (5A Port) |
| f. | B2 Port | - To swivel joint (3A Port) |
| g. | A3 Port | - To swivel joint (8A Port) |
| h. | B3 Port | - To swivel joint (6A Port) |
| i. | A4 Port | - To swivel joint (9A Port) |
| j. | B4 Port | - To swivel joint (7A Port) |
| k. | A5 Port | - To boom cylinder (Bottom side) |
| l. | B5 Port | - To boom cylinder (Head side) |
| m. | A6 Port | - To arm cylinder (Head side) |
| n. | B6 Port | - To arm cylinder (Bottom side) |
| o. | A7 Port | - To bucket cylinder (Head side) |
| p. | B7 Port | - To bucket cylinder (Bottom side) |
| q. | A8 Port | - To boom swing cylinder (Head side) |
| r. | B8 Port | - To boom swing cylinder (Bottom side) |
| s. | A9 Port | - To optional attachment (L.H. side) |
| t. | B9 Port | - To optional attachment (R.H. side) |
| u. | TSW Port | - To swing motor (S1 Port) |
| v. | TC Port | - To oil cooler |
| x. | TB Port | - To hydraulic tank |
| y. | A10 Port | - To 2-piece boom cylinder (Head side) |
| w. | B10 Port | - To 2-piece boom cylinder (Bottom side) |
| xx. | TS Port | - To hydraulic tank |
| aa. | PLS Port | - To hydraulic pump (PLS Port) |
| Pa. | PA1 Port | - From L.H. PPC valve (P2 Port) |
| Pb. | PB1 Port | - From L.H. PPC valve (P4 Port) |
| Pc. | PA2 Port | - From blade PPC valve (P1 Port) |
| Pd. | PB2 Port | - From blade PPC valve (P2 Port) |
| Pe. | PA3 Port | - From travel PPC valve (P2 Port) |
| Pf. | PB3 Port | - From travel PPC valve (P1 Port) |
| Pg. | PA4 Port | - From travel PPC valve (P3 Port) |
| Ph. | PB4 Port | - From travel PPC valve (P4 Port) |
| Pi. | PA5 Port | - From R.H. PPC valve (P4 Port) |
| Pj. | PB5 Port | - From R.H. PPC valve (P2 Port) |
| Pk. | PA6 Port | - From L.H. PPC valve (P3 Port) |
| Pl. | PB6 Port | - From L.H. PPC valve (P1 Port) |
| Pm. | PA7 Port | - From R.H. PPC valve (P3 Port) |
| Pn. | PB7 Port | - From R.H. PPC valve (P1 Port) |
| Po. | PA8 Port | - From boom swing PPC valve (P1 Port) |
| Pp. | PB8 Port | - From boom swing PPC valve (P2 Port) |
| Pq. | PA9 Port | - From OP1 solenoid valve group (B Port) |
| Pr. | PB9 Port | - From OP1 solenoid valve group (A Port) |
| Ps. | PDB Port | - From R.H. PPC valve (P4 Port) |
| Pt. | PA10 Port | - From 2-piece boom PPC valve (P2 Port) |
| Pu. | PB10 Port | - From 2-piece boom PPC valve (P1 Port) |


FUNCTION PRINCIPLE

1. Control of pump swash plate angle

- The pump swash plate angle (pump discharge amount) is so controlled that the **LS differential pressure ΔPLS** , which is the difference between the pump discharge pressure **PP** and the **LS pressure PLS** at the outlet Port of the control valve (actuator load pressure), is maintained at a constant level.
(**LS differential pressure ΔPLS = Pump discharge pressure **PP** – **LS pressure PLS**).**
- If the **LS differential pressure ΔPLS** becomes lower than the setting pressure of the **LS valve**, the pump swash plate angle becomes larger, and if it becomes higher, the pump swash plate angle becomes smaller.
- ★ For the details of this action, refer to the descriptions of "HYDRAULIC PUMP"..



RKP02921



RKP02931


Area ratio of pressure compensation valve

FUNCTION

- The pressure compensation valve determines the compensation characteristics by carrying out fine adjustment of the area ratio ($S1/S2$) between the area $S1$ of the flow control valve (2) side and the area $S2$ of the pressure reducing valve (1) side to match the characteristics of each actuator.

$S1$ = Area of the flow control valve (2) – Area of the piston (3)

$S2$ = Area of the pressure reducing valve (1) – Area of the piston (3).



RKP03030


Area ratio ($S1/S2$) and compensation characteristics

- When the ratio is 1.00 :
 $[Pump\ pressure\ PP - Upstream\ pressure\ of\ the\ spool\ notch\ PPB] = [LS\ circuit\ pressure\ PLS - Actuator\ circuit\ pressure\ PA (=A)]$
 Thus, the flow is distributed in proportion of opening areas of the spool.
- When the ratio is larger than 1.00 : $PP - PPB > PLS - PA (=A)$
 Thus, the flow is divided less than the proportion of opening areas of the spool.
- When the ratio is smaller than 1.00 : $PP - PPB < PLS - PA$
 Thus, the flow is divided more than the proportion of opening areas of the spool.

OPERATION OF THE MODULATING RELIEF VALVE

FUNCTION

- The relief valve for the swing motor has the properties to suppress the rapid increase of the relief pressure as per shown in the figure right, and serves to reduce the shock at the time of start and stop of swing.




OPERATION



When the circuit pressure is P0

- The relief valve does not operate.

When the circuit pressure has rapidly increased

- When the circuit pressure increases to **P1**, the valve (3) starts to open because the oil pressure acts on the difference in area between **D1** and **D3** ($D1 > D3$), thus pressing the spring (4).
On this occasion, the seat (1) tries to follow the valve (3) because the pressure acts on the difference in area between **D1** and **D2** ($D1 < D2$).
However, the route that the oil in the chamber **a** compressed by the movement of the seat (1) can flow to the **S** port has been throttled by the ball (2), so that the movement of the seat (1) is slower than that of the valve (3).
Therefore, during the time **T** until the seat (1) makes contact with the sleeve (5), the relief pressure gradually increases from **P1** to **P2**.






RKP03971

- 1. Hydraulic pump
- 2. Valve
- 3. Spring
- 4. Screw
- 5. Poppet
- 6. Spring (reducing valve pilot)
- 7. Spring (reducing valve)
- 8. Spool (reducing valve)
- 9. Spring (safety valve)
- 10. Ball
- 11. Filter

BLADE PPC VALVE




View Z

RKP12241

- a. T Port - To hydraulic tank
- b. P Port - From solenoid valve group (A Port)
- c. P1 Port - To control valve (PA2 Port)
- d. P2 Port - To control valve (PB2 Port)

SOLENOID VALVES

SOLENOID VALVE GROUP ST1




RKP12380

- | | | |
|-----------|---|------------------------------|
| a. P Port | - From servocontrol feed unit (PR Port) | 1. Y4 Travel speed increment |
| b. B Port | - To swivel joint (2A Port) | 2. Y7 Servocontrol |
| c. A Port | - To servocontrol | |
| d. T Port | - To hydraulic tank | |

ELECTRICAL DIAGRAM (4/5)

| | | | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|

STRUMENTO MULTIFUNZIONALE MULTIFUNCTION



X6





| PIN | FUNZIONE CONNESSA | COMANDO | COLORE FILO |
|-----|---|----------|-------------|
| 1 | COMUNE SPIE LENTA/VELOCE COMMON W/L SLOW/FAST GEAR | NEGATIVO | |
| 2 | STRUMENTO IND. LIV. CARB. FUEL LEVEL GAUGE | ohm | |
| 3 | STRUMENTO TEMPERATURA COOLANT TEMP. GAUGE | ohm | |
| 4 | SEGNALE DI START START SIGNAL | +50 | |
| 5 | | | |
| 6 | MASSA GROUND | GND | |
| 7 | SPIA PALA-STABILIZZATORI (giallo) W/L SHOVEL-STABILIZER (yellow) | NEGATIVO | |
| 8 | POSITIVO ALIMENTAZIONE (+12V) POWER SUPPLY (+12V) | +15 | |
| 9 | ILLUMINAZIONE NOTTURNA NIGHTLIGHT | +LUCI | |
| 10 | USCITA BUZZER BUZZER O/P | NEGATIVO | |
| 11 | SPIA AVARIA FRENI (rosso) W/L BRAKE SYSTEM FAILURE (red) | NEGATIVO | |
| 12 | SPIA PRERISCALDO (giallo) W/L PREHEAT (yellow) | POSITIVO | |
| 13 | SPIA BLOCCAGGIO PONTE (giallo) W/L AXLE BLOCKED (yellow) | NEGATIVO | |
| 14 | SPIA FILTRO ARIA (rosso) W/L AIR FILTER (red) | NEGATIVO | |
| 15 | SPIA GENERATORE (rosso) W/L CHARGE (red) | NEGATIVO | |
| 16 | SPIA PRESS. OLIO MOTORE (rosso) W/L ENGINE OIL PRESS. (red) | NEGATIVO | |

| | | | | | | | |
|---|----|----|----|----|----|----|----|
| 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 |
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |

LATO FILI
WIRE SIDE VIEW

RKP11650

FOR MACHINE

| Machine model | | | | PC95R-2 | | |
|---------------------|---|--|----------|---|---|--------------------|
| Classifi- cation | Check item | Test conditions | Unit | Standard value | Permissible value | |
| Travel | Travel motor swing speed (1) (no-load) | <p>Measuring posture</p>  <ul style="list-style-type: none"> Working Mode: P position Engine speed: high idling Oil temperature: 45–55 °C Rest the bucket on the ground, raise one track-shoe and mark a position on the reduction unit. Measure the rotating speed of the sprocket wheel. Repeat for the 2nd track-shoe. | rpm | Normal | $36 \begin{smallmatrix} - & 4 \\ + & 2 \end{smallmatrix}$ | 30÷40 |
| | | | | With increment | $55 \begin{smallmatrix} - & 6 \\ + & 3 \end{smallmatrix}$ | 46÷60 |
| | Travel speed (2) | <p>Measuring posture</p>  <ul style="list-style-type: none"> Engine speed: high idling Oil temperature: 45–55 °C On flat ground Travel for at least 10 metres and then check on the time needed to cover 20 metres. | sec. | Normal | $23.2 \begin{smallmatrix} - & 1.7 \\ + & 0.8 \end{smallmatrix}$ | Max. 26 Min. 20 |
| With increment | | | | $15.0 \begin{smallmatrix} - & 1 \\ + & 0.7 \end{smallmatrix}$ | Max. 17 Min. 13 | |
| Travel deviation |  <ul style="list-style-type: none"> Working Mode: P position Engine speed: high idling Oil temperature: 45–55 °C Travel 20 metres on flat ground and measure the deviation. ★ The surface must be hard and horizontal  <ul style="list-style-type: none"> ★ Measure dimension «X» | mm | Max. 200 | Max. 300 | | |

MEASURING THE ENGINE SPEED

! When measuring the speed (rpm) of the engine, do not touch heated parts and take care not to become entangled in rotating elements.

★ Do not start to measure engine speed until the following conditions have been met:

- Engine cooling water temperature: 68–80°C
- Hydraulic system oil temperature: 45–55°C.


1 - Install and connect the tachometer **C1**.

★ If a stroboscopic tachometer **C2** is used, make a distinct mark on the motor pulley to facilitate the reading.



2 - Start the engine and check:

- Low idling without load (accelerator lever in «minimum» position).
- High idling without load (accelerator lever in «maximum» position).
 - ★ Low idling: 1100±50 rpm
 - ★ High idling: 2400±50 rpm
- ★ If the minimum and maximum engine speeds without load do not fall within the correct range, check the position stops of the accelerator lever and the accelerator cable sheathing (See «ACCELERATOR LEVER ADJUSTMENT») before performing the stress tests.
- Engine rpm with the pumps working.
 - ★ Max. speed with the **P1** pump working: 2150_{-50}^{+150} rpm
 - ★ Max. speed with the **P1** and **P2** pumps working: 2100_{-50}^{+200} rpm
- ★ If the efficiency is not within the permissible limits, call the Authorised Repair Shop to come and give the engine a diagnostic check.




TESTING AND ADJUSTING TRACK-SHOE TENSION

1. Test

★ Test conditions:


- Firm, flat ground.
- Work equipment resting on the ground.

- 1 - Swing the turret 90° to the side of the track to be tested.
- 2 - Close the bucket, position the arm perpendicular to the ground and rest the bucket on the ground.
- 3 - Push down with the boom until the track-shoe to be tested has been raised completely from the ground.



- 4 - Measure the distance between the track-shoe race and the central track rollers.

- ★ Measure «A» between track roller and track-shoe: 20–25 mm




2. Adjustment

If track-shoe tension is not within permissible limits, adjust them as follows.

- ★ Before introducing the grease-pump (2), and on completion of the adjustment, thoroughly clean the grease nipple and the surrounding area.


- 1 - If the tension is too slack.
Inject grease through the grease nipple (1).
★ If the grease proves difficult to inject, move the machine backwards and forwards slowly over a short stretch.



- 2 - If the tension is too tight.
Loosen the grease nipple (1) slowly to allow grease to flow out of the valve.

- ⚠ The grease contained in the stretching cylinder is under pressure and could injure the operator. For this reason the valve should not be loosened by more than one turn.

- ★ If the grease does not flow easily, move the machine backwards and forwards slowly over a short stretch.



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL



CHECKING AND ADJUSTING PRESSURES IN THE SERVOCONTROL FEED UNIT

★ Test conditions:

- Hydraulic oil: 45–55°C.

★⚠ Release any residual pressures from the circuits (See
↑ «RELEASING RESIDUAL PRESSURES FROM THE
CIRCUITS»).

- 1 - Connect the pressure gauge **E1** to the adapter **M3**.
- 2 - Start the engine and move the accelerator into its maximum position.
- 3 - Put the lever of the safety device in its working position, (UNLOCKED).
- 4 - Bring a servocontrol circuit up to pressure by operating the work equipment (i.e. bucket).
- 5 - Check the working pressure on the pressure gauge **E1**
 - ★ Working pressure: $32 \pm \frac{2}{1}$ bar
 - ★ If the working pressure is lower than the permissible value, check servocontrol feed unit valve.



3. Preparation for testing:

- travel motors
- travel brakes
- speed increment

- 1 - Relieve all residual hydraulic pressures (See «RELEASING RESIDUAL PRESSURES FROM THE CIRCUITS»).
- 2 - Identify the branch involved in the test (1).
- 3 - Disconnect the hoses (2) from the branches adjacent to the part to be tested and cap them tightly.

! Make sure that the detached tubes are securely sealed, to prevent jets of high-pressure oil escaping if circuits that are not undergoing tests should accidentally become pressurised.

★ The tubes of the adjacent branches must be disconnected from the upper parts of the swivel joint.

- 4 - Provisional hoses (3) for collecting any oil leakages should be connected to the inlets of the branches adjacent to the one being tested.

4. Preparation for testing the blade

- 1 - Relieve all residual hydraulic pressures (See «RELEASING RESIDUAL PRESSURES FROM THE CIRCUITS»).
- 2 - Identify the branch involved in the test.
- 3 - Disconnect the tube corresponding to the branch to be tested from the safety valve input and cap it.

! Make sure that the detached tubes are securely sealed, to prevent the escape of jets of oil at high pressure.

- 4 - Cap the valve to prevent entry of impurities.

- 5 - Disconnect from the swivel joint the hoses (2) of the branches adjacent to the branch to be tested, and cap them tightly.

! Make sure that the detached hoses are securely sealed, to prevent jets of high-pressure oil escaping if the circuits that are not undergoing tests should accidentally become pressurised.


★ The tubes of adjacent branches must be disconnected from the upper parts of the swivel joint.

- 6 - Provisional hoses (3) to collect any leaking oil should be connected to the inlets of the branches adjacent to the one being tested.


5. Test

- 1 - Start the engine and bring it up to the test speed described for each group or component.
- 2 - Pressurise the branch to be tested.
- 3 - After 30 seconds, watch for another minute if there are any leakages.

★ If oil leaks out of one of the two provisional hoses, it means that there is a leakage in the intermediate gasket between the branch connected to the provisional hose and the pressurised branch.




RKP07420



RKP07410

EMPTYING THE AIR-CONDITIONING UNIT

- 1 - Connect the maintenance station **L1** to the service valves (1) and (2) and follow the specific maintenance station instructions relative to the drainage of the unit.
- 2 - Disconnect the group to be substituted or reconditioned immediately after switching off the maintenance station. **Plug the removed or disconnected connection tubes tightly and with a minimum of delay.**
- 3 - Carefully check the quantity of anti-freeze oil recovered and contained in the disassembled parts, since the same quantity must be replaced when the air-conditioning unit is refilled.



REMOVAL OF THE AIR-CONDITIONING UNIT COMPRESSOR


(Only for machines equipped with an air-conditioning unit)

! Disconnect the cable from accumulator negative terminal (-).


1 - Connect the outlets (1) and (2) to the maintenance station for air-conditioning units **D1** and drain the cooling fluid.




Quantity of fluid R134a: $1100 \begin{smallmatrix} -30 \\ +50 \end{smallmatrix}$ g



2 - Remove the clamp (3) and disconnect the connector (4).




3 - Loosen screw (5) and remove return (6) and delivery (7) pipes. ✖ 1



4 - Remove the fan guard (8). ✖ 2


5 - Loosen screws (9), (10) and (11) to leave free the compressor (12).



9 - Disconnect the pre-heater cable (12) and remove the support (13).


10 - Disconnect the coupling sleeve (14).

11 - Remove the muffler (15).
(For details see «REMOVAL OF THE EXHAUST PIPE-MUFFLER»).




12 - Remove the fuel filter (18).

13 - Disconnect the fuel return hose (17) from the injectors.



14 - Remove the injectors (18).
(For details see: «REMOVAL OF THE NOZZLE INJECTORS») ※ 2 ※ 3


15 - Loosen the nuts (19) and remove the tappet cover (20). ※ 4



16 - Remove the valve rocker-arm(21).
★ Loosen the nuts (22) and unscrew the tappets by 2-3 turns.

※ 5


17 - Take out the rocker arm control arms (23).



REMOVAL OF FRONT HOOD

! Lower the work equipment until it is resting on the ground and switch off the engine.


- 1 - Detach the gas cylinder (2) from the support (1).
- 2 - **Only for machine equipped with an air conditioning unit:** remove the condenser unit.
(For detail see «REMOVAL OF CONDENSER UNIT»).



- 3 - While holding up the engine hood (3), remove the screws (4) that attach the hood to the hinges (5).

★ Mark the position of any shims. ✖ 1

kg Engine hood: 27 kg




INSTALLATION OF FRONT HOOD

- To install, reverse the removal procedure.

✖ 1

- ★ Position any shims.
- ★ Check the centering and adjustment of the closing hook (6).

! Replace the cotter pins (7).



REMOVAL OF HYDRAULIC OIL TANK

! Lower the work equipment until it is resting on the ground and switch off the engine.

! Release residual pressures from all circuits. (For details, see «20. TESTING AND ADJUSTMENTS»).

- Drain the hydraulic oil.




Quantity of oil: approx. 74 ℓ

1 - Remove the fuel tank.

(For details, see «REMOVAL OF FUEL TANK»).


2 - Disconnect the return pipe (1) and (2).



3 - Disconnect the drain pipes (3) and (4).


4 - **With arm safety valve:**

Disconnect the drain pipe (5) from safety valve.



5 - Disconnect the coupling of the pump suction tube and the pipe (6).


6 - Hook the tank to the hoisting equipment and slightly put the rope under tension.



7 - Remove the bolts and the oil tank (7).



Oil tank: 62 kg



REMOVAL OF SWING MACHINERY

! Lower the work equipment until it is resting on the ground and switch off the engine.

! Release residual pressures from all circuits. (For details, see «20. TESTING AND ADJUSTMENTS»).

1 - Drain the reduction gear hydraulic oil.




Quantity of oil: approx. 4 ℓ

2 - Remove the front hood (For details, see «REMOVAL OF FRONT HOOD»).

3 - Disconnect the feed pipes (1), the exhaust pipe (2), the brake release pipe (3) and the drain line connection (4).

※ 1



4 - Remove the drain extension tube (5).

5 - Remove the check screws (6) (No. 12) of the reduction gear (7).

※ 2


6 - Fasten two screws into the holes opposite to each other and remove the reduction gear

7 - Sling the complete assembly and remove it.

★ During removal, slowly lift the assembly and pay particular attention not to damage the pipes or other parts.



Complete group: approx. 87 kg



INSTALLATION OF THE SWING MACHINERY

• To install, reverse the removal procedure.

★ In order to centre the holes of the pins and of the fastening screws, connect a hydraulic power unit "A" to the hydraulic motor and slowly rotate the motor until the correct angle for the positioning of the reduction gear has been obtained.

※ 1

★ Fill with hydraulic oil through the breather (8).


※ 2




Screws: 294 Nm

1 - Start the engine to allow oil circulation in all systems and check the seals.

2 - Bleed the air from engine. (For details, see «20. TESTING AND ADJUSTMENTS»).




8 - Mount the sealing ring (21) in the gearbox housing (4).




9 - Fill with grease the bearing (22) seat.


 Bearing: ASL800050



10 - Position the gearbox housing (4) over the swing pinion (15).




11 - Mount the inside bearing ring (17) on the swing pinion (15).




REMOVAL OF SWING CIRCLE

- 1 - Remove the upper revolving frame. (For details, see «REMOVAL OF UPPER REVOLVING FRAME»).
- 2 - Completely remove all contaminated grease.
- 3 - Remove the screws (1) that secure the swing circle (2).



- 4 - Remove the swing circle (2) using a lifting equipment "A".

kg Swing circle: 124 kg



INSTALLATION OF SWING CIRCLE


- ★ Before installing the swing circle, check the condition of the central gasket (3).
- ⚠ For reasons of safety, when installing the swing circle, insert two screws into the front and back holes in the frame.
- To install, reverse the removal procedure.



Before attaching the swing circle, check that the area marked with an «S» is positioned on the right-hand side of the chassis.


 Attachment screws: Loctite 242

 Attachment screws: 314 Nm


 Lubricating grease: approx. 25 kg

ASSEMBLY OF THE FINAL DRIVE

- 1 - Insert the planetary carrier (25) into sun gear (26) and lock it with a new snap ring (24).




- 2 - Mount on the planetary carrier the roller (8) and sun gear (7).



- 3 - Mount on the planetary carrier (25) the spacers (23) and the planetary gear (22).


- ★ Heat the planetary gear to approx. 70°C to ease the mounting.
- ★ Take care to the orientation of the planetary gear.

- 4 - Lock the planetary gear (21) with new snap rings (22).



- 5 - Degrease and dry the cavities for the seal gasket (17).

- 6 - To ease the next step, insert O-ring (A) (200x3) between steel ring and rubber ring.




REMOVAL OF CARRIER ROLLER

1 - Slowly unscrew the lubricator (1) to let out the grease and relieve tension on the track shoe.

⚠ The grease contained in the track shoe stretching cylinder is under pressure and could cause serious injury to the operator. For this reason the valve should not be loosened by more than one turn.


★ If the grease does not flow out easily, move the machine backwards and forwards slowly.

⚠ Lower the work equipment to the ground and switch off the engine.



2 - Raise the track shoe (2) to a height that leaves the idler (3) free. For reasons of safety, position some blocks (4).


3 - Loosen the retaining screw (5) and remove the carrier roller (3).



INSTALLATION OF CARRIER ROLLER

- To install, reverse the removal procedure.

1 - Adjust track shoe tension. (For details, see «20. TESTING AND ADJUSTMENTS»).





REMOVAL OF BOOM CYLINDER (For 2-piece boom)


1 - Fully extend the front work equipment, raise the boom and 2-piece boom and position a supporting stand (A) between them.




★ The stand should be 1.60 m high.

2 - Manoeuvre the arm until the bucket is resting on the ground. Switch off the engine.



3 - Put a sling round the RH 2nd boom cylinder (1) of the 2-piece boom and remove the self-locking nut (2), the screw (3) and the spacer (4). 






4 - Slide off the pin (5) that connects the RH 2nd boom cylinder (1) to the 2-piece boom, until the piston rod is completely disconnected.   

5 - Start the motor and retract the RH cylinder piston. 



★ To secure the piston rod in this position, tie it with wire and switch off the engine.

6 - Disconnect the tubes (6) from the RH cylinder (1) and plug them.

7 - Slide out the pin (7) until the cylinder (1) is free and remove it.  




8 - Put the boom cylinder (8) in a sling.

9 - Slide the pin (7) out until the boom cylinder piston rod (8) is disconnected.  


★ To hold the piston rod in its fully retracted position, tie it with wire and switch off the engine.

10 - Start the engine and retract the piston.

11 - Lower the cylinder (8) and rest it on a stand (B).





- 5 - Gauge the diameter of the internal seals, mounting the group underneath a press and using the specific gauging knuckle pin "C" for the diameter of the piston rod.




3. Piston assembly

- 1 - Using the suitable plunger D, mount the piston seal. Mount in the correct sequence the rubber ring (1), the external seal (2), and the anti-extrusion rings (3).
- 2 - Mount the guide rings (4).
- 3 - **For the arm and 2nd boom piston only:** Mount the O-ring (5) and the anti-extrusion rings (6) for the sealing between piston rod and piston.



- 4 - Gauge the diameter of the seal (2) of the piston (7), mounting the group under a press and use the specific gauging ring "E" for the piston diameter.




REMOVAL OF 2nd BOOM

1 - Remove the bucket, the bucket cylinder, the arm cylinder and the arm. For details see:


- REMOVAL OF BUCKET
- REMOVAL OF BUCKET CYLINDER
- REMOVAL OF ARM CYLINDER
- REMOVAL OF ARM

2 - Start the engine and bring the 2-piece boom (1) into a vertical position. Lower it until it rests on the ground and switch off the engine.



3 - Put a sling round the RH cylinder (2) of the 2-piece boom and remove the nut (3), the screw (4) and the shim (5).

※ 1



4 - Slide out the pin (6) that connects the RH cylinder (2) to the 2-piece boom (1) until the piston rod is completely disconnected.

※ 2 ※ 3


5 - Start the engine and completely retract the piston rod of the RH cylinder.

- ★ To hold the piston rod in a fully retracted position, tie it with wire and switch off the engine.

6 - Lower the cylinder until it is in a vertical position, leaving the boom tied up.

7 - Repeat these operations from point 3 to point 6 in order to disconnect the LH cylinder (7).

※ 2 ※ 3




8 - Hook the 2-piece boom to the hoisting tackle.

9 - Remove the screws and take out the pin (8).


※ 2 ※ 3 ※ 4

10 - Take off the 2-piece boom.

kg 2-piece boom: 195 kg






SWING CIRCLE



Unit: mm


| No. | Check item | Criteria | | Remedy |
|-----|-----------------|--------------------|-----------------|---------|
| | | Standard clearance | Clearance limit | |
| 1 | Axial clearance | 0.3-1.2 | 3 | Replace |

HYDRAULIC PUMP




View Y

13.25 ± 1.45 Nm



RKP03731

SWING MOTOR



Unit: mm

| No. | Check item | Criteria | | | | | Remedy |
|-----|----------------------|-----------------------|---------------------|-------------------|-----------------------|-------------------|---------|
| | | Standard size | | | Repair limit | | |
| | | Free length x O.D. | Installed length | Installed load | Free length x O.D. | Installed load | |
| 1 | Suction valve spring | — | 11.5 | 0.9 N | — | — | Replace |
| 2 | Shuttle valve spring | — | 19.5 | 1.8 N | — | — | |

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL