

SHOP MANUAL

KOMATSU

WA300-1

WA320-1

MACHINE MODEL	SERIAL No.
WA300-1	10001 and up
WA320-1	10001 and up

This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you may require.

Materials and specifications are subject to change without notice.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below




- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

NETWORK (Disassembly and assembly relationship drawings)

In the shop manual the following network drawings show relationship between work items and sequence for assembly and disassembly.



FS0001

In this network the sequence of disassembly is marked on the top right of each work item so that handling can be easily understood. For example, when taking D of the Ass'y follow the sequence A → B → D, when removing E follow the sequence A → E.

F ass'y indicates a further separate disassembly, and indicates the existence of a previous work network. For assembly the sequence is shown using the same kind of network.

TROUBLESHOOTING CHART

As shown below, the symptoms relating to a particular trouble are described in the line designated "Problems". The probable cause of the trouble is then marked under the "Causes" column.

Example:
Symptom: Reduced tractive power or slow travel speed.

Problems	Causes		
	Oil leaks in torque converter	Air suction in the hydraulic pump	
Torque converter oil pressure gauge shows lower than normal pressure. (normal 3 - 4.8 kg/cm ²)	○	○	○
Transmission oil pressure gauge shows lower than normal pressure. (normal 20 - 23 kg/cm ²)		○	
	○		

MAINTENANCE STANDARD

Standard size, Tolerance


The dimensions of finished parts each differ a little. Therefore, when determining the finished dimensions of parts, a dimension that will be standard is determined provisionally, then the difference allowed from it is indicated. The former is called the standard size, and the latter the tolerance.

The way to show this is by a plus or a minus sign with the tolerance in smaller numerals to the right of the standard size.

Example: $120 \begin{matrix} -0.026 \\ -0.126 \end{matrix}$
(It equals 119.874 - 119.978 mm)

Moreover, when expressing the dimensions of a hole and the shaft that goes inside it, for the sake of convenience, the standard size for the hole and the shaft are usually taken as the same, and the tolerances changed to indicate the tightness of the fit. For example, the fit of a revolving shaft is indicated as follows, and is shown in the drawing.


Hole: $60 \begin{matrix} +0.046 \\ 0 \end{matrix}$ Shaft: $60 \begin{matrix} -0.030 \\ -0.076 \end{matrix}$



FS0002

MEASURING INSTRUCTIONS


● Measuring end play, looseness or deviation



FS0025

Read the T.I.R. while moving the object back and forth or vertically.

● Measuring face runout or radial runout




FS0026

- 1) Read runout at six or more positions during one complete rotation of the object.
- 2) At the start of each measurement, set the zero-point at the middle of the assumable range of the spindle movement. Be careful not to confuse positive and negative readings of runout.

	Face runout	Radial runout
When the pointer is to the right of "0"	+	-
When the pointer is to the left of "0"	-	+

- 3) When measuring face runout, place the contact-point on the object along a circle 2 or 3 mm smaller in diameter than the outside diameter of the object.

● Measuring gear backlash




FS0027

- 1) Fully mesh one of two gears and place the dial gauge contact-point on a tooth of the other gear. Swing the free gear within the limits of its play in the rotational directions, and read the T.I.R.
- 2) Use of the lever and fulcrum type dial gauge is recommended for this purpose as the contact-point placed on the gear is moved tangentially to the gear pitch circle.
- 3) The lever and fulcrum type dial gauge is suitable for use in a narrow space or for a special measurement which requires placing the contact-point on an object at an angle to the spindle of the gauge. Since the contact-point of this type of gauge has a very narrow measuring range (usually 3 mm or less), the contact-point should be carefully checked for contact with the object during measurement.


CYLINDER GAUGES


- Install a contact-point having a length approximately equal to the cylinder bore to be measured on the cylinder gauge. Set the zero-point of the test indicator to the bore diameter of the standard cylinder measured with a reference ring gauge or a micrometer.



FS0028

HOISTING INSTRUCTIONS



⚠ Heavy parts (25 kg or more) must be lifted with a hoist etc. In the **Disassembly and Assembly** section, every part weighing 25 kg or more is indicated clearly with the symbol 

1. If a part cannot be smoothly removed from the machine by hoisting, the following checks should be made:

- Check for removal of all bolts fastening the part to the relative parts.
- Check for existence of another part causing interference with the part to be removed.

2. Wire ropes


1) Use adequate ropes depending on the weight of parts to be hoisted, referring to the table below:

Wire ropes (Standard "Z" or "S" twist ropes without galvanizing)	
Rope diameter (mm)	Allowable load (tons)
10	1.0
11.2	1.4
12.5	1.6
14	2.2
16	2.8
18	3.6
20	4.4
22.4	5.6
30	10.0
40	18.0
50	28.0
60	40.0

The allowable load value is estimated to be one-sixth or one-seventh of the breaking strength of the rope used.

2) Sling wire ropes from the middle portion of the hook.

Slinging near the edge of the hook may cause the rope to slip off the hook during hoisting, and a serious accident can result. Hooks have maximum strength at the middle portion.



FS0064


3) Do not sling a heavy load with one rope alone, but sling with two or more ropes symmetrically wound on to the load.

⚠ Slinging with one rope may cause turning of the load during hoisting, untwisting of the rope, or slipping of the rope from its original winding position on the load, which can result in a dangerous accident.

4) Do not sling a heavy load with ropes forming a wide hanging angle from the hook.

When hoisting a load with two or more ropes, the force subjected to each rope will increase with the hanging angles. The table below shows the variation of allowable load (kg) when hoisting is made with two ropes, each of which is allowed to sling up to 1000 kg vertically, at various hanging angles.

When two ropes sling a load vertically, up to 2000 kg of total weight can be suspended. This weight becomes 1000 kg when two ropes make a 120° hanging angle. On the other hand, two ropes are subjected to an excessive force as large as 4000 kg if they sling a 2000 kg load at a lifting angle of 150°.




FS0065

SPECIFICATIONS

Machine model	WA300-1	
Weight		
• Operating weight (incl. one person's 80kg)	kg	12,180
• Front wheel loading	kg	5,540
• Rear wheel loading	kg	6,640
Dimensions		
• Overall length (tooth length excluded)	mm	7,045
• Overall width of machine	mm	2,585
• Overall width of bucket	mm	2,685
• Overall height (top edge of exhaust pipe)	mm	3,190
• Overall height (top of cab)	mm	3,385
• Overall height (turing bucket ascent)	mm	5,035
• Wheel base	mm	3,030
• Tread	mm	2,050
• Bucket hinge pin height	mm	3,750
• Dumping clearance (bucket base)	mm	2,800
• Dumping reach (bucket base)	mm	1,060
• Bucket dumping angle	degree	45
• Bucket tilt angle (traveling posture)	degree	48
• Excavation depth (10° dump)	mm	250
• Minimum height above ground	mm	400
Performance		
• Bucket capacity	m ³	2.3
• Operating load	kg	3,560
• Travel speed		
Forward		
1st speed	km/h	7.9
2nd speed	km/h	12.0
3rd speed	km/h	21.0
4th speed	km/h	37.0
Reverse		
1st speed	km/h	7.9
2nd speed	km/h	12.0
3rd speed	km/h	21.0
4th speed	km/h	37.0
• Maximum traction force	kg	11,400
• Gradeability	degree	25
• Minimum turning radius		
• At outside of machine	mm	5,935
• At center of outermost wheel	mm	5,160

FUEL TANK AND PIPING

The fuel level sensor is installed in the main fuel tank.



F4230001

1. Connector
2. Fuel level sensor
3. Injection pump
4. Drain valve
5. Fuel filler port

MEASURING BLOW-BY PRESSURE

★ Measurement condition


- Coolant temperature: Inside operating range.
- Engine valve clearance: Standard valve

Unit: mmH₂O

Item	Standard value	Permissible value
Blow-by pressure	Max. 100	200


Special tool

	Part number	Part name	Q'ty
A	799-201-1503	Blow-by checker	1

 When taking measurements, be careful not to touch the exhaust manifold or muffler, or to get caught in rotating parts.

1. Measuring blow-by


- 1) When measuring the blow-by, warm the engine up thoroughly (oil temp: min. 60°C).
- 2) Stop engine and install adapter ① of blow-by checker A on engine breather hose (1).
- 3) Connect adapter and pressure gauge (0 – 1000 mm H₂O) to hose.
- 4) Run engine at rated output and measure blow-by pressure.




2. Precautions when measuring blow-by

- ★ Blow-by may vary greatly according to the condition of the engine, so if there is any abnormality in the reading, check for any problem related to defective blow-by, such as excessive oil consumption, defective exhaust gas color, or early deterioration or contamination of the oil.

REMOVAL OF ALTERNATOR ASSEMBLY



 Disconnect the cable from the negative (–) terminal of the battery.

1. Remove catch, then open hood.
2. Disconnect wires (1), (2) and (3).
3. Remove bolt (4) of adjustment plate, then loosen mounting bolt and nut (5).
4. Move alternator assembly towards cylinder block to loosen belt tension, then remove belt (6).
5. Remove mounting bolt and nut, then remove alternator assembly (7).




INSTALLATION OF ALTERNATOR ASSEMBLY

1. Install alternator assembly (7), then partially tighten mounting bolt and nut (5).
2. Fit belt (6) in pulley groove and install.
3. Partially tighten bolt (4) of adjustment plate.
4. Insert a bar between alternator assembly and cylinder block, raise alternator assembly and adjust tension of belt.
 - ★ The belt should deflect about 10 mm when pushed with a finger pressure of 6 kg at a point midway between the alternator and the fan pulley.
5. Tighten bolt of adjustment plate, mounting bolt and nut.
6. Connect wires (3), (2) and (1).
7. Close hood, then lock with catch.
8. Connect cable to negative (–) terminal of battery.



10. Oil filter


- 1) Disconnect connector (23), then remove mounting bolt (24) of tube.
- 2) Remove oil filter (26) together with tube (27) and bracket (25).

**11. Fuel injection tube**


Remove 6 fuel injection tubes (28).

12. Electrical intake air heater switch

Remove wiring clamps (29) and (30), then remove electrical intake air heater switch (31) and move it to outside.

**13. Bracket, hoses**


- 1) Disconnect aeration hose (32), then disconnect thermostat outlet hose (33).
- 2) Disconnect bypass hose (34).
- 3) Remove bracket (35).

**14. Spill pipe**


Remove spill pipe (36).

15. Nozzle holder assembly

Remove nozzle holder assembly (37).



REMOVAL OF RADIATOR

 Park the machine on level ground, set the safety bar on the frame, ground the bucket, shut down the engine apply the parking brake and place blocks under the tires.

1. Water drainage

- 1) Loosen drain valve (1) and drain off the cooling water.



Cooling water: 38 ℓ

★ If the cooling water contains anti-freeze solution, treat it as a chemical reagent. Do not discard it carelessly.



2. Hood

- 1) Open hood and remove cable (2), then close hood and install safety bolt (3).
- 2) Remove radiator grille (4) and exhaust pipe (5).
- 3) Remove mounting bolts, then remove hood (6).

★ Screw eye bolts into the holes for the mounting bolts of the exhaust pipe, and be careful of the balance when removing the hood.






Hood: 110 kg




3. Fan guard

Remove fan guard (7) and radiator support (8).



INSTALLATION OF ENGINE




419F204

HYDRAULIC CIRCUIT DIAGRAM FOR POWER TRAIN


(WA300-1 Serial No. 10001 – 19999)

(Engine low idling, F-R lever at Neutral, Speed lever at 1st)



TORQUE CONVERTER REGULATOR VALVE

(WA300-1 Serial No. 10001 – 19999)



419F015A

FUNCTION


- The torque converter regulator valve is installed at the outlet side of the torque converter. It adjusts the maximum oil pressure inside the torque converter.
- When shifting, the pressure inside the torque converter is lowered and the modulation function in the control valve is stabilized.

- | | |
|----------------|-----------|
| 1. Lower valve | 6. Spring |
| 2. Upper valve | 7. Plug |
| 3. Spring | 8. Spring |
| 4. Piston | 9. Spool |
| 5. Spool | |
-
- | |
|--|
| A. Torque converter outlet port |
| B. Oil cooler port |
| C. Transmission lubrication oil port |
| D. To lower valve |
| E. Transmission control valve (from upper valve) |
| F. Drain port |

OPERATION OF CLUTCH

When engaged


- The oil sent from the transmission valve passes through the oil passage inside shaft (1). It reaches the rear face of piston (6) and acts on the piston.
 - When piston (6) is actuated, separator plate (2) and clutch disc (3) are brought into close contact. Shaft (1) and clutch gear (4) form one unit and transmit the motive force.
- When this happens, oil is drained from oil drain hole (5). However, the volume of oil drained is less than the volume of oil entering, so there is no effect on the operation of the clutch.



419F024

When disengaged

- The oil sent from the transmission valve is shut off, so the pressure of the oil acting on the rear face of piston (6) is reduced.
- The piston is returned to its original position by wave spring (7), and shaft (1) and clutch gear (4) are separated.
- When the clutch is disengaged, the oil at the rear face of the piston is drained by centrifugal force through oil drain hole (5). This prevents the clutch from remaining partially engaged.



419F025


PILOT REDUCING VALVE

FUNCTION

- The pilot reducing valve regulates the pressure use to actuate the transmission spools.


OPERATION

- The oil from the pump enters port (a). It passes through port (b) of pilot reducing valve (1), and enters transmission spool (2) of the lower valve to fill the pilot circuit. The oil at port (b) passes through orifice (3) and goes to port (c).




419F035

- As the pressure in the pilot circuit rises, the hydraulic pressure at port (c) also rises. It pushes against spring (4) and moves pilot reducing spool (2) in the direction of the right. Port (a) and port (b) are shut off, so the pressure at port (c) is maintained at the same level.



419F036

FORWARD 1st



419F054A

- The oil from the pump passes through priority valve (7), and is divided to the pilot circuit and clutch actuation circuit.
- If the transmission control levers are placed in 1st FORWARD, FORWARD solenoid valve (22B) is actuated, and the oil which fills port (a) is drained. When this happens, FORWARD spool (17) moves to the left, and the clutch oil pressure port and FORWARD clutch oil pressure port (b) are connected. 2nd speed solenoid valve (22E) is closed, so the 1st and 2nd spool is pushed to the right, and clutch oil pressure port (c) and 1st clutch port (d) are connected.
- The oil in the clutch actuation circuit passes through main orifice (e). It then passes through clutch ports (b) and (d), which are connected at the FORWARD and 1st and 2nd spools, and flows to the FORWARD and 1st clutches.
- When the oil completely fills the clutch cylinder, the oil pressure rises gradually because of the action of the accumulator valve and quick return valve. When it reaches the set pressure, the FORWARD and 1st clutches are completely engaged.


MAIN REGULATOR VALVE

FUNCTION

- The main regulator valve controls the amount of oil that flows to the clutch circuit. It sends any excess oil to the torque converter circuit.


OPERATION

- The oil from the pump enters priority valve (1). It then flows from port "a" through main orifice (2) and fills the clutch circuit.




U41901022

- The oil which passes through orifice (4) and enters port "b" acts against spring (5) and moves the spool to the left. It then passes through port "c" and flows to the torque converter circuit.



U41901023

PILOT OIL FILTER



1. Head
 2. Element
 3. Case
- a. Oil suction port
b. Oil delivery port

Specifications

- Particle size: 105 microns (150 mesh)
- Filtering area: 370 cm²

419F053

FUNCTION



- The pilot oil filter is installed between the upper valve and lower valve of the transmission control valve. It removes dirt from the oil flowing to the pilot circuit.

AXLE MOUNT


(WA300-1 Serial No. 20001 and up, WA320-1)

WA300-1
Serial No.
20001 and up

WA320-1



Section A-A




Section B-B

U41901056A

MEASURING OIL PRESSURE OF TORQUE CONVERTER AND TRANSMISSION (WA300-1 Serial No. 20001 and up, WA320-1)

- ★ Measurement conditions
 - Engine water temperature: Within green range on engine water temperature gauge
 - Torque converter oil temperature: 60 – 80°C
- ⚠ Apply the parking brake and block the wheels.




Preparatory work


- ★ The following operations are necessary preparatory work for all measurements of the hydraulic system.
 - Open left inspection cover (1) of the rear frame.
 - Turn transmission cut-off selector switch (9) to the OFF position, and use the left brake. (Check that the pilot lamp has gone out.)
 - Remove the plug from the measuring port of the transmission valve.
 - Install hydraulic test kit (1) to the measurement port, pull the cage into the operator's compartment, then start the engine and measure the pressure.
- ★ Check that there is no leakage of oil from any joints.
- ★ After removing the measurement plug, always coat the plug with adhesive.



 Plug: **Sealing agent (LG-1)**



416F251



U41901037

PREVENTING RECURRENCE OF TROUBLE

- The troubleshooting table is used to establish the direct cause of damage or breakdown of a part or piece of equipment. It is not able to establish the root cause of the damage or failure, however.
- Also, this table only describes the action to be taken with the particular part or piece of equipment. It does not mention what action should be taken to prevent a recurrence of the root cause.
- In order to remove the root cause of a fault so as to prevent a recurrence, carefully investigate the real cause while referring to the following items.
- Regarding the method of checking and adjusting each part or piece of equipment, refer to "Testing and adjusting" in the Shop Manual.

HYDRAULIC EQUIPMENT

1. Oil checks

- The fundamental cause of almost all faults occurring in hydraulic equipment is the inclusion of water, air or other foreign matter in the oil. Accordingly, it is necessary to check the oil to see whether or not it contains any of the above substances, and then take appropriate action.

1) Oil checks

- Check for water ingress

Check the oil for possible water ingress by means of a diesel engine oil checker or a hot plate.

- Check for ingress of other foreign matter

Remove the drain plug and filter, then check the bottom of the tank and also the filter to see if any foreign matter has collected there. Check the degree of contamination by means of a contamination checker.

- Viscosity check

Check the viscosity of the oil using a viscometer in order to confirm whether or not the oil is satisfactory.

2) Check of ingress point

If, as a result of the above checks, it is discovered that the oil is contaminated by water or other foreign matter, it is necessary to find out where the contamination is occurring and also the take steps to prevent it.

Water: Oil storage tank, breather, etc.

Sand: Oil replenishing or replacing method, etc.

Rubber: Cylinder packing, etc.


Metal: Wear or damage to hydraulic equipment such as pump and motor, as well as transmission and torque converter, etc.

3) Oil cleaning and replacement

- If a large amount of metal particles or other foreign matter is discovered in the oil, either wash the oil using an oil refresher or replace it.
 - ★ If the oil is contaminated by water, it is not possible to remove the water by means of an oil refresher.
 - ★ When washing the oil, also wash or replace the strainer and replace the filter.

2. Cleaning fragments of damaged parts

- If a part becomes damaged, fragments may pass into the oil line. It is thus necessary to wash the oil.
- In addition, disassemble and wash such parts as valves and cylinders which are liable to collect metal fragments and other foreign matter, thus helping to prevent a recurrence of faults due to such fragments becoming lodged in various parts of the engine or hydraulic equipment.




419F205

9. Fuel control cable

Set fuel control cable (20) in mounting position, then secure with lock nut.


- ★ Install the clamp at the bottom of the hydraulic tank.
- ★ For details of adjusting the fuel control cable, see 12 TESTING AND ADJUSTING.



10. Steering linkage

Connect steering linkage (19) to center lever.

 Mounting nut: 12.5 ± 1.0 kgm




11. Main control valve linkage, brake hose

1) Connect hose (18) between brake oil tank and brake booster at brake oil tank end.

2) Connect main control valve linkage (17) to main control valve.



- ★ Connect the washer liquid hose to the tank.



12. Electric wiring

Connect the following wiring to the connector.

- Ground connection (16).
- Wire (15) for cab.
- Wire (14) for transmission.
- Wire (12) for rear frame.
- Wires (10) and (11) for front frame.
- ★ Apply the connector lock securely.



419F403

Special tools


	Part number	Part name	Q'ty
A	793-305-1600	Lifting tool	2
B	793-310-2100	Lifting tool	1
C	793-520-2900	Lifting tool	1

1. Hydraulic piping

Disconnect the following hydraulic piping.

- Tube between transmission control valve and torque converter regulator valve.
- Hose (1) between filter and transmission valve.
- Tube (2) between pump and filter.
- Hose (3) between transmission and brake booster.


★ After removing the tubes, fit covers to protect the threads.

**2. Filter**

1) Remove filter (4), then remove bracket (5).

2) Remove oil filler (6).

★ Remove the rear coupling.


**3. Transmission control valve**

Remove transmission control valve (7).




3) Assemble shaft (41) in housing.

★ Insert the shaft at an angle as shown in the photograph.



4) Partially tighten mounting bolts of shaft retainer (33).




5) Inset gear (40) in shaft spline, then set shroud (38) in mounting position.



6) Secure with ring (39).

7) Fit lock plate (37) and install shroud.


★ Bend the lock plate securely.

★ Check that the gear does not contact the shroud.

 kgm Mounting bolt: 11.5 ± 1 kgm




419F409




DISASSEMBLY OF CLUTCH PACK


DISASSEMBLY OF FORWARD-REVERSE CLUTCH PACK



DISASSEMBLY OF 1ST-3RD SPEED CLUTCH PACK




DISASSEMBLY OF 2ND-4TH SPEED CLUTCH PACK



419F209

Special tools


	Part number	Part name	Q'ty
A	793-310-1300	Stand	1
A ₁	793-310-1370	Guide pin	5
A ₂	793-310-1330	Plate	1
A ₃	01541-1260	Nut	2
A ₄	793-310-1360	Bar	2



ASSEMBLY OF FORWARD-REVERSE CLUTCH PACK ASSEMBLY

⚠ When setting the clutch pack on the stand, wipe off all oil to prevent the pack from slipping, and be careful not to get your fingers caught between the stand and the clutch pack.


★ Set the shaft and housing on stand A with the REVERSE side at the top.




1. REVERSE piston

Install REVERSE piston (56).

- ★ Be careful not to damage the piston seal.
- ★ Check that the spring pin is not protruding from the circumference of the shaft.

 Sliding surface of piston seal:
Transmission oil



2. Clutch plate


Insert tool A₁ in housing, then assemble plate (57), disc (58) and spring (59) in turn.

- ★ Soak plate (57) in clean transmission oil for at least two minutes before assembling.

(WA300-1 Serial No. 10001 – 19999)


- ★ Assemble spring (59) in sets of two springs.

- ★ Be careful not to let spring (59) and plate (57) catch on each other.
- ★ Do not let the plate or spring catch in the ring groove of the clutch housing when assembling.




4. Thrust bearing

Install thrust bearing (55).

**5. 2nd speed gear**


Install 2nd gear (54), then assemble needle bearing (53).

★ If the spline of the gear cannot be aligned, rotate the gear lightly. Never try to force the gear into position.

**6. Bearing**

Install thrust bearing (52).


★ Check that the end face of the thrust bearing is level with or below the stepped part of the shaft.

**7. Bearing**


Assemble idler gear (50), then press fit bearing (51).

★ After press fitting the bearing, check that clearance 'e' between the thrust bearing and the idler gear is within the standard range.

'e' = 0.04 – 0.71 mm




419F418



DISASSEMBLY OF TRANSMISSION CONTROL VALVE

(WA300-1 Serial No. 20001 and up, WA320-1)



U41901805


5. Axle

1) Using jack and hoist, sling axle (4), then remove mounting bolts and lower axle.


★ Use the jack to adjust the height when removing the mounting bolts.



Axle: **690 kg**



2) Pull out axle assembly from machine.




5. Differential carrier

1) Lift off differential carrier (6) from housing.


- ★ Be careful not to let the lifting tool slip out of place when removing.




Differential carrier: **85 kg**




2) Remove bearing cone (7) from differential carrier, remove mounting bolts, then remove differential case (8).



3) Remove thrust washer (9), then remove side gear (10).



4) Remove cross shaft (11), pinion gear (12) and washer (13).




8. Adjusting backlash

1) Measure backlash of bevel gear with dial gauge.


- ★ Measure first with all the shims installed on the bevel gear side.
- ★ Measure the backlash at three places around the circumference of the bevel gear. The variation between measurements must be within 0.1 mm.

Backlash of bevel gear: 0.3 – 0.41 mm



2) To make backlash within specified range, move some of shims from bevel gear side to opposite side.

- ★ When moving the shims, do not change the total shim thickness.
- ★ If the backlash is too large, move shims from **B** to **A**.
- ★ If the backlash is too small, move shims from **A** to **B**.




3) Set bearing (16) on press stand, and press fit axle shaft (9).

- ★ Be careful not to let the bearing slip out of position.

 Press-fitting portion of bearing:

Axle oil




419F443

5. Housing

1) Stand shaft (9) on end, and install tool A.

- ★ Adjust the height with the adjustment bolt so that the top of tool A touches seal (15) lightly with a uniform clearance.
- ★ Secure tool A firmly so that it does not slip out of position.




419P900

2) Raise housing (4) horizontally and insert carefully on shaft.

- ★ Stop housing (4) before press fitting the oil seal.

 Press-fitting portion of oil seal:

Axle oil




419P901

419P902

3) Align housing (4) with press-fitting portion of oil seal and lower housing slowly.

- ★ Use the weight of the housing to insert it.
- ★ After installing the housing, seal surfaces (a) and (A) must be level. In addition, if there is any clearance at 'a', the clearance must be uniform.

4) Remove tool A.




419F444

Unit: mm

No.	Check item	Criteria			Remedy	
		Standard size	Tolerance			Standard clearance
	Shaft		Hole			
1	Clearance between idle shaft and bearing	60	0 -0.012	0 -0.015	-0.015 - 0.012	Replace
2	Clearance between idle gear and bearing	110	0 -0.015	-0.020 -0.042	-0.042 - -0.005	
3	Clearance between pump drive shaft and bearing	45	+0.013 +0.002	0 -0.012	-0.025 - -0.002	
4	Clearance between pump drive gear bearing and housing	85	0 -0.015	+0.022 -0.013	-0.013 - 0.037	
5	Clearance between pump drive shaft and bearing	45	+0.013 +0.002	0 -0.012	-0.025 - -0.002	
6	Clearance between pump drive gear bearing and housing	100	0 -0.015	+0.022 -0.013	-0.013 - 0.037	
7	Clearance between output shaft oil seal and housing	100	+0.400 +0.200	+0.054 0	-0.400 - -0.146	
8	Clearance between output shaft oil seal and housing	100	+0.400 +0.200	+0.054 0	-0.400 - -0.146	
9	Clearance between output shaft bearing and housing	110	0 -0.015	-0.015 -0.040	-0.04 - 0	
10	Clearance between output shaft and bearing	60	+0.035 +0.015	0 -0.015	-0.05 - -0.015	
11	Clearance between output shaft bearing and housing	110	0 -0.015	-0.015 -0.040	-0.04 - 0	
12	Clearance between output shaft and bearing	60	+0.035 +0.015	0 -0.015	-0.05 - -0.015	
13	Clearance between Forward-Reverse clutch bearing and housing (R)	90	0 -0.015	+0.022 -0.013	-0.013 - 0.037	
14	Clearance between Forward-Reverse clutch bearing and housing (F)	90	0 -0.015	+0.022 -0.013	-0.013 - 0.037	
15	Clearance between 1st-3rd clutch bearing and housing (R)	100	0 -0.015	+0.022 -0.013	-0.013 - 0.037	
16	Clearance between 1st-3rd clutch bearing and housing (F)	100	0 -0.015	+0.022 -0.013	-0.013 - 0.037	
17	Clearance between 2nd-4th clutch bearing and housing (R)	90	0 -0.015	+0.022 -0.013	-0.013 - 0.037	
18	Clearance between 2nd-4th clutch bearing and housing (F)	130	0 -0.018	+0.026 -0.014	-0.014 - 0.044	

LOWER VALVE (WA300-1 Serial No. 10001 – 19999)






E419F131
Unit: mm


No.	Check item	Criteria				Remedy
		Standard size	Tolerance		Standard clearance	
Shaft	Hole					
1	Clearance between forward spool and body	19	-0.024 -0.032	+0.013 +0.004	0.028 – 0.045	Replace
2	Clearance between reverse spool and body	19	-0.024 -0.032	+0.013 +0.004	0.028 – 0.045	
3	Clearance between 1st-2nd speed spool and body	19	-0.024 -0.032	+0.013 +0.004	0.028 – 0.045	
4	Clearance between 3rd speed spool and body	19	-0.024 -0.032	+0.013 +0.004	0.028 – 0.045	
5	Clearance between 4th speed spool and body	19	-0.024 -0.032	+0.013 +0.004	0.028 – 0.045	
6	Clearance between emergency manual valve spool and body	19	-0.024 -0.032	+0.013 +0.004	0.028 – 0.045	
7	Forward-Reverse and 1st, 2nd, 3rd, 4th spool spring	Standard size			Repair limit	
		Free length	Installation length	Installation load (kg)	Free length	Installation load (kg)
		51.52	28	18.3±0.9	49.2	16.5
8	Emergency manual valve detent spring	18.42	15.32	6±0.3	18.1	5.4

AXLE MOUNT

(WA300-1 Serial No. 10001 – 19999)




Section A-A



Section B-B


E419F136

STEERING VALVE



423F074B

- A. To steering cylinder
- B. To hydraulic circuit
- C. To steering cylinder
- D. From hydraulic pump
- E. From steering pump
- F. To hydraulic tank

STEERING CYLINDER

419F076

1. Cylinder head
2. Cylinder
3. Piston rod
4. Piston
5. Lock nut

Specification





Cylinder bore: 70 mm
Rod diameter: 40 mm
Stroke: 460 mm
Width across flats of lock nut: 46 mm
Cylinder min. length: 818 mm
Cylinder max. length: 1,278 mm

STANDARD VALUE TABLE

Testing and measuring item	Measurement condition	Unit	Standard value	Permissible value
Steering wheel	<ul style="list-style-type: none"> Road surface: Flat, horizontal, dry, paved surface Hydraulic temperature: 45 – 55°C Machine posture: Facing straight 	mm	20 – 70	20 – 100
<ul style="list-style-type: none"> Steering wheel play Steering wheel operating force 		kg	Max. 2.5	Max. 3.8
<ul style="list-style-type: none"> Operating time of steering wheel (Low idling) (High idling) 		Sec.	2.5 – 3.5 2.5 – 3.5	Max. 5.3 Max. 5.3
Steering linkage	<ul style="list-style-type: none"> Tire inflation pressure: Specified pressure 	mm	20 – 30	–
<ul style="list-style-type: none"> Clearance between front frame and rear frame 				
Steering oil pressure	<ul style="list-style-type: none"> Hydraulic temperature: 45 – 55°C Engine speed: High idling 	kg/cm ²	210 ± 10	210 ± 20
<ul style="list-style-type: none"> Main relief oil pressure 				

TOOL LIST FOR TESTING AND ADJUSTING

No.	Testing and measuring item	Tool	Part number	Remark
1	Steering wheel operating force	Push-pull scale	7A0-262-0020	0 – 25 kg
2	Steering wheel operating play	Convex scale	Commercially available	0 – 2 m
3	Steering wheel operating time	Stop watch	Commercially available	1/10 second
4	Clearance between front frame and rear frame	Convex scale	Commercially available	

-  When carrying out testing, adjusting or troubleshooting, stop the machine on level ground, install the safety bar on the frame, lower the bucket to the ground, and stop the engine. Then apply the parking brake and block the tires.
-  When installing or removing gauges, loosen the oil filler cap slowly to release the pressure inside the hydraulic tank. Then operate the control levers several times to release the remaining pressure in the hydraulic piping.
-  When taking measurements, do not allow unauthorized persons near the machine.
-  The oil in the circuit is hot, so be careful not to get burnt.

3. Steering wheel moves unsteadily or is subjected to large shock.


Checks before troubleshooting

- Is oil level in hydraulic tank and also oil type satisfactory?
- Is there any damage to the steering gearbox mounting part, steering column or linkage?
- Is there any play in the center pin hinge bearing or steering cylinder pin bushing?
- Does tire pressure fluctuate?

Fault check

Operate the wheel loader in a safe place and check the conditions under which the steering wheel becomes unsteady.

★ If, in addition to the steering wheel being unsteady, there are other faults such as sluggishness, etc., refer to item 2 "Steering wheel is sluggish".



No.	Problem	Remedy	Cause			
			a	b	c	d
			△ A	△		△
			X	X	X	X
1	Machine body is unsteady when traveling on bumpy road surface.		○	○		○
2	Steering wheel becomes unsteady if suddenly turned when working or traveling.				○	○
3	Machine body becomes unsteady when traveling at high speed.		○	○		○
4	Machine body becomes unsteady during engine starting.			○		

The following symbols are used to indicate the action to be taken when a cause of failure is located.
 X: Replace △: Repair
 A: Adjust C: Clean

4. Machine tends to turn naturally in one particular direction when traveling.

Cause: Faulty steering valve

- Incorrect positioning of spool.
- Faulty safety valve.
- Oil leakage in steering cylinder.
- Does tire pressure fluctuate?

5. Left and right turning radii are different.


Cause: Incorrectly adjusted steering linkage.
 Left and right steering balance, lock position of stopper.
 (Valve relief noise can be heard upon completion of turning.)

INSTALLATION OF STEERING VALVE

1. Steering valve

Set steering valve (11) in mounting position, then tighten mounting bolts.


- ★ Tighten the mounting bolts fully after connecting the hydraulic piping.
- ★ Insert the mounting bolts of tube (6) of the steering cylinder before installing.




2. Hydraulic piping

Connect the following piping

- Connect hose (10) between steering valve and main control valve at steering valve end.
- Connect hoses (8) and (9) between steering and hydraulic pump and steering valve at steering valve end.



- Connect tube (7) between steering valve and hydraulic tank at steering valve end.
 - ★ Install the tube clamp.
- connect tubes (5) and (6) between steering valve and steering cylinder at steering valve end.




3. Linkage

Connect linkage (4) between center lever and steering valve at steering valve end.

- ★ Check that the steering valve is at NEUTRAL.

 Mounting nut: 12.5 ± 1.0 kgm



ASSEMBLY OF STEERING CYLINDER

Special tools

	Part number	Part name	Q'ty
A	790-502-1001	Cylinder repair stand	1
B	790-100-1200	Wrench	1
C	790-702-1000	Expander	1
D	796-720-1640	Ring	1

★ Coat the sliding surface of all parts with engine oil.
Take care not to damage rod packings, dust seals or assembly (6) on rod, then install nut (5).

1. Assemble cylinder head assembly as follows;


1) Using a push tool, press fit bushing (19) on cylinder head (20).

★ Take particular care not to deform the bushing when press fitting.


2) Assemble rod packing (18).

★ Be careful to install the rod packing facing in the correct direction.

Rod packing



419F449




125P388A 125P389A

3) Using a push tool, install dust seal (17) on head (20).

4) Install snap ring (16).

5) Install back-up ring (22) and O-ring (21).

★ Do not force back-up ring. Heat in hot water (50 – 60°C) before inserting.



125P390A

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below




- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

INSTALLATION OF CENTER HINGE PIN (WA300-1 Serial No. 10001 – 19999)

Special tools


	Part number	Part name	Q'ty
A	793-840-1410	Push tool	1
B	793-101-5221	Glip	1
C	793-840-1310	Push tool	1
D	793-840-1430	Guide	1
E	793-840-1420	Push tool	1



1. Upper hinge

- 1) Install ring (25) at bottom of upper hinge, then assemble dust seal (24).



★ Be careful to install the seal lip facing in the correct direction.

 Lip of seal: Grease (G2-LI)

★ Insert ring (25) inside the planetary carrier before starting.


- 2) Using tools B and C, press fit bearing (26).


★ After press fitting, check that there is no clearance at the ring.





- 3) Install ring (25), then press fit dust seal (24).

★ Be careful to install the seal lip facing in the correct direction.


 Lip of dust seal: Grease (G2-LI)




STEERING CYLINDER MOUNT




Detail P



Section A-A



Section B-B






Detail Q

419F138

Unit: mm

No.	Check item	Criteria				Remedy
		Standard size	Tolerance		Standard clearance	
Shaft	Hole					
1	Clearance between mounting pin and bushing at connection of steering cylinder rod and frame	40	0 -0.025	+0.142 +0.080	0.080 - 0.167	-
2	Clearance between mounting pin and bushing at connection of steering cylinder bottom and frame	40	0 -0.025	+0.150 +0.050	0.050 - 0.175	-
3	Connection of steering cylinder and front frame	Width of boss	Width of hinge		Standard clearance (clearance a + b)	Replace
		50 ^{+0.8} ₀	-		After adjusting with shim: Less than 0.5	
4	Connection of steering cylinder and rear frame	50	54 ± 0.8		After adjusting with shim: Less than 0.5	

SECURITY VALVE (If equipped)



Section A-A

419F494


Unit: mm

No.	Check item	Criteria					Remedy
		Standard size	Tolerance		Standard clearance	Clearance limit	
Shaft	Hole						
1	Clearance between body and spool	26	-	+0.015 +0.009	0.017 ~ 0.027	-	Replace
2	Spool spring	Standard size			Repair limit		
		Free length	Installation length	Installation load	Free length	Installation load	
		116.7	70	13.3 kg	113.9	12.5 kg	
3	Tightening torque of plug	11.0 ± 1.5 kgm					Retighten

OPERATION

Brake operated


- When the brake pedal is depressed, the rod of the master cylinder is pushed. Oil pressure P is generated, and this acts on the piston inside the brake cylinder to slide piston (6) slightly. Therefore, the rotation of disc (7), which is between inner ring (9) and outer ring (8), is stopped, and the brakes are applied to stop the machine.



419F089

Brake released

- When the oil pressure is released, piston (6) moves back slightly because of the return force of piston O-ring (11). A gap is created between inner ring (9) and outer ring (8), so disc (7) is free. Grooves are cut in a lattice pattern on the lining stuck to disc (7). When the disc is rotating, oil flows in these grooves to cool the lining.



419F090

MEASURING WEAR OF BRAKE DISC


- ★ Measurement condition
- Coolant temperature: Inside operating range

Unit: mm

Item	Standard value	Permissible value
Disc wear (one side)	1.02 – 1.14	Min. 0.7

Special tool

Part number	Part name	Q'ty
Commercially available	Feeler gauge	1

 Apply the parking brake and block the tires.

Measuring

1. Loosen drain plug (1) and drain the axle oil.

 Axle oil: 24 ℓ

2. Remove measuring plug (2).



3. Depress the brake pedal lightly.

★ Check that the piston is in close contact with the disc.

4. Insert a feeler gauge between disc (3) and plate (4), and measure the clearance.


5. Tighten the drain plug and add axle oil through the oil filler to the specified level.

 Axle oil: 24 ℓ



419F308


REMOVAL OF BRAKE BOOSTER

 Park the machine on level ground, set the safety bar on the frame, ground the bucket, shut down the engine, apply the parking brake and place blocks under the tires.

1. Draining oil


Disconnect hoses (1) and (2) between brake oil tank and brake booster, and drain brake oil.

 Brake oil: 1 ℓ




2. Hydraulic hoses, tubes

1) Disconnect hoses (3) and (4) between transmission and brake booster at brake booster end.



2) Disconnect brake tubes (5) and (6) from brake booster.





3. Brake booster

1) Remove cotter pin of rod linkage, then remove pin.


2) Disconnect connector (7) of transmission cut-off sensor.

3) Remove mounting bolts, then remove brake booster (8).

 Brake booster: 15 kg



REMOVAL OF PARKING BRAKE PAD

-  Park the machine on level ground, set the safety bar on the frame, ground the bucket, shut down the engine, apply the parking brake and place blocks under the tires.


1. Linkage

Remove pin (1).

- ★ Check that the parking brake is in the RE-LEASED position.

2. Pads

- 1) Extend lock plate (2) with a chisel, and remove bolts (3).
- 2) Remove calipers (4) and (5).
- 3) Remove nut from calipers (4) and (5), then remove pads (6) and (7).




INSTALLATION OF PARKING BRAKE PAD

1. Pads

- 1) Set pads (6) and (7) in mounting position, then secure with nut.
- 2) Set calipers (4) and (5) in mounting position, install lock plate (2), then tighten mounting bolts.
 - ★ Knock the tip of the lock plate into the caliper mount hole up to the root.

 Mounting bolt: 1.2 ± 0.1 kgm

- 3) Bend lock plate (2) with a chisel to lock bolt (3).




2. Linkage

Install pin (1).

- ★ Bend the cotter pin securely.

3. Adjusting linkage


- ★ For details of adjusting the linkage, see 52 TESTING AND ADJUSTING.



HYDRAULIC CIRCUIT DIAGRAM





(For 3-Spool, with emergency steering (if equipped))

Engine stopped



- | | |
|--------------------------------------|---------------------------------|
| 1. Hydraulic tank | 15. Safety valve (with suction) |
| 2. Oil filter | 16. Dump spool |
| 3. Hydraulic pump (SAR(3)-80) | 17. Lift spool |
| 4. Steering pump (SAR(3)-50) | 18. Suction valve |
| (SAR(3)-40: Serial No. 11118 and up) | 19. Lift cylinder |
| 5. Steering valve | 20. Dump cylinder |
| 6. Check valve | 21. Oil cooler |
| 7. Demand spool | 22. Main control valve |
| 8. Check valve | 23. Attachment spool |
| 9. Steering relief valve | 24. Attachment cylinder |
| 10. Steering spool | 25. Safety valve (with suction) |
| 11. Safety valve (with suction) | 26. Float valve |
| 12. Two-way restrictor valve | 27. Security valve |
| 13. Steering cylinder | 28. Diverter valve |
| 14. Relief valve | 29. Emergency pump |


MAIN CONTROL VALVE (For 2-Spool)



419F097

- A. From steering valve
- B. To dump cylinder rod side
- C. To dump cylinder bottom side
- D. To lift cylinder rod side
- E. To lift cylinder bottom side
- F. Drain port (To tank)
- G. Drain port
- H. Drain port

Lift spool at "FLOAT position"



F4190008


OPERATION

- When lift control lever (4) is pushed down further from the LOWER position, lift spool (3) is pushed into the FLOAT position.
- The oil flows from pump (1) through the steering valve. It then flows around the bypass circuit of dump spool (2) to the lift spool bypass circuit. The oil in the bypass circuit flows to the drain circuit because of the spool, but it cannot push open check valve (5).

In addition, RAISE circuit E and LOWER circuit D of the lift cylinder are connected to the drain circuit, so the lift arm goes down under its own weight.

- When the bucket is in contact with the ground, it can move up and down in accordance with the shape of the ground.

2. Adjusting

 Always stop the engine before adjusting the hydraulic pressure.

- 1) Stop the engine, open the engine hood and inspection cover, then remove the side cover.
- 2) Remove cap nut (1) of the relief valve.
- 3) Loosen lock nut (2), and turn adjustment screw (3) to adjust.

★ Amount of adjustment for 1 turn of screw


1 turn: **Approx. 35.7 kg/cm²**

★ Turn the adjustment screw as follows.

To **INCREASE** pressure, **TIGHTEN** screw.

To **DECREASE** pressure, **LOOSEN** screw.

★ If the relief pressure cannot be measured accurately, do not try to adjust the pressure.



419F312

9. Bucket moves slowly or has insufficient tilt back power.

Checks before troubleshooting

- Is the oil quantity in the hydraulic tank and the type of oil satisfactory?
- Is the stroke of the bucket control lever and the main control valve spool correct?
- Seizure of bushing in work equipment linkage.
- Was an unusually noise produced?

Fault check

- Check the amount of deficient tilt back force by performing actual work.
- Measure the operating speed of the bucket and check it against the judgement criterion table to determine whether or not it is normal.

Cause	Tank to pump		Demand valve	Control valve			Cylinder	
	a	b	c	d	e	f	g	h
	Blockage on suction side of pump to excessive amount of air contained in oil	Faulty work equipment pump	Faulty steering pump	Faulty demand valve	Faulty or incorrectly adjusted main relief valve cylinder	Faulty safety with suction valve on bottom of the dump	Internally worn or damaged valve body (dump spool)	Damaged dump cylinder piston seal

No.	Problem	Remedy	Cause									
			a	b	c	d	e	f	g	h		
1	Lift arm lifting force and lifting speed are abnormal and also bucket tilt back force and tilt back speed are abnormal.		△	X	X	X	X	X	X	X	X	X
2	Lift arm lifting force and lifting speed are normal but bucket tilt back force and tilt back speed are abnormal.								○	○	○	
3	Phenomena of item 1 become particularly bad when the oil temperature increases.			○	○							
4	The hydraulic pump emits an unusual noise.		○	○	○							
5	Steering action is light and excessively fast when the engine is at full throttle.					○						
6	Steering action is heavy and slow when the engine is at full throttle.		○		○							
7	The dump cylinder has a large amount of hydraulic drift.								○	○	○	
8	The relief pressure of main relief valve is low when the engine is at full throttle.						○	○	○	○		
9	The discharge volume of the hydraulic pump is low.			○	○							


The following symbols are used to indicate the action to be taken when a cause of failure is located.
 X: Replace △: Repair
 A: Adjust C: Clean

INSTALLATION OF HYDRAULIC, STEERING PUMP

1. Steering and hydraulic pump


Set pump (8) in mounting position, then tighten mounting bolts.

- ★ Check that there is an O-ring installed between the pump and housing.
- ★ This operation should be carried out by two workers.
- ★ There is little space, so be careful when working.




2. Hydraulic piping

1) Connect hoses (6) and (7) between hydraulic and steering pump and steering valve at pump end.




2) Connect tubes (4) and (5) between hydraulic tank and hydraulic and steering pump at pump end.




REMOVAL OF LIFT CYLINDER

- ⚠ Park the machine on level ground, set the safety bar on the frame, ground the bucket, shut down the engine, apply the parking brake and place blocks under the tires.
- ⚠ Loosen the oil filler cap to relieve the pressure in the hydraulic oil tank, then operate the control lever 2 or 3 times to eliminate the residual pressure in the piping.




1. Rod pin

- 1) Sling lift cylinder (1), remove lock bolt, then remove pin (2).
- 2) Start engine, and operate control levers to retract cylinder rod on side where pin has been removed.
 - ★ Do not retract the rod fully. Stop about 20 mm from the end of the stroke.




2. Hydraulic piping

- 1) Disconnect tube (3) and hose (4) at rod end from connector.
- 2) Disconnect tube (5) and hose (6) at bottom end from connector.
 - ★ Fit covers to prevent dirt or dust from entering the hoses or connections.




3. Lift cylinder

- 1) Remove lock bolt, then remove pin (7) at bottom end.
 - ★ There are shims installed, so check the number and thickness of the shims, and keep in a safe place.
- 2) Remove lift cylinder (1).
 - ★ Be careful of the center of gravity, and remove slowly.
 - ★ Be careful not to damage the cylinder rod.




 Lift cylinder: 115 kg




INSTALLATION OF WORK EQUIPMENT

 Use a bar to align the pin holes. Never use your fingers.

1. Dust seal, bushing



Press fit bushings (15) in bucket link, tilt lever, and lift arm, then assemble dust seal (14).

 Bushing: Grease (G2-L1)





2. Tilt lever, bucket link

1) Align holes of tilt lever (11) and lift arm (13), then install mounting pin (12) and lock with bolt.





2) Assemble cord ring on bucket link (9), align holes of tilt lever (11), then install pin (10) and lock with bolt.

- ★ Tie the bucket link to the tilt lever with wire.
- ★ Be careful not to let the cord ring get caught when installing.



LIFT CYLINDER



E419F144

Unit: mm

No.	Check item	Criteria				Remedy	
		Standard size	Tolerance		Standard clearance		Clearance limit
Shaft	Hole						
1	Clearance between rod and bushing	80	-0.100 -0.174	+0.271 +0.061	0.445 -0.161	0.745	Replace bushing
2	Clearance between piston rod mounting pin and inside diameter of hole	75	-	+0.219 +0.145	-	-	Replace
3	Clearance between cylinder bottom mounting pin and bushing	75	-	+0.174 +0.100	-	-	Replace bushing
4	Cylinder bore	140	-	+0.35 0	-	-	Replace
5	Tightening torque of cylinder head mounting bolt	83 ± 22 kgm				Retighten	
6	Tightening torque of piston mounting bolt	11.5 ± 1.0 kgm					

ENGINE STARTING CIRCUIT

OPERATION


When the FORWARD-REVERSE lever is placed at N (neutral), the neutral contacts of the direction lever switch are closed. When this happens and the starting switch is turned to START, electric current flows in the following circuit.

(1) Battery (+) → starting switch terminal B → starting switch terminal C → safety relay terminal E → terminal N of direction lever switch → ground connection.

When this happens, the safety relay is actuated and following circuit is formed.

(2) Battery (+) → battery relay → starting motor terminal B → starting motor terminal C. The engine then starts.

If the FORWARD-REVERSE lever is any in position except N (neutral), the circuit in (1) is not formed, so the engine does not start.




419F117A


MONITOR PANEL

- The monitor consists of the following components. CHECK module (1), CAUTION module (2), CAUTION module (3), gauge module (5), speedometer module (including service meter), the case, and various other components.
 - Each module (excluding the service meter) has its own microcomputer which processes the signals from the sensor and gives a display.
- The panel uses a liquid crystal display.


- CHECK (1), and CAUTION (2) and (3) modules all use common parts.
- The microcomputer judges which module it is from the wiring harness to which it is connected.
- Note:** Serial No. 20001 and up machines are equipped two modules.
(See Fig. U41901060).



(WA300-1 Serial No. 10001 – 19999)





(WA300-1 Serial No. 20001 and up, WA320-1)



- | | | |
|---|--|---|
| <p>1. Check (Be fore starting)</p> <ul style="list-style-type: none"> 1A. Brake oil level 1B. Engine oil level 1C. Coolant level <p>2. Caution (Warning)</p> <ul style="list-style-type: none"> 2A. Battery charge 2B. Fuel level <p>3. Caution (Emergency warning)</p> <ul style="list-style-type: none"> 3A. Brake oil level 3B. Engine oil pressure | <p>4. Pilot indicator</p> <ul style="list-style-type: none"> 4A. Preheat monitor 4B. Parking brake 4C. Work lamp 4D. Transmission cut off selector | <p>5. Gauge</p> <ul style="list-style-type: none"> 5A. Coolant temperature 5B. Torque converter oil temperature 5C. Fuel <p>6. Wipers</p> <p>7. Speedometer</p> <p>8. Head lamp (High beam)</p> <p>9. Service meter</p> <p>10. Service meter indicator</p> |
|---|--|---|











- When the lift arm goes up and reaches the set position for the kick-out (that is, the detection unit (steel plate) is separated from the sensing surface of the proximity switch), the proximity switch and relay circuit act to send electric current to the solenoid. This actuates the solenoid, the cam is pulled out of the cam detent, and the lift spool is returned to the neutral position by the return spring.




Movement of proximity switch

Position	Sensing surface of proximity switch is in contact with detection unit	Sensing surface of proximity switch is separated from detection unit
Operation display of proximity switch	ON	OFF
Proximity switch load circuit (relay switch circuit)	Current flows	Current shut off
Relay switch load circuit (solenoid circuit)	Current shuts off	Current flows

CONNECTOR TERMINAL NUMBERS



Connector	ECONOSEAL CONNECTOR	
	Female terminal (Socket)	Male terminal (Pin)
CN17,CN21 CN83,CN84 CN86,CN101 CN105,CN107 CN163,CN96 CN310	 <p>142F401A</p>	 <p>142F400A</p>
CN41 CN42 CN102 CN104	 <p>142F403A</p>	 <p>142F402A</p>
CN14 CN43	 <p>142F405A</p>	 <p>142F404A</p>
CN63 CN75 CN302 CN303 CN306	 <p>142F407A</p>	 <p>142F406A</p>
CN15,CN16 CN64,CN97 CN304	 <p>142F409A</p>	 <p>142F408A</p>

4. PREHEATING CIRCUIT SYSTEM





419F319A



CN54




CN16




CN85





Heater relay





Battery relay





CN13





CN54



CN16




CN391, CN392, CN393




E-15 PREHEATING DOES NOT STOP

- ★ When disconnecting or connecting the T-adapter (or socket adapter) or short connector, or when disconnecting the connector for checking, turn the starting switch OFF to prevent accidents.
- ★ When connecting the T-adapter (or socket adapter), connect to the connector specified. (CNxx ())
- ★ When disconnecting connectors or connecting T-adapters, return them to the original condition immediately after checking, then go to the next check.





Cause	Remedy
Defective glow switch	Replace
Defective heater relay	Replace
Contact between +24V wiring harness and heater relay output terminal — input terminal of electrical intake air heater or contact between +24V harness and CN13(2) — heater relay, CN13(3) — auto-preheating timer, or defective auto-preheating timer.	Repair or replace



Heater relay





CN13





CN51



CNP5



CNP8




CN86



M-14  (PREHEAT) LIGHTS UP OR DOES NOT LIGHT UP



- ★ When disconnecting connectors to connect the T-adapter (or socket adapter), turn the starting switch OFF.
- ★ When connecting the T-adapter (or socket adapter), connect to the connector specified in ().
- ★ After checking, connect the disconnected connectors again immediately.


a)  lights up.



Cause	Remedy
Defective CHECK BEFORE STARTING module	Replace
Defective contact, or disconnection in wiring harness between CNP4 (female)(6) and chassis ground, or between CNP4 (female)(10) – CN64 (12) – CN97 (6) – electrical intake air heater	After inspection repair (clean) or replace
See M-22	
Contact between chassis ground and electrical intake air heater (+) – CN97 (9) – CN64 (12) – CNP4 (female)(10).	Replace
Defective CHECK BEFORE STARTING module.	After inspection repair (clean) or replace

b)  does not light.

Note: The engine oil pressure or the battery charged value is indicated on the meter (which makes us think that the engine has run), even though the engine remains at rest. In this case, the engine is not preheated. (See failures  or .)




Troubleshooting tools	Tester	
	T-adapter (for DLI)	

M-18 TURN SIGNAL LAMPS, HIGH BEAM LIGHT UP OR DO NOT LIGHT UP


- ★ When disconnecting connectors to connect the T-adaptor (or socket adapter), turn the starting switch OFF.
- ★ When connecting the T-adaptor (or socket adapter), connect to the connector specified in ().
- ★ After checking, connect the disconnected connectors again immediately.

e) HIGH BEAM pilot lamp does not light up.

Note: If the head lamp cannot be switched to HIGH BEAM, see Troubleshooting for machine.



f) HIGH BEAM pilot lamp does not go out.




Troubleshooting tools	Tester	
	T-adaptor (for DLI)	T-adaptor or socket adapter (for Econoseal)


M-24 CENTRAL WARNING LAMP DOES NOT GO OUT

- ★ When disconnecting connectors to connect the T-adaptor (or socket adaptor), turn the starting switch OFF.
- ★ When connecting the T-adaptor (or socket adaptor), connect to the connector specified in ().
- ★ After checking, connect the disconnected connectors again immediately.

a) Monitor displays no abnormality, but central warning lamp light up intermittently.





b) Central warning lamp stays on continuously.




Troubleshooting tools	Tester	
	T-adaptor or socket adaptor (for Econoseal)	



CN42



CN43



CN107





TROUBLESHOOTING CHART FOR ELECTRONIC VEHICLE MONITORING SYSTEM (M-1 TO M-32)



WA300-1 Serial No. 20001 and up, WA320-1

M-1	Even engine is stopped, brake oil level display flashes	82-122
M-2	Even engine is stopped, engine oil level display flashes	82-122
M-3	Even engine is stopped, coolant level display flashes	82-124
M-4	Battery charge display flashes	82-124
M-5	Fuel level display flashes	82-126
M-6	When engine is running, even though there is no abnormality in machine, brake oil level display flashes	82-126
M-7	When engine is running, even though there is no abnormality in machine, engine oil pressure display flashes	82-128
M-8	When engine is running, even though there is no abnormality in machine, coolant level display flashes	82-128
M-9	When engine is running, even though there is no abnormality in machine, brake serve pressure display flashes (If equipped)	82-130
M-10	When engine is running, even though there is no abnormality in machine, coolant temperature display flashes	82-130
M-11	When engine is running, even though there is no abnormality in machine, torque converter oil temperature display flashes	82-132
M-12	Parking brake display lights up, or does not light up	82-134
M-13	Working lamp display lights up abnormally, or does not light up	82-136
M-14	Preheat display lights up or does not light up	82-138
M-15	Failure in main steering display lights up abnormally, or does not light up (If equipped)	82-140
M-16	Emergency steering normal display lights up or does not light up (If equipped)	82-142
M-17	Transmission cut-off display lights up or does not light up	82-144
M-18	Turn signal, high beam light up or do not light up	82-146
M-19	Speedometer display does not work	82-150
M-20	Hourmeter does not work normally	82-152
M-21	All or part of monitor panel does not work	82-154
M-22	Even when engine stopped, engine oil pressure display flashes, or battery charge display flashes	82-155
M-23	No lamps on monitor light up (Immediately after turning starting switch to "ON" engine stopped)	82-156
M-24	Central warning lamp does not go out	82-157
M-25	Central warning buzzer does not stop	82-158
M-26	None of panel lamps on machine monitor light up	82-159
M-27	Some of panel lamps on machine monitor do not light up	82-162
M-28	Emergency item is flashing, but alarm buzzer does not sound	82-163
M-29	Emergency item or non-emergency item is flashing, but warning lamp does not flash	82-164
M-30	Abnormality in fuel gauge	82-166
M-30-1	Abnormality in fuel level sensor	82-167
M-31	Abnormality in coolant temperature gauge	82-168
M-32	Abnormality in torque converter oil temperature gauge	82-170
	Table of monitor reference values	82-172


CNP2



CNP3




CN310




M-16  (EMERGENCY STEERING NORMAL) LIGHTS UP OR DOES NOT LIGHT UP (IF EQUIPPED)

- ★ When disconnecting connectors to connect the T-adaptor (or socket adapter), turn the starting switch OFF.
- ★ When connecting the T-adaptor (or socket adapter), connect to the connector specified in ().
- ★ After checking, connect the disconnected connectors again immediately.

a)  (emergency steering normal) light up.



b)  (emergency steering normal) does not light up.




Cause	Remedy
Emergency steering NORMAL sensor defective	Replace
Defective module (7851-51-6000)	Replace
Defective contact, or disconnection in wiring harness between chassis ground - CN322 (male) - CN323 (female) - CN149 connector - CNP3 (female) (7)	After inspection, repair (clean) or replace
Defective contact, or disconnection in wiring harness between CN322 and chassis ground	After inspection, repair (clean) or replace
Emergency steering NORMAL sensor defective	After inspection, repair (clean) or replace
Contact between chassis ground and CN323 (female) - CN149 (connector) - CNP3 (female) (7).	After inspection, repair (clean) or replace
Defective module (7851-51-6000)	Replace

Troubleshooting tools	Tester	
	T-adaptor (for DLI)	

M-20 HOURMETER DOES NOT WORK NORMALLY


- ★ When disconnecting connectors to connect the T-adapter (or socket adapter), turn the starting switch OFF.
- ★ When connecting the T-adapter (or socket adapter), connect to the connector specified in ().
- ★ After checking, connect the disconnected connectors again immediately.




M-27 SOME OF PANEL LAMPS ON MACHINE MONITOR DO NOT LIGHT UP

- ★ When disconnecting connectors to connect the T-adapter (or socket adapter), turn the starting switch OFF.
- ★ When connecting the T-adapter (or socket adapter), connect to the connector specified in ().
- ★ After checking, connect the disconnected connectors again immediately.

a) Panel lamps of monitor module do not light up.



b) Panel lamps of service meter do not light up.



Troubleshooting tools	Tester	T-adapter or socket adapter (for MIC)
		T-adapter (for DLI)

CNP6









TABLE OF MONITOR REFERENCE VALUES

System	Equipment name	Connector No.	Inspection method, Judgement	Condition for measurement	
Vehicle monitor	Brake fluid level sensor	CN86 (male)	Shorting connector 1) Case where a shorting connector is used; The sensor is faulty if the indication is as follows.	1) Starter switch "ON"	
			When shorting connector is connected		Monitor is out
			When CN86 is disconnected		Monitor is lit
			Continuity 1) Case of continuity test; The sensor is normal if the indication is as follows.		
			When brake fluid level is normal		No continuity
			When brake fluid level is low		Continuity
	Engine oil level sensor	CN96 (male)	Shorting connector 1) Case where a shorting connector is used; The sensor is faulty if the indication is as follows.	1) Starter switch "ON"	
			When shorting connector is connected		Monitor is out
			When CN96 is disconnected		Monitor is lit
			Continuity 1) Case of continuity test; The sensor is normal if the indication is as follows.		
When engine oil level is normal			Continuity		
When engine oil level is low			No continuity		
Radiator water level sensor		Shorting connector 1) Case where a shorting connector is used; The sensor is faulty if the indication is as follows.	1) Starter switch "ON"		
		When shorting connector is connected		Monitor is out	
		When CN107 is disconnected		Monitor is lit	

CAB



View Z


- 1. Front wiper
- 2. Front glass
- 3. Door
- 4. Rear wiper

419F114

6. Air blower

Remove mounting bolts, then remove air blower (21).

- ★ Be careful not to damage the seal at the contact face between the air blower and the air conditioner unit.



**7. Air conditioner unit**

Remove mounting bolts (22), (23) and (24), then remove air conditioner unit (25).


- ★ Move the air conditioner unit outside the cab, then lift off.
- ★ Be careful not to damage the connector of the air conditioner hoses.



Air conditioner unit: 80 kg



- ★ When repairing the inside of the air conditioner unit, follow Steps 1 – 4, then remove cover (26).
- When removing the cover, disconnect the connectors of the air conditioner wiring and the temperature regulator cable, then remove the cover.



• **"TRAPPING" PHENOMENON OF THE OIL**

When a gear pump is rotating with the gears in mesh as shown in the drawing at right, in some instances two sets of gear teeth are in mesh while in other instances only one set of the gear teeth is in mesh. When two sets of the teeth are in mesh simultaneously, the oil in the space between the meshed gear teeth will be trapped inside — the front and rear exits will be completely shut.

This is called the "trapping" phenomenon of oil.


The space in which the oil is trapped moves from the suction side to the delivery side as the gears rotate. The volume of the space gradually decreases from the start of trapping until the space reaches the center section, and then gradually increases after leaving the center section until the end of trapping.

Since the oil itself is non-shrinkable, a reduction of the volume of space will greatly increase the oil pressure, unless some provision is made to relieve oil pressure. The high pressure oil will cause the pump to make noise and vibrate.

To prevent this, relief notches are provided on the side plates to release the oil to the delivery side.


As shown in the drawing below, the relief notches are provided in such a way that the oil can be relieved from the trapping space to the delivery side when the volume of the space is reduced.

Relief notches are also provided on the suction side to prevent the formation of a vacuum in the space by allowing the oil to enter the space from the suction side when the space is expanded.




230F143

Fixed side plate type



230F144

Pressure loaded type



230F145

Note 1) If it is impossible to raise the pump speed to the value shown in the table because of limitations of the test bench, calculate the allowance for the delivery from the following formula:

$$Q = Q_0 - \frac{(N_0 - N) Q_{th}}{1000}$$


however, $N \geq 1000$ rpm
 where, N: RPM of test bench
 Q: Repair limit for delivery at N rpm (liters/min)
 N_0 : RPM in the table (liters/min)
 Q_0 : Repair limit for delivery in the table
 Q_{th} : Capacity code

Note 2) If the test bench allows the pump to raise its delivery pressure above 140 kg/cm² but not above 210 kg/cm², use the repair limit for delivery given in Table, No. 1.

Note 3) For pumps whose service pressure exceeds 50 kg/cm² in operation, use Table, No. 1. (Do not use Table, No. 2)

Note 4) The volumetric efficiency of a pump decreases after the pump is reassembled. After reassembly, therefore, perform the following tests with a test bench or flow-meter kit (790-303-1001).

(1) Shock test
20 times



(2) Performance test (measure the delivery)

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL