

# SHOP MANUAL

## **KOMATSU**

# **WA700-3**

## **(KA SPEC.)**

**MACHINE MODEL**

**SERIAL NO.**

**WA700-3**

**51005 and up**

- This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you may require.  
Materials and specifications are subject to change without notice.
- WA700-3 mount the SAA6D170E-3 engine.  
For details of the engine, see the 170-3 Series Engine Shop Manual.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

**HOW TO READ THE SHOP MANUAL**

**VOLUMES**

Shop manuals are issued as a guide to carrying out repairs. They are divided as follows:

- Chassis volume:** Issued for every machine model
- Engine volume:** Issued for each engine series
- Electrical volume:** Each issued as one volume to cover all models
- Attachments volume:** Each issued as one volume to cover all models


These various volumes are designed to avoid duplicating the same information. Therefore, to deal with all repairs for any model, it is necessary that chassis, engine, electrical and attachment volumes be available.

**DISTRIBUTION AND UPDATING**


Any additions, amendments or other changes will be sent to KOMATSU distributors. Get the most up-to-date information before you start any work.

**FILING METHOD**


1. See the page number on the bottom of the page. File the pages in correct order.
2. Following examples show how to read the page number.  
Example 1 (Chassis volume):



Example 2 (Engine volume):



3. Additional pages: Additional pages are indicated by a hyphen (-) and number after the page number. File as in the example.



**REVISED EDITION MARK**

When a manual is revised, an edition mark ((1)(2)(3)....) is recorded on the bottom of the pages.

**REVISIONS**

Revised pages are shown in the LIST OF REVISED PAGES next to the CONTENTS page.

**SYMBOLS**

So that the shop manual can be of ample practical use, important safety and quality portions are marked with the following symbols.

Symbol	Item	Remarks
	Safety	Special safety precautions are necessary when performing the work.
	Caution	Special technical precautions or other precautions for preserving standards are necessary when performing the work.
	Weight	Weight of parts of systems. Caution necessary when selecting hoisting wire, or when working posture is important, etc.
	Tightening torque	Places that require special attention for the tightening torque during assembly.
	Coat	Places to be coated with adhesives and lubricants, etc.
	Oil, water	Places where oil, water or fuel must be added, and the capacity.
	Drain	Places where oil or water must be drained, and quantity to be drained.

# CONVERSION TABLE

## METHOD OF USING THE CONVERSION TABLE

The Conversion Table in this section is provided to enable simple conversion of figures. For details of the method of using the Conversion Table, see the example given below.

### EXAMPLE


- Method of using the Conversion Table to convert from millimeters to inches
1. Convert 55 mm into inches.
    - (1) Locate the number 50 in the vertical column at the left side, take this as (A), then draw a horizontal line from (A).
    - (2) Locate the number 5 in the row across the top, take this as (B), then draw a perpendicular line down from (B).
    - (3) Take the point where the two lines cross as (C). This point (C) gives the value when converting from millimeters to inches. Therefore, 55 mm = 2.165 inches.
  2. Convert 550 mm into inches.
    - (1) The number 550 does not appear in the table, so divide by 10 (move the decimal point one place to the left) to convert it to 55 mm.
    - (2) Carry out the same procedure as above to convert 55 mm to 2.165 inches.
    - (3) The original value (550 mm) was divided by 10, so multiply 2.165 inches by 10 (move the decimal point one place to the right) to return to the original value. This gives 550 mm = 21.65 inches.

1 mm = 0.03937 in

	0	1	2	3	4	5	6	7	8	9
0	0	0.039	0.079	0.118	0.157	0.197	0.236	0.276	0.315	0.354
10	0.394	0.433	0.472	0.512	0.551	0.591	0.630	0.669	0.709	0.748
20	0.787	0.827	0.866	0.906	0.945	0.984	1.024	1.063	1.102	1.142
30	1.181	1.220	1.260	1.299	1.339	1.378	1.417	1.457	1.496	1.536
40	1.575	1.614	1.654	1.693	1.732	1.772	1.811	1.850	1.890	1.929
(A) --- 50	1.969	2.008	2.047	2.087	2.126	2.165	2.205	2.244	2.283	2.323
60	2.362	2.402	2.441	2.480	2.520	2.559	2.598	2.638	2.677	2.717
70	2.756	2.795	2.835	2.874	2.913	2.953	2.992	3.032	3.071	3.110
80	3.150	3.189	3.228	3.268	3.307	3.346	3.386	3.425	3.465	3.504
90	3.543	3.583	3.622	3.661	3.701	3.740	3.780	3.819	3.858	3.898



Machine model		WA700-3		
Serial No.		51005 and up		
Engine	Model		SAA6D170E-3	
	Type		4-cycle, water-cooled, in-line, 6-cylinder, direct injection, with turbocharger, after-cooler	
	No. of cylinders – bore × stroke	mm	6 – 170 × 170	
	Piston displacement	ℓ {cc}	23.15 {23,150}	
	Performance	Flywheel horsepower	kW/rpm {HP/rpm}	502/2,000 {672/2,000}
		Maximum torque	Nm/rpm {kgm/rpm}	2,884/1,400 {294/1,400}
		Fuel consumption ratio (at rated output)	g/kW·h {g/HP·h}	214 {160}
		High idling speed	rpm	2,240
		Low idling speed	rpm	725
	Starting motor		24 V 7.5 kW × 2	
Alternator		24 V 75 A		
Battery		12 V 200 Ah × 2		
Power train	Torque converter		3-element, 1-stage, single-phase	
	Transmission		Planetary gear, constant-mesh multiple-disc, hydraulically actuated, pressure rised lubrication, modulation type	
	Reduction gear		Spiral bevel gear, splash lubrication	
	Differential		Straight bevel gear	
	Final drive		Planetary gear single stage, splash lubrication	
Axle, wheel	Drive type		Front/rear-wheel drive	
	Front axle		Fixed-frame, full-floating	
	Rear axle		Center pin support type, full-floating	
	Tire		40/65-39-36PR(L-5)	
	Wheel rim		32.00 × 39-4WTB	
	Inflation pressure	Front tire Rear tire	kPa {kg/cm <sup>2</sup> } kPa {kg/cm <sup>2</sup> }	441 {4.5} 441 {4.5}
Brakes	Main brake		Front/rear wheel braking, separate front/rear wheel, wet disc, hydraulically actuated	
	Parking brake		Drive shaft, dry caliper type disc brake, hydraulically released spring type	

# POWER TRAIN SYSTEM



SWW03409

TORQUE CONVERTER AND PTO




**SPECIFICATIONS**

Type: 3-element, single stage, single phase  
 Stall torque ratio: 2.84

- 1. Torque converter outlet oil pressure pick-up
  - 2. Torque converter inlet oil pressure pick-up
  - 3. Steering and switch pump mounting
  - 4. Main pump mounting
  - 5. Coupling
  - 6. Torque converter charging, cooling, PPC and brake pump mounting
- 
- A. Torque converter outlet port
  - B. Torque converter oil temperature sensor mounting port
  - C. Torque converter inlet port
  - D. Drain port (to transmission)

SJW06563

FORWARD 2ND



SWW03421

- In the case of FORWARD 2nd, FORWARD clutch (8) and 2nd clutch (15) are engaged. The power transmitted from the torque converter to input shaft (1) is transmitted to output shaft (25).
- FORWARD clutch (8) is actuated by the oil pressure applied by the clutch piston, and holds ring gear (9) in position. 2nd clutch (15) is actuated by the oil pressure applied by the clutch piston, and engages ring gear (14) and hub (16).
- The power from the torque converter is transmitted to input shaft (1). The rotation of input shaft (1) is transmitted through sun gear (7) to planet gear (10). Ring gear (9) is held in position by FORWARD clutch (8), so the rotation of planet gear (10) rotates carrier (28) inside ring gear (9).
- The rotation of carrier (28) is transmitted along two paths. One path goes through planet gear (11) and rotates ring gear (14). The other goes through planet gear (11) and sun gear (12) and is transmitted to output shaft (25).
- Ring gear (14) and hub (16) are formed into one unit by 2nd clutch (15), and the rotation of hub (16) is transmitted to output shaft (25).
- The rotation of output shaft (25) is output in combination with the power transmitted from sun gear (12) and hub (16).


**PILOT REDUCING VALVE**

**FUNCTION**


- The pilot reducing valve acts to control the pressure needed to actuate the transmission spools.

**OPERATION**

- The oil from the pump passes through the pilot filter and enters port **A** of pilot reducing valve (1). The oil passes through port **B** and enters through the orifice of transmission spool (2) to fill the inside of port **C**.



- When the pressure inside port **C** rises, pressurized oil flows from orifice "a" of pilot reducing valve (1) and goes to port **D**. As a result, pilot reducing valve (1) moves to the right, and ports **A** and **B** are shut off, so the pressurized oil at port **C** is maintained at the same pressure.



**EMERGENCY MANUAL SPOOL**


**FUNCTION**

- A directional spool and the speed spools are installed to make it possible to actuate the transmission valve mechanically if there should be a failure in the electrical system of the transmission controller system and the solenoid valve cannot be actuated. (This spool is used to move the machine under its own power to a place where it can be serviced.)
  - ★ When using this spool, pay particularly careful attention to safety.

**OPERATION**


• **Normal position**

When the solenoid valve is working normally, spool (3) is held in the position shown in the diagram. The oil from the directional spool and speed spool (1) enters port **A**, but it is shut off by solenoid valve (2).




• **Clutch at OFF position**

When emergency manual spool (3) is pushed in to the left (screwed in 10 mm), the oil at port **A** is shut off regardless of the operation of solenoid valve (2). It cannot flow to port **B**, so the clutch is not actuated.




• **Clutch at ON position**

When emergency manual spool (3) is pulled out to the right (loosened 10 mm), the oil at port **A** is drained to port **B** regardless of the operation of solenoid valve (2). Therefore, the clutch is actuated.



# DIFFERENTIAL

## FRONT DIFFERENTIAL




SWW03429

- 1. Bevel gear (Teeth 43)
- 2. Differential case
- 3. Side gear (Teeth 24)

- 4. Shaft
- 5. Bevel pinion (Teeth 9)
- 6. Pinion gear (Teeth 17)

# STEERING AND SWITCH PUMP

MODEL: HPF95 + HPV95



- |                   |                     |
|-------------------|---------------------|
| 1. Shaft (front)  | 9. Impeller         |
| 2. Cradle (front) | 10. Cradle (rear)   |
| 3. Case (front)   | 11. Shaft (rear)    |
| 4. Swash plate    | 12. Case (rear)     |
| 5. Shoe           | 13. End cap (rear)  |
| 6. Piston         | 14. End cap (front) |
| 7. Cylinder block | 15. Servo piston    |
| 8. Valve plate    | 16. Collar          |

### Specification

SWW06458


	Steering and switch pump
Model	HPF95 + HPV95
Rated delivery pressure	31.4 MPa {320 kg/cm <sup>2</sup> }
Rated rpm	2,120 rpm
Theoretical delivery (front)	97.4 cc/rev
Theoretical delivery (rear)	10 – 97.4 cc/rev
Max. delivery	206.5 + 206.5 ℓ/min

### OUTLINE

- This pump consists of 1 fixed-displacement swash plate-type piston pump on the front side, 1 variable-displacement swash plate-type piston pump on the rear side, and 1 impeller pump between them.
- The front pump is originally of the variable displacement type, but its displacement is

- fixed since inserted collar (16) disables servo piston (15) and fixes swash plate (4).
- For explanation of the operation, see the section of the work equipment pump. The work equipment pump is of the variable displacement type, however, since its rocker cam can move.

Engine running at high speed




SDW01634

- There is no need for supply of extra oil from the switch pump, so the steering pump pressure rises until notch **g** closes and shuts off the merge passage from port **B**.
- The pressure difference on both sides of notch **c** is controlled only by notch **f**, and the excess oil from the steering pump is drained from notch **f** to the drain circuit. (At this point, notch **g** is completely closed.)
- The oil from the steering pump passes through notches **c** and **d**, pushes load check valve (5), and flows to the cylinder. The return oil from the cylinder passes through notch **e** and flows to the drain circuit.
- Notch **g** is closed, so the oil from the switch pump all flows from port **B** and is sent to the main control valve.


OPERATION

- Pump and engine are working normally.



SJW06827

When the steering pump and engine are working normally, the steering pump, and switch pump are rotated by the engine. Therefore, oil is sent to the steering valve, and the machine can be steered. In addition, the emergency steering pump is rotated by the transmission, so oil from port **A** of the diverter valve pushes open check valve (2) and enters port **B**. Pressure oil from the steering pump is flowing to port **D**, so it pushes spool (3) in the direction of the arrow. As a result, the oil from port **B** flows to port **C** and is drained to the hydraulic tank.



SJW06828


**Brake released (right brake valve)**

**Upper portion**


- When pedal (1) is released and the operating force is removed from the top of the spool, the back pressure from the brake cylinder and the force of the spool return spring move spool (3) up. Drain port **a** is opened and the oil from the brake cylinder flows to the hydraulic tank return circuit to release the rear brake.

**Lower portion**

- When the pedal is released, spool (3) in the upper portion moves up. At the same time, the back pressure from the brake cylinder and the force of the spool return spring move spool (5) up. Drain port **b** is opened and the oil from the brake cylinder flows to the hydraulic tank return circuit to release the front brake.



## BRAKE




SJW06587

1. Guide pin
2. Return spring
3. Brake piston
4. Disc
5. Plate
6. Floating seal


1. Hydraulic tank
2. Breather
3. Oil filter
4. Torque converter & transmission, cooling, PPC, and brake pumps
5. Differential pressure valve
6. Work equipment pump (main piston pump)
7. CO valve
8. ES valve
9. Servo valve
10. Control pump
11. Steering and switch pumps
12. Servo valve
13. Solenoid valve
14. Emergency steering pump
15. Diverter valve
16. Alarm lamp switch
17. Emergency relief valve (20.6 MPa {210 kg/cm<sup>2</sup>})
18. Hydraulic oil cooler
19. Cold relief valve
20. PPC relief valve
21. Check valve
22. Accumulator
23. PPC valve
24. Work equipment valve
25. Bucket spool
26. Boom spool
27. Relief valve (31.4 MPa {320 kg/cm<sup>2</sup>})
28. Safety-suction valve (36.8 MPa {375 kg/cm<sup>2</sup>})
29. Unload valve
30. Float selector valve (2.6 MPa {26 kg/cm<sup>2</sup>})
31. Rotary valve
32. Oil pressure switch
33. Lock valve
34. EPC valve
35. Steering demand valve
36. Demand spool
37. Steering spool
38. Relief valve (31.4 MPa {320 kg/cm<sup>2</sup>})
39. Surge cut relief valve (33.3 MPa {340 kg/cm<sup>2</sup>})
40. Overload relief valve (33.3 MPa {340 kg/cm<sup>2</sup>})
41. Slow-return valve (2-way restrictor valve)
42. Steering cylinder
43. Boom cylinder
44. Bucket cylinder

# SERVO VALVE




SXW04029

1. Plug
2. Arm
3. Spool
4. Body
5. Sleeve
6. Sleeve
7. Spool
8. Plug



SXW04030

RELIEF VALVE



9JY00851


1. Main valve
2. Piston
3. Piston spring
4. Poppet
5. Poppet spring
6. Plug with valve seat
7. Sleeve
8. Adjustment screw
9. Lock nut
10. Orifice

FUNCTION


- The relief valve is installed at the inlet of the work equipment valve. When the oil pressure rises above the specified level, this valve drains the oil into the hydraulic tank to limit the maximum pressure of the work equipment circuit and protect the circuit.

OPERATION


- Ports **A** and **B** are connected to the pump circuit and drain circuit respectively. The oil pressure in port **A** is applied through the hole of piston (3) to port **C**.
- When the oil pressure is below the set relief pressure, poppet (4) is in contact with the seat of plug (6) and the oil does not flow from chamber **C** into the drain circuit. Accordingly, the oil pressure in port **A** is equal to that in chamber **C**.
- Since  $d2 < d3$ , main valve (2) is in contact with the left side. The sectional areas are set in the following order;  $d5 > d4 > d1 > d3 > d2$ .
- If the pump pressure is raised by spring (5) to the relief pressure poppet (4) opens and the oil in chamber **C** is drained through chamber **D**.
- If poppet (4) opens, the oil flows from **A** through **C** to **D**.
- As the oil flows from **A** → **C** [hole through piston (2)], its pressure lowers. As a result, the pressure in chamber **C** is lower than that in port **A**, thus main valve (1) moves to the right.
- Then, the oil flows from port **A** to port **B** and limits the maximum pressure to protect the circuit.



9JY00859




9JY00860



9JY00861

BUCKET SPOOL IN "TILT BACK"



SJW06799


OPERATION

- When bucket lever (4) is pulled, the pressure oil at port L of the PPC valve flows from port P to port R. In addition, the oil at port V flows to the drain circuit. The pressure oil at port R moves bucket spool (1) to the TILT position.
- The bypass circuit is closed by bucket spool


- (1), so the oil from port A pushes open check valve (10). The oil from check valve (10) flows from port E to port D, and then flows to the cylinder bottom.
- At the same time, the oil at the cylinder rod end flows from port G to drain port C, and returns to the tank, so the bucket is tilted.

**BUCKET TILT**

- When the bucket is dumped beyond the set position for the auto-leveler, the sensor (steel plate) is above the detection surface of the bucket proximity switch, so electric current flows in the proximity switch load circuit. The positioner relay is turned ON and the current for the solenoid is shut off.




SVW03369




SEW02327

- When the bucket lever is moved to the TILT position, the bucket spool is held at the TILT position by the cam follower and cam on the lever, and the bucket tilts.




SVW03369



SEW02328

# MAINTENANCE MONITOR



SJW06832

- |   |   |   |
|---|---|---|
| <p>1. Check items (Checks before starting)</p> <p>1A. Engine water level</p> <p>1B. Engine oil level</p> <p>2. Caution items (warning items)</p> <p>2A. Engine oil pressure</p> <p>2B. Brake oil pressure</p> <p>2C. Battery charge</p> | <p>2D. Air cleaner</p> <p>2E. Transmission oil filter</p> <p>3. Gauge items</p> <p>3A. Fuel level</p> <p>3B. Engine water temperature</p> <p>3C. Torque converter oil temperature</p> | <p>4. Service meter</p> <p>4A. Service meter numeric display</p> <p>4B. Service meter RUN pilot lamp</p> <p>5. Monitor module</p> <p>6. Switch module</p> |
|---|---|---|

## OUTLINE

- The maintenance monitor has a display function for the caution items and gauges.
- The maintenance monitor consists of the monitor module, switch module, service meter, case, and other mechanisms.
- The monitor module has a built-in CPU (Central Processing Unit). It processes the signal from the sensors, and carries out the display and output.
- A liquid crystal display and LEDs are used for the display portions. The switches are embossed sheet switches.

**11. Function selection signal**

This signal is a GND/OPEN digital signal. When the engine is started, the function is judged from this signal.

1) Model selection

**Table 4 Machine model selection signal table**

Machine model	CN3B-2	CN3B-10	CN3B-3
WA600-3	OPEN	OPEN	GND
WA700-3	GND	OPEN	OPEN

2) Engine selection

**Table 5 Engine selection table**

	Engine	Komatsu	Cummins
Signal and data			
Engine selection (CN3A-10)		OPEN	GND

3) Option function selection

**Table 6 Option (function) selection table**

Input signal	Signal condition			
Auto-shift transmission (opt) (CN3A-20)	OPEN	GND	OPEN	GND
Joystick steering (opt) (CN3B-1)	OPEN	OPEN	GND	GND
Applicable model	Function			
WA600-3 WA700-3	Not set (*1)	Transmission auto/manual	Not set (*1)	Transmission auto/manual & joystick auto/manual

\*1: When Not set condition is detected, all controller outputs are turned OFF and it is impossible to travel.

★ After displaying the program part number, the LED display shows [0.0.].

**12. Engine speed sensor signal**

This signal is a pulse signal. It converts the pulses from the electromagnetic pickup sensor to rotation speed for control. When the engine speed is 1450 rpm or above, it is called the engine speed ON mode, and when the speed is less than 1450 rpm, it is called the engine speed OFF mode.


**13. Travel speed sensor signal**

This signal is a pulse signal. It converts the pulses from the electromagnetic pickup sensor to rotation speed for control.

**14. Communications signal (S-NET)**

This transmits the troubleshooting code to the main monitor.

# ENGINE STARTING CIRCUIT



### Function

- The neutral safety circuit is employed to secure safety when the engine is started. This circuit allows the engine to start only when the forward-reverse lever and the joystick steering lever are in the **N** (Neutral) position.
- If the starting switch is turned to the **OFF** position, supply of the fuel is stopped to stop the engine.

### Operation


- If the forward-reverse lever is set in the **N** (Neutral) position, the neutral contacts of the forward-reverse lever are “closed”. If the starting switch is turned to the ON position, the neutral relay operates to “close” terminals 3 – 5. Then, the current flows from starting switch terminal **BR** through the battery relay coil to the ground to “close” the battery relay. While the joystick steering lever is in the **N** (Neutral) position, the current does not flow from the transmission and joystick steering controller to the steering lever neutral safety

relay coil and relay contacts 3 – 6 are “closed”

If the starting switch is turned to the START position, the current flows from the positive (+) terminal of battery through starting switch terminals **B** and **C**, neutral relay terminals ⑤ and ③, steering lever neutral safety relay terminals ⑥ and ③, and starting motor terminals **C** and **E** to the ground.

- The ECM controller controls the fuel injection rate and injection timing according to various signals.
- The circuit from the battery through battery relay to starting motor terminal **B** is formed to start the engine.
- If the forward-reverse switch is not in the **N** (Neutral) position, the neutral relay does not operate, thus the starting circuit is not formed and the engine does not start. If the joystick steering lever is not in the **N** (Neutral) position, the steering lever neutral safety relay operates to break the starting circuit, thus the engine does not start.

2-2 When parking brake switch is OFF (actuated) before starting switch is turned ON



SJW06838

- Electric current flows in circuit ① from the battery → starting switch → battery relay coil → ground, so the battery relay is closed. However, in this case, the parking brake switch is OFF (released), so the parking safety relay is not actuated. For this reason, the electric current does not flow to the parking brake solenoid valve, so after the automatic parking brake is applied, the parking brake is not released automatically even when the starting switch is turned ON.
- In addition, the electric current does not flow to the transmission & joystick steering controller, so the machine does not move.

## VHMS CONTROLLER

### VHMS: Vehicle Health Monitoring System



- ★ For details of the basic precautions, outlines, method of sending and receiving data, and the procedure for the initial setup, see TESTING AND ADJUSTING.

#### Specifications

1. Voltage of power supply : DC20V - DC30V
2. Size : W272 x D169 x H72 (mm)

#### Function

The VHMS controller collects and stores signals from each sensor and signals from the machine controller. It also gives commands for transmitting the accumulated data through the communications satellite.




## BLOW-BY PRESSURE SENSOR

#### Specifications

1. Voltage of power supply: DC5V
2. Output voltage : Min. 0.5V (at engine stopped)
3. Size: Mount (portion a) : R 1/4 : Outside diameter of seat receiving pressure : 37 mm : Length of cable: 1,110 mm

#### Function

The blow-by sensor converts the pressure inside the engine crankcase into a voltage and inputs this into the VHMS controller as the blow-by pressure.




# STANDARD VALUE TABLE FOR CHASSIS

Machine model				WA700-3				
Category	Item		Measurement conditions	Unit	Standard value for new machine	Service limit value		
Directional lever	Operating effort	N-FORWARD, REVERSE	<ul style="list-style-type: none"> <li>• Engine stopped</li> <li>• Measure at center of lever knob</li> </ul>	N{kg}	5.88 <sup>+4.9</sup> <sub>-2.94</sub> {0.6 <sup>+0.5</sup> <sub>-0.3</sub> }	Max. 16.7 {1.7}		
	Travel	N-FORWARD, REVERSE		mm	35 ± 10	35 ± 10		
Speed control lever	Operating effort	1st – 2nd	<ul style="list-style-type: none"> <li>• Engine stopped</li> <li>• Measure at center of lever knob</li> </ul>	N{kg}	5.88 <sup>+4.9</sup> <sub>-2.94</sub> {0.6 <sup>+0.5</sup> <sub>-0.3</sub> }	Max. 16.7 {1.7}		
		2nd – 3rd			5.88 <sup>+4.9</sup> <sub>-2.94</sub> {0.6 <sup>+0.5</sup> <sub>-0.3</sub> }	Max. 16.7 {1.7}		
		3rd – 4th			5.88 <sup>+4.9</sup> <sub>-2.94</sub> {0.6 <sup>+0.5</sup> <sub>-0.3</sub> }	Max. 16.7 {1.7}		
	Travel	1st – 2nd		mm	35 ± 10	35 ± 20		
		2nd – 3rd			35 ± 10	35 ± 20		
		3rd – 4th			35 ± 10	35 ± 20		
Work equipment control lever	Operating effort	HOLD→RAISE	<ul style="list-style-type: none"> <li>• Engine speed: Low idling</li> <li>• Hydraulic oil temperature: 45 – 55°C</li> </ul>	N {kg}	Max. 23.5 {2.4}	Max. 35.3 {3.6}		
		RAISE→HOLD			Max. 15.7 {1.6}	Max. 23.5 {2.4}		
		HOLD→LOWER			Max. 24.5 {2.5}	Max. 37.3 {3.8}		
		LOWER→HOLD			—	—		
		LOWER→FLOAT			Max. 34.3 {3.5}	Max. 52.0 {5.3}		
		FLOAT→HOLD			Max. 14.7 {1.5}	Max. 22.6 {2.3}		
	Bucket	HOLD→DUMP		Max. 23.5 {2.4}	Max. 35.3 {3.6}			
		HOLD→TILT		Max. 23.5 {2.4}	Max. 35.3 {3.6}			
		TILT→HOLD		Max. 14.7 {1.5}	Max. 22.6 {2.3}			
	Travel	Boom		HOLD→RAISE	<ul style="list-style-type: none"> <li>• Engine speed Low idling</li> <li>• Hydraulic oil temperature: 45 – 55°C</li> </ul>	mm	67 ± 15	67 ± 30
				HOLD→LOWER			53 ± 15	53 ± 30
				HOLD→FLOAT			67 ± 15	67 ± 30
Bucket		HOLD→DUMP	60 ± 15	60 ± 30				
		HOLD→TILT	60 ± 15	60 ± 30				
Steering wheel	Play		<ul style="list-style-type: none"> <li>• Engine stopped</li> <li>• Machine facing straight to front</li> </ul>	mm	Max. 20	Max. 20		
	Operating effort		<ul style="list-style-type: none"> <li>• Flat, horizontal, straight, dry paved road surface</li> </ul>	N {kg}	10.0 ± 3.0 {1.0 ± 0.3}	Max. 19.6 {2.0}		
	Turns		<ul style="list-style-type: none"> <li>• Engine speed: High idling</li> <li>• Leftt lock - righ lock</li> </ul>	Turns	4.0 ± 0.7	Max. 4.5		
	Operating time	Low idling	<ul style="list-style-type: none"> <li>• Engine running</li> <li>• Hydraulic oil temperature: 45 – 55°C</li> <li>• Leftt lock - righ lock</li> </ul>	sec.	Max. 5.5	Max. 6.5		
		High idling			Max. 4.7	Max. 5.0		

System	Name of component	Connector No.	Inspection method	Judgement table	Measurement conditions											
Others	Emergency brake switch	C07, C08 (male)	Measure resistance	<p>If the condition is as shown in the table below, it is normal.</p> <table border="1"> <tr> <td>Accumulator pressure: Min. <math>3.92 \pm 0.49</math> MPa {<math>40 \pm 5</math> kg/cm<sup>2</sup>}</td> <td rowspan="2">Between C07, C08 (1) – (2)</td> <td>Max. 1 Ω</td> </tr> <tr> <td>Depress brake and lower accumulator pressure to below <math>3.63 \pm 0.49</math> MPa {<math>37 \pm 5</math> kg/cm<sup>2</sup>}</td> <td>Min. 1 MΩ</td> </tr> </table>	Accumulator pressure: Min. $3.92 \pm 0.49$ MPa { $40 \pm 5$ kg/cm <sup>2</sup> }	Between C07, C08 (1) – (2)	Max. 1 Ω	Depress brake and lower accumulator pressure to below $3.63 \pm 0.49$ MPa { $37 \pm 5$ kg/cm <sup>2</sup> }	Min. 1 MΩ	<ol style="list-style-type: none"> <li>1) Turn starting switch OFF.</li> <li>2) Disconnect connectors.</li> <li>3) Connect T-adapter.</li> </ol>						
	Accumulator pressure: Min. $3.92 \pm 0.49$ MPa { $40 \pm 5$ kg/cm <sup>2</sup> }	Between C07, C08 (1) – (2)	Max. 1 Ω													
	Depress brake and lower accumulator pressure to below $3.63 \pm 0.49$ MPa { $37 \pm 5$ kg/cm <sup>2</sup> }		Min. 1 MΩ													
	Emergency brake switch	BC01	Measure voltage	<p>If the condition is as shown in the table below, it is normal.</p> <table border="1"> <tr> <td>Accumulator pressure: Min. <math>3.92 \pm 0.49</math> MPa {<math>40 \pm 5</math> kg/cm<sup>2</sup>}</td> <td rowspan="2">Between (4) – (5)</td> <td>20 – 30 V</td> </tr> <tr> <td>Depress brake and lower accumulator pressure to below <math>3.63 \pm 0.49</math> MPa {<math>37 \pm 5</math> kg/cm<sup>2</sup>}</td> <td>Max. 1 V</td> </tr> </table>	Accumulator pressure: Min. $3.92 \pm 0.49$ MPa { $40 \pm 5$ kg/cm <sup>2</sup> }	Between (4) – (5)	20 – 30 V	Depress brake and lower accumulator pressure to below $3.63 \pm 0.49$ MPa { $37 \pm 5$ kg/cm <sup>2</sup> }	Max. 1 V	<ol style="list-style-type: none"> <li>1) Turn starting switch OFF.</li> <li>2) Insert T-adapter.</li> <li>3) Turn starting switch ON.</li> </ol>						
	Accumulator pressure: Min. $3.92 \pm 0.49$ MPa { $40 \pm 5$ kg/cm <sup>2</sup> }	Between (4) – (5)	20 – 30 V													
	Depress brake and lower accumulator pressure to below $3.63 \pm 0.49$ MPa { $37 \pm 5$ kg/cm <sup>2</sup> }		Max. 1 V													
Bucket positioner proximity switch	F05	Measure voltage	<p>If the condition is as shown in the table below, it is normal.</p> <table border="1"> <tr> <td></td> <td>When screwdriver is brought close</td> <td>When screwdriver is not brought close</td> </tr> <tr> <td>Between (1) – (2)</td> <td>20 – 30 V</td> <td>Max. 3 V</td> </tr> <tr> <td>Between (1) – (3)</td> <td>20 – 30 V</td> <td>20 – 30 V</td> </tr> <tr> <td>Between (2) – (3)</td> <td>Max. 3 V</td> <td>20 – 30 V</td> </tr> </table>		When screwdriver is brought close	When screwdriver is not brought close	Between (1) – (2)	20 – 30 V	Max. 3 V	Between (1) – (3)	20 – 30 V	20 – 30 V	Between (2) – (3)	Max. 3 V	20 – 30 V	<ol style="list-style-type: none"> <li>1) Turn starting switch OFF.</li> <li>2) Insert T-adapter.</li> <li>3) Turn starting switch ON.</li> </ol>
	When screwdriver is brought close	When screwdriver is not brought close														
Between (1) – (2)	20 – 30 V	Max. 3 V														
Between (1) – (3)	20 – 30 V	20 – 30 V														
Between (2) – (3)	Max. 3 V	20 – 30 V														
Boom kick-out proximity switch	F06	Measure voltage	<p>If the condition is as shown in the table below, it is normal.</p> <table border="1"> <tr> <td></td> <td>When screwdriver is brought close</td> <td>When screwdriver is not brought close</td> </tr> <tr> <td>Between (1) – (2)</td> <td>20 – 30 V</td> <td>Max. 3 V</td> </tr> <tr> <td>Between (1) – (3)</td> <td>20 – 30 V</td> <td>20 – 30 V</td> </tr> <tr> <td>Between (2) – (3)</td> <td>Max. 3 V</td> <td>20 – 30 V</td> </tr> </table>		When screwdriver is brought close	When screwdriver is not brought close	Between (1) – (2)	20 – 30 V	Max. 3 V	Between (1) – (3)	20 – 30 V	20 – 30 V	Between (2) – (3)	Max. 3 V	20 – 30 V	<ol style="list-style-type: none"> <li>1) Turn starting switch OFF.</li> <li>2) Insert T-adapter.</li> <li>3) Turn starting switch ON.</li> </ol>
	When screwdriver is brought close	When screwdriver is not brought close														
Between (1) – (2)	20 – 30 V	Max. 3 V														
Between (1) – (3)	20 – 30 V	20 – 30 V														
Between (2) – (3)	Max. 3 V	20 – 30 V														
Boom kick-out solenoid	L16	Measure resistance	<p>If the condition is as shown in the table below, it is normal.</p> <table border="1"> <tr> <td>Between (1) – (2)</td> <td>19 – 23 Ω</td> </tr> <tr> <td>Between (1), (2) – chassis</td> <td>Min. 1 MΩ</td> </tr> </table>	Between (1) – (2)	19 – 23 Ω	Between (1), (2) – chassis	Min. 1 MΩ	<ol style="list-style-type: none"> <li>1) Turn starting switch OFF.</li> <li>2) Disconnect connectors.</li> <li>3) Connect T-adapter.</li> </ol>								
Between (1) – (2)	19 – 23 Ω															
Between (1), (2) – chassis	Min. 1 MΩ															
Bucket positioner solenoid	L17	Measure resistance	<p>If the condition is as shown in the table below, it is normal.</p> <table border="1"> <tr> <td>Between (1) – (2)</td> <td>19 – 23 Ω</td> </tr> <tr> <td>Between (1), (2) – chassis</td> <td>Min. 1 MΩ</td> </tr> </table>	Between (1) – (2)	19 – 23 Ω	Between (1), (2) – chassis	Min. 1 MΩ	<ol style="list-style-type: none"> <li>1) Turn starting switch OFF.</li> <li>2) Disconnect connectors.</li> <li>3) Connect T-adapter.</li> </ol>								
Between (1) – (2)	19 – 23 Ω															
Between (1), (2) – chassis	Min. 1 MΩ															


## MEASURING BLOW-BY PRESSURE

1. Install the nozzle of pressure test kit **E** to blow-by hose (1), then connect to the pressure test kit.
2. Run the engine at near rated output, and measure the blow-by pressure.

 When measuring, be careful not to touch any hot parts or rotating parts.

**Note:**


- ★ Blow-by varies greatly according to the condition of the engine. Therefore, if the blow-by value is considered abnormal, check for problems connected with defective blow-by, such as excessive oil consumption, defective exhaust gas color, and prematurely dirty or deteriorated oil.




# MEASURING FUEL CIRCUIT PRESSURE

## 1. Measuring fuel pump inlet pressure

- 1) Connect adapter **C4**, hose **C5**, and oil pressure gauge **C6** to inlet pressure pickup coupler (1).
  - ★ Connect nipple [1] of hydraulic tester **C1** to adapter **C4**.
  
- 2) Run the engine at high idling and measure the fuel pump inlet pressure.
  - ★ Check that the fuel pump inlet pressure is in the following range.
  - ★ Fuel pump inlet pressure (negative pressure):



Engine speed	Fuel pump inlet pressure (kPa {mmHg})	Condition
High idling	Max. -13.6 {Max. -102}	When new filter is used
	Max. -27.1 {Max. -203}	Normal



## 2. Adjusting


### Adjusting output voltage of potentiometer

- 1) Check that punch mark (2) made on intermediate connector (1) between the case and potentiometer is on the side where it can be seen.

Insert the protruding part of the potentiometer into the groove in the intermediate connector, then temporarily tighten the mounting screw.

 Potentiometer mounting surface:

#### Cemedyne POS seal



 Potentiometer mounting screw: **LT-2**

- 2) Set the pedal to the low idling position, impress a voltage of DC5V on the potentiometer, and turn the potentiometer to the left and right to set it within the range for the low idling output voltage.
  - Output voltage at low idling:  $4.1^{+0.2}_{-0.1}$  V

Operate the pedal 2 or 3 times and check that the voltage is within the specified output voltage range at the low idling position. If the voltage is not within the specified range, carry out the adjustment again.

  - ★ When adjusting the low idling output voltage, first operate the pedal 2 or 3 times at the lowest output voltage position, then turn the potentiometer to increase the voltage until it is within the specified voltage range. This will keep the play on one side and make it easier to adjust.
- 3) Next, operate the pedal to the high idling position and check that the voltage is within the high idling output voltage range.
  - Output voltage at high idling:  $0.7 \pm 0.2$  V


If the voltage is not within the specified range, adjust the low idling voltage again within the specified range and adjust so that both the low idling and high idling voltages are the specified voltage.
- 4) If the high idling voltage does not enter the voltage range with the procedure up to Step 3), remove the pin from the bottom of stopper bolt (3), loosen the stopper bolt, and move it up or down to adjust so that the high idling voltage is within the voltage range.
  - ★ Adjust the position of the hole so that the pin can enter the hole at the bottom of the bolt.
  - ★ The stopper bolt is already properly adjusted, so do not adjust it unless there is some special reason.
- 5) Tighten the potentiometer mounting screw.



## TESTING BRAKE OIL PRESSURE


### 1. Inspecting brake oil pressure

- 1) Remove bleeder screw (1), then install oil pressure gauge tool I (19.6 MPa {200 kg/cm<sup>2</sup>}), the elbow, joint, bleeder screw, and nipple,
- 2) Connect hose (2) to the bleeder screw and bleed the air from the brake circuit. For details, see BLEEDING AIR.
- 3) Depress the left brake and measure the brake oil pressure.



### 2. Measuring drop in brake piston pressure

- 1) Remove bleeder screw (1), then install oil pressure gauge tool I (19.6 MPa {200 kg/cm<sup>2</sup>}), the elbow, joint, bleeder screw, and nipple.
  - 2) Connect hose (2) to the bleeder screw and bleed the air from the brake circuit. For details, see BLEEDING AIR.
  - 3) Stop the engine, depress the left brake pedal, leave for 5 minutes with the oil pressure at 4.9 MPa {50 kg/cm<sup>2</sup>}, and measure the drop in pressure.
- ★ Be careful not to move the brake pedal for 5 minutes.
  - ★ After completing the operation, bleed the air from the brake circuit again.



## BLEEDING AIR FROM PISTON PUMP

★ If the oil in the hydraulic tank has been changed, or the piston pump has been removed, or the piston pump piping has been removed, bleed the air as follows to prevent seizure of the pump.



1. Check that the oil in the hydraulic tank is at the upper level.
  - ★ The cap of the hydraulic tank remains removing, until the air bleeding of the piston pump finishes.

2. Loosen plugs (1) and (2) of the tube at the suction side of the piston pump.

3. Let oil flow out in turn from plugs (1) and (2), and when the air is completely bled from the piston pump, tighten the plugs. After that, in order to fill the inside of the pump with the hydraulic oil, leave it for 10 minutes.

★ The oil level in the hydraulic tank is higher than the positions of parts (1) and (2), so it is possible to bleed the air easily.

4. Loosen the mouthpiece of the case drain hose (3), starting an engine at the condition of low idling. Tighten the mouthpiece, confirming that hydraulic oil flows from the mouthpiece.



# Pm CLINIC INSPECTION TABLE

WA700-3

		Machine serial No.	#
	-hour inspection	Engine serial No.	SAA6D170E-3
Work instruction No.	Date of execution		Service meter
	Year:	Month:	Inspector
	Day:	hours	

## Interview with operator and walk-around check

Is there abnormality before starting inspection?		Outside temperature											
-----		Max.: °C											
-----		Min.: °C											
-----		Height: m											
What is maximum level of coolant temperature? (During work)		What is maximum level of torque converter and transmission oil temperature? (During work)											
White	Green	Green	Green	Green	Red	Red	Green	Green	Green	Green	Green	Red	Red
1	2	3	4	5	6	7	1	2	3	4	5	6	7

### ★ After starting engine

Item	Condition		Unit	Standard value for new machine	Service limit value	Measurement result	Good	Bad	
ENGINE	Engine speed	Low idling	rpm	700 – 750	—				
		High idling		2240 – 2300	—				
		Torque converter stall		2125 – 2225	1975 – 2275				
		Hydraulic stall		2100 – 2200	1950 – 2250				
		Full stall		1520 – 1720	1320 – 1920				
	Blow-by pressure	Torque converter stall		kPa {mmAq}	Max. 3.92 {Max. 400}	Max. 7.9 {Max. 800}			
	Engine lubricating oil pressure	SAE30 or SAE15W-40	Engine: Full throttle	MPa {kg/cm <sup>2</sup> }	0.39 – 0.54 {4.0 – 5.5}	Min. 0.21 {Min. 2.1}			
			Engine: Low idling		Min. 0.12 {Min. 1.2}	Min. 0.07 {Min. 0.7}			
		SAE10W	Engine: Full throttle		0.34 – 0.49 {3.5 – 5.0}	Min. 0.18 {Min. 1.8}			
			Engine: Low idling		Min. 0.10 {Min. 1.0}	Min. 0.05 {Min. 0.5}			
Boost pressure	Torque converter stall		kPa {mmHg}	Min. 120 {Min. 900}	Min. 107 {Min. 800}				
Exhaust temperature	Outside temperature		°C	—	—				
	Torque converter stall			Max. 650	Max. 700				

T/C	Inlet pressure 1	Engine: Full throttle	MPa {kg/cm <sup>2</sup> }	0.65 – 0.85 {6.6 – 8.6}	0.65 – 0.85 {6.6 – 8.6}			
	Outlet pressure 2	Torque converter oil temperature: 60 – 80°C Transmission: Neutral		0.54 – 0.64 {5.5 – 6.5}	0.54 – 0.64 {5.5 – 6.5}			

### ★ When the transmission is in the speed range, apply the brake fully.

TRANSMISSION	Item	Condition	Engine: Full throttle Oil temperature: (SAE30) 70 – 90°C	MPa {kg/cm <sup>2</sup> }	Standard value for new machine	Service limit value	Measurement result	Good	Bad	
	Main relief pressure	P6			Transmission: Neutral	2.94 – 3.24 {30.0 – 33.0}				2.94 – 3.24 {30.0 – 33.0}
	Modulating pressure in N & 1st	P1			Forward-reverse lever: Neutral Gearshift lever: 2nd → 1st	2.94 – 3.24 {30.0 – 33.0}				2.94 – 3.24 {30.0 – 33.0}
	Modulating pressure in N & 2nd	P1			Forward-reverse lever: Neutral Gearshift lever: 1st → 2nd	2.94 – 3.24 {30.0 – 33.0}				2.94 – 3.24 {30.0 – 33.0}
	Reducing pressure	P3				2.2 – 2.4 {22.5 – 24.5}				2.2 – 2.4 {22.5 – 24.5}
	Modulating pressure in N & 3rd	P1			Forward-reverse lever: Neutral Gearshift lever: 2nd → 3rd	2.94 – 3.24 {30.0 – 33.0}				2.94 – 3.24 {30.0 – 33.0}
	Modulating pressure in N & 4th	P1			Forward-reverse lever: Neutral Gearshift lever: 3rd → 4th	2.94 – 3.24 {30.0 – 33.0}				2.94 – 3.24 {30.0 – 33.0}
	Modulating pressure in F & 4th	P1			Forward-reverse lever: Neutral → F Gearshift lever: 4th	2.94 – 3.24 {30.0 – 33.0}				2.94 – 3.24 {30.0 – 33.0}
Modulating pressure in R & 4th	P1	Forward-reverse lever: Neutral → R Gearshift lever: 4th	2.94 – 3.24 {30.0 – 33.0}	2.94 – 3.24 {30.0 – 33.0}						


**3) External communication function**




- Connect the PC (personal computer) to the VHMS controller, download the data, and transmit the data through the Internet.
- Send the data automatically from remote areas through the communications satellite (ORB).

(12): Ground level download connector

(13): Download connector inside cab

(14): Communications antenna/pole

 Antenna mount:  
**Thread tightener (LT-2)**



## POINTS TO REMEMBER WHEN TROUBLESHOOTING

- ⚠ Stop the machine in a level place, and check that the safety pin, blocks, and parking brake are securely fitted.
- ⚠ When carrying out the operation with two or more workers, keep strictly to the agreed signals, and do not allow any unauthorized person to come near.
- ⚠ If the radiator cap is removed when the engine is hot, hot water may spurt out and cause burns, so wait for the engine to cool down before starting troubleshooting.
- ⚠ Be extremely careful not to touch any hot parts or to get caught in any rotating parts.
- ⚠ When disconnecting wiring, always disconnect the negative (-) terminal of the battery first.
- ⚠ When removing the plug or cap from a location which is under pressure from oil, water, or air, always release the internal pressure first. When installing measuring equipment, be sure to connect it properly.

The aim of troubleshooting is to pinpoint the basic cause of the failure, to carry out repairs swiftly, and to prevent reoccurrence of the failure.

When carrying out troubleshooting, an important point is of course to understand the structure and function. However, a short cut to effective troubleshooting is to ask the operator various questions to form some idea of possible causes of the failure that would produce the reported symptoms.

### 1. When carrying out troubleshooting, do not hurry to disassemble the components.

If components are disassembled immediately any failure occurs:

- Parts that have no connection with the failure or other unnecessary parts will be disassembled.
- It will become impossible to find the cause of the failure.

It will also cause a waste of manhours, parts, or oil or grease, and at the same time, will also lose the confidence of the user or operator.

For this reason, when carrying out troubleshooting, it is necessary to carry out thorough prior investigation and to carry out troubleshooting in accordance with the fixed procedure.

### 2. Points to ask user or operator

- 1) Have any other problems occurred apart from the problem that has been reported?
- 2) Was there anything strange about the machine before the failure occurred?
- 3) Did the failure occur suddenly, or were there problems with the machine condition before this?
- 4) Under what conditions did the failure occur?
- 5) Had any repairs been carried out before the failure?  
When were these repairs carried out?
- 6) Has the same kind of failure occurred before?

### 3. Check before troubleshooting

- 1) Check the oil level
- 2) Check for any external leakage of oil from the piping or hydraulic equipment.
- 3) Check the travel of the control levers.

- 4) Check the stroke of the control valve spool.
- 5) Other maintenance items can be checked externally, so check any item that is considered to be necessary.

### 4. Confirming failure

Confirm the extent of the failure yourself, and judge whether to handle it as a real failure or as a problem with the method of operation, etc.

- ★ When operating the machine to reenact the troubleshooting symptoms, do not carry out any investigation or measurement that may make the problem worse.

### 5. Troubleshooting

Use the results of the investigation and inspection in Items 2 – 4 to narrow down the causes of failure, then use the troubleshooting flowchart to locate the position of the failure exactly.

- ★ The basic procedure for troubleshooting is as follows.
  - 1) Start from the simple points.
  - 2) Start from the most likely points.
  - 3) Investigate other related parts or information.







### 6. Measures to remove root cause of failure

Even if the failure is repaired, if the root cause of the failure is not repaired, the same failure will occur again.









To prevent this, always investigate why the problem occurred. Then, remove the root cause.

## CHECKS BEFORE TROUBLESHOOTING

	Item	Judgement standard	Remedy
Lubricating oil, cooling water	1. Check fuel level, type of fuel	—	Add fuel
	2. Check for impurities in fuel	—	Clean, drain
	3. Check hydraulic oil level	—	Add oil
	4. Check hydraulic filter (Torque convert, Transmission hydraulic oil)	—	Clean, drain
	5. Check brake oil level	—	Add oil
	6. Check engine oil level	—	Add oil
	7. Check coolant level	—	Add water
	8. Check dust indicator for clogging	—	Clean or replace
Electrical equipment	9. Check for looseness, corrosion of battery terminal, wiring	—	Tighten or replace
	10. Check for looseness, corrosion of alternator terminal, wiring	—	Tighten or replace
	11. Check for looseness, corrosion of starting motor terminal, wiring	—	Tighten or replace
	12. Check operation of instruments	—	Repair or replace
Hydraulic, mechanical equipment	13. Check for abnormal noise, smell	—	Repair
	14. Check for oil leakage	—	Repair
	15. Carry out air bleeding	—	Bleed air
	16. Check effect of parking brake, wheel brake	—	Repair or replace
Electrics, electrical equipment	17. Check battery voltage (engine stopped)	24 – 26 V	Replace
	18. Check battery electrolyte level	—	Add or replace
	19. Check for discolored, burnt, exposed wiring	—	Replace
	20. Check for missing wiring clamps, hanging wiring	—	Repair
	21. Check for water leaking on wiring (be particularly careful attention to water leaking on connectors or terminals)	—	Disconnect connector and dry
	22. Check for blown, corroded fuses	—	Replace
	23. Check alternator voltage (engine running at 1/2 throttle or above) (If the battery charge is low, the voltage may be approx. 25V immediately after starting.)	28.5 – 29.5 V	Replace
	24. Sound of actuation of battery relay (when starting switch is turned ON, OFF)	—	—

No. of pins	S-type connector		
	Male (female housing)	Female (male housing)	T-adapter Part No.
10 (Blue)			—
12 (Blue)			799-601-7160
	Part No.: 08056-11272	Part No.: 08056-11282	
16 (Blue)			799-601-7170
	Part No.: 08056-11672	Part No.: 08056-11682	

[The pin No. is also marked on the connector (electric wire insertion end)]

Type (shell size code)	HD30 Series connector		
	Body (plug)	Body (receptacle)	T-adapter Part No.
18-8 (1)	Pin (male terminal)	Pin (female terminal)	799-601-9210
	 BWP05001	 BWP05002	
	Part No.: 08191-11201, 08191-11202, 08191-11205, 08191-11206		Part No.: 08191-14101, 08191-14102, 08191-14105, 08191-14106
	Pin (female terminal)	Pin (male terminal)	799-601-9210
 BWP05003	 BWP05004		
Part No.: 08191-12201, 08191-12202, 08191-12205, 08191-12206		Part No.: 08191-13101, 08191-13102, 08191-13105, 08191-13106	
18-14 (2)	Pin (male terminal)	Pin (female terminal)	799-601-9220
	 BWP05005	 BWP05006	
	Part No.: 08191-21201, 08191-21202, 08191-21205, 08191-21206		Part No.: 08191-24101, 08191-24102, 08191-24105, 08191-24106
	Pin (female terminal)	Pin (male terminal)	799-601-9230
 BWP05007	 BWP05008		
Part No.: 08191-22201, 08191-22202, 08191-22205, 08191-22206		Part No.: 08191-23101, 08191-23102, 08191-23105, 08191-23106	

## METHOD OF DISPLAYING ACTION CODE AND FAILURE CODE

### 1. Outline

The speedometer display on the main monitor is used to display the troubleshooting for each control system. The nature of the troubleshooting is displayed as the failure action code, failure code, and the time elapsed since failure.

The signals between the main monitor and each controller are transmitted in serial through the network circuit. (Only the engine controller uses a special parallel signal.)

### 2. Display of failure action code

This code informs the operator directly of the abnormality, and takes action, such as stopping the machine immediately.

There are three types of action code: E00, E01 + CALL (E01 and CALL are displayed alternately), and CALL. If a failure occurs suddenly, one of these codes is shown on the speedometer display.



### 3. Failure code and time elapsed since failure

The failures detected by each controller are changed to a code and displayed. It is possible to tell from this code which system in which controller has failed, so carry out troubleshooting for the applicable controller.

### 4. Saving failure code

The transmission controller writes the failure codes to memory.

- 1) A total of 9 failure codes can be saved in memory.
  - 2) The data that is saved to memory is as follows:
    - (1) Failure code
    - (2) Time elapsed since failure (up to 1000 hours)
  - 3) The failures are saved in the order that they occur. If a failure code already exists in the memory, the repeat failure code is not saved.
  - 4) If there are already 9 items in memory, and a 10th failure occurs, the oldest item is deleted and the new item is saved.
- ★ It is possible to display the failure code and time elapsed since failure for items saved in memory by operating the main monitor set switch.



• **Example of troubleshooting when exhaust gas is black**

Let us assume that [Clogged air cleaner] is taken to be the cause of black exhaust gas. Three symptoms have causal relationship with this problem: [Exhaust gas slowly became black], [Power slowly became weaker], and [Dust indicator is red].

If we look from these three symptoms to find the causes, we find that there is a relationship with five causes. Let us explain here the method of using this causal relationship to pinpoint the most probable cause.

**S-7 Exhaust gas is black (incomplete combustion)**

General causes why exhaust gas is black

- Insufficient intake of air
- Improper condition of fuel injection
- Excessive injection of fuel

		Causes										
		Seized turbocharger, interference	Clogged air cleaner element	Worn piston ring, cylinder	Clogged, seized injection nozzle	Improper injection timing	Defective injection pump (excessive injection)	Crushed, clogged muffler	Leakage of air between turbocharger and head	Defective contact of valves, valve seat	Defective injection pump (rack, plunger seized)	
Questions	Confirm recent repair history											
	Degree of use		△	△	△					△		
	Color of exhaust gas	Suddenly became black	○			○					○	
		Gradually became black	◎			◎					◎	
		Blue under light load				○						
	Engine oil must be added more frequently											
	Power was lost	Suddenly	◎						○		○	
		Gradually		○	○					○	○	
	Non-specified fuel has been used					○					○	
	Noise of interference is heard from around turbocharger	◎										
Dust indicator is red	◎											
Blow-by gas is excessive		○										
Check items	Engine pickup is poor and combustion is irregular	○			◎			○	○	○	○	
	When exhaust manifold is touched immediately after starting engine, temperature of some cylinders is low				◎						○	
	Match marks on fuel injection pump are out of alignment					○						
	Seal on injection pump has come off						○					
	Clanging sound is heard from around cylinder head							○				
	Exhaust noise is abnormal	○		○					◎			
	Muffler is crushed								◎			
	Leakage of air between turbocharger and head, loose clamp								◎			
	Troubleshooting	When turbocharger is rotated by hand, it is found to be heavy	●									
		When air cleaner is inspected directly, it is found to be clogged		●								
When compression pressure is measured, it is found to be low				●						●		
Speed of some cylinders does not change when operating on reduced cylinders					●							
When check is made using delivery method, injection timing is found to be incorrect						●						
Injection pump test shows that injection amount is incorrect							●					
When valve clearance is checked directly it is found to be outside standard value								●				
When muffler is removed, exhaust gas color returns to normal									●			
When control rack is pushed, it is found to be heavy or does not return										●		
Remedy	Replace	Clean	Replace	Replace	Adjust	Adjust	Adjust	Repair	Replace	Replace		

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

### S-3 Engine does not pick up smoothly (follow-up is poor)

General causes why engine does not pick up smoothly

- Insufficient intake of air
  - Insufficient supply of fuel
  - Defective condition of fuel spray
  - Improper fuel used
  - Abnormality in fuel control system
  - Defective HPI sensor
  - Defective HPI actuator
  - Normal output is not applied
- See Troubleshooting S-6

Causes										
Clogged air cleaner element	Seized turbocharger	Defective contact of valve and valve seal	Improper valve clearance	Worn piston ring, cylinder liner	Clogged fuel tank cap	Loose piping, fuel filter, entry of air	Clogged fuel filter, strainer	Defective fuel pump	Defective injector	Failure boost pressure sensor

Questions											
	Clogged air cleaner element	Seized turbocharger	Defective contact of valve and valve seal	Improper valve clearance	Worn piston ring, cylinder liner	Clogged fuel tank cap	Loose piping, fuel filter, entry of air	Clogged fuel filter, strainer	Defective fuel pump	Defective injector	Failure boost pressure sensor
Confirm recent repair history											
Degree of use of machine	Operated for long period	△						△			
Engine pick-up suddenly became worse		◎	○			○	◎			○	
Non-specified fuel is being used								◎	◎	◎	
Replacement of filters has not been carried out according to Operation Manual		◎						◎		○	
Engine oil must be added more frequently					◎						
Dust indicator is red		◎									
Air breather hole in fuel tank cap is clogged						◎					
Rust and water are found when fuel tank is drained							◎	◎			
There is leakage from fuel piping							◎				
When engine is cranked with starting motor, and	Fuel pump outlet port coupler is pushed, almost no fuel comes out							◎	◎		
	Fuel pump outlet port coupler is pushed, air comes out together with fuel					◎	◎				
When exhaust manifold is touched immediately after starting engine, temperature of some cylinders is low										◎	
Color of exhaust gas	Blue under light load				◎						
	Black	◎	◎	○						◎	◎
Clanging sound is heard from around cylinder head				◎							
Noise of interference is heard from around turbocharger		◎									
High idling speed under no load is normal, but speed suddenly drops when load is applied								◎	◎		◎
There is hunting from engine (rotation is irregular)								○	◎	○	
Blow-by gas is excessive					◎						

Troubleshooting											
	Clogged air cleaner element	Seized turbocharger	Defective contact of valve and valve seal	Improper valve clearance	Worn piston ring, cylinder liner	Clogged fuel tank cap	Loose piping, fuel filter, entry of air	Clogged fuel filter, strainer	Defective fuel pump	Defective injector	Failure boost pressure sensor
Inspect air cleaner element directly	●										
When turbocharger is rotated by hand, it is found to be heavy		●									
When compression pressure is measured, it is found to be low			●		●						
Inspect valve clearance directly				●							
When pressure at outlet port of fuel pump is measured, it is found to vary						●	●				
Inspect fuel filter, strainer directly								●			
When negative pressure at inlet port of fuel pump is measured, it is found to be high								●			
When pressure at outlet port of fuel pump is measured, it is found to be low									●		
When temperature of injector of each cylinder is measured, there are some cylinders that are low										●	
When intake air pressure (boost pressure) is measured, it is found to be normal											●
Inspect actuator directly (Resistance and filter for clogging)											
Inspect sensor directly (Output voltage and resistance)											
Inspect for air leakage											

Remedy	Clogged air cleaner element	Seized turbocharger	Defective contact of valve and valve seal	Improper valve clearance	Worn piston ring, cylinder liner	Clogged fuel tank cap	Loose piping, fuel filter, entry of air	Clogged fuel filter, strainer	Defective fuel pump	Defective injector	Failure boost pressure sensor
Clean	●										
Correct		●									
Replace			●		●						
Correct				●							
Replace											
Correct						●	●				
Clean								●			
Clean									●		
Replace										●	
Replace											●
Replace											●

## S-8 Oil consumption is excessive (or exhaust smoke is blue)

★ To prevent the oil from leaking up or down in the turbocharger, do not run the engine at idling for more than 20 minutes continuously (both low and high idling).

General causes why oil consumption is excessive

- Abnormal combustion of oil
- External leakage of oil
- Wear of parts in lubrication system


		Causes															
		Dust sucked in from intake system	Turbocharger		Worn seal at turbine end	Worn seal at blower end	Worn, damaged valve (stem, guide, seal)	Worn piston ring, cylinder liner	Broken piston ring	Clogged breather or breather hose	Worn, broken rear oil seal	Too much engine oil added	Leakage from oil drain plug	Broken oil cooler	Leakage from oil filter or oil cooler	Leakage from oil piping	Leakage from oil pan or cylinder head
Questions	Confirm recent repair history																
	Degree of use of machine		Operated for long period		△	△	△	△									
	Oil consumption suddenly increased							⊙			⊙		○				
	Engine oil must be added more frequently							⊙					○				
	Engine oil becomes contaminated quickly							⊙	○	○							
	Oil level is above H level on gauge											⊙					
	Outside of engine is dirty with oil												⊙		⊙	⊙	⊙
	There are loose piping clamps in intake system																
	Inside of turbocharger intake pipe is dirty with oil																
	Inside of exhaust pipe is dirty with oil																
	There is oil in engine cooling water														⊙		
	Oil level in clutch chamber or damper chamber rises																
	Exhaust smoke is blue under light load																
	Amount of blow-by gas	Excessive															
None																	
Troubleshooting	When intake manifold is removed, dust is found inside																●
	Excessive play of turbocharger shaft																●
	When intake manifold is removed, inside is found to be dirty with oil																●
	When compression pressure is measured, it is found to be low																●
	Inspect breather element directly																●
	Inspect rear oil seal directly																●
	There is external leakage of oil from engine																●
	Pressure-tightness test of oil cooler shows there is leakage																●
	Remedy	Correct	Replace	Replace	Correct	Replace	Replace	Clean	Correct	Correct	Correct	Replace	Correct	Correct	Correct	Correct	

Auto-shift specification


a)	When monitor switch (transmission cut-off switch) is pressed, cut-off function is not switched and display does not change .....	20-371
b)	When monitor switch (transmission cut-off switch) is OFF, monitor display goes out but cut-off function is actuated when pedal is depressed .....	20-371
c)	When monitor display is turned off (transmission cut-off switch turned OFF), cut-off function is always actuated .....	20-371
d)	Cut-off function is always actuated regardless of monitor display (transmission cut-off switch ON or OFF) .....	20-371
e)	Monitor display lights up (transmission cut-off switch turned ON), but cut-off function is not actuated .....	20-372
M-11	Abnormality in parking brake dragging warning .....	20-373
a)	When parking brake is applied, buzzer sounds (intermittently) and caution lamp flashes even when directional lever is at N .....	20-373
b)	When parking brake is applied, buzzer does not sound and caution lamp does not light up even when directional lever is at position other than N .....	20-373
M-12	When parking brake dragging warning is given, buzzer and caution lamp are actuated continuously, or they are not actuated .....	20-375
a)	Actuated continuously .....	20-375
b)	Not actuated .....	20-375
M-13	Abnormality in buzzer .....	20-376
a)	Buzzer does not sound when starting switch is at ON (for 3 seconds) (during self-check) .....	20-376
b)	Buzzer always sounds .....	20-376
M-14	Condition of monitor switches is not stored in memory .....	20-377
M-15	Abnormality in failure display mode .....	20-378
a)	Does not enter failure display mode .....	20-378
b)	Count for time elapsed since failure in failure display mode does not advance .....	20-378
M-16	Abnormality in emergency steering actuation display .....	20-379
a)	Emergency steering actuation display does not light up .....	20-379
b)	Emergency steering actuation display stays lighted up .....	20-379
M-17	Abnormality in auto-greasing system .....	20-380
a)	Forced greasing cannot be carried out .....	20-380
b)	Monitor display flashes rapidly (2 times/sec) .....	20-380
c)	When no more grease remains, monitor display flashes rapidly (2 times/sec) .....	20-380
d)	Monitor display flashes slowly (1 time/sec) .....	20-381
e)	Monitor display goes out .....	20-381
M-18	Abnormality in low idling select system .....	20-382
a)	Display does not change when switch is pressed .....	20-382
b)	Monitor display lights up but low idling select function does not work .....	20-382

M-4 Related electrical circuit diagram

Standard specification




Auto-shift specification



**e) Monitor display lights up (transmission cut-off switch turned ON), but cut-off function is not actuated**

		Cause	Remedy	
<p><b>1</b></p> <p>Does cut-off function work when L12 is disconnected?</p> <ul style="list-style-type: none"> <li>• Disconnect L12.</li> <li>• Turn starting switch ON.</li> </ul>	YES	Defective transmission cut-off switch	Replace	
	NO	<p><b>2</b></p> <p>Does cut-off function work when L06 is disconnected?</p> <ul style="list-style-type: none"> <li>• Disconnect L06.</li> <li>• Turn starting switch ON.</li> </ul>	Defective main monitor	Replace
	YES		Defective transmission controller	Replace
	NO	<p><b>3</b></p> <p>Is voltage between C5 (6) and chassis ground normal?</p> <ul style="list-style-type: none"> <li>• Disconnect L12.</li> <li>• Turn starting switch ON.</li> <li>• 20 – 30 V</li> </ul>	Short circuit with power source in harness between L06 (female) (3) – C5 (female) (6) – L12 (female) (1)	Repair or replace

**M-10 Related electrical circuit diagram**



TWW02289

### M-18 Abnormality in low idling select system

- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.


a) Display does not change when switch is pressed

	Cause	Remedy
	Defective main monitor	Replace

b) Monitor display lights up but low idling select function does not work

	Cause	Remedy
	See Troubleshooting (EA mode) of engine controller  Defective contact or disconnection in wiring harness between L06 (female) (7) and ECMB (female) (36)	—  Repair or replace
<p>• Max. 3 V • Turn starting switch ON.</p>	Defective main monitor	Replace

M-18 Related electrical circuit diagram




BWW10925

c) Brake oil pressure display flashes  
(Check that the brake oil pressure is correct.)

		Cause	Remedy
<p><b>1</b></p> <p>Is resistance between C03 (male) (1) and (2) normal?</p> <ul style="list-style-type: none"> <li>• Max. 1 Ω</li> <li>• Start engine.</li> <li>• Disconnect C03.</li> </ul> <p><b>YES</b></p> <p><b>2</b></p> <p>Is resistance between C04 (male) (1) and (2) normal?</p> <ul style="list-style-type: none"> <li>• Max. 1 Ω</li> <li>• Start engine.</li> <li>• Disconnect C04.</li> </ul> <p><b>YES</b></p> <p><b>3</b></p> <p>Is resistance between C03 (female) (2) and chassis ground normal?</p> <ul style="list-style-type: none"> <li>• Max. 1 Ω</li> <li>• Turn starting switch OFF.</li> <li>• Disconnect C03.</li> </ul> <p><b>YES</b></p> <p><b>4</b></p> <p>Is voltage between L18 (11) and chassis ground normal?</p> <ul style="list-style-type: none"> <li>• Start engine.</li> <li>• Max. 3 V</li> </ul> <p><b>NO</b></p> <p><b>NO</b></p>	<p><b>YES</b></p> <p>Defective monitor module of maintenance monitor</p>	Replace	
	<p><b>NO</b></p> <p>Defective contact or disconnection in wiring harness between L18 (female) (11) – LR4 (11) – BC01 (3) – C03 (female) (1)</p>	Repair or replace	
	<p><b>NO</b></p> <p>Defective contact or disconnection in wiring harness between C03 (female) (2) – C04 (female) (1), or between C04 (female) (2) – BC01 (1) – chassis ground</p>	Repair or replace	
	<p><b>NO</b></p> <p>Defective brake accumulator charge oil pressure switch (C04 end)</p>	Replace	
	<p><b>NO</b></p> <p>Defective brake accumulator charge oil pressure switch (C03 end)</p>	Replace	

K-5 c) Related electrical circuit diagram



TW02302

### K-14 Abnormality in gauge items

- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on to the next step.

**a) Abnormality in fuel gauge**

- ★ Before carrying out troubleshooting, check the fuel level again.  
(Check that the fuel level is correct.)


(1) Little or nothing is displayed in display area

		Cause	Remedy	
<p><b>1</b></p> <p>Does fuel gauge show FULL when short connector is connected to R05 (female)?</p> <p>• Disconnect R05. • Connect short connector to R05 (female). • Turn starting switch ON.</p>	<p><b>YES</b></p>	Defective fuel sensor	Replace	
	<p><b>2</b></p> <p>Is resistance between R05 (female) (2) and chassis ground normal?</p> <p>• Max. 1 Ω • Turn starting switch OFF. • Disconnect R05.</p>	<p><b>YES</b></p>	Defective monitor module of maintenance monitor	Replace
	<p><b>3</b></p> <p>Is resistance between L18 (female) (6) and chassis ground normal when short connector is connected to R05?</p> <p>• Max. 1 Ω • Turn starting switch OFF. • Connect short connector to R05 (female). • Disconnect L18.</p>	<p><b>YES</b></p>	Defective contact or disconnection in wiring harness between R05 (female) (1) – LR4 (10) – L18 (female) (6)	Repair or replace
	<p><b>NO</b></p>	Defective contact or disconnection in wiring harness between R05 (female) (2) and chassis ground	Repair or replace	


(2) Display always shows FULL and does not move

		Cause	Remedy
<p><b>1</b></p> <p>Do all display areas on fuel gauge go out when R05 is disconnected?</p> <p>• Disconnect R05. • Turn starting switch ON.</p>	<p><b>YES</b></p>	Defective fuel sensor	Replace
	<p><b>2</b></p> <p>Is resistance between R05 (female) (1) and chassis ground normal?</p> <p>• Min. 1 MΩ • Turn starting switch OFF. • Disconnect L18 and R05.</p>	<p><b>YES</b></p>	Defective monitor module of maintenance monitor
	<p><b>NO</b></p>	Short circuit with chassis ground in wiring harness between R05 (female) (1) – LR4 (10) – L18 (female) (6)	Repair or replace

**K-14 a) Related electrical circuit diagram**




TWW02308






d) Short circuit to chassis ground in directional solenoid circuit

1) Short circuit to chassis ground in travel FORWARD circuit




2) Short circuit to chassis ground in 2nd solenoid circuit



### E-11 Kick-down switch works even when traveling FORWARD in 2nd


- ★ Before disconnecting or connecting connectors, surely turn starting switch OFF.
- ★ Before carrying out troubleshooting, check that all related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on to the next step.



### E-15 Defective operation of solenoid for power maximizing function

a) Inspection of timer 1 and no-load relay system

- ★ Lower the work equipment to the ground in the digging position and set the transmission in the forward 1st gear speed for inspection. (Do not perform digging operation.)





### H-7 Turning, response of steering is poor

Ask the operator the following questions.

- Did the problem suddenly start?  
Yes → Related equipment broken  
Was there any abnormal noise when this happened? Where did the noise come from?
- Was there any symptom of difficulty in steering?  
Yes → Wear of related equipment, defective seal

Checks before troubleshooting

- Is the oil level in the hydraulic tank correct? Is the type of oil correct?

No.	Problems	Remedy													
		Hydraulic pump			PPC initial valve	Orbit-roll	Stop valve	Steering valve			Cylinder				
		a	b	c	d	e	f	g	h	i	j	k	l	m	
		△	△	×	×	×	×	△	△	△	△	△	△	△	△
		×	△	×	×	×	×	×	×	×	×	×	×	×	×
1	Turning, response of steering is poor in both directions(left and right)	○	○	○	○	○	○	○	○	○	○	○	○	○	○
2	Turning, response of steering is poor in one direction (left or right)		○					○						○	
3	Steering wheel is heavy in both directions (left and right)							○				○			
4	Steering wheel is heavy in one direction (left or right)							○							
5	Work equipment moves normally							○	○	○		○	○	○	
6	Work equipment speed is low	○	○	○		○	○								
7	Abnormal noise comes from around PTO	○													
8	Abnormal noise comes from around steering pump or hydraulic tank		○		○										
9	Abnormal noise comes from around switch pump or hydraulic tank			○	○										
10	When steering relief pressure is measured	Oil pressure is low or zero in both directions (left and right)													
11		Oil pressure is low or zero in one direction (left or right)													
12	Measured Orbit-roll output pressure is low		○			○	○								
13	Measured PPC valve (Orbit-roll) basic pressure is low		○			○									

★ There is close connection between the steering circuit and the work equipment circuit, so if any abnormality is felt in the steering, check the operation of the work equipment, also.

### H-14 Wheel brakes are not released or brakes drag

Ask the operator the following questions.

- Did the problem suddenly start?  
→ Related equipment broken  
Was there any abnormal noise when this happened? Where did the noise come from?

Checks before troubleshooting

- Does the brake pedal come back fully?
- Is the parking brake still applied?

No.	Problems	Remedy	Causes							
			Brake valve		Slack adjuster	Wheel brake				
			a	b	c	d	e			
			△	△	△	△	△	△	△	△
			×	×	×	×	×	×	×	×
1	Machine cannot travel at all		○	○						
2	Machine can travel a small amount				○	○	○			
3	When remaining pressure is released from brake accumulator circuit with left brake pedal only, break is released			○						
4	When remaining pressure is released from brake accumulator circuit with right brake pedal only, break is released		○							
5	When air bleed plug in wheel portion is loosened, oil flows out and brake is released				○					
6	When air bleed plug is loosened, a large amount of oil flows out		○	○						
7	When wear of brake disc is measured and brake pedal is released, piston returns								○	
8	When wear of brake disc is measured and brake pedal is released, piston does not return				○	○				

### H-25 Bucket is slow or lacks power

Ask the operator the following questions.

- Did the problem suddenly start?  
Yes = Related equipment broken
- Was there any abnormal noise when this happened? Where did the noise come from?
- Did the problem gradually appear?  
Yes = Wear of related parts, defective seal


No.	Problems	Remedy						
		PPC valve	Control valve				Cylinder	Others
		a	b	c	d	e	f	
		△	△	△	×	△	A	
		×	×	×		×		
1	Does not move in both directions (TILT and DUMP)		○	○		○	○	
2	Does not move in one direction (TILT or DUMP)	○			○			
3	When bucket relief pressure is measured	Oil pressure is low in both directions (TILT and DUMP)						
4		Oil pressure is low in one direction (TILT or DUMP)						
5	When PPC valve output pressure is measured, oil pressure is found to be low	○					○	
6	When hydraulic drift of bucket is measured, it is found to be excessive					○		
7	When operating effort of bucket control lever is measured, lever is found to be heavy	○					○	
8	When travel of bucket control lever is measured, it is found to be short						○	

- Causes**
- Defective PPC valve
  - Defective actuation of bucket spool
  - Defective actuation of load check valve
  - Defective safety-suction valve
  - Defective cylinder seal
  - Defective control lever linkage


Failure code	Abnormal system	Nature of abnormality
23	Abnormality in engine speed sensor system	<ol style="list-style-type: none"><li>1) Defective engine speed sensor</li><li>2) Defective adjustment of engine speed sensor mount</li><li>3) Short circuit with ground, defective contact, disconnection in wiring harness between transmission controller C4 (female) (2) and EC3A (5)</li><li>4) Defective contact or disconnection in wiring harness between transmission controller C4 (female) (9) – LR5 (3) – chassis ground</li><li>5) Defective transmission controller</li></ol>

### T-7 Failure code [17] (Short circuit, disconnection, short circuit with power source in 4th solenoid) is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the error code is no longer displayed on the monitor display, the problem has been removed.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on to the next step.



#### T-7 Related electrical circuit diagram




TWW02351

### T-12 Failure code [23] (Short circuit, disconnection in engine speed sensor system) is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the failure code is no longer displayed on the monitor display, the problem has been removed.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on to the next step.

		Cause	Remedy
	1 YES	Go to A	
	1 NO	Defective contact or disconnection in wiring harness between C4 (female) (9) and E13 (female) (2)	Repair or replace
	2 YES	Short circuit with chassis ground in harness between C4 (female) (2) and E13 (female) (1)	Repair or replace
	2 NO	Defective contact or disconnection in wiring harness between C4 (female) (2) and E13 (female) (1)	Repair or replace
	3 YES	Defective engine speed sensor	Replace
	3 NO	Defective transmission & joystick steering controller	Replace
4 YES	Short circuit of harness between C4 (female) (2) and E03 (female) (1) and harness between C4 (female) (9) and E13 (female) (2) with each other	Repair or replace	
4 NO	Short circuit with chassis ground in harness between C4 (female) (9) and E13 (female) (2)	Repair or replace	
5 YES			
5 NO			
6 YES			
6 NO			

### T-12 Related electrical circuit diagram




JUDGEMENT TABLE FOR AJSS (ADVANCED JOYSTICK STEERING SYSTEM) CONTROL SYSTEM


		Self-diagnosis display (Display of abnormality)							Diagnosis code when failure code is not displayed	
		56	57	58	59	60	62	63		
		Disconnection or short circuit with chassis ground in caution buzzer relay system	Disconnection or short circuit with chassis ground in steering lever angle sensor system	Deviation of steering lever angle sensor and frame angle sensor signals	Disconnection or short circuit with chassis ground in frame angle sensor system	Disconnection or short circuit with chassis ground in steering lever lock pressure switch system	Disconnection or short circuit with chassis ground in steering neutral interlock relay system	Disconnection, short circuit with chassis ground, or short circuit with power source in steering main pressure control EPC solenoid system		
		56	57	58	59	60	62	63		
		1	Engine does not start					○		E-1
		2	Steering speed is heightened						○	—
		3	Steering speed is lowered						○	H-8, H-11
		4	Response of steering system is heightened						○	—
		5	Response of steering system is lowered						○	H-8, H-11
		6	Steering speeds in both directions are different		○	○	○			—
		7	Machine is steered suddenly after engine is started					○		—
		8	Engine can be started while machine is steered					○		—
9	Caution buzzer does not sound or keeps sounding	○						M-13		
Diagnosis code when failure code is displayed		J-1	J-2	J-3	J-4	J-5	J-6	J-7		

### J-3 Error code [58] (Deviation of steering lever angle sensor and frame angle sensor signals) is displayed

- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the error code is no longer displayed on the monitor display, the problem has been removed.
- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ When the joystick steering lever is not being used, leave it at the neutral position.
- ★ Always connect any disconnected connectors before going on to the next step.



#### J-3 Related electrical circuit diagram



BJW11354

EA-38	Error code [432] (Idling validation process error) .....	20-750
EA-39	Error code [441] (Abnormality [low level] in battery voltage) .....	20-752
EA-40	Error code [442] (Abnormality [high level] in battery voltage) .....	20-752
EA-41	Error code [451] (Abnormality [high level] in fuel rail pressure sensor system) .....	20-753
EA-42	Error code [452] (Abnormality [low level] in fuel rail pressure sensor system) .....	20-754
EA-43	Error code [455] (Abnormality in fuel rail actuator system current) .....	20-755
EA-44	Error code [467] (Abnormality in timing rail actuator control) .....	20-756
EA-45	Error code [468] (Abnormality in fuel rail actuator control) .....	20-756
EA-46	Error code [514] (Abnormality in fuel rail actuator) .....	20-756
EA-47	Error code [527] (Abnormality in dual output solenoid A system) .....	20-757
EA-48	Error code [551] (Abnormality [2] in idling validation switch system) .....	20-757
EA-49	Error code [554] (Abnormality [in range] in fuel rail pressure sensor) .....	20-758

★ This section gives an outline of the troubleshooting procedures for the electrical systems related to the engine proper and the engine controller (for construction equipment).  
When carrying out troubleshooting of the electrical system with the engine mounted on the machine, use this section and the shop manual for the machine.

User code	System with abnormality	Nature of abnormality	Condition when normal
432	Idling validation process error	<ul style="list-style-type: none"> <li>Throttle sensor signal and idling validation ON signal, OFF signal do not match</li> <li>ECMB (12): Idling OFF signal</li> <li>ECMB (13): Idling ON signal</li> </ul>	<ul style="list-style-type: none"> <li>Resistance of idling switch</li> <li>Between L14(1) – (2): Max. 125 Ω (pedal released)</li> <li>Between L14(1) – (3): Max. 125 Ω (pedal depressed)</li> </ul>
441	Abnormality in battery voltage low level	<ul style="list-style-type: none"> <li>Abnormality has occurred in controller power source circuit</li> <li>ECMB (3)(4)(5): 12 V or less detected</li> </ul>	<ul style="list-style-type: none"> <li>Voltage of controller power source</li> <li>Between ECMB (3)(4)(5) – ECMA (7)(8): 17.3 – 34.7 V</li> <li>(When starting switch is OFF)</li> </ul>
442	Abnormality in battery voltage high level	<ul style="list-style-type: none"> <li>Abnormality has occurred in controller power source circuit</li> <li>ECMB (3)(4)(5): 38 V or less detected</li> </ul>	<ul style="list-style-type: none"> <li>Voltage of controller power source</li> <li>Between ECMB (3)(4)(5) – ECMA (7)(8): 17.3 – 34.7 V</li> <li>(When starting switch is OFF)</li> </ul>
451	Abnormality in fuel rail pressure sensor system high level	<ul style="list-style-type: none"> <li>Abnormality has occurred in fuel rail pressure sensor circuit</li> <li>ECMA (31): 4.78 V or more detected</li> </ul>	<ul style="list-style-type: none"> <li>Voltage of fuel rail pressure sensor</li> <li>Between ECMA (5) – (18) (power source): 4.75 – 5.25 V</li> <li>Between ECMA (31) – (18) (signal): 0.42 – 0.58 V (engine stopped)</li> </ul>
452	Abnormality in fuel rail pressure sensor system low level	<ul style="list-style-type: none"> <li>Abnormality has occurred in fuel rail pressure sensor circuit</li> <li>ECMA (31): 0.15 V or less detected</li> </ul>	<ul style="list-style-type: none"> <li>Voltage of fuel rail pressure sensor</li> <li>Between ECMA (5) – (18) (power source): 4.75 – 5.25 V</li> <li>Between ECMA (31) – (18) (signal): 0.42 – 0.58 V (engine stopped)</li> </ul>
455	Abnormality in fuel rail actuator system current	<ul style="list-style-type: none"> <li>Abnormality has occurred in fuel rail actuator circuit</li> <li>Between ECMA (1) – (20) (reference value): 0.40 ± 0.35 A (engine stopped)</li> </ul>	<ul style="list-style-type: none"> <li>Resistance of fuel rail actuator</li> <li>Between RAIL (A) – (C): 7 – 9 Ω</li> </ul>
467	Abnormality in timing rail actuator control	<ul style="list-style-type: none"> <li>Excessive difference between timing rail command fuel value and actual timing fuel, does not reach target value</li> </ul>	—
468	Abnormality in fuel rail actuator control	<ul style="list-style-type: none"> <li>Excessive difference between fuel rail command injection amount value and actual injection amount, does not reach target value</li> </ul>	—
514	Abnormality in fuel rail actuator	<ul style="list-style-type: none"> <li>Excessive difference between fuel rail command injection amount value and actual injection amount</li> <li>Fuel rail judgment value (reference): Difference ±600 mm<sup>3</sup>/st or more for ±50 msec or difference ±250 mm<sup>3</sup>/st or more for ± 200 msec</li> </ul>	—
527	Abnormality in dual output solenoid A system	<ul style="list-style-type: none"> <li>Abnormality has occurred in dual output solenoid A circuit</li> <li>ECMB (1): Circuit open or short circuit detected</li> </ul>	<ul style="list-style-type: none"> <li>Resistance of dual output solenoid A</li> <li>Between R17(female)(A) – chassis: 28 – 32 Ω</li> </ul>
529	Abnormality in dual output solenoid B system	<ul style="list-style-type: none"> <li>Abnormality has occurred in dual output solenoid B circuit</li> <li>ECMB (9): Circuit open or short circuit detected</li> </ul>	<ul style="list-style-type: none"> <li>Resistance of dual output solenoid B</li> <li>Between solenoid pins: 28 – 32 Ω</li> </ul>
551	Abnormality 2 in idling validation switch system	<ul style="list-style-type: none"> <li>Simultaneous detection of no voltage from both ON signal and OFF signal of idling validation switch</li> <li>ECMB (12): Idling OFF signal</li> <li>ECMB (13): Idling ON signal</li> </ul>	<ul style="list-style-type: none"> <li>Resistance of idling switch</li> <li>Between IVS (A) – (B): Max. 125 Ω (pedal released)</li> <li>Between IVS (A) – (C): Max. 125 Ω (pedal depressed)</li> </ul>
554	Abnormality in fuel rail pressure sensor in range	<ul style="list-style-type: none"> <li>Fuel rail pressure sensor detected abnormal pressure</li> <li>Judgment value (reference): When starting switch is ON: 0.17 MPa {1.76 kg/cm<sup>2</sup>} or more</li> </ul>	—

### EA-7 Error code [118] (Abnormality [high level] in fuel pump pressure sensor system)




Table 1

ECMA (female), PMPR (female)	Resistance value
Between ECMA (5) and PMPR (A)	Max. 10 Ω
Between ECMA (5) and surrounding wiring harnesses	Min. 1 MΩ


Table 2

ECMA (female), PMPR (female)	Resistance value
Between ECMA (18) and PMPR (B)	Max. 10 Ω
Between ECMA (18) and surrounding wiring harnesses	Min. 1 MΩ

Table 3

ECMA (female), PMPR (female)	Resistance value
Between ECMA (32) and PMPR (C)	Max. 10 Ω
Between ECMA (32) and surrounding wiring harnesses	Min. 1 MΩ

#### EA-7 Related electrical circuit diagram



BJW11341

### EA-17 Error code [144] (Abnormality [high level] in water temperature sensor system)





Table 1

ECMA (female), CLTP (female)	Resistance value
Between ECMA (22) and CLTP (A)	Max. 10 Ω
Between ECMA (22) and surrounding wiring harnesses	Min. 1 MΩ

Table 2

ECMA (female), CLTP (female)	Resistance value
Between ECMA (17) and CLTP (B)	Max. 10 Ω
Between ECMA (17) and surrounding wiring harnesses	Min. 1 MΩ

### EA-17 Related electrical circuit diagram



BJW10709

### EA-30 Error code [316] (Abnormality in fuel pump actuator system current)





Table 1

ECMA (female), PUMP (female)	Resistance value
Between ECMA (11) and PUMP (A)	Max. 10
Between ECMA (11) and surrounding wiring harnesses	Min. 1 M

Table 2

ECMA (female), PUMP (female)	Resistance value
Between ECMA (40) and PUMP (C)	Max. 10
Between ECMA (40) and surrounding wiring harnesses	Min. 1 M

### EA-30 Related electrical circuit diagram



BXE00024

**EA-39 Error code [441] (Abnormality [low level] in battery voltage)**


- ★ Carry out troubleshooting for error code [346].

**EA-40 Error code [442] (Abnormality [high level] in battery voltage)**

- ★ Carry out troubleshooting for error code [346].




Related electrical circuit diagram




TW03131

Related electrical circuit diagram




TWW03135

Related electrical circuit diagram




Related electrical circuit diagram



TWW03142

Related electrical circuit diagram



TWW03145

Unit: mm

No.	Check item	Criteria				Remedy
1	Clearance between bearing and shaft	Standard size	Tolerance		Standard clearance	Clearance limit
			Shaft	Hole		
2	Clearance between bearing and housing	85	+0.015 +0.003	0 -0.020	-0.035 – -0.003	0.025
3	Clearance between bearing and shaft	150	0 -0.018	-0.008 -0.033	-0.033 – 0.010	0.018
4	Clearance between inner body and shaft	85	-0.012 -0.034	+0.110 +0.030	0.042 – 0.144	0.25
5	Wear of surface in shaft and oil seal	Standard size		Tolerance		Repair limit
		100		0 -0.087		-0.133
6	Wear of surface in sleeve and oil seal	120		0 -0.087		-0.138
7	Backlash of spline	0.068 – 0.262				

Replace

Unit: mm

No.	Check item	Criteria					Remedy
		Standard size	Tolerance		Standard clearance	Clearance limit	
Shaft	Hole						
1	Clearance between FORWARD-REVERSE spool and body	22	-0.035 -0.045	+0.013 0	0.035 – 0.058	0.08	Replace
2	Clearance between 1st speed spool and body	22	-0.035 -0.045	+0.013 0	0.035 – 0.058	0.08	
3	Clearance between 2nd speed spool and body	22	-0.035 -0.045	+0.013 0	0.035 – 0.058	0.08	
4	Clearance between 3rd speed spool and body	22	-0.035 -0.045	+0.013 0	0.035 – 0.058	0.08	
5	Clearance between 4th speed spool and body	22	-0.035 -0.045	+0.013 0	0.035 – 0.058	0.08	
6	Clearance between pilot reducing valve spool and body	25	-0.035 -0.045	+0.013 0	0.035 – 0.058	0.08	
7	Clearance between lubrication valve plunger and body	22	-0.035 -0.045	+0.013 0	0.035 – 0.058	0.08	
8	FORWARD-REVERSE, No. 1, No. 2 No. 3, and No. 4 speed spring	Standard size			Repair limit		
		Free length	Installation length	Installation load	Free length	Installation load	
		78	47	107 N {10.9 kg}	75	102 N {10.4 kg}	
9	Pilot reducing valve spring	62	43.7	164 N {16.7 kg}	60.1	156 N {15.9 kg}	
10	Lubrication valve spring	39.4	37	60.8 N {6.2 kg}	38.2	57.9 N {5.9 kg}	
11	Thickness of shim for pilot reducing valve	3 mm (pressure per 1 piece: 0.026 MPa {0.26 kg/cm <sup>2</sup> })					Adjust


Unit: mm

No.	Check item	Criteria				Remedy
1	Clearance between planetary shaft and bearing	Standard size	Tolerance		Standard clearance	Clearance limit
			Shaft	Hole		
2	Clearance between planet gear and bearing	90	+0.018 0	0 -0.020	0 – -0.038	-
3	Clearance between ring gear hub and bearing	155	0 -0.025	-0.035 -0.075	-0.010 – -0.075	-
4	Clearance between wheel hub and bearing	300.038	+0.066 +0.034	+0.025 0	-0.009 – -0.066	-
5	Clearance between case and bearing	422.275	+0.051 0	-0.017 -0.080	-0.017 – -0.131	-
6	Clearance between wheel hub and bearing	266.7	-0.017 -0.049	+0.025 0	0.074 – 0.017	-
7	Thickness of retainer at ring gear hub mount	355.6	+0.051 0	-0.016 -0.073	-0.016 – -0.124	-
8		Standard size	Tolerance		Repair limit	
9	Backlash between planetary gear and sun gear	25	±0.1		24.6	
10	Backlash between planetary gear and ring gear	Standard clearance		Clearance limit		
11	Thickness of standard shim for wheel hub	0.22 – 0.53		-		
12	Thickness of standard shim for wheel hub	0.26 – 0.72		-		
13	Thickness of standard shim for wheel hub	2.1				

Replace

# BRAKE VALVE

(LEFT)



SJW06618

Unit: mm

No.	Check item	Criteria				Remedy
1	Clearance between pedal mount hole and bracket hole	Standard size	Tolerance		Standard clearance	Clearance limit
			Shaft	Hole		
		10	-0.025 -0.075	+0.1 0	0.175 - 0.025	0.25
2	Clearance between roller and pin	10	-0.025 -0.075	+0.1 0	0.175 - 0.025	0.25
3	Outside diameter of roller	Standard size	Tolerance		Repair limit	
		30	0 -0.5		29.2	
4	Control spring	Standard size			Repair limit	
		Free length	Installation length	Installation load	Free length	Installation load
		28	28	0 N {0 kg}	27	-
5	Control spring	47.2	46	37.2 N {3.8 kg}	46.2	-
6	Return spring	86.2	58	60.8 N {6.2 kg}	78	-
7	Return spring	31.5	19.5	16.7 N {1.7 kg}	28	-

Replace

Unit: mm

No.	Check item	Criteria					Remedy
		Standard size			Repair limit		
		Free length	Installation length	Installation load	Free length	Installation load	
1	Spool return spring	69.9	63.0	431.5 N {44.0 kg}	-	345.2 N {35.2 kg}	Replace
2	Spool return spring	77.0	77.0	0 N {0 kg}	-	-	
3	Spool return spring	79.7	78.5	61.6 N {6.28 kg}	-	49.0 N {5.0 kg}	
4	Main valve spring of relief valve (Large)	15.0	12.1	5.6 N {0.57 kg}	-	4.5 N {0.46 kg}	
5	Check valve spring	78.2	52.0	18.8 N {1.92 kg}	-	14.7 N {1.5 kg}	
6	Suction valve spring of safety valve	27.9	18.0	6.9 N {0.70 kg}	-	5.9 N {0.6 kg}	
7	Suction valve spring	64.9	5.6	6.4 N {0.65 kg}		5.1 N {0.52 kg}	
8	Float selector valve spring	53.0	42.1	137.3 N {14.0 kg}		109.8 N {11.2 kg}	
9	Unloader valve spring	82.7	47.0	49.0 N {5.0 kg}		39.2 N {4.0 kg}	
10	Pilot poppet spring of relief valve	27.7	25.4	319.7 N {32.6 kg}		256.0 N {26.1 kg}	
11	Main valve spring of relief valve (Small)	10.45	6.3	2.3 N {0.236 kg}		1.9 N {0.19 kg}	

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL