

WA70M-8E0

WHEEL LOADER

Model:
WA70M-8E0

Serial number:
H71051 and up

- This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local KOMATSU distributor for those items you may require.
- Materials and specifications are subject to change without notice.
- The Wheel Loader WA70M-8E0 is equipped with the engine 4D98E-6SHA.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

50 DISASSEMBLY AND ASSEMBLY

This section describes the special tools, work procedures, and safety precautions necessary for removal, installation, disassembly, and assembly of the components and parts. In addition, tightening torques, quantity, and weight of the coating materials, lubricants, and coolant necessary to these works are shown.

60 MAINTENANCE STANDARDS

This section describes the maintenance standard value of each component. The maintenance standard shows the criteria and remedies for disassembly and assembly.

80 THE OTHER INFORMATION

This section describes the structure and function, testing and adjusting, and troubleshooting for all of the other components or equipment which cannot be separately classified in the appendix.

90 Circuit diagrams

This section describes hydraulic circuit diagrams and electrical circuit diagrams.

Selecting wire ropes

Select adequate ropes depending on the weight of the parts to be hoisted referring to the table below.

REMARK

The allowable load is calculated with one sixth (safety factor 6) of the breaking load of the rope.

Wire rope (JIS G3525 6x37-A type) (Standard Z twist wire ropes without galvanizing)

Nominal diameter of rope (mm)	Allowable load (kN {t})
10	8.8 {0.9}
12	12.7 {1.3}
14	17.3 {1.7}
16	22.6 {2.3}
18	28.6 {2.9}
20	35.3 {3.6}
25	55.3 {5.6}
30	79.6 {8.1}
40	141.6 {14.4}
50	221.6 {22.6}
60	318.3 {32.4}

Precautions for disconnecting air conditioner piping

NOTICE

When replacing the air conditioner unit, air conditioner compressor, condenser or receiver drier, etc., collect the refrigerant (air conditioner gas: R134a) from the air conditioner circuit before disconnecting the air conditioner hoses.

REMARK

- Ask a qualified person for collecting, adding and filling operations of the refrigerant (air conditioner gas: R134a).
- Never release the refrigerant (air conditioner gas: R134a) to the atmosphere.
- **⚠ Put on the protective eyeglasses, gloves and working clothes with long sleeves while you are collecting or filling the refrigerant. Otherwise, when refrigerant gas (R134a) gets in your eyes, you may lose your sight, and when it touches your skin, you may suffer from frost-bite.**
- When loosening the nuts fixing air conditioner hoses and tubes, be sure to use 2 wrenches; use one wrench to fix and use the other one to loosen the nut.

Precautions for air conditioner piping

- When installing the air conditioner piping, be careful so that dirt, dusts and water do not enter the hose.

Check that the O-rings are fitted to the joints when connecting the air conditioner piping.

PRECAUTIONS FOR DISCONNECTION AND CONNECTION OF PIPINGS


When performing "testing and adjusting" of the machine, "removal and installation" and "disassembly and assembly" of the components, observe the following precautions.

PRECAUTIONS FOR REMOVAL AND DISASSEMBLING WORK

- If the cooling water contains coolant, dispose of it correctly as chemicals. Do not drain it to the sewage rashly.
- After disconnecting the hoses or tubes, plug them to prevent dust from entering.
- When draining oil, prepare a container with sufficient capacity.
- Check the matchmarks which indicate the installing position and put matchmarks on the places where they seem necessary before removal of the components to prevent any mistake when assembling.
- To prevent any excessive force from being applied to the wiring, always hold the connectors when disconnecting the connectors. Do not pull the wires.
- Attach the tags to wires and hoses so that installation is done to the correct installing positions.
- Check the thickness and number of shims when storing shims.
- When hoisting the components, prepare the slings with sufficient strength.
- When using forcing screws to remove any component, tighten the forcing screws uniformly and alternately.
- Before removing any component, clean the surrounding area and cover the component to prevent any foreign material from entering after removal.
- To disconnect the face seal type hose from the cylinder tube, loosen the joint by gripping the two wrenches together, one is the wrench (1) on the hose side, and another is the wrench (2) on the cylinder tube reaction force point as shown in the following figure. Use the grip strength only. Check after disconnecting the hose that the joint portion of the cylinder and the cylinder tube is tightened to the specified torque. Re-tighten it if the tightening torque is insufficient.

NOTICE

Cylinder tube is rotated due to the load applied to the reaction force point of the cylinder tube, and it is a cause of weakening of the tightening torque. It may lead to oil leakage.



Check of function of muffler in exhaust system**REMARK**

When an equipment is described as a muffler in exhaust system, it is one of the followings. (The applications or components of equipment are different depending on its models or specifications.)

- DPF
- DOC muffler
- Muffler
- Exhaust pipe
- Parts which connects the above, or etc.

Check that there is no unusual noise by comparing to it of the time when the machine was new.


If there is any unusual noise, repair DPF or muffler, referring to "TROUBLESHOOTING" and "DISASSEMBLY AND ASSEMBLY".

3. Correct the protrusion of the boot and misalignment of the wiring harness.


- If the connector is with the boot, correct any extrusion of the boot. In addition, if the wiring harness is misaligned or the clamp is out of position, adjust it to its correct position.

REMARK

If the protrusion of the boot and misalignment of the wiring harness cannot be fixed, remove the clamp to adjust them.




- If the connector clamp is removed, be sure to return it to its original position. Check that there is no looseness.



Method for connecting ring terminals and strip fuses to power stud of printed circuit boards

The assembly of a strip fuse and a wire terminal with a power stud on a printed circuit board, has to be performed as follows:



A direct connection between the stud and the conductive element is required and no mounting elements are to come in between.

For the board equipped with spring washers, it is expressly forbidden to reuse these elements if they were tightened with high torque.

Consider the following maximum torque for the nuts on the power studs of the printed circuit boards (central electric board and relaybox).


Thread size (metric)	M5	M6	M8
Max. torque [Nm]	2,2	3,9	9,0

Nominal No.	Thread diameter (mm)	Width across flats (mm)	Tightening torque (Nm {kgm})	
			Range	Target
18	18	27	34.3 to 44.1 {3.5 to 4.5}	39.2 {4.0}
20	20	30	44.1 to 53.9 {4.5 to 5.5}	49.0 {5.0}
24	24	32	58.8 to 78.4 {6.0 to 8.0}	68.6 {7.0}
30	30	32	93.1 to 122.5 {9.5 to 12.5}	107.8 {11.0}
33	33	-	107.8 to 147.0 {11.0 to 15.0}	127.4 {13.0}
36	36	36	127.4 to 176.4 {13.0 to 18.0}	151.9 {15.5}
42	42	-	181.3 to 240.1 {18.5 to 24.5}	210.7 {21.5}
52	52	-	274.4 to 367.5 {28.0 to 37.5}	323.4 {33.0}

TABLE OF TIGHTENING TORQUE FOR BOSS PIPING JOINTS WITH FLAT SEAL (DIN3852)

REMARK

Tighten the pipe joint for boss with the torque shown in the table below unless otherwise specified.



Thread diameter	Width across flats (mm)	Tightening torque	
		Target (Nm)	Tolerance (Nm)
M12x1.5	Varies depending on type of connector.	25	0/-2,5
M14x1,5		50	0/-5
M16x1,5		70	0/-7
M18x1,5		90	0/-9
M20x1,5		130	0/-13
M22x1,5		130	0/-13
M26x1,5		180	0/-18
M27x2		200	0/-20
M33x2		230	0/-23
M42x2		330	0/-33

Thread diameter	Width across flats (mm)	Tightening torque	
		Target (Nm)	Tolerance (Nm)
G1/8A	Varies depending on type of connector.	20	0/-2
G1/4A		50	0/-5
G3/8A		80	0/-8
G1/2A		100	0/-10
G3/4A		180	0/-18
G1A		230	0/-23
G1 1/4A		330	0/-33
G1 1/2A		500	0/-50

COOLANT

- River water contains large amounts of calcium and other impurities, so if it is used, scale will stick to the engine and radiator causing a defective heat exchange and overheating.
- Do not use water that is not suitable for drinking.
- When using anti-freeze, always observe the precautions given in the Operation and Maintenance Manual.
- Komatsu machines are supplied with Komatsu original anti-freeze in the coolant when the machine is shipped. This anti-freeze prevents corrosion in the cooling system. The anti-freeze can be used continuously for two years or 4000 hours. Therefore, it can be used as it is, even in hot areas.
- Anti-freeze is flammable, so be extremely careful not to expose it to open flame or fire.
- The proportion of anti-freeze to water differs according to the ambient temperature. For details of the mixing ratios, see Operation Manual: "METHOD FOR CLEANING INSIDE OF COOLING SYSTEM".
- If the engine overheats, wait for the engine to cool down before adding coolant.
- If the coolant level is low, it will cause overheating and corrosion due to the air in the coolant.

GREASE

- Grease is used to prevent twisting and noise at the joints.
- The nipples not included in the maintenance section are nipples for overhaul, so they need not be lubricated. If any part becomes stiff after being used for a long time, add grease.
- Always wipe off all of the old grease that is pushed out when greasing. Be particularly careful to wipe off the old grease in places where sand or dirt in the grease would cause the rotating parts to wear.

STORING OIL AND FUEL

- Keep oil and fuel indoors to prevent any water, dirt or other impurities from penetrating.
- When keeping barrels for a long period, lay the barrel down on its side so that the filler port is at the side (to prevent moisture from being sucked in).
If barrels have to be stored outside, cover them with a waterproof sheet or take other measures to protect them.
- To prevent any change in quality during long term storage, be sure to use in the order of 'first in - first out' (use the oldest oil or fuel first).


Abbreviation	Actual word spelled out	Purpose of use (major applicable machine (*1), or component/system)	Explanation
ICT	Information and Communication Technology	Communication and electronic control	A general term for the engineering and its socially applied technology of information processing and communication.
IMA	Inlet Metering Actuator	Engine	This is a valve that adjusts the fuel intake amount at the pump inlet in order to control the supply pump fuel discharged volume. (Same
IMU	Inertial Measurement Unit	Engine	This is a device to detect the angle (or angular velocity) and acceleration of the 3 axes that control motions.
IMV	Inlet Metering Valve	Engine	This is a valve that adjusts the fuel intake amount at the pump inlet in order to control the supply pump combustion discharged volume. (Same as IMA)
CCV	Closed Crankcase Ventilation	Engine	This is a mechanism that burns the blowby gas again by separating oil from blowby gas and returning it to the intake side. It primarily consists of filters.
KCSF	Komatsu Catalyzed Soot Filter	Engine	This is a filter that captures soot in exhaust gas.
DOC	Komatsu Diesel Oxidation Catalyst	Engine	This is a catalyst that is used for purifying exhaust gas. It is built in to DPF or assembled with the muffler.
DPF	Komatsu Diesel Particulate Filter	Engine	This is a component that is used to purify the exhaust gas. DOC (catalyst) and KCSF (filter to capture soot) are built-in it. It is installed instead of the conventional muffler.
KTCS	Komatsu Traction Control System	Travel and brake (HM)	This is a function that performs braking with the optimum force and recovers the driving force of the wheels by actuating the inter-axle differential lock when the wheels runs idle while the machine travels on the soft ground.
LCD	Liquid Crystal Display	Machine monitor	This is an image display equipment such as a monitor in which the liquid crystal elements are assembled.
LED	Light Emitting Diode	Electronic parts	This is a semiconductor element that emits light when the voltage is applied in forward direction.
LIN	Local Interconnect Network	Communication and electronic control	This is one of communication standards that are used in the network on the machine.
LS	Load Sensing	Hydraulic system	This is a function that detects differential pressure of pump, and controls discharged volume corresponding to load.
LVDS	Low Voltage Differential	Communication and electronic control	This is one of communication standards that are used in the network on the machine.
MAF	Mass Air Flow	Engine	This indicates engine intake air flow. This is not used independently but is used as combined with sensor. Mass air flow sensor can be called as MAF sensor.

FUNCTION OF AUTOMATIC PREHEATING SYSTEM

- Automatic preheating system is installed for the engine to start easily in cold weather.
- When the starting switch is turned to "ON" position, the automatic preheating system starts to set the preheating time automatically corresponding to the coolant water temperature.
- The preheating pilot lamp on the machine monitor lights up and the electric glow plugs are energized when the starting switch is turned to "ON" position.
- Engine controller detects coolant temperature with the temperature sensor and sets the preheating time according to them (up to 15 sec).
- Pilot lamp on monitor stays lit while preheating is operated. Keep the starting switch in "ON" position during this time. If starting switch is turned to "START" position, automatic preheating is canceled.


OPERATION OF AUTOMATIC PREHEATING SYSTEM

1. When the starting switch is turned to "ON" position, the engine controller starts.
2. The engine controller drives the preheater relay just after starting switch is turned to "ON" position, and the electric heater relay operates for electric heater to start preheating of the engine.
3. The operating time of preheater is shown in the following figure.



KOMTRAX SYSTEM

KOMTRAX SYSTEM DIAGRAM



KOMTRAX system consists of KOMTRAX terminal (controller) and two antennas (communication and GPS)

FUNCTION OF KOMTRAX SYSTEM

- KOMTRAX system transmits various types of information on the machine. KOMTRAX administrator sees the information in the office and supplies various services to the customers.
- KOMTRAX system can transmits the following information.
- Positional information
- Operation information (service meter, odometer, etc.)
- Fuel consumption information
- Machine working condition information

REMARK

To provide the services, you need to establish radio station for KOMTRAX separately.

Service mode function of machine monitor

These functions are not displayed normally. These are for a technician to display and set with special switch operation. These functions are used for special settings, testing, adjusting, or troubleshooting.


Items available in the service mode are as follows.

Self-define Monitoring	
Abnormality Record	Mechanical Sys Abnormality Record
	Electrical Sys Abnormality Record
Maintenance Record	
Maintenance Mode Setting	
Phone Number Entry	
Default	Machine Model Selection
	Option Selection
	Unit Selection
Adjustment	T/C Device Calibration

REMARK

For operating method of the service mode functions, See "SERVICE MODE" on page 30-70.

Structure of the pump for steering, work equipment and cooling fan



Double pump

- 1 Pump for steering and work equipment
- 2 Pump for cooling fan

Specifications of the pumps for steering, work equipment, cooling fan and high flow

Work equipment / Steering pump

Model: CASAPPA KP30.31

Discharged pressure: max. 23,0 MPa {235 kg/cm²}

Standard discharged volume: 61.4 ℓ/min

Cooling fan pump

Model: CASAPPA PL20.8

Discharged pressure: max. 28,0 MPa {285 kg/cm²}

Standard discharged volume: 17,4 ℓ/min

Operation of HST pump

- The HST pump is a variable displacement pump, where the displacement pistons are mounted axially parallel to the drive shaft. They react against the swash plate.
- The drive shaft is rotated by the engine. The drive shaft is rigidly connected to the cylinder head.


The cylinder head rotates with the drive shaft. The pistons (2) are mounted in the cylinder head. The pistons are mounted on guide shoes, which glide on the swash plate. Due to the tilted position of the swash plate, this causes an axial displacement of the pistons in the cylinder head. The guide shoes are held with oil pressure against the swash plate.

During rotation the pistons move between bottom dead centre and top dead centre and back to the start position. In moving between the dead centres (here the piston changes its linear direction) the piston completes a stroke. Because of this oil is sucked in on the inlet port and displaced through the outlet port. The displaced oil volume depends on the piston area and the length of stroke.

Suction takes place when the oil fills the increasing cylinder space. The oil is additionally forced into the cylinder by charge pump pressure. The returning piston forces the oil out of the cylinder head through the outlet port.

The swash plate angle can be changed to increase or decrease the piston stroke and with this the displaced oil volume. When the swash plate angle changes over the neutral position, the pumped direction also changes. Inlet becomes outlet, outlet becomes inlet.

1. Drive shaft
2. Pistons
3. Piston area
4. Piston displacement
5. Swash plate
6. Operating angle
7. Cylinder head
8. Drive shaft
9. Control plate
10. Top dead centre
11. Bottom dead centre
12. Inlet port (rotation as shown)
13. Outlet port (rotation as shown)




Function of towing system

For towing the machine, follow the instructions in the operator's manual.

For towing the machine, the HST motor needs to be bypassed. If this is not done, rotation of the wheels will be transmitted through the transfer box to the HST motor (2). The oil displaced by the motor would be forcing the pump (1) to turn, which may damage the engine.


This is achieved by activating the towing valve (3) by turning the lever downwards.

After activating the valve, the oil displaced by the motor (2) is not flowing through the pump (1), but through the towing valve (3). In this case, no rotational force is generated in the pump (1) and a damage of the engine is prevented.



STEERING SYSTEM

LAYOUT DRAWING OF STEERING SYSTEM




- 1 Orbitrol valve
- 2 Priority valve

- 3 Steering pump
- 4 Steering cylinder

UNDERCARRIAGE AND FRAME

FRAME, AXLE MOUNT AND CENTER HINGE PIN

Structure of frame, axle mount and center hinge pin general view



- 1 Front axle
- 2 Front frame
- 3 Rear frame
- 4 Counterweight

- 6 Frame lock bolt
- 7 Axle mounting bolt
- A Detail see next picture
- B Detail see next picture


x0001179

TIPPING UP THE OPERATOR'S CAB (STANDARD, WITHOUT TIPPING CYLINDER)




- **Risk of injury!** The tipped up operator's cab can suddenly lower itself!
- **Never enter the raised cabin.**
- **Never start the engine with the cabin up.**
- **Never tip up the cabin in strong winds.**

1. Park the machine on solid, level ground.
2. Lower the work equipment to the ground and switch off the engine.
3. Close the cab door.




4. Secure the articulated steering (1) with the locking bolt.



NOTICE

The machine has to be positioned as for driving in a straight line, and the articulated steering has to be secured with the locking bolt! If the operator's cab is tipped up while the machine is bent, the front frame may damage the windscreen!

5. Open the engine hood (2).



20 STANDARD VALUE TABLE

ABBREVIATION LIST	20-2
List of abbreviations used in the text	20-2
List of abbreviations used in the circuit diagrams	20-7
STANDARD VALUE TABLE	20-8
Standard value table for engine	20-8
Standard value table for chassis	20-9
TEST CERTIFICATE	20-11

TEST CERTIFICATE

Chassis N°:			Customer:		
Test temperatures			°C	Target	Value
1	Cooling water	82±5			
2	Hydraulic oil (drive and working hydraulic, measured in the hydraulic oil cooler return)	50±5			
Engine speed			rpm	Target	Value
3	Low idle speed	900±10			
★	4	High idle speed		2230±10	
	5	Engine speed hydrostat full stall (oil temperature: min.55°C)		2230±10	
	6	Engine speed working hydraulic+hydrostat full stall		2230±10	
	7	Start of drive RPM		1050±50	
System pressures			bar	Target	Value
★	8	Work hydraulic pressure		230+5	
★	9	Steering hydraulic pressure		180±5	
	10	Feed pressure (low idle speed and test temperature)		min. 26	
	11	Feed pressure (high idle speed and test temperature)		max. 30	
★	12	Pressure (absolut) machine is full braked forward		455±5	
★	13	Pressure (absolut) machine is full braked backward		455±5	
Steering cycle times			sec	Target	Value
	14	Low idle speed, left and right (end to end)		LH: 3.3±04 RH: 4.2±04	
★	15	Rated idle speed, left and right (end to end)		LH: 1.7±04 RH: 2.1±04	
Lift and tilt times			sec	Target	Value
★	16	Raising time with empty bucket		5.3±0.3	
★	17	Dump time of bucket on full raised position		1.1±0.3	
★	18	Roll back time from ground level of bucket to bucket stopper		1.0±0.5	
Lower times			sec	Target	Value
★	19	Lowering time from full raised position to ground level of bucket		3.2±0.5	
★	20	Lowering time from full raised position to ground level of bucket joystick in float position		4.3±0.5	
Travel speeds			km/h	Target	Value
	21	1. drive range: 20 km/h STD (Tires 455/70R20)		0 - 5±1	
	22	2. drive range: 20 km/h STD (Tires 455/70R20)	0 - 20±1		
★	27	Fan speed 20 km/h version	rpm	2000±50	

All measurements and setups has to do at operation temperature of machine!

★ Measurements with maximum engine speed!

Abbreviation	Actual word spelled out	Purpose of use (major applicable machine (*1), or component/system)	Explanation
MMS	Multimedia Messaging Service	Communication	This is a service that allows transmission and reception of short messages consisting of characters or voice or images between cell phones.
NC	Normally Closed	Electrical system, hydraulic system	This is a characteristic of electrical or hydraulic circuits. Circuit is normally closed if it is not actuated, and it opens when it is actuated.
NO	Normally Open	Electrical system, hydraulic system	This is a characteristic of electrical or hydraulic circuits. Circuit is normally open if it is not actuated, and it closes when it is actuated.
OLSS	Open-center Load Sensing System	Hydraulic system	This is a hydraulic system that can operate multiple actuators at the same time regardless of the load.
PC	Pressure Compensation	Hydraulic system	This is a function that corrects the oil pressure.
PCCS	Palm command control system	Steering (D Series)	This is a function that electrically controls the engine and transmission in an optimal way with the controller instantly analyzing data from levers, pedals, and dials.
PCV	Pre-stroke Control Valve	Engine	This is a valve that adjusts the fuel intake amount at the pump inlet in order to control fuel discharged volume of supply pump.
PPC	Proportional Pressure Control	Hydraulic system	This is a system that operates actuators in proportion to the oil pressure.
PPM	Piston Pump and Motor	Hydraulic system (D, PC, etc)	Piston type hydraulic pump and motor.
PTO	Power Take Off	Power train system	Power take-off mechanism
PTP	Power Tilt and power Pitch dozer	Work equipment (D Series)	This is a function that performs hydraulic control of the tilt and pitch of the dozer blade of the bulldozer.
ROPS	Roll-Over Protective Structure	Cab and canopy	ROPS is a protective structure that intended to protect the operator wearing seat belt from suffering injury which may be caused if the cab is crushed when the machine rolls over. (Roll-over protective structure) This performance is standardized as ISO 3471 or ISO 12117-2.
SCR	Selective Catalytic Reduction	Urea SCR system	This is an exhaust gas purifier using urea water that converts nitrogen oxides (NOx) into harmless nitrogen and water by oxidation-reduction reaction. It may also be mentioned as exhaust gas purification catalyst or part of the name of related devices.
SI	Le Systeme International d' Unites (International unit system)	Unit	Abbreviation for "International System of Units" It is the universal unit system and "a single unit for a single quantity" is the basic principle applied.
SOL	Solenoid	Electrical system	This is an actuator that consists of a solenoid and an iron core that is operated by the magnetic force when the solenoid is energized.

Free for technical reason

TEST FUEL CIRCUIT FOR LEAKAGE

Tools for testing the leakage in fuel system

Symbol	Part No.	Part name	Q'ty	Remarks
A	Commercially available	Developer for dye penetrant (color checker)	1	



- **Very high pressure is generated in the high-pressure circuit of the fuel system. If fuel leaks while the engine is running, it presents a serious danger that could result in a fire. When the fuel circuit is tested or any component is removed from or installed to it, check for fuel leakage according to the following procedure.**
- **Place the machine on a level ground, lower the work equipment to the ground, apply the parking brake, turn work equipment lock switch to LOCK position, and stop the engine.**
- **Chock the tires to prevent the machine from moving.**
- **Immediately after the engine is stopped, its parts and oil are still very hot and may cause burn injury. Wait for the temperature to go down, and then start the work.**

Clean the engine and the parts around it and degrease them in advance so that you can easily find the leakage if any.

For testing of fuel system for leakage to perform troubleshooting or others, refer to this section.

METHOD FOR TESTING FUEL CIRCUIT FOR LEAKAGE

Testing method of fuel circuit for leakage at engine stopped

1. Start the engine.
2. Stop the engine after the engine automatic warm-up function is cancelled and the engine speed is stabilized while the accelerator pedal is not depressed (low idle).
3. Spray the colour checker A to the high-pressure supply pump, common rail, injectors, and joints of the high-pressure piping.
4. Check the fuel piping and component for fuel leakage.
 - Check the high-pressure circuit for fuel leakage focusing on the area where the colour checker A is sprayed.
 - If there is a fuel leakage, repair it and perform the testing from Step 1 again.

TEST DRIVE SHAFT FOR LOOSENESS, BACKLASH, AND DAMAGE



-
- Place the machine on a level ground, lower the work equipment to the ground, set the parking brake lever in **PARKING** position and work equipment lock switch in **LOCK** position, and stop the engine.
 - Chock the tires to prevent the machine from moving.
-

For testing of the drive shaft for looseness, backlash and damage to perform troubleshooting or others, refer to this section.

METHOD FOR TESTING DRIVE SHAFT FOR LOOSENESS, BACKLASH, AND DAMAGE

Check the drive shaft for damage, abnormal backlash, and loosening of connecting bolts and nuts.

1. Move the cross member at the universal joint up and down, right and left, and rotate in both directions to check.
2. Move the sliding part of the drive shaft upward and rotate it in both directions for several times to check.

REMARK

- If any part is loosened or damaged, repair it.
- For the tightening torques, See "DISASSEMBLY AND ASSEMBLY" on page 40-1.

TEST AND ADJUST BRAKE PEDAL



Park the machine on level ground and secure it against rolling away and jack-knifing!


Lower the bucket, switch the engine off and actuate the parking brake!

Length of rod

1. Mount the fork to the brake rod, loosen the locking nut (3) and set the length of the brake to approx. 112.5 mm.
2. Install the brake rod to the brake pedal.

Angle of brake pedal

1. Release the locknut (2) and turn the adjusting bolt (1) to adjust the pedal angle to 45°.
2. Tighten the locknut (2) and check the pedal angle adjustment.



x0001184

TEST ECSS ACCUMULATOR NITROGEN GAS PRESSURE



Risk of injury!

Release remaining pressure from pressurized circuit before working on the ECSS accumulator.

For detail See "Releasing the remaining pressure in ECSS" on page 40-54.

Put on the appropriate protective equipment (goggles, leather gloves, protective clothes) so that the leaked nitrogen gas does not come in contact with your skin or clothes. Perform the work on the windward side as much as possible.

⚠ When using the nitrogen gas indoors or on an ill-ventilated location, ventilate the room, etc. and observe the Industrial Safety and Health Law, Ordinance on Prevention of Anoxia, etc.

⚠ The accumulator is charged with high-pressure nitrogen gas, and incorrect operation may cause an explosion which will lead to serious injury or death. When handling, always observe the following.

- Do not bring open flame close to it or do not dispose of it in fire.
- Do not perform drilling, welding or flame-cutting.
- Do not hit or roll it or subject it to any impact.
- Discharge the gas before disposing.
- Before disassembly and removal, be sure to lower the charged gas pressure to the ambient pressure.
- Be sure to use the nitrogen gas for charging.
- Do not charge explosive gas such as oxygen.
- Follow this procedure always when handling accumulator.


For testing and charging of ECSS accumulator nitrogen gas pressure to perform troubleshooting, refer to this section.

- When the inputted password is incorrect, a message to request inputting the password again is displayed.
 - Set a new password of 4 to 6 digits (A password with 3 or less digits or 7 or more digits is not allowed to set)
3. After "Usage Limitation New Password Input" screen is displayed again, use a switch on the switch panel to input and validate a new password. NEXT switch (6): Switch to the next numeric input box. UP switch (7): Increase the Number in the selected box. DOWN switch (8): Decrease the number in the selected box. RETURN switch (9): Clears an input numeric/ Return the screen to the standard screen. ENTER switch (10): Validates the inputted password.

REMARK

If the inputted password is different from the one inputted before, a message to request inputting again is displayed.

If "Usage Limitation Setting" screen is displayed after the screen to notify completion of setting is displayed, the password is changed successfully.



Monitoring code	Self-define Monitoring items (screen displayed)	Unit	Applicable component	Remark
68701	DPF Reg Control Status	-	DPF	0: Normal operation 1: Start of automatic speed control by ECU 2: After injectin and retard, Intake throttle operation (Target position limitation) 3: Intake throttle operation (No limitation of target position) 4: Post injection (Phase 1) 5: Judgement of finishing the DPF regeneration (Start of judgment by the DBF middle temperatur) 6: Post injection (Phase 2) 7: Judgement of finishin the DPF regeneration 8: Finish of automatic speed control by ECU (Gradually deceleration) 9: Accumulation value reset
68702	Emergency Mode Status	-	DPF	0: Not detected 1: Emergency detection when operating assist regeneration 2: Emergency detection when operating reset regeneration 3: Emergency detection when operating stationary regeneration
68703	Stat Reg Request Flag	-	DPF	0: No stationary regeneration request 1: Stationary regeneration request by operator command 2: Stationary regeneratio request by emergency 3: Recovery regeneration request
68704	Ash Cleaning Request Flag	-	DPF	0: No ash cleaning request 1: Ash cleaning request (Low) 2: Ash cleaning request (High)
68705	DPF Reg Control Start Flag	-	DPF	0: Warm-up incompleted for DPF regeneration control 1: Warm-up completed for DPF regeneration control
68706	Required DPF Reg Status	-	DPF	0: Regeneration not needed 1: Regeneration needed - lowest level 2: Regeneration needed - moderate level 3: Regeneration needed - highest level
68707	DPF Reg Permission Status	-	DPF	0: Not allowed 1: Allowed

Selectable items from Maintenance Record


Code	Item
49	Air Cleaner Cleaning or Change
60	Coolant Change
41	Fuel Prefilter Change
01	Engine Oil Change
02	Engine Oil Filter Change
03	Fuel Main Filter Change
11	Differential Oil Change
25	T/M Oil Change
15	Axle Oil Change
10	Hydraulic Oil Change
04	Hydraulic Oil Filter Change
80	General Machine Maintenance

Displayed information of "Maintenance Record" screen

a: Maintenance items

b: Number of replacements up to now

c: Service meter reading (SMR) at the last replacement



- When the settings of the items are completed, press RETURN switch (9) to return to the "Default" screen from the "Option Selection" screen.

REMARK

If ENTER switch (10) has never been pressed (no change is made) for setting of any item, this screen will not be displayed even if the display changes from "Option Selection" screen to "Default" screen.

- After the screen which prompts you a key off is displayed, turn the starting switch to OFF position.

Turning the starting switch to OFF position completes "Option Selection" setting.



METHOD FOR SETTING WITH DEFAULT SETTING MENU (UNIT)


Default menu is used to check or change default values of the machine monitor and machine.

"Unit Selection" function is used to select the unit of the data to be displayed on standard screen.

- Select "Default" on "Service Menu" screen.

REMARK


For selection method, See "METHOD FOR OPERATING SERVICE MODE" on page 40-70.



- After the "Default" screen is displayed, select "Unit Selection".

REMARK

For selection method, sSee "METHOD FOR OPERATING SERVICE MODE" on page 40-70.



40 TROUBLESHOOTING

ABBREVIATION LIST	40-5
List of abbreviations used in the text	40-5
List of abbreviations used in the circuit diagrams	40-11
RELATED INFORMATION ON TROUBLESHOOTING	40-12
GENERAL TROUBLESHOOTING POINTS	40-12
SEQUENCE OF EVENTS IN TROUBLESHOOTING	40-14
CHECKS BEFORE TROUBLESHOOTING	40-16
Engine, lubricating oil and coolant	40-16
Hydraulic and mechanical equipment	40-16
Electric equipment	40-17
Exterior	40-17
Interior	40-17
INSPECTION PROCEDURE BEFORE TROUBLESHOOTING	40-18
WALK-AROUND CHECK	40-18
PROCEDURE FOR TESTING AND TROUBLESHOOTING	40-20
INFORMATION DESCRIBED IN TROUBLESHOOTING TABLE	40-21
CONNECTOR LOCATION LIST	40-23
CONNECTOR CONTACT IDENTIFICATION	40-31
SPARE FUSES AND RELAY	40-68
USB socket on central electric board (CEB)	40-73
FAILURE CODES TABLE	40-76
E-1 ENGINE DOES NOT START (ENGINE DOES NOT CRANK)	40-94
E-3 AUTOMATIC PREHEATING SYSTEM DOES NOT WORK	40-98
E-5 MACHINE MONITOR DISPLAY NOTHING (BATTERY RELAY IS NOT ENERGIZED)	40-99
E-6 LCD UNIT ON MACHINE MONITOR DISPLAYS NOTHING (BATTERY RELAY IS ENERGISED)	40-100
E-15 SOME ITEMS OF GAUGES AND CAUTION LAMPS ON MACHINE MONITOR ARE NOT DISPLAYED PROPERLY	40-101
E-24 INDICATION OF HST OIL TEMPERATURE GAUGE DOES NOT INCREASE, OR HST OIL TEMPERATURE CAUTION LAMP DOES NOT LIGHT UP	40-102
E-25 FUEL LEVEL GAUGE DOES NOT INDICATE CORRECT LEVEL	40-103
E-27 ALARM BUZZER DOES NOT SOUND	40-104
E-28 ALARM BUZZER DOES NOT STOP SOUNDING	40-105
E-34 DIRECTIONAL SELECTION DOES NOT WORK	40-106
E-36 ECSS FUNCTION CANNOT BE SELECTED OR ACTIVATED	40-108
E-XY REAR FLASHER OPERATES ABNORMAL (Synchronizing)	40-109
TROUBLESHOOTING FOR HYDRAULIC AND MECHANICAL SYSTEMS (H MODE)	40-111
INFORMATION MENTIONED IN TROUBLESHOOTING TABLE (H MODE)	40-111
H-10 MACHINE SWAYS OR LARGE SHOCKS ARE MADE WHILE MACHINE TURNS	40-112
H-11 MACHINE UNINTENTIONALLY TURNS TO ONE SIDE WHEN MACHINE TRAVELS	40-113
H-12 WHEEL BRAKES DO NOT WORK OR ARE WEAK	40-114
H-13 WHEEL BRAKES ARE NOT RELEASED OR DRAG	40-115
H-14 PARKING BRAKE DOES NOT WORK OR IT IS WEAK	40-116

List of abbreviations used in the circuit diagrams

Abbreviation	Actual word spelled out
A/C	Air Conditioner
A/D	Analogue-to-Digital
A/M	Air Mix Damper
ACC	Accessory
ADD	Additional
AUX	Auxiliary
BR	Battery Relay
CW	Clockwise
CCW	Counter Clockwise
ECU	Electronic Control Unit
ECM	Electronic Control Module
ENG	Engine
EXGND	External Ground
F.G.	Frame Ground
GND	Ground
IMA	Inlet Metering Actuator
NC	No Connection
S/T	Steering
STRG	
SIG	Signal
SOL	Solenoid
STD	Standard
OPT	Option
OP	
PRESS	Pressure
SPEC	Specification
SW	Switch
TEMP	Temperature
T/C	Torque Converter
T/M	Transmission







INFORMATION DESCRIBED IN TROUBLESHOOTING TABLE



The following types of information are described in the troubleshooting list and related circuit diagram. Fully understand the description and perform troubleshooting



Action level	Failure code	Failure	Failure name displayed on "Abnormality Record" screen of the machine monitor
Display on machine monitor	Display on machine monitor		
Details of failure	Description of the failure detected by the machine monitor or controller		
Action of controller	An action that is performed to protect the system and devices when a failure is detected by the machine monitor or controller		
Problem on machine	A problem that is displayed as a failure on the lift truck as a result of an action (shown above) that is performed by the machine monitor or controller.		
Related information	Information related to the occurred failure and its troubleshooting		
No.	Cause	Procedure, measuring location, criteria, and remarks	
1	Defective ---	Contents of description	
2	Open or short circuit in wiring harness	<ul style="list-style-type: none"> Procedure Measuring point 	
3	Open circuit in wiring harness (wire breakage or defective contact of connector)	<p>"Between A and B" denotes measuring values such as voltage and resistance between A and B.</p> <p>"Between A and ground" means the measurement of voltage, resistance or others between place A and the place which has a continuity with chassis frame such as unpainted hexagonal head bolt or bolt hole which has no rust, etc.</p>	
4	Ground fault in wiring harness (contact with ground circuit)	<ul style="list-style-type: none"> Criteria to judge probable causes (standard value), remarks 	
5	Hot short circuit	<p>How to use troubleshooting sheet</p> <ul style="list-style-type: none"> Perform troubleshooting procedures in following order. If the check result does not meet the criteria, the probable cause described on the left column is the actual cause of the failure. If the check result meets the criteria and there is no specific instruction, proceed to the next step (cause). If a defect is found and repaired, check that the defect has been corrected. Failures in wiring harness Open circuit When the wiring and the internal circuit of the connector are not connected with each other, and there is no continuity Ground fault A wiring harness not to be connected to the GND (ground) circuit comes into contact with the GND (ground) circuit or chassis accidentally. Hot short circuit A wiring harness not to be connected to the power circuit comes into contact with the power circuit accidentally. Short circuit An independent wire in the harness abnormally comes into contact with one of another wire. (Defective insulation in connector or others) 	
6	Short circuit in wiring harness		



CONNECTOR CONTACT IDENTIFICATION



The male or female is for pin, and the convex or concave is for fitting (housing).

No. of pins	X type connector		T-adapter Part No.
	Male (female housing)	Female (male housing)	
1	Part No.: 08055-00181	Part No.: 08055-00191	799-601-7010
2	 <p>Part No.: 08055-00282</p>	 <p>Part No.: 08055-00292</p>	799-601-7020
	 <p>Part No.: 08055-00381</p>	 <p>Part No.: 08055-00391</p>	
4	 <p>Part No.: 08055-00481</p>	 <p>Part No.: 08055-00491</p>	799-601-7040
	—	<ul style="list-style-type: none"> Terminal part No.: 79A-222-3370 Electric wire size: 0.85 Grommet: Black Q'ty: 20 	
—	<ul style="list-style-type: none"> Terminal part No.: 79A-222-3380 Electric wire size: 2.0 Grommet: Red Q'ty: 20 	<ul style="list-style-type: none"> Terminal part No.: 79A-222-3410 Electric wire size: 2.0 Grommet: Red Q'ty: 20 	—





No. of pins	AMP070 type connector		T-adapter Part No.
	Male (female housing)	Female (male housing)	
20	 <p>BWP04767</p>	 <p>BWP04768</p>	799-601-7550
	—	Part No.: 7821-92-7370	

No. of pins	AMP type connector		T-adapter Part No.
	Oil pressure sensor		
	Sensor side (plug)	Harness side (receptacle)	
3	 <p>B4H17076</p>	 <p>B4H17077</p>	799-601-9420 (Kit: 799-601-4101) (Kit: 799-601-4201)
	—	—	



No. of pins	YAZAKI type connector		Testing connection use special tool part No.
	Wiper intermittent unit		
	Male (female housing)	Female (male housing)	
11	 <p>B4H17078</p>	 <p>B4H17079</p>	—
	—	—	

No. of pins	L type connector		T-adapter Part No.
	Male (female housing)	Female (male housing)	
2	 <p>BWP04769</p>	 <p>BWP04770</p>	—
	—	—	







[The pin No. is also marked on the connector (electric wire insertion end)]

No. of pins	DT Series connector		
	Body (plug)	Body (receptacle)	T-adapter Part No.
8	 <p style="text-align: center;">BWP05045</p>	 <p style="text-align: center;">BWP05046</p>	Body color (Gray): 799-601-9060 Body color (Black): 799-601-9070 Body color (Green): 799-601-9080 Body color (Brown): 799-601-9090
	Part No.: 08192-1820□ (Normal type) 08192-2820□ (Fine wire type)	Part No.: 08192-1810□ (Normal type) 08192-2810□ (Fine wire type)	
12	 <p style="text-align: center;">BWP05047</p>	 <p style="text-align: center;">BWP05048</p>	Body color (Gray): 799-601-9110 Body color (Black): 799-601-9120 Body color (Green): 799-601-9130 Body color (Brown): 799-601-9140
	Part No.: 08192-1920□ (Normal type) 08192-2920□ (Fine wire type)	Part No.: 08192-1910□ (Normal type) 08192-2910□ (Fine wire type)	

[The pin No. is also marked on the connector (electric wire insertion end)]

No. of pins	DTM Series connector		T-adapter Part No.
	Body (plug)	Body (receptacle)	
2	 <p style="text-align: center;">BWP05049</p>	 <p style="text-align: center;">BWP05050</p>	799-601-9010 799-601-9890
	Part No.: 08192-02200	Part No.: 08192-02100	

FRAMATOME connector for engine

No. of pins	NE speed sensor (95, 107, 114, 125, 140 engine) CAM sensor (95, 107, 114 engine)		T-adapter Part No.
	Sensor side (plug)	Harness side (receptacle)	
3	 <p>KSP00178</p>	 <p>KSP00179</p>	799-601-4130 (Kit: 799-601-4101) (Kit: 799-601-4201)
—	—	—	—
No. of pins	Boost (air intake) pressure sensor (125, 140 engine) Exhaust manifold pressure sensor (107, 114 engine)		T-adapter Part No.
	Sensor side (plug)	Harness side (receptacle)	
3	 <p>KSP00180</p>	 <p>KSP00181</p>	799-601-4180 (Kit: 799-601-4101) (Kit: 799-601-4201)
—	—	—	—
No. of pins	Lubricating oil pressure sensor (125, 140 engine)		T-adapter Part No.
	Sensor side (plug)	Harness side (receptacle)	
3	 <p>KSP00182</p>	 <p>KSP00183</p>	799-601-4150 (Kit: 799-601-4101) (Kit: 799-601-4201)
—	—	—	—

F5.8	5 A	Monitor
F5.9	10 A	Spare

Part	Name	Remark
BR1	Machine select 1	No function
BR2	Machine select 2	No function
BR4	ECSS relay bypass	Set to off position for normal operation.
BZ1	Buzzer	
R158.2	Komtrax relay	
R16	Backup alarm relay	
R167	Blank	
R209	Return to dig relay	
R235	Driving range relay	
R3	Fan drive reverse relay	
R31	Air condition relay	
R337	Interval relay	
R373.1	Blank	
R373.2	Parking brake REV relay	
R376	Blank	
R411	Over center valve relay	
R42	ECSS relay	
R45	Monitor brightness relay	
R56.1	Low beam relay	
R56.2	High beam relay	
R67	Flasher relay	
ROP3	Option relay	Relay not part of the machine. Socket can be used for individual option.
R51	Blank	Not used in machine

Failure Code	Trouble-shooting Code	Failure (Displayed on screen)	Applicable component	History category	Remarks
#B1471	P1471	External Monitoring IC and CPU Fault 1	ECU	Electrical System	Internal error of ECU
#B1473	P1473	ROM Fault	ECU	Electrical System	Internal error of ECU
#B1474	P1474	Shutoff Path Fault 1	ECU	Electrical System	Internal error of ECU
#B1475	P1475	Shutoff Path Fault 2	ECU	Electrical System	Internal error of ECU
#B1476	P1476	Shutoff Path Fault 3	ECU	Electrical System	Internal error of ECU
#B1477	P1477	Shutoff Path Fault 4	ECU	Electrical System	Internal error of ECU
#B1478	P1478	Shutoff Path Fault 5	ECU	Electrical System	Internal error of ECU
#B1479	P1479	Shutoff Path Fault 6	ECU	Electrical System	Internal error of ECU
#B1480	P1480	Shutoff Path Fault 7	ECU	Electrical System	Internal error of ECU
#B1481	P1481	Shutoff Path Fault 8	ECU	Electrical System	Internal error of ECU
#B1482	P1482	Shutoff Path Fault 9	ECU	Electrical System	Internal error of ECU
#B1483	P1483	Shutoff Path Fault 10	ECU	Electrical System	Internal error of ECU
#B1484	P1484	Recognition Error of Engine Speed	ECU	Electrical System	Internal error of ECU
#B148A	P148A	EGR Valve Sticking	ECU	Electrical System	Internal error of EGR Valve
#B1562	P1562	Charge Switch Disconnection	ECU	Electrical System	Related pins at ECU: A66
#B1568	P1568	Charge Alarm	ECU	Mechanical System	Related pins at ECU: A66
#B1608	P1608	Excessive Voltage of Supply 1	ECU	Electrical System	Internal error of ECU
#B1609	P1609	Sensor Supply Voltage Error 1	ECU	Electrical System	Related pins at ECU: A44
#B160E	P160E	EEPROM Memory Read Error	ECU	Electrical System	Internal error of ECU
#B160F	P160F	EEPROM Memory Writing Error	ECU	Electrical System	Internal error of ECU
#B1613	P1613	H Bridge Control IC (CAN Communcion Error)	ECU	Electrical System	Internal error of ECU
#B1617	P1617	Insufficient Voltage of Supply 1	ECU	Electrical System	Internal error of ECU
#B1618	P1618	Sensor Supply Voltage Error 2	ECU	Electrical System	Related pins at ECU: A45

Failure Code	Trouble-shooting Code	Failure (Displayed on screen)	Applicable component	History category	Remarks
#R9Q8B	0x8500 (11)	Speed Sensor Motor Input Fault Unknown	HST	Electrical System	Related pins at HST: 8, 10, 30 and 56
#R9Q8J	0x8500 (19)	Speed Sensor Motor Input CAN Communication Error	HST	Electrical System	Not in use
#R9Q8V	0x8500 (31)	Speed Sensor Motor Input Not Available	HST	Electrical System	Related pins at HST: 8, 10, 30 and 56
#R9QDB	0x8530 (11)	Velocity Not Plausible Fault Unknown	HST	Electrical System	Related pins at HST: 8, 10, 30 and 56. In addition check the tire size and tire size compensation in the default menu.
#W8001		CAN Communication Error (SA03) Bosch Rexroth	HST	Electrical System	Missing CAN Communication between I/O Controller 64P and HST (Related pins at 64P: B7 and B6 or pins at HST: 49 and 50).
#W8003		CAN Communication Error (SA00) ECU	ECU	Electrical System	Missing CAN Communication between I/O Controller 64P and ECU (Related pins at 64P: B7 and B6 or pins at ECU: A75 and A33).
#W8006		CAN Communication Error (SA20) Komtrax	Komtrax	Electrical System	Missing CAN Communication between I/O Controller 64P and Komtrax Controller (Related pins at 64P: B5 and B4 or pins at Komtrax: A11 and A10).
#W8200		CAN Communication Error (SA17) Display	MON	Electrical System	Missing CAN Communication between I/O Controller 64P and Monitor (Related pins at 64P: B5 and B4 or pins at Monitor: 20 and 29).
#W8400		CAN Communication Error (SA82) Fan Controller	FAN	Electrical System	Missing CAN Communication between I/O Controller 64P and Fan Drive Relay (Related pins at 64P: B5 and B4 or pins at Fan Drive Relay: H and L).
#W8800		CAN Communication Error (SA1E) 64P	64P	Electrical System	Missing CAN Communication between I/O Controller 64P and Monitor (Related pins at 64P: B5 and B4 or pins at Monitor: 20 and 29). When this error is displayed, no other error can be displayed on the monitor.
CA144		Coolant Water Temp (Low) Sensor Short Circuit	MON	Mechanical System	Related pins at I/O Controller 64P: A3
CA145		Coolant Water Temp (Low) Sensor Open Circuit	MON	Mechanical System	Related pins at I/O Controller 64P: A3
DDWCKZ		Direction Switch Abnormality	MON	Mechanical System	Faulty plausibility check at I/O Controller 64P for MFL FNR-Switch. Related pins at I/O Controller 64P: D15 and D7
DGH2KA		Hyd Oil Sensor Open Circuit	MON	Mechanical System	Related pins at I/O Controller 64P: A4

E-15 SOME ITEMS OF GAUGES AND CAUTION LAMPS ON MACHINE MONITOR ARE NOT DISPLAYED PROPERLY

Failure	Some items of gauges and caution lamps are not displayed properly.	
Related information	If mechanical system failure code is displayed, perform troubleshooting for that code first.	
No.	Cause	Procedure, measuring location, criteria and remarks
1	Defective sensor or switch	Perform troubleshooting for failure code related to defective sensor or switch.
2	Defective CAN communication system	Perform troubleshooting for failure code related to defective CAN communication.
3	Defective 64P controller	If no failure is found by checks on causes 1 and 2, 64P controller is defective. (Since this is an internal defect, troubleshooting cannot be performed.)

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

TROUBLESHOOTING FOR HYDRAULIC AND MECHANICAL SYSTEMS (H MODE)

INFORMATION MENTIONED IN TROUBLESHOOTING TABLE (H MODE)

The following information is summarized in the troubleshooting table. Before performing troubleshooting, understand that information fully.

Failure	Failure symptom that appears on machine	
Related information	Information on occurred failure or troubleshooting	
No.	Cause	Procedure, measuring location, criteria and remarks
1	Probable cause of failure (Each number is serial number, not priority sequence.)	<Contents of description> <ul style="list-style-type: none"> • Criteria to determine probable causes • Remarks for determination of probable cause
2		
3		
4		
5		

S-1 ENGINE DOES NOT CRANK WHEN STARTING SWITCH IS TURNED TO START POSITION

No	Cause	Point to check, remarks	Remedy
	Failure	Engine does not crank when starting switch is turned to "START" position	
	Related information	<ul style="list-style-type: none"> See E-mode in "ENGINE DOES NOT START (ENGINE DOES NOT CRANK)" for electrical system troubleshooting If any failure code is displayed, perform troubleshooting for that code first. 	
1	Defective starting circuit wiring system	When starting switch is turned to START, starting motor pinion does not pop out.	Perform troubleshooting of "ENGINE DOES NOT START (ENGINE DOES NOT CRANK)" in E mode, and take corrective action.
2	Defective starting motor (safety relay portion)	<ul style="list-style-type: none"> Starting motor pinion makes grating noise (When starting switch is turned to START position, starting motor pinion pops out). Starting motor pinion comes off halfway (When starting switch is turned to START position, starting motor pinion pops out). Starting motor makes flapping sound and does not turn (When starting switch is turned to START position, starting motor pinion protrudes) (Reference: "Flapping sound" means sound made when starting motor pinion pops in and out) 	Perform troubleshooting of "ENGINE DOES NOT START (ENGINE DOES NOT CRANK)" in E mode, and take corrective action.
3	Breakage of flywheel ring gear	If starting motor pinion makes grating noise and the starting motor does not turn, visually check the flywheel ring gear.	Replace if the item is broken
4	A crack on the EGR cooler (Reference: coolant contained in exhaust)	Disconnect the inlet and outlet gas piping of EGR cooler to check if water containing coolant is draining. REMARK Moisture in exhaust gas may be condensed, but this is not a failure. Check if it is coolant or not.	After EGR cooler replacement, drain the water in the engine cylinder.

No	Cause	Point to check, remarks	Remedy
19	Defective valve clearance	<ul style="list-style-type: none"> When engine is operated, unusual noise is heard from around cylinder head. Check valve clearance. 	Valve clearance adjustment
20	Defective injector	<ul style="list-style-type: none"> A low-temperature cylinder is found when touching the exhaust manifold right after the engine starts. A cylinder running at the unchanged speed is found during operation in the cylinder cut-out mode. <p>REMARK If a black smoke is seen continuously during warm-up operation after storage for a few days, injector may be defective.</p>	Replace injector.
21	Defective engine controller	In case of an internal defect, troubleshooting is impossible as an assembly. Replace whole assembly.	Engine controller replacement
22	Defective contact of valve and valve seat	<ul style="list-style-type: none"> Measure compression pressure (See Standard value table). Check valve clearance 	Valve or valve seat repair or replacement
23	Defective piston ring	<ul style="list-style-type: none"> Remove plug of bore for measuring the exhaust gas color in front of DOC, and check color of the exhaust gas coming out of the bore. Measure compression pressure (See standard value table). Check piston ring and piston ring groove. 	Piston ring and piston replacement

S-17 COOLANT TEMPERATURE RISES TOO HIGH (OVERHEATING)

Failure	Coolant temperature rises too high (overheating)		
Related information	If any failure code is displayed, perform troubleshooting for that code first.		
No.	Cause	Point to check, remarks	Remedy
1	Clogged radiator core	Check for clogging of radiator core and crushing of fin.	Cleaning of radiator core
2	Malfunction of thermostat	Thermostat does not open at cracking temperature. REMARK Opening temperature: 82 °C)	Thermostat replacement
3	Defective coolant temperature gauge	The error is detected in coolant temperature gauge system, but measured coolant temperature in radiator is normal.	Coolant temperature sensor monitor or wiring harness replacement
4	Increase of fuel injection amount	Fuel injection amount is excessive.	Perform troubleshooting of "FUEL CONSUMPTION IS EXCESSIVE" in S mode and take corrective action.
5	Low coolant level	Check coolant level for decrease.	Refilling with coolant
6	Coolant leakage	Check coolant piping for coolant leakage.	Coolant piping replacement
7	Broken water pump	Visually check water pump (check of water leakage through shaft seal, breakage of impeller, breakage of shaft)	Water pump replacement
8	Overheat due to increase in EGR ratio (EGR amount against fresh air intake amount) caused by defective mass air flow and temperature sensor	Check for defective mass air flow and temperature sensor.	Mass air flow and temperature sensor replacement
9	Overheat caused by increase of EGR ratio (quantity of EGR to fresh intake air) caused by deformation of air cleaner	Check air cleaner and rectifying wire net for deformation.	Air cleaner repair or replacement
10	Defective cylinder head or head gasket	Check if there are many bubbles in radiator and if coolant blows back.	Perform troubleshooting of "OIL IS IN COOLANT" in S mode and take corrective action.
11	Defective piston ring	<ul style="list-style-type: none"> Remove plug of bore for measuring the exhaust gas colour in front of DOC and check colour of the exhaust gas coming out of the bore. (Reference: See TESTING AND ADJUSTING "TEST EXHAUST GAS COLOR") Measure compression pressure (See standard value table). (Reference: See "TESTING AND ADJUSTING", "Testing compression pressure".) Check piston ring and piston ring groove. 	Piston ring and piston replacement

Abbreviation	Actual word spelled out	Purpose of use (major applicable machine (*1), or component/system)	Explanation
SCR	Selective Catalytic Reduction	Urea SCR system	This is an exhaust gas purifier using urea water that converts nitrogen oxides (NOx) into harmless nitrogen and water by oxidation-reduction reaction. It may also be mentioned as exhaust gas purification catalyst or part of the name of related devices.
SI	Le Systeme International d' Unites (International unit system)	Unit	Abbreviation for "International System of Units" It is the universal unit system and "a single unit for a single quantity" is the basic principle applied.
SOL	Solenoid	Electrical system	This is an actuator that consists of a solenoid and an iron core that is operated by the magnetic force when the solenoid is energized.
TOPS	Tip-Over Protective Structure	Cab and canopy	This is a protective structure that intended to protect the operator wearing seat belt from suffering injury which may be caused if the cab is crushed when the machine tips over. (Roll-over protective structure of hydraulic excavator) This performance is standardized as ISO 12117.
TWV	2-Way Valve	Hydraulic system	This is a solenoid valve that switches over direction of flow.
VGT	Variable Geometry Turbocharger	Engine	This is a turbocharger on which the cross-section area of the exhaust passage is variable.
VHPC	Variable Horse Power Control	Engine control	This is a function that finely controls the maximum output of the machine so that high work efficiency and low fuel consumption rate are both achieved.


5. Reinstall the fuel filter.
- ☞ Bolts M10: 35-43Nm (25.8-31.7 ft*lb, 3.6-4.4 kgf*m)
6. Reinstall the common rail and the return pipe from the injector.
7. Reinstall the return pipe from the supply pump.
8. Reinstall the fuel supply pipe (supply pump inlet) from the fuel filter.
9. Reinstall the wiring coupler of the fuel temperature sensor.
10. Reinstall the wiring coupler of the SCV.

NOTE


Be sure to perform priming the engine before starting. If air is mixed to the fuel, seizure to the supply pump and the injector may result.

11. Replace attached parts of the supply pump Spare parts for the fuel temperature sensor (1) and the fuel metering valve (suction control valve) (2) are available for replacement. See the below table for the part number and the tightening torque.

Part name	Part No.	Tightening torque
Fuel temperature sensor (with gasket)	129A00-51200	19.2 - 22.1 ft·lb (26 - 30 N·m; 2.7 - 3.1 kgf·m)
Fuel metering valve (suction control valve) (with seal ring and O-ring)	129A00-51100	2.2 - 3.0 ft·lb (3.0 - 4.0 N·m; 0.31 - 0.41 kgf·m)
Fuel metering valve seal ring	129A00-51110	—
Fuel metering valve O-ring	129A00-51120	—
Fuel metering valve fixing bolt	129A00-51130	—




4. Place all the valves (69) in their proper location in the cylinder head.
5. Place the cylinder head on the workbench with the combustion side down to install the valve springs. Install the valve spring (67) and the spring retainer (68).
6. Using the valve spring compressor tool, compress the valve spring.
7. Insert the valve keepers (65) and slowly release the tension on the valve spring. Install the valve cap (64). Repeat the steps on all the remaining valves.





3. Reassembly of cylinder head

1. Carefully clean both the combustion surface of the cylinder head and the top surface of the cylinder block. Then place a new cylinder head gasket (53) on the cylinder block.
2. Position the cylinder head on the cylinder head gasket.




3. Lightly oil the threads of the cylinder head bolts (52). Tighten the bolts to the specified torque in two steps as shown in the chart below. Tighten in the sequence shown in the picture on the right.


-  First step: half of final torque
-  Second step: final torque

4. Insert the push rods in their respective positions.


- 1: Fan end
- 2: Camshaft side



8. Position the brush springs in brush holders. Reinstall the brushes in the brush holders. Reversing the brushes will cause the starter motor to turn backwards.




9. Carefully install the brush holder assembly to the armature assembly.
10. Reinstall the field coil assembly with the armature assembly to the gear housing.
11. Reinstall the rear cover to the brush holder assembly. Securely tighten the two bolts.
12. Reinstall the two M4 through bolts. Securely tighten the through bolts. Reconnect the wire to the magnetic switch assembly. Tighten the M8 nut. Reinstall the cover over the connection.





Install the Starter Motor

1. Reinstall the starter motor to the flywheel housing.
2. Reinstall the starter mounting bolts (1).
3. Reconnect the electrical wires to the magnetic switch assembly (solenoid). Be sure to place the cover over the battery positive (+) cable connection.





2. Drain the hydraulic oil from the radiator


 Total hydraulic oil: 80l

 Hydraulic oil in tank: approx. 45l

1. Unscrew three bolts and remove (3) cover.
2. Screw a drain hose onto the drain valves and open the drain valves for coolant (2a), engine oil (2b) and hydraulic oil (2c).
3. Close the hydraulic lines and coolant lines immediately with a plug in order to prevent vapours from exiting and to prevent any dirt and foreign particles from entering. Remove air filter assembly.




4. Remove the bolts (4).




3. Remove hydraulic and coolant hoses


Allow residual oil and coolant will flow out of the radiator.

1. Loosen the four screws (1) and remove the radiator guard.
2. Disconnect the both hydraulic hoses (2) from the fan drive.
3. Disconnect the connector (3) from the backup buzzer.




3. Loosen the fastening screws (3) and remove the steel hood (1).


 Steel hood: 9 kg



Installation of steel hood

1. Open the engine hood and secure it against falling down by means of a support rod.
2. Tighten all fastening screws (3) slightly. To make sure to achieve the smallest possible gap between front side of steel hood (1) and plastic hood (2) the 4 screws (4) have to be tightened first. Then finally tighten the other screws.

 Screws: 27-34Nm (2.75-3.47kgm)





Removal of engine hood assembly



- Park the machine on level ground and secure it against rolling away and jack-knifing!
- Lower the bucket, switch the engine off and actuate the parking brake!

1. Remove the counterweight.
2. Open the engine hood and secure it against falling down by means of a support rod.
3. Loosen the eight fastening screws (5) on both sides and remove the both fenders.

 Screws: 59 - 74 Nm (6.01 - 7.54 kgm)



Adjust the air conditioner belt. For details See "TEST AND ADJUST AIR CONDITIONER COMPRESSOR BELT TENSION" on page 50-35.

REMOVE AND INSTALL AIR CONDITIONER CONDENSER ASSEMBLY



-
- Place the machine on a level ground and set the parking brake switch to ON position.
 - Set the frame lock bar to LOCK position and chock the tires.
 - Lower the work equipment to the ground and set the work equipment lock switch to LOCK position.
 - Turn the starting switch to OFF position to stop the engine.
 - Turn the battery disconnect switch to OFF position and remove the key.
 - Ask a qualified person for collecting, adding, and filling operations of the refrigerant. (Only qualified persons can work.)
 - Never release the refrigerant to the atmosphere.
 - If refrigerant gas gets in your eyes, you may lose your eye sight. And if it touches your skin, you may suffer from frostbite. Accordingly, put on the protective eyeglasses, gloves, and working clothes with long sleeves while you are collecting or filling with the refrigerant.
-

NOTE

Check the connector numbers and installed positions before disconnecting the wires and hoses and write them down.

NOTE

When disconnecting the wires and hoses, take extreme care not to damage or deform the wires and hoses by the clips and clamps. If the wires or hoses may be damaged or deformed, remove the clips and clamps before starting the work.

GEARBOX (TRANSFER ASSEMBLY)

PRECAUTIONS FOR ASSEMBLY AND DISASSEMBLY

SPECIFICATIONS

DEFINITION OF VIEWPOINTS

LEFT SIDE
LATO SINISTRO
LINKE SEITE
LADO IZQUIERDO
COTE GAUCHE

RIGHT SIDE
LATO DESTRO
RECHTE SEITE
LADO DERECHO
COTE DROITE

DATA PLATE

SPICER®

DANA

TYPE	SERIAL No.
<input type="radio"/> MODEL	<input type="radio"/> RATIO

MANUFACTURED BY DANA ITALIA S.p.a.
MADE IN ITALY

1 - Model number
2 - Reduction ratio
3 - Serial number
4 - Axle number

x0001333

AREXONS (REPOSITIONABLE JOINTING COMPOUND FOR SEALS)

Solvent-based sealing compound for elastic seals, drying through evaporation. Used for sealing the outer diameter of sealing rings for rotating shafts with outer metal reinforcement.

SILICONE

Semi-fluid adhesive material used for sealing and filling and to protect components from environmental and physical elements. Polymerises with non-corrosive dampness.

TECNO LUBE/101 (SILICONE-BASED GREASE)

Highly adhesive synthetic grease, with silicone compounds added.
Applied to adjustment screws with hole communicating with oil-type fluids.
Used when frequent adjusting is required.

MOLIKOTE (DOW CORNING)

Lubricating compound containing molybdenum disulphide, used to lubricate articulation pins and to prevent sticking and oxidation of parts that are not lubricated on a regular basis.

(LITHIUM-BASED) GREASE

Applied to bearings, sliding parts and used to lubricate seals or parts during assembly.

SAFETY PRECAUTIONS

1 - During all operations described in this manual, the axle should be fastened onto a trestle, while the other parts

mentioned should rest on supporting benches.

2 - When removing one of the arms, an anti-tilting safety trestle should be placed under the other arm.

3 - When working on an arm that is fitted on the machine, make sure that the supporting trestles are correctly positioned

and that the machine is locked lengthways.





4 - Do not admit any other person inside the work area; mark off the area, hang warning signs and remove the ignition

key from the machine.

5 - Use only clean, quality tools; discard all worn, damaged, low-quality or improvised wrenches and tools. Ensure that all dynamometric wrenches have been checked and calibrated.

6 - During maintenance operations, always wear protective glasses, safety footwear, protective gloves and all P.P.E. (Personal Protective Equipment) in function of the risks which the workers may be exposed to.

7 - Should you stain a surface with oil, remove marks straight

 DANGER	Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.
 WARNING	Indicates an imminently hazardous situation which, if not avoided, could result in death or serious injury.
 CAUTION	Indicates a situation which, if not avoided, may result in damage to components.
 NOTICE	Indicates information which may make product service easier to perform.

x0001243

Disassembly

CAUTION
Before draining oil, release the internal pressure, for details see OIL DRAINING p. 17.

CAUTION
Make sure all fluids are contained during inspection, maintenance, tests, adjustment and repair of the product. Prepare a suitable container to collect the fluid before removing any component containing fluids. Dispose of all fluids following legal and local regulations.

CAUTION
Hot oil and components can cause personal injury. Avoid skin contact.

CAUTION
Perform all operations on both arms.




FIGURE 1: Remove the oil - level plug (4).




FIGURE 2: Remove the securing screws (20) from the spider cover (21).




FIGURE 3: Disjoin the spider cover (21) from the hub (26) by alternatively forcing a screwdriver into the appropriate slots.




FIGURE 4: Remove the complete planetary carrier cover (21).

x0001311




FIGURE 17: Remove the snap ring (25).




FIGURE 19: Remove the flange and secondary gear wheel (9) using two levers.

⚠ WARNING

Removal of the snap rings can cause personal injuries. You must wear appropriate safety equipment. To avoid injury to eyes, wear eye protection equipment.




FIGURE 18: With a puller, remove the bearing (24) from the input shaft (18).





FIGURE 20: Remove the center ring (8).

x0001120


PLANETARY REDUCTION AND AXLE SHAFT

Exploded view




x0001126

T2



T3



x0001136




FIGURE 19: Bring the pin holes in line with the help of a pin driver. Insert pins (11) to end of stroke.




FIGURE 22: Tighten the capscrews of the crown wheel using the criss-cross method. Torque wrench setting: 78 - 86 N·m




FIGURE 20: Insert planetary gear wheel (6). Position the shim washer (5) on the crown (13).




FIGURE 23: Grease and insert balls (3).

NOTE:

In order to hold the shim washer (5) in position, apply grease to it.



FIGURE 21: Install the crown wheel (13).




FIGURE 24: Verify the position of the slot that fits the coupling (16) to the fixing ball (4).

x0001146

PRECAUTIONS FOR ASSEMBLY AND DISASSEMBLY OF AXLE COMPONENTS

Safety precautions

1. During all operations described in this manual, the axle should be fastened onto a trestle, while the other parts mentioned should rest on supporting benches.
2. When removing one of the arms, an anti-tilting safety trestle should be placed under the other arm.
3. When working on an arm that is fitted on the machine, make sure that the supporting trestles are correctly positioned and that the machine is locked lengthways.
4. Do not admit any other person inside the work area; mark off the area, hang warning signs and remove the ignition key from the machine.
5. Use only clean, quality tools; discard all worn, damaged, low quality or improvised wrenches and tools. Ensure that all torque wrenches have been checked and calibrated.
6. Always wear gloves and non-slip rubber shoes when performing repair work.
7. Should you stain a surface with oil, remove marks straight away.
8. Dispose of all lubricants, seals, rags and solvents once work has been completed. Treat them as special waste and dispose of them according to the relative law provisions obtaining in the country where the axles are being overhauled.
9. Make sure that only weak solvents are used for cleaning purposes; avoid using turpentine, dilutants and toluol, xylol-based or similar solvents; use light solvents such as Kerosene, mineral spirits or water-based, environment friendly solvents.
10. For the sake of clarity, the parts that do not normally need to be removed have not been reproduced in some of the diagrams.
11. After repair work has been completed, accurately touch up any coated part that may have been damaged.
12. Before draining oil it is mandatory to loosen the oil filling plug or the breather (if present), and wait until the internal pressure is completely released. Remove the oil draining plug and drain oil only when the pressure is completely released.

Lubricant & Sealant specifications

- 1 - Locking, sealing and lubricating materials referred to in this manual are the same used in the shop-floor.
- 2 - The table below gives an account of the typical applications of each single material, in order to facilitate replacement with




FIGURE 4: Insert block screws to end stroke and release pressure. Gradually loosen the sleeve and remove.




FIGURE 7: Sling the arm to be removed and connect it to a hoist. Remove screws.

⚠ DANGER

Carefully check that the hydraulic pressure is discharged completely before removing the external pump sleeve connected to the brake.



FIGURE 5: Remove the screws of the planetary gearbox cover on the brake side. Remove the planetary gearbox cover.



FIGURE 8: Take off the arm and lay it down vertically



FIGURE 6: Remove the axle half shaft.



FIGURE 9: In order to keep the disc springs of the negative brake preloaded, tighten the screws with washers to the end stop.

X0001251




FIGURE 60: Insert the disc springs in the right position (28).




FIGURE 63: Check the earlier measured distance Z from the plane to the tooth next to the pin.




FIGURE 61: Insert at the bottom the piston of the negative brake (27) and tighten up the slotted nut (29).




FIGURE 64: Put the pin in locking (21) position.




FIGURE 62: Tighten down the slotted nut to the earlier determined position.



FIGURE 65: Insert two screws of M12 to fix the break arm.

x0001261



FIGURE 12: Remove the planetary gear (22) with washer (23).

x0001270




FIGURE 19: Bring the pin holes in line with the help of a pin driver.
Insert pins (19) to end of stroke.



FIGURE 20: Insert and replace, if necessary, the discs of the differential lock (24, 25).
In case of new discs pack (as spare part), dip the complete disc pack in oil (with LS additive) at least 8 hours (plus 2 dripping hours) before assembly, for details about oil see MAINTENANCE INTERVALS p. 20

⚠ CAUTION

First and last disc have to be of steel (25).



FIGURE 21: Install the thrust block with maximum internal diameter.
Position the bearing (26) in the differential unit.
Install the thrust block with minimum internal diameter.



FIGURE 22: Insert the snap ring (27).

⚠ WARNING

Personal injury can result when installing snap ring. The appropriate safety equipment must be worn. To avoid injury to your eyes, wear protective glasses during this procedure.



FIGURE 23: As to ring (33), the side without notches must face outwards.

x0001287




FIGURE 29: Install the flange (2) onto the pinion (11) without the sealing ring.




FIGURE 30: Install the nut (1) without Loctite 270.




FIGURE 31: Lock the wrench T1 (See drawing T1 p. 258), rotate the pinion using a dynamometric wrench, up to a minimum required torque setting of 260 N-m.




FIGURE 32: Apply onto the pinion (1) the bar - hold and with the help of a torque meter, check the torque of the pinion (1). Torque: 80 - 120 N-cm

⚠ CAUTION

If torque exceeds the maximum value, then the size of shim "S1" (4) between the bearing (9) and the spacer (3) needs to be increased.

If torque does not reach the set value, increase the torque setting of the ring nut (10) in different stages to obtain a maximum value of 300 N-m.

If torque does not reach the minimum value, then the size of shim "S1" (4) needs to be reduced.

When calculating the increase or decrease in size of shim "S1", bear in mind that a variation of shim of 0.01 mm corresponds to a variation of 60 N-cm in the torque of the pinion (1).





FIGURE 33: Make positional marks across nut (1) and pinion (11) tang; then remove nut and flange (2)

x0001343

Exploded view



x0001352

Assembly




FIGURE 1: SETTING OF THE CROWN WHEEL AND PINION
 Insert the thrust block of the bearing (6) opposite side of the crown wheel shims (Sb)(7) to an initial thickness of about 0,55mm.



FIGURE 2: Insert the thrust block (6) and the shims (Sb)(7) into the arm.

NOTE:

Check that it is at the end of stroke.




FIGURE 3: Inspect the o-ring (2) and grease.




FIGURE 4: Temporarily insert all screws of the arm (18).




FIGURE 5: Insert complete differential (5).

CAUTION
 Do not damage the seat of the o-ring with the ring gear.





FIGURE 6: SETTING OF THE CROWN WHEEL AND PINION
 Insert t thrust block (4) of the bearing shims (Sc)(3) of an initial thickness of about 0,75mm.

x0001370

11. Unscrew the three fastening screws (5) under the front frame and lift the main control valve out of the machine.




12. . Remove the two remaining hoses (12) from the main valve.

- ★ Close the hydraulic lines immediately with plugs in order to prevent any dirt and foreign particles from entering.


Now you can remove the main valve from the cabin.





 Main control valve: 16,7kg








Cab door assembly


1. Reassemble the door assembly. For reference see the sketches below.
2. Reassemble the complete door assembly (1) to the cab.

**a. Left door assembly**

-  Screw M8 (1): 25 Nm
-  Screw M6 (2): 10 Nm
-  Screw M8 (3): 11 Nm
-  Screw M10 (4): 15 Nm

**b. Right door assembly**

-  Screw M8 (1): 25 Nm
-  Screw M6 (2): 10 Nm
-  Screw M8 (3): 11 Nm
-  Screw M10 (4): 15 Nm



ELECTRICAL SYSTEM

REMOVE AND INSTALL ENGINE CONTROLLER ASSEMBLY




-
- Place the machine on a level ground and activate the parking brake.
 - Lower the work equipment to the ground.
 - Turn the starting switch to OFF position to stop the engine.
 - Turn the battery disconnect switch to OFF position and remove the key. (For details, see TESTING AND ADJUSTING, "HANDLE BATTERY DISCONNECT SWITCH".)
 - Do not plug or unplug the ECU for a period of at least 60 seconds after power to the unit has been turned on or off.
 - Do not plug or unplug the connector of the DCU when the power is on. Moreover, when the key switch is turned OFF and you have confirmed that the after-run has finished (Check the operating noise of the SM, or define the time after the key is off until the DCU shuts off (approx. 10 min.)), remove the connector.
 - Do not touch connector pins of the ECU and DCU with bare hands. Doing so may result in corrosion of the connector pins and/or damage to the internal circuits of the ECU and DCU due to static electricity.
 - Do not force a measuring probe into the female coupler. Doing so may cause contact failure of the connector pins, resulting in malfunction of the ECU.
 - Take care to prevent water from entering the couplers when plugging or unplugging the connector. Water inside the couplers may cause corrosion, resulting in malfunction of the ECU.
 - Avoid plugging/unplugging the connector more than approx. 10 times.
Frequent plugging/unplugging of the connector may cause contact failure of the connector pins, resulting in malfunction of the ECU.
 - Do not use the ECU and DCU that has ever suffered drop impact.
 - Do not disassemble the ECU and DCU terminal.
-

through the hole in the socket of the relay.

Install I/O controller 64P

1. If required mount the spacers (6) at the front side of the central electric board, bolts (7), toothed washers (8), metal washers (9) and plastic washers (10) at the rear. Check the picture for the correct order of the parts.


2. Fix the spacer at the front side while tightening the bolt at the rear side.


 Bolts (7) (6): Max. 0,8 Nm

3. Check the socket connectors on the central electric board and on the controller for the correct orientation of the controller.

4. Push the I/O Controller 64P (5) to its socket connectors on the central electric board.

5. Tighten the four bolts (1) together with toothed washers (2), metal washers (3) and plastic washers (4). Check the picture above for the correct order of the parts.

 Bolts (1): Max. 0,8 Nm



Install central electric board (CEB)

1. If necessary, move all accessory parts (IO controller 64P, fuses, relays, buzzer, bridge jumper, etc.) from an old central electric board to the new one and add additional parts.

Minimum all parts, which have been equipped before, should be equipped afterwards.

Put the parts back to the exact same position as before.

For the correct place of the components check also: See "SPARE FUSES AND RELAY" on page 50-68.

2. Place the central electric board with its accessories in the console inside the cabin on the dampers (1).

3. Put the washers on the stud of the damper and tighten the nuts.



 Nuts: Max. 4,5 Nm

4. Connect the CEB wiring harness back to the terminals at the front side of the board. For the method of assembling the ring terminals and the tightening torques, See "Method for connecting ring terminals and strip fuses to power stud of printed circuit boards" on page 50-59.

★ Make sure the cap at the end of the cable covers the terminal of the central electric board.

★ Turn the cable on the terminal in a way, that contact with the surrounding covers is avoided.

5. Fix the caps of the harness on the terminals with cable ties.




ABBREVIATION LIST

- This list of abbreviations includes the abbreviations used in the text of the shop manual for parts, components, and functions whose meaning is not immediately clear. The spelling is given in full with an outline of the meaning.
- Abbreviations that are used in general society may not be included.
- Special abbreviations which appear infrequently are noted in the text.
- This list of abbreviations consists of two parts. The first part is a list of the abbreviations used in the text of the manual, and the second part is a list of the abbreviations used in the circuit diagrams.

List of abbreviations used in the text

Abbreviation	Actual word spelled out	Purpose of use (major applicable machine (*1), or component/system)	Explanation
ABS	Antilock Brake System	Travel and brake (HD, HM)	This is a function that releases the brake when the tires skid (tires are not rotated). This function applies the brake again when the tires rotate.
AISS	Automatic Idling Setting System	Engine	This is a function that automatically sets the idle speed.
AJSS	Advanced Joystick Steering System	Steering (WA)	This is a function that performs the steering operations with a lever instead of using a steering wheel. This function performs gear shifting and changing forward and reverse direction.
ARAC	Automatic Retarder Accelerator Control	Travel and brake (HD, HM)	This is a function that automatically operates the retarder with a constant braking force when letting go of the accelerator pedal on the downhill.
ARSC	Automatic Retarder Speed Control	Travel and brake (HD, HM)	This is a function that automatically operates the retarder to ensure that the machine speed does not accelerate above the speed set by the operator when letting go of the accelerator pedal on the downhill.
ASR	Automatic Spin Regulator	Travel and brake (HD, HM)	This is a function that drives both wheels automatically using the optimum braking force when the tire on one side spins on the soft ground surfaces.
ATT	Attachment	Work equipment	A function or component that can be added to the standard specification.
BCV	Brake cooling oil control valve	BRAKE (HD)	This is a valve that bypasses a part of the brake cooling oil to reduce the load applied to the hydraulic pump when the retarder is not being used.
CAN	Controller Area Network	Communication and electronic control	This is one of communication standards that are used in the network on the machine.
CDR	Crankcase Depression Regulator	Engine	This is a regulator valve that is installed to CCV ventilator. It is written as CDR valve and is not used independently.
CLSS	Closed-center Load Sensing System	Hydraulic system	This is a system that can actuate multiple actuators simultaneously regardless of the load (provides better combined operation than OLSS).

MAINTENANCE STANDARD OF REAR AXLE



x0001235

No.	Item	Judgment criteria	Remedy
1	Rear axle bolts (4x)	560 Nm	

ABBREVIATION LIST

- This list of abbreviations includes the abbreviations used in the text of the shop manual for parts, components, and functions whose meaning is not immediately clear. The spelling is given in full with an outline of the meaning.
- Abbreviations that are used in general society may not be included.
- Special abbreviations which appear infrequently are noted in the text.
- This list of abbreviations consists of two parts. The first part is a list of the abbreviations used in the text of the manual, and the second part is a list of the abbreviations used in the circuit diagrams.

List of abbreviations used in the text

Abbreviation	Actual word spelled out	Purpose of use (major applicable machine (*1), or component/system)	Explanation
ABS	Antilock Brake System	Travel and brake (HD, HM)	This is a function that releases the brake when the tires skid (tires are not rotated). This function applies the brake again when the tires rotate.
AISS	Automatic Idling Setting System	Engine	This is a function that automatically sets the idle speed.
AJSS	Advanced Joystick Steering System	Steering (WA)	This is a function that performs the steering operations with a lever instead of using a steering wheel. This function performs gear shifting and changing forward and reverse direction.
ARAC	Automatic Retarder Accelerator Control	Travel and brake (HD, HM)	This is a function that automatically operates the retarder with a constant braking force when letting go of the accelerator pedal on the downhill.
ARSC	Automatic Retarder Speed Control	Travel and brake (HD, HM)	This is a function that automatically operates the retarder to ensure that the machine speed does not accelerate above the speed set by the operator when letting go of the accelerator pedal on the downhill.
ASR	Automatic Spin Regulator	Travel and brake (HD, HM)	This is a function that drives both wheels automatically using the optimum braking force when the tire on one side spins on the soft ground surfaces.
ATT	Attachment	Work equipment	A function or component that can be added to the standard specification.
BCV	Brake cooling oil control valve	BRAKE (HD)	This is a valve that bypasses a part of the brake cooling oil to reduce the load applied to the hydraulic pump when the retarder is not being used.
CAN	Controller Area Network	Communication and electronic control	This is one of communication standards that are used in the network on the machine.
CDR	Crankcase Depression Regulator	Engine	This is a regulator valve that is installed to CCV ventilator. It is written as CDR valve and is not used independently.
CLSS	Closed-center Load Sensing System	Hydraulic system	This is a system that can actuate multiple actuators simultaneously regardless of the load (provides better combined operation than OLSS).

- The quantity of the liquid refrigerant that can be evaporated in the evaporator depends on the amount of heat (refrigeration load) to be removed under the specific evaporation temperature (evaporation pressure).
- The expansion valve controls the refrigerant supply rate to prevent too much or too little supply of the liquid refrigerant.

(*1) Throttle action

- If there is a narrow section in the passage through which liquid is flowing at a constant rate, a resistance to the flow is generated.
When the liquid passes through a narrow section, cross-sectional area suddenly increases. The liquid expansion causes pressure and temperature to decrease.
- No heat is transferred between inside and outside by the throttle action.

Evaporation (Evaporator)

- The evaporator evaporates the liquid refrigerant (superheated vapor).
- The refrigerant evaporates, while absorbing an amount of heat necessary for evaporation (evaporation heat) from the air around the cooling fins (air in the cab).
- The cooled air is sent into the cab by the blower fan, and it decreases the temperature in the cab.
- In the evaporator, the misty refrigerant sent from the expansion valve and the evaporated gas refrigerant are mixed together.
- The temperature (evaporation temperature) and the pressure (evaporation pressure) at which the liquid refrigerant is evaporated are proportional to each other.
- To evaporate the liquid refrigerant at lower temperature, the pressure in the evaporator must be kept as low as possible. For this purpose, the compressor sucks in the evaporated refrigerant.

Relation between refrigerant and cooling trouble

- While repeating the refrigeration cycle, the refrigerant circulates in the refrigeration circuit and dissipates the heat in the cab to the outside of the cab.
- If there is an insufficient quantity of refrigerant, all of it is evaporated while it is passing through the evaporator. This causes evaporator efficiency to deteriorate, which will result in defective air conditioning.
- If there is excessive refrigerant, not all of it is evaporated and part of it will be sucked into the compressor in liquid form, which causes the compressor to compress the liquid and may damage the components.


90 OTHER

NOTE

Spare part numbers and drawing numbers are only for orientation between pages.
For more details, see Part No. in Parts Book.

HYDRAULIC CIRCUIT DIAGRAM	90-5
WIRING DIAGRAMS.....	90-7
Contents	90-7
1-0 SYMBOLS SUMMARY, ABBREVIATIONS	90-8
1-1 HARNESS ARRANGEMENT DETAILS, JOYSTICK BUTTONS	90-9
1-2 CAN BUS SUMMARY	90-10
2-0 POWER SUPPLY, STARTER SWITCH	90-11
2-1 GROUNDING	90-12
2-2 RELAYB., STARTER, ALTERN., BATTERY, GLOW PLUG	90-13
2-3 MAIN ENGINE (EGR) RELAY, EGR VALVE	90-14
3-0 ECU, DPF SENS., REGENER. SW., SEC. ENG. STOP	90-15
3-1 ECU, ENGINE SENSORS	90-16
3-2 INJECT., FUEL P., AIR CLEAN., TRAVEL PED., OIL PR.	90-17
4-0 MONITOR, I/O CONTROLLER 64P, BUZZER	90-18
4-1 KOMTRAX CTRL, SERVICE CONNECTOR	90-19
4-2 FLUID-SENSORS (OIL, FUEL, COOLANT), SPEED SENS.	90-20
5-0 IMMOBILIZER, PARKING BRAKE, FNR SWITCH	90-21
5-1 HST CONTROLLER, DRIVING FUNCTIONS	90-22
5-2 HST CONTROLLER INPUTS, AUTO INCH	90-23
5-3 CREEP	90-24
6-0 FAN DRIVE, REVERSE FAN	90-25
7-0 AIR CONDITIONER, OPERATOR'S SEAT	90-26
7-1 WASHER, WIPER, REAR WINDOW HEATER, HORN	90-27
8-0 LIGHTING FRONT	90-28
8-1 FLASHER	90-29
8-2 REAR LIGHT, BACKUP AL., REAR FLASHER	90-30
8-3 WORK LAMPS	90-31
8-4 INTERIOR LAMP, ROTATING BEACON, PLUG BOX	90-32
9-0 ECSS, OVER CENTER VALVE	90-33
9-1 RETURN TO DIG, QUICK COUPLER	90-34
9-2 RADIO, CLS, BLANK OPTION	90-35
W1 WIRING HARNESS LIST	90-36
W2 CONNECTOR LIST 1	90-37
W2 CONNECTOR LIST 2	90-38
W2 CONNECTOR LIST 3	90-39
W2 CONNECTOR LIST 4	90-40
W2 CONNECTOR LIST 5	90-41
W3 PIN LOCATION LIST 1	90-42
W3 PIN LOCATION LIST 2	90-43
W3 PIN LOCATION LIST 3	90-44

8-3 WORK LAMPS



PARTS IN NOT MARKED AREA ARE LOCATED IN: CABIN - CABIN HARNESS 42W-06-52114

FUNCTION: WORK LAMPS

8-3/29

42T-06-50000
WIRING DIAGRAM WA70M-8E0

SIZE A3



W3 PIN LOCATION LIST 10

A		B			C			D			E			F								
PARTS IN NOT MARKED AREA ARE LOCATED IN:		FUNCTION: PIN LOCATION LIST			W3-10			42T-06-50000			WIRING DIAGRAM WA70M-8E0			SIZE A3								
8		7			6			5			4			3			2			1		
NO.	CONNECTOR NAME	PIN NO	▲ PART OF			DRAWN ON PAGE																
791	CN-R56.1F	5	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R56.1F			42T-06-50000 8-0.5B																
792	CN-R56.1F	6	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R56.1F																			
793	CN-R56.1F	7	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R56.1F																			
794	CN-R56.1F	8	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R56.1F																			
795	CN-R56.1F	9	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R56.1F																			
796	CN-R56.2F	1	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R56.2F			42T-06-50000 8-0.4B																
797	CN-R56.2F	2	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R56.2F			42T-06-50000 8-0.4B																
798	CN-R56.2F	3	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R56.2F			42T-06-50000 8-0.4B																
799	CN-R56.2F	4	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R56.2F																			
800	CN-R56.2F	5	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R56.2F			42T-06-50000 8-0.4B																
801	CN-R56.2F	6	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R56.2F																			
802	CN-R56.2F	7	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R56.2F																			
803	CN-R56.2F	8	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R56.2F																			
804	CN-R56.2F	9	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R56.2F																			
805	CN-R67F	1	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R67F			42T-06-50000 8-1.7D																
806	CN-R67F	2	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R67F			42T-06-50000 8-1.7D																
807	CN-R67F	3	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R67F			42T-06-50000 8-1.7D																
808	CN-R67F	4	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R67F																			
809	CN-R67F	5	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R67F			42T-06-50000 8-1.7D																
810	CN-R67F	6	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R67F																			
811	CN-R67F	7	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R67F																			
812	CN-R67F	8	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R67F																			
813	CN-R67F	9	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R67F																			
814	CN-R158.2F	1	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R158.2F			42T-06-50000 4-1.5E																
815	CN-R158.2F	2	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R158.2F			42T-06-50000 4-1.5E																
816	CN-R158.2F	3	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R158.2F			42T-06-50000 4-1.5E																
817	CN-R158.2F	4	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R158.2F			42T-06-50000 4-1.4E																
818	CN-R158.2F	5	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R158.2F																			
819	CN-R158.2F	6	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R158.2F																			
820	CN-R158.2F	7	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R158.2F																			
821	CN-R158.2F	8	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R158.2F																			
822	CN-R158.2F	9	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R158.2F																			
823	CN-R167F	1	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R167F			42T-06-50000 5-0.2F																
824	CN-R167F	2	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R167F			42T-06-50000 5-0.1F																
825	CN-R167F	3	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R167F			42T-06-50000 5-0.1F																
826	CN-R167F	4	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R167F			42T-06-50000 5-0.1F																
827	CN-R167F	5	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R167F			42T-06-50000 5-0.2F																
828	CN-R167F	6	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R167F																			
829	CN-R167F	7	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R167F																			
830	CN-R167F	8	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R167F																			
831	CN-R167F	9	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R167F																			
832	CN-R209F	1	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R209F			42T-06-50000 9-1.8F																
833	CN-R209F	2	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R209F			42T-06-50000 9-1.8E																
834	CN-R209F	3	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R209F			42T-06-50000 9-1.7F																
835	CN-R209F	4	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R209F																			
836	CN-R209F	5	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R209F			42T-06-50000 9-1.7E																
837	CN-R209F	6	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R209F																			
838	CN-R209F	7	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R209F																			
839	CN-R209F	8	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R209F																			
840	CN-R209F	9	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R209F																			
841	CN-R235F	1	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R235F			42T-06-50000 5-1.3F																
842	CN-R235F	2	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R235F			42T-06-50000 5-1.3E																
843	CN-R235F	3	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R235F			42T-06-50000 5-1.3F																
844	CN-R235F	4	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R235F			42T-06-50000 5-1.3E																
845	CN-R235F	5	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R235F			42T-06-50000 5-1.3E																
846	CN-R235F	6	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R235F																			
847	CN-R235F	7	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R235F																			
848	CN-R235F	8	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R235F																			
849	CN-R235F	9	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R235F																			
850	CN-R337F	1	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R337F			42T-06-50000 7-1.6C																
851	CN-R337F	2	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R337F			42T-06-50000 7-1.6C																
852	CN-R337F	3	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R337F			42T-06-50000 7-1.5C																
853	CN-R337F	4	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R337F			42T-06-50000 7-1.5C																
854	CN-R337F	5	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R337F																			
855	CN-R337F	6	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R337F																			
856	CN-R337F	7	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R337F																			
857	CN-R337F	8	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R337F																			
858	CN-R337F	9	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R337F			42T-06-50000 7-1.6C																
859	CN-R373.1F	1	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R373.1F			42T-06-50000 5-0.3D																
860	CN-R373.1F	2	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R373.1F			42T-06-50000 5-0.3C																
861	CN-R373.1F	3	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R373.1F			42T-06-50000 5-0.3D																
862	CN-R373.1F	4	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R373.1F																			
863	CN-R373.1F	5	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R373.1F			42T-06-50000 5-0.3C																
864	CN-R373.1F	6	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R373.1F																			
865	CN-R373.1F	7	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R373.1F																			
866	CN-R373.1F	8	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R373.1F																			
867	CN-R373.1F	9	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R373.1F																			
868	CN-R373.2F	1	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R373.2F			42T-06-50000 5-0.2D																
869	CN-R373.2F	2	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R373.2F			42T-06-50000 5-0.2C																
870	CN-R373.2F	3	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R373.2F			42T-06-50000 5-0.2D																
871	CN-R373.2F	4	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R373.2F																			
872	CN-R373.2F	5	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R373.2F			42T-06-50000 5-0.2C																
873	CN-R373.2F	6	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R373.2F																			
874	CN-R373.2F	7	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R373.2F																			
875	CN-R373.2F	8	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R373.2F																			
876	CN-R373.2F	9	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R373.2F																			
877	CN-R376F	1	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R376F			42T-06-50000 9-1.3E																
878	CN-R376F	2	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R376F			42T-06-50000 9-1.3E																
879	CN-R376F	3	CABIN - CENTRAL ELECTRIC BOARD 42W-06-52720 CN-R376F			42T-06-50000 9-1.3E																

No entry in „DRAWN ON PAGE“ means pin is not used.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL