



BI012589  
JUNE 2013  
VOLUME I of II

# System Operation, Testing & Adjusting Manual

---

## MD6640 Blast Hole Drill

---

Serial Number DR612159

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Caterpillar Global Mining, LLC.  
Electrical Adjustments For MD6640 Drill

	I 9.3	
	I 9.4	
	I 9.5	
	I 9.6	
	I 9.7	
	I 10.0	
	I 10.1	
	I 10.2	
	I 10.3	
	I 10.4	
	I 10.5	
	I 10.6	
	I 10.7	
	I 11.0	
	I 11.1	
	I 11.2	
	I 11.3	
	I 11.4	
	I 11.5	
	I 11.6	
	I 11.7	
SLOT 7	I 12.0	
	I 12.1	
	I 12.2	
	I 12.3	
	I 12.4	
	I 12.5	
	I 12.6	
	I 12.7	
	I 13.0	
	I 13.1	
	I 13.2	
	I 13.3	
	I 13.4	
	I 13.5	
	I 13.6	
	I 13.7	
	I 14.0	
	I 14.1	
	I 14.2	
	I 14.3	
	I 14.4	
	I 14.5	
	I 14.6	
	I 14.7	
	I 15.0	
	I 15.1	
	I 15.2	
	I 15.3	
	I 15.4	
	I 15.5	
	I 15.6	
	I 15.7	
SLOT 8	I 16.0	
	I 16.1	
	I 16.2	
	I 16.3	
	I 16.4	
	I 16.5	
	I 16.6	
	I 16.7	
	I 17.0	
	I 17.1	
	I 17.2	
	I 17.3	
	I 17.4	
	I 17.5	
	I 17.6	
	I 17.7	
	I 18.0	
	I 18.1	
	I 18.2	
	I 18.3	
	I 18.4	
	I 18.5	
	I 18.6	
	I 18.7	
	I 19.0	
	I 19.1	

CATERPILLAR GLOBAL MINING, LLC.  
ELECTRICAL ADJUSTMENTS FOR BLAST HOLE DRILLS  
USING SIEMENS DC MOTION CONTROL DRIVES

ROTARY DRIVE START UP ADJUSTMENTS WITH POWER ON

PARAM. INDEX		PARAM	DEFAULT	MDV810 ROTARY	ACTUAL VALUE
<u>NO.</u>	<u>NO.</u>	<u>DESC.</u>	<u>VALUE</u>	<u>STD. VALUE</u>	
P456	2	CONNECTOR SELECTOR SWITCH 1 CONTROL	0	20	
P457	1	INPUT FOR CONNECTOR SELECTOR SWITCH 2	0	230	
P458	1	CONNECTOR SELECTOR SWITCH 2 CONTROL	0	24	
P611	1	FIELD CURRENT REFERENCE SELECTION	277	231	
P664	1	SOURCE FOR CONTROL WORD 1, BIT 6	1	16	
P665	1	1ST SOURCE FOR CONTROL WORD 1, BIT 7	0	10	
P750	0	OUTPUT VALUE SOURCE, ANALOG OUTPUT 1	0	292	
P752	0	ANALOG OUTPUT 1 FILTER TIME	0	100	
P753	0	NORMALIZATION OF ANALOG OUTPUT 1	10	10.38	
P755	0	OUTPUT VALUE SOURCE, ANALOG OUTPUT 2	0	266	
P757	0	ANALOG OUTPUT 2 FILTER TIME	0	100	
P758	0	NORMALIZATION OF ANALOG OUTPUT 2	10	15	
P760	0	OUTPUT VALUE SOURCE, ANALOG OUTPUT 3	0	117	
P762	0	ANALOG OUTPUT 3 FILTER TIME	0	100	
P763	0	NORMALIZATION OF ANALOG OUTPUT 3	10	6.8	
P771	0	OUTPUT VALUE SOURCE, BINARY OUTPUT 1	0	107	
P820	7	DISABLE FAULT MONITORING	0	38	
P820	8	DISABLE FAULT MONITORING	0	42	
P820	9	DISABLE FAULT MONITORING	0	48	
P820	10	DISABLE FAULT MONITORING	0	40	
P825	1	FIELD FEEDBACK ANALOG OFFSET	19139	*	
P825	2	FIELD FEEDBACK ANALOG OFFSET	19139	*	
P825	3	FIELD FEEDBACK ANALOG OFFSET	19139	*	
P826	1	AC LINE ZERO CROSSING CORRECTION	0	**	
P826	2	AC LINE ZERO CROSSING CORRECTION	0	**	
P826	3	AC LINE ZERO CROSSING CORRECTION	0	**	
P826	4	AC LINE ZERO CROSSING CORRECTION	0	**	
P826	5	AC LINE ZERO CROSSING CORRECTION	0	**	
P826	6	AC LINE ZERO CROSSING CORRECTION	0	**	
U580	0	CONTROL WORD FOR COMMUATION MONITORING	7	4	
U962	99	FUNCTION BLOCK PROCESSING SEQUENCE	299	0	
U962	100	FUNCTION BLOCK PROCESSING SEQUENCE	300	299	

\* AUTOMATICALLY DETERMINED BY THE DRIVE DURING THE PARAMETER DEFAULT PROCEDURE.

\*\* AUTOMATICALLY DETERMINED BY THE DRIVE IF ARMATURE CURRENT CONTROLLER SELF TUNING IS PERFORMED.

COPYRIGHTED

COPYRIGHTED

COPYRIGHTED

COPYRIGHTED

SYMBOL DESCRIPTIONS

SYMBOL	DESCRIPTION	LOCATION	SHEET	LINE
ACAFT	AIR COMP. AIR PRESSURE TRANSDUCER	AC	110	19
ACATS	AIR COMPRESSOR AIR TEMP SENSOR	AC	110	37
ACATT	AIR COMPRESSOR AIR TEMP TRANSDUCER	ZPCA	110	36
ACC	AIR COMPRESSOR CONTACTOR	MCC-ZSC	21	19
ACCFA	AIR COMP. COOLER FAN MOTOR	ZMF	21	62
ACCFA2	AIR COMP. COOLER FAN MOTOR CONTACTOR	MCC-ZLVA	200	70
ACCFA3	AIR COMP. COOLER FAN MTR. OIL BREAKER	MCC-ZLVA	21	62
ACCFA4	AIR COMP. COOLER FAN OVERLOAD RELAY	MCC-ZLVA	21	62
ACD	AIR COMPRESSOR DISCONNECT	MCC-ZSC	21	04
ACDAVS	AIR COMPRESSOR DRILL AIR VALVE SOLENOID	ZMF	201	45
ACPS	AIR COMPRESSOR INLET PRESSURE SWITCH	AC	110	06
ACM	AIR COMPRESSOR MOTOR	AC	21	06
ACMH	AIR COMPRESSOR MOTOR HEATER	AC	811	34
ACMSR	AIR COMPRESSOR MOTOR START RELAY	ZPCA	200	74
ACD	AIR COMPRESSOR START CABINET OVERLOAD	MCC-ZSC	21	03
ACD31	AIR COMPRESSOR OIL FILTER SWITCH	AC	110	03
ACDPS	AIR COMPRESSOR OIL PRESSURE SWITCH	AC	110	11
ACDTS	AIR COMPRESSOR OIL TEMP SENSOR	AC	110	27
ACDIT	AIR COMPRESSOR OIL TEMP TRANSDUCER	ZPCA	110	26
ACSHM	AIR COMPRESSOR START HYDRAULIC MOTOR	ZMF	812	18
ACSHMC	AIR COMPRESSOR START HYDRAULIC MOTOR CONTACTOR	ZPCA	813	18
ACSHMO	AIR COMPRESSOR START HYDRAULIC MOTOR OVERLOAD	ZPCA	813	18
ACSHRFB	AIR COMPRESSOR START PUSHBUTTON	ZPCA	100	32
ACSTOFPB	AIR COMPRESSOR STOP PUSHBUTTON	ZPCA	100	30
ACLES	AIR COMPRESSOR UNLOAD SELECTOR SWITCH	ZCSL	500	46
ACVYS	AIR COMPRESSOR VENT VALVE SOLENOID	ZMF	201	49
ACVV01	AIR COMP. VARIABLE VOLUME VALVE SOL.	AC	201	08
ACVV02	AIR COMP. VARIABLE VOLUME VALVE SOL.	AC	201	12
ACVV03	AIR COMP. VARIABLE VOLUME VALVE SOL.	AC	201	16
ANH	ANNUNCIATOR HORN	ZCCA	503	53
APK1	AUXILIARY POWER FUSED DISCONNECT	ZHVC	20	13
APK2	AUXILIARY POWER FUSED DISCONNECT	ZHVC	20	15
APK3	AUXILIARY POWER FUSED DISCONNECT	ZHVC	20	17
APT	AUXILIARY POWER TRANSFORMER	ZTH	20	15
ASCH1	AIR COMPRESSOR START CABINET HEATER	MCC-ZSC	810	06
BS5A	BREAKOUT BOARD A - NODE 5 - MODULE 4	ZCSL	500	03
BS5-4B	BREAKOUT BOARD B - NODE 5 - MODULE 4	ZCSL	500	44
BS5-5A	BREAKOUT BOARD A - NODE 5 - MODULE 5	ZCSR	501	03
BS5-5B	BREAKOUT BOARD B - NODE 5 - MODULE 5	ZCSR	501	44
BS5-6A	BREAKOUT BOARD A - NODE 5 - MODULE 6	ZCCA	500	03
BS5-6B	BREAKOUT BOARD B - NODE 5 - MODULE 6	ZCCA	500	44
BS5-8	BREAKOUT BOARD NODE 5 - MODULE 8	ZCCA	500	44
BOWEVS	BREAK-OUT WRENCH EXTEND VALVE SOLENOID	ZZMA	304	24
BOWRVS	BREAK-OUT WRENCH RETRACT VALVE SOLENOID	ZZMA	304	20
BOWS	BREAK-OUT WRENCH SELECTOR SWITCH	ZCSR	501	05
BSCS	BOARDING STAR CAB SELECTOR SWITCH	ZCCA	500	05

THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LA SUITE. © 2012. Bucyrus International, Inc. ALL RIGHTS RESERVED.

**Bucyrus International, Inc.**  
 BUCYRUS INTERNATIONAL  
 10000 W. 100TH AVENUE  
 BROOMFIELD, CO 80020-3000

BY: J. MURPHY  
 DATE: 12-18-2012  
 ESN: D  
 DESCRIPTION: SYMBOL DESCRIPTIONS

NO: MD6640  
 MODEL: MD6640  
 SHEET: 9  
 OF: 8

NO: 4356336  
 SHEET: 8  
 OF: 8

REVISION DATA

COPYRIGHTED

COPYRIGHTED

COPYRIGHTED

COPYRIGHTED



PAGE INTENTIONALLY BLANK

COPYRIGHTED

01  
02  
03  
04  
05  
06  
07  
08  
09  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41

LOCATION		BY		DATE	ECN	DESCRIPTION		REVISION DATA	
THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LA SUITE. © 2012 Bucyrus International, Inc. ALL RIGHTS RESERVED.		Bucyrus International, Inc.		NO		DATE		CONF ON BK	
DESCRIPTION		Bucyrus International, Inc.		MD6640		12-18-2012		35	
ENGINEER		J. MURPHY		AZD		D		SHEET	
DRAWER		J. MURPHY		4356336				34	

COPYRIGHTED









## TABLE OF CONTENTS

<b>OVERVIEW.....</b>	<b>5</b>
<b>GENERAL MACHINE DESCRIPTION .....</b>	<b>5</b>
<b>GENERAL MACHINE DESCRIPTION .....</b>	<b>6</b>
DRILL OVERVIEW .....	6
AUXILIARY FUNCTIONS.....	6
GENERAL CONTROLS AND POWER .....	7
<b>OPERATOR INTERFACE .....</b>	<b>9</b>
OVERVIEW.....	9
OPERATOR CHAIR CONTROLS.....	9
<i>Left Propel Track / Winch – Joystick – POLMS.....</i>	<i>10</i>
<i>Right Propel Track / Pipe Rack / Mast – Joystick – PORMS.....</i>	<i>10</i>
<i>Hoist/Pulldown Master Switch - HPMS.....</i>	<i>10</i>
<i>Rotary Master Switch – RMS.....</i>	<i>10</i>
<i>Programmed Drill Control Pushbutton – PDCPB (Option).....</i>	<i>10</i>
<i>Depth Indicator Reset Pushbutton – DIRPB.....</i>	<i>10</i>
<i>Drill Deck Hatch Selector Switch – DDHSS.....</i>	<i>11</i>
<i>Hoist/Pulldown Selector Switch – HPSS.....</i>	<i>11</i>
<i>Drill/Propel/Mast Selector Switch – DPMSS.....</i>	<i>11</i>
<i>Rotary Speed Control Selector Switch – RSCSS.....</i>	<i>12</i>
<i>Hoist/Pulldown Brake Selector Switch – HPBSS.....</i>	<i>12</i>
<i>Air Compressor Unload Selector Switch – ACUSS.....</i>	<i>12</i>
<i>Water Injection Selector Switch – WISS (Option).....</i>	<i>13</i>
<i>Water Injection Rheostat – WIR (Option).....</i>	<i>13</i>
<i>Dust Curtain Selector Switch – DCSS (Option).....</i>	<i>13</i>
<i>Emergency Stop Maintained Pushbutton – ESPB1.....</i>	<i>14</i>
<i>Drill Pipe Position Selector Switch (STORE/OVER HOLE) – DPPSS (Option).....</i>	<i>14</i>
<i>Dust Seal Slider Selector Switch (FRONT/REAR) - DSSSS (Option).....</i>	<i>14</i>
<i>Propel Speed Range Selector Switch – POSRSS.....</i>	<i>14</i>
<i>Horn Pushbutton – SHNPB1.....</i>	<i>14</i>
<i>Tool Wrench Selector Switch – TWSS.....</i>	<i>14</i>
<i>Breakout Wrench Selector Switch – BOWSS.....</i>	<i>15</i>
<i>Pipe Rack Selector Switch – PRSS (Option).....</i>	<i>15</i>
<i>Manual Leveling Jack Control Switches – JRRSS, JFLRSS, JRLSS.....</i>	<i>15</i>
<i>Automatic Leveling Jack Control Switch – JACSS.....</i>	<i>15</i>
CONSOLE CONTROLS.....	16
<i>Ground Test Pushbutton – GTPB.....</i>	<i>16</i>
<i>Exterior Lights Selector Switch – ELSS.....</i>	<i>16</i>
<i>Thermostat Control – HVACTC.....</i>	<i>16</i>
<i>HVAC Fan Selector Switch – HVACFSS.....</i>	<i>16</i>
<i>HVAC Mode Selector Switch – HVACMSS.....</i>	<i>16</i>
<i>Boarding Stairs Cab Selector Switch – BSCSS.....</i>	<i>17</i>
MACHINERY HOUSE CONTROLS.....	17
<i>Air Compressor Start Pushbutton - ACSTARTPB.....</i>	<i>17</i>
<i>Air Compressor Stop Pushbutton - ACSTOPPB.....</i>	<i>17</i>
<i>Emergency Stop Pushbutton – ESPB2.....</i>	<i>17</i>
OPERATOR DISPLAY.....	17
<b>MACHINE OPERATION .....</b>	<b>19</b>
OVERVIEW.....	19
MACHINE STARTUP.....	19

In the UP position, the hydraulic valve for raising the dust curtain is energized until the operator releases the selector switch. In the DOWN position, the hydraulic valve for lowering the dust curtain is energized until the operator releases the selector switch. An option can be set through the operator display to automatically raise the dust curtain when either PROPEL or REMOTE PROPEL modes are selected. In this case the hydraulic valve for raising the dust curtain is energized for 10 seconds upon entering these modes. See "Operator Display Instructions" for more information on this option.

#### **Emergency Stop Maintained Pushbutton – ESPB1**

This maintained pushbutton is located toward the rear of the left pod on the operator's chair. This button is wired in series with the other Emergency Stop buttons around the machine. Pressing any of these buttons has the same affect. As soon as this button is pressed, the control signal for the main air compressor motor is interrupted and it, along with the DC drives and all auxiliary equipment shuts down. Additionally, the power to all PLC outputs is interrupted, the control to the proportional hydraulic valves (hoist/pulldown, bit, propel, mast, etc.) is shut off, and an alarm is displayed on the operator display. Power to the PLC is not interrupted in order to maintain communication with the operator display. Since this is a maintained button, it is necessary to lift the button back up to allow normal operation to resume. The "Fault Reset" button on the operator display will also need to be pressed to clear the annunciation and allow operation.

**WARNING:** This switch is for emergency use only. It is not to be used as a regular shutdown for the drill. Refer to the Operator's Manual for standard shutdown procedures.

#### **Drill Pipe Position Selector Switch (STORE/OVER HOLE) – DPPSS (Option)**

This momentary switch is used only on angle hole drilling capable machines and controls operation of the hydraulically actuated pipe positioner. It is functional whenever the hydraulic pump motor is ON (ACM running).

#### **Dust Seal Slider Selector Switch (FRONT/REAR) - DSSSS (Option)**

This momentary switch is used only on angle hole drilling capable machines and controls operation of the hydraulically actuated dust seal. It is functional whenever the hydraulic pump motor is ON (ACM running). Moving the switch to the REAR position will move the dust seal mechanism toward the rear of the machine, while moving the switch to the FRONT position will move the dust seal mechanism toward the front of the machine.

#### **Propel Speed Range Selector Switch – POSRSS**

This two-position selector switch is located in the right pod of the operator's chair. In the NORMAL position, full speed capabilities can be achieved. In the LOW position, top speed is limited to about 30% of maximum. Full resolution is allowed in the joysticks to allow fine positioning of the machine.

#### **Horn Pushbutton – SHNPB1**

This pushbutton is located in the right pod of the operator's chair. It is wired in series with the other horn buttons located throughout the drill. Pressing any of these buttons sounds the electric signal horn and is available any time control power is available.

#### **Tool Wrench Selector Switch – TWSS**

This three-position switch (with spring return to neutral) is used for controlling the tool wrench when adding or removing pipes from the drill string. It is located in the right pod of the operator's chair. The states of this switch are as follows:

### **Automatic Leveling**

In addition to manual leveling switches, the 49HR incorporates logic for the automatic leveling of the drill. Pressing and holding the JACSS (Jack Automatic Control Selector Switch) in the EXTEND position will activate the automatic leveling logic as long as the button is held. The logic extends the leveling jacks until ground pressure is sensed in each jack before leveling the machine first in the side-to-side axis, and then in the front-to-rear axis. When the machine reaches "Fine Level", all jacks are extended simultaneously until the operator releases the Jack Automatic Control Selector Switch.

A customer selectable option is available through the Configuration Screen of the operator display to toggle One Touch Automatic Leveling. With this option enabled, the leveling process is carried out with one touch of the Jack Automatic Control Selector Switch rather than having to hold the switch down. The machine is automatically leveled and then all jacks are raised for 5 seconds after "Fine Level" has been achieved.

In both modes of automatic leveling, the machine must be within 7° of level before automatic functions can take place. If in a position where the drill has a tilt reading of greater than 7° the drill must be manually leveled to within this limit before pressing the Jack Automatic Control Selector Switch. An indicator on the Leveling Screen of the operator display will indicate when automatic leveling operations are allowed.

### **Retract Switches**

The drill is also equipped with Jack Retract Switches. This will tell the operator, via the operator display if each of the jacks has been fully retracted. These switches are also integrated with the control logic to prevent certain operations, such as propel, if the jacks are down.

## ***Mast***

### **Operation**

The raising and lowering of the mast is controlled with the same joystick used to control the right propel crawler track. This joystick is located in the right pod of the operator's chair. The mast can only be moved when the drill is in MAST/WINCH mode, as set by the DPMSS on the operator's chair.

In order for the mast to be raised or lowered with the joystick, the following conditions must be met.

*NOTE: Other conditions may also be required due to customer requests or system enhancements.*

- Control must be enabled (see above).
- The drill must be set in MAST mode.
- The head machinery must be lowered to the mast lower limit.

### **Mast Lock Pins**

These hydraulically actuated pins are used to lock the mast in a vertical position and are controlled through buttons located on the Mast Operations Screen of the operator display. To function, the hydraulic pump motor must be on (ACM running) and the DPMSS (Drill/Propel/Mast Selector Switch) must be in the MAST/WINCH position. At this point, the mast lock pins can operate in the LOCK direction. To function in the UNLOCK direction the rotary head assembly must be at the lower limit point. On machines that incorporate the angle hole drilling option, the additional restriction of having the A-frame pins in place is included. When controlling these pins through the operator display, pressing the Lock or Unlock Button will move both pins in the appropriate direction for 10 seconds, or until limit switches within the mast lock pin cylinders indicate that the pins are fully in the desired position.

## Hardware

### Overview

This subsection gives a brief overview of each of the original major components in the control system. It should be noted that some of these may differ on a specific drill due to customer request, design enhancements, or options.

### Standard "Nodes"

All PLC nodes on the 49HR use a standard DIN rail rack configuration. In this setup, there is no separate backplane device. Rather, all modules are simply mounted to a large DIN rail with a "U" type connector linking the backplane of each device together. Figure 11 shows this connector by itself. Figure 12 shows it attached to an I/O card with the right card removed from the rack.



**Figure 11 – "U" Connector**



**Figure 12 – "U" Connector with Right Card Removed**

To remove a card, first disconnect its wiring arm (in the case of I/O modules) or its communication and power connections. Then, loosen the screw on the bottom-rear of the module, which holds the card to the DIN rail. Note that the processor and certain other devices may have two such screws. Then, swing the module up to disconnect it from the "U" connector and lift the module off the DIN rail. To replace a module, simply reverse the process. Note that if you are adding a module to the end or replacing more than one module, it may be necessary to add or move one of the "U" connectors. They snap into slots on the back of each module, and are bidirectional so that installing them backwards is not possible.

**WARNING:** Never remove a card with power applied. Always remove power from the rack you are working on before disconnecting or adding a card. Failure to follow this warning may result in damage to the system or card.

- b. The JACSS (Jack Automatic Control Selector Switch) must be in its center off position.
- c. Put the DPMSS (Drill/Propel/Mast Selector Switch) in the DRILL position.
- d. Each jack manual selector switch controls a jack extend valve and a jack retract valve. When the selector switch is moved out of its center off position, the JLVS (Jack Loader Valve Solenoid) and a jack extend or retract valve are simultaneously energized. When the selector switch is returned to its center off position, the JLVS will turn off immediately. The jack extend or retract valve that was energized will turn off two seconds later. Verify that the correct jack valves are energized when the joysticks are operated as shown in the table below.

Switch	Position	PLC Input	PLC Output	Valve
JRLSS	Extend	I40.6	Q12.5	JRLLVS
JRLSS	Retract	I40.7	Q12.4	JRLRVS
JFLRSS	Extend	I41.0	Q12.1	JFLLVS
JFLRSS	Retract	I41.1	Q12.0	JFLRVS
JFLRSS	Extend	I41.0	Q12.3	JFRLVS
JFLRSS	Retract	I41.1	Q12.2	JFRRVS
JRRSS	Extend	I41.2	Q12.7	JRRLVS
JRRSS	Retract	I41.3	Q12.6	JRRRVS

8. The lubrication system hydraulic valves can be electrically tested using the procedure that follows.
  - a. Use the Maintenance Screen of the operator display to ensure that automatic lubrication is not enabled.
  - b. Display the Lubrication Screen on the operator display, and note the setting for the low pressure fault time.
  - c. Press the Manual Lube Pushbutton on the Maintenance Screen of the operator display. The LDVS (Lube Direction Valve Solenoid) connected to output Q2.5 should energize immediately. After a delay of approximately one second, the LEVS (Lube Enable Valve Solenoid) connected to output Q2.6 should energize. When the low pressure fault time is exceeded, the operator display should annunciate a low pressure fault alarm. The lube system fault indicator on the Status Screen of the operator display should come on, and all of the lube valves should turn off.

### ***Proportional Hydraulic Valves Electrical Setup***

This section covers the adjustment of the proportional hydraulic valve control cards EHPC1, and EHPC2. Further adjustments should not be required unless a card is replaced. The following procedure can be used to check card operation and to make card adjustments should this be necessary. Refer to the C-sheets and electrical schematics.

1. Open and lockout the ACD air compressor disconnect. This will prevent operation of the air compressor motor during any of the testing that follows.

## ***Drill Leveling System***

The leveling system was adjusted and tested at the factory. It will be functionally checked in this section to verify that field wiring and piping are correct. Do not make adjustments unless absolutely certain that they are necessary.

The level sensors are precision inclinometers mounted to detect tilt in the front-to-rear and side-to-side axes of the drill. The inclinometer analog signals are sent to the PLC which controls the jacks in the automatic leveling mode and scales the signals for the operator display.

1. Navigate to the Leveling/Propel Screen on the operator display. This provides complete information on the status of the leveling system. Indicators in the upper right corner of the display show when a jack is on the ground or fully retracted. Illuminated bars show the amount of front-to-rear and side-to-side tilt. In addition to the bar indication, the actual degrees of tilt are shown numerically at the bottom of the screen.
2. Put the DPMSS (Drill/Propel/Mast Selector Switch) in its DRILL position.
3. Make certain that all personnel are clear of the main air compressor. Put the ACUSS (Air Compressor Unload Selector Switch) in the CLOSE position, and start the compressor.
4. Make certain that all personnel and equipment are clear of the jacks.
5. Using the manual jack control switches, extend each jack until it touches the ground. The associated ground pressure indicator should illuminate on the operator display.
6. Using the manual jack control switches, fully retract each jack. The associated fully retracted indicator should illuminate on the operator display.
7. Manually level the drill with the jack control switches. Use the most accurate means available on site to determine when the drill is level. Surveying instruments or laser leveling devices can be used and provide good results. The level sensors will be checked using this manually obtained level condition as a reference.
8. The operator display side-to-side level and front-to-rear level numeric display values should be +/- 0.1 degrees or zero. If the values are greater than +/- 0.1 degrees, the level sensors can be adjusted using the procedure that follows.
  - a. The inclinometers are located on the back panel of the ZCCA cabinet of the operator's cab. Both inclinometers are mounted as a single unit that sends two independent signals to the PLC.
  - b. Open the cabinet and the cover of the inclinometer unit to check that there is incoming 24VDC to each of the inclinometer channels. 24VDC should be present on each of the channels opposite the signal wire to the PLC.
  - c. Use the Test Analog Inputs Screen, or the PLC – Remote Rack 5 Screen to see the incoming signals from the clinometers. The screen will indicate 12.0mA if viewing voltage/current signal level, or 13824 if viewing PLC integer value, when the inclinometer channel is correctly zeroed.
  - d. To adjust either inclinometer, turn the "Zero Pot" for the associated channel until the above values are achieved. Two potentiometers are provided for the adjustment of each channel. Channel 1 potentiometers (front-to-rear level indication) are located on the left



Fault	Message	Description / Effect	Recommended Action	Critical Fault
ANF048	Head Overspeed Fault	This fault occurs when the head exceeds the maximum speed (approximately 1.6 ft/s). Further use of the hoist functions are inhibited until the fault is reset.	<ol style="list-style-type: none"> <li>1. Verify that the head is actually moving at a faulted speed.</li> <li>2. If the speed is verified, refer to the hydraulic/mechanical documentation.</li> <li>3. If the speed is NOT verified and the fault repeats, test and/or replace the head encoder.</li> </ol>	
ANF049	Cable Reel Control Fault	This fault occurs when there is not feedback from the cable reel contactor.	<ol style="list-style-type: none"> <li>1. Check the operation of the cable reel.</li> <li>2. Verify the operation and/or wiring of the cable reel motor contactor.</li> <li>3. On the operator display, check for feedback from the cable reel.</li> </ol>	
ANF050	Radio Remote Tilt Shutdown	This fault occurs when the radio remote propel option is enabled and tilt becomes greater than 14 degree. This will disable radio remote control.	<ol style="list-style-type: none"> <li>1. Check the level monitors to assure the tilt angle is greater than 14 degrees.</li> <li>2. Propel the drill from the cab until tilt is less than 14 degrees.</li> </ol>	
ANF051	Radio Remote Fault	If the radio remote option is installed and the operating mode switch is in the remote propel position for more than 5 seconds, outputs to power the receiver are turned on. After a delay to allow the receiver to power up, the inputs from both the receiver and transmitter must be present or this fault is set and control is disabled.  Note: If the transmitter gets too far out of range, the transmitter on signal will be lost and control will be disabled.	<ol style="list-style-type: none"> <li>1. Assure the remote transmitter is within the signal range.</li> <li>2. Check the operations and/or wiring of the transmitter and receiver.</li> </ol>	
ANF052	24VDC Control Power Fault	This fault occurs if 24VDC control power supply is not available. The emergency shutdown sequence will occur.	<ol style="list-style-type: none"> <li>1. Check the connection and/or operation of the 24VDC control power supply.</li> </ol>	X
ANF053	24VDC Input Power Fault	This fault occurs if the input power (24V) is not available to the PLC Node 1. The emergency shutdown sequence will occur.	<ol style="list-style-type: none"> <li>1. Check the operation and/or connection of the 24VDC power supply to PLC Node 1.</li> </ol>	X

## APPENDIX B – PLC LED DIAGNOSTICS

### Processor LED's



**Figure 2 – Processor Status LED's**

This table shows the status of the LED's on the PLC processor, located in the Console in the Operator's Cab. The description column shows some suggested procedures that might be able to fix the problem.

LED						Description
SF	BF	DC5V	FRCE	RUN	STOP	
OFF	OFF	OFF	OFF	OFF	OFF	Processor power is missing. Check power connections and breakers that feed the processor in the operator cab.
OFF	OFF	ON	OFF	ON	OFF	Normal operation.
OFF	X	ON	X	OFF	ON	CPU is on STOP mode. Move keyswitch on processor to RUN mode.
ON	OFF	ON	X	X	X	Processor or remote I/O node has an error. Possible solutions are: <ol style="list-style-type: none"> <li>1. Check remote nodes (including the operator cab display and the head encoder) to make sure a non-critical node fault is not causing this situation.</li> <li>2. Move keyswitch on processor from STOP to RUN.</li> <li>3. Cycle keyswitch on processor from RUN to STOP and then back to RUN.</li> <li>4. Cycle power to the processor.</li> <li>5. Reset the memory using the procedure outlined in the PLC section of this manual.</li> <li>6. If the error was not found to be in the remote I/O or in the main rack's I/O modules, record what was happening when the error occurred.</li> </ol>
X	OFF	ON	X	OFF	Flash 0.5Hz	Processor requires a memory reset. Possible solutions are: <ol style="list-style-type: none"> <li>1. Cycle power to the processor.</li> <li>2. Reset the memory using the procedure outlined in the PLC section of this manual</li> </ol>
X	X	ON	X	OFF	Flash 2Hz	Processor is executing a memory reset. This is information only and does not constitute a problem.

Decimal	Hexadecimal	Description
32835	8043	RAM error
32836	8044	ADC/DAC error
32837	8045	Fuse blown
32838	8046	Hardware interrupt lost
32839	8047	Reserved
32848	8050	Configuration/parameter assignment error
32849	8051	Common mode error
32850	8052	Short circuit to phase
32851	8053	Short circuit to ground
32852	8054	Wire break
32853	8055	Reference channel error
32854	8056	Below measuring range
32855	8057	Above measuring range
32864	8060	Configuration/parameter assignment error
32865	8061	Common mode error
32866	8062	Short circuit to phase
32867	8063	Short circuit to ground
32868	8064	Wire break
32869	8065	Reserved
32870	8066	No load voltage
32880	8070	Configuration/parameter assignment error
32881	8071	Chassis ground fault
32882	8072	Short circuit to phase (sensor)
32883	8073	Short circuit to ground (sensor)
32884	8074	Wire break
32885	8075	No sensor power supply
32896	8080	Configuration/parameter assignment error
32897	8081	Chassis ground fault
32898	8082	Short circuit to phase
32899	8083	Short circuit to ground
32900	8084	Wire break
32901	8085	Fuse tripped
32902	8086	No load voltage
32903	8087	Excess temperature
32944	80B0	Counter module, signal A faulty
32945	80B1	Counter module, signal B faulty
32946	80B2	Counter module, signal N faulty
32947	80B3	Counter module, incorrect value passed between the channels
32948	80B4	Counter module, 5.2 V sensor supply faulty
32949	80B5	Counter module, 24 V sensor supply faulty
33024	8100	Module fault/OK
33025	8101	Internal error
33026	8102	External error
33027	8103	Channel error
33028	8104	No external auxiliary voltage
33029	8105	No front connector
33030	8106	No parameter assignment
33031	8107	Incorrect parameters in module
33072	8130	User submodule incorrect/not found
33073	8131	Communication problem

## APPENDIX D – PROFIBUS NODE DIAGNOSTICS

These tables list possible state and node information. These values are generally displayed on the PLC Diagnostics screen on the operator display (Main Menu – PLC/Profibus – PLC Status). The descriptions in this table were taken directly from the documentation supplied by the PLC manufacturer.

Note that not all codes are available on all devices

### Node State

0	Node is OK
1	Node has failed
2	Node is faulty
3	Node is not configured properly and cannot be diagnosed

### Error Type

1	Slot diagnosis (general specification of the faulty slot)
2	Module status (refinement of the slot diagnosis to include status of the module)
3	Channel diagnosis (location of the module, channel, and error type)
4	S7 diagnosis (Siemens PLC object)
5	Unit diagnosis
6	Slave diagnosis

### Module State

*This is only meaningful if the Error Type above is Type 2.*

0	Module OK
1	Module fault
2	Incorrect module
3	No module

### Channel Type

01	Input
02	Output
03	Input/Output
85	DP Interface Module
112	Digital Input
113	Analog Output
114	Digital Output
115	Analog Output
123	DP-Norm Channel (Input)
124	DP-Norm Channel (Output)
125	DP-Norm Channel (Other)

### Channel Error

Code	Description
1	Short circuit on encoder or output line
2	Undervoltage – Supply
3	Overvoltage – Supply
4	Overload
5	Overtemperature
6	Wire Break
7	Upper Limit Violated
8	Lower Limit Violated

number, the parameter index, or the parameter value depending upon the selection made by the select key. Pressing the program key when either the raise or lower key is pressed will increase the change rate of the parameter number, parameter index number, or parameter value by a factor of ten. The change rate can be increased to 100 by pressing the lower key after the raise key has been pressed or by pressing the raise key after the lower key has been pressed. The size of the change increment is dependent upon the parameter that has been selected. The raise and lower keys are also used to start and stop drive self-tuning test functions.

The five digit display shows drive status codes during normal operation and diagnostic codes when faults occur. The select key can be used to reset the drive after a fault occurs. Indexed parameter r047 can be used to provide additional troubleshooting information on certain types of faults. Indexed parameter r947 can be used to display the numbers of the last eight faults that have occurred. Refer to the Simoreg 6RA70 Instruction manual for a complete listing of all status and fault codes.

Setting key parameter P051 to 40 provides the greatest access to drive parameters and allows all parameter values to be changed. This parameter defaults to 0 for no change access whenever drive power is cycled off and on. This prevents accidental or unauthorized change of the drive parameters. Parameter P051 is also used to set up drive self-tuning tests. Refer to the Simoreg 6RA70 Instruction manual for more detailed information on the use of the function keys and display. This manual also provides detailed information on each parameter, which includes the default value, value range, value adjustment increment, and P051 access code.

The Simoreg drive analog and binary input/output is used for the PLC interface. The drive analog interface signals are as follows:

- a) The operator console speed reference pot is supplied with +/- 10 VDC from drive terminals CUD1/X174 - 1, 2, and 3. The reference pot wiper voltage is processed by the PLC, which feeds the resulting reference signal into drive analog input terminals CUD1/X174 - 4 and 5.
- b) Hoist/pulldown drive analog input terminals CUD1/X174 - 6 and 7 are used for the programmed drill control current limit signal from the PLC.
- c) Drive analog output terminal CUD1/X175 - 14 is the armature voltage signal to the PLC.
- d) Drive analog output terminal CUD1/X175 - 16 is the field current signal to the PLC.
- e) Drive analog output terminal CUD2/X164 - 18 is the armature current signal to the PLC.

- aa) If the drive under test is hoist/pulldown, put the HBS brake switch in its release position. The head brake should release, and the drive should hold the head. If the head begins to accelerate downward, press the drive control off pushbutton immediately. If the hoist/pulldown drive has control of the head, set the master switch pot at 20% travel for hoist operation if the position of the drill head will allow hoist direction travel.
  - bb) If the drive under test is rotary, set the master switch pot at 20% travel for clockwise bit rotation.
  - b) If the motion runs in the wrong direction, press drive control off and open the drive disconnect. Reverse the motor field connections to the panel. Repeat the rotation check and verify that the direction of rotation is now correct.
  - c) Return the master switch pot to neutral and press the drive control off pushbutton.
  - d) If the drive under test was hoist/pulldown, put the HBS brake switch in its set position.
- 31) If the hoist/pulldown drive is being tested, the EHBC electric head brake control should be checked as follows.
- a) Connect a DC voltmeter across wires CP169 and CP170 to the electric head brake operating coil. These wires are available on terminals 8 and 9 of the EHBC control located on the machinery house inside front wall. Wire CP169 will be positive, and the maximum expected voltage will be less than 300 volts DC.
  - b) If the hoist/pulldown drive successfully held the head in step 32aa above, ask the operator to press the drive control on pushbutton and put the HBS brake release switch in the release position.
  - c) The brake coil voltage measured from CP169 to CP170 should initially be about 239 VDC, and the red lamp on the EHBC cabinet door should be on. After approximately five seconds the red lamp should go out, and the coil voltage should decrease to about 72 VDC.
  - d) Put the HBS brake switch in the set position, and press the drive control off pushbutton.
- 32) The drive no load tests should be performed as follows:
- a) Install a DC voltmeter across drive armature output terminals A1 and A2. This is a +/- 500 VDC circuit (480 volts nominal).
  - b) Ask the operator to press the drive control on pushbutton. If the drive under test is hoist/pulldown, put the HBS brake switch in its release position and set the master







Figure 4 – Icon Help Screen Sample

## Security

Since some of the screens contain setup parameters that may impact performance of the drill, it is not always desirable for all users to have access to all screens. Therefore, the parameter screens that are not required for day to day operation are protected by a three to five digit security code. The Administrator password has access to all screens. User 1 has access to all screens except the Setup screen. Each of the other users has access to one screen as shown in the Password Setup section.

When a user attempts to access a secure screen, the Password Entry window will pop up. Figure 5 shows a typical Password Entry window.

**Leveling Screen Button**

This button is located on the left side of the screen, the second of the four buttons in the submenu. It is used to change the screen to one that displays more detailed leveling and jack status information.

**Maintenance Screen Button**

This button is located on the left side of the screen, the third of the four buttons in the submenu. It is used to change the screen to one that displays maintenance related information such as lubrication system settings, air and oil temperatures, and cooler status.

**Mast Operations Screen Button**

This button is located on the left side of the screen, the fourth of the four buttons in the submenu. It is used to change the screen to one that displays mast pin locations, mast operating conditions, and winch settings.

### Lubrication Setup Button

Below the lubrication timer table is the Lubrication Setup Button. Pressing this button toggles the lubrication setup mode which performs two functions. First, it performs the same function as holding the manual lube button down continuously. Second, this mode disables the lube system low pressure and vent pressure faults. When active, the background of this button will turn green.

### Hour Meters and Fault Counters Screen

The Operating Hours & Fault Counters screen shows the length of time certain machine functions have been operating, as well as some cumulative hole and fault data (see Figure 16). This data can provide the maintenance and service personnel with a cumulative fault count of areas that may be experiencing problems. The accumulation interval can be controlled by manually resetting the counters at pre-established intervals and keeping records of machine performance during those intervals.




Figure 16 - Hour Meters & Fault Counters Screen

### Total Operating Hours Section

The top middle section of the screen shows the total number of hours the drill has been powered on, the total number of hours spent operating the hoist and rotary motors, total hours propelling and the total number of hours the PLC has been turned on. The total number of holes drilled and total distance drilled is also displayed. It is not possible for the user to reset these values, however, they may be lost if the PLC program is reloaded.

*NOTE: Only one button for each signal can be active at any given time. In addition, leaving the Hydraulic Card Setup Screen will disable all active signals being forced by these buttons.*

### Test Screens (Test – Analog I/O)

The Test Screens are accessible from the Test – Analog I/O Button on the Main Menu. These screens display all of the analog input and output values as they are read by the PLC. Two screens are available to display analog inputs (see Figure 23) while another screen displays analog outputs (see Figure 24). These screens are useful for testing the drills control system to determine where problems may exist.




Figure 23 - Test Screen Analog Inputs 1 (Units View)

to be changed. In the raw mode, signals normally have a range of  $\pm 32767$  including over-range values. This range is reduced to  $\pm 27648$  for the full range.

### **View Voltage/Current – View Integer Button**

This button is located on the left side of the screen at the bottom of the sub-menu, and toggles the display between showing the voltage or current measured at the card's terminals and the integer signal in the PLC. Changing the view on one screen will change it on all screens that use this feature.

### **Timers/Counters Screen**

This screen is accessible from the Main Menu (see Figure 30). It allows the user to view the preset and time values of the timers and the current count of the counters in the PLC. In order to use this screen, it is necessary to know the timer or counter address, which can be found in the PLC software documentation.




Figure 30 - Timers/Counters Screen

### **Entering Addresses**

Once the address is known, perform the following steps to display the values.


Touch the Timer/Counter box in the first column to select either "T" for Timer or "C" for Counter. These values toggle back and forth.

Enter the address number in the second box. This will completely specify the desired timer or counter.

## Appendix A – ANF Messages

The following table is a representative list of the fault and alarm conditions along with their ANF numbers. These faults will appear on the Active Alarms Screen when the associated condition is present and will stay active until the condition is corrected and the Fault Reset Button is pressed by the operator (see Alarms, Faults, and Messages section). Note that the actual list may differ due to options or version.

Alarm	Message
ANF000	Emergency Stop Active
ANF001	Emergency Stop Circuit Fault
ANF002	Operator Control Screen Communication Fault
ANF003	Spare
ANF004	Spare
ANF005	Spare
ANF006	Hydraulic Oil Overtemperature
ANF007	Hydraulic Oil Filter Clogged
ANF008	Hydraulic Oil Cooler Control Fault
ANF009	Hydraulic Tank Oil Level Sensor Fault
ANF010	Phase Sequence Line Fault
ANF011	Auxiliary Ground Fault
ANF012	Rotary Motor Blower Control Fault
ANF013	Rotary Input Power Fault
ANF014	Rotary Stall Fault
ANF015	Rotary Drive Incomplete Sequence
ANF016	Rotary Drive Internal Fault
ANF017	Rotary Field Loss
ANF018	Rotary Field Overcurrent
ANF019	Hoist/Pulldown Drive Internal Fault
ANF020	Hoist/Pulldown Field Loss
ANF021	Hoist/Pulldown Field Overcurrent
ANF022	Hoist/Pulldown Motor Blower Control Fault
ANF023	Hoist/Pulldown Input Power Fault
ANF024	Hoist/Pulldown Stall Fault
ANF025	Hoist/Pulldown Drive Incomplete Sequence
ANF026	House Fan Fault
ANF027	Water Injection Drive Fault
ANF028	Water Injection Low Water Level
ANF029	Drill Mode Low Lube Pressure
ANF030	Propel Mode Low Lube Pressure
ANF031	Lubrication System Vent Fault
ANF032	Drill Bit Lubrication Level Low
ANF033	Jacks Not Retracted in Propel Mode
ANF034	Air Compressor Oil Pump Start Failure
ANF035	Air Compressor Failure
ANF036	Air Compressor Oil Cooling Failure
ANF037	Air Compressor High Air Temperature Fault
ANF038	Air Compressor Oil Pressure Switch Fault
ANF039	Air Compressor High Oil Temperature Fault
ANF040	Air Compressor Oil Cooler Fan Control Fault
ANF041	Air Compressor Control Fault



## **Bulletin 161 AC Drive (Series B)**

0.2-3.7 kW (0.3-5 HP)

Firmware 2.001

User Manual

**Rockwell  
Automation**

## Installation & Wiring

### Power terminal block wiring specifications

Model	Screw Size	Max/Min Wire Size mm <sup>2</sup> (AWG)	Max/Min Torque Nm (lbin)
AA01-AA02	M3.5	2.1 – .75 (14-18)	0.9-0.8 (8.0-7.0)
AA03	M3.5	2.1 – 1.3 (14-16)	0.9-0.8 (8.0-7.0)
AA04, DA01	M4	5.3 – 1.3 (10-16)	1.3-1.2 (11.5-10.6)
AA05-AA10, DA02-DA03	M4	5.3 – 2.1 (10-14)	1.3-1.2 (11.5-10.6)
AA15	M4	5.3 – 3.3 (10-12)	1.3-1.2 (11.5-10.6)

### Power Terminal Connection

#### IMPORTANT:

- Bulletin 161 Drives feature an electronic overload protection to monitor the motor current. In the case of multi-motor operation, thermal contacts or PTC resistors must be used for each motor.
- In the case of motor lead lengths greater than 50 meters (165 feet), motor reactors should be used.

### Branch Circuit Protection Devices

The following table shows the minimum recommended values for the branch circuit protection devices:

Model	Fuse Rating (Class J)		Bulletin 140	
	1 Ph	3 Ph	1 Ph	3 Ph
AA01	10	10	140M-D8N-C10	140M-D8N-B40
AA02-AA03	10	10	140M-D8N-C10	140M-D8N-B63
AA04-AA05	15	15	140M-D8N-C16	140M-D8N-C10
AA07	20	15	140M-D8N-C16	140M-D8N-C16
AA10	30	20	140M-D8N-C25	140M-D8N-C16
AA15	N/A	30	N/A	140M-D8N-C25
DA01	10	N/A	140M-D8N-C10	N/A
DA02	15	N/A	140M-D8N-C10	N/A
DA04	20	N/A	140M-D8N-C16	N/A

### Input Power Conditioning

The drive is suitable for connection to input power within the rated voltage of the drive (see specifications). The power factor of the input power supply must not exceed .99. Compensation systems must ensure that over compensation does not occur at any time.

If the drive must be installed in any of the following conditions, an Input Line Reactor must be used:

Input Power Condition	Corrective Action
Line has intermittent noise spikes in excess of 2000V	Install 3% impedance Input Line Reactor
If frequent voltage dips occur	Install 3% impedance Input Line Reactor
The drive is operated on a generator	Install 3% impedance Input Line Reactor
Line has power factor correction capacitors	Install 3% impedance Input Line Reactor
Several drives are linked via a short common power supply bus bar.	Install 3% impedance Input Line Reactor

### Grounding




#### ATTENTION

- The Bulletin 161 has a high leakage current and must be permanently (fixed) hard wired to ground. Failure to observe this precaution could result in severe bodily injury or loss of life.

Ground the drive. Be sure to separate the drive's grounding pole from those of other electrical machinery. If multiple drives are used, make certain grounding connections do not create a loop as shown in Fig. 2.5.

Figure 2.5 Suggested 161 Grounding





## Parameters &amp; Programming


## Parameter Descriptions

## D Group - Display and Diagnostic Parameters (Read Only)

This group of parameters consists of commonly viewed drive operation conditions such as output frequency. All parameters in this group are Read Only.

Parameter Number	Parameter Name / Description	Min./Max. Range	Units
<b>Display and Diagnostic Functions</b>			
d01	<b>[Output Frequency]</b> Displays the output frequency to the motor.	0.0/360.0	0.1 Hz
d02	<b>[Output Current]</b> Displays the output current to the motor.	0.00/999.9	0.01A
d03	<b>[Direction]</b> Displays the present direction of rotation. F=Forward r=Reverse o=Stop	Alpha Numeric Value	Alpha Numeric Value
d04	<b>[PID Process Display]</b> Displays the scaled PID Process variable (feedback), this is only available when the PID control is active. The scale factor is set using PC15 - [Digital Input 5 Logic].	0/100.0	0.01%
d05	<b>[Digital Input Status]</b> Displays the status of the 5 digital inputs regardless of how each input is programmed in PC11 - [Digital Input 1 Logic] through PC15 - [Digital Input 5 Logic].  5 4 3 2 1 	N/A	N/A
d06	<b>[Output Status]</b> Displays the status of the digital outputs and the fault indication relays.  AL12 11 	N/A	N/A
d07	<b>[Process Display]</b> Displays Pd01 - [Output Frequency ] scaled by the variable set in Pb86 - [Process Display Scale Factor]. <i>Note: If there are more than 4 digits, the LSB will be dropped.</i>	0.00/9999	0.01
d08	<b>[Last Fault]</b> Displays the last fault. The output frequency, motor current, and DC-bus voltage at the time of the last fault can be viewed by pressing the SElect key. If there has not been a fault or the register has been cleared, then --- will be displayed.	N/A	---
d09	<b>[Fault Register]</b> Displays the 2 <sup>nd</sup> and 3 <sup>rd</sup> fault, if there are no faults stored in this register, then --- will be displayed. To view the 3 <sup>rd</sup> fault, press the SElect key.	N/A	---
d16	<b>[Elapsed Run Time]</b> Displays the elapsed running time of the drive. The elapsed running time is the displayed value x 10.	0/9999	10 hours

## Parameters &amp; Programming

Parameter Number	Parameter Name/Description	Min/Max Range	Units	Factor Default	
Outputs 11, 12, FM, AL0-AL1				U <sup>1</sup>	K <sup>1</sup>
C23	<b>[Output FM Select]</b> Sets the operation of the output FM. Settings: 00={A-F} (Analog Output Frequency) 01={A} (Motor Current) 02={D-F} (Digital Output Frequency) Refer to control inputs table in chapter 2 for setting descriptions..	00/02	Numeric Value	00	00
C31	<b>[Digital Output 11-12 Logic]</b> Sets the digital outputs to be NO or NC contacts. Settings: 00=NO contact (Active high) 01=NC contact (Active open)	00/01	Numeric Value	00	00
C32				00	00
C33	<b>[Fault Relay AL1 Logic]</b> Sets the fault relay to be either NO or NC contacts. Settings: 00 = NO contact (active high) 01 = NC contact (active open) Refer to control inputs table in Chapter 2 for setting descriptions.	00/01	Numeric Value	01	01
C41	<b>[Overload Alarm Threshold]</b> Sets the allowable overload level before digital outputs 11-12 change state when set to 03 {OL}.	0/200% of drive rating	0.01 A	100% of drive rating	100% of drive rating
C42	<b>[Above Frequency Accel Threshold]</b> Sets the frequency at which digital outputs 11-12 change state when set to 02 {FA2} if the drive is accelerating.	0.0/360.0	0.1 Hz	0.0	0.0
C43	<b>[Above Frequency Decel Threshold]</b> Sets the frequency at which digital outputs 11-12 change state when set to 02 {FA2} if the drive is decelerating.	0.0/360.0	0.1 Hz	0.0	0.0
C44	<b>[PID Deviation Threshold]</b> Sets the allowable PID Loop error before digital outputs 11-12 change state when set to 04 {OD}.	0.0/100%	+/- 0.1%	+/-3.0	+/-3.0
Communications				U <sup>1</sup>	K <sup>1</sup>
C70	<b>[Communication Command Select]</b> Selects the source of the communication command. Settings: 02 = Remote Operator 03 = RS485	02/03	Numeric Value	02	02
C71	<b>[Baud Rate]</b> Selects the Baud Rate for RS485 communication. Settings: 04 = 4800 bps 05 = 9600 bps 06 = 19200 bps	04/06	Numeric Value	04	04
C72	<b>[Drive Address]</b> Sets the drive node address on the RS485 network.	01/32	N/A	01	01
C79	<b>[Communication Error Select]</b> Selects the drives operation when a communication error (E60) occurs. Settings: 00 = Fault 01 = No Fault and continue operation	00/01	Numeric Value	00	00
C91	<b>Debug Mode</b> Used by Rockwell Automation field service personnel.  <b>ATTENTION</b> If PC91-[Debug Mode] is set to 01 parameters PC92-PC95 are enabled. Changing parameters PC92-PC95 can lead to personal injury, death, or equipment damage. DO NOT CHANGE PARAMETERS PC91-PC95.				

<sup>1</sup> U = 60 Hz default settings, K = 50 Hz default settings. Settable using Pb85 – [Factory Default Select]

---

**Reach us now at [www.rockwellautomation.com](http://www.rockwellautomation.com)**

Wherever you need us, Rockwell Automation brings together leading brands in industrial automation including Allen-Bradley controls, Reliance Electric power transmission products, Dodge mechanical power transmission components, and Rockwell Software. Rockwell Automation's unique, flexible approach to helping customers achieve a competitive advantage is supported by thousands of authorized partners, distributors and system integrators around the world.

**Americas Headquarters**, 1201 South Second Street, Milwaukee, WI 53204, USA, Tel: (1) 414 382-2000, Fax: (1) 414 382-4444

**European Headquarters SA/NV**, avenue Hermann Debroux, 46, 1180 Brussels, Belgium, Tel: (32) 2 683 06 00, Fax: (32) 2 683 06 40

**Asia Pacific Headquarters**, 27/F Citicorp Centre, 18 Whitfield Road, Causeway Bay, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846





BI012589  
JUNE 2013  
VOLUME II of II

# System Operation, Testing & Adjusting Manual

---

**MD6640 Blast Hole Drill**

---

Serial Number DR612159

MD6640



CBD612159  
Cliffs - Bloom Lake  
OB1

Network: 11

T1  
Power Up  
Timer  
"PUT"

(RET)

Down References



PUT            OB1:3/SD

Network: 12      Air Compressor Control (Standard Leroi)

The networks called in this logic control the standard 3000CFM Leroi compressor on the 49HR.

DB190.DBX3  
.2  
SULLAIR  
COMPRESSOR  
OPTION  
INSTALLED

"OptionsIn  
stalled".  
SCOI



EN

ENO

EN

ENO

THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.  
© 2013 Bucyrus International, Inc. ALL RIGHTS RESERVED

**MD6640**




CBD612159  
Cliffs - Bloom Lake  
OB1

Network: 41 Retractable Boarding Stairs Control (Optional)

DB190.DBX1  
.0  
RETRACTABL  
E  
BOARDING  
STAIRS  
OPTION  
INSTALLED  
(STANDARD)

"OptionsIn  
stalled".  
RBSOI





Network: 42 Digital Forcing Control

MW2  
Operator  
Screen  
Display

"OD\_DSN" — IN1

1019 — IN2



**Down References**

OD\_DSN

THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.  
© 2013 Bucyrus International, Inc. ALL RIGHTS RESERVED

## MD6640



CBD612159  
Cliffs - Bloom Lake  
FC3

```

JCN  F264 //has built up to check for out of range
      fault.
L     #RETVAL #RETVAL
L     0
<>I
FR    "ORFT264" T161
      -- OUT OR RANGE F
      AULT TIMER PIW264
      DB911.DBW320
      -- ORFT264 (1 s)
L     "Timers".t161 T161
      -- OUT OR RANGE F
      AULT TIMER PIW264
      T161
SD    "ORFT264" T161
      -- OUT OR RANGE F
      AULT TIMER PIW264
      T161
O     "ORFT264" T161
      -- OUT OR RANGE F
      AULT TIMER PIW264
      DB1.DBX10.4
      -- PIW264 INPUT O
      UT OF RANGE (HOIST
      /PD ARMATURE CURRE
      NT)
S     "FaultedConditions".ANF084

F264: CALL "Filter" , "FilterDB_HCPAC" FB501 / DB264
      raw_R :=#PIW264_R #PIW264_R
      time_K :=5
      feedback_Real :="FilterDB_HCPAC". DB264.DBD10
      filtered_out_Real
      filtered_out_Real:="FilterDB_HCPAC". DB264.DBD10
      filtered_out_Real

L     "FilterDB_HCPAC".filtered_out_R DB264.DBD10
eal
T     "AnalogInputsScaledData".HCPAC_ DB607.DBD16
SCALED -- (PIW264) HOIST
      CONTROL ARMATURE
      CURRENT (-750 TO +
      750 ADC, + = HOIST
      )
T     "DisplayWords_PLC2HMI".HAC DB1002.DBD288
      -- Hoist Armature
      Current

```

**Down References**

ALWAYS\_ON OB1:1/S  
HPMFTR FC43:8/SD  
ORFT264 FC3:5/FR

**Up References**

ORFT264 FC3:5/O

THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.

## MD6640



CBDR612159  
Cliffs - Bloom Lake  
FC3

```

1      L      "FilterDB_VVM".filtered_out_Rea      DB280.DBD10
      T      "AnalogInputsScaledData".VVM_SC      DB607.DBD48
ALED      -- (PIW280) VERTI
          CAL VIBRATION METE
          R (0 - 10 IPS)
      O      "DisplayBits_HMI2PLC".ULF      DB1001.DBX7.1
          -- Units Length F
          eet
      JCN    D280
      T      "DisplayWords_PLC2HMI".VV      DB1002.DBD128
          -- Vertical Vibra
          tion
      JU     E280
D280: L      "FilterDB_VVM".filtered_out_Rea      DB280.DBD10
1      L      2.540000e+000
      *R
      T      "DisplayWords_PLC2HMI".VV      DB1002.DBD128
          -- Vertical Vibra
          tion
E280: NOP  0

```

**Down References**

ALWAYS\_OFF OB1:2/R  
ORFT280 FC3:13/FR

**Up References**

ORFT280 FC3:13/O

Network: 14 PIW282 HVM\_SCALED

HORIZONTAL VIBRATION METER

INPUT: 4 - 20 mA

OUTPUT: 0 - 10 INCHES/SEC = 0 - 25.4 CM/SEC (IN X 2.54 = CM)

```

CALL  "SCALE"      FC191
      IN           := "HVM"      -- Scaling Values
      PIW282      -- HORIZONTAL VIB
      RATION METER
      HI_LIM :=1.000000e+001
      LO_LIM :=0.000000e+000
      BIPOLAR:="ALWAYS_OFF"
      M0.0      -- Always off
      RET_VAL:=#RETVAL
      OUT      :=#PIW282_R      #PIW282_R

```

THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.

## MD6640



CBD612159  
Cliffs - Bloom Lake  
FC3

**Down References**

ALWAYS\_ON OB1:1/S  
ORFT298 FC3:22/FR

**Up References**

ORFT298 FC3:22/O

Network: 23 PIW300 PORMS\_SCALED

PROPEL RIGHT MASTER SWITCH

INPUT: -10 TO +10 VDC  
OUTPUT: -100 TO +100%

```

CALL "SCALE"                                FC191          -- Sc
                                           aling Values
IN      := "PORMS"                          PIW300         -- PR
                                           OPEL RIGHT MASTER SWITCH

HI_LIM := 1.000000e+002
LO_LIM := -1.000000e+002
BIPOLAR := "ALWAYS_ON"                    M0.1          -- Al
                                           ways On
RET_VAL := #RETVAL                          #RETVAL
OUT      := #PIW300_R                       #PIW300_R

L      #RETVAL                              #RETVAL
L      0
<>I
FR      "ORFT300"                          T179          -- OU
                                           T OF RANGE FAULT TIMER P
                                           IW300
L      "Timers".t179                        DB911.DBW356  -- OR
                                           FT300 (1 s)
SD      "ORFT300"                          T179          -- OU
                                           T OF RANGE FAULT TIMER P
                                           IW300
O      "ORFT300"                          T179          -- OU
                                           T OF RANGE FAULT TIMER P
                                           IW300
S      "FaultedConditions".ANF102          DB1.DBX12.6   -- PI
                                           W300 INPUT OUT OF RANGE
                                           (PROPEL RIGHT MASTER SWI
                                           TCH)

CALL "Filter" , "FilterDB_PORMS"          FB501 / DB300
raw_R      := #PIW300_R                    #PIW300_R
time_K     := 2
feedback_Real := "FilterDB_PORMS".filtered_out_Real DB300.DBD10
filtered_out_Real := "FilterDB_PORMS".filtered_out_Real DB300.DBD10

L      "FilterDB_PORMS".filtered_out_Real  DB300.DBD10

```


THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.

**MD6640**



CBD612159  
Cliffs - Bloom Lake  
FC6

Network: 4 UNSCALE REAL VALUE FOR HOIST/PD CURRENT LIMIT (PQW262)



**Down References**  
ALWAYS\_OFF OB1:2/R


THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.  
© 2013 Bucyrus International, Inc. ALL RIGHTS RESERVED



CBD612159  
Cliffs - Bloom Lake  
FC6

**MD6640**

Network: 16 UNSCALE REAL VALUE FOR PQW286 (SPARE)



**Down References**  
ALWAYS\_ON OB1:1/S

Network: 17



**Down References**  
ALWAYS\_ON OB1:1/S

THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.  
© 2013 Bucyrus International, Inc. ALL RIGHTS RESERVED

**MD6640**



CBD612159  
Cliffs - Bloom Lake  
FC9

**Down References**

ESCFTR FC9:2/SD

**Up References**

ESCFTR FC9:2/A

THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.

**MD6640**



CBD612159  
Cliffs - Bloom Lake  
FC9

Network: 13 CONTROL ENABLE

WHEN THE SYSTEM IS READY AND THE HMI PB IS PRESSED CONTROL IS ENABLED. THIS WILL LATCH IN THE CONTROL ENABLED BIT AND TURN THE HMI PB A SOLID GREEN.

CONTROL IS ALSO ENABLED WHEN ANY OF THE DRIVE TEST BUTTONS ARE PRESSED SINCE THE OPERATOR/TESTOR CANNOT LEAVE THE DRIVE TEST SCREEN TO PRESS THE CONTROL ENABLE BUTTON.

	DB1001.DBX	
DB1000.DBX	0.2	
4.7	CONTROL	
CONTROL	ENABLE	
ENABLE	PUSH	DB100.DBX2
READY	BUTTON	.5
"DisplayBi	"DisplayBi	Control
ts_	ts_	Enabled
PLC2HMI".	HMI2PLC".	"System".
CER	COS	ctrlEN

<S>

DB1001.DBX	DB1000.DBX
9.1	5.0
Drive	CONTROL
Setup Test	ENABLE ON
"DisplayBi	"DisplayBi
ts_	ts_
HMI2PLC".	PLC2HMI".
DST	CEO

<S>

DB1001.DBX
9.2
Drive
Stall Test
"DisplayBi
ts_
HMI2PLC".
DST1

DB1001.DBX
9.0
Drive
Bypass
Test
"DisplayBi
ts_
HMI2PLC".
DBT

THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.

MD6640



CBD612159  
Cliffs - Bloom Lake  
FC10

Network: 14 ENCODER BIT BINARY BIT 12


NETWORKS 14-27 TAKE THE GRAY SCALE INPUT VALUE OF THE HEAD ENCODER AND CONVERTS IT TO A BINARY WORD VALUE.

DB25.DBX3.  
4  
ENCODER  
GRAY BIT  
12

"EncoderGr  
ayDecimalD  
ata".GB12

DB25.DBX1.  
4  
ENCODER  
BINARY  
BIT 12

"EncoderGr  
ayDecimalD  
ata".BB12



Network: 15 ENCODER BIT BINARY BIT 11

DB25.DBX3.  
3  
ENCODER  
GRAY BIT  
11


"EncoderGr  
ayDecimalD  
ata".GB11

DB25.DBX1.  
4  
ENCODER  
BINARY  
BIT 12

"EncoderGr  
ayDecimalD  
ata".BB12

DB25.DBX1.  
3  
ENCODER  
BINARY  
BIT 11

"EncoderGr  
ayDecimalD  
ata".BB11



DB25.DBX3.  
3  
ENCODER  
GRAY BIT  
11

"EncoderGr  
ayDecimalD  
ata".GB11

DB25.DBX1.  
4  
ENCODER  
BINARY  
BIT 12

"EncoderGr  
ayDecimalD  
ata".BB12

THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.

MD6640



CBD612159  
Cliffs - Bloom Lake  
FC10


Network: 31

IF THE ERROR BIT IS SET, THE "LAST SCAN DATA 1" VALUE WILL NOT BE UPDATED (THEREBY KEEPING THE BIT ON AND KEEPING THE BUFFERED VALUE FROM CHANGING) UNTIL THE ENCODER HAS MAINTAINED A COUNT WITHIN +/- 3 FOR 8 SCAN CYCLES

DB7.DBX10.  
0  
HEAD  
ENCODER  
ERROR  
"HeadEncoderDataConvData".HEE

DB7.DBW12  
HEAD  
ENCODER  
LAST SCAN  
DATA (2)  
"HeadEncoderDataConvData".  
HLSD2

DB25.DBW8  
HEAD  
ENCODER  
BINARY  
VALUE  
"EncoderGrayDecimalData".HEBV



DB7.DBW16  
HEAD  
ENCODER  
DATA  
CHANGE (2)  
"HeadEncoderDataConvData".HDC2

DB7.DBW16  
HEAD  
ENCODER  
DATA  
CHANGE (2)  
"HeadEncoderDataConvData".HDC2


-3



CMP ==I

DB7.DBW16  
HEAD  
ENCODER  
DATA  
CHANGE (2)  
"HeadEncoderDataConvData".HDC2

3



MOVE  
EN ENO

DB7.DBW8  
HEAD  
ENCODER  
SCAN COUNT  
"HeadEncoderDataConvData".HESC

1

31.A

THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.

**MD6640**




CBD612159  
Cliffs - Bloom Lake  
FC10

Network: 39 Head Overspeed Fault

If the encoder changes 7 counts within the interval timed above (75ms) then a head overspeed fault is set. This equates to a head speed of approximately 1.6ft/s.

To avoid overspeed faults when the head encoder binary value jumps from 0 to 8192 or 8192 to 0 (13 bit encoder) in a rollover situation, the change in encoder value must be less than 8000 counts in order to throw an overspeed fault.

DB7.DBX38.  
0  
HEAD  
OVERSPEED  
INTERVAL  
CLOCK DONE  
"HeadEncoderDataConv  
Data".  
HOIC\_DN



DB7.DBW4  
HEAD  
ENCODER  
BUFFERED  
BINARY  
VALUE  
"HeadEncoderDataConv  
Data".  
HEBBV — IN1

DB7.DBW48  
HEAD  
ENCODER  
BUFFERED  
BINARY  
VALUE AT  
CLOCK  
RESET  
"HeadEncoderDataConv  
Data".  
HEBBVCR — IN2

DB7.DBW50  
HEAD  
ENCODER  
BUFFERED  
BINARY  
VALUE  
CHANGE  
PER  
INTERVAL  
"HeadEncoderDataConv  
Data".  
HEBBVCI — OUT

39.A

T1  
Power Up

THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.  
© 2013 Bucyrus International, Inc. ALL RIGHTS RESERVED

**MD6640**



CBD612159  
Cliffs - Bloom Lake  
FC11

THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

**MD6640**



CBD612159  
Cliffs - Bloom Lake  
FC11

10.B

THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.

**MD6640**



CBD612159  
Cliffs - Bloom Lake  
FC11

13.B

13.D

THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.

MD6640



CBDR612159  
Cliffs - Bloom Lake  
FC11

DB9.DBD42  
PIPE RACK  
LIMIT 4  
COUNT  
"HeadLimit  
sData".  
PRL4C

IN2

PIPE RACK  
SELECTOR  
SWITCH -  
4TH RACK  
"PRSS\_4"


DB1001.DBX  
11.2  
Shop Test  
3 -  
Simulate  
Head  
Encoder  
Position  
Above  
Pipe Rack  
Limit  
"DisplayBi  
ts\_  
HMI2PLC".  
ST3

THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE  
EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION,  
DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.

**MD6640**



CBD612159  
Cliffs - Bloom Lake  
FC11



30.A

M0.4  
SPARE  
"DUMMY"

THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.

© 2013 Bucyrus International, Inc. ALL RIGHTS RESERVED



MD6640




CBD612159  
Cliffs - Bloom Lake  
FC11

Network: 39 BIT ON BOTTON OF THE HOLE

DB81.DBX62  
.1  
BIT ON  
BOTTON OF  
THE HOLE  
"PDCOn/  
OffMotionS  
peedData".  
ANI083


DB8.DBD14  
BIT  
POSITION  
COUNT 2  
"HoleDepth  
Data".BPC2-IN1  
  
DB8.DBD18  
HOLE  
DEPTH  
COUNT  
VALUE  
"HoleDepth  
Data".HDC-IN2



DB1000.DBX  
10.1  
Bit At  
Bottom Of  
Hole  
"DisplayBi  
ts\_  
PLC2HMI".  
BABOH

Network: 40

M0.1  
Always On  
"ALWAYS\_  
ON"




**Down References**  
ALWAYS\_ON OB1:1/S

THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.  
© 2013 Bucyrus International, Inc. ALL RIGHTS RESERVED



CBD612159  
Cliffs - Bloom Lake  
FC12

Network: 12



THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.  
© 2013 Bucyrus International, Inc. ALL RIGHTS RESERVED

## MD6640



CBDR612159  
Cliffs - Bloom Lake  
FC30

## FC30 - <offline>

"AirCompressor(Sullair)"

**Name:** **Family:**  
**Author:** **Version:** 0.1  
**Block version:** 2  
**Time stamp Code:** 03/02/2012 01:42:52 PM  
**Interface:** 05/27/2009 10:15:51 AM  
**Lengths (block/logic/data):** 01482 01334 00002

Name	Data Type	Address	Comment
IN		0.0	
OUT		0.0	
IN_OUT		0.0	
TEMP		0.0	
RETURN		0.0	
RET_VAL		0.0	

### Block: FC30 AIR COMPRESSOR OPERATION

THIS MODULE CONTROLS THE OPERATION OF THE MAIN AC MOTOR WHICH POWERS THE AIR COMPRESSOR AND THE HYDRAULIC PUMPS. THE MOTOR HAS BOTH HARDWIRED (TO THE PLC) START AND STOP PBs (LOCATED ON THE DOOR OF ITS MOTOR STARTER PANEL) AND A SOFT BUTTON ON THE HMI THAT WILL TOGGLE IT ON AND OFF WHEN PRESSED.

THE COMPRESSOR HAS AN EXTERNAL OIL PUMP WHICH NEEDS TO BE STARTED BEFORE THE MAIN MOTOR. WHEN A START SIGNAL IS RECEIVED, AND ALL PERMISSIVES ARE OK, THE OIL PUMP STARTER IS ENERGIZED. WHEN THE AUX CONTACT FROM ITS STARTER IS PULLED IN A SHORT DELAY IS PROVIDED TO ALLOW PRESSURE TO BUILD THEN THE MAIN MOTOR IS STARTED.

THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.

**MD6640**



CBD612159  
Cliffs - Bloom Lake  
FC30

Network: 8 COMPRESSOR START DRIVE SHUTDOWN

IF EITHER OF THE DC DRIVES ARE RUNNING, THIS BIT WILL SHUT THEM DOWN BEFORE STARTING THE COMPRESSOR. THIS IS DONE TO PREVENT POWER ISSUES AT THE DRIVES RELATED TO THE LARGE INRUSH WHEN THE MAIN MOTOR IS STARTED.

DB130.DBX1			DB130.DBX1
04.4			6.6
AIR	I5.1		COMPRESSOR
COMPRESSOR	ROTARY	I2.7	START
RUN	CONTROL	AIR	DRIVE
ENABLE	POWER	COMPRESSOR	SHUTDOWN
"AirCompre	CONTACTOR	CONTACTOR	"AirCompre
ssorOperDa	AUX	AUX	ssorOperDa
ta".ACSTL	"RCPC_AUX"	"ACC_AUX"	ta".DASL

I6.1  
HOIST/PULL  
DOWN  
CONTROL  
POWER  
CONTACTOR  
AUX  
"HPCPC\_  
AUX"

THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.

MD6640




CBD612159  
Cliffs - Bloom Lake  
FC30

Network: 20 COMPRESSOR FAILURE (SHUTDOWN)

CATT > 100 DEGREES C (212F), COTT < (CATT - 40C)

DB1.DBX4.3  
AIR  
COMPRESSOR  
FAILURE  
(SHUTDOWN)  
"FaultedCo  
nditions".  
ANF035  
<S>



THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER SHALL BE SUBJECT TO LIABILITY.  
© 2013 Bucyrus International, Inc. ALL RIGHTS RESERVED

MD6640



CBD612159  
Cliffs - Bloom Lake  
FC31

Network: 6 AIR COMPRESSOR OIL TEMP HIGH FAULT (SHUTDOWN)

ACOTT > 93 deg. C (200 deg. F)

DB1.DBX4.7  
AIR  
COMPRESSOR  
OIL TEMP  
HIGH  
(SHUTDOWN)  
"FaultedCo  
nditions".  
ANF039

CMP >R

<S>

DB607.DBD3  
6

(PIW274)

AIR  
COMPRESSOR  
OIL

TEMPERATUR  
E (-50 TO  
150 DEG C)

"AnalogInp  
utsScaledD  
ata".

ACOTT\_  
SCALED -IN1

9.300000e+  
001 -IN2

Network: 7

M0.1  
Always On  
"ALWAYS\_  
ON"

<SAVE>


THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE  
EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION,  
DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.  
© 2013 Bucyrus International, Inc. ALL RIGHTS RESERVED

MD6640



CBD612159  
Cliffs - Bloom Lake  
FC33

Network: 5 COMPRESSOR REDUCTION 3



THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.  
© 2013 Bucyrus International, Inc. ALL RIGHTS RESERVED


MD6640



CBD612159  
Cliffs - Bloom Lake  
FC34

Network: 8 WATER INJECTION CALCULATED FLOW

WATER INJECTION FLOW RATE BASED ON MEASURED WATER INJECTION MOTOR SPEED UNDER CONTROLLED CONDITIONS.  $GPM = ((WIMS * WIMS) - 225.0) * 0.00320879$



THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.  
© 2013 Bucyrus International, Inc. ALL RIGHTS RESERVED

MD6640




CBDR612159  
Cliffs - Bloom Lake  
FC36

Network: 1 AIR COMPRESSOR START-STOP

IF THE HMI MAIN MOTOR ON-OFF BUTTON (MOMENTARY) IS PRESSED, IT WILL ACT AS A START REQUEST IF THE ENABLE BIT IS NOT ALREADY SET, OTHERWISE IT WILL ACT AS A STOP.

NOTE: THE BUTTON MUST BE PRESSED FOR 2 SEC. BEFORE ACTIVATION (TO AVOID ACCIDENTAL OPERATION)



THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.

© 2013 Bucyrus International, Inc. ALL RIGHTS RESERVED

MD6640



CBD612159  
Cliffs - Bloom Lake  
FC36

Network: 10 COMPRESSOR INLET PRESSURE SWITCH LATCH

I3.3  
AIR  
COMPRESSOR  
INLET  
PRESSURE  
SWITCH  
"ACIPS"

DB130.DBX1  
8.5  
COMPRESSOR  
INLET  
PRESSURE  
SWITCH  
LATCH  
"AirCompre  
ssorOperDa  
ta".CIPSL1

(S)

THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.  
© 2013 Bucyrus International, Inc. ALL RIGHTS RESERVED

**MD6640**



CBD612159  
Cliffs - Bloom Lake  
FC36

**Down References**


CFDAVT FC30:22/SD FC36:21/SD

**Up References**

CFDAVT FC30:22/AN FC36:21/AN

Network: 22 AIR COMPRESSOR OIL PRESSURE LOW FAULT

WAIT UNTIL THE AIR COMPRESSOR HAS BEEN RUNNING FOR 30 SEC, THEN BEGIN CHECKING THE OIL PRESSURE SWITCH AND IF IT STAYS TRIPPED FOR 5 SEC, LATCH THE LOW OIL PRESSURE FAULT.



THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.  
© 2013 Bucyrus International, Inc. ALL RIGHTS RESERVED


**MD6640**



CBD612159  
Cliffs - Bloom Lake  
FC41

Network: 8 DRIVE TEST DISABLE

DO NOT ALLOW DRIVE CONTROL IF THE OPERATOR NAVIGATES AWAY FROM DRIVE TEST SCREEN WHILE A TEST IS ACTIVE.



**Down References**  
OD\_DSN


THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.  
© 2013 Bucyrus International, Inc. ALL RIGHTS RESERVED

MD6640



CBDR612159  
Cliffs - Bloom Lake  
FC43

3.A



THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.  
© 2013 Bucyrus International, Inc. ALL RIGHTS RESERVED

**MD6640**




CBD612159  
Cliffs - Bloom Lake  
FC43

**Down References**

CPCATR FC43:9/SD

Network: 13 DRIVE FAULT RESET TIMER




**Down References**

CPCATR FC43:9/SD

**Up References**

DFRTR FC43:14/A

Network: 14 DRIVE FAULT RESETS



THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.

**MD6640**




CBD612159  
Cliffs - Bloom Lake  
FC50

Network: 3      MOTOR FIELD OVER CURRENT

---

FIELD OVERCURRENT REF SHOULD BE SET TO 120% OF MAX RUNNING AMPS (12.5 A)



**Up References**  
HMFOTR      FC50:4/A

THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.


© 2013 Bucyrus International, Inc. ALL RIGHTS RESERVED



CBDR612159  
Cliffs - Bloom Lake  
FC50

Network: 10 HEAD BRAKE RELEASED CHECK DELAY TIMER

IF EVERYTHING IS FUNCTIONING PROPERLY, ALLOW THE SPEED REFERENCE OUTPUT TO THE DRIVE. THE HEAD BRAKE SHOULD BE RELEASED AT THIS TIME AND T27 TIMES A SHORT DELAY BEFORE CHECKING TO SEE IF ALL THREE LIMIT SWITCHES AGREE THAT IT ACTUALLY HAS.



THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.  
© 2013 Bucyrus International, Inc. ALL RIGHTS RESERVED


**MD6640**



CBD612159  
Cliffs - Bloom Lake  
FC51

Network: 6

RESULT = IA/DELTA IA



THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.  
© 2013 Bucyrus International, Inc. ALL RIGHTS RESERVED




**MD6640**



CBD612159  
Cliffs - Bloom Lake  
FC53


Network: 4      RATE OF SPEED CHANGE

USING THE PLC SCAN TIME AND THE CHANGE IN SPEED FROM THE LAST SCAN, THE RATE OF CHANGE IS CALCULATED.



Network: 5      Hoist/Pd motor inertial torque (ft-lb)

INERTIAL TORQUE CONSTANT = (1000)(PI)(J)/30



THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.  
© 2013 Bucyrus International, Inc. ALL RIGHTS RESERVED


MD6640



CBD612159  
Cliffs - Bloom Lake  
FC54

Network: 3 PULLDOWN TORQUES SCALING MATH RESULT

USE THE HOIST/PD SPEED FINAL REF. VALUE TO CONVERT THE MOTOR FORCE REQUIRED INTO A TORQUE VALUE.



THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.  
© 2013 Bucyrus International, Inc. ALL RIGHTS RESERVED

MD6640



CBD612159  
Cliffs - Bloom Lake  
FC55

Network: 3 HEAD BRAKE RELEASE RELAY

IF THE MOTOR IS OPERATING AT A SPEED BELOW A DEFINED THRESHOLD (DIFFERENT VALUES FOR HOIST LOW/PULLDOWN AND HOIST HIGH) THE BRAKE WILL SET AS SOON AS THE SS IS TURNED TO THE SET POSITION. IF ABOVE THE THRESHHOLD, IT WILL BE DELAYED FROM SETTING FOR A SHORT TIME TO ALLOW THE MOTOR TO SLOW DOWN AND AVOID EXCESSIVE WEAR.

I37.0  
HOIST/PULL  
DOWN  
BRAKE  
SELECTOR  
SWITCH -  
RELEASE  
"HPBSS"

T28  
HEAD  
BRAKE SET  
DELAY  
TIMER  
"HBSDTR"

I36.0  
HOIST/PULL  
DOWN  
SELECTOR  
SWITCH -  
PULLDOWN  
"HPSS\_P"

DB5.DBX0.1  
HEAD  
BRAKE  
RELEASE  
RELAY  
"HeadBrake  
DriveData"  
.HBRR

I36.1  
HOIST/PULL  
DOWN  
SELECTOR  
SWITCH -  
HOIST LOW  
"HPSS\_HL"

DB73.DBD84  
CALCULATED  
HOIST/PD  
MOTOR  
SPEED  
(RPM, + =  
HOISTING)  
"Hoist/  
PdSpeedTor  
queData".  
HRPM -IN1

1.740000e+  
002 -IN2

CMP >=R

CMP <=R

DB73.DBD84  
CALCULATED  
HOIST/PD  
MOTOR  
SPEED  
(RPM, + =

3.A

THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.

**MD6640**



CBD612159  
Cliffs - Bloom Lake  
FC60

**Down References**


PRST FC60:1/SD  
RMST FC60:1/SD

**Up References**

PHTRS FC46:41/O  
PRST FC60:1/A  
RMST FC60:1/A

Network: 2 ROTARY MOTOR FIELD LOSS TIMER

FIELD LOSS REF SHOULD BE SET TO 50% OF WEAK FIELD CURRENT



**Up References**

RMFLTR FC60:4/A

THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.  
© 2013 Bucyrus International, Inc. ALL RIGHTS RESERVED

MD6640



CBD612159  
Cliffs - Bloom Lake  
FC60

-4.  
620000e+  
002 -IN2

DB71.DBX24  
.0  
Rotary  
high  
overload  
"RotaryMot  
orOverload  
Data".  
ANI056

CMP >=R

DB607.DBD4  
(PIW258)  
ROTARY  
CONTROL  
ARMATURE  
CURRENT  
(-750 TO  
+750 ADC,  
+ = CW)  
"AnalogInp  
utsScaledD  
ata".  
RCPAC\_  
SCALED -IN1

4.450000e+  
002 -IN2

CMP <=R

DB607.DBD4  
(PIW258)  
ROTARY  
CONTROL  
ARMATURE  
CURRENT  
(-750 TO  
+750 ADC,  
+ = CW)  
"AnalogInp  
utsScaledD  
ata".  
RCPAC\_  
SCALED -IN1

-4.  
450000e+  
002 -IN2

THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE  
EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION,  
DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.  
© 2013 Bucyrus International, Inc. ALL RIGHTS RESERVED


**MD6640**



CBD612159  
Cliffs - Bloom Lake  
FC61


Network: 11

RESULT = MOTOR SPEED IN RPM



Network: 12

THE OPERATORS DISPLAY SHOWS THE ROTARY SPEED OF THE BIT AS WELL AS THE MOTOR SPEED IN RPM. THE MOTOR SPEED MUST BE MULTIPLIED BY THIS CONSTANT TO GET THE ROTARY SPEED AT THE BIT.



THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.  
© 2013 Bucyrus International, Inc. ALL RIGHTS RESERVED

MD6640




CBD612159  
Cliffs - Bloom Lake  
FC71

Up References

TWEVS FC153:30/A

Network: 5 BIT VIEWING HATCH DELAYED MFV OFF TIMER

I37.2	DB52.DBX0.	Q10.4	T38
DRILL	5	VALVE	BIT
DECK	ONE SHOT	BANK TWO	VIEWING
HATCH	"MastLock/	LOAD	HATCH
SELECTOR	HatchStair	CONTROL	DELAYED
SWITCH	Data".	VALVE	MFV OFF
"DDHSS"	ONS342	SOLENOID	TIMER
		"VB2LCVS"	"BVHDOT"



I37.2	DB52.DBX0.	DB911.DBW7
DRILL	6	4
DECK	ONE SHOT	BVHDOT
HATCH	"MastLock/	(15 S)
SELECTOR	HatchStair	"Timers".
SWITCH	Data".	t38
"DDHSS"	ONS343	



Down References

VB2LCVS FC30:16/= FC36:16/=

Up References

BVHDOT FC71:12/A

THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.  
© 2013 Bucyrus International, Inc. ALL RIGHTS RESERVED

MD6640



CBDR612159  
Cliffs - Bloom Lake  
FC71

Network: 14 MAIN FLOW HYDRUALIC VALVE AUXILLIARY

DB190.DBX2  
.7  
ANGLE  
HOLE  
DRILLING  
OPTION  
INSTALLED  
"OptionsIn  
stalled".  
AHOI

I37.4  
DRILL/PROP  
EL MASTER  
SELECTOR  
SWITCH -  
PROPEL  
"DPMSS\_P"

I37.5  
DRILL/PROP  
EL MASTER  
SELECTOR  
SWITCH -  
REMOTE  
PROPEL  
"DPMSS\_R"

I37.6  
DRILL/PROP  
EL MASTER  
SELECTOR  
SWITCH -  
MAST  
"DPMSS\_M"

DB209.DBX2  
.5  
JACKS NOT  
OPERATING  
"Auto  
Level".JNO

DB9.DBX47.  
1  
HEAD  
LOWER  
LIMIT  
AUXILLIARY  
RELAY  
"HeadLimit  
sData".  
HLLAR

DB50.DBX3.  
2  
A-FRAME  
PINS LOCK  
TIMER  
TIMING  
"MastLockR  
H/  
LHData".  
AFPLT\_TT

I41.7  
DUST SEAL  
SLIDER  
SELECTOR  
SWITCH -  
REAR  
"DSSSS\_R"

I41.6  
DUST SEAL  
SLIDER  
SELECTOR  
SWITCH -  
FRONT  
"DSSSS\_F"

I41.4  
DRILL  
PIPE  
POSTION  
SELECTOR  
SWITCH -

14.A

THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE  
EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION,  
DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.  
© 2013 Bucyrus International, Inc. ALL RIGHTS RESERVED

MD6640



CBD612159  
Cliffs - Bloom Lake  
FC72

1.800000e+  
001

DB607.DBD2  
4

(PIW268)  
RADIO  
REMOTE  
RECIEVER  
RIGHT  
MASTER  
SWITCH  
(-100 TO  
+100%, +  
= FORWARD)  
"AnalogInp  
utsScaledD  
ata".  
RRRMS\_  
SCALED

-1.  
800000e+  
001

5.B

DB1001.DBX  
3.4

I37.6  
DRILL/PROP  
EL MASTER  
SELECTOR  
SWITCH -  
MAST  
"DPMSS\_M"

DB190.DBX2  
.6  
REMOTE  
WINCH  
INSTALLED  
"OptionsIn  
stalled".  
RWOI

Remote  
Winch  
Enable  
"DisplayBi  
ts\_  
HMI2PLC".  
RWE

I4.0  
REMOTE  
WINCH  
DIRECTION  
SELECTOR  
SWITCH  
DOWN  
"RWDSS\_D"

I4.1  
REMOTE  
WINCH  
DIRECTION  
SELECTOR  
SWITCH UP  
"RWDSS\_U"

THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE  
EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION,  
DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.  
© 2013 Bucyrus International, Inc. ALL RIGHTS RESERVED




CBD612159  
Cliffs - Bloom Lake  
FC72

Network: 15 Remote Propel Left Control Signal

If remote propel movement is allowed, send the scaled signal from the master switch to the address used by the unscale function (FC6)

This network functions the same for both radio remote and pendant remote propel options.



THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.  
© 2013 Bucyrus International, Inc. ALL RIGHTS RESERVED


**MD6640**



CBD612159  
Cliffs - Bloom Lake  
FC74

Network: 1      Hydraulic oil level sensor test cycle timer

WHENEVER THE MAIN MOTOR (AIR COMPRESSOR) IS STARTED OR PROPEL MODE IS SELECTED,  
T118 TIMES A 4 SEC PERIOD.



**Down References**

HLOSCT1      FC74:1/SF

**Up References**

HLOSCT1      FC74:3/A    FC74:2/AN    FC74:1/AN


THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.



CBD612159  
Cliffs - Bloom Lake  
FC75

Network: 3 PROPEL ENABLE

THE READY SIGNAL IS LATCHED IN AS PROPEL ENABLE IF ALL PERMISSIVES ARE OK.



THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.  
© 2013 Bucyrus International, Inc. ALL RIGHTS RESERVED

**MD6640**



CBDR612159  
Cliffs - Bloom Lake  
FC75

**Up References**

POWH  
PSHTR FC4:4/AN

Network: 14

M0.1  
Always On  
"ALWAYS\_  
ON"

<SAVE>

**Down References**

ALWAYS\_ON OB1:1/S

THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.  
© 2013 Bucyrus International, Inc. ALL RIGHTS RESERVED



**MD6640**



CBD612159  
Cliffs - Bloom Lake  
FC76

**Down References**

LJST FC76:18/SD  
RLJGPT FC76:15/SD  
RRJGPT FC76:14/SD

**Up References**

LJST FC76:18/A

Network: 19 All Jacks On The Ground

T71	T72	T73	DB209.DBX0
FRONT	RIGHT	LEFT REAR	.7
JACK	REAR JACK	JACK	All Jacks
GROUND	GROUND	GROUND	On The
PRESSURE	PRESSURE	PRESSURE	Ground
TIMER	TIMER	TIMER	"Auto
"FJGPT"	"RRJGPT"	"RLJGPT"	Level".AJG

**Down References**

FJGPT FC76:13/SD  
RLJGPT FC76:15/SD  
RRJGPT FC76:14/SD

THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.



CBD612159  
Cliffs - Bloom Lake  
FC76

**Down References**


FLT FC76:27/SD

**Up References**

FLT FC76:30/O FC76:29/O FC76:28/O FC76:27/A FC76:9/A

Network: 28 FRONT JACKS EXTEND

PERMISSIVES TO ALLOW EXTENDING THE LEVEL JACKS IN AUTO OR MANUAL MODE.



**Down References**

FET FC76:23/SD  
FJGPT FC76:13/SD  
FLT FC76:27/SD  
JFLLVS FC76:39/R FC76:38/S  
JFRLVS FC76:39/R FC76:38/S  
SSLT FC76:26/SD

THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.  
© 2013 Bucyrus International, Inc. ALL RIGHTS RESERVED

**MD6640**



CBD612159  
Cliffs - Bloom Lake  
FC76

**Down References**

ALWAYS\_ON    OB1:1/S

THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.


MD6640



CBDR612159  
Cliffs - Bloom Lake  
FC76

Network: 40      Jacks Not Operating

Other logic requires that the jacks not be operating. This network sets a bit for use elsewhere.



**Down References**

JFLLVS      FC76:39/R    FC76:38/S  
 JFLRVS      FC76:39/R    FC76:38/S  
 JFRLVS      FC76:39/R    FC76:38/S  
 JFRRVS      FC76:39/R    FC76:38/S  
 JRLLVS      FC76:39/R    FC76:38/S  
 JRLRVS      FC76:39/R    FC76:38/S  
 JRRLVS      FC76:39/R    FC76:38/S  
 JRRRVS      FC76:39/R    FC76:38/S

Network: 41

M0.1  
Always On  
"ALWAYS\_  
ON"



**Down References**


ALWAYS\_ON    OB1:1/S

THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.  
 © 2013 Bucyrus International, Inc. ALL RIGHTS RESERVED

**MD6640**



CBD612159  
Cliffs - Bloom Lake  
FC77



THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.

© 2013 Bucyrus International, Inc. ALL RIGHTS RESERVED

MD6640



CBDR612159  
Cliffs - Bloom Lake  
FC77

Network: 19      LH MAST LOCK PIN UNLOCKED

I26.5  
MAST PIN  
UNLOCKED  
LEFT HAND  
LIMIT  
SWITCH  
"MPULHLS"

DB50.DBX1.  
6  
LH MAST  
LOCK PIN  
UNLOCKED  
"MastLockR  
H/  
LHData".  
ANI110

DB1000.DBX  
12.2  
LEFT MAST  
LOCK PIN  
UNLOCKED  
"DisplayBi  
ts\_  
PLC2HMI".  
LMLPU

THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.

**MD6640**



CBD612159  
Cliffs - Bloom Lake  
FC77

Network: 32 MAST LOCK CONSTANT PRESS VALVE RELAY

Q9.3	DB50.DBX3.
MAST PIN	0
UNLOCK	MAST LOCK
VALVE	CONSTANT
SOLENOID	PRESS
"MPUVS"	VALVE
	RELAY
	"MastLockR
	H/
	LHData".
	MLCPVR
	<R>

**Down References**

MPUVS FC77:4/=

Network: 33 Mast lock constant pressure valve

	DB50.DBX3.		
	0		
	MAST LOCK	Q10.4	Q11.2
	CONSTANT	VALVE	MAST PIN
DB100.DBX2	PRESS	BANK TWO	CONSTANT
.5	VALVE	LOAD	PRESSURE
Control	RELAY	CONTROL	VALVE
Enabled	"MastLockR	VALVE	SOLENOID
"System".	H/	SOLENOID	"MPCPVS"
ctrlEN	LHData".	"VB2LCVS"	
	MLCPVR		
			<>

**Down References**

VB2LCVS FC30:16/= FC36:16/=

**Up References**


MPCPVS

THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.



CBD612159  
Cliffs - Bloom Lake  
FC78

Network: 4 PIPE RACK FLOW ENABLE



4.A

THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.  
© 2013 Bucyrus International, Inc. ALL RIGHTS RESERVED

**MD6640**



CBD612159  
Cliffs - Bloom Lake  
FC79

Network: 4

M0.1  
Always On  
"ALWAYS\_  
ON"

<SAVE>

**Down References**

ALWAYS\_ON OB1:1/S

THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.

**MD6640**

CBD612159  
Cliffs - Bloom Lake  
FC81

**Down References**

LDVS FC81:13/=

VB2LCVS FC30:16/= FC36:16/=

**Up References**

LDVDDT FC81:13/A


PDT FC81:16/O

Network: 13 LUBE DIRECTION VALVE SOLENOID

WHEN THE DIRECTION VALVE IS ENERGIZED, LUBE WILL BE SENT TO BOTH THE HEAD AND THE CRAWLER/CHASSIS LUBE POINTS. WHEN OFF, ONLY THE CRAWLER/CHASSIS IS LUBED.

T35  
LDV valve  
dropout  
delay  
timer  
"LDVDDT"

Q2.5  
LUBE  
DIRECTION  
VALVE  
SOLENOID  
"LDVS"

**Down References**

LDVDDT FC81:12/SF

**Up References**

LDVS FC81:12/A


THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.



CBD612159  
Cliffs - Bloom Lake  
FC82

Network: 1 Pipe Thread Lubrication Timer

IF IN PIPE JOINTS MODE, THE THREAD LUBRICATION SOLENOID WILL BE ENERGIZED FOR 5 SEC EACH TIME THE LUBE BUTTON IS PRESSED ON THE HMI MAINTENANCE SCREEN, OR FOR AS LONG AS IT IS PRESSED AND HELD.



**Down References**


PTLT FC82:1/SF

THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.  
© 2013 Bucyrus International, Inc. ALL RIGHTS RESERVED



CBD612159  
Cliffs - Bloom Lake  
FC90

Network: 2 CABLE REEL OUT ENABLE



**Down References**

VB2LCVS FC30:16/= FC36:16/=

THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.  
© 2013 Bucyrus International, Inc. ALL RIGHTS RESERVED

**MD6640**



CBD612159  
Cliffs - Bloom Lake  
FC91

Q11.6  
CABLE  
REEL WIND  
VALVE  
SOLENOID  
"CRWVS"



4.A

THIS DOCUMENT IS PROTECTED UNDER APPLICABLE COPYRIGHT LAWS TO THE EXTENT AVAILABLE. ANY UNAUTHORIZED AND UNLAWFUL REPRODUCTION, DISTRIBUTION OR OTHER USE SHALL BE SUBJECT TO LIABILITY.

© 2013 Bucyrus International, Inc. ALL RIGHTS RESERVED

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL