

PART NO. TT97C5-E-00

**HITACHI**

ZW370 WHEEL LOADER TECHNICAL MANUAL TROUBLESHOOTING

# Technical Manual

## Troubleshooting

# ZW 370 Wheel Loader

 **Hitachi Construction Machinery**

URL:<http://www.hitachi-c-m.com>

PRINTED IN JAPAN (K) 2009.10

Service Manual consists of the following separate Part No.  
Technical Manual (Operational Principle) : Vol. No.TO97C5-E  
Technical Manual (Troubleshooting) : Vol. No.TT97C5-E  
Workshop Manual : Vol. No.W97C5-E

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

## Cautions Regarding Troubleshooting

### Important points

The important points for troubleshooting is to carefully read the operation manual and shop manual to get enough information on the operation, circuits, structure, and function of each component. If you have enough knowledge of each component and system, you can easily determine the cause of the problem.

There may be various causes for each problem, therefore experience will be needed to determine which is the actual cause of the problem.

It is necessary to know the normal operation of each component. In addition, it is also important to know the abnormal condition when a problem occurs. This chapter shows various examples of past problems, and describes possible causes and remedies for each problem.

### Before starting troubleshooting

To prevent incorrect diagnosis, talk with the persons concerned, particularly with the operator, to get enough information on the problem. If possible, check the machine by repeating the symptom.

If the problem cannot be repeated, do not provide any repair service.

For instance, assume that the operator complains that the boom power is low, and the rim-pull is also low. In this case, there are two possible causes; low hydraulic power and low rim-pull. The remedies against both causes are much different from each other.

If you hastily determine the wrong cause without checking the actual condition of the problem, it will take too much time and expense to solve the problem. As a result, you will not be trusted by the user.

The following questions will be helpful in determining of the cause. Answer the questions to prevent an incorrect diagnosis.

1. Did the problem occur suddenly?
2. When did the operator notice the problem?
3. Is there any past problem that may be the cause of this problem?
4. When the problem occurred, what kind of work was the operator doing?
5. Has the machine had the same kind of problem before?
6. Has the machine been repaired or inspected recently?
7. Does the machine have any other problem?

### Troubleshooting

- Check before determination of cause  
A problem may be caused by poor daily maintenance, such as lack of grease, low or improper oil or a clogged filter. Be sure to check the machine for oil level, appearance, unpleasant odor, etc. to prevent time loss due to other unnecessary tests.
- Inspection procedure  
As a rule, check the easy-to-be-repaired system first (excluding the cases where the cause can be easily determined based on the past experiences).

This machine is controlled by electrical, hydraulic, and mechanical systems. The most easy-to-be-repaired system is the electrical system. Check the electrical system first. If no problem is detected in the electrical system, check the hydraulic system, and then the mechanical system.

### Note

Check the error code on the MODM at first !



<b>8. ELS (Efficient Loading System) does not work.            (Excavating and scooping tractive power does not become up during ELS working condition)</b>  Check before starting work. 1. Check the error code No. shown on the MODM.		Symptoms / check point														
Possible cause		Pressing ELS switch, it does not function.	Without pressing ELS switch, if functions.	At upper position of lower kickout setting, ELS works.												Solution
	ELS switch defective	<input type="radio"/>														Repair
	Solenoid valve coil or wiring failure	<input type="radio"/>														Disassembly & repair
	Solenoid valve spool stuck	<input type="radio"/>														Disassembly & repair
	Relief valve set pressure is extremely low.		<input type="radio"/>													Disassembly & repair
	Main controller failure	<input type="radio"/>		<input type="radio"/>												Replacement
	Kickout sensor defective or link, rod bent			<input type="radio"/>												Replacement or repair
	Speed sensor failure	<input type="radio"/>														Replacement
	Pump defective	<input type="radio"/>														Refer to (No.1)

# Electrical Group

<p><b>1. Instrument panel does not indicate properly.</b></p> <p>Check before starting work.</p> <ol style="list-style-type: none"> <li>1. Check the fuses.</li> <li>2. Lamp test Turn the starter switch key to "ON" position and leave it there for 3 seconds. Check the indicator lamps.</li> <li>3. Check the error code No. shown on the MODM.</li> </ol>		Symptoms / check point										Solution	
		Possible cause											
Remarks	Bulb of monitor lamp burnt out	<input type="radio"/>											Bulb replacement
	Defective sensor or improper wiring			<input type="radio"/>			<input type="radio"/>	<input type="radio"/>		<input type="radio"/>			Sensor replacement
	Disconnected or defective electrical circuit	<input type="radio"/>					<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		<input type="radio"/>	<input type="radio"/>	Repairing cable
	Loose connector		<input type="radio"/>				<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		<input type="radio"/>	<input type="radio"/>	Connector check & re-connection
	T/M controller failure alarm turned on		<input type="radio"/>										Inspection & repair
	Defective controller	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	Controller replacement
	Defective inside mechanism of gauge or meter						<input type="radio"/>	<input type="radio"/>		<input type="radio"/>	<input type="radio"/>		Replacement
	Defective board of instrument panel								<input type="radio"/>				Replacement
	T/M solenoid valve improperly connected.										<input type="radio"/>	<input type="radio"/>	Properly connect
	Gauge circuit grounded improperly.								<input type="radio"/>	<input type="radio"/>			Inspection & repair
* If the gauge and warning lamps do not agree there probably is a defect in the wiring. Stop immediately and diagnose the defect.													

FAULT CODE/ LAMP	DESCRIPTION	ZW370
EG1358 Yellow	Accelerator Pedal Position Sensor 1 Circuit - voltage above normal or shorted high.	
EG1359 Yellow	Accelerator Pedal Position Sensor 1 Circuit - voltage below normal or shorted low.	
EG1361 Yellow	Remote Accelerator Pedal Position Sensor 1 Circuit - voltage below normal or shorted low.	
EG1376 Orange	Engine Camshaft Speed / Position Sensor - data erratic, intermittent, or incorrect.	
EG1595 Yellow	Remote Accelerator Pedal Position Sensor 1 Circuit - voltage above normal or shorted high.	
EG1597 Orange	Engine Control Module Critical Internal Failure - bad intelligent device or component.	
EG1845 Orange	Water in Fuel Indicator Sensor Circuit - voltage above normal or shorted to high source.	
EG1846 Orange	Water in Fuel Indicator Sensor Circuit - voltage below normal or shorted to low source.	
EG1852 Yellow	Water in Fuel Indicator - data valid but above normal operational range - moderately severe level.	
EG1911 Yellow	Injector Metering Rail 1 Pressure - above normal operating range.	
EG2185 Yellow	Sensor Supply Voltage #4 Circuit - shorted high.	
EG2186 Yellow	Sensor Supply Voltage #4 Circuit - shorted low.	
EG2215 Yellow	Fuel Pump Delivery Pressure - data valid but below normal operational range - moderately severe level.	
EG2249 Yellow	Fuel Pump Delivery Pressure Sensor Circuit - shorted low.	
EG2261 Orange	Fuel Pump Delivery Pressure - data valid but above normal operational range - least severe level.	
EG2262 Orange	Fuel Pump Delivery Pressure - data valid but below normal operational range - least severe level.	
EG2265 Yellow	Fuel Priming Pump Control Signal Circuit - shorted high.	
EG2266 Yellow	Fuel Priming Pump Control Signal Circuit - shorted low.	
EG2311 Yellow	Fueling Actuator #1 Circuit Error - condition exists.	
EG2321 None	Engine Speed Sensor #1 - data erratic, intermittent, or incorrect.	
EG2322 None	Engine Speed Sensor #2 - data erratic, intermittent, or incorrect.	
EG2697 Orange	Accelerator Pedal Position Sensor Circuit and Idling Position Detection Switch Circuit - data erratic, intermittent, or incorrect.	
EG2963 None	Engine Coolant Temperature High - warning.	
EG2964 None	Intake Manifold Temperature High - warning.	
EG2973 Yellow	Intake Manifold Pressure Sensor Circuit - data erratic, intermittent, or incorrect.	

(09D20E)

# Measurement for Performance Check

## 03

Cautions on Safety .....	03-2
Standard Measurement Values for Performance Check .....	03-3
Preparation for Performance Check .....	03-6
Engine .....	03-8
Measuring engine speed .....	03-8
Clutch Oil Pressure and Time Lag .....	03-12
Measuring clutch oil pressure .....	03-12
Hydraulic Cylinder .....	03-15
Cylinder natural drift .....	03-15
Boom Cycle Time .....	03-17
Full Steering Time .....	03-19
Loading/Steering Circuit Relief Valve .....	03-21
Loading circuit relief valve setting pressures .....	03-21
Steering circuit relief valve setting pressures .....	03-26
Stop Valve .....	03-32
Stop valve adjustment procedure .....	03-32
Fan Revolution .....	03-33
Service Brake .....	03-34
Service brake performance check .....	03-34
Parking Brake .....	03-35
Parking brake performance check .....	03-35
Brake Circuit Oil Pressure .....	03-36
Unloader valve setting pressure .....	03-36
Brake valve oil pressure .....	03-39
Accumulator Circuit Charging Time .....	03-41
Number of Brake Pedal Applications .....	03-43
Declutch Engagement .....	03-44

**Cause of extremely high or low measurement value and solution**

Minimum no-load speed (LI) or maximum no-load speed (HI) low

Possible cause	Solution
Insufficient warm up	Warm up
Malfunctioning accelerator pedal or harness	Inspection & repair
Clogged fuel filter	Clean
Defective fuel pump	Repair
Defective fuel injection nozzle	Repair
Valve clearances incorrect	Adjustment
Insufficient compression pressure	Repair

The engine speed is too high in torque converter stall mode.

Possible cause	Solution
Slipping transmission clutch or defect inside of transmission	Disassembly & repair
Defect inside torque converter	Disassembly & repair

The engine speed is too low in torque converter stall mode.

**Caused by reduction in engine power**

Possible cause	Solution
Clogged air cleaner element	Cleaning
Improper type of fuel	Fuel replacement
Clogged fuel filter or suction strainer	Clean or replace
Frozen fuel / wax build up	Use antifreeze mixture
Malfunctioning accelerator pedal or harness	Inspection & repair
Defective fuel pump	Repair
Defective fuel injector nozzle	Repair
Insufficient compression pressure	Repair
Hydraulic load is extremely large	Inspection & repair
Malfunctioning torque converter	Inspection & repair

The engine speed is too high in multiple control valve relief mode.

Possible cause	Solution
Relief valve pressure too low	Adjustment or disassembly
Defective pump / pump seals	Disassembly & repair

The engine speed is too low in multiple control valve relief mode.

Possible cause	Solution
Engine low power	Inspection & repair
Extremely high relief pressure of multiple control valve	Adjustment

The engine speed is too high in torque converter stall plus multiple control valve relief mode.

Possible cause	Solution
Slipping transmission clutch or defect inside of transmission or T/C	Disassembly & repair
Relief pressure too low	Adjustment
Defective pump / pump seals	Disassembly & repair

The engine speed is too low in torque converter stall plus multiple control valve relief mode.

Possible cause	Solution
Engine low power	Inspection & repair
Extremely high relief pressure of multiple control valve or steering valve	Adjustment
Malfunctioning torque converter	Repair

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

# Loading/Steering Circuit Relief Valve

## Loading circuit relief valve setting pressures

**⚠ WARNING**

Unexpected movement of the machine may cause an accident resulting in injury or death. Therefore, to provide repair service with the engine running, be sure to observe the following items:

- Park the machine on level ground.
- Apply the parking brake.
- Block the tires with chocks to prevent the tires from moving.
- Determine the signals between the service man.
- Prohibit any person from walking into dangerous areas.
  - Near articulation areas of the machine
  - Under the machine
  - Around the engine
  - In front of or behind the machine

**⚠ CAUTION**

Be careful, you may get burned if the high pressure oil spouts out. To prevent such an accident, be sure to release the residual pressure from the pipe, and open the cap of the hydraulic tank before removing the plug from the pressure measurement port.

**⚠ CAUTION**

Do not touch the fan or V-belt of the engine or a high-temperature section if the engine is running. An accident resulting in injury may occur. Be sure to stop the engine before you open the access panel of the engine room. Keep all guards in place. Avoid high temperature components even when the engine is stopped.

## Measurement instruments

Pressure gauge

30 MPa (300 kgf/cm<sup>2</sup>) (5,000 psi)  
 (for loading line with 3 m (10 ft.) hose and steering line with 1.5~3 m (4~10 ft.) hose)

5 MPa (50 kgf/cm<sup>2</sup>) (1,000 psi)  
 (for pilot line) with 2~3 m (6~10 ft.) hose

**Note**

For safety, route the gauge to an area where it may be safely read by the person doing the test.

## Gauge port

	Gauge port location	Port size
Main relief pressure	(1), (2), (3)	(1), (2), (3) G (PF) 1/4 with O-ring
Overload relief pressure	(1), (2), (3)	
Pilot line pressure (Reducing valve)	(4)	(4) G (PF) 3/8 with O-ring

### **Adjusting pilot line pressure**

Loosen the lock nut and adjust the pressure by the adjusting screw.

Turn clockwise the adjusting screw to raise the pilot line pressure.

<b>IMPORTANT</b>
------------------

After the completion of the adjustment of the pilot line pressure, be sure to tighten the lock nut.
---

## Accumulator Circuit Charging Time

### WARNING


Unexpected movement of the machine may cause an accident resulting in injury or death.

Therefore, to provide repair service with the engine running, be sure to observe the following items:

- Park the machine on level ground.
- Apply the parking brake.
- Block the tires with chocks to prevent the tires from moving.
- Determine the signals between the service men.
- Prohibit any person from walking into dangerous areas.
  - Near articulation areas of the machine
  - Under the machine
  - Around the engine
  - In front of or behind the machine

### CAUTION

Be careful, you may get burned if the high pressure oil spouts out. To prevent such an accident, be sure to release the residual pressure from the pipe, and open the cap of the hydraulic oil tank before removing the plug and hose from the pressure measurement port.



Valve assembly

95V2E03003

### Measurement instrument

- Hydraulic pressure gauge  
20 MPa (200 kgf/cm<sup>2</sup>) (3,000 psi)
- Stop watch

### Gauge installation position

- Valve assembly ACF port  
size Rc (PT) 1/8




## Electrical wiring diagram abbreviation chart




INSTRUMENT PANEL		INSTRUMENT PANEL		MCU		MCU		MCU		MCU	
WL	Radiator water level warning lamp	P	Parking brake lamp	A20	Auto brake lamp	B25	E/G coolant temperature sensor (S/N 9001~9150)	C1	Efficient loading system oil pressure sensor	D1	Parking switch
C	Charge lamp	A	AUTO lamp	A21	Auto shift indicator lamp		E/G water temperature sensor (for inspection) (S/N 9151~)	C2	Specification change 1	D2	Auto/Manual selection
AC	Air cleaner clogging alarm	AB	Auto brake lamp	A22	Fuel level lamp (1/2)	B26	Communication TXD1	C3	Specification change 2	D3	Shift lever 2
TT	T/M oil temperature alarm	SM	Meter (Speed/Tacho) +	A23	Fuel level lamp (E)	E1	S/S solenoid valve R	C4	Spare digital input	D4	Shift lever R
WT	Engine water temperature alarm	SM	Meter (Speed/Tacho) -	A24	S/S indicator lamp	E2	Fan speed control solenoid valve	C5	T/M oil temperature switch (not used)	D5	Shift lever 3
EP	Engine oil pressure alarm		—	A25	Traction control selection	E3	Power supply +24 V	C6	Air cleaner clogging switch	D6	Shift up switch
BP	Brake oil pressure alarm	TC	Declutch lamp	A26	T/M oil filter warning lamp	E4	Power supply +24 V	C7	E/G coolant temperature switch (not used)	D7	Shift down switch
CE	MCU error (failure alarm)	PH	Preheating lamp	A27	Air cleaner warning lamp	E5	Power supply GND	C8	—	D8	E/G speed sensor selection
+	+24 V power supply	WL	Work lamp	A28	Brake pressure warning lamp	E6	Power supply GND	C9	—	D9	Meter selection
ES	Secondary steering	W	Central alarm lamp	A29	Neutral indicator lamp	E7	Power supply GND	C10	Spare digital input	D10	Shift lever 1
FR	Reversal fan indication lamp	GND	GND (-)	A30	Traction control indicator lamp	E8	Power supply GND	C11	Hydraulic oil level switch	D11	Shift lever F
EG2	Engine warning lamp		—	A31	Fuel level lamp (1/4)	E9	+5 V output	C12	Reset switch (S/N 9001~9250)	D12	Shift lever A
EG1	Engine protection lamp		—	A32	Reversal fan indicator lamp	E10	Tacho-graph E/G speed		New ECO mode selection (S/N 9251~)		Spare digital input (S/N 9001~9150)
EG3	Engine stop lamp	H	High-beam lamp	A33	Fuel level lamp (3/4)	E11	Power supply +24 V	C13	Lower kickout set-up	D13	F34 change point selection (S/N 9151~)
SS	FR switch, S/S switch indication lamp	L	Turn signal (left) lamp	A34	E/G droop selection 2	E12	Power supply +24 V	C14	T/M oil filter clogging switch	D14	Downshift button
WTM	Engine water temperature gauge (sensor)	R	Turn signal (right) lamp	B1	H solenoid valve	E13	Communication CAN H1	C15	Radiator water level switch	D15	Declutch set up
TTM	T/M oil temperature gauge (sensor)		—	B2	—	E14	E/G speed sensor 2 (not used)	C16	E/G oil pressure switch	D16	Odometer selection
	—	GND	Hour meter (-)	B3	Pressure intensifying solenoid valve	E15	E/G ECM	C17	Fuel level F switch	D17	Shift hold switch
(+)	Instrument panel illumination	HM	Hour meter (+)	B4	R solenoid valve	E16	Machine speed sensor	C18	Spare analog input	D18	S/S shift selection switch
TF	T/M oil filter clogging alarm	MCU		B5	Modulation valve (SPCC)	E17	Power supply	C19	T/M pressure sensor	D19	S/S shift switch F
	—	A1	Efficient loading system solenoid valve	B6	Reversal fan solenoid valve	E18	Communication CAN L1	C20	Fuel level 1/2 switch	D20	—
	—	A2	2nd speed solenoid valve	B7	S/S solenoid valve L	E19	S/S potentiometer	C21	Fuel level 1/8 switch	D21	Declutch switch
F	Fuel level lamp (F)	A3	Secondary steering motor relay	B8	E/G idle selection	E20	Communication CAN L0	C22	Efficient loading system switch	D22	Kickout set up
3/4	Fuel level lamp (3/4)	A4	Ride control solenoid valve	B9	Buzzer	E21	T/M oil temperature gauge	C23	E/G mode selection switch	D23	Traction control switch
1/2	Fuel level lamp (1/2)	A5	3rd speed solenoid valve	B10	Lower kickout relay	E22	Brake oil pressure sensor 2	C24	Pressure intensifying switch	D24	Armrest switch
1/4	Fuel level lamp (1/4)	A6	Hour meter	B11	Lift kickout relay	E23	Hydraulic oil temperature sensor	C25	Reversal fan (manual) switch		Tire diameter selection (S/N 9001~9150)
EMP	Fuel level lamp (E)	A7	T/C lock-up solenoid valve	B12	MCU fault relay	E24	Alternator	C26	Boom angle sensor		F23 change point selection (S/N 9151~)
GND	GND (-)	A8	4th speed indicator relay	B13	L solenoid valve	E25	Communication RXD1	C27	Secondary steering oil pressure sensor	D25	S/S shift switch R
+	+ 24 V power supply	A9	E/G torque selection	B14	Auto brake solenoid valve	E26	Tacho-graph machine speed	C28	Fuel level 3/4 switch		
	—	A10	Back-up lamp	B15	E/G droop selection 1	E27	Declutch sensor (brake oil pressure sensor)	C29	Fuel level 1/4 switch		
	—	A11	Fuel level lamp (F)	B16	Communication RINI	E28	Spare analog input	C30	Recall switch (S/N 9001~9250)		
	—	A12	Steering oil pressure warning lamp	B17	—	E29	Communication CAN H0		New declutch selection (S/N 9251~)		
	—	A13	Radiator water level warning lamp	B18	Neutral relay	E30	Brake oil pressure sensor 1	C31	Lower kickout switch (S/N 9001~9150)		
N	Neutral	A14	Central warning lamp	B19	Brake lamp	E31	T/M oil temperature sensor		Auto/Full auto selection (S/N 9151~)		
-	GND (-)	A15	E/G coolant temperature warning lamp	B20	—	E32	Air temperature probe	C32	Spare digital input		
1	1st speed indication	A16	T/M oil temperature warning lamp	B21	—	E33	—	C33	Ride control switch		
2	2nd speed indication	A17	D solenoid valve	B22	Communication DOUT1	E34	E/G coolant temperature gauge	C34	Auto fan reversal switch		
3	3rd speed indication	A18	1st speed solenoid valve	B23	—						
4	4th speed indication	A19	E/G oil pressure warning lamp	B24	Meter output (Speed/Tacho)						

# Electrical Equipment Layout


Front chassis




# Electrical Equipment Layout (K-Lever)




A-A (Fuse unit)




B-detail



Control box detail



K-Lever detail



1. Cable assembly
2. Cable assembly
3. Cable assembly
4. Fuse unit

**Note**

Refer to the electrical connection diagram for the K-Lever electrical connection diagram.

For adjusting the speed of the K-Lever, refer to the K-Lever section on "MODM Parameter Setting Monitor" page 62-92.

## MODM: Input/Output Monitor - Input/Output Signal Correspondence Table

	0	1	2	3	4	5	6	7
INPUT 1	Shift lever F	Shift lever R	Shift lever 1	Shift lever 2	Shift lever 3	Shift lever A	Shift-up	Shift-down
INPUT 2	Transmission pressure switch	Kick-down	Declutch switch	Declutch setup	Parking switch	Engine speed sensor selection (ECM output/sensor output)	A/M selection (automatic/manual)	Meter selection (speedometer/tachometer)
INPUT 3	Speedometer dividing ratio selection (large size tire/small size tire)	F/R switch F	F/R switch R	Spare input	F/R switch selection ON/OFF switch	Stick steering (K-Lever) arm rest switch	Shift hold switch	Traction control switch
INPUT 4	Engine mode selection (economical/normal)	Spare input	Pressure increase switch	Ride control switch	Kickout setup	Odometer selection (only forward/forward and backward)	Efficient loading system (ELS) switch	Lower kickout switch
INPUT 5	Lower kickout setup	Spare input	Clear fault log	Alternator neutral point voltage	Spare input	Opt 1	Hydraulic oil level switch	Opt 2
INPUT 6	Brake differential pressure switch	Brake oil level switch	Engine oil pressure switch	Engine coolant temperature switch	Transmission oil temperature switch	Transmission oil filter switch	Air cleaner clogging switch	Radiator water level switch
INPUT 7	Fuel level 3/4	Fuel level 1/2	Fuel level 1/4	Fuel level 1/8	Fuel level F	Reversal fan	Auto fan reversal	Error log recall

	0	1	2	3	4	5	6	7
OUTPUT 1	1st speed solenoid valve	2nd speed solenoid valve	3rd speed solenoid valve	4th speed solenoid valve	F solenoid valve	R solenoid valve	H solenoid valve	Brake solenoid valve
OUTPUT 2	D solenoid valve	LU solenoid valve	Ride control solenoid valve	Efficient loading system (ELS) selection solenoid valve	Alternate idle relay	Pressure increase solenoid valve	Reversal fan solenoid valve	Brake lamp
OUTPUT 3	Selection switch indicator lamp	Reversal fan indicator lamp	Brake oil pressure warning lamp	Engine oil pressure warning lamp	Engine coolant temperature warning lamp	Transmission oil temperature warning lamp	Transmission oil filter warning lamp	Air cleaner warning lamp
OUTPUT 4	Back lamp	Secondary steering motor relay	Hour meter driving	Engine curve selection 1 (torque)	Neutral relay	MCU failure relay	Kickout coil	Lower kickout relay
OUTPUT 5	Slip control indicator lamp	Auto shift indicator lamp	Neural indicator lamp	Auto brake indicator lamp	Central warning lamp	Radiator water level warning lamp	Steering oil pressure warning lamp	Fuel level F
OUTPUT 6	Fuel level 3/4	Fuel level 1/2	Fuel level 1/4	Fuel level E	Slip control selection	Engine curve selection 3 (ISC)	Engine curve selection 1 (droop)	Buzzer

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL