

850DLC Excavator Operation and Tests

TECHNICAL MANUAL 850DLC Excavator Operation and Test

TM10009 06SEP07 (ENGLISH)

For complete service information also see:

850DLC Excavator Repair TM10011
Undercarriage Appraisal Manual SP326
850DLC Operator's Manual OMT221101
JDLink™ / ZXLink™ Machine Monitoring
System CTM10006

**Worldwide Construction
And Forestry Division**
LITHO IN U.S.A.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below




- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Add Cab Guarding for Special Uses

Special work situations or machine attachments may create an environment with falling or flying objects. Working near an overhead bank, doing demolition work, using a hydraulic hammer, or working in a wooded area, for example, may require added guarding to protect the operator.

Additional Level II FOPS (falling object protective structures) and special screens or guarding should be installed when falling or flying objects may enter or damage the machine. Contact your authorized dealer for information on devices intended to provide protection in special work situations.



T133733 -UN-15SEP00

DW90712,0000056 -19-03FEB06-1/1

Inspect Machine

Inspect machine carefully each day by walking around it before starting.

Keep all guards and shields in good condition and properly installed. Fix damage and replace worn or broken parts immediately. Pay special attention to hydraulic hoses and electrical wiring.



T6607AQ -UN-18OCT88


TX03679,0001734 -19-03JAN07-1/1

Stay Clear of Moving Parts

Entanglements in moving parts can cause serious injury.

Stop engine before examining, adjusting or maintaining any part of machine with moving parts.

Keep guards and shields in place. Replace any guard or shield that has been removed for access as soon as service or repair is complete.



T133592 -UN-12SEP01


TX03679,00016D2 -19-03JAN07-1/1

Remove Paint Before Welding or Heating

Hazardous fumes can be generated when paint is heated by welding or using a torch. Dust from sanding or grinding paint can also be hazardous.

Remove paint to at least 76 mm (3 in.) from area to be heated. Wear an approved respirator when sanding or grinding paint. If a solvent or paint stripper is used, wash area with soap and water. Remove solvent or paint stripper containers from work area and allow fumes to disperse at least 15 minutes before welding or heating.

Work outside or in a well-ventilated area. Dispose of waste, paint and solvents properly.



T133546 -JUN-24AUG00

TX03679,0001732 -19-28FEB06-1/1

Make Welding Repairs Safely

IMPORTANT: Disable electrical power before welding. Turn off main battery switch or disconnect positive battery cable. Separate harness connectors to engine and vehicle microprocessors.

Avoid welding or heating near pressurized fluid lines. Flammable spray may result and cause severe burns if pressurized lines fail as a result of heating. Do not let heat go beyond work area to nearby pressurized lines.

Remove paint properly. Do not inhale paint dust or fumes. Use a qualified welding technician for structural repairs. Make sure there is good ventilation. Wear eye protection and protective equipment when welding.



T133547 -JUN-31AUG00

TX03679,00016D5 -19-08MAY07-1/1

Main Controller (MCF) Diagnostic Trouble Codes

2 Machine Function Check	Is operation of machine normal? See Operational Checkout Procedure. (Group 9005-05).	<p>YES: Machine may be operated but it is recommended that the main controller (MCF) be replaced.</p> <p>NO: Main controller (MCF) malfunction. Replace. See Main Controller (MCF) Remove and Install. (Group 9015-20).</p>
---------------------------------	--------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

9001
10
3

-- -1/1

11002.02 — Abnormal A/D Conversion

LD30992,0000375 -19-02MAY07-1/1

Controller Hardware Diagnostics

-- -1/1

1 Code Check	Clear and re-check diagnostic trouble codes. Is DTC 11002.02-Abnormal EEPROM still present?	<p>YES: Code is still present and machine does not operate. Replace main controller (MCF). See Main Controller (MCF) Remove and Install. (Group 9015-20).</p> <p>YES: Code is still present but machine is still operable. Go to Machine Function Check.</p> <p>NO: Main controller (MCF) is OK.</p>
---------------------	----------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

-- -1/1

Main Controller (MCF) Diagnostic Trouble Codes

<p>4 Open Circuit Check</p>	<p>Disconnect connector to switch panel.</p> <p>Check continuity between main controller (MCF) connector D pin D15 and switch panel connector pin 2.</p> <p>Is there continuity between the pins?</p>	<p>YES: Go to Short Circuit Check.</p> <p>NO: Open circuit in harness.</p> <p>Repair or replace harness. See Cab Harness (W1) Wiring Diagram. (Group 9015-10.)</p> <p style="text-align: right;">-- -1/1</p>
<p>5 Short Circuit Check</p>	<p>Disconnect connector to switch panel.</p> <p>Check continuity between switch panel connector pin 2 and power and ground.</p> <p>Is there continuity to power or ground?</p>	<p>YES: Short circuit in harness.</p> <p>Repair or replace harness. See Cab Harness (W1) Wiring Diagram. (Group 9015-10.)</p> <p>NO: Main controller (MCF) malfunction.</p> <p>Replace main controller. See Main Controller (MCF) Remove and Install. (Group 9015-20).</p> <p style="text-align: right;">-- -1/1</p>
<p>6 Harness Voltage Check</p>	<p><i>NOTE: Key Switch: ON</i></p> <p>Disconnect connector to switch panel.</p> <p>Check voltage between switch panel connector pin 1 and machine ground.</p> <p>Is voltage between 4.5—5.5 volts?</p>	<p>YES: Open circuit in harness between main controller (MCF) and engine speed dial pin 3.</p> <p>Repair or replace harness. See Cab Harness (W1) Wiring Diagram. (Group 9015-10.)</p> <p>NO: Open circuit in harness between main controller (MCF) and engine speed dial pin 1.</p> <p>Repair or replace harness. See Cab Harness (W1) Wiring Diagram. (Group 9015-10.)</p> <p style="text-align: right;">-- -1/1</p>

9001
10
13

Main Controller (MCF) Diagnostic Trouble Codes

<p>4 Short Circuit Check</p>	<p>Disconnect harness from main controller (MCF) and pump 2 delivery pressure sensor.</p> <p>Check continuity between pump 2 delivery pressure sensor connector pin 2 and power and ground.</p> <p>Is there continuity between pin 2 and power or ground?</p>	<p>YES: Short circuit in harness.</p> <p>Repair or replace harness. See Cab Harness (W1) Wiring Diagram, see Machine Harness (W2) Wiring Diagram, and see Pump Harness (W8) Wiring Diagram. (Group 9015-10.)</p> <p>NO: Main controller (MCF) malfunction. See Main Controller (MCF) Remove and Install. (Group 9015-20.)</p> <p style="text-align: right;">-- -1/1</p>
<p>5 Harness Voltage Check</p>	<p>Disconnect pump 2 delivery pressure sensor from harness.</p> <p>Check voltage between pump 2 delivery pressure sensor connector pin 1 and machine ground.</p> <p>Is voltage between 4.5—5.5 Volts?</p> <p><i>NOTE: Key Switch: On</i></p>	<p>YES: Open circuit in harness between main controller (MCF) and pump 2 delivery pressure sensor pin 3.</p> <p>Repair or replace harness. See Cab Harness (W1) Wiring Diagram, see Machine Harness (W2) Wiring Diagram, and see Pump Harness (W8) Wiring Diagram. (Group 9015-10.)</p> <p>NO: Open circuit in harness between main controller (MCF) and pump 2 delivery pressure sensor pin 1.</p> <p>Repair or replace harness. See Cab Harness (W1) Wiring Diagram, see Machine Harness (W2) Wiring Diagram, and see Pump Harness (W8) Wiring Diagram. (Group 9015-10.)</p> <p style="text-align: right;">-- -1/1</p>

9001
10
23

11301.03 — Swing Pilot Pressure Sensor Circuit Voltage High

LD30992.000037E -19-02MAY07-1/1

Main Controller (MCF) Diagnostic Trouble Codes

<p>4 Short Circuit Check</p>	<p>Disconnect harness from arm in pilot pressure sensor and main controller (MCF).</p> <p>Check continuity between arm in pilot pressure sensor connector pin 2 and power and ground.</p> <p>Is there continuity to power or ground?</p>	<p>YES: Short circuit in harness.</p> <p>Repair or replace harness. See Cab Harness (W1) Wiring Diagram and see Machine Harness (W2) Wiring Diagram. (Group 9015-10.)</p> <p>NO: Main controller (MCF) malfunction. Replace controller. See Main Controller (MCF) Remove and Install, (Group 9015-20.)</p>
-------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

9001
10
33

-- -1/1

<p>5 Harness Voltage Check</p>	<p>Disconnect arm in pilot pressure sensor from harness.</p> <p>Check voltage between arm in pilot pressure sensor connector pin 1 and machine ground.</p> <p>Is voltage between 4.5—5.5 volts?</p> <p><i>NOTE: Key Switch: On</i></p>	<p>YES: Open circuit in harness between main controller (MCF) and arm in pilot pressure sensor pin 3.</p> <p>Repair or replace harness. See Cab Harness (W1) Wiring Diagram and see Machine Harness (W2) Wiring Diagram. (Group 9015-10.)</p> <p>NO: Open circuit in harness between main controller (MCF) and arm in pilot pressure sensor pin 1.</p> <p>Repair or replace harness. See Cab Harness (W1) Wiring Diagram and see Machine Harness (W2) Wiring Diagram. (Group 9015-10.)</p>
---------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

-- -1/1

11303.04 — Arm Roll-in Pilot Pressure Sensor Circuit Voltage Low

LD30992,0000383 -19-02MAY07-1/1

Main Controller (MCF) Diagnostic Trouble Codes

<p>③ Solenoid Function Check</p>	<p>Switch travel speed solenoid (SI) harness connector with another solenoid valve in solenoid valve manifold.</p> <p>Clear diagnostic trouble codes (DTC) and re-check for DTC.</p> <p>Does diagnostic trouble code stay with travel speed solenoid (SI)?</p>	<p>YES: Travel speed solenoid (SI) malfunction. Replace solenoid.</p> <p>NO: Main controller (MCF) malfunction. Replace controller. See Main Controller (MCF) Remove and Install. (Group 9015-20.)</p> <p style="text-align: right;">-- 1/1</p>
-----------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

9001
10
43

11405.04 — Travel Speed Solenoid (SI) Valve Current Feedback Low

LD30992,000038B -19-02MAY07-1/1

Travel Speed Solenoid (SI) Diagnostics

Travel speed solenoid (SI) current 56 mA or less.

-- 1/1

<p>① Solenoid Resistance Check</p>	<p>Disconnect harness connector from travel speed solenoid (SI). Check resistance of solenoid.</p> <p>Is resistance between 14.8—22.2 ohms?</p>	<p>YES: Go to Continuity Check.</p> <p>NO: Travel speed solenoid (SI) malfunction. Replace solenoid.</p> <p style="text-align: right;">-- 1/1</p>
-------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------

<p>② Continuity Check</p>	<p>Disconnect harness connectors from main controller (MCF) and travel speed solenoid (SI).</p> <p>Check for continuity between main controller (MCF) connector A pin A11 and travel speed solenoid (SI) harness connector pin 1.</p> <p>Check for continuity between main controller (MCF) connector A pin A17 and travel speed solenoid (SI) harness connector pin 2.</p> <p>Is there continuity between the pins?</p>	<p>YES: Go to Solenoid Function Check.</p> <p>NO: Open circuit in harness.</p> <p>Repair or replace harness. See Cab Harness (W1) Wiring Diagram, see Machine Harness (W2) Wiring Diagram, and see Control Valve Harness (W7) Wiring Diagram. (Group 9015-10.)</p> <p style="text-align: right;">-- 1/1</p>
----------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Hydraulic Oil Temperature Sensor Diagnostics

Hydraulic oil temperature sensor 4.10 volts or higher.

Diagnostic trouble code sets when intake air temperature is 21°C (70°F) or higher and sensor voltage is 4.10 volts or higher for more than 30 seconds.

--1/1

<p>1 Connector Check</p>	<p>Check harness connections to hydraulic oil temperature sensor, MCF and between harness.</p> <p>Are connectors clean and free from debris?</p> <p>Are pins straight and make a good connection?</p>	<p>YES: Go to Hydraulic Oil Temperature Sensor Check.</p> <p>NO: Repair or replace connector. See Machine Harness (W2) Wiring Diagram. (Group 9015-10.)</p>
---------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------

--1/1

<p>2 Hydraulic Oil Temperature Sensor Check</p>	<p>Disconnect hydraulic oil temperature sensor from harness.</p> <p>Check resistance of sensor.</p> <table border="1" data-bbox="399 1205 1227 1623"> <thead> <tr> <th>Hydraulic Oil Temperature</th> <th>Resistance</th> </tr> </thead> <tbody> <tr> <td>-20°C -4°</td> <td>14.6—17.8 kΩ</td> </tr> <tr> <td>0°C 32°F</td> <td>5.88 kΩ</td> </tr> <tr> <td>20°C 68°F</td> <td>2.21—2.69 kΩ</td> </tr> <tr> <td>40°C 104°F</td> <td>1.14 kΩ</td> </tr> <tr> <td>60°C 140°F</td> <td>0.54 kΩ</td> </tr> <tr> <td>80°C 176°F</td> <td>0.32 kΩ</td> </tr> </tbody> </table> <p>Is sensor within specifications?</p>	Hydraulic Oil Temperature	Resistance	-20°C -4°	14.6—17.8 kΩ	0°C 32°F	5.88 kΩ	20°C 68°F	2.21—2.69 kΩ	40°C 104°F	1.14 kΩ	60°C 140°F	0.54 kΩ	80°C 176°F	0.32 kΩ	<p>YES: Go to Continuity Check.</p> <p>NO: Hydraulic oil temperature sensor malfunction. Replace sensor.</p>
Hydraulic Oil Temperature	Resistance															
-20°C -4°	14.6—17.8 kΩ															
0°C 32°F	5.88 kΩ															
20°C 68°F	2.21—2.69 kΩ															
40°C 104°F	1.14 kΩ															
60°C 140°F	0.54 kΩ															
80°C 176°F	0.32 kΩ															

--1/1

Main Controller (MCF) Diagnostic Trouble Codes

9001
10
63

<p>24 DTC Check</p>	<p>Connect connector to information controller (ICF).</p> <p>Clear diagnostic trouble codes (DTC) and re-check for DTCs.</p> <p>Is DTC 11910.02-Actual Engine Speed Message Error still present?</p>	<p>YES: information controller (ICF) malfunction. Replace. See Information Controller (ICF) Remove and Install. (Group 9015-20.)</p> <p>NO: Check harness connection to information controller (ICF).</p> <p align="right">-- -1/1</p>
<p>25 ECM CAN Resistance Check</p>	<p>Connect all connectors except engine control module (ECM) connector.</p> <p>Check resistance between pin 18 (CAN High) and pin 37 (CAN Low) wires in connector.</p> <p>Is resistance between 110—130 Ω?</p>	<p>YES: Go to DTC Check.</p> <p>NO: Go to Monitor Controller CAN Resistance Check.</p> <p align="right">-- -1/1</p>
<p>26 DTC Check</p>	<p>Connect connector to engine control module (ECM).</p> <p>Clear diagnostic trouble codes (DTC) and re-check for DTCs.</p> <p>Is DTC 11910.02-Actual Engine Speed Message Error still present?</p>	<p>YES: Engine control module (ECM) malfunction. Replace. See Engine Control Module (ECM) Remove and Install. (Group 9015-20.)</p> <p>NO: Check harness connection to engine control module (ECM).</p> <p align="right">-- -1/1</p>
<p>27 Monitor Controller CAN Resistance Check</p>	<p>Connect all connectors except monitor controller connector B (X20).</p> <p>Check resistance between pins B6 and B7.</p> <p>Is resistance between 110—130 Ω?</p>	<p>YES: Go to DTC Check.</p> <p>NO: Malfunction in any controller on CAN.</p> <p align="right">-- -1/1</p>
<p>28 DTC Check</p>	<p>Connect connector to monitor controller.</p> <p>Clear diagnostic trouble codes (DTC) and re-check for DTCs.</p> <p>Is DTC 11910.02-Actual Engine Speed Message Error still present?</p>	<p>YES: Monitor controller malfunction. Replace. See Monitor Controller Remove and Install. (Group 9015-20.)</p> <p>NO: Check the connection to monitor controller.</p> <p align="right">-- -1/1</p>

Main Controller (MCF) Diagnostic Trouble Codes

9001
10
73

<p>6 ECM Short to Ground Check</p>	<p>Disconnect all connectors to main controller (MCF), information controller (ICF), engine control module (ECM) and monitor controller.</p> <p>Check for continuity between engine control module (ECM) pin 18 (CAN High wire) and engine control module (ECM) pins 1, 3, 4, 43, and 62 (ground).</p> <p>Check for continuity between engine control module (ECM) pin 37 (CAN Low wire) and engine control module (ECM) pins 1, 3, 4, 43, and 62 (ground).</p> <p>Is there continuity between CAN circuit and ground circuit?</p>	<p>YES: CAN circuit short to ground.</p> <p>Repair or replace harness. See Cab Harness (W1) Wiring Diagram and see Machine Harness (W2) Wiring Diagram. (Group 9015-10.)</p> <p>NO: Go to ICF Short to Ground Check.</p> <p align="right">-- -1/1</p>
<p>7 ICF Short to Ground Check</p>	<p>Disconnect all connectors to main controller (MCF), information controller (ICF), engine control module (ECM) and monitor controller.</p> <p>Check for continuity between information controller (ICF) pin C5 and pins C14 and C15.</p> <p>Check for continuity between information controller (ICF) pin C11 and pins C14 and C15.</p> <p>Is there continuity between CAN circuit and ground circuit?</p>	<p>YES: CAN circuit short to ground.</p> <p>Repair or replace harness. See Cab Harness (W1) Wiring Diagram. (Group 9015-10.)</p> <p>NO: Go to Monitor Controller Short to Ground Check.</p> <p align="right">-- -1/1</p>
<p>8 Monitor Controller Short to Ground Check</p>	<p>Disconnect all connectors to main controller (MCF), information controller (ICF), engine control module (ECM) and monitor controller.</p> <p>Check for continuity between monitor controller pin B7 and pin B11.</p> <p>Check for continuity between monitor controller pin B6 and pin B11.</p> <p>Is there continuity between CAN circuit and ground circuit?</p>	<p>YES: CAN circuit short to ground.</p> <p>Repair or replace harness. See Cab Harness (W1) Wiring Diagram. (Group 9015-10.)</p> <p>NO: Go to MCF Short to Power Check.</p> <p align="right">-- -1/1</p>
<p>9 MCF Short to Power Check</p>	<p>Disconnect all connectors to main controller (MCF), information controller (ICF), engine control module (ECM) and monitor controller.</p> <p>Check for continuity between main controller (MCF) pin C4 and pins A1, A12, B7, and B17.</p> <p>Check for continuity between main controller (MCF) pin C15 and pins A1, A12, B7, and B17.</p> <p>Is there continuity between CAN circuit and power circuit?</p>	<p>YES: CAN circuit short to power.</p> <p>Repair or replace harness. See Cab Harness (W1) Wiring Diagram. (Group 9015-10.)</p> <p>NO: Go to ECM Short to Power Check.</p> <p align="right">-- -1/1</p>

Main Controller (MCF) Diagnostic Trouble Codes

9001
10
83

<p>18 ECM CAN High and Low Side Continuity Check</p>	<p>Disconnect all connectors to main controller (MCF), information controller (ICF), engine control module (ECM) and monitor controller.</p> <p>Check for continuity between engine control module (ECM) pin 18 (CAN High and Low wires).</p> <p>Is there continuity between CAN high and low side wires?</p>	<p>YES: CAN wires short circuit.</p> <p>Repair or replace harness. See Cab Harness (W1) Wiring Diagram and see Machine Harness (W2) Wiring Diagram. (Group 9015-10.)</p> <p>NO: Go to ICF CAN High and Low Side Continuity Check.</p> <p align="right">-- -1/1</p>
<p>19 ICF CAN High and Low Side Continuity Check</p>	<p>Disconnect all connectors to main controller (MCF), information controller (ICF), engine control module (ECM) and monitor controller.</p> <p>Check for continuity between information controller (ICF) pins C5 and C11.</p> <p>Is there continuity between CAN high and low side wires?</p>	<p>YES: CAN wires short circuit.</p> <p>Repair or replace harness. See Cab Harness (W1) Wiring Diagram. (Group 9015-10.)</p> <p>NO: Go to Monitor Controller CAN High and Low Side Continuity Check.</p> <p align="right">-- -1/1</p>
<p>20 Monitor Controller CAN High and Low Side Continuity Check</p>	<p>Disconnect all connectors to main controller (MCF), information controller (ICF), engine control module (ECM) and monitor controller.</p> <p>Check for continuity between monitor controller pins B6 and B7.</p> <p>Is there continuity between CAN high and low side wires?</p>	<p>YES: CAN wires short circuit.</p> <p>Repair or replace harness. See Cab Harness (W1) Wiring Diagram and see Monitor Harness (W3) Wiring Diagram. (Group 9015-10.)</p> <p>NO: Go to MCF CAN Resistance Check.</p> <p align="right">-- -1/1</p>
<p>21 MCF CAN Resistance Check</p>	<p>Connect all connectors except main controller (MCF) connector C (X30).</p> <p>Check resistance between pin C4 and C15.</p> <p>Is resistance between 50—70 Ω?</p>	<p>YES: Go to DTC Check.</p> <p>NO: Go to ICF CAN Resistance Check.</p> <p align="right">-- -1/1</p>

**11977.03 — Auxiliary Valve 1 Feedback
Current High**

Diagnostic Trouble Code Not Applicable to This Machine.

LD30992,000039B -19-02MAY07-1/1

9001
10
93

**11977.04 — Auxiliary Valve 1 Feedback
Current Low**

Diagnostic Trouble Code Not Applicable to This Machine.

LD30992,000039C -19-02MAY07-1/1

**11980.03 — ATT Relief Change Valve
Feedback Current High**

Diagnostic Trouble Code Not Applicable to This Machine.

LD30992,000039D -19-02MAY07-1/1

**11980.04 — ATT Relief Change Valve
Feedback Current Low**

Diagnostic Trouble Code Not Applicable to This Machine.

LD30992,000039E -19-02MAY07-1/1

Main Controller (MCF) Diagnostic Trouble Codes

9001
10
,103

24 DTC Check	<p>Connect connector to information controller (ICF).</p> <p>Clear diagnostic trouble codes (DTC) and re-check for DTCs.</p> <p>Is DTC 11983.02-Intake Air Temperature Message Error still present?</p>	<p>YES: information controller (ICF) malfunction. Replace. See Information Controller (ICF) Remove and Install. (Group 9015-20.)</p> <p>NO: Check harness connection to information controller (ICF).</p> <p style="text-align: right;">-- -1/1</p>
25 ECM CAN Resistance Check	<p>Connect all connectors except engine control module (ECM) connector.</p> <p>Check resistance between pin 18 (CAN High) and pin 37 (CAN Low) wires in connector.</p> <p>Is resistance between 110—130 Ω?</p>	<p>YES: Go to DTC Check.</p> <p>NO: Go to Monitor Controller CAN Resistance Check.</p> <p style="text-align: right;">-- -1/1</p>
26 DTC Check	<p>Connect connector to engine control module (ECM).</p> <p>Clear diagnostic trouble codes (DTC) and re-check for DTCs.</p> <p>Is DTC 11983.02-Intake Air Temperature Message Error still present?</p>	<p>YES: Engine control module (ECM) malfunction. Replace. See Engine Control Module (ECM) Remove and Install. (Group 9015-20.)</p> <p>NO: Check harness connection to engine control module (ECM).</p> <p style="text-align: right;">-- -1/1</p>
27 Monitor Controller CAN Resistance Check	<p>Connect all connectors except monitor controller connector B (X20).</p> <p>Check resistance between pins B6 and B7.</p> <p>Is resistance between 110—130 Ω?</p>	<p>YES: Go to DTC Check.</p> <p>NO: Malfunction in any controller on CAN.</p> <p style="text-align: right;">-- -1/1</p>
28 DTC Check	<p>Connect connector to monitor controller.</p> <p>Clear diagnostic trouble codes (DTC) and re-check for DTCs.</p> <p>Is DTC 11983.02-Intake Air Temperature Message Error still present?</p>	<p>YES: Monitor controller malfunction. Replace. See Monitor Controller Remove and Install. (Group 9015-20.)</p> <p>NO: Check the connection to monitor controller.</p> <p style="text-align: right;">-- -1/1</p>

11991.03 — Travel Right Pilot Pressure Sensor Circuit Voltage High

LD30992,00003A7 -19-02MAY07-1/1

9001
10
113

Travel Right Pilot Pressure Sensor Diagnostics

Travel right pilot pressure sensor voltage 4.75 volts or higher.

--1/1

<p>1 Sensor Check</p>	<p>Switch travel right pilot pressure sensor with another pilot pressure sensor.</p> <p>Clear diagnostic trouble codes (DTC) and re-check DTCs.</p> <p>Does DTC follow travel right pilot pressure sensor?</p>	<p>YES: Travel right pilot pressure sensor malfunction. Replace sensor.</p> <p>NO: Go to Sensor Circuit Check.</p>
<p>2 Sensor Circuit Check</p>	<p>Disconnect connector of travel right pilot pressure sensor.</p> <p>Check voltage between terminals 1 and 3 of harness.</p> <p>Is voltage between 4.5—5.5 volts?</p> <p><i>NOTE: Key Switch: ON</i></p>	<p>YES: Go to Open Circuit Check.</p> <p>NO: Go to Harness Voltage Check.</p>
<p>3 Open Circuit Check</p>	<p>Disconnect harness from travel right pilot pressure sensor and main controller (MCF).</p> <p>Check continuity between travel right pilot pressure sensor connector pin 2 and main controller (MCF) connector D pin D9.</p> <p>Is there continuity between the pins?</p>	<p>YES: Go to Short Circuit Check.</p> <p>NO: Open circuit in harness.</p> <p>Repair or replace harness. See Cab Harness (W1) Wiring Diagram and see Machine Harness (W2) Wiring Diagram. (Group 9015-10.)</p>

--1/1

--1/1

--1/1

Main Controller (MCF) Diagnostic Trouble Codes

Travel Left Pilot Pressure Sensor Diagnostics

Travel left pilot pressure sensor voltage 0.25 volts or less.

-- -1/1

9001
10
123

<p>1 Sensor Check</p>	<p>Switch travel left pilot pressure sensor with another pilot pressure sensor.</p> <p>Clear diagnostic trouble codes (DTC) and re-check DTCs.</p> <p>Does DTC follow travel left pilot pressure sensor?</p>	<p>YES: Travel left pilot pressure sensor malfunction. Replace sensor.</p> <p>NO: Go to Sensor Circuit Check.</p>
-- -1/1		
<p>2 Sensor Circuit Check</p>	<p>Disconnect connector of travel left pilot pressure sensor.</p> <p>Check voltage between terminals 1 and 3 of harness.</p> <p>Is voltage between 4.5—5.5 volts?</p> <p><i>NOTE: Key Switch: ON</i></p>	<p>YES: Go to Open Circuit Check.</p> <p>NO: Go to Harness Voltage Check.</p>
-- -1/1		
<p>3 Open Circuit Check</p>	<p>Disconnect harness from travel left pilot pressure sensor and main controller (MCF).</p> <p>Check continuity between travel left pilot pressure sensor connector pin 2 and main controller (MCF) connector D pin D14.</p> <p>Is there continuity between the pins?</p>	<p>YES: Go to Short Circuit Check.</p> <p>NO: Open circuit in harness.</p> <p>Repair or replace harness. See Cab Harness (W1) Wiring Diagram and see Machine Harness (W2) Wiring Diagram. (Group 9015-10.)</p>
-- -1/1		

Main Controller (MCF) Diagnostic Trouble Codes

Bucket Dump Pilot Pressure Sensor Diagnostics

Bucket dump pilot pressure sensor voltage 4.75 volts or higher.

-- -1/1

**9001
10
,133**

<p>1 Sensor Check</p>	<p>Switch bucket dump pilot pressure sensor with another pilot pressure sensor.</p> <p>Clear diagnostic trouble codes (DTC) and re-check DTCs.</p> <p>Does DTC follow bucket dump pilot pressure sensor?</p>	<p>YES: Bucket dump pilot pressure sensor malfunction. Replace sensor.</p> <p>NO: Go to Sensor Circuit Check.</p>
-- -1/1		
<p>2 Sensor Circuit Check</p>	<p>Disconnect connector of bucket dump pilot pressure sensor.</p> <p>Check voltage between terminals 1 and 3 of harness.</p> <p>Is voltage between 4.5—5.5 volts?</p> <p><i>NOTE: Key Switch: ON</i></p>	<p>YES: Go to Open Circuit Check.</p> <p>NO: Go to Harness Voltage Check.</p>
-- -1/1		
<p>3 Open Circuit Check</p>	<p>Disconnect harness from bucket dump pilot pressure sensor and main controller (MCF).</p> <p>Check continuity between bucket dump pilot pressure sensor connector pin 2 and main controller (MCF) connector C pin C11.</p> <p>Is there continuity between the pins?</p>	<p>YES: Go to Short Circuit Check.</p> <p>NO: Open circuit in harness.</p> <p>Repair or replace harness. See Cab Harness (W1) Wiring Diagram and see Machine Harness (W2) Wiring Diagram. (Group 9015-10.)</p>
-- -1/1		

Main Controller (MCF) Diagnostic Trouble Codes

Bucket Curl Pilot Pressure Sensor Diagnostics

Bucket curl pilot pressure sensor voltage 0.25 volts or less.

-- -1/1

9001
10
143

<p>1 Sensor Check</p>	<p>Switch bucket curl pilot pressure sensor with another pilot pressure sensor.</p> <p>Clear diagnostic trouble codes (DTC) and re-check DTCs.</p> <p>Does DTC follow bucket curl pilot pressure sensor?</p>	<p>YES: Bucket curl pilot pressure sensor malfunction. Replace sensor.</p> <p>NO: Go to Sensor Circuit Check.</p>
-- -1/1		-- -1/1
<p>2 Sensor Circuit Check</p>	<p>Disconnect connector of bucket curl pilot pressure sensor.</p> <p>Check voltage between terminals 1 and 3 of harness.</p> <p>Is voltage between 4.5—5.5 volts?</p> <p><i>NOTE: Key Switch: ON</i></p>	<p>YES: Go to Open Circuit Check.</p> <p>NO: Go to Harness Voltage Check.</p>
-- -1/1		-- -1/1
<p>3 Open Circuit Check</p>	<p>Disconnect harness from bucket curl pilot pressure sensor and main controller (MCF).</p> <p>Check continuity between bucket curl pilot pressure sensor connector pin 2 and main controller (MCF) connector C pin C2.</p> <p>Is there continuity between the pins?</p>	<p>YES: Go to Short Circuit Check.</p> <p>NO: Open circuit in harness.</p> <p>Repair or replace harness. See Cab Harness (W1) Wiring Diagram and see Machine Harness (W2) Wiring Diagram. (Group 9015-10.)</p>
-- -1/1		-- -1/1

**651.03 — Open Circuit in Injection Nozzle #1
(P0201)**

Injector #1 feedback signal does not exist.

See Tech 2 Diagnostic Trouble Code P0201 in Isuzu Engine Trouble Shooting Manual. (1E-273.)

LD30992,00003D3 -19-02MAY07-1/1

**652.03 — Open Circuit in Injection Nozzle #2
(P0202)**

Injector #2 feedback signal does not exist.

See Tech 2 Diagnostic Trouble Code P0202 in Isuzu Engine Trouble Shooting Manual. (1E-278.)

LD30992,00003D4 -19-02MAY07-1/1

**653.03 — Open Circuit in Injection Nozzle #3
(P0203)**

Injector #3 feedback signal does not exist.

See Tech 2 Diagnostic Trouble Code P0203 in Isuzu Engine Trouble Shooting Manual. (1E-283.)

LD30992,00003D5 -19-02MAY07-1/1

**654.03 — Open Circuit in Injection Nozzle #4
(P0204)**

Injector #4 feedback signal does not exist.

See Tech 2 Diagnostic Trouble Code P0204 in Isuzu Engine Trouble Shooting Manual. (1E-288.)

LD30992,00003D6 -19-02MAY07-1/1

**14100.02 — Satellite Communication
Terminal: Abnormal EEPROM**

NOT APPLICABLE TO THIS MACHINE

LD30992,0000400 -19-02MAY07-1/1

9001
30
3

**14101.02 — Satellite Communication
Terminal: Abnormal IB/OB Queue**

NOT APPLICABLE TO THIS MACHINE

LD30992,0000401 -19-02MAY07-1/1

**14102.02 — Satellite Communication
Terminal: Abnormal Local Loop Back**

NOT APPLICABLE TO THIS MACHINE

LD30992,0000402 -19-02MAY07-1/1

**14103.02 — Satellite Communication
Terminal: The satellite is not found.**

NOT APPLICABLE TO THIS MACHINE

LD30992,0000403 -19-02MAY07-1/1

E43 — Abnormal Damper

Abnormal air conditioner and heater blower port change servomotor or air conditioner and heater rear blower port change servomotor.

LD30992,000048A -19-15MAR06-1/1

Harness Diagnostics

-- -1/1

<p>① Connector Check</p>	<p>Check harness connection to servomotors and air conditioner and heater controller.</p> <p>Are connectors clean and free from debris? Are pins straight and do they make a good connection?</p>	<p>YES: Go to Open Circuit Check.</p> <p>NO: Repair or replace connector or pins.</p> <p>-- -1/1</p>
<p>② Open Circuit Check</p>	<p>Disconnect harness from servomotors and air conditioner and heater controller.</p> <p>Check continuity between pins on controller and servomotor connector.</p> <p>Is there continuity on the appropriate pins?</p> <p>IMPORTANT: Some wires between air conditioner controller and air conditioner servomotor are spliced with other control, power, and ground circuits. Use caution when checking and testing wires.</p>	<p>YES: Air conditioner and heater blower port change servomotor or air conditioner and heater rear blower port change servomotor malfunction.</p> <p>NO: Repair or replace harness. See Air Conditioner Harness (W6) Wiring Diagram. (Group 9015-10.)</p> <p>-- -1/1</p>

E44 — Abnormal Damper

Abnormal air conditioner and heater mixer servomotor.

LD30992,000048B -19-15MAR06-1/1

Monitor Controller (MON) Diagnostic Trouble Codes

<p>11 ICF Short to Power Check</p>	<p>Disconnect all connectors to main controller (MCF), information controller (ICF), engine control module (ECM) and monitor controller.</p> <p>Check for continuity between information controller (ICF) pin C5 and pins C1 and C2.</p> <p>Check for continuity between information controller (ICF) pin C11 and pins C1 and C2.</p> <p>Is there continuity between CAN circuit and power circuit?</p>	<p>YES: CAN circuit short to power.</p> <p>Repair or replace harness. See Cab Harness (W1) Wiring Diagram. (Group 9015-10.)</p> <p>NO: Go to Monitor Controller Short to Power Check.</p> <p align="right">--1/1</p>
<p>12 Monitor Controller Short to Power Check</p>	<p>Disconnect all connectors to main controller (MCF), information controller (ICF), engine control module (ECM) and monitor controller.</p> <p>Check for continuity between monitor controller pin B7 and A16.</p> <p>Check for continuity between monitor controller pin B6 and A16.</p> <p>Is there continuity between CAN circuit and power circuit?</p>	<p>YES: CAN circuit short to power.</p> <p>Repair or replace harness. See Cab Harness (W1) Wiring Diagram and see Monitor Harness (W3) Wiring Diagram. (Group 9015-10.)</p> <p>NO: Go to MCF Short to Key Switch Signal Check.</p> <p align="right">--1/1</p>
<p>13 MCF Short to Key Switch Signal Check</p>	<p>Disconnect all connectors to main controller (MCF), information controller (ICF), engine control module (ECM) and monitor controller.</p> <p>Check for continuity between main controller (MCF) pin C4 and B16.</p> <p>Check for continuity between main controller (MCF) pin C15 and B16.</p> <p>Is there continuity between CAN circuit and key switch signal circuit?</p>	<p>YES: CAN circuit short to key switch signal.</p> <p>Repair or replace harness. See Cab Harness (W1) Wiring Diagram. (Group 9015-10.)</p> <p>NO: Go to ECM Short to Key Switch Signal Check.</p> <p align="right">--1/1</p>
<p>14 ECM Short to Key Switch Signal Check</p>	<p>Disconnect all connectors to main controller (MCF), information controller (ICF), engine control module (ECM) and monitor controller.</p> <p>Check for continuity between engine control module (ECM) pin 18 (CAN High wire) and engine control module (ECM) pin 24 (key switch signal wire).</p> <p>Check for continuity between engine control module (ECM) pin 37 (CAN Low wire) and engine control module (ECM) pin 24 (key switch signal wire).</p> <p>Is there continuity between CAN circuit and key switch signal circuit?</p>	<p>YES: CAN circuit short to key switch signal.</p> <p>Repair or replace harness. See Cab Harness (W1) Wiring Diagram and see Machine Harness (W2) Wiring Diagram. (Group 9015-10.)</p> <p>NO: Go to ICF Short to Key Switch Signal Check.</p> <p align="right">--1/1</p>

9001
50
7

Operational Checkout

This procedure is used to check operation of the machine. It is designed so you can do a walk around inspection, check machine operation, and perform specific checks from the operator's seat.

If there is a problem with the machine, diagnostic information in this checkout will help determine the probable cause. This information may allow you to perform a simple adjustment to correct the problem. Use the table of contents to help find adjustment procedures.

A location will be required which is level and has adequate space to complete the checks. No tools are needed to perform the checkout.

Complete the usual necessary visual checks (oil levels, oil condition, external leaks, loose hardware, linkage, wiring) prior to doing the checkout. The machine must be at operating temperature for many of the checks.

Read each check completely before performing. If no problem is found, you will be instructed to go to the next check. If a problem is indicated, you will be referred to a procedure for adjustment, repair, or replacement.

The monitor can be used to perform diagnostic and operational checks. The monitor can display engine speed, pressures, and Diagnostic Trouble Codes (DTCs).

9005
10
1

MD46667,00000A5 -19-10NOV06-1/1

Diagnostic Trouble Codes Check

-- -1/1

<p>Display and Clear Trouble Diagnostic Codes</p>	<p>Always check for diagnostic trouble codes and correct them before performing the operational checkout.</p> <p>Diagnostic trouble codes can be displayed by using several methods:</p> <ul style="list-style-type: none"> • Monitor Controller • With Service Advisor • With Dr. ZX <p><i>LOOK: Are diagnostic trouble codes present?</i></p>	<p>YES: Correct all diagnostic trouble codes before proceeding.</p> <p>See Reading Diagnostic Trouble Codes With Service ADVISOR™ Diagnostic Application (Group 9015-20.) or see Reading Diagnostic Trouble Codes With Monitor Display (Group 9015-20.) or see Reading Diagnostic Trouble Codes With Dr. ZX. (Group 9015-20.)</p> <p>NO: Proceed with operational checkout.</p>
----------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------


-- -1/1

Operational Checkout Procedure

Reversing Cooling Fan Switch—If Equipped

NOTE: The pilot control shut-off lever must be in the LOCKED (rearward) position, for the reversing cooling fan to operate.

IMPORTANT: Air conditioner may be damaged if the reversing cooling fan switch is pressed when using the air conditioner. Turn air conditioned off while performing this check.



TX1005664 -UN-31MAR06

TX1000874 -UN-01DEC05

- 1—Engine Speed Dial
- 9—Reversing Cooling Fan Switch

Pilot control shut-off lever in the LOCK position.

Turn engine speed dial (1) to H fast idle with auto idle A/I OFF.

Push air conditioner switch OFF.

Press reversing cooling fan switch ON.

LISTEN: Does engine speed go to slow idle? Does fan speed slow down?

LOOK/LISTEN: After approximately 20 seconds, does engine return to fast idle, does the fan speed increase and rotate in reverse direction for approximately one minute?

LISTEN/LOOK: Does engine speed go to slow idle? Does the fan speed slow for approximately 20 seconds? Does fan direction return to normal?

LISTEN: Does engine return to fast idle? Does fan speed increase?

YES: Go to next check.

NO: See Reversing Fan Switch Harness (W16) Wiring Diagram (Group 9015-10.) and see Reversing Fan Switch Harness (W16) Component Location (Group 9015-10.) and see Cab Harness (W1) Wiring Diagram. (Group 9015-10.)

9005
10
11


Swing Priority Circuit Check



CAUTION: Perform check in an open area away from other machinery or personnel.



T6290AF -UN-19OCT88



TX1000170 -UN-10NOV05

- 1—Engine Speed Dial
- 2—Auto-Idle Switch
- 3—Power Mode Switch

Position machine as shown.

Turn engine speed dial (1) to H (fast idle) position.

Turn power mode switch (3) to P (power) mode.

Operate swing function and record time required for three complete revolutions.

Divide that time by three to get an average time for one revolution.

Specification

Swing Function—Time—One Revolution..... 7.93—8.60 seconds

IMPORTANT: Position machine as shown. Operate swing and arm in slowly a few times before attempting to perform check to ensure bucket does not contact machine or ground.

Position machine as shown, arm extended, bucket curled, and upper structure 90 degrees to tracks.

Turn engine speed dial (1) to H (fast idle) position.

Turn power mode switch (3) to P (power) mode.

Raise boom high enough so bucket does not contact the machine or ground during arm in and swing combined operation.

Operate swing function and slowly actuate arm in function when upperstructure is in line with tracks. Record time required for one complete revolution.

NOTE: Swing speed should not slow when actuating arm in.

LOOK: Does swing speed remain unchanged when actuating arm in?

YES: Go to next check.

NO: Check arm 1 flow rate pilot valve. See Diagnose Swing Circuit Malfunctions (Group 9025-15.) and see Pilot Signal Manifold Operation (Group 9025-05.) and see Arm 1 (Swing Priority) Flow Rate Circuit Operation. (Group 9025-05.)

9005
10
21

Section 9010 Engine


Contents

	Page	Page
Group 05—Theory of Operation		
Engine Component Location	9010-05-1	
Engine Sampling Port Location	9010-05-2	
Engine Fuel System Operation	9010-05-4	
Engine Cooling System Operation	9010-05-8	
Engine Lubrication System Operation	9010-05-9	
Engine Intake and Exhaust System Operation	9010-05-12	
Engine Turbocharger Operation	9010-05-13	
Exhaust Gas Recirculation (EGR) Operation	9010-05-16	
Quick On Start (QOS) System Operation	9010-05-18	
Engine Speed Control System Operation	9010-05-19	
Group 15—Diagnostic Information		
Isuzu AH-6WG1XYSA-03	9010-15-1	
Diagnose Engine Malfunctions	9010-15-1	
Engine Cranks But Will Not Start	9010-15-2	
Engine Cranks But Will Not Start Diagnostic Procedure	9010-15-2	
Engine Misfires Or Runs Irregularly	9010-15-5	
Engine Misfires Or Runs Irregularly Diagnostic Procedure	9010-15-5	
Engine Does Not Develop Full Power	9010-15-9	
Engine Does Not Develop Full Power Diagnostic Procedure	9010-15-9	
Engine Overheats	9010-15-12	
Engine Overheats Diagnostics Procedure	9010-15-12	
Auto-Idle Does Not Work	9010-15-13	
Auto-Idle Does Not Work Diagnostics Procedure	9010-15-13	
Coolant Temperature Too Low	9010-15-15	
Coolant Temperature Too Low Diagnostics Procedure	9010-15-15	
Coolant in Oil or Oil in Coolant	9010-15-15	
Coolant in Oil or Oil in Coolant Diagnostics Procedure	9010-15-15	
Low Engine Oil Pressure	9010-15-16	
Low Engine Oil Pressure Diagnostics Procedure	9010-15-16	
High Engine Oil Pressure	9010-15-17	
High Engine Oil Pressure Diagnostics Procedure	9010-15-17	
Engine Uses Too Much Oil	9010-15-17	
Engine Uses Too Much Oil Diagnostics	9010-15-17	
Engine Uses Too Much Fuel	9010-15-18	
Engine Uses Too Much Fuel Diagnostic Procedure	9010-15-18	
Engine Emits Excessive White Exhaust Smoke	9010-15-20	
Engine Emits Excessive White Exhaust Smoke Diagnostic Procedure	9010-15-20	
Engine Emits Excessive Black or Gray Exhaust Smoke	9010-15-22	
Engine Emits Excessive Black or Gray Exhaust Smoke Diagnostic Procedure	9010-15-22	
Turbocharger Excessively Noisy or Vibrates	9010-15-24	
Turbocharger Excessively Noisy or Vibrates Diagnostics Procedure	9010-15-24	
Oil Dripping From Turbocharger Adapter	9010-15-25	
Oil Dripping From Turbocharger Adapter Diagnostics Procedure	9010-15-25	
Excessive Drag in Turbocharger Rotating Members	9010-15-25	
Excessive Drag in Turbocharger Rotating Members Diagnostics Procedure	9010-15-26	
Fuel In Oil	9010-15-26	
Fuel In Oil Diagnostics Procedure	9010-15-26	
Group 25—Tests		
Serpentine Belt Tension Check	9010-25-1	
Check and Adjust Injection Pump Timing	9010-25-2	
Engine Valve Lash (Clearance) Check and Adjust	9010-25-4	
Engine Compression Pressure Test	9010-25-7	
Air Filter Restriction Indicator Switch	9010-25-8	
Air Intake System Leakage Test	9010-25-9	
Engine Power Test Using Turbocharger Boost Pressure	9010-25-11	
Engine Oil Pressure Test	9010-25-15	
Rail Pressure Control Test	9010-25-16	
Injector Balance Test (Injector Misfire Test)	9010-25-19	
Injector Force Drive Test	9010-25-22	
EGR Regulating Valve Test	9010-25-24	
Injector ID Code Registration	9010-25-27	

Continued on next page

9010

Engine Lubrication System Operation



The engine lubrication system consists of a positive displacement gear-driven oil pump, full-flow oil filters, water-cooled oil cooler, oil jets and relief valves. The oil pump pulls oil from the oil pan sump through a strainer and a suction line. The pump forces oil through the outlet tube into a vertical drilling in the cylinder block, and up to the oil cooler and to the remote-mounted filters. After flowing through the cooler and filters, oil flows into the right and left oil galleries and some is routed to the turbocharger.

The right-side oil gallery runs the length of the cylinder block and delivers oil to oil passages that feed the cylinder head, cam journal rocker arm shaft, and main bearing bushings. The left-side oil gallery runs the length of the cylinder block as well as providing oil to oil jets, supply pump, air compressor, idle gears, crank journal, crank pin, and connecting rod. From the main bearings, oil flows to the connecting rod bearings through drilled cross-passages in the crankshaft between the main journals and connecting rod journals.

Oil from the main bearing also supplies oil to the piston cooling orifices. Oil from the piston cooling orifices sprays on the underside of the piston to keep the piston crown cool. The oil spray also provides splash lubrication for the piston pin and bushing by splashing oil into a hole drilled in the top end of the connecting rod. At the rear of the cylinder block, oil flows from the rear camshaft bushing, up through the cylinder head, and into the rocker arm shaft. Oil flows through the rocker arm shaft and lubricates each of the rocker arms. Oil drips from the rocker arms to lubricate the adjusting screws, push rods, and camshaft followers. At the front of the cylinder block, oil flows from the oil passage into a machined groove in the front face of the block. This groove connects with the upper idler gear shaft to provide oil to the idler gear bushing. The lower idler gear bushing is splash lubricated.

Continued on next page

JC89288,000003E -19-30JAN06-1/2

9010
05
9

TX1001650 -19-22DEC05

Engine Speed Control System Operation

Engine Speed Specifications

Item	Measurement	Specification
Engine Speeds 850DLC		
Slow Idle	Speed	885 rpm
Fast Idle—HP Mode	Speed	1650 rpm
Fast Idle—P Mode	Speed	1650 rpm
Fast Idle—E Mode	Speed	1630 rpm
Travel HP	Speed	1750 rpm
Auto Idle	Speed	1030 rpm

9010
05
19

Continued on next page

AH91621,0000297 -19-31JAN06-1/4

Diagnostic Information

<p>6 Injector Check</p>	<p>1. Clear the DTC.</p> <p>For information on how to clear DTC, See Reading Diagnostic Trouble Codes With Tech 2 Diagnostic Scan Tool (9015-20) or See Reading Diagnostic Trouble Codes With Dr. ZX. (9015-20.)</p> <p>2. Start the engine.</p> <p>3. Select the Actuator test from the Tech 2 menu.</p> <p><i>NOTE: If Tech2 scan tool is not available, See Injector Balance Test (Injector Misfire Test). (Group 9010-25.) or Injector Force Drive Test. (Group 9010-25.)</i></p> <p>4. Select the Injection Stop at each injector in the common rail system.</p> <p>5. Press the OFF soft key to stop the fuel injection in the cylinder one by one, and check the change in engine sound.</p> <p>Is there any cylinder of which engine vibration and engine sound did not change when it is stopped?</p>	<p>YES: Replace the injector in the cylinder of which engine sound did not change when it is stopped.</p> <p>NO: Go to Crankshaft Position Sensor Check.</p> <p style="text-align: right;">-- -1/1</p>
<p>7 Crankshaft Position Sensor Check</p>	<p>Check for condition of the crankshaft position sensor.</p> <p>1. Check to see if the sensor is loose. See Engine Component Location. (Group 9010-05.)</p> <p>2. Check the signal detection condition of the crankshaft position sensor.</p> <p style="margin-left: 20px;">a. Connect the Tech 2.</p> <p style="margin-left: 20px;">b. Crank the engine.</p> <p style="margin-left: 20px;">c. Correct the data list on the Tech 2.</p> <p>Is the speed displayed?</p>	<p>YES: Go to Camshaft Position Sensor Check.</p> <p>NO: Repair or replace parts as necessary and retest.</p> <p style="text-align: right;">-- -1/1</p>
<p>8 Camshaft Position Sensor Check</p>	<p>Check for condition of the crankshaft position sensor.</p> <p>1. Check to see if the sensor is loose. See Engine Component Location. (Group 9010-05.)</p> <p>2. Check the signal detection condition of the camshaft position sensor.</p> <p style="margin-left: 20px;">a. Connect the Tech 2.</p> <p style="margin-left: 20px;">b. Start the engine.</p> <p style="margin-left: 20px;">c. Remove the harness from the crankshaft position sensor.</p> <p style="margin-left: 40px;">(The DTC is detected when this procedure is performed. Be sure to clear the DTC after repairing the machine.)</p> <p>Is the speed displayed?</p>	<p>YES: Go to EGR Control System Check.</p> <p>NO: Repair or replace parts as necessary and retest.</p> <p style="text-align: right;">-- -1/1</p>

9010
15
7

Serpentine Belt Tension Check

SPECIFICATIONS

Serpentine Belt Deflection	6-8 mm at 98 N .24-.32 in. at 22 lb-force
----------------------------	----------------------------------------------

SERVICE EQUIPMENT AND TOOLS

JDG529 Belt Tension Gauge


MS12501.000002F -19-24APR06-1/2

1. Check belt regularly for wear. Replace if necessary.
2. Check belt tension with belt deflection gauge at midway between tensioner pulley (6) and alternator pulley (3).

Specification

Serpentine Belt—Deflection 6-8 mm at 98 N
.24-.32 in. at 22 lb-force

3. If deflection is not within specification, loosen alternator lock nut (1) and tensioner pulley lock nut (5).
4. Adjust tensioner pulley adjustment bolt (7) and alternator adjustment bolt (2) until belt tension is within specification.
5. Tighten alternator lock nut (1) and tensioner pulley lock nut (5).



- 1—Lock Nut (alternator)
- 2—Adjustment Bolt (alternator)
- 3—Alternator Pulley
- 4—Bolt (alternator)
- 5—Lock Nut (tensioner pulley)
- 6—Tensioner Pulley
- 7—Adjustment Bolt (tensioner pulley)

9010
25
1

TX1002487 -UN-10JAN06

MS12501.000002F -19-24APR06-2/2

Engine Power Test Using Turbocharger Boost Pressure

SPECIFICATIONS	
Work Mode Switch Position	HP
Engine Rated Speed	1800 RPM
450DLC	
Turbocharger Boost Pressure	128 kPa (1.28 bar) (18 psi) using No. 2 fuel
Turbocharger Boost ^a Pressure	119 kPa (1.19 bar) (17 psi) using No. 1 fuel
650DLC	
Turbocharger Boost Pressure	128 kPa (1.28 bar) (18 psi) using No. 2 fuel
Turbocharger Boost ^a Pressure	119 kPa (1.19 bar) (17 psi) using No. 1 fuel
850DLC	
Turbocharger Boost Pressure	128 kPa (1.28 bar) (18 psi) using No. 2 fuel
Turbocharger Boost ^a Pressure	119 kPa (1.19 bar) (17 psi) using No. 1 fuel
^a Turbocharger boost pressure is reduced by 7% if using No. 1 fuel.	

SERVICE EQUIPMENT AND TOOLS
JT07248 Turbo Boost Test Kit

OTHER MATERIAL
T43512 Thread Lock and Sealer (Medium Strength)
TY9473 Canadian Thread Lock and Sealer (Medium Strength)
242 LOCTITE [®] Thread Lock and Sealer (Medium Strength)

This procedure must only be used as a guide to determine engine condition. One technician can perform this test if the Turbo Boost Test Kit is used.

LOCTITE is a trademark of Loctite Corp.

Continued on next page

JC89288,0000196 -19-24APR06-1/4

9010
25
11

5. Select **F1: Injector Balancing** from Common Rail System Menu.



Common Rail System Menu


TX1006104 -19-07APR06

9010
25
21

JC89288,00001AA -19-24APR06-4/5

6. Send instruction to each injector (set to OFF by soft key on Tech 2) to stop the injector, and check the variation of engine speed.

If engine speed varies when injector stops, electrical circuit of that injector is judged as normal. If engine speed does not vary when injector stops, electrical circuit of that injector or injector body is judged as faulty.



Injector Balancing

TX1006104 -19-10APR06

JC89288,00001AA -19-24APR06-5/5


(Injector ID Code) Cylinder 1 - Cylinder 6 cylinder registration using Tech 2

“Fuel rate adjust, Injector Code Label” is attached to the cylinder head cover. It is used for rewriting and registering the Injector ID Code.

NOTE: Do not enter the six figures “0” indicated with strike through in the illustration, of the ID Code on the Injector ID plate.

The Injector Code information is also on top of the injector. When replacing the injector, register its code.

- 5—Injector ID Plate
- 6—Injector ID Code
- 7—Injector




9010
25
31

JC89288,00001AD -19-24APR06-8/18

7. You need to enter the ID on the following display. ID Code is number of the year. The following conditions must be met. Press the function keys (F0—F9) to enter.

The time setting of the Tech 2 matches the calendar.


Press the function keys (F0—F9) to enter.



Continued on next page

JC89288,00001AD -19-24APR06-9/18

2. Press the softkey Confirm.




TX1006469 -19-19APR06

9010
25
41

JC89288,00001AF -19-20APR06-3/10

As an example, the vehicle will be checked whether it is in the condition engine stopped that the ECM requests during ID Code Registration.

The following display appears while checking if the engine speed is 0 rpm.



TX1006470 -19-19APR06

Continued on next page

JC89288,00001AF -19-20APR06-4/10

1—Continuity Chart
2—Power Wires
3—Routing Location Information

4—Wire Identification
5—Ground Wires
7—Section Number
8—Component Name

9—Component Identification Number
10—Component Schematic Symbol

11—Connector Identification Number
12—Connector
13—Connector Pin Information

System Functional Schematic Diagram

The System Functional Schematic is made up of equal sections to simplify searching the schematic. Each section of the System Functional Schematic is assigned a number (7). The System Functional Schematic is formatted with power supply wires (2) shown near the top of the drawing and ground wires (5) near the bottom. The schematic may contain some harness or connector information.

When connector information is shown, it will be displayed as a double chevron (12) with a component identification number (11) corresponding to the connector identification number. Connector pin information (13) will be displayed in a text size smaller than that of the connector identification number.

Each electrical component is shown by a schematic symbol (10), the component name (8), and a

component identification number (9). A component identification number and name will remain the same throughout the Operation and Test Technical Manual. This will allow for easy cross-referencing of all electrical drawings (Schematics, Wiring Diagrams, and Component Location).

Routing location information (3) is presented to let the reader know when a wire is connected to a component in another section. TO and FROM statements identify when power is going “To” or coming “From” a component in a different location. The section and component identification number are given in the first line of information and any pin information for the component is given in parenthesis in the second line. In this example, power is going TO section 23, component B14 on pin C4.


Continued on next page

LD30992,00002D8 -19-14JAN06-3/9

9015
05
3

Fuse Block 1

- F1—Boom Lights 20 A Fuse (Marked LAMP)
- F2—Windshield Wiper and Washer 10 A Fuse (Marked WIPER)
- F3—Air Conditioner and Heater 20 A Fuse (Marked HEATER)
- F4—Solenoid 10 A Fuse (Marked SOLENOID)
- F5—Travel Alarm 5 A Fuse (Marked OPT. ALT 1)
- F6—Optional Equipment 10 A Fuse (Marked OPT. 2)
- F7—Lubricator 10 A Fuse (Marked LUBRICATOR)
- F8—Engine Control Module (ECM) 30 A Fuse (Marked ECM)
- F9—Radio Backup 5 A Fuse (Marked BACK UP)
- F10—Machine Information Center and Main Controller Batter Power 5 A Fuse (Marked CU)
- F11—Horn 10 A Fuse (Marked HORN)
- F12—Radio and Dome Light 5 A Fuse (Marked ROOM LAMP RADIO)
- F13—Lighter 10 A Fuse (Marked LIGHTER)
- F14—High Pressure Fuel Pump Control Valve 15 A Fuse (Marked PCV)
- F15—Cab Auxiliary Power Connector One 10 A Fuse (Marked AUXILIARY)
- F16—Glow Plug Relay 5 A Fuse (Marked GLOW/RELAY)
- F17—Air Conditioner and Heater 5 A Fuse (Marked AIR CON)
- F18—Controller Key Switch Signal 5 A Fuse (Marked POW ON)
- F19—Controller 5 A Fuse (Marked SW. BOX)
- F20—Optional Equipment 10 A Fuse (Marked (OPT. BATT 3))




TX1000782 -JUN-29NOV05

9015
10
3

Continued on next page

LD30992.000047F -19-31AUG07-2/4



System Diagrams

A3—Main Controller (MCF)	W16—Reversing Fan Switch Harness	X25—Auxiliary Power Connectors	X39—Cab Harness-to-Air Conditioner Harness4-Pin Connector
A5—Information Controller (ICF)	W17—Pilot Shutoff Valve Harness	X26—Optional Connector	X41—Cab Harness-to-Machine Harness 2-Pin Connector
A9—Switch Panel	W35—Cab Harness Ground 1	X27—Cab Harness-to-Switch Panel Connector	X42—Cab Harness-to-Machine Harness 2-Pin Connector 1
B25—Left Speaker	W36—Cab Harness Ground 2	X28—Cab Harness-to-Main Controller 32-Pin Connector	X43—Auxiliary Fuse Box Connector
B26—Right Speaker	W37—Cab Harness Ground 3	X29—Cab Harness-to-Main Controller 25-Pin Connector	X44—Optional Light Connector
E3—Cab Dome Light	W38—Cab Harness Ground 4	X30—Cab Harness-to-Main Controller 31-Pin Connector	X45—Option 2 12-Pin Connector (Not Used)
H2—Security Alarm	X2—Dr. ZX 6-Pin Connector	X31—Cab Harness-to-Main Controller 16-Pin Connector	X47—Cab Harness-to-Air Conditioner Harness 6-Pin Connector
H3—Monitor Warning Alarm	X3—Cab Harness-to-Machine Harness 52-Pin Connector	X32—Cab Harness-to-Information Controller 31-Pin Connector	X71—Cab Harness-to-Auto Lubricator Switch Harness (Not Used)
M5—Windshield Wiper Motor	X4—Cab Harness-to-Machine Harness 32-Pin Connector	X34—Cab Harness-to-Information Controller 17-Pin Connector	X73—Cab Harness-to-Cab Switch Harness Connector
R9—Lighter	X11—Cab Harness-to-Pilot Shutoff Solenoid Valve Harness Connector	X36—Machine Information Center 20-Pin Connector (Not Used)	X74—Cab Harness-to-Travel Alarm Cancel Switch Harness Connector
R15—Engine Speed Dial	X12—Cab Harness-to-Reversing Fan Switch Harness Connector	X37—Machine Information Center 16-Pin Connector (Not Used)	X100—Cab Ground Splice Connector
S2—Cab Dome Light Switch	X17—Cab Harness-to-Auxiliary Fuse Box Harness Connector	X38—Cab Harness-to-Air Conditioner Harness 16-Pin Connector	Y10—Pilot Shutoff Solenoid
S5—Horn Switch	X18—Cab Harness-to-Monitor Harness 4-Pin Connector		
S8—Auto Idle Switch	X22—Cab Harness-to-Monitor Harness 16-Pin Connector (White)		
S9—Windshield Wiper and Washer Switch	X23—Cab Harness-to-Monitor Harness 16-Pin Connector (Black)		
S10—Work Light Switch	X24—Cab Harness-to-Monitor Harness 16-Pin Connector (Brown)		
S11—Travel Speed Switch			
S12—Power Mode Switch			
S13—Travel Alarm Cancel Switch			
S15—Reversing Fan Switch			
S18—Learning Switch			
V3—Load Dump Relay Diode			
V4—Security Diode			
V5—Start Relay Diode			
V6—Auxiliary Power Connector Diode			
V12—Main Controller Pilot Switch Signal Diode			
V13—ECM Power On Signal Diode			
W15—Travel Alarm Cancel Switch Harness			

LD30992,000045A -19-28APR06-2/2

9015
10
23

9015
10
33

System Diagrams

B1—Crankshaft Position Sensor	B60—Exhaust Gas Recirculation (EGR) Position Sensor	X89—Machine Harness-to-Engine Harness 20-Pin Connector (D)	X92—Machine Harness-to-Engine Harness 6-Pin Connector (G)
B2—Camshaft Position Sensor (G Sensor)	M3—Exhaust Gas Recirculation (EGR) Valve Actuator	X90—Machine Harness-to-Engine Harness 12-Pin Connector (E)	X93—Machine Harness-to-Engine Harness 1-Pin Connector (H)
B4—Engine Coolant Temperature Sensor	X57—Engine Harness-to-Glow Plug Bus Bar Connector	X91—Machine Harness-to-Engine Harness 8-Pin Connector (F)	Y15—Fuel Pump Control Valve Solenoid 1
B5—Fuel Temperature Sensor	X58—Engine Harness-to-Injector Harness Connector 1 (Y1, Y2, Y3)		Y16—Fuel Pump Control Valve Solenoid 2
B10—Boost Temperature Sensor	X59—Engine Harness-to-Injector Harness Connector 2 (Y4, Y5, Y6)		
B11—Engine Oil Pressure Sensor			
B12—Fuel Rail Pressure Sensor			
B14—Boost Pressure Sensor			

LD30992,0000460 -19-18APR06-2/2

9015
10
43

System Diagrams

A6—Radio	M7—Air Conditioner and Heater Blower Motor	R17—Blower Motor Resistor	X48—Air Conditioner Harness-to-Air Conditioner and Heater Controller 20-Pin Connector
B20—Air Conditioner High/Low Pressure Switch	M9—Air Conditioner and Heater Internal and External Servomotor	S1—Key Switch	X49—Air Conditioner Harness-to-Air Conditioner and Heater Controller 16-Pin Connector
B41—Air Conditioner Freeze Control Switch	M10—Air Conditioner and Heater Blower Port Change Servomotor	S7—Power Dig Switch	
B42—Cab Air Temperature Sensor	M11—Air Conditioner and Heater Mixer Servomotor	V7—Blower Motor Diode	
B43—Coolant Temperature Sensor	M12—Air Conditioner and Heater Rear Blower Port Change Servomotor	V11—Blower Motor Signal Diode	
K12—Blower Motor Relay		X38—Cab Harness-to-Air Conditioner Harness 16-Pin Connector	
K15—Air Conditioner Compressor Clutch Relay		X39—Cab Harness-to-Air Conditioner Harness 4-Pin Connector	
		X47—Cab Harness-to-Air Conditioner Harness 6-Pin Connector	

LD30992,0000465 -19-20MAR06-2/2

9015
10
53

System Diagrams

A8—12 Volt Power Converter	X44—Optional Light Connector	X63—IMOB I Connector	X67—Warning Lamp Connector
G5—12 Volt Power Outlet	X60—Heated Air Seat Connector	X64—Quick Hitch Connector	X68—Cab Auxiliary Power Connector 2
X17—Cab Harness-to-Auxiliary Fuse Box Harness 4-Pin Connector	X61—Rear Cab Light Connector	X65—Cab Auxiliary Power Connector 3	X69—Front Cab Light 1 Connector
X43—Auxiliary Fuse Box Connector	X62—12 Volt Power Converter Connector	X66—Front Cab Light 2 Connector	

LD30992,000046A -19-26APR06-2/2


9015
10
63

System Diagrams

B13—Radiator Level Switch B22—Ambient Air Temperature Sensor X55—Machine Harness-to-Oil Cooler Harness Connector Y9—Fan Reversing Solenoid 2

LD30992,000047C -19-26APR06-2/2

Oil Cooler Harness (W20) Wiring Diagram



NUMBER	COLOR	END #1	END #2
95	YEL	X55	Y9
96	YEL/BLK	X55	Y9
104	PNK/GRN	X55	B13
256	BLK	X55	B13
588	RED/WHT	X55	B22
597	BLK/RED	X55	B22

Oil Cooler Harness (W20) Wiring Diagram

B13—Radiator Level Switch B22—Ambient Air Temperature Sensor X55—Machine Harness-to-Oil Cooler Harness Connector Y9—Fan Reversing Solenoid 2

LD30992,000047D -19-20MAR06-1/1

9015
10
83

TX1003988 -UN-09MAR06

System Diagrams

F40—JDLINK™ Unswitched
Power 7 Amp Fuse

F41—JDLINK™ Switched Power
3 Amp Fuse

F42—JDLINK™ Alternator Run
Signal 3 Amp Fuse

F43—JDLINK™ Ground 7.5
Amp Fuse

K19—Battery Relay

X140—Power
Harness-to-Machine
Information Gateway
(MIG) Harness 4-Pin
Connector

X149—Power
Harness-to-JDLINK™
Jumper Harness
Connector


JDLINK is a trademark of Deere & Company

AA95137,0000C53 -19-31AUG07-2/2

9015
10
93

Sub-System Diagnostics

TX1001916 -19-25JAN06



TX1001916

Monitor Controller (A4) Circuit (2 of 2)

CS33148.00008EF -19-15MAR06-2/4

NOTE: For information on diagnosing main controller (MCF) circuit malfunctions, see *Main Controller (MCF) Diagnostic Trouble Codes (Group 9001-10.)*

The main controller (MCF) (A3) is the heart of the machine electrical controls. The MCF interfaces directly with inputs (sensors and switches) and outputs (solenoids and an audible alarm). In addition, the MCF communicates information, as needed, with the engine control module (ECM) (A1), information controller (ICF) (A5), and monitor controller (A4). It does this through the CAN data link.

For information on the CAN data link, see *Controller Area Network (CAN) Theory of Operation. (Group 9015-15.)*

For information on the ECM, see *Engine Control Module (ECM) Theory of Operation. (Group 9015-15.)*

For information on the ICF, see *Information Controller (ICF) Theory of Operation. (Group 9015-15.)*

For information on the monitor controller, see *Monitor Controller Theory of Operation. (Group 9015-15.)*

The main controller (MCF) receives inputs from the MCF sensors, switches, etc., then sends the appropriate signals to the MCF outputs (solenoids, travel alarm, and ECM) to control the following major systems:

- Engine Control
- Pump Control
- Valve Control
- Miscellaneous Controls

The main controller inputs:

- A/C Controller (A7)
- Radiator Level Switch (B13)
- Engine Oil Level Switch (B15)
- Swing Pressure Sensor (B33)
- Pump 1 Delivery Pressure Sensor (B35)
- Pump 1 Control Pressure Sensor (B36)

- Pump 2 Delivery Pressure Sensor (B37)
- Pump 2 Control Pressure Sensor (B38)
- Hydraulic Oil Temperature Sensor (B40)
- Attachment Pressure Sensor (B45)
- Counterweight Removal Pressure Sensor (B46)
- Arm Out Pressure Sensor (B50)
- Arm In Pressure Sensor (B51)
- Boom Up Pressure Sensor (B52)
- Boom Down Pressure Sensor (B53)
- Bucket Curl Pressure Sensor (B54)
- Bucket Dump Pressure Sensor (B55)
- Travel Right Pressure Sensor (B56)
- Travel Left Pressure Sensor (B57)
- Boom Pressure Sensor (B58)
- Engine Speed Dial (R15)
- Pilot Shutoff Switch (S3)
- Power Dig Switch (S7)
- Auto-Idle Switch (S8)
- Travel Speed Switch (S11)
- Power Mode Switch (S12)
- Reversing Fan Switch (S15) (Optional)
- Pump Learning Switch (S18)
- Boom Mode Switch (S20)
- Engine Fluid Level Check Switch (S21)

The main controller outputs:

- Travel Alarm (H4)
- Reversing Fan Solenoid (Y8) (optional)
- Reversing Fan Solenoid (Y9) (optional; 850DLC)
- Pump 1 Control Solenoid (Y12)
- Pump 2 Control Solenoid (Y13)
- Boom flow rate solenoid (Y22) (SF)
- Boom mode solenoid (Y23) (SC)
- Power dig solenoid (Y24) (SG)
- Travel speed solenoid (Y25) (SI)

Engine Control—The engine control involves the following functions:

- Engine Speed Dial and ECO Control
- Power Mode Control
- Travel Speed Increase Control
- Auto-Idle Control
- Attachment Operation Speed Control

MCF inputs involved:

- Pump 1 delivery pressure sensor (B35)
- Arm in pressure sensor (B51)
- Boom up pressure sensor (B52)

MCF output involved: Power dig solenoid (Y24)

The auto-power lift control has the following requirements:

- Boom up function operated [pressure detected by boom up pressure sensor (B52) (terminal C13) more than 1700 kPa (17 bar) (247 psi)]
- Arm in function not operated [pressure detected by arm in pressure sensor (B51) (terminal C23) less than 500 kPa (5 bar) (73 psi)]
- High pressure detected by pump 1 delivery pressure sensor (B35) (terminal C3) 29 100 kPa (291 bar) (4220 psi)

Counterweight Removal and Installation Control—Temporarily energizes the power dig solenoid and controls pump delivery flow rate during the counterweight remove and install process.

MCF inputs involved:

- Counterweight removal pressure sensor (B46)
- Pump 1 control pressure sensor (B36)
- Pump 2 control pressure sensor (B38)

MCF outputs involved:

- Power dig solenoid (Y24)
- Pump 1 control solenoid (Y12)
- Pump 2 control solenoid (Y13)

The MCF determines the actual swash plate angle from signals received from pump control pressure sensors (B36 and B38) (terminals D11 and D4). The MCF determines the target swash plate angle from signals received from pump delivery pressure sensors (B35 and B37) (terminals C3 and C12).

The MCF continually compares signals from the pump control pressure sensors to signals from the pump delivery pressure sensors.

When the counterweight control lever is moved to the raise or lower position, counterweight pressure sensor (B46) detects pilot pressure and sends a corresponding signal to terminal D3 on the MCF. When the MCF receives this signal, it activates power dig solenoid (Y24) to increase main relief pressure.

At the same time, the MCF decreases current to pump control solenoids (Y12 and Y13), causing pump displacement (and pump delivery flow rate) to go to minimum.

Travel Speed Solenoid (Y25) (SI): Selects travel mode by changing the swash plate angle on the travel motors.

MCF input involved: Travel speed switch (S11)

MCF output involved: Travel speed solenoid (Y25)

Slow speed— When travel speed switch (S11) is at the LOW (turtle) position, no ground is sent to terminal B21 on the MCF. When the MCF does not detect ground at terminal B21, the MCF de-energizes travel speed solenoid (Y25).

Fast speed— When travel speed switch (S11) is at the HI (rabbit) position, the switch provides a ground to terminal B21 on the MCF. When the MCF detects this ground, it sends current out terminals A11 and A17 to travel speed solenoid (Y25), energizing the solenoid.

For hydraulic information on this circuit, see Travel Motor Speed Circuit Operation. (Group 9025-05.)

Reversing Fan Solenoids (Y8 and Y9): The reversing fan operation requires that the pilot shut off lever be in the rearward (LOCK) position and the air conditioning OFF. The process takes approximately 100 seconds from beginning to end.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

The pilot shutoff circuit enables or disables (unlocks or locks) the pilot oil, thus enabling or disabling the machine hydraulics. The pilot shutoff circuit consists of the following components:

- Pilot shutoff switches 1 and 2 (S3 and S4)
- Pilot shutoff diode (V8)
- Pilot shutoff solenoid (Y10)
- Pilot shutoff solenoid relay (K2)
- Security relay (K5)
- Monitor controller (A4)
- Security diode (V4)
- Engine stop switch (S14)
- Starter relay (K4)
- Starter protection relay (K18)
- Starter relay diode (V5)

When the key switch is turned to the ON or START position, power is available to the following components:

- Coil of pilot shutoff solenoid relay (K2) [from battery relay (K19)]
- Pilot shutoff solenoid (Y10) [from battery relay (K19)]
- Coil of security relay (K5) (from key switch terminal M)

Pilot Shutoff Disabled (Locked)—For the pilot shutoff to be disabled, the pilot shutoff lever must be in the rearward (LOCK) position. When the pilot shutoff lever is at this position, the cam levers of both pilot shutoff switches (S3 and S4) are in the down (released) position and continuity exists across the normally closed contacts connecting the red and black wires of the pilot shutoff switches.

When continuity exists across the normally closed contacts of the pilot shutoff switches, the following occur:

—Terminal B19 of monitor controller (A4) is connected to cab harness ground 4 (W38), through pilot shutoff diode (V8) (terminals 2 and 3) and the normally closed

contacts of both pilot shutoff switches. When ground is present at terminal B19, the monitor controller knows that the pilot shutoff circuit is functioning properly. If ground is not present at terminal B19, the pilot control shutoff lever alarm indicator will appear on the monitor display, alerting the operator that the pilot shutoff circuit is malfunctioning. For information on monitor alarms, see Alarm Occurrence Screen. (Operator's Manual.)

NOTE: The monitor controller must detect a ground at terminal B19 at all times, regardless of position of pilot shutoff lever.

—No ground is present at terminal B12 of the monitor controller. Terminals B2 and B12 are connected inside the monitor controller, so with no ground available at terminal B12, no ground is available to the coil of pilot shutoff solenoid relay (K2). Relay is de-energized. With the pilot shutoff solenoid relay de-energized, no ground is available to pilot shutoff solenoid (Y10). Solenoid is de-energized; pilot hydraulics are disabled.

—No ground is present at terminal C31 of main controller (MCF) (A3). With no ground available at terminal C31, the MCF knows the pilot shutoff is disabled. This input is used by the optional fan reversing circuit. For more information, see Main Controller (MCF) Theory of Operation. (Group 9015-15.)

Pilot Shutoff Enabled (Unlocked)—For the pilot shutoff to be enabled, the pilot shutoff lever must be in the forward (UNLOCK) position. When the pilot shutoff lever is at this position, the cam levers of both pilot shutoff switches (S3 and S4) are pushed up and continuity exists across the normally open contacts (now closed), connecting the white and black wires of the pilot shutoff switches.

When continuity exists across the normally open contacts of the pilot shutoff switches, the following occur:

NOTE: The monitor can display up to 20 diagnostic trouble codes for each controller. The Main Fault Code screen can display 10 diagnostic trouble codes at one time. If the Main Fault Code screen displays 10 codes, use the buttons (1) and (2) to view any additional codes on the next screen.


- View the diagnostic trouble codes for the selected controller.

See Main Controller (MCF) Diagnostic Trouble Codes. (Group 9001-10.)

See Engine Control Unit (ECU) Diagnostic Trouble Codes. (Group 9001-20.)

See Information Controller (ICF) Diagnostic Trouble Codes. (Group 9001-30.) This section includes diagnostic trouble codes displayed for both the Monitor Controller and the Information Controller (ICF).

- Press the back button (12) to return to the Troubleshooting screen and select another controller, or push the Return to Default Screen button (6) to display the default screen.



Main Fault Code Screen

- 1—Button 1
- 2—Button 2
- 6—Return to Default Screen Button
- 12—Back Button

TX1002679 -19-20JAN06


9015
20
5

LD30992.0000218 -19-16MAR06-5/5

Reading Diagnostic Trouble Codes With Monitor Display

- Press and hold the back button (12) and turn key switch to the ON position. This step adds the service menu option to the main menu.
- After the default screen displays, push the menu button (13) to display the main menu.

- 12—Back Button
- 13—Menu Button




Default Screen

TX1002673 -JUN-06SEP06

Continued on next page

LD30992.0000219 -19-16MAR06-1/5

17. The following illustration shows the state in which the Tech 2 is waiting for communication with the machine controller. If **Confirm** is selected with the ignition key in the OFF position this display will stay forever.




TX1004459 -19-09MAR06

9015
20
15

JC89288,00001A1 -19-21APR06-10/13

NOTE: If a mistake was made in the selection of the vehicle type, despite the fact that the communication is enabled, a message to that effect will appear, flashing. If this occurs, check the vehicle type again and redo the connection procedure.

18. Once communication is established, the display will show the **Part No.** and **Diagnostic Data Identification (DDI)** (which varies from system to system). Select **Confirm**.




TX1004460 -19-09MAR06

System Information Screen

Continued on next page

JC89288,00001A1 -19-21APR06-11/13

5. Select the Connect to Model(s) radio button on the Connection Options dialog box, and click OK.



TX1002997A -UN-26JAN06

Connection Options Dialog Box

Continued on next page

LD30992,000021C -19-16MAR06-2/3


9015
20
25

5. Monitor Display will show the status of switches, sensors, and controller signals on the machine. See **Monitor Display** later in this procedure.

Special Function will allow control over some functions of the machine. See **Special Function** later in this procedure.

Setup adjusts parameters of machine operation. See **Setup** later in this procedure.

ESC will return to Dr. ZX start screen.



TX1002951 -19-25JAN06

Main Controller Select Function Screen

LD30992,0000220 -19-25APR06-5/30


1. Monitor Display

After selecting Monitor Display, enter the model and serial number of the machine.

Select OK to continue after entering model and serial number.

ESC will return to Main Controller Select Function Screen.

NOTE: Model and serial numbers are not necessary to proceed. Model and serial numbers will be necessary if a recording is to be taken.



TX1002998 -19-25JAN06


Enter Model and Serial Number Screen

Continued on next page

LD30992,0000220 -19-25APR06-6/30

- a. **ATT Parameter Change**—After selecting ATT Parameter Change, Dr. ZX will display a list of attachments which parameters can be changed. Select an attachment to change the parameters.

ESC will return to Main Controller Parameter Change screen.



Attachment Selection


TX1007023 -19-26APR06

9015
20
45

LD30992,0000220 -19-25APR06-23/30

- b. Each attachment has a list of parameters that may be changed. Select a parameter to change.

ESC will return to Attachment Selection Screen.



Attachment Parameter Change List

TX1007024 -19-26APR06

Continued on next page

LD30992,0000220 -19-25APR06-24/30

6. Once the data has been stored, comments or additional information may be added to the recording.


Select Comment to add a comment to the reading.

ESC will return to the Monitoring Screen.

7. Following the comment screen, Dr. ZX will allow corrections to the comment by selecting Re-Input.

Special Function

Engine Special Function is not available at this time.



TX1002972 -19-25JAN06

Data Bank Comment Screen


LD30992,0000221 -19-25APR06-10/10

Monitor Controller Diagnostics Using Dr. ZX

1. Start Dr. ZX and select Select Controller.

For connection procedure to machine, See Personal Digital Assistant (PDA) Connection to Excavator Using DR. ZX Application. (Group 9015-20.)

NOTE: Screen will display "Communicating" while sending and receiving data.



TX1002912 -19-24JAN06


Function Selection Screen

Continued on next page


LD30992,0000222 -19-26APR06-1/9

9015
20
55

5. When “1Su” and “2Su” are displayed, pump learning procedure is complete. If “1Fa” or “2Fa” is displayed, pump learning procedure has failed. See diagnostic table below.



Pump Learning Success



Pump Learning Failure

TX1007071 -19-27APR06

9015
20
65

TX1007072 -19-27APR06


Continued on next page

LD30992,00004C8 -19-08JUN06-3/4

Information Controller (ICF) Date and Time

1. Start Dr. ZX and select Select Controller.

ESC will return ZX—3 Large Screen.




TX1002912 -19-24JAN06

Function Selection Screen

LD30992,00004C5 -19-08JUN06-1/7

2. Select Information C/U.

ESC will return to Function Selection Screen.



TX1002915 -19-24JAN06

Controller Selection Screen

Continued on next page


LD30992,00004C5 -19-08JUN06-2/7

9015
20
75

References

6. The download screen is displayed while data is transferred.

Cancel will terminate download and return to Information Controller Setup Screen.



Data Download Screen

Continued on next page

LD30992,0000226 -19-08JUN06-6/7

9015
20
85

Pressure Sensor Test

Pressure Sensor Resistance Test

1. A suspect pressure sensor can be checked by switching positions with a known good sensor. If the problem follows the suspect pressure sensor, it has failed.

If the problem remains, the harness has failed.

2. To check a pressure sensor using a multimeter, remove it from the machine.

NOTE: Resistance values for pump 1 delivery pressure sensor (B35) and pump 2 delivery pressure sensor (B37) may vary widely. To verify the sensor's functionality, use the on-board monitor or check for diagnostic trouble codes and to monitor the sensor's output. See Monitor Data Items. (Group 9015-20.) See SERVICE ADVISOR™ Diagnostic Application . (Group 9015-20.) See Dr. ZX Diagnostic Application. (Group 9015-20.)

3. Measure resistance as indicated. Resistance may vary from one sensor to another.

Pressure Sensor Resistance Ranges—Specification

Pump 1 (4-Spool) Control	
Pressure Sensor (B36)—	
Resistance	5k—15k ohms (Pins 1—2) 30k—50k ohms (Pins 2—3)
Pump 2 (5-Spool) Control	
Pressure Sensor (B38)—	
Resistance	5k—15k ohms (Pins 1—2) 30k—50k ohms (Pins 2—3)
Swing Pressure Sensor (B33)—	
Resistance	5k—15k ohms (Pins 1—2) 30k—50k ohms (Pins 2—3)
Counterweight Removal Pressure	
Sensor (B46)—Resistance	
	5k—15k ohms (Pins 1—2) 30k—50k ohms (Pins 2—3)
Arm Out Pressure Sensor	
(B50)—Resistance	
	5k—15k ohms (Pins 1—2) 30k—50k ohms (Pins 2—3)
Arm In Pressure Sensor (B51)—	
Resistance	5k—15k ohms (Pins 1—2) 30k—50k ohms (Pins 2—3)
Boom Up Pressure Sensor	
(B52)—Resistance	
	5k—15k ohms (Pins 1—2) 30k—50k ohms (Pins 2—3)

Continued on next page


LD30992,000022A -19-14MAR06-1/3

References

<p>CAN Bus Terminator Check</p>	<p>Turn key switch (S1) OFF.</p> <p>Disconnect harness from CAN bus terminator. See Engine Interface Harness (W6) Component Location. (Group 9015-10.)</p>  <p>T140697B -UN-29MAR01</p> <p>Measure resistance across terminator pins.</p> <p><i>LOOK: Does the multimeter read 105—135 ohms?</i></p>	<p>YES: CAN bus terminator is OK.</p> <p>NO: CAN bus terminator has failed. Replace the CAN bus terminator.</p>
----------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------

9015
20
,105

--1/1


<p>Pilot Shutoff Switch Harness Check</p>	<p>Disconnect harness from cab.</p> <p>Remove diode from harness.</p> <p>With the positive lead on the center terminal of the diode, there should be continuity when you probe the two outer terminals with the negative lead.</p> <p>Switch the leads and put the negative lead on the center terminal, there should not be continuity when you probe the two outer terminals with the positive lead.</p> <p>Is there continuity one way and not the other?</p>	<p>YES: Diode is good, reinstall the diode into the harness.</p> <p>Continue checkout.</p> <p>NO: Replace the diode.</p>
	 <p>TX1005243A -UN-28MAR06 <i>Pilot Shutoff Switch Connector</i></p> <p>1—Blue Wire 2—Red Wire</p> <p>With the positive lead on the red wire (2), and the negative lead on the blue wire (1), check for continuity with the pilot shutoff switch handle in the forward position. Bring the handle back to the rearward position, and check for continuity.</p> <p>Is there continuity with the handle in the forward position and not in the rearward position?</p>	<p>YES: Harness is good.</p> <p>NO: Replace the pilot shutoff switch harness.</p>

--1/1

Switch Panel Remove and Install

1. Lift pilot control lever boot (2) and remove screws and spacers (3).
2. Pull up pilot control lever boot and console cover.

- 1—Switch Panel
- 2—Pilot Control Lever Boot
- 3—Screw and Spacer (4 used)
- 4—Console Cover



Pilot Control Lever Boot

TX1005211A -UN-27MAR06

LD30992,0000493 -19-23MAR06-1/3

3. Remove plugs and screws (5) and remove cap screws (6).
4. Pull switch panel assembly forward and gently tilt back. Disconnect harness connector to key switch.

- 5—Plug and Screw (2 used)
- 6—Cap Screw (2 used)



Switch Panel Cap Screws

TX1005212A -UN-27MAR06

9015
20
,115

Continued on next page

LD30992,0000493 -19-23MAR06-2/3

Replace (Push Type) Metri-Pack™ Connectors

Disconnect the Metri-Pack¹ connector. Remove the tie bands and tape.

Remove the connector lock (A), and mark wire colors for identification.

Identify wire color locations with connector terminal letters.


Insert JDG776 or JDG777² Terminal Extraction Tool (B) into connector body socket (C) pushing the terminal locking tab inward.

NOTE: Use JDG776 Extraction Tool with 56, 280 and 630 series METRI-PACK terminals. Use JDG777 Extraction Tool with 150 series METRI-PACK terminals.

Remove extraction tool and pull terminal (D) out of the socket.

Replace terminal. Make sure locking tab (E) on the new terminal is in the outward position.

Push terminal into connector body socket until terminal locks.



A—Connector Lock
B—Extraction Tool JDG777
C—Connector Body Socket
D—Terminal
E—Locking Tab


RW21325 -UN-29JUN92

9015
20
,125

¹Metri-Pack is a trademark of Packard Electric

²Included in JT07195A Electrical Repair Kit

Track Adjuster and Recoil Spring Operation



- | | | | |
|-------------------------|---------------|-----------------|-------------------------------------|
| 1—Grease Fitting | 4—Cylinder | 7—Piston | 10—Track Adjuster and Recoil Spring |
| 2—Valve | 5—Yoke | 8—Recoil Spring | |
| 3—Grease Relief Passage | 6—Front Idler | 9—Grease | |

The track adjuster and recoil spring (10) is supported by the track frame. Shock loads on the track and front idler (6) are absorbed by the recoil spring (8).

To decrease track sag, grease (9) is pumped into the cylinder (4) through the grease fitting (1). The grease pushes the piston (7) against the yoke moving the

front idler out, reducing track sag. The grease fitting (1) is protected from excess pressure by a check ball.

Increasing track sag is accomplished by loosening the valve (2) to release grease from the cylinder through the grease relief passage (3). When releasing grease from the cylinder, only loosen the valve (2).

T140036 -19-17MA Y01

9020
05
1

MR50960,0000FF -19-27APR06-1/1

CAUTION: Stay clear of moving parts. Position dial indicator so it can be seen while the operator can see you.

NOTE: Two people are needed to take the measurement. One to operate the machine and one to take the readings.




1. Check that swing bearing-to-main frame cap screws are tightened to specification. See Upperstructure Remove and Install. (Group 4350.)
2. Check that swing bearing is lubricated with the specified grease. See Track Adjuster, Working Tool Pivot, Swing Bearing, And Swing Bearing Gear Grease. (Operator's Manual.)
3. Check that bearing rotation is smooth and without noise.

NOTE: Readings vary depending on the location of dial indicator base with respect to the swing bearing support tower. To obtain an accurate reading, the base for dial indicator must be attached to the support tower or as close to it as possible.

4. Install dial indicator with needle point contacting bottom face of bearing outer race and base attached to the swing bearing support tower or as close to it as possible.
5. Move boom and arm to the position shown with bucket off the ground. Bucket must be empty.
6. Turn dial indicator to zero.
7. Lower the boom to raise front idlers off the ground approximately 500 mm (20 in.).
8. Record dial indicator reading.

Swing Bearing—Specification

Swing Bearing—Play.....	0.4—1.6 mm new
	0.016.—0.063 in. new
	3.6—4.8 mm maximum allowable
	0.142—0.189 in. maximum allowable



T140090 -UN-17MAY01

9020
15
7

T7886AJ -UN-23NOV92

17—Pump 1 Regulator	81—Accumulator	110—Bypass Shutoff Valve (4-spool)	Y12—Pump 1 Control Solenoid Valve
18—Pump 2 Regulator	82—Pilot Check Valve Manifold	121—Arm Reduced Leakage Valve—Switch Valve	Y13—Pump 2 Control Solenoid Valve
27—Pilot Pump	83—Right Control Valve	129—Boom Mode Relief Control Valve	Y14—Fan Drive Pump Solenoid Valve
29—Fan Drive Pump Regulator	84—Left Control Valve	149—Swing Motor	Y22—Boom Flow Rate Solenoid Valve (SF)
47—Hydraulic Oil Tank	85—Main Relief and Power Digging Valve	154—Swing Park Brake Release	Y23—Boom Mode Relief Solenoid Valve (SC)
50—Suction Screen	89—Travel Flow Combiner Valve	157—Left Travel Motor	Y24—Power Dig Solenoid Valve (SG)
52—Pilot Filter Element	97—Boom Flow Rate Control Valve—Switch Valve	159—Right Travel Motor	Y25—Travel Speed Solenoid Valve (SI)
54—Pilot Pressure Regulating Valve	102—Boom Reduced Leakage Valve—Switch Valve	190—To Control Valve Pilot Caps	
55—Solenoid Valve Manifold	105—Arm 2 Flow Rate Control Valve—Switch Valve	Y10—Pilot Shutoff Solenoid Valve	
56—Travel Pilot Control Valve			
57—Left Pilot Control Valve			
58—Right Pilot Control Valve			
59—Boom Up Shockless Valve			
66—Pilot Signal Manifold			

The pilot system is used to operate the control circuits of the machine. The pilot pump (27) is mounted on the end of the fan drive pump. Oil is drawn into the pilot pump from the hydraulic tank (47) and out to the pilot filter (52) and pilot pressure regulating valve (54).

The filtered oil then flows to the fan drive pump solenoid (Y14), fan drive pump regulator (29), pump 1 regulator (17), pump 2 regulator (18), pump 1 control solenoid valve (Y12), and pump 2 control solenoid valve (Y13).


From the filter, oil is also routed to the solenoid valve manifold (55), which controls power dig (SG), travel speed (SI), boom flow rate (SF), and boom mode relief (SC). Pilot oil is routed directly to the control valve to facilitate the functioning of the arm reduced leakage

valve (121) and the boom reduced leakage valve (102).

The pilot oil continues on to the pilot check valve manifold (82), where it is divided off to the accumulator (81), the pilot signal manifold (66), and the pilot shutoff solenoid valve (Y10). From the pilot shutoff solenoid valve, pilot oil flows to the travel pilot control valve (56), left pilot control valve (57), right pilot control valve (58), and to the pilot signal manifold's warm-up circuit.

Pilot oil from the right pilot control valve flows through the boom up shockless valve (59) to the pilot signal manifold. Pilot oil from the pilot signal manifold flows to the swing park brake release (154) of the swing motor (149) and to the control valve pilot caps (190).

Pilot Signal Manifold Operation



- 1, A—Boom Up
- 2, B—Boom Down
- 3, C—Arm Out
- 4, D—Arm In
- 5, E—Swing Left
- 6, F—Swing Right
- 7, G—Bucket Curl
- 8, H—Bucket Dump
- 9, I—Left Travel Forward
- 10, J—Left Travel Reverse
- 11, K—Right Travel Forward
- 12, L—Right Travel Reverse
- 13, M—Plug (auxiliary)
- 14, N—Plug (auxiliary)
- 15—Control Valve Side of Pilot Signal Manifold

- 16—Pilot Control Valve Side of Pilot Signal Manifold
- 67—Boom Down Shockless Valve
- 69—Orifice
- 70—Pilot Valve (port SE) (not used, plug installed)
- 71—Arm 2 Flow Rate Pilot Valve (port SK)
- 72—Pump 1 Flow Rate Pilot Valve (port SA) (not used, plug installed)
- 73—Pump 2 Flow Rate Pilot Valve (port SB) (not used, plug installed)
- 74—Swing Park Brake Release Pilot Valve (port SH)

- 75—Travel Flow Combiner Pilot Valve (port SL)
- DF—To Hydraulic Oil Tank
- TR—B56 and B57 Travel Pressure Sensor
- S3—B33 Swing Pressure Sensor
- SA—From Pump 1 Flow Rate Pilot Valve Remote Control Spool (not used, plug installed)
- SB—From Pump 2 Flow Rate Pilot Valve Remote Control Spool (not used, plug installed)
- SE—To Pilot Valve (port SE) (not used, plug installed)

- SH—To Swing Park Brake (port SH)
- SK—To Arm Flow Rate Control Valve—Switch Valve
- SL—To Travel Flow Combiner Valve
- SM—To Hydraulic Oil Tank
- SN—Plug (not used)
- SP—To Solenoid Valve Manifold (port SP)
- PH—From Pilot Shutoff Solenoid Valve
- PI—From Pilot Check Valve Manifold

Continued on next page

MM61211,0001519 -19-25APR06-1/10

TX1005673 -UN-25APR06

9025
05
15

9025
05
25

Theory of Operation

15—Pump 1
19—Servo Piston
20—Load Sleeve
21—Load Spool
22—Feedback Link

23—Check Valve
24—Check Valve
25—Pilot Piston
27—Pilot Pump
83—To Right Control Valve

180—Supply Oil
182—Pilot Oil
184—Return Oil
200—Spring
201—Pivot Pin

202—Large Chamber
203—Small Chamber
Y12—Pump 1 Control Solenoid Valve

Operation of pump 1 regulator and pump 2 regulator is the same. Pump 1 regulator is discussed throughout.

The pump regulators are located at the top of each pump and are responsible for the control of the pump delivery flow rate. The pump control solenoid valve (Y12) regulates the pilot control pressure according to signals received from the main controller (MCF). As pilot control pressure increases, the pump delivery flow rate increases. For more information on the MCF and the pump control circuit, see Main Controller (MCF) Circuit Theory of Operation. (Group 9015-15.)

Supply oil (180) is routed through check valve (23) to load spool (21) and to the small chamber (203) of the servo piston (19).

Pilot oil (182) from the pump control solenoid valve acts on the pilot piston (25), moving the load spool back and forth against the spring (200). Pilot oil can also be combined with the supply oil through check

valve (24) if the supply oil pressure becomes lower than the pilot oil pressure.

Regulator Operation at Minimum Flow Rate—With pump 1 control solenoid valve open to the tank, the load spool is shifted to the left by the spring. With the spool in this position, supply oil is routed to the large chamber (202) of the servo piston. With supply oil at both ends of the servo piston, the servo piston will move to the right, due to the difference in surface areas on either end.

When the servo piston moves to the right, the feedback link (22) will rotate counterclockwise, moving the load sleeve (20) to the left. The servo piston will continue to move to the right until the oil passages on the load sleeve and load spool are completely closed. With the servo piston in this position, the pump swash plate is moved to minimum displacement; thus the pump will deliver minimum flow rate.

Continued on next page

LD30992,0000258 -19-11APR06-2/4

9025
05
35

27—Pilot Pump
 28—Fan Drive Pump
 30—Servo Piston
 31—Feedback Link
 32—Load Sleeve
 33—Load Spool
 34—Pilot Piston
 35—Compensating Piston

36—To Fan Drive Motor
 200—Lever
 201—Pin
 202—Pin
 203—Pin
 204—Hole
 205—Inner Spring
 206—Small Chamber

207—Outer Spring
 208—Compensating Rod
 209—Pin
 210—Pin
 211—Large Chamber
 212—Lever
 213—Pin
 214—Hole

215—Spring
 216—Pin
 217—Solenoid Valve Spool
 218—Supply Oil
 219—Pilot Oil
 Y14—Pump Control Solenoid Valve

Regulator Control by Fan Drive Pump Delivery Pressure (Decreasing Flow Rate)—The regulator controls the fan drive pump in this manner if engine speed (fan drive pump speed) increases beyond the rated speed during startup. When fan drive pump delivery pressure increases beyond the force of the inner spring (205) and the outer spring (207), the compensating piston (35) will move the compensating rod (208) to the right, in turn moving the lever (200) to the right (counterclockwise), around the pin (201), which is fixed to the housing.

The pin (203), which is attached to the feedback link (31), pulls the feedback link and the load spool (33) to the right, as the feedback link pivots clockwise around the pin (210).

With the load spool in this position, supply oil (218) is routed to the large chamber (211) of the servo piston (30). With supply oil being routed to both ends of the servo piston, the servo piston will move to the right, due to the larger surface area of the large chamber side. When the servo piston moves to the right, the feedback link (31) will rotate counterclockwise around the pin (203), moving the load spool (33) to the left.

The servo piston will continue to move to the right until the oil passages on the load spool and the load sleeve (32) are completely closed. With the servo piston in this position, the pump swash plate will move to minimum displacement, decreasing the flow rate of the pump.

Continued on next page



OUT3035.000001D -19-27APR06-7/9

9025
 05
 45

Theory of Operation

- | | | | |
|---------------------------------------------------------------|----------------------------------------------------------------|----------------------------------------------------------|---------------------------------------------------------------|
| 87—Main Relief Valve Isolation Check Valve (5-spool) | 117—Neutral Passage Check Valve (arm 1 in function lift check) | 128—Boom Mode Relief Valve | 145—Left Travel and Bucket Flow Combining Circuit Check Valve |
| 112—Neutral Passage Check Valve (swing lift check) | 122—Arm In Circuit Relief and Anticavitation Valve | 129—Boom Mode Relief Control Valve | 146—Bypass Shutoff (Bucket Flow Combiner) Valve (5-spool) |
| 115—Power Passage Check Valve (arm 1 in function lift check) | 123—Arm Out Circuit Relief and Anticavitation Valve | 133—Check Valve (lift check) | |
| 116—Power Passage Check Valve (arm 1 out function lift check) | 124—Neutral Passage Check Valve (boom 2 lift check) | 138—Auxiliary Circuit Relief and Anticavitation Valve | |
| | | 139—Auxiliary Circuit Relief and Anticavitation Valve | |
| | | 141—Neutral Passage Check Valve (left travel lift check) | |

MM61211.0001522 -19-26APR06-4/15



TX1006458

4 and 5-Spool Cross Section


- | | | | |
|----------------------------------------|-------------------------------|-------------------------------|------------------------------|
| 85—Main Relief and Power Digging Valve | 172—Bucket Regenerative Valve | 173—Boom 2 Regenerative Valve | 174—Arm 1 Regenerative Valve |
| 89—Travel Flow Combiner Valve | | | |

Continued on next page

MM61211.0001522 -19-26APR06-5/15

9025
05
55
TX1006458 -UN-17APR06

9025
05
65



TX1006229

Power Dig Solenoid Valve SG Operation

- | | | | |
|--------------------------------|----------------------------------------------------|--------------------------|----------------------|
| 21—Pilot Oil | 33—Flange on the Right Is Larger | 35—Valve Function Port | 37—Valve Spool |
| 22—Return Oil | 34—From Pilot Filter and Pressure Regulating Valve | 36—To Hydraulic Oil Tank | 38—Reduced Pilot Oil |
| 27—Power Dig Solenoid Valve SG | | | |

Power Dig Solenoid Valve SG Operation—The power dig solenoid valve SG (27) is a proportional solenoid valve type. The solenoid valve is activated by an electrical signal from the MCF.

When de-energized, the spool (37) is pushed to the right by a spring. The valve function port (35) is then connected to the hydraulic oil tank (36).

When energized, the magnetic force shifts the spool left against the spring. Pilot oil (21) flows past the spool flange and out the valve function port as reduced

pilot oil (38) to the main relief and power dig valve. Because the flange on the right is larger (33) than the flange on the left, the spool is pushed to the right against the magnetic force as the electrical signal to the solenoid increases. When the reduced pilot oil pressure becomes equal to or greater than the magnetic force, the spool is pushed to the right, closing the passage. The spool is moving constantly to maintain the reduced pilot oil pressure to the main relief and power dig valve in response to the electrical signal to the solenoid.

TX1006229 -JUN-12APR06


9025
05
75

LD30992,000025C -19-13APR06-6/6


Bucket Regenerative Valve Circuit Operation

During bucket digging operation, return oil (184) from the bucket cylinder (170) flows to the hydraulic oil tank (47). Return oil (184) from the bucket cylinder (170) enters the spool (94) and acts on the bucket regenerative check valve (172) inside the spool (94). When digging operation is done with the bucket rolled-out, the bucket moves faster as compared with supply oil (180) from the pump (15). Therefore, pressure in the circuit between pump (15) and bottom of the bucket cylinder (170) decreases. When pressure in the bottom of bucket cylinder becomes lower than that of the top side, the bucket regenerative check valve (172) opens. Therefore, regenerative return oil (185) from the top of the bucket cylinder (170) flows to the bottom side of the bucket cylinder and is combined with supply oil (180) from the pump (15). Consequently, the regenerative operation is done and speed of the cylinder increases.

- 15—From Pump 1
- 47—Hydraulic Oil Tank
- 91—Bucket Regenerative Switch Valve
- 93—Power Passage Check Valve (bucket lift check)
- 94—Bucket Spool
- 170—Bucket Cylinder
- 172—Bucket Regenerative Valve
- 180—Supply Oil
- 182—Pilot Oil
- 184—Return or Pressure-Free Oil
- 185—Regenerative Return Oil



TX1006656 -19-19APR06




During Regenerative Operation

Continued on next page

LD30992,0000261 -19-26APR06-1/2

9025
05
85

TX1006681 -UN-20APR06



T216853

Boom Flow Rate Solenoid Valve, (port SF)

- | | | | |
|----------------------------------------------|-------------------------------------------|----------------------------------------------|----------------------|
| Y22—Boom Flow Rate Solenoid Valve, (port SF) | Y25—Travel Speed Solenoid Valve (port SI) | 20—Boom Flow Rate Control Valve—Switch Valve | 24—Pilot Oil |
| Y23—Boom Mode Solenoid Valve (port SC) | 16—Solenoid Coil | 21—To Hydraulic Oil Tank | 25—Reduced Pilot Oil |
| Y24—Power Digging Solenoid Valve (port SG) | 17—Adjusting Screw | 22—Spool | 26—Return Oil |
| | 18—Nut | 23—Pressure Equals Magnetic Force | |
| | 19—From Pilot Shutoff Solenoid Valve | | |

Boom Flow Rate Solenoid Valve, (port SF)

Operation— Boom flow rate solenoid valve (Y22) is a proportional solenoid valve type. The solenoid valve is activated by an electrical signal from the main controller (MCF). The electrical signal is DC voltage that is turned on and off to form a pulse-width modulated signal. Solenoid coil (16) reacts to the average voltage to create a magnetic force to shift the spool (22) left against a spring. When shifted left,

reduced pilot oil (25) is sent to the boom flow rate control valve—switch valve (20). The pressure of reduced pilot oil is in proportion to the electrical signal to the solenoid coil.


De-energized—When de-energized, the spool is pushed to the right by a spring. The boom flow rate control valve—switch valve is then connected to the hydraulic oil tank (21) through the spool.

Continued on next page

LD30992,0000263 -19-26APR06-6/7

T216853 -JUN-06FEB06

9025
05
95



TX1006977

Travel Motor and Park Brake Valve Assembly

1—Travel Speed Change Selector Valve

2—Crossover Relief Valve

3—Check Valve

4—Counterbalance Valve

Travel Motor and Park Brake Valve Assembly

Components—The travel brake valve is located on the travel motor head and consists of the following valves. Crossover relief valve (2) which prevents the occurrence of overload and surge pressure in the motor circuit. The counterbalance valve (4) makes starting and stopping travel operations smooth and

prevents the machine from running away while descending slopes. Check Valve (3) will assist the counterbalance valve operation and prevents cavitation in the motor circuit. And the travel speed change selector valve (1) which controls the tilt piston when selecting travel mode.

TX1006977 -JUN-25APR06

9025
05
,105

LD30992,0000269 -19-25APR06-2/2

Diagnostic Information

<p>5 Main Relief Valve Check</p>	<p>Key on, use monitor service menu to display Pump 1 and Pump 2 Delivery Pressure.</p> <p>See Monitor Service Menu Operation. (Group 9015-16.)</p> <p><i>NOTE: To test with remote gauge, Perform Main Relief and Power Digging Valve Test and Adjustment. (Group 9025-25.)</i></p> <p>Set power mode at HP.</p> <p>Run engine at fast idle and operate boom raise function.</p> <p>Observe pump 1 and 2 delivery pressure when boom raise is held over relief.</p> <p>Are both pumps delivery pressure in 30.4—32.9 MPa range?</p>	<p>YES: Go to Cycle Time Check.</p> <p>NO: Adjust or replace main relief and power digging valve.</p> <p>Perform Main Relief and Power Digging Valve Test and Adjustment. (Group 9025-25.)</p> <p style="text-align: right;">-- -1/1</p>
<p>6 Cycle Time Check</p>	<p>Perform Cycle Times Check. (Group 9005-10.)</p> <p>Check travel cycle times.</p> <p>Are travel cycle times at specifications?</p>	<p>YES: Diagnostic procedure complete.</p> <p>NO: Go to Restricted Hydraulic Oil Tank Suction Screen Check.</p> <p style="text-align: right;">-- -1/1</p>
<p>7 Restricted Hydraulic Oil Tank Suction Screen Check</p>	<p>Inspect hydraulic oil tank suction screen.</p> <p>See Change Hydraulic Tank Oil, Clean Suction Screen. (Operator's Manual.)</p> <p>Is hydraulic oil tank suction screen free of restriction?</p>	<p>YES: Go to Hydraulic Pump Check.</p> <p>NO: Clean or replace hydraulic oil tank suction screen.</p> <p style="text-align: right;">-- -1/1</p>
<p>8 Hydraulic Pump Check</p>	<p>Perform Pump Flow Test. (Group 9025-25.)</p> <p>Check pump flow.</p> <p>Does pump flow meet specification?</p>	<p>YES: Go to Wiring Connector Check.</p> <p>NO: Repair or replace pump.</p> <p>See Pump Remove and Install. (Group 3360.)</p> <p style="text-align: right;">-- -1/1</p>
<p>9 Wiring Connector Check</p>	<p>See Pilot Shutoff Switch Harness (W11) Component Location. (Group 9015-10.)</p> <p>Inspect hydraulic control wiring.</p> <p><i>NOTE: Most wiring problems should generate a DTC, check for DTC's before tracing wiring.</i></p> <p>Are all the connectors in good condition?</p>	<p>YES: Diagnostic procedure complete.</p> <p>NO: Repair or replace connectors.</p> <p style="text-align: right;">-- -1/1</p>

9025
15
5

All Functions Slow Diagnostic Procedure

-- 1/1


<p>1 Restricted Pilot Filter Check</p>	<p>Inspect pilot filter.</p> <p>Is pilot filter free of restriction?</p>	<p>YES: Go to Actuating Pilot Pressure Check.</p> <p>NO: Replace pilot filter.</p> <p>See Replace Pilot System Oil Filter. (Operator's Manual.)</p>
<p>2 Actuating Pilot Pressure Check</p>	<p>Key on, use monitor service menu to display Swing / Attachment Control Pilot Pressure.</p> <p>See Monitor Service Menu Operation. (Group 9015-16.)</p> <p><i>NOTE: Spool actuating pressure can be checked for each function by installing a tee and gauge in pilot line and then actuating that function. Perform Control Valve Spool Actuating Pilot Pressure Test. (Group 9025-25.)</i></p> <p>Run engine at fast idle and operate problem function.</p> <p>Observe pressure when function held over relief.</p> <p>Is pilot pressure above 3.70 MPa?</p>	<p>YES: Go to Pilot Shutoff Solenoid Valve Check.</p> <p>NO: Adjust, repair or replace pilot pressure regulating valve.</p> <p>See Pilot Pressure Regulating Valve Test and Adjustment. (Group 9025-25.)</p> <p>NO: Pilot pump worn. Inspect, repair or replace pilot pump.</p> <p>See Pilot Pump Remove and Install. (Group 3360.)</p>
<p>3 Pilot Shutoff Solenoid Valve Check</p>	<p>Inspect pilot shutoff solenoid valve for restriction.</p> <p>Is pilot shutoff solenoid valve free of restriction?</p>	<p>YES: Diagnostic procedure complete.</p> <p>NO: Repair or replace pilot shutoff solenoid valve.</p> <p>See Pilot Shutoff Solenoid Valve Disassemble and Assemble. (Group 3360.)</p>

9025
15
15

-- 1/1

-- 1/1

④ **Boom Circuit Leakage Check**



TX1006310 -UN-12APR06

Leakage Test Position

Position bucket and arm as shown with bucket cylinder fully retracted.

1. Relieve hydraulic pressure from boom circuit.
2. Remove rod end hoses from both boom cylinders.
3. Drain oil from hoses and cap hose ends with high pressure plugs.
4. Leave cylinder rod end ports open and place container under them to catch any excess oil.
5. Start engine and slowly retract arm cylinder so bucket is approximately 300 mm (12 in.) off ground

Does oil leak out of rod end of boom cylinder?

YES: Repair boom cylinder piston seals.

NO: If boom lowers and no oil leaks out of rod end ports, the control valve is leaking. Inspect and repair control valve spool. Look for broken spring or loose spool end.

--1/1

Load Drifts Down When Control Valve Is In Neutral Position Diagnostic Procedure

9025
15
25

--1/1

Diagnostic Information

<p>5 Circuit Relief Valve Check</p>	<p>Perform Circuit Relief Valve Test and Adjustment. (Group 9025-25.)</p> <p>Check swing relief pressure.</p> <p>Do circuit relief valves meet test specifications?</p>	<p>YES: Go to Swing Motor Case Drain Check.</p> <p>NO: Adjust or repair circuit relief.</p> <p style="text-align: right;">-- -1/1</p>
--------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------

<p>6 Swing Motor Case Drain Check</p>	<p>Perform Swing Motor Leakage Test. (Group 9025-25.)</p> <p>Check if swing case drain leakage is normal.</p> <p>Does case drain leakage meet specification?</p>	<p>YES: Remove and repair motor.</p> <p>NO: Inspect swing reduction gear.</p> <p>See Swing Gearbox Disassemble and Assemble. (Group 4350.)</p> <p style="text-align: right;">-- -1/1</p>
----------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<p>7 Control Valve Check</p>	<p>See Control Valve Operation. (Group 9025-05.)</p> <p>Inspect control valve for sticking spool. For component location.</p> <p>Does control valve spool move freely?</p>	<p>YES: Diagnostic procedure complete.</p> <p>NO: Repair or replace control valve components as necessary.</p> <p>See Control Valve Disassemble and Assemble. (Group 3360.)</p> <p style="text-align: right;">-- -1/1</p>
-------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

9025
15
35

<p>Swing Is Too Fast Diagnostic Procedure</p> <p style="text-align: right;">-- -1/1</p>

<p>1 DTC Check</p>	<p>See Reading Diagnostic Trouble Codes With Monitor Display. (Group 9015-20.)</p> <p>See Reading Diagnostic Trouble Codes With Service ADVISOR™ Diagnostic Application</p> <p>Are any of the following DTC displayed?</p> <ul style="list-style-type: none"> • 11301.03 See Swing Pilot Pressure Sensor Circuit Voltage High. (Group 9001-10.) • 11301.04 See Swing Pilot Pressure Sensor Circuit Voltage Low. (Group 9001-10.) 	<p>YES: Diagnose and repair as required to clear displayed DTC.</p> <p>Diagnostic procedure complete.</p> <p>NO: Go to Swing Pressure Sensor Check.</p> <p style="text-align: right;">-- -1/1</p>
---------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Diagnostic Information

<p>8 Servo Piston Shuttle Valve Check</p>	<p>See Park Brake Valve Housing Disassemble and Assemble. (Group 0260.)</p> <p>Inspect servo piston shuttle valve.</p> <p>Does shuttle valve operate correctly?</p>	<p>YES: Inspect travel reduction gear.</p> <p>NO: Repair or replace motor swash plate angle control.</p> <p>See Travel Motor Cover Disassemble and Assemble. (0260.)</p> <p style="text-align: right;">-- -1/1</p>
--------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Machine Mistracks During Combined Operation With Dig Functions Diagnostic Procedure

-- -1/1

<p>1 Flow Combiner Valve Check</p>	<p>See Control Valve Operation. (Group 9025-05.)</p> <p>Remove and inspect flow combiner valve in control valve.</p> <p>Is valve in good working condition?</p>	<p>YES: Go to Flow Combiner Signal Pressure Check.</p> <p>NO: Repair or replace flow combiner valve.</p> <p>See Control Valve 5-Spool Disassemble and Assemble. (Group 3360.)</p> <p style="text-align: right;">-- -1/1</p>
-------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------


9025
15
45

Diagnostic Information

<p>5 Rotary Manifold Leakage Check</p>	<p>Perform Rotary Manifold Air Test. (Group 0260.)</p> <p>Inspect rotary manifold for leakage.</p> <p>Is rotary manifold OK?</p>	<p>YES: Go to Hydraulic Pump Check.</p> <p>NO: Repair or replace rotary manifold.</p> <p>See Rotary Manifold Disassemble and Assemble. (Group 0260.)</p> <p style="text-align: right;">-- -1/1</p>
<p>6 Hydraulic Pump Check</p>	<p>Perform Cycle Times Check. (Group 9005-10.)</p> <p>Slow travel cycle times may indicate worn pump. If travel cycle times do not meet specification, check pump flow.</p> <p>Perform Pump Flow Test. (Group 9025-25.)</p> <p>Do travel cycle times and pump flow meet specification?</p>	<p>YES: Go to HP Engine Speed Check.</p> <p>NO: Repair or replace pump.</p> <p>See Pump Remove and Install. (Group 3360.)</p> <p style="text-align: right;">-- -1/1</p>
<p>7 HP Engine Speed Check</p>	<p>Key on, use monitor service menu to display Actual Engine Speed and Power Mode.</p> <p>See Monitor Service Menu Operation. (Group 9015-16.)</p> <p>Put power mode switch on P and work mode on digging.</p> <p>Run engine at fast idle and take arm-in function over relief.</p> <p>Record engine speed.</p> <p>Turn power mode switch to HP position.</p> <p>Does engine speed increase approximately 100 rpm when switch is moved to HP?</p>	<p>YES: Go to Power Boost Pressure Check.</p> <p>NO: Select correct engine speed and power mode setting.</p> <p>See Engine Speed Control System Operation. (Group 9010-05.)</p> <p style="text-align: right;">-- -1/1</p>
<p>8 Power Boost Pressure Check</p>	<p>Key on, use monitor service menu to display Pump 1 or Pump 2 Delivery Pressure.</p> <p>See Monitor Service Menu Operation. (Group 9015-16.)</p> <p>Put power mode switch on HP and work mode on digging.</p> <p>Run engine at fast idle and take arm-in function over relief.</p> <p>Record pressure.</p> <p>Push power dig switch on control lever and observe monitor.</p> <p>Does pump 1 and 2 delivery pressure increase approximately 2.5 MPa when power dig switch held on?</p>	<p>YES: Diagnostic procedure complete.</p> <p>NO: Replace or adjust main relief valve.</p> <p>See Main Relief and Power Digging Valve Test and Adjustment. (Group 9025-25.)</p> <p style="text-align: right;">-- -1/1</p>

9025
15
55

Pump 1, Pump 2, Fan Drive Pump, and Pilot Pump Line Connections



Pump 1, Pump 2, Fan Drive Pump, and Pilot Pump Line Identification

- | | | | |
|----------------------------------------------------------------------------|-----------------------------------------------------------------------|---------------------------------------------------|---------------------------------------------------------------------------|
| 1—Hydraulic Oil Tank | 8—Pump 1 | 17—Pump Drive Gearbox
Drain Line | 25—Pump 2-to-Left Control
Valve (5-spool) |
| 2—Pilot Filter and Pressure
Regulating Valve | 9—Pilot Pump | 18—Fan Drive Pump-to-Fan
Drive Control Valve | 26—Pump Case Drain Filter
and Bypass
Valve-to-Hydraulic Oil
Tank |
| 3—Pilot Pump-to-Pilot Filter
and Pressure Regulating
Valve (port PA) | 10—Fan Drive Pump | 19—Pilot Pump Suction Line | 27—Pump 1 Case
Drain-to-Pump Case Drain
Filter and Bypass Valve |
| 4—Port PG-to-Pilot Check
Valve Manifold (port P) | 11—Pump 2 Regulator-to-Fan
Drive Pump Regulator | 20—Fan Drive Pump Suction
Line | 28—Pump Case Drain Filter
and Bypass Valve |
| 5—Port TA-to-Hydraulic Oil
Tank | 12—Pump 1
Regulator-to-Pump 2
Regulator | 21—Pump 1 Suction Line | 29—Fan Drive Pump Case
Drain-to-Pump 1 Case
Drain |
| 6—Port PD-to-Solenoid Valve
Manifold (port PD) | 13—Pump 2 | 22—Hydraulic Oil
Tank-to-Pumps Suction
Line | |
| 7—Port PF-to-Pump 1
Regulator | 14—Pump 2 Case
Drain-to-Pump Case Drain
Filter and Bypass Valve | 23—Pump 1-to-Right Control
Valve (4-spool) | |
| | 15—Pump 1 Attenuator Hose | 24—Pump 1 Attenuator Hose | |
| | 16—Pump 2 Suction Line | | |

LD30992,0000274 -19-07JUN06-1/1

Diagnostic Information

NOTE: DO NOT use manufacturer's hose tags or markings on hose ends to identify hoses for this conversion procedure. The conversion must be done on the side of digging sensor manifold that is connected to the pilot control valves.

Port numbers on digging sensor manifold are given from front to rear of machine and are not marked on manifold.

6. Switch pilot lines connected to port 2 and 5 at digging sensor manifold (9).

7. Disconnect pilot line from port B of the boom shockless valve (10).

8. Use the following table to fabricate the hydraulic hose needed.

Part Number	Description	Assembly Quantity
X10643-6-6	Fittings	2
X421-6	Hydraulic Hose, No Skive	1905 mm (75 in.)
Left Fitting: X10643-6-6 (Parker No. 10643-6-6) Right Fitting: X10643-6-6 (Parker No. 10643-6-6) Hydraulic Hose: X421-6 (Parker No. 421-6) Cut Length: 1885.4 mm (74.23 in.) Crimp Dies: 43-6 (YEL) Die Ring: Silver Length: 1949.9 mm (76.77 in.)		

9. Install a -6 M 37° x -6 M 37° union to fabricated hose. Connect union to pilot line disconnected from the shockless valve

10. Route fabricated hose to digging sensor manifold.

11. Disconnect pilot line from port 6.

12. Connect fabricated hose to port 6.

13. Route pilot line disconnected from port 6 to the shockless valve. Connect line to port B.

14. Install covers.

9025
15
75

GD61784.0000062 -19-26OCT06-6/6

Diagnostic Information

9—Left Travel Forward (pilot)	83—Right Control Valve (4-spool)	160—Left Travel Forward	Y25—Travel Speed Solenoid Valve (SI)
10—Left Travel Reverse (pilot)	84—Left Control Valve (5-spool)	161—Right Travel Forward	I—Left Travel Forward (pilot)
11—Right Travel Forward (pilot)	90—Right Travel Spool	162—Left Travel Reverse	J—Left Travel Reverse (pilot)
12—Right Travel Reverse (pilot)	140—Left Travel Spool	163—Right Travel Reverse	K—Right Travel Forward (pilot)
55—Solenoid Valve Manifold	155—Center Joint	164—Return Line to Hydraulic Oil Tank	L—Right Travel Reverse (pilot)
56—Travel Pilot Control Valve	158—Right Travel Motor	165—Case Drain Lines	PI—From Pilot Shutoff Solenoid Valve
66—Pilot Signal Manifold	157—Left Travel Motor	Y10—Pilot Shutoff Solenoid Valve	

TX04577,0000105 -19-05SEP07-2/2

9025
15
85

Diagnostic Information

1—Boom Up (pilot)	58—Right Pilot Control Valve (bucket and boom)	81—Accumulator	182—Pilot Oil
2—Boom Down (pilot)	59—Boom Up Shockless Valve	82—Pilot Check Valve Manifold	184—Return or Pressure-Free Oil
3—Arm Out (pilot)	62—Bulkhead	85—To Main Relief and Power Digging Valve	B33—Swing Pressure Sensor
4—Arm In (pilot)	63—Travel Sensor Manifold	89—To Travel Flow Combiner Valve	B50—Arm Out Pressure Sensor
5—Swing Left (pilot)	64—Shuttle Valve (2 used)	97—To Boom Flow Rate Control Valve—Switch Valve	B51—Arm In Pressure Sensor
6—Swing Right (pilot)	65—Digging Sensor Manifold	— From Boom Flow Rate Control Valve—Spring Cavity of Switch Valve	B52—Boom Up Pressure Sensor
7—Bucket Curl (pilot)	66—Pilot Signal Manifold	99—To Boom 1 Spool	B53—Boom Down Pressure Sensor
8—Bucket Dump (pilot)	67—Boom Down Shockless Valve	105—To Arm 2 Flow Rate Control Valve—Switch Valve	B54—Bucket Curl Pressure Sensor
9—Left Travel Forward (pilot)	68—Check Valve—Warmup Circuit	—From Arm 2 Flow Rate Control Valve—Spring Cavity of Switch Valve	B55—Bucket Dump Pressure Sensor
10—Left Travel Reverse (pilot)	70—Pilot Valve (port SE) (not used, plug installed)	110—From Bypass Shutoff Valve (4-spool)	B56—Travel Right Pressure Sensor
11—Right Travel Forward (pilot)	71—Arm 2 Flow Rate Pilot Valve (port SK)	118—To Arm 1 Spool	B57—Travel Left Pressure Sensor
12—Right Travel Reverse (pilot)	72—Pump 1 Flow Rate Pilot Valve (port SA) (not used, plug installed)	129—To Boom Mode Relief Control Valve	Y10—Pilot Shutoff Solenoid Valve
13—Plug—Auxiliary (pilot)	73—Pump 2 Flow Rate Pilot Valve (port SB) (not used, plug installed)	146—From Bypass Shutoff Valve (5-spool)	Y22—Boom Flow Rate Solenoid Valve (port SF)
14—Plug—Auxiliary (pilot)	74—Swing Park Brake Release Pilot Valve (port SH)	154—To Swing Park Brake (port SH)	Y23—Boom Mode Solenoid Valve (port SC)
17—To Pump 1 Regulator	75—Travel Flow Combiner Pilot Valve (port SL)	164—To Travel Speed Selector Valve	Y24—Power Dig Solenoid Valve (port SG)
18—To Pump 2 Regulator	76—Filter (18 used)		Y25—Travel Speed Solenoid Valve (port SI)
27—Pilot Pump	77—Orifice—Warmup Circuit		
29—To Fan Drive Pump Regulator	78—Shuttle Valve (17 used)		
47—From Hydraulic Oil Tank	79—Check Valve—Warmup Circuit (3 used)		
51—Pilot Filter and Pressure Regulating Valve			
52—Pilot Filter Element			
53—Pilot Filter Bypass Valve			
54—Pilot Pressure Regulating Valve			
55—Solenoid Valve Manifold			
56—Travel Pilot Control Valve			
57—Left Pilot Control Valve (swing and arm)			

Continued on next page

OUT3035,000007 -19-01JUN06-2/16

9025
15
95

Diagnostic Information

26—Check Valve	36—Fan Drive Motor (2 used)	44—Restriction Valve	Y8—Reversing Fan Solenoid Valve 1
27—Pilot Pump	37—Fan Drive Control Valve (standard) (2 used)	46—To Pump Case Drain Filter and Bypass Valve	Y9—Reversing Fan Solenoid Valve 2
28—Fan Drive Pump	38—Fan Drive Relief Valve	47—From Hydraulic Oil Tank	Y14—Fan Pump Control Solenoid Valve
29—Fan Drive Pump Regulator	39—Make-Up Check Valve	51—From Pilot Filter and Pressure Regulating Valve	180—Supply Oil
30—Servo Piston	40—Fan Drive Reversing Control Valve (2 used)	82—From Pilot Check Valve Manifold	182—Pilot Oil
31—Feedback Link	41—Fan Drive Reversing Spool	83—From Right Control Valve	184—Return or Pressure-Free Oil
32—Load Sleeve	43—Hydraulic Oil Cooler	176—Radiator	
33—Load Piston			
34—Pilot Piston			
35—Compensating Piston			

Continued on next page

OUT3035,0000007 -19-01JUN06-12/16

9025
15
,105

1. Connect one of the following test equipment to perform test:

1. SERVICE ADVISOR™ application. See SERVICE ADVISOR Connection Procedure for instruction. (Group 9015-20.)

Access Hydraulic Warm-Up.

Or select the following items from the menu:

- Coolant Temperature
- Hydraulic Oil Temperature
- Actual Engine Speed

2. See Personal Digital Assistant (PDA) Connection To Excavator Using Dr. ZX Application for instruction. (Group 9015-20.)

Select the following items from the Monitor Display:

- Coolant Temperature
- Hydraulic Oil Temperature
- Actual Engine Speed

3. See Monitor Service Menu Operation for instruction to actuate the service menu on monitor in cab. (Group 9015-20.)

Select the following items from Monitoring list:


- Coolant Temperature
- Hydraulic Oil Temperature
- Actual Engine Speed



CAUTION: Avoid possible serious injury from machine movement during warm-up procedure. Clear the area of all bystanders before doing the warm-up procedure.

2. Clear the area of all bystanders to allow for machine movement.

3. Start engine. Run engine at approximately 1/2 speed for approximately 5 minutes before operating any functions.



Monitor

TX100295 -19-03MAR06

9025
25
5


NOTE: Pressure reading displayed on the monitor is calculated pressure from an electrical signal in the main controller (MCF). The reading does not change when valve adjustment is made. The actual pressure to the power digging valve must be measured using a gauge.

1. Release pressure from hydraulic oil tank by pushing pressure release button at top of hydraulic oil tank.
2. Disconnect line for power dig solenoid valve (Y24) to main relief and power digging valve (85) from elbow at the bottom of solenoid valve manifold (55).


Install a JT03191 Tee in the line.

3. Connect the JT02156A Digital Pressure/Temperature Analyzer and JT02162 Transducer or a 7 MPa (7000 kPa) (70 bar) (1000 psi) gauge. See JT02156A Digital Pressure/Temperature Analyzer Installation.

- Y22—Boom Flow Rate Solenoid Valve (port SF)
- Y23—Boom Mode Solenoid Valve (port SC)
- Y24—Power Dig Solenoid Valve (port SG)
- Y25—Travel Speed Solenoid Valve (port SI)
- 55—Solenoid Valve Manifold
- 66—Pilot Signal Manifold
- 83—Right Control Valve (4-spool)
- 84—Left Control Valve (5-spool)
- 85—To Main Relief and Power Digging Valve
- 97—To Boom Flow Rate Control Valve—Switch Valve
- 129—To Boom Mode Relief Control Valve
- 164—To Travel Speed Selector Valve (left and right travel motors)



Solenoid Valve Manifold Location



Power Dig Solenoid Valve (port SG)

TX1003387 -UN-10FEB06

TX1003386 -UN-13FEB06

9025
25
15

Continued on next page

LD30992,00002B1 -19-05JUN06-2/5

NOTE: Pressure reading displayed on the monitor is calculated from an electrical signal in the main controller (MCF). The reading does not change when valve adjustment is made. The actual pressure to the boom mode relief control valve must be measured using a gauge.

The calculated pressure reading for boom mode solenoid valve does not displayed on the monitor in cab.

1. Release pressure from hydraulic oil tank by pushing pressure release button at top of hydraulic oil tank.
2. Disconnect line for boom mode solenoid valve (Y23) to boom mode relief control valve (129) from elbow at the bottom of solenoid valve manifold (55).

Install a JT03191 Tee in the line.

3. Connect the JT02156A Digital Pressure/Temperature Analyzer and JT02162 Transducer or a 7 MPa (7000 kPa) (70 bar) (1000 psi) gauge. See JT02156A Digital Pressure/Temperature Analyzer Installation.
4. Use one of the following test equipment to display the calculated pressure:

1. SERVICE ADVISOR™ application. See SERVICE ADVISOR Connection Procedure for instruction. (Group 9015-20.)

Access Boom Mode Solenoid Valve Test.


Or select the following items from the menu:

- Hydraulic Oil Temperature
- Actual Engine Speed
- Boom Mode Switch


2. See Personal Digital Assistant (PDA) Connection To Excavator Using Dr. ZX Application for instruction. (Group 9015-20.)

Select the following items from the Monitor Display:

- Boom Mode Control Pressure
- Hydraulic Oil Temperature
- Actual Engine Speed
- Boom Mode Switch



Solenoid Valve Manifold Location



Boom Mode Solenoid Valve (port SC)

- Y22—Boom Flow Rate Solenoid Valve (port SF)
- Y23—Boom Mode Solenoid Valve (port SC)
- Y24—Power Dig Solenoid Valve (port SG)
- Y25—Travel Speed Solenoid Valve (port SI)
- 55—Solenoid Valve Manifold
- 66—Pilot Signal Manifold
- 83—Right Control Valve (4-spool)
- 84—Left Control Valve (5-spool)
- 85—To Main Relief and Power Digging Valve
- 97—To Boom Flow Rate Control Valve—Switch Valve
- 129—To Boom Mode Relief Control Valve
- 164—To Travel Speed Selector Valve (left and right travel motors)

TX1003387 -JUN-10-FEB06

TX1003386 -JUN-13-FEB06

9025
25
25

NOTE: A pressure setting that cannot be raised can be caused by a low pressure setting of the circuit relief valve. Use boom up and the other propel function for adjusting the main relief and power digging valve. See *Circuit Relief Valve Test and Adjustment* to check the circuit relief valve that is low. (Group 9025-25.)

7. Adjust the main relief and power digging valve pressure setting as needed.

Specification

Main Relief Valve—Pressure 30.4—32.9 MPa
 30 400—32 900 kPa
 304—329 bar
 4410—4770 psi

Specification

Power Digging Valve—Pressure 32.8—35.3 MPa
 32 800—35 300 kPa
 328—353 bar
 4770—5120 psi

8. Loosen the 30 mm nut (2).

9. Turn first adjusting plug (1) in until piston (5) is against shoulder (6) in second adjusting plug (3). Tighten nut finger tight.

10. Loosen the 41 mm nut (4).

11. Actuate the propel function over relief.

12. Turn second adjusting plug (3) in to increase power digging relief pressure; turn adjusting plug out to decrease pressure.


Specification

Second Adjusting Plug—Pressure
 Change 4.5 MPa approximate per 1/4 turn
 4500 kPa approximate per 1/4
 turn
 45 bar approximate per 1/4 turn
 655 psi approximate per 1/4 turn

13. Hold second adjusting plug. Tighten 41 mm nut to specification.

Specification

41 mm Nut—Torque 98 N•m
 70 lb-ft



Main Relief and Power Digging Valve

- 1—First Adjusting Plug
- 2—30 mm Nut
- 3—Second Adjusting Plug
- 4—41 mm Nut
- 5—Piston
- 6—Shoulder

TX1003242 -UN-01FEB06

9025
25
35

5. Adjust the boom mode relief valve (128) as needed.

Disconnect pilot line from relief valve.

Loosen nut (2).

Turn adjusting plug (1) in to increase pressure setting; turn adjusting plug out to decrease pressure setting.

Hold adjusting plug and then tighten nut.


Specification

Boom Mode Relief Valve

Adjusting Plug—Pressure Change..... 2.1 MPa approximate per 1/4 turn
 2100 kPa approximate per 1/4 turn
 21 bar approximate per 1/4 turn
 300 psi approximate per 1/4 turn

6. Connect pilot line.

7. Check the pressure setting.



Boom Mode Relief Valve

- 1—Adjusting Plug
- 2—Nut
- 128—Boom Mode Relief Valve
- 129—Boom Mode Relief Control Valve

TX1004306 -JUN-09MAR06

OUT3035,0000036 -19-06JUN06-4/4

9025
25
45

2. See Personal Digital Assistant (PDA) Connection To Excavator Using Dr. ZX Application for instruction. (Group 9015-20.)

Select the following items from the Monitor Display:

- Pump 1 Delivery Pressure
- Pump 2 Delivery Pressure
- Hydraulic Oil Temperature
- Actual Engine Speed

3. See Monitor Service Menu Operation for instruction to actuate the service menu on monitor in cab. (Group 9015-16.)

Select the following items from Monitoring list:

- Pump 1 Delivery Pressure
- Pump 2 Delivery Pressure
- Hydraulic Oil Temperature
- Actual Engine Speed

4. Push the pressure release button on top of the hydraulic oil tank to relieve pressure.

Install 4200465 adapter into test port (1 and 2) on pump one and two.

Connect the JT02156A Digital Pressure/Temperature Analyzer and JT02160 Transducer or a 70 000 kPa (700 bar) (10,000 psi) gauge. See JT02156A Digital Pressure/Temperature Analyzer Installation for instruction.

2. Turn second adjusting plug of main relief and power digging valve in 1/2 turn to increase pressure setting. See Main Relief and Power Digging Valve Test and Adjustment for adjustment procedure. (Group 9025-25.)

3. Warm hydraulic oil to specification. See Hydraulic Oil Warm-Up Procedure. (Group 9025-25.)

9025
25
55

Continued on next page

TX04577,00000F1 -19-05JUN06-2/4

Cylinder Drift Test—Arm, Boom, and Bucket

SPECIFICATIONS	
Hydraulic Oil Temperature	45—55°C 110—130°F
Bucket Load Weight	4650 kg approximate 10,250 lb approximate
Test Time	5 minutes
Boom Cylinder Drift	5 mm or less 0.2 in. or less
Arm Cylinder Drift	18 mm or less 0.7 in. or less
Bucket Cylinder Drift	27 mm or less 1.1 in. or less
Bucket Bottom to Ground Drift	150 cm 60 in.

The following test is used to check the leakage past the cylinder piston seals and past the spools in the control valve.

1. Connect one of the following test equipment to perform test:

1. SERVICE ADVISOR™ application. See SERVICE ADVISOR Connection Procedure for instruction. (Group 9015-20.)

Access Cylinder Drift Test.

Or select the following items from the menu:

- Hydraulic Oil Temperature
- Actual Engine Speed

2. See Personal Digital Assistant (PDA) Connection To Excavator Using Dr. ZX Application for instruction. (Group 9015-20.)


Select the following items from the Monitor Display:

- Hydraulic Oil Temperature
- Actual Engine Speed


3. See Monitor Service Menu Operation for instruction to actuate the service menu on monitor in cab. (Group 9015-16.)

Select the following items from monitor list:

- Hydraulic Oil Temperature
- Actual Engine Speed



Display Monitor



2—150 cm (60 in.)

TX1003295 -19-03MAR06

T141254 -UN-26APR01

9025
25
65

NOTE: The fan drive control valves and motors are connected in parallel. Therefore, the fan drive system relief valve with the lower pressure setting controls the system pressure.

- 12. Turn the adjusting screw for one of the fan drive system relief valve (38) in to increase pressure setting; turn adjusting screw out to decrease pressure setting.

A pressure reading that does not increase or decrease means that the other relief valve has a pressure setting that is lower.

Turn the adjusting screw back to its original position and then turn the adjusting screw for the other relief valve in to increase the pressure setting.

Specification

Fan Drive System Relief Valve—Pressure Change	1.7 MPa approximate per 1/4 turn
	1723 kPa approximate per 1/4 turn
	17.2 bar approximate per 1/4 turn
	250 psi approximate per 1/4 turn

OUT3035,0000015 -19-06JUN06-4/4

9025
25
75

Specification

Fan Drive Pump—Flow Rate—

Minimum Allowable..... 88.6 L/min at 17.6 MPa and 1750 rpm
88.6 L/min at 17 580 kPa and 1750 rpm
88.6 L/min at 175.8 bar and 1750 rpm
23.4 gpm at 2550 psi and 1750 rpm

Fan Drive Pump—Flow Rate—

Minimum Allowable..... 70.0 L/min at 21.7 MPa and 1750 rpm
70.0 L/min at 21 720 kPa and 1750 rpm
70.0 L/min at 217.2 bar and 1750 rpm
18.5 gpm at 3150 psi and 1750 rpm

- 13. Open loading valve. Stop the engine.

Pump flow rate can be increased some by adjusting the pump servo piston maximum flow adjusting screw. See Fan Drive Pump Servo Piston Maximum Flow Test and Adjustment. (Group 9025-25.)

- 14. Turn adjusting screw for fan drive system relief valve back to its original setting.

Diagnose Heating System Malfunctions

NOTE: Diagnostic charts are arranged from most probable and simplest to verify, to least likely more difficult to verify.


NOTE: Prior to diagnosis and component tests Perform Air Conditioner and Heater Operational Checks. (Group 9031-25.) These conditions may affect diagnostic and test results.

Symptom	Problem	Solution
Heater System Does Not Operate	Air conditioner and heater 5 amp fuse (F17)	Replace fuse. See Fuse and Relay Specifications. (Group 9015-10.)
	Air conditioner and heater 20 amp fuse (F3)	Replace fuse. See Fuse and Relay Specifications. (Group 9015-10.)
	Fan motor malfunction or operating too slowly	Check fan motor resistor. See Air Conditioner Harness (W6) Wiring Diagram. (Group 9015-10.)
		Check fan motor for obstructions. See Heater and Air Conditioner Component Location. (Group 9031-15.)
		Check fan motor. See Air Conditioner Harness (W6) Wiring Diagram. (Group 9015-10.)
	Heater and air conditioner controller malfunction	Check air conditioner diagnostic trouble codes. See Air Conditioner Diagnostic Trouble Code Check. (Group 9031-15.)
Heater Does Not Warm Interior of Cab	Fresh air filter restricted	Clean or replace filter. See Clean Cab Fresh Air and Recirculating Air Filter. (Operator's Manual.)
	Recirculating air filter restricted	Clean or replace filter. See Clean Cab Fresh Air and Recirculating Air Filter. (Operator's Manual.)

9031
15
5

Air Conditioner Compressor Clutch Test

1. Disconnect connector (1) from clutch.
2. Connect battery voltage to clutch connector.
3. Clutch solenoid should engage and will “click”.
4. If clutch solenoid does not engage repair or replace compressor. See Compressor Remove and Install (Group 1830.) and see Compressor Clutch Disassemble and Assemble. (Group 1830.)
5. If clutch solenoid engages check harness. See Air Conditioning Harness (W6) Wiring Diagram. (Group 9015-10.)



1—Connector

T144993 -UN-28AUG01

LD30992,00004B5 -19-23MAR06-1/1

Refrigerant Leak Test

1. Inspect all lines, fittings, and components for oily or dusty spots. When refrigerant leaks from the system, a small amount of oil is carried out with it.
2. A soap and water solution can be sprayed on the components in the system to form bubbles at the source of the leak.
3. If a leak detector is used, move the leak detector probe under the hoses and around the connections at a rate of 25 mm (1 in.) per second.
4. Some refrigerant manufacturers add dye to refrigerant to aid in leak detection.

LD30992,00004B8 -19-23MAR06-1/1

Page	Page
Control valve	Reading with Dr. ZX9015-20-30
Check valves identification and operation9025-05-66	Reading, monitor display.9015-20-3, 9015-20-5
Line identification9025-15-66	Reading, Service ADVISOR9015-20-24
Operation9025-05-51	Diagnostic Trouble Codes
Pilot operation.9025-05-26	Service ADVISOR.9015-20-22
Pilot, operation9025-05-10, 9025-05-12	Diagnostic trouble codes
Schematic, hydraulic.9025-15-94	Trouble codes check.9005-10-1
Control valve harness (W7)	Diagnostics
Component location9015-10-54	Auto lubrication system malfunctions . . .9025-15-61
Wiring diagram9015-10-56	Auto-Idle Does Not Work9010-15-13
Control valve lift check valve	Counterweight circuit malfunctions9025-15-58
Operational check.9005-10-22	Dig circuit malfunctions9025-15-16
Cooling fan circuit	Hydraulic function speed too fast9025-15-7
Diagnostics9025-15-10	Hydraulic oil overheats9025-15-8
Cooling system operation	Observable
Engine9010-05-8	Engine emits excessive black or gray exhaust smoke9010-15-22
Counterweight	Pilot circuit malfunctions9025-15-11
Removal cylinder9025-05-109	Slow Hydraulics9025-15-3
Counterweight circuit	Swing circuit malfunctions.9025-15-31
Diagnose malfunctions9025-15-58	Travel circuit malfunctions.9025-15-37
Cover	Undercarriage components
Cab rear, remove and install.9015-20-108	malfunctions9020-15-1
Crossover relief valve	White Exhaust Smoke.9010-15-20
Swing motor, test and adjustment.9025-25-51	Dig circuit
Cumulative operating hour list	Diagnose malfunctions9025-15-16
Information controller (ICF)9015-20-87	Dig function drift
Cycle times check	Operational check.9005-10-20
Operational check.9005-10-27	Digital pressure/temperature analyzer
Cylinder	Installation.9025-25-2
Boom, arm, and bucket, operation . . .9025-05-108	Digital thermometer installation.9025-25-2
Cylinder drift	Diode
Test9025-25-65	Check9015-20-104
D	Display
Daily report data list	Monitor, remove and install.9015-20-111
Information controller (ICF)9015-20-87	Download injector ID code
Data download	Tech 29010-25-40
Information controller (ICF)9015-20-82	Dr. ZX
Date and time	Password change9015-20-60
Information controller (ICF)9015-20-75	Personal digital assistant (PDA) connection to excavator.9015-20-27
Diagnostic application	Reading diagnostic trouble codes9015-20-30
Tech 2 diagnostic scan tool, Data display.9015-20-19	Driving metal pins.9000-01-14
Diagnostic connection	E
Service ADVISOR.9015-20-23	E (economy) mode
Diagnostic trouble code	Operational check.9005-10-12
Check, air conditioner and heater9031-15-7	ECM
Diagnostic trouble codes	Remove and install9015-20-110
Display and clear trouble codes9005-10-1	

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL