




Workshop Service Manual



MASSEY FERGUSON

Technician Service Book - series tractors MF 6700 S

Schémas électriques et hydrauliques



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL



5.1.3.94 FAI223 - Roof harness_standard_municipal_cab_ACW001936_3/3 . . . 5-104

5.1.3.95 FAI224 - Hand rail lighting harness - 4390262_1/2 5-105

5.1.3.96 FAI224 - Hand rail lighting harness - 4390262_2/2 5-106

5.1.3.97 FAI225 - Electric rear-view mirror harness - 4352622_1/2 5-107

5.1.3.98 FAI225 - Electric rear-view mirror harness - 4352622_2/2 5-108

5.1.3.99 FAI227 - Roof harness with automatic air conditioning - 4352621_1/3 . 5-109

5.1.3.100 FAI227 - Roof harness with automatic air conditioning - 4352621_2/3 5-110

5.1.3.101 FAI227 - Roof harness with automatic air conditioning - 4352621_3/3 5-111

5.1.3.102 FAI228 - Number plate lighting harness - 4353107_1/2 5-112

5.1.3.103 FAI228 - Number plate lighting harness - 4353107_2/2 5-113

5.1.3.104 FAI228 - Number plate lighting harness - 4357222_1/2 5-114

5.1.3.105 FAI228 - Number plate lighting harness - 4357222_2/2 5-115

5.1.3.106 FAI245 - Left-hand linkage external controls harness - 4348463_1/2 . 5-116

5.1.3.107 FAI245 - Left-hand linkage external controls harness - 4348463_2/2 . 5-117

5.1.3.108 FAI253 - Hand rail harness - 4390260_1/2 5-118

5.1.3.109 FAI253 - Hand rail harness - 4390260_2/2 5-119

5.1.3.110 FAI261 - Isobus harness - 4353130_1/2 5-120

5.1.3.111 FAI261 - Isobus harness - 4353130_2/2 5-121

5.1.3.112 FAI261 - Isobus harness - 4353133 5-122

5.1.3.113 FAI262 - Auto-Guide™ engine harness - 4296810_1/2 5-123

5.1.3.114 FAI262 - Auto-Guide™ engine harness - 4296810_2/2 5-124

5.1.3.115 FAI263 - Auto-Guide™ cab adapter harness - 4353936_1/2 5-125

5.1.3.116 FAI263 - Auto-Guide™ cab adapter harness - 4353936_2/2 5-126

5.1.3.117 FAI265 - Pneumatic braking harness Dyna-6- ACW034317_1/2 5-127

5.1.3.118 FAI265 - Pneumatic braking harness Dyna-6- ACW034317_2/2 5-128

5.1.3.119 FAI265 - Pneumatic braking harness Dyna-VT - ACW016912_1/2 . . . 5-129

5.1.3.120 FAI265 - Pneumatic braking harness Dyna-VT - ACW016912_2/2 . . . 5-130

5.1.3.121 FAI272 - Suspended cab harness Dyna-6 - ACW039185_1/2 5-131

5.1.3.122 FAI272 - Suspended cab harness Dyna-6 - ACW039185_2/2 5-132

5.1.3.123 FAI272 - Suspended cab harness Dyna-VT - ACW060395_1/2 5-133

5.1.3.124 FAI272 - Suspended cab harness Dyna-VT - ACW060395_2/2 5-134

5.1.3.125 FAI273 - Front linkage harness with power socket - 4353047_1/2 . . . 5-135

5.1.3.126 FAI273 - Front linkage harness with power socket - 4353047_2/2 . . . 5-136

5.1.3.127 FAI273 - Front linkage harness without power socket - 4353048_1/2 5-137

5.1.3.128 FAI273 - Front linkage harness without power socket - 4353048_2/2 5-138

5.1.3.129 FAI283 - TopDock harness - 4377536_1/2 5-139

5.1.3.130 FAI283 - TopDock harness - 4377536_2/2 5-140

5.1.3.131 FAI287 - ALO loader harness external without multi-function armrest -
4378794_1/2 5-141

5.1.3.132 FAI287 - ALO loader harness external without multi-function armrest -
4378794_2/2 5-142

5.1.3.133 FAI287 - ALO loader harness internal without multi-function armrest -
4378879_1/2 5-143

5.1.3.134 FAI287 - ALO loader harness internal without multi-function armrest -
4378879_2/2 5-144

5.1.3.135 FAI290 - Non-Isobus implement connector harness - 4296266_1/2 . . 5-145

5.1.3.136 FAI290 - Non-Isobus implement connector harness - 4296266_2/2 . . 5-146

5.1.3.137 FAI292 - NA indicator harness - 4350987 5-147

5.1.3.138 FAI292 - NA indicator harness - 4355519_1/2 5-148

5.1.3.139 FAI292 - NA indicator harness - 4355519_2/2 5-149

5.1.3.140 FAI293 - EAME indicator harness - 4350988 5-150

5.1.3.141 FAI293 - EAME indicator harness - 4355520_1/2 5-151

5.1.3.142 FAI293 - EAME indicator harness - 4355520_2/2 5-152

5.1.3.143 FAI294 - Additional heater harness - 4299327_1/2 5-153

5.1.3.144 FAI294 - Additional heater harness - 4299327_2/2 5-154

5.1.3.145 FAI299 - Battery isolator harness - ACW028832_1/2 5-155

5.1.3.146 FAI299 - Battery isolator harness - ACW028832_2/2 5-156

5.1.3.147 FAI300 - Air conditioning shunt harness - 4353106 5-157

Engine				
Model	MF 6712 S	MF 6713 S	MF 6714 S	MF 6715 S
Device brand	Bosch Denox 2.2+			
Type of control	Engine controller EEM4			
Urea solidification temperature	-11 °C			
Oil vapor recirculation system	Closed system breather (CCV)			
Belt: Air conditioning compressor/ left-hand alternator	Poly V belt			
Belt: Fan/right-hand alternator	Poly V belt			
Belt: Air compressor	Poly V belt			

Rear axle transmission		
Model	MF 6712 S/MF 6713 S	MF 6714 S/MF 6715 S
Gearbox type	GBA25	
Number of ratios	4	
Number of ranges	4	
Number of gears	16/16	
Super creeper gears	14/1	
Number of gears with super creeper gears	32/32	
Maximum speed	40 km/h	
Rear axle type	GPA22/22+	GPA23/23+
Number of pinion/crown wheel teeth	8/39	8/39
Rear axle ratio	24.75	27.16
4WD ratio	0.83	0.83
Final drive type	Heavy Duty (HD) or Heavy Duty + (HD+)	Super Heavy Duty (SHD)
Final drive reduction ratio	(53+13)/13	(64+14)/14
Maximum 4WD clutch torque	180 daNm	206 daNm
Number of 4WD disks	6 disks	
Main brake type	Disk	
Number of disks per side	1 disk	
Braking pressure	66 - 70 bar	
Parking brake type	Hand brake	

Rear axle transmission		
Model	MF 6713 S/MF 6714 S	MF 6715 S/MF 6716 S/MF 6718 S
Braking pressure	66 - 70 bar	
Parking brake type	Hand brake	
Trailer brake type	Hydraulic and pneumatic with built-in antifreeze pump	
Pneumatic trailer braking pressure	6,9 bar to 8,3 bar	
Hydraulic trailer braking pressure	0 to 150 bar	
Maximum operating tilt - pitch (front/rear)	15° (> 15 km/h) 22° (< or = 15 km/h)	
Maximum operating tilt - roll (right/left)	15° (> 15 km/h) 22° (< or = 15 km/h)	
Maximum operating tilt - combined	15° (> 15 km/h) 22° (< or = 15 km/h)	
Total loaded weight supported by rear axle	7600 kg	9000 kg

Front axle			
Model	MF 6713 S/MF 6714 S	MF 6715 S	MF 6716 S/MF 6718 S
Brand	DANA		
Axle type	Suspended or fixed		
Supplier reference - suspended axle	735/614	735/613	740/614
Suspended front axle weight	587 kg	587 kg	620 kg
Supplier reference - fixed axle	735/528	735/530	740/553
Fixed front axle weight	347 kg	347 kg	380 kg
Number of differential disks	12		
Total ratio for fixed and suspended front axle	15.5	17	
Total loaded weight supported by front axle	6000 kg		
Rotational direction	Anti-clockwise		
Recommended oil type (beam and final drive)	SAE85W90 (API GL5-MIL 2105B)		
Ratio for fixed and suspended axle final drive	6		

Front axle		
Model	MF 6713 S/MF 6714 S	MF 6715 S/MF 6716 S/MF 6718 S
Suspension ram diameter	68 mm x 32 mm	
Suspension ram stroke	2 x 129 mm	
Hydraulic control unit brand	Husco	
Hydraulic control unit nominal pressure	190 bar	
Number of accumulators	2	
Accumulator pressure	10 bar and 50 bar	
Suspension sensor type	Angular potentiometer.	
Steering sensor type	Angular potentiometer.	
Brake type	Combined with the rear brake	
Factor K	1.32	

Spool valve	
Model	All models
System type	Closed Center Load Sensing (CCLS)
Flow rate	110 l/190 l
High-pressure pump type	Bosch Rexroth piston pump
High-pressure pump displacement	45 cm ³ at 110 l/min 85 cm ³ at 190 l/min
High-pressure pump rotational speed	2512 rpm
High-pressure pump maximum flow rate	110 l/min or 190 l/min
High-pressure pump maximum pressure	205 bar
Maximum quantity of oil	110 l
Maximum exportable oil quantity (without adding oil)	42 l continuous 52 l temporary (example: emptying a bucket)
Charge pump type	Suction
Main relief valve adjustment pressure	230 bar ± 5 bar
Number of spool valves (maximum)	8
Number of front "push-pull" connectors	4
Number of rear "push-pull" connectors	10

Range	Ratio	GTA 2522+ - MF 6713 S/MF 6714 S at 1800 rpm	GTA 2523 - MF 6715 S/MF 6716 S/MF 6718 S at 1800 rpm
1	F	0,25 km/h	0,23 km/h
2	A	0,28 km/h	0,25 km/h
2	B	0,34 km/h	0,31 km/h
2	C	0,39 km/h	0,36 km/h
2	D	0,47 km/h	0,43 km/h
2	E	0,56 km/h	0,51 km/h
2	F	0,67 km/h	0,61 km/h
3	A	0,57 km/h	0,52 km/h
3	B	0,68 km/h	0,62 km/h
3	C	0,80 km/h	0,73 km/h
3	D	0,96 km/h	0,88 km/h
3	E	1,13 km/h	1,03 km/h
3	F	1,36 km/h	1,24 km/h
4	A	1,43 km/h	1,37 km/h
4	B	1,72 km/h	1,65 km/h
4	C	2,02 km/h	1,93 km/h
4	D	2,43 km/h	2,33 km/h
4	E	2,86 km/h	2,73 km/h
4	F	3,44 km/h	3,29 km/h

1.2.5 Forward speed for all models with transmission in Dyna-VT mode

50 kph version* tractors

*depending on country legislation.

For the 40 kph version, the speed is electronically controlled.

Continuous variation mode		
	Forward	Reverse
Slow speed range (Tortoise)	0.03 kph to 28 kph	0.03 kph to 16 kph
High speed range (Hare)	0.03 kph to 40 kph or 50 kph*	0.03 kph to 38 kph

1.4.3 Attachment points: MF 6715 S / MF 6716 S / MF 6718 S Dyna-4/Dyna-6 models without front linkage




Fig. 6

NOTE:

Values x, y and z represent reference point 0 of the tractor.

Reference		X	Y	Z
1 ¹	M20	-1582 mm	-315 mm	-45 mm
2 ¹	M20	-1582 mm	-315 mm	-125 mm
3 ¹	M20	-667 mm	-280 mm	27,5 mm
4 ¹	M20	-667 mm	-280 mm	-37,5 mm
5	M16	-667 mm	-280 mm	-102,5 mm
6 ¹	M20	126,8 mm	-280 mm	38 mm
7 ¹	M20	126,8 mm	-280 mm	-35 mm

1.6 Tightening torques, retaining compounds and sealing products

1.6.1 Retaining compounds and sealing products

General

The Loctite compounds mentioned in this manual are referred to by their industrial name.

For repair purposes, use their commercial names or the corresponding Massey Ferguson references listed in the table below.

Loctite product type	Operation
221	Standard threadlock
241	
242	Medium threadlock
270	Strong threadlock
496	Glue (for metals)
510	Standard sealant
518	Sealant for flat surfaces and paper seals
542	Thread sealant
549	Oil-resistant surface sealant
573	Surface sealant (engine, gearbox)
574	
577	Threaded union sealant (prevents loosening and leakages caused by vibrations)
603	Retainer for cylindrical assemblies (bearings, rings etc.)
638	Strong retainer for cylindrical assemblies (bearings, rings etc.)
648	Strong retainer for cylindrical assemblies (resistant to high temperatures)
706	Degreasing cleaner
5206	Metallic surface sealant (gearbox housing, engine sump)
5910	± Flexible surface sealant
5922	Sealant paste for ± flexible unions (sensor attachments etc.)
7100	Leakage detector for pneumatic systems

NOTE: Use the product "Form A gasket 2" when sealing between plastic material and cast iron or steel.

Application method for Loctite products

1. Remove all traces of previous sealants and corrosion
 - mechanically: wire brush or emery cloth
 - chemically: "DECAPLOC 88" (Leave the product to take effect then scrape off and wipe clean).
2. Degrease the components with dry solvent: preferably use "Super Solvant Sec LOCTITE 706".
3. Allow the solvents to evaporate



[2] Metric unit

Torque		
Nm	x 0.7375	lbf ft
lbf ft	x 1.3558	Nm
daNm	x 7.3756	lbf ft
lbf ft	x 0.1356	daNm


Pressure		
bar	x 14.504	psi
psi	x 0.0690	bar


Flow rate		
l/min	x 0.2642	gal/min (US)
gal/min (US)	x 3.7853	l/min
l/hr	x 0.2642	gal/hr (US)
gal/hr (US)	x 3.7853	l/hr
l/ha	x 0.1069	gal/acre (US)
gal/acre (US)	x 9.3531	l/ha


Speed		
kph	x 0.6214	mph
mph	x 1.6093	kph


Weight		
g	x 0.03527	oz
oz	x 28.3495	g
kg	x 2.2046	lb
lb	x 0.4536	kg
t	x 1.1023	US ton
US ton	x 0.9072	t

Temperature		
°C	$(^{\circ}\text{C} \times 1.8) + 32$	°F
°F	$(^{\circ}\text{F} - 32)/1.8$	°C

 General failure warning light	
Activating condition(s) <ul style="list-style-type: none"> Indicator light flashing with engine oil pressure indicator light = engine error - stop the engine Indicator light permanently on = major error - stop the tractor 	
Cause(s)	Solution(s)
Engine error	Contact the dealer.
Major error	Contact the dealer.

 Lubrication pressure indicator light	
Activating condition(s) <ul style="list-style-type: none"> Indicator light permanently on = lubrication pressure lower than 0.45 bar 	
Cause(s)	Solution(s)
Oil level too low	Check the transmission oil level.
Hydraulic system components faulty	Contact the dealer.

 Steering supply pressure indicator light	
Activating condition(s) <ul style="list-style-type: none"> Indicator light flashing = auxiliary hydraulic oil level below 55 l Indicator light permanently on = auxiliary hydraulic oil pressure lower than 25 bar or oil level below 35 l 	
Cause(s)	Solution(s)
Oil level too low	Check the auxiliary hydraulic oil level.
Hydraulic system components faulty	Contact the dealer.

 Transmission oil pressure indicator light	
Activating condition(s) <ul style="list-style-type: none"> Indicator light flashing = transmission oil pressure lower than 9 bar 	
Cause(s)	Solution(s)
Transmission oil level too low	Check the transmission oil level.
Transmission module faulty	Contact the dealer.

No.	Components concerned	Causes
0.X.3B	X56 - PowerShuttle lever	Electrical signal too high
0.X.3C		Electrical signal too low
0.X.3D		Electrical signal too high
0.X.3E		Electrical signal too low
0.X.3F		CAN network deactivated (CAN bus off)
0.X.40		CAN message lost
0.X.41		Tractor speed too high
0.X.42	X55 - Instrument panel	Hourmeter error for engine maintenance
0.X.43		Configuration error
0.X.44		CAN communications from transmission controllers to instrument panel are faulty
0.X.45	X55 - Instrument panel	Incorrect tractor code selected
0.X.46	X68 - Clutch pedal sensor	TOC stuck open
0.X.47	X56 - PowerShuttle lever	Switch error when in neutral position
0.X.48		Switch error when not in neutral position
0.X.49		Failure of CAN communications from EEM to the instrument panel
0.X.4A		Loss of CAN messages between the instrument panel and the engine controller
0.X.4B	Hand throttle	Signal in open circuit
0.X.4C	X358 - Outside temperature sensor / X541 - Temperature info shunt for automatic air conditioning	Outside temperature sensor connected to the instrument panel
0.X.4E	X236 - Electrohydraulic Orbitrol (gray connector)	Error on the steering unit
0.X.4F	X55 - Instrument panel	Power output error
0.X.54	X168 - Pneumatic brake system pressure sensor	Electrical signal too high or too low
0.X.5E	X235 - Front axle steering sensor (WAS sensor)	Electrical signal too high or too low
0.X.5F	X57 - Keypad Setup and Information Screen	Electrical signal too high or too low
0.X.61	X55 - Instrument panel	The 9.5 V output is too low or too high
0.X.63	X55 - Instrument panel	Internal temperature electrical signal is too high or too low

2.1.7 AGCO Power Tier 3/Stage IIIA engine and Tier 4F/Stage IV SCR Technology engine error codes

Description of the protection modes

In order to protect the engine, the electronic system activates a protection mode when certain error codes appear.

Standard protection modes for all engines:

No.	FMI	Components concerned	Causes	Stand ard modes	modes
4334	4	DEF or AdBlue™ pressure sensor	Voltage below normal		X
4340	3	DEF or AdBlue™ preheating suction line	Short circuit to +12 V		
4340	4	DEF or AdBlue™ preheating suction line	Short circuit to earth (-)		
4340	5	DEF or AdBlue™ preheating suction line	Open circuit		
4340	31	DEF or AdBlue™ preheating suction line	Excessive temperature		
4342	3	DEF or AdBlue™ preheating return line	Short circuit to +12 V		
4342	4	DEF or AdBlue™ preheating return line	Short circuit to earth (-)		
4342	5	DEF or AdBlue™ preheating return line	Open circuit		
4342	31	DEF or AdBlue™ preheating return line	Excessive temperature		
4344	2	DEF or AdBlue™ heating module	Invalid temperature signal		X
4344	3	DEF or AdBlue™ heating module	Short circuit to +12 V		
4344	4	DEF or AdBlue™ heating module	Short circuit to earth (-)		
4344	5	DEF or AdBlue™ heating module	Open circuit		
4344	8	DEF or AdBlue™ heating module	Fault with temperature range signal		X
4344	12	DEF or AdBlue™ heating module	No response from the temperature measurement		
4344	31	DEF or AdBlue™ heating module	Excessive temperature		
4346	3	DEF or AdBlue™ preheater pressure line	Short circuit to +12 V		
4346	4	DEF or AdBlue™ preheater pressure line	Short circuit to earth (-)		
4346	5	DEF or AdBlue™ preheater pressure line	Open circuit		
4346	31	DEF or AdBlue™ preheater pressure line	Excessive temperature		
4356	5	DEF or AdBlue™ module relay	Open circuit		
4360	2	DOC inlet temperature sensor	Incorrect temperature value		X
4360	3	DOC inlet temperature sensor	Voltage above normal or open circuit		X
4360	4	DOC inlet temperature sensor	Voltage below normal		X
4360	10	DOC inlet temperature sensor	Temperature value inconsistent		
4363	2	Exhaust outlet temperature sensor	Incorrect temperature value		X

No.	Components concerned	Causes
4.X.16		Electrical power supply (+APC < 7 V)
4.X.40	X483 - Intermediate speed sensor X482 - Theoretical forward speed sensor	Difference in value between the intermediate speed sensor and the forward travel speed sensor, depending on the range engaged
4.X.54	X19 - Transmission hydraulic oil temperature sensor	Value > 150°C or < -24°C
4.X.61	X484 - Range solenoid valve 1	Open circuit or short circuit to +12 V or 0 V
4.X.62	X485 - Range solenoid valve 2	Open circuit or short circuit to +12 V or 0 V
4.X.69	X486 - Range solenoid valve 3	Open circuit or short circuit to +12 V or 0 V
4.X.6A	X487 - Range solenoid valve 4	Open circuit or short circuit to +12 V or 0 V
4.X.6B	X488 - Range switch 1	Short circuit to 0 V
4.X.6C	X489 - Range switch 2	Short circuit to 0 V
4.X.6D	X490 - Range switch 3	Short circuit to 0 V
4.X.6E	X491 - Range switch 4	Short circuit to 0 V
4.X.85	X481 - Engine speed sensor/ X483 - Intermediate speed sensor	Slippage > 10% for more than 700 ms between engine speed and intermediate speed
4.X.90	X483 - Intermediate speed sensor	No intermediate speed value and current forward speed > 0 kph
4.X.91	X481 - Engine speed sensor	No engine speed value and current forward speed > 0 kph
4.X.92	X482 - Theoretical forward speed sensor	No forward speed value and actual intermediate speed is > 0
4.X.95	X484 - Range solenoid valve 1 X488 - Range switch 1	Inconsistency between the switch and range solenoid valve
4.X.96	X485 - Range solenoid valve 2 X489 - Range switch 2	Inconsistency between the switch and range solenoid valve
4.X.97	X486 - Range solenoid valve 3 X490 - Range switch 3	Inconsistency between the switch and range solenoid valve
4.X.98	X487 - Range solenoid valve 4 X491 - Range switch 4	Inconsistency between the switch and range solenoid valve
4.X.99	X478 - Powershift module solenoid valve P	Short circuit to +12 V Open circuit Measured current > 40 mA in relation to required value Current measured > maximum possible (1.4 A) Measured current < 13 mA in relation to required value

2.1.19 Air conditioning error codes

No.	Component(s) concerned	Cause(s)
10.X.01	X441 - Ventilation temperature sensor (TT1)	Sensor in open circuit
10.X.02	X441 - Ventilation temperature sensor (TT1)	Sensor short-circuited
10.X.03	X442 - Ventilation temperature sensor (TT2)	Sensor in open circuit
10.X.04	X442 - Ventilation temperature sensor (TT2)	Sensor short-circuited
10.X.05	X69 - Cab interior temperature sensor	Sensor in open circuit
10.X.06	X69 - Cab interior temperature sensor	Sensor short-circuited
10.X.07	X358 - Outside temperature sensor	Sensor in open circuit
10.X.08	X358 - Outside temperature sensor	Sensor short-circuited
10.X.09	X443 - Evaporator temperature sensor	Sensor in open circuit
10.X.10	X443 - Evaporator temperature sensor	Sensor short-circuited
10.X.11	X70 - Solar radiation sensor	The signal from the solar sensor is outside its limits or is giving an impossible value
10.X.14	X449 - Motor for left-hand heating shutter	The signal from the potentiometer of the left-hand recirculation actuator is outside its operating range
10.X.15	X449 - Motor for left-hand heating shutter X450 - Motor for right-hand heating shutter	The potentiometer reference is short-circuited to earth
10.X.16	X439 - Air conditioning control module (blue connector) X440 - Air conditioning control module (yellow connector)	Error in temperature selected, the signal is out of range
10.X.17	X439 - Air conditioning control module (blue connector)	Error from the fan potentiometer
10.X.18	X69 - Cab interior temperature sensor	Ambient temperature sensor fan fault
10.X.19	X451 - Motor for heating mixer shutter	Stepper motor output error (water valve)
10.X.20	X449 - Motor for left-hand heating shutter X450 - Motor for right-hand heating shutter	Left-hand and right-hand recirculation actuator motor output error
10.X.21	X318 - Air conditioning compressor	Air conditioning compressor relay output error

Number	Amperage	Size	Protected function
F28	15 A	Small	+APC <ul style="list-style-type: none"> • X87 - Linkage lifting switch on right-hand fender • X97 - Linkage lifting switch on left-hand fender • X111 - dynamic transmission mode switch Dyna-TM • X124 - Pedal/ mode switchLever • X127 - Front PTO engagement switch • X128 - Rear PTO engagement switch • X166 - Suspended front axle position sensor • X235 - Front axle steering sensor (WAS sensor) • X277 - Front linkage lifting switch • X618 - Parking brake sensor • X658 - Front linkage lowering switch • X664 - Linkage lowering switch on right-hand fender • X665 - Linkage lowering switch on left-hand fender • X884 - Hydraulic spool valve controls change-over switch
F29	10 A	Small	+APC <ul style="list-style-type: none"> • Transmission control module
F30	15 A	Small	+ APC X191 - Fuel preheater
F31	15 A	Small	+ APC X513 - Additional heater
F32	15 A	Small	+ APC X739 - Sensor detecting presence of operator in seat
F33	50 A	Large	Tractor +APC
F34	5 A	Small	+ BAT X55 - Instrument panel
F35	7.5 A	Small	+BAT <ul style="list-style-type: none"> • X104 - TECU controller • X105 - Datatronic CCD • X594 - unit AgCommand™

Number	Amperage	Size	Protected function
F42	10 A	Small	+ APC <ul style="list-style-type: none"> • X58 - Windscreen wiper and direction indicator control unit • X74 - Audible alarm supply (+12 V APC)
F43	10 A	Small	+ APC <ul style="list-style-type: none"> • X55 - Instrument panel • X717 - Linkage and PTO keypad on pillar
F44	5 A	Small	+ APC <ul style="list-style-type: none"> • X345 - Supply for additional terminal (Mitron unit) • Aerial Auto-Guide™
F45	5 A	Small	Not used
F46	15 A	Small	K24 relay power circuit supplying the + APC to the brake lights
F47	20 A	Average	Not used
F48	30 A	Average	+ BAT <ul style="list-style-type: none"> • X58 - Windscreen wiper and direction indicator control unit • X250 - Power socket in cab(on the front right-hand wheel arch)
F49	30 A	Average	+ BAT <ul style="list-style-type: none"> • Trailer connector (NA) • power circuit X815 - Panoramic cab + APC relay
F50	25 A	Average	+ BAT X271 - Front accessories connection socket (+12 V battery)
F51	30 A	Average	+ BAT <ul style="list-style-type: none"> • X157 - Left-hand side power socket (power) • X395 - Radio supply • X407 - Interior light • X439 - Air conditioning control module (blue connector) • X811 - Triflash switch (only for panoramic cabs) • X812 - Side windscreen wiper motor connection (only for panoramic cabs)

3.1.4 Battery isolator

Battery isolator

A device isolates the battery/batteries (depending on assembly) from all the other electrical equipment on the tractor.

This isolator is programmed for automatic cut-off after a delay of 60 minutes after switching off the ignition. Therefore, the operator does not have to activate the device; this system is self-managed in terms of activation and cut-off, depending on the position of the ignition key.

The isolator timer control can vary according to the tractor configuration.

The temporary control conditions for the closed isolator are as follows:

1. the time required to drain the DEF or AdBlue™ system
2. the Datatronic CCD standby time
3. power supply maintained on an ISOBUS or Auto-Guide™ implement

Whatever the status of the above conditions, the isolator will always open after a maximum period of 60 minutes after the ignition key has been set to the OFF position.

The permanent control condition for the closed isolator is as follows:

1. Activation of the hazard warning lights

NOTE:

The battery isolator will open once the hazard warning lights have been deactivated.

IMPORTANT:

In the event of electrical faults on the tractor or the implement, emergency cut-off of the isolator is possible via a switch located under the controllers housing cover plate in the cab, but only if the ignition key is in the OFF position. The DEF or AdBlue™ system is drained even after pressing the switch for the emergency cut-off of the battery isolator.

1. Open the cover plate (A) located on the cab floor (right-hand side).




Fig. 12

EFD00182 - Brake system (Italy)

EFD00183 - Implement attachment without Isobus


EFD00184 - AgCommand™

4.1.2 Identification of electrical connectors from X1 to X500

- X1** - Auxiliary hydraulic oil temperature sensor
- X2** - Auxiliary hydraulic filter blockage sensor
- X3** - 540E rpm PTO speed solenoid valve
- X4** - 1000 rpm PTO speed solenoid valve
- X5** - 4-wheel drive solenoid valve
- X6** - Differential lock solenoid valve
- X7** - Rear PTO solenoid valve
- X8** - Bevel gear theoretical speed sensor
- X9** - Transmission oil high pressure sensor 1
- X10** - Collector shaft speed sensor
- X11** - Solenoid valve limiting speed to 30 km/h
- X12** - Coupler function solenoid valve
- X13** - High speed range (Hare) solenoid valve
- X14** - Low speed range (Tortoise) solenoid valve
- X15** - PTO clutch speed sensor
- X16** - PTO output shaft speed sensor
- X17** - High/low speed range (Hare/Tortoise) position sensor
- X18** - Transmission control module
- X19** - Transmission hydraulic oil temperature sensor
- X20** - Transmission filter blockage sensor
- X22** - Radar
- X23** - Steering pressure sensor
- X24** - Auxiliary hydraulic oil gage
- X25** - Engine speed sensor
- X27** - Rear linkage lifting solenoid valve
- X28** - Rear linkage lowering solenoid valve
- X29** - Dual Control socket connector
- X30** - Rear linkage position sensor
- X30a** - Position sensor for normal-capacity rear linkage
- X31** - Rear linkage right-hand draft sensor
- X32** - Rear linkage left-hand draft sensor
- X32** - Top link draft sensor
- X33** - Connector for the electrohydraulic spool-valves supply
- X34** - Transmission oil high pressure sensor 2

- X403** - Rear windscreen wiper motor
- X404** - Door switch
- X405** - Interior light (earth)
- X406** - Interior light (control)
- X407** - Interior light
- X408** - Right-hand console light
- X409** - Left-hand rotary beacon
- X410** - Right-hand rotary beacon
- X411** - Rear windscreen wiper switch
- X412** - Radio antenna
- X413** - Earth (antenna)
- X414** - Left-hand number plate lighting
- X414-A** - Left-hand number plate lighting supply
- X414-B** - Left-hand number plate lighting earth
- X415** - Right-hand number plate lighting
- X415-A** - Right-hand number plate lighting supply
- X415-B** - Right-hand number plate lighting earth
- X416** - Radio supply
- X416-A** - Reverse connector of the radio battery supply, tractor side
- X416-B** - Reverse connector of the radio battery supply, radio side
- X417** - Radio speaker connector
- X417-A** - Reverse connector of the supply after radio is switched on, tractor side
- X417-B** - Reverse connector of the supply after radio is switched on, radio side
- X418** - Earth
- X419** - Earth
- X420** - Rotary beacon harness earth (chassis)
- X421** - Earth
- X422** - Roof harness earth (chassis)
- X423** - Left-hand side fan ON/OFF switch
- X424** - Fan speed control knob
- X425** - Air conditioning switch
- X426** - Air conditioning indicator light
- X427** - Manual air conditioning module
- X428** - Electronic thermostat for heating
- X429** - Speed 1 relay for fan
- X430** - Speed 2 relay for fan
- X431** - Speed 3 relay for fan
- X432** - Speed 4 relay for fan

- X847** - Protection fuse for the engine controller supply
- X848** - Protection fuse for the fuse box supply
- X849** - EGR temperature sensor
- X850** - Electrical pack connection for joysticks 1 and 2
- X851** - Valtra sensor for defrosting ECR system
- X852** - Mid Mounted cab harness/cab harness connection
- X853** - Mid Mounted cab harness/Mid Mounted harness connection
- X854** - Electrohydraulic unit controller
- X855** - Spool 2 position sensor
- X856** - Spool 1 position sensor
- X857** - Electrohydraulic block supply solenoid valve
- X858** - Solenoid valve B1
- X859** - Solenoid valve A2
- X860** - Solenoid valve A1
- X861** - Solenoid valve B2
- X865** - Crosswiring connector 2 (CW2)
- X866** - input temperature sensor DOC (catalyseur d'oxydation diesel)
- X867** - Protection fuse for the valve EGR
- X868** - Protection fuse for the turbocharger wastegate
- X869** - Battery isolator protection fuse
- X871** - Cooling system pressure sensor
- X877** - Earth relay for the side/rear windscreen washer pump
- X878** - Power relay for the rear windscreen washer pump
- X879** - Fuse for the side/rear windscreen washer pump
- X880** - Fuse for the side windscreen washer switch
- X875** - Loader selector sensor
- X881** - Relay for the valve EGR
- X882** - FingerTIP 7
- X883** - FingerTIP 8
- X884** - Hydraulic spool valve controls change-over switch
- X885** - Rear lighting harness/windscreen washer pump 2 harness connection
- X886** - Supply fuse for the NOX sensors
- X887** - Supply relay for the NOX sensors, for the EGR valve and for the turbocharger wastegate
- X888** - Diagnostics connector
- X891** - Steering pressure sensor/standby pump
- X892** - PTO neutral solenoid valve
- X892** - Standard speed PTO solenoid valve
- X897** - Rear-linkage raised position adjustment potentiometer



EFD00101_17

Fig. 6

4.1.5.7 EFD00101_18 - Differential lock Dyna-6

EFD00101_18 - Differential lock Dyna-6






Fig. 26

4.1.5.27 EFD00111_35 - GTA2520 transmission Dyna-4 Load Sensing_1/2
EFD00111_35 - GTA2520 transmission Dyna-4 Load Sensing_1/2





EFD0122_9

Fig. 46

4.1.5.47 EFD00123 - C3000
EFD00123 - C3000




Fig. 56

4.1.5.57 EFD00128_18 - NA/SAE cab power socket
EFD00128_18 - NA/SAE cab power socket




Fig. 76

4.1.5.77 EFD00131_35 - CAN network Dyna-6 (tractor)_5/7 with Tier 4F/Stage IV SCR Technology engine and cab harnesses ACW005780-ACW005784-4392642
 EFD00131_35 - CAN network Dyna-6 (tractor)_5/7 with Tier 4F/Stage IV SCR Technology engine and cab harnesses ACW005780-ACW005784-4392642




Fig. 86

4.1.5.87 EFD00131_39 - CAN network Dyna-6 (tractor_5/7 with Tier 4F/Stage IV SCR Technology engine and cab harness ACW039167
EFD00131_39 - CAN network Dyna-6 (tractor_5/7 with Tier 4F/Stage IV SCR Technology engine and cab harness ACW039167




Fig. 96

4.1.5.97 EFD00135_11 - Ventilation for tractors with standard roof

EFD00135_11 - Ventilation for tractors with standard roof




Fig. 116

4.1.5.117 EFD00141_97 - Work lights EFD00141_97 - Work lights




Fig. 126

4.1.5.127 EFD00148_13 - Audible alarm
 EFD00148_13 - Audible alarm




Fig. 136

EFD00157_6

4.1.5.137 EFD00159_18 - Hydraulic spool valves Dyna-VT
EFD00159_18 - Hydraulic spool valves Dyna-VT

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL




Fig. 146

4.1.5.147 EFD00162_12 - Dual Control linkage and trailed implements (TIC) Dyna-6
EFD00162_12 - Dual Control linkage and trailed implements (TIC) Dyna-6





Fig. 156

4.1.5.157 EFD00169_19 - Controller power supply Dyna-6 - linkage
EFD00169_19 - Controller power supply Dyna-6 - linkage



EFD00172_6_1/2

Fig. 166

DIN	Pin	Connector	Function	Name of wire	Color of wire
L	1	X271	+ battery	X 271.1/S2.1	Brown
54G	2	X275	Work lights	X 275.1/X 290.6	White
31	3	X276	Earth	X 276.1/S3.1	Black
R	4	X272	+ 12 V APC	X 272.1/X 290.5	Red
58R	5	X273	Side lights	X 273.1/S1.1	White
54	6	X270	Rotary beacon	X 270.1/X 290.2	White
58L	7	X274	Side lights	X 274.1/S1.1	White

4.1.5.167 EFD00172_6 - Front accessory connection socket_2/2
EFD00172_6 - Front accessory connection socket_2/2




Fig. 176


4.1.5.177 EFD00176 - LoaderALO
EFD00176 - LoaderALO

5. Harnesses

5.1 Harnesses	5-5
5.1.1 Identification of harnesses	5-5
5.1.2 Identification table for cable colors	5-8
5.1.3 Harnesses	5-11
5.1.3.1 FAI200 - Engine harness cab - ACW0349940_1/2	5-11
5.1.3.2 FAI200 - Engine harness cab - ACW0349940_2/2	5-12
5.1.3.3 FAI200 - Engine harness - ACW061250_1/4	5-13
5.1.3.4 FAI200 - Engine harness - ACW061250_2/4	5-14
5.1.3.5 FAI200 - Engine harness - ACW061250_3/4	5-15
5.1.3.6 FAI200 - Engine harness - ACW061250_4/4	5-16
5.1.3.7 FAI201 - Front headlights harness - 4388041_1/2	5-17
5.1.3.8 FAI201 - Front headlights harness - 4388041_2/2	5-18
5.1.3.9 FAI202 - Suspended front axle harness - ACW033127_1/2	5-19
5.1.3.10 FAI202 - Suspended front axle harness - ACW033127_2/2	5-20
5.1.3.11 FAI203 - Transmission harness Dyna-VT - 4389481_1/3	5-21
5.1.3.12 FAI203 - Transmission harness Dyna-VT - 4389481_2/3	5-22
5.1.3.13 FAI203 - Transmission harness Dyna-VT - 4389481_3/3	5-23
5.1.3.14 FAI203 - Transmission harness Dyna-4/Dyna-6 GTA2520 - ACW104556_1/3	5-24
5.1.3.15 FAI203 - Transmission harness Dyna-4/Dyna-6 GTA2520 - ACW104556_2/3	5-25
5.1.3.16 FAI203 - Transmission harness Dyna-4/Dyna-6 GTA2520 - ACW104556_3/3	5-26
5.1.3.17 FAI205 - Electrohydraulic valves harness - 4292090	5-27
5.1.3.18 FAI205 - Electrohydraulic valves harness - 4292091	5-28
5.1.3.19 FAI205 - Electrohydraulic valves harness - 4292093	5-29
5.1.3.20 FAI205 - Electrohydraulic valves harness - 4387694	5-30
5.1.3.21 FAI208 - Linkage with Dual Control and TIC harness - 4387797_1/2	5-31
5.1.3.22 FAI208 - Linkage with Dual Control and TIC harness - 4387797_2/2	5-32
5.1.3.23 FAI210 - Cab transmission harness Dyna-4 municipal - 4391826_1/8	5-33
5.1.3.24 FAI210 - Cab transmission harness Dyna-4 municipal - 4391826_2/8	5-34
5.1.3.25 FAI210 - Cab transmission harness Dyna-4 municipal - 4391826_3/8	5-35
5.1.3.26 FAI210 - Cab transmission harness Dyna-4 municipal - 4391826_4/8	5-36
5.1.3.27 FAI210 - Cab transmission harness Dyna-4 municipal - 4391826_5/8	5-37
5.1.3.28 FAI210 - Cab transmission harness Dyna-4 municipal - 4391826_6/8	5-38
5.1.3.29 FAI210 - Cab transmission harness Dyna-4 municipal - 4391826_7/8	5-39
5.1.3.30 FAI210 - Cab transmission harness Dyna-4 municipal - 4391826_8/8	5-40
5.1.3.31 FAI210 - Cab transmission harness Dyna-6 municipal - 4392642_1/9	5-41
5.1.3.32 FAI210 - Cab transmission harness Dyna-6 municipal - 4392642_2/9	5-42
5.1.3.33 FAI210 - Cab transmission harness Dyna-6 municipal - 4392642_3/9	5-43
5.1.3.34 FAI210 - Cab transmission harness Dyna-6 municipal - 4392642_4/9	5-44
5.1.3.35 FAI210 - Cab transmission harness Dyna-6 municipal - 4392642_5/9	5-45
5.1.3.36 FAI210 - Cab transmission harness Dyna-6 municipal - 4392642_6/9	5-46
5.1.3.37 FAI210 - Cab transmission harness Dyna-6 municipal - 4392642_7/9	5-47
5.1.3.38 FAI210 - Cab transmission harness Dyna-6 municipal - 4392642_8/9	5-48
5.1.3.39 FAI210 - Cab transmission harness Dyna-6 municipal - 4392642_9/9	5-49
5.1.3.40 FAI210 - Cab transmission harness Dyna-6 long console - ACW005784_1/8	5-50
5.1.3.41 FAI210 - Cab transmission harness Dyna-6 long console - ACW005784_2/8	5-51
5.1.3.42 FAI210 - Cab transmission harness Dyna-6 long console - ACW005784_3/8	5-52
5.1.3.43 FAI210 - Cab transmission harness Dyna-6 long console - ACW005784_4/8	5-53
5.1.3.44 FAI210 - Cab transmission harness Dyna-6 long console - ACW005784_5/8	5-54
5.1.3.45 FAI210 - Cab transmission harness Dyna-6 long console - ACW005784_6/8	5-55
5.1.3.46 FAI210 - Cab transmission harness Dyna-6 long console - ACW005784_7/8	5-56
5.1.3.47 FAI210 - Cab transmission harness Dyna-6 long console - ACW005784_8/8	5-57

5.1.3 Harnesses

5.1.3.1 FAI200 - Engine harness cab - ACW0349940_1/2



FAI200-ACW0349940_1/2

Fig. 1

5.1.3.11 FAI203 - Transmission harness Dyna-VT - 4389481_1/3





Fig. 11

5.1.3.21 FAI208 - Linkage with Dual Control and TIC harness - 4387797_1/2



4387797_1/2

Fig. 21

5.1.3.31 FAI210 - Cab transmission harness Dyna-6 municipal - 4392642_1/9




Fig. 31

5.1.3.41 FAI210 - Cab transmission harness Dyna-6 long console - ACW005784_2/8




Fig. 41

5.1.3.51 FAI210 - Cab transmission harness Dyna-4 long console - ACW017847_4/7




Fig. 51

5.1.3.61 FAI210 - Cab transmission harness Dyna-VT short console - ACW039162_7/9




Fig. 61

5.1.3.71 FAI210 - Cab transmission harness Dyna-6 short console - ACW039167_8/9




Fig. 71

5.1.3.81 FAI212 - Lighting harness NA - 4389034_3/3




Fig. 81

FAI212-4389034-3

5.1.3.91 FAI223 - Roof harness_High visibility_4375395_3/3




Fig. 91

5.1.3.101 FAI227 - Roof harness with automatic air conditioning - 4352621_3/3




Fig. 101

5.1.3.111 FAI261 - Isobus harness - 4353130_2/2




Fig. 111

5.1.3.121 FAI272 - Suspended cab harness Dyna-6 - ACW039185_1/2





Fig. 121

5.1.3.131 FAI287 - ALO loader harness external without multi-function armrest - 4378794_1/2



FAI287-4378794_1/2

Fig. 131

5.1.3.141 FAI293 - EAME indicator harness - 4355520_1/2




Fig. 141

5.1.3.151 FAI307 - Datatronic 4 harness - 4390934_1/2




Fig. 151

FAI074390934_1/2

5.1.3.161 FAI321 - GSPTO harness - ACW008066_1/2




Fig. 161

5.1.3.171 FAI340 - Battery/fuse box positive cable harness - ACW029172




Fig. 171

6. Hydraulics diagrams

6.1 Hydraulics diagrams	6-3
6.1.1 Hydraulics diagrams	6-5
6.1.1.1 HFD01022 - Standard auxiliary hydraulics diagram ML180/ML140	6-5
6.1.1.2 HFD01032 - Standard hydraulics diagram, GTA2520 Open Center 57 L/min	6-6
6.1.1.3 HFD01034 - Standard hydraulics diagram, GTA2520 Open Center 100 L/min	6-7
6.1.1.4 HFD01047 - Standard hydraulics diagram, GTA2520 Load Sensing	6-8
6.1.1.5 HFD01060 - Auxiliary hydraulics diagram with all options, ML140	6-9
6.1.1.6 HFD01061 - Auxiliary hydraulics diagram: all options, GTA2520 Load Sensing	6-10
6.1.1.7 HFD01062 - Auxiliary hydraulics diagram: all options, GTA2520 Open Center 57 l/min	6-11
6.1.1.8 HFD01063 - Auxiliary hydraulics diagram: all options, GTA2520 Open Center 100 l/min	6-12
6.1.1.9 HFD02009 - ML180/ML140 Auto-Guide™/SpeedSteer steering system hydraulics diagram	6-13
6.1.1.10 HFD02010 - ML140/ML180 standard steering system hydraulics diagram	6-14
6.1.1.11 HFD03040 - Hydraulics diagram: ML180/ML140 brake system with trailer air brake	6-15
6.1.1.12 HFD03041 - Hydraulics diagram: ML180/ML140 brake system without trailer brake	6-16
6.1.1.13 HFD03052 - Hydraulics diagram: GTA2520 Open Center 57 L/min assisted braking	6-17
6.1.1.14 HFD03056 - Hydraulics diagram: GTA2520 Open Center 100 L/min assisted braking	6-18
6.1.1.15 HFD03059 - Hydraulics diagram: GTA2520 Load Sensing high-pressure braking with pneumatic trailer brake and Auto-Guide™ steering	6-19
6.1.1.16 HFD03060 - Hydraulics diagram: GTA2520 Load Sensing high pressure braking with trailer air brake	6-20
6.1.1.17 HFD03061 - Hydraulics diagram: GTA2520 Load Sensing assisted braking with pneumatic trailer brake and Auto-Guide™ steering	6-21
6.1.1.18 HFD03062 - Hydraulics diagram: GTA2520 Load Sensing assisted braking with trailer air brake	6-22
6.1.1.19 HFD03063 - Hydraulics diagram: GTA2520 Load Sensing high-pressure braking and Auto-Guide™ steering	6-23
6.1.1.20 HFD03064 - Hydraulics diagram: GTA2520 Load Sensing high pressure braking	6-24
6.1.1.21 HFD03065 - Hydraulics diagram: GTA2520 Load Sensing assisted braking and Auto-Guide™ steering	6-25
6.1.1.22 HFD03066 - Hydraulics diagram: GTA2520 Load Sensing assisted braking	6-26
6.1.1.23 HFD03075 - Hydraulics diagram: Open Center 57 l/min assisted braking with front suspension and trailer brake	6-27
6.1.1.24 HFD03076 - Hydraulics diagram: Open Center 57 l/min high-pressure braking with front suspension and trailer brake	6-28
6.1.1.25 HFD03077 - Hydraulics diagram: Open Center 57 l/min high-pressure braking and front suspension	6-29
6.1.1.26 HFD03078 - Hydraulics diagram: Open Center 100 l/min assisted braking with front suspension and trailer brake	6-30
6.1.1.27 HFD03079 - Hydraulics diagram: Open Center 100 l/min high-pressure braking with front suspension and trailer brake	6-31
6.1.1.28 HFD03080 - Hydraulics diagram: Open Center 100 l/min high-pressure braking and front suspension	6-32
6.1.1.29 HFD04004 - ML140/ML180 rear linkage hydraulics diagram	6-33

6.1.1.7 HFD01062 – Auxiliary hydraulics diagram: all options, GTA2520 Open Center 57 l/min




Fig. 7

6.1.1.17 HFD03061 - Hydraulics diagram: GTA2520 Load Sensing assisted braking with pneumatic trailer brake and Auto-Guide™ steering




Fig. 17

6.1.1.27 HFD03079 - Hydraulics diagram: Open Center 100 l/min high-pressure braking with front suspension and trailer brake




Fig. 27

6.1.1.37 HFD06014 - Hydraulics diagram: GTA2520 Load Sensing rear spool valves, four electrohydraulic and Power Beyond




Fig. 37

- 1V1** - Cooler bypass valve
- 1V2** - Flushing pressure relief valve
- 1V3** - Charge pressure relief valve
- 1V4** - Lubricating pressure relief valve
- 1V5** - Service pump pressure relief valve
- 1V6** - System pressure relief valve
- 1Z1** - Intake filter with bypass
- 1Z2** - Pressure filter with bypass
- 1Z3** - Transmission oil cooler
- 1Z4** - Transmission lubrication
- 1Z5** - Auxiliary hydraulic oil/transmission oil cooler
- 2A1** - Hydrostatic motor
- 2P1** - Hydrostatic pump
- 2V1** - Forward charge non-return valve
- 2V2** - Reverse charge non-return valve
- 2V3** - Forward high-pressure relief valve
- 2V4** - Reverse high-pressure relief valve
- 2V5** - Flushing valve
- 2V6** - Shuttle valve
- 3A1** - Piston for setting the hydrostatic pump displacement
- 3A2** - Piston for setting the hydrostatic motor displacement
- 3A3** - Forward speed limiter in limp home mode
- 3V1** - Hydrostatic pump control spool valve
- 3V2** - Hydrostatic motor control spool valve
- 3Z1** - Cam channel adjustment shaft
- 3Z2** - Control unit
- 4A1** - Forward range selector
- 4S1** - Pressure sensor
- 4S2** - Pressure sensor
- 4V1** - Low-speed range (Tortoise) solenoid valve
- 4V2** - High-speed range (Hare) solenoid valve
- 4V3** - Forward speed limiting solenoid valve
- 4V4** - Coupler function solenoid valve
- 4V7** - High-pressure shock relief valve
- 5A1** - Right-hand brake cylinder
- 5A2** - Left-hand brake cylinder
- 5A3** - Universal joint shaft brake
- 5V1** - Cooling oil valve, right-hand brake
- 5V2** - Cooling oil valve, left-hand brake
- 5V4** - Universal joint brake control valve
- 5V5** - Cooling oil valve, universal joint brake
- 5Z2** - Rear PTO lubrication
- 5Z3** - Differential and right-hand brake lubrication
- 5Z4** - Differential and left-hand brake lubrication
- 5Z5** - Universal joint brake lubrication
- 6A1** - Rear PTO clutch
- 6A2** - 540 rpm PTO selector piston
- 6A3** - Economy PTO selector piston
- 6A4** - Front axle clutch
- 6A5** - Rear axle differential lock
- 6A6** - 1000 rpm PTO selector piston
- 6A7** - Front axle differential lock
- 6A8** - Standard PTO selector piston
- 6V1** - Rear PTO clutch solenoid valve
- 6V2** - 540 rpm PTO control solenoid valve
- 6V3** - Economy PTO control solenoid valve
- 6V4** - Front axle clutch solenoid valve
- 6V5** - Differential lock solenoid valve
- 6V6** - 1000 rpm PTO control solenoid valve
- 6V8** - Standard PTO control solenoid valve
- M1** - Pressure upstream of cooler (KV)
- M2** - Lubricating pressure (SM)
- M3** - Flushing pressure (AS)
- M4** - Charge pressure (ES)
- M5** - Service pump pressure (PU)
- M6** - Transmission system pressure (P)
- M7** - Low-speed range engaging pressure (Tortoise) (I)
- M8** - High-speed range engaging pressure (Hare) (II)
- M9** - High pressure (PH)
- M10** - Rear axle and brake system pressure (P)
- M11** - Rear PTO clutch pressure
- M12** - 540 rear PTO selector pressure
- M13** - Economy rear PTO selector pressure
- M14** - Front axle clutch pressure
- M15** - Differential lock pressure
- M16** - 1000 rpm rear PTO selector pressure
- M22** - Oil leak from clutch or coupler function valve
- M24** - Oil leak from high-pressure shock valve (T)
- M30** - Standard rear PTO selector pressure

8.1 Bleeding

8.1.1 Bleeding: Dyna-VT - Assisted brake master cylinders

8.1.1.1 Charge connector

(A) Charge connector for the braking system




Fig. 1

8.1.1.2 Pressure connector

(B) Supply for charging the braking system




Fig. 2

8.1.1.3 Bleed screw locations

Main brakes

- (L) Left-hand brake bleed screw
- (R) Right-hand brake bleed screw
- (F) Front universal joint brake bleed screw

The bleed screws are located on the auxiliary hydraulic spool valve support.




Fig. 3

8.2 Calibrations

8.2.1 Calibration of the clutch pedal sensor

Calibration of the clutch pedal sensor

Calibration procedure

The calibration of the clutch pedal potentiometer must be carried out each time one of the following elements is replaced or modified:

- clutch pedal switch
- instrument panel.

NOTE: *This calibration is carried out with the engine stopped.*

Procedure

1. Switch on the ignition.
2. Press down the clutch pedal and keep it depressed.
3. Lift the Power Control lever arm (PowerShuttle) and keep it raised throughout the calibration procedure.
4. An alarm sounds. Slowly release the clutch pedal.
5. The alarm will stop. Fully release the clutch pedal.
6. The alarm will sound again. Release the Power Control lever arm (PowerShuttle).
7. Switch off the ignition for at least 5 seconds to validate calibration.

8.2.2 Calibration of the throttle pedal sensor

Calibration of the throttle pedal sensor

Calibration procedure

The calibration of the throttle pedal potentiometer must be carried out each time one of the following elements is replaced or modified:

- Throttle potentiometer
- instrument panel.



WARNING:
This calibration is carried out with the engine stopped.

The calibration is carried out in two successive steps so as to determine the minimum and maximum engine speeds in relation to the position of the pedal.

Procedure

1. Switch on the ignition, with the Power Control (PowerShuttle) lever in neutral.

NOTE: *The power take-off must be disengaged.*

Minimum speed

2. When the pedal is fully released, this corresponds to minimum engine speed.
3. Press and hold down the differential lock switch for 5 seconds.
4. An alarm sounds. This indicates the end of the first calibration phase (pedal fully released).

NOTE:

The daily hourmeter resets to 0 after 5 seconds.

3. "CAL" should appear on the screen .
4. Drive the tractor forward at normal working speed.

NOTE:

The tractor must be moving at a constant speed before starting out on the measured course. Otherwise, the calibration is not correct.

5. Press the display selector switch (A) when the starting line of the 100 m course has been passed.
6. "run" should appear on the screen .
7. Press the display selector switch (A) when the finish line of the course has been passed.
8. Press the display selector switch (A). The constant forward speed (theoretical) measured during calibration is displayed.
9. Press the display selector switch (A) again. The actual constant forward speed (radar) measured during calibration is displayed on tractors fitted with radar.
10. Press the display selector switch (A) one final time to return the instrument panel to normal operating mode.




Fig. 36




Fig. 37

8.2.9 Front power take-off calibration for Dyna-4/Dyna-6

Front power take-off calibration for Dyna-4/Dyna-6

General**NOTE:**

This calibration must be performed only in the event of a starting problem with a high-inertia implement

- When changing the PTO solenoid valve
- Transmission controller


NOTE:

The tractor engine must be running.

NOTE: To access the calibration menu on the instrument panel, see chapter 8.2.12 *Dyna-VT transmission calibrations: Introduction and access to calibration using the instrument panel*, page 8-28.

4.



After having selected  in the CAL1 screen, press "OK" to start calibration.

5. Engage the rear PTO.

6. Calibration takes place automatically, and the time taken depends on the implement.

7. The calibration result is displayed:

- "OK": successful calibration
- "ERROR": calibration failed


8. **Switch off the ignition for at least 30 seconds in order to validate the calibration.**

Fig. 50

8.2.17 Front power take-off calibration for Dyna-VT

Front power take-off calibration

NOTE:

Calibration procedure

This calibration must be performed only in the event of a starting problem with a high-inertia implement

- When changing the PTO solenoid valve
- Transmission controller

For optimum calibration, the implement must be connected.

Preliminary conditions


1. Hand brake applied or ParkLock engaged.
2. Power Control lever in neutral position.

Calibration

NOTE: To access the calibration menu on the instrument panel, see chapter 8.2.12 *Dyna-VT transmission calibrations: Introduction and access to calibration using the instrument panel*, page 8-28.

3.



After having selected  in the CAL1 screen, press "OK" to start calibration.

4. Engage the front PTO.

5. Calibration takes place automatically, and the time taken depends on the implement.

6. The calibration result is displayed:

- "OK": successful calibration
- "ERROR": calibration failed


7. **Switch off the ignition for at least 30 seconds in order to validate the calibration.**

Fig. 51


Procedure

Fig. 63

(1) Calibration of the FingerTIPs

(2) Start calibration

1. Select "FingerTIP"**2.** Then click on the button (2) to start calibration

Fig. 64

(1) Selecting the FingerTIP controls on the armrest

(3) Close the screen

(2) Selecting the FingerTIP controls on the console

3. Click on the button (2) to begin calibration of FingerTIPs from the console.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL