

**HITACHI**

# **Training Text**

**LX130-7/160-7/190-7/230-7**

**Operational Principle**

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

## ENGINE AND RELATED COMPONENTS



### ENGINE

#### General Description



The engine mounted on this loader is a 4-cycle, water-cooled, in-line direct-injection type diesel engine. Each engine is equipped with a turbocharger.

The engine is mounted at the rear of the loader and its power is transmitted through the flywheel, coupling gear, and the torque converter, into the transmission.


In a Model LX130-7, the flywheel and torque converter are connected through the input plate instead of the coupling gear.






Installation of radiator hose



1-013

 NOTE: This sketch shows the cooling system of the LX130-7.

 NOTE: 1.  5.9 N-m {0.6 kg-m} [4.3 lbf-ft]

2.  Tube end: Sealing agent (Japan Hermetic Co., Ltd. Herme-seal SS-80); it should not be applied to the inner side of the hose.

- |                        |                        |                   |
|------------------------|------------------------|-------------------|
| 1- Hose                | 4- Radiator            | 7- Reservoir Tank |
| 2- Engine              | 5- Radiator Lower Hose | 8- Shroud         |
| 3- Radiator Upper Hose | 6- Shroud              | 9- Shroud         |


Fig. 1.6 Engine Cooling System

## ENGINE CONTROL UNIT

### Accelerator Pedal

The engine speed is controlled by operating the accelerator pedal.

When the accelerator pedal is pressed, the governor control lever of the engine is actuated through the control cable so that an engine speed most suited to the working condition is obtained.




- 1- Accelerator Pedal Assembly
- 2- Cable
- 3- Bracket
- 4- (Engine)
- 5- Pedal

- 6- Pin
- 7- Push Rod
- 8- Bellows
- 9- Body
- 10- Stopper Bolt

- 11- Pin
- 12- Hanger Plate
- 13- Return Spring
- 14- Lever
- 15- Bearing

1-022

**Fig. 1.15** Accelerator Pedal



2-019

NOTE: 1. 39 – 45 N-m {4.0 – 4.6 kgf-m} [29 – 33 lbf-ft]

2. 51 – 58 N-m {5.2 – 6.0 kgf-m} [38 – 43 lbf-ft]

3. *Align the arrows of the oil outlet grooves in the stator holder and stator hub.*

- |                                  |                   |                     |
|----------------------------------|-------------------|---------------------|
| 1- Taper Plug                    | 5- Impeller Hub   | 10- Pump Drive Gear |
| 2- Cover Wheel                   | 6- Input Guide    | 11- Stator Holder   |
| 3- Coupling Gear<br>(Drive Ring) | 7- Stator Hub     | 12- Turbine Shaft   |
| 4- Turbine Wheel                 | 8- Stator Wheel   | 13- Oil Seal Ring   |
|                                  | 9- Impeller Wheel | 14- Oil Seal Ring   |


**Fig. 2.8** Converter Wheel Assembly (LX160-7)

## TRANSMISSION CONTROL VALVE

The transmission control valve selectively sends oil to each clutch so as to change over the directions and speeds of the loader.

The control valve consists of a valve body and 4 solenoid valves. The solenoid valves are engaged and disengaged by the transmission control switch (shift lever), to shift the spool in the valve to control the clutch lock-up oil.

The control valve also has a modulation mechanism which operates differently according to the speed ranges. It is possible to operate the control valve manually if the electric system fails to operate normally.



2-037

- |                                    |  |                        |
|------------------------------------|--|------------------------|
| 1- Plate<br>(For Manual Operation) | 11- Spool A  | 21- Spring             |
| 2- Cover                           | 12- Selector Spring  | 22- Flow Sensing Spool |
| 3- Cover                           | 13- Spool B  | 23- Spring             |
| 4- Cover                           | 14- Selector Spring  | 24- Pin                |
| 5- Solenoid Valve                  | 15- Orifice, 0.8 mm [0.031 in.] dia.<br>(For Solenoid Valve) | 25- Rod                |
| 6- Adapter                         | 16- Orifice (W)*   | 26- Spring, Inner      |
| 7- Valve Body (Lower)              | 17- Orifice (Z)*   | 27- Spring, Center     |
| 8- F/R Selector Spool              | 18- Orifice (Y)*   | 28- Spring, Outer      |
| 9- Adapter                         | 19- Orifice (X)*   | 29- Load Piston H      |
| 10- Spring                         | 20- Valve Body (Upper)                                       | 30- Regulator Spool    |
|                                    |  | 31- Piston             |

\* See Note

Fig. 2.18 Transmission Control Valve (1)

5. Fwd And 2nd Speed Clutches In Engagement (Point E In Fig. 2.21)


- 5.1 Since The Solenoids A And B Are In The ON State, The Speed Spools A And B Move To The Right In The Figure.
- 5.2 The Oil Which Entered Circuit (8) Flows Into Circuit (23). It Then Passes Through The Drilled Holes In The Spool, To Circuit (24) ,From Which Some Of The Oil Passes Orifice (X) Into The Load Piston Chamber (20).
- 5.3 At The Same Time, The Other Flows From Circuit (24) Into Circuit (27) Of The Spool B. The Oil Leaving The Circuit (27) Flows Through The Circuit (28) And Orifice (Y) If Circuit (29), Into The Load Piston Chamber (20).
- 5.4 In Other Words, When The Shift Lever Is Put In 2nd Speed, The Oil Flows Through Orifices (X, Y), So That The Time Needed For The Clutch Oil Pressure To Build Up Is Shorter Than When The 1st Speed Clutch (The Oil Passes Through Orifice (X) Alone) Is Selected.

## 1. General Description

The ATC (Automatic Transmission Controller) controls the transmission automatically based on the loader traveling speed and engine rpm.

The ATC has the following features:

- 1.1 The transmission shifts into the 2nd speed gear when the engine is started. The 2nd speed gear is selected for digging and loading; the 3rd speed gear for load & carry operation; the 4th speed gear for traveling and moving. (The speed range is automatically selected depending upon the shift lever position.)
- 1.2 It is possible to shift into a suitable gear position using the DSS (Down Shift Switch) and USS (Up Shift Switch).
- 1.3 The kick-down function quickens shifting down when climbing an uphill.
- 1.4 The transmission does not shift up when descending a downhill with the engine at low rpm, because the engine brake is used.
- 1.5 The over-run function protects the clutch assembly.
- 1.6 To protect the clutch assembly, the direction of travel is switched over (from forward to reverse or vice versa) after changing over the speed gears properly. (See 4. F-R selection pattern.)

 **NOTE:** When the Auto/Manual switch is in Manual, the operator shifts the gears using the transmission shift lever. (Automatic gearshifting function is not available.)

### ATC operates as follows when the key switch is turned on.

- When the key switch is turned on, the ATC checks the operation of the transmission solenoid valves.
- During this checking process, the loader won't move in either direction even if the shift lever is placed in forward or reverse.
- The ATC checks the operation of the forward and reverse solenoid valves, respectively, when the shift lever is placed in forward or reverse.

## 2. Relationship between shift lever positions and gearshift pattern

		Speed range			
		1	2	3	4
Lever position	1	○			
	2	○	○		
	3	○	○	○	
	4	○	○	○	○

○: Fixed speed range in manual mode

When the DSS is pressed with the gears in the 4th speed, the transmission shifts from the 4th speed to the 3rd speed. (Press DSS once)

When the DSS is pressed with the gears in the 3rd speed, the transmission shifts from the 3rd speed to the 2nd speed. (Press DSS once)


When the DSS is pressed and held down with the gears in the 4th speed, the transmission shifts from the 4th speed to the 3rd speed and then to the 2nd speed.


(For the 1st speed, release the DSS switch and then press it once.)

When the USS is pressed with the gears in the 2nd speed, the transmission shifts from the 2nd speed to the 3rd speed. (When the shift lever is in "3" or "4", press the USS once.)

When the USS is pressed with the gears in the 3rd speed, the transmission shifts from the 3rd speed to the 4th speed. (When the shift lever is in "4", press the USS once.)

The transmission shifted into the 1st speed by the DSS, will shift into the 2nd speed when the USS is pressed.

 **NOTE:** The transmission won't shift up, or from the 2nd speed to 3rd speed and to the 4th speed even if the USS is pressed and held down.



A: Brake Piping Ports, 2 points

- NOTE:**
- 1. 225 N-m {23 kgf-m} [170 lbf-ft]
  - 2. LX130-7: 98 N-m {10 kgf-m} [72 lbf-ft], LX160-7 – LX230-7: 225 N-m {23 kgf-m} [170 lbf-ft]
  - 3. Threaded area: LOCTITE#572
  - 4. Lip: Grease
  - 5. Mating surface: LOCTITE FMD-127
  - 6. LX130-7: 49 N-m {5 kgf-m} [36 lbf-ft], LX160-7 – LX230-7: 98 N-m {10 kgf-m} [72 lbf-ft]

- |                      |                 |                          |
|----------------------|-----------------|--------------------------|
| 1- Oil Seal          | 6- Ring Gear    | 11- Bleeder              |
| 2- Axle Shaft        | 7- Pin          | 12- Breather             |
| 3- Final Assembly    | 8- Pin          | 13- Cover                |
| 4- Differential Body | 9- Axle Tube    | 14- Drain Plug           |
| 5- Differential      | 10- Level Gauge | 15- Plug (Checking Port) |

**NOTE:** Threaded area not specified: LOCTITE#262  
 This sketch shows the front axle of the model LX160-7. On the other models, the construction of the front axle is the same.

**Fig. 2.42** Front Axle

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

**NOTE**

## DISK BRAKE

The disk brake is wet multiple-plate disk brake and built in the differential body of the drive axle. On the loader, four disk brake units are installed on the 4 wheels, one for each. For the structure of the disk brake, refer to "2.6 DRIVE AXLE."

### Operation


#### 1. Brake in operation

The brake oil pressure acts on the back of the brake piston, moves the brake piston and locks up the brake disks with the brake rings.

The inner periphery of each brake disk is splined through the disk hub to the shaft in the power transmission line. The outer peripheries of the brake rings are secured to the differential body by pins so that the locked-up brake disks stop rotating to brake the loader.

#### 2. Brake released

When the brake oil pressure acting on the brake piston is released, the brake piston returned a little by the return spring to make the brake disks free, thus releasing the braking force.




3-007

- |                   |               |                   |
|-------------------|---------------|-------------------|
| 1- Axle Shaft     | 6- Pin        | 11- D-Ring        |
| 2- Planet Carrier | 7- Brake Disk | 12- Return Spring |
| 3- Gear & Shaft   | 8- Brake Ring | 13- Adapter       |
| 4- Disk Hub       | 9- Piston     | 14- Bolt          |
| 5- End Plate      | 10- D-Ring    |                   |

**Fig. 3.7** Disk Brake Operation

**NOTE**

# CONTROL LINKAGE




- NOTE:** 1. Threaded area: LOCTITE#262  
 2. Align with the center of the center hinge pin  
 3. 246.0 N-m {25.1 kgf-m} [181 lbf-ft]  
 4. 34.3 N-m {3.5 kgf-m} [25.3 lbf-ft]  
 5. 87.2 N-m {8.9 kgf-m} [64.3 lbf-ft]  
 6. 149.9 N-m {15.3 kgf-m} [111 lbf-ft]


- |                    |                    |            |
|--------------------|--------------------|------------|
| 1- Steering Valve  | 5- Ball Joint      | 9- Bearing |
| 2- Stopper         | 6- Plate           | 10- Link   |
| 3- (Steering Gear) | 7- Mounting Rubber | 11- Pivot  |
| 4- Rod             | 8- Rod             |            |

**Fig. 4.8** Control Linkage

(Upper hinge)



(Lower hinge)



5-004

- NOTE:**
- 1. 88 N-m {9.0 kgf-m} [65 lbf-ft]
  - 2. 224 N-m {22.8 kgf-m} [165 lbf-ft]
  - 3. Threaded area: LOCTITE#262
  - 4. Outer ring area: LOCTITE#262

5-005


- |                   |            |               |
|-------------------|------------|---------------|
| 1- Cap            | 7- Bearing | 13- Pin       |
| 2- Dust Seal      | 8- Pin     | 14- Cap       |
| 3- Bushing        | 9- Bushing | 15- Shim      |
| 4- Cap            | 10- Cap    | 16- Bearing   |
| 5- Shim           | 11- Shim   | 17- Dust Seal |
| 6- Grease Fitting | 12- Washer | 18- Bushing   |

**Fig. 5.4** Center Hinge (LX130-7, LX160-7)

All pumps are installed in the converter housing and driven with the pump drive of the torque converter. Therefore, each pump always rotates with engine running. For the installation of the charging pump, refer to "2.1 DRIVE UNIT."


**(LX130-7)**

- 1- Pump
- 2- Drive Sleeve
- 3- (Torque Converter)
- 4- (Charging Pump)
- 5- "O"-Ring




6-005

**NOTE:** 1. Pay attention to the installation position of the snap ring.

2.  88 N-m {9.0 kgf-m} [65.1 lbf-ft]


**(LX160-7, LX190-7, LX230-7)**

- 1- Steering Pump, Brake & Assist Pump
- 2- Main Pump
- 3- Drive Sleeve
- 4- (Torque Converter)
- 5- (Charging Pump)
- 6- "O"-Ring





6-006

**NOTE:** 1. Pay attention to the installation position of the snap ring.




2.  224 N-m {22.8 kgf-m} [165 lbf-ft]

**Fig. 6.5** Pumps Installed on Converter Housing

- Ⓐ : SUCTION PORT
- Ⓑ : FRONT PUMP DISCHARGE PORT
- Ⓒ : REAR PUMP DISCHARGE PORT



View looking from Z




Inside construction

- |                  |                |                   |
|------------------|----------------|-------------------|
| 1- Drive Gear    | 6- Drive Gear  | 10- Back-Up Strip |
| 2- Oil Seal      | 7- Rear Cover  | 11- Gasket        |
| 3- Side Plate    | 8- Front Cover | 12- Bushing       |
| 4- Body          | 9- Driven Gear | 13- Driven Gear   |
| 5- Adapter Plate |                |                   |

**Fig. 6.14** Charging Pump (LX160-7, LX190-7, LX230-7)



# OIL TANK

	LX130-7	LX160-7	LX190-7, LX230-7
Type	Pressurized, enclosed type	←	←
Cap operating pressure	Positive pressure: 44.1 – 53.9 kPa {0.45 – 0.55 kgf/cm <sup>2</sup> } [6.4 – 7.8 psi]  Negative pressure: 3.9 – 4.9 kPa {0.04 – 0.05 kgf/cm <sup>2</sup> } [0.57 – 0.71 psi]	←	←
Return filter	1pc., 15 m	←	←
Tank capacity	80 L [21.1 US gal]	97 L [25.6 US gal]	124 L [32.8 US gal]
Tank weight (dry)	141 kg [311 lbs]	161 kg [355 lbs]	178 kg [392 lbs]



- 1- Support Plate
- 2- Spring
- 3- Retainer
- 4- Filter
- 5- Cap
- 6- Filter
- 7- Hose
- 8- Oil Tank
- 9- Level Gauge
- 10- Cover
- 11- Magnet

**Fig. 6.22** Oil Tank



NOTE:

7-008

*N-m {kgf-m} [lbf-ft]*

	LX130-7	LX160-7	LX190-7	LX230-7
1.	442 {45.1} [326]	442 {45.1} [326]	442 {45.1} [326]	603 {61.5} [445]
2.	3450 {352} [2540]	3450 {352} [2540]	3550 {362} [2620]	5710 {582} [4210]
3.	56.9 {5.8} [42]	56.9 {5.8} [42]	56.9 {5.8} [42]	56.9 {5.8} [42]
4.	{5.22} [37.8]	51.2 {5.22} [37.8]	51.2 {5.22} [37.8]	51.2 {5.22} [37.8]

5. After tightening, calk 2 parts around the bolt.

- |                  |                            |                         |                 |
|------------------|----------------------------|-------------------------|-----------------|
| 1- Cylinder Head | 6- "U"-Ring & Back-up Ring | 11- Seal Ring, "O"-Ring | 16- Shim        |
| 2- Back-up Ring  | 7- Buffering               | 12- Piston              | 17- Pin Bushing |
| 3- "O"-Ring      | 8- Piston Rod              | 13- Nut                 | 18- Wiper Ring  |
| 4- Wiper Ring    | 9- Cylinder Tube           | 14- Set Screw           | 19- Pipe        |
| 5- Bushing       | 10- Slide Ring             | 15- Steel Ball          |                 |

NOTE: The above sketches show the boom cylinder of the LX160-7. The boom cylinders of the other models have the same construction.

**Fig. 7.7** Boom Cylinder

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL