



**neuson<sup>®</sup>**

# **SERVICE MANUAL NEUSON**

COMPACT EXCAVATOR

**5002 / 6002**



Symbol picture

*Edition:* **February 03**  
*Id.No.:* **9707749**

**GB**

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below








- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

3. LIFT CAPACITY CHARTS

Tab.: Lift capacity - 5002

HUBKRAFTTABELLE

						
A	B	4,0m	5,0m	4,0m	3,0m	2,0m
4,0m	1000*	675		950*	650	950*
3,0m	980*	495		980*	660	1080*
2,0m	1000*	425	1000*	1120*	625	1420*
1,0m	1040*	380	1050*	1300*	575	1855*
0,0m	1075*	390	1075*	380	1425*	530
-1,0m	1110*	440		1390*	525	2110*
-2,0m	1140*	600			1650*	800
						2650*

max. .... Zulässige Last bei gestrecktem Löffelstiel  
 A ..... Ausladung von Mitte Drehkranz  
 B ..... Lasthakenhöhe  
 \* ..... Hubkraft durch Hydraulik begrenzt


Alle Tabellenwerte sind in kg angegeben, bei waagrechter Stellung auf festem Untergrund und ohne Löffel.


⊥ ..... mit Planierschildabstützung in Fahrtrichtung  
 ⊥ ..... ohne Planierschildabstützung 90° zur Fahrtrichtung

Sofern ein Löffel oder sonstige Arbeitsgeräte angebaut sind, verringert sich die Hubkraft oder Kippplast um deren Eigengewicht.

Berechnungsgrundlage: gem. ISO 10567





Die Hubkraft des Kompaktbaggers ist durch die Einstellung der Überdruckventile und durch die Kippsicherheit begrenzt. Es werden weder 75 Prozent der statischen Kippplast noch 87 Prozent der hydraulischen Hubkraft überschritten.



		Fläche (mm²)		Gewicht(kg)		Werkst.		Maßstab	
		Blechst. (mm)		Konung (mm)				BAGGER 5002 RD	
		Bearb. Datum		Name				HUBTABELLE	
		1998/07/18		HAUER					
		Zust. Änderung		Datum		Name			
2		neu überarb.		00/06/18		WA			
		ZG-Nr.:		4411005		Blatt		2	
		Ersatz-tuec.							

Cycle courses - excavators

Hueman / 25. April 03

Machine model				Neuson 5002		Neuson 6002	
Classifi- cation	Item	Check conditions	Unit	Value		Value	
				normal	allow ed	normal	allow ed
WORK EQUIPMENT ( Response time )	<b>Boom</b>	Position for the check  > Engine speed: <b>Min.</b> Hydraulic oil temperature: 45 - 55 °C > Retract the dipper stick and bucket cylinders completely. > Low er the boom from its maximum height and measure the time from the moment in which the bucket touches the ground to the moment in which the machine starts lifting.	sec.	---	---	---	---
	<b>Dipper stick</b>	Position for the check  > Engine speed: <b>Min.</b> Hydraulic oil temperature: 45 - 55 °C > Move the boom to the horizontal position > Retract the dipper stick cylinder completely and then extend it. > Measure the time from the moment in which it starts moving again.	sec.	---	---	---	---
	<b>Bucket</b>	Position for the check  > Engine speed: <b>Min.</b> Hydraulic oil temperature: 45 - 55 °C > Move the boom to the horizontal position > Retract the bucket cylinder completely, then extend it. > Measure the time from the moment in which the bucket stops at the dead center and the moment in which it starts moving again.	sec.	---	---	---	---
	<b>Dozer blade</b>	Position for the check  > Engine speed: <b>Min.</b> Hydraulic oil temperature: 45 - 55 °C > Raise the blade to the maximum height and then low er it. > Measure the time from the moment in which the blade touches the ground and the moment in which the machine starts lifting.	sec.	---	---	---	---

Hue 5 / 5





**neuson**<sup>®</sup>

CHAPTER B:

# Maintenance

( Neuson Service Manual 5002 - 6002 )





**5002**  
NEUSON

Fabr.No.:  
Work hrs./Dat.  
Checked:

**PRESSURE  
CHECK LIST**  
Neuson Baumaschinen

No: HueC  
Stand: Ju

Function	Motion	Symbol	Press.Limit. Valve	Measure point	Setting (1)	Checked:	OK?
----------	--------	--------	--------------------	---------------	-------------	----------	-----

**PUMP 1** X


Function	Motion	Symbol	Press.Limit. Valve	Measure point	Setting	bar	tolerance	direction	Notice:		
Boom	UP		Primary press. Limiting valve PPLV 1 (Main valve block)	Measuring point MP 1 (Main valve block)	Setting	230	+/- 3	>			
					Fall	25		>			
Bucket	OUT						Setting	230	+/- 3	>	
					Fall	25		>			
Bucket	IN						Setting	230	+/- 3	>	
					Fall	25		>			
Drive left	FORWARD						Setting	230	+/- 3	>	
					Fall	25		>			
Drive left	BACKWARD				Setting	230	+/- 3	>			
			Fall	25		>					

**PUMP 2** X

Function	Motion	Symbol	Press.Limit. Valve	Measure point	Setting	bar	tolerance	direction	Notice:		
Dipper stick (Arm)	OUT		Primary press. Limiting valve PPLV 2 (Main valve block)	Measuring point MP 2 (Main valve block)	Setting	230	+/- 3	>			
					Fall	25		>			
Drive right	FORWARD						Setting	230	+/- 3	>	
					Fall	25		>			
Drive right	BACKWARD						Setting	230	+/- 3	>	
					Fall	25		>			
Auxiliary hydraulics	A						Setting	230	+/- 3	>	
					Fall	25		>			
Auxiliary hydraulics	B				Setting	230	+/- 3	>			
			Fall	25		>					

## 6. HOSE BURST PROTECTION VALVE

### Gap dimensions of hose burst valves



The European Safety Regulations provide for the installation of hose burst protection facilities in dozer blade cylinders and in tilting cylinders.

If such valves are missing, there will be liability problems in case of an excavator accident.

SETTING of GAP DIMENSION „**S**“ :


1. Loosen the two nuts.
2. Adjust the gap S by means of a gauge for the relevant type of excavator (see Chapt. Technical Data).
3. Tighten the nuts lightly by hand and fix them cautiously against each other

## Injection Pump

### > DISMANTLING/INSTALLATION :

The injection pump is driven directly via spur wheels from the crankshaft.  
Prior to dismantling the pump dismantle the spur wheel.

Take care to align the relevant markers of the spur wheels correctly! (see schematic)




## Moment of Injection

### > Direct injection:

1. Dismantle injection pipe for 1<sup>st</sup> cylinder.  
Cylinders are always numbered starting from the flywheel side.
2. Turn engine clockwise (from the water-cooler point of view) at the crankshaft, until fuel emerges from the bottom valve of the injection pump.
3. Remove rubber cover at the flywheel case and read moment of injection by the marker at the flywheel and flywheel case.
4. If the markers don't correspond, the moment of injection must be corrected by turning the injection pump.


Moment of injection too late: turn pump away from engine

Moment of injection too early: turn pump towards engine



longitudinal slots for turning the injection pump

Diese Zeichnung ist urheberrechtlich geschützt und darf ohne unsere schriftliche Genehmigung weder kopiert und vervielfältigt noch dritten Personen mitgeteilt oder zugänglich gemacht werden. Widerrechtliche Benutzung ist strafbar und verpflichtet zu Schadensersatz.



P1 ... 245bar, 58.8L/min  
 P2 ... 245bar, 58.8L/min  
 P3 ... 220bar, 44.1L/min  
 n = 2100 min-1

<b>neuson</b> Baumaschinen		Werkst.	Gewicht[kg]	Maßstab
		BAGGER 6002 RD		
		HYDRAULIKSCHALTPLAN		
		ZG-Nr.:	511044	Blatt
		Ersatz-Tier		



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Fig.: **Port assignment** of control oil unit 5002 - 6002  
(version 1408610 / 1408615 )






Fig.: **Main valve block 6002 - view B**



- P stopper auxiliary hydraulics (option secondary valves)
- Q shock suction valve dipper stick cylinder
- R shock suction valve boom
- S shock suction valve bucket
- T primary pressure limiting valve **P2**
- U shock valve dozer blade cylinder bottom side

6. PILOT CONTROL VALVES - Assignment


Option: Switch Valve

Neuson 5002 - 6002

Function: Via **selector lever at the directional control valve** the assignment of the joysticks may be reversed.

- Pos. 1: joystick right - boom                      joystick left - dipper stick
- Pos. 2: joystick right - dipper stick            joystick left - boom

Fig.: **Port assignment / mounting position - directional control valve 5002 - 6002**



Joystick left

- LST 3** dipper stick out -> joystick pos. 3
- LST 1** dipper stick in -> joystick pos. 1
- DL 2** swivelling left -> joystick pos. 2
- DR 4** swivelling right -> joystick pos. 4

Joystick right

- HU 3** boom up -> joystick pos. 3
- HU 1** boom down -> joystick pos. 1
- LÖ 4** bucket out -> joystick pos. 4
- LÖ 2** bucket in -> joystick pos. 2

Fig.: Joystick positions le. / ri.





Fig.: **Swivel motor**  
Swivel unit 4408490





**neuson®**

CHAPTER D:

# Diesel engine

( Neuson Service Manual 5002 - 6002 )



- K4 Switch relay initial contact
- K5 Time relay glow plug indicator 15 sec.
  
- M1 Starter
- M2 Fan motor
- M3 Wiper motor
- M4 Windshield washer pump
- M5 Additional filler pump for filling fuel tank (optional)
  
- P1 Operating hours counter and fuel gauge
- R1 Warm up glow plug
- R2 Feeler for fuel gauge
  
- S1 Switch for 2nd gear
- S2 Switch for fan motor
- S3 Switch wiper motor
- S4 Light switch
- S5 Switch for rear work lighting
- S6 Switch for work lights
- S7 Feeler for minimum fuel warning light
- S10 Feeler for water temperature
- S11 Feeler for oil pressure switch
- S12 Feeler for clogged air filter
- S13 Feeler for return filter
- S14 Ignition
- S15 Switch roof light
- S16 Button for 2nd gear
- S17 Horn button
- S18 Change over valve button
- S19 Switch safety solenoid valve
  
- Y0 Stop solenoid
- Y1 Change over valve
- Y2 Solenoid valve 2nd gear
- Y3 Safety solenoid valve
  

X1 Plug in engine area 21 pole	X6 Plug for additional filler pump 2 pole
X2 Plug in engine area 6 pole	X7 Cab plug 7 pole
X3 Plug for work lights 2 pole	X8 Plug for buzzer 2 pole
X4 Plug for solenoid valve 24 pole	X9 Plug 1 pole




**Legend - Elektric wiring Neuson 5002 AB / Legende Elektroschaltplan 5002 AB**

**Fabr.No.: AB00473 and higher**

S36	switch klima	Schalter Klimaanlage
S37	switch klima van	Schalter Klimagebläse
S38	pressure switch klima	Druckschalter Klima
S39	pressure switch klima	Druckschalter Klima
R1	preheating	Vorglühanlage
X0	cigarette lighter	Zigarettenanzünder
X1	main connector engine cable tree	Hauptstecker Motorkabelbaum
X4	some engine relays	einige Motorrelais
X5	alternator load control	Lichtmaschine Ladekontrolle/Erregung
X6	alternator main plus	Lichtmaschine Hauptplus
X9	starter main plus	Starter Hauptplus
X10	starter solenoid	Starterritzel Spule
X11	heating / clima switches	Heizung / Klima Schalter
X12	connector instrumenenpanel left	Stecker Anzeigeelement links
X13	heating / clima ventilator	Heizung / Klima Ventilator
X14	connector right to left armrest	Verbindung Rechte und Linke Armlehne
X15	connector right to left armrest	Verbindung Rechte und Linke Armlehne
X16	connector right to left armrest	Verbindung Rechte und Linke Armlehne
X17	main connector armrest cable tree	Hauptstecker Armlehnenkabelbaum
X18	ground	Masse
X19	socket	Steckdose
X24	connector engine speed / pump reg.	Verbindung Motordrehzahlsteller
X26	connector to horn button	Stecker Hupentaster
X27	connector anti theft device	Stecker Diebstahlsicherung
X28	cabin connector	Kabinenstecker
X29	connector instrumenten panel	Stecker Anzeigeinstrument
X30	motoroil control	Motorölkontrolle
X31	buzzer	Summer
Y2	boom swing / extended hydraulik valve	Armschwenk / Zusatzhydraulik Ventil
Y3	3 rd hydraulic circuit	3. Steuerkreis
Y4	3 rd hydraulic circuit	3. Steuerkreis
Y5	safety valve	Sicherheitsventil
Y6	fast speed valve	Schnellfahrventil
F1	switch lights, controll lamps	Schalterbeleuchtung, Kontrollanzeigen
F2	anti thift device, engine relais	Diebstahlsicherung, Motorrelais
F3	lights chassis, arm	Beleuchtung Chassis, Hubarm
F4	heating van, clima, horn	Heizung, Klima, Hupe
F5	armrest left, engine speed, pumpregulatio	Steuerhebelträger links, Motordrehzahl, Pumpenregelung
F6	windscreenwiper, cabin	Scheibenwischer, Kabine
F7	stop solenoid, alternator	Abstellmagnet, Erregung Lichtmaschine
F8	valves	Ventile
F9	option cabin	Dachscheinwerfer
F10	socket, refuelling pump	Steckdose, Betankungspumpe
F11	rotating light, cabin, anti thief device	Drehleuchte, Radio, Zigarettenanz., Diebstahlsich.
Q1	main fuse	Hauptsicherung
Q2	main fuse	Hauptsicherung
X40	main connector back lights	Hauptstecker Rücklichter
X41	lights front left	Lichter vorne links
X42	lights front right	Lichter vorne rechts
X43	lights on boom	Lichter auf Hubarm



**Connection to RIGHT armrest /  
Stecker zum rechten Steuerhebelträger 5002-12002 AB**

<b>X24</b>		<b>6 pol. AMP</b>	
1		X15, P1	dark blue
2		X15, P1	green / black
3		X15, P1	light blue
4		GND	black
5		Supply +12 V	red
6		res	
<b>X27</b>			
1		starter	white / black
2		valves	brown / white
3		stop solenoid	blue
4		starter	white / black
5		valves	brown / white
6		stop solenoid	blue
7			
8		ground	black
9			
10		supply +30	red
11		supply +15	blue
<b>X28</b>			
1		windscreen wiper back	blue / red
2		rotating lamp	violett
3		ground	black
4		windscreen wiper	white
5		cabin roof light front	green
6		windscreen washer	white/black/white
7		supply +15	blue
8		supply +30	red black
9		cabin roof light back	yellow / black

**Connection between right and left armrest 5002-12002 AB  
Stecker zwischen rechter und linkem Steuerhebelträger 5002 - 12002 AB**

<b>X14, male</b>		<b>13 poles AMP:</b>	
1		res. Lamp	brown
2		res. lamp	brown
3		display back light	green
4		earth	black
5		watertemperature	green / white
6		brake lamp (6502)	red / yellow
7		accumulator load lamp (6502)	green / white
8		res. lamp	brown
9		res. lamp	brown
10		nc.	
11		speed pick up signal	blue / black
12		indicator lamp (6502)	blue / red
13		light lamp (6502)	yellow / black



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL