


# ARX 23.1

# ARX 26.1

TANDEM ROLLER  
KUBOTA D1703-M-DI-E4B  
EU Stage V, U.S. EPA Tier 4f



## WORKSHOP MANUAL

EDITION 07/2022 EN

ARX 23.1 KU St V / T4f Product Identification Number 3035577 -  
ARX 26.1 KU St V / T4f Product Identification Number 3042949 -

**AMMANN**

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

**SAFETY NOTICES AND SIGNS:**



The notice warns of a serious risk of personal injury or other personal hazards.




The notice warns of possible damage to the machine or its parts.



The notice warns of the necessity of environmental protection.

**! CAUTION!**


As used in this operating manual, the terms **right**, **left**, **front** and **rear** indicate sides of the machine moving forward.




588027\_cs

Nameplate position

Nameplate




Serial number of the machine frame



Position of the ROPS nameplate

ROPS nameplate



Engine nameplate position

Serial number of the Kubota engine



#### 4.1.4 Hydraulic oil

For the hydraulic system of the machine, it is necessary to use only high-quality hydraulic oil grades according to ISO 6743/HV (equal to DIN 51524 part 3 HVLP).

Fill the machines normally with hydraulic oil that has cinematic viscosity of 46 mm<sup>2</sup>/s at 40°C (104°F) ISO VG 46. This oil is most appropriate for its use within the widest range of ambient temperatures.

##### Synthetic hydraulic oil

The hydraulic system can be filled with synthetic oil, which if leakages occur will be degraded completely by micro-organisms present in water and soil.



**Please consult always with oil manufacturer or dealer any switching from mineral oil to synthetic one or mixing the oils of various brands!**

---

#### 4.1.5 Lubricating grease

To lubricate the machine you must use plastic grease containing lithium according to:

ISO 6743/9 CCEB 2

DIN 51 502 KP2K-30

#### 4.1.6 Emulsion

For sprinkling the tyres, use anti-adhesive emulsion of RHODOSIL EMULSION E1P with water in the mixing ratio of 1.5:100.

**5.4.7 Swinging support**

**5.4.8 Replacement of joint head**

Secure the machine.

Mount a lock against cranking.



589D006

Place the hydraulic jack to the centre of the swinging joint.

Slightly unload the roller.



611A773

Remove the lower sheet metal.




611A774

(3x) Disconnect water piping (1).


Disconnect the (M4) connector from the water pump.

Disconnect the (Y9) connector from the shut-off valve.



611A775

Secure the screws with a suitable adhesive, e.g. Loxeal 53-84  
Install the clamp.



Re-install hose bundles.  
Fix them using a cable coupling.



Mount the bearing flange to the chassis using hexagonal screws. Tighten tightly at the tightening torque of 210 Nm.



Apply the Würth motordich preparation on the bearing, flange and the lid.




Disconnect water piping.



Disconnect the X9 connector.




Mount the eye bolt (M8) in the front to the appropriate inner thread.




Now the water tank can be carefully taken out.



Release the canopy by pulling out the lever (1) slightly and raise the canopy.



Mount the screws (2x) at the bottom of the plastic canopy.



## 7 Front drum

- Material:
- 114544 Thrust plate

Place the thrust plate on the centre of the shaft.



- Material:
- 114547 Puller tool

Screw on the puller tool on the sealing flange.



Pre-load the tool using an impact wrench.



Heat up the bearing with a gas flame to release it.



Insert the SpeedySleeve ring into the assembly tool.



Place the tool on the vibration shaft.



Using a nylon mallet and the assembly tool for SpeedySleeve ring place the ring to the correct position.



**A position of the ring will be determined by the assembly tool**



Mounted SpeedySleeve ring




- Material:
  - (4x) M8x25 cheese head screw

Mount the vibration motor on the bearing support with a torque of 25 Nm.




- Material:
  - Screw plug with the inner hexagon G1/4" zinc-plated (1)
  - Seal ring 13.4 / 10.2x1.0 (2)

Secure the screw plug with a suitable adhesive, e.g. Loxeal 53-84  
Using the screwdriver (SW5) mount the screw plug and the seal ring.




- Material:
  - Screw plug with the inner hexagon G1/4" zinc-plated (1)
  - Seal ring 13.4 / 10.2x1.0 (2)

Secure the screw plug with a suitable adhesive, e.g. Loxeal 53-84  
Using the screwdriver (SW5) mount the screw plug and the seal ring.




Introduce the wheel support (1) by means of a crane and locate it on the drum.




Mount two upper screws of the roller support (2) on the vibration motor side of the machine (size 24).

Tighten two lower screws of the roller support (1) on the vibration motor side of the machine (size 24).



Mount the hydraulic hoses.

Mount the hose clip (hexagonal socket wrench, size 5).



### On both sides of the rear drum

Release the pressure on the rubber couplings by lifting the machine chassis.



Remove the spacers between the drum and chassis on both sides.

Lower the machine down to the ground.



### 8.4.1.2 Drum disassembly

(4x) Remove M8x25 cheese head screws (SW6) on the vibration motor.

Take the vibration motor out.



(6x) Remove M10x25 hexagonal screws (SW17) from the travel bearing flange.

Take the travel bearing flange out.



Take the vibration shaft out.



**A safe fastening is a prerequisite for taking out the vibration shaft.**

**Note**

When you do not have an appropriate auxiliary tool, especially for taking out vibration shaft, we recommend that you stand up the drum. The side of the vibration motor should be up.



(6x) Remove M10x25 hexagonal screws (SW17).

Take the vibration bearing flange out.




- Material:
  - Roller bearing NJ 2308 E.TVP2.C3

Clean the roller bearing (1) and insert it to the flange.



Push in the flange (1) and the roller bearing (2).



Assembled flange and roller bearing.  
Insert the inner lock ring.



- Material:
  - Shaft seal ring A60/95x10
  - Isopropylalcohol

Soak the shaft seal ring in alcohol and insert it to the flange fastening.



- Material:
  - (6x) M10x60/26 hexagonal screw
  - (6x) U washer D13/24 x2.5

Mount the screws and U washers together.  
Apply the adhesive on the screws.



Screw on the screws at a torque of 48 Nm.



- Material:
  - (6x) M10x25 hexagonal screw
  - (6x) Lock washer 10.5/23x2.5

Assemble the screws and lock washer.  
Secure the screws with a suitable adhesive, e.g. Loxeal 53-84



Screw on the screws at a torque of 48 Nm.



**The shaft seal ring can be pushed out when the vibration shaft is inserted.**  
**Remove the venting screw in the housing!**



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL


- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Remove the rubber-metal elements from the drum.  
Use installation tool pn 4-64614022\_00.



Clean the area for mounting the new rubber-metal elements  
and the thread.



Mount new rubber-metal elements.  
The tightening torque is 210 Nm.

Secure the rubber-metal elements with the LOXEAL 83-54 (re-  
moveable thread lock) adhesive.



## **9 Front axle (not part of machine equipment)**

# 11 Travel


# 12 Vibration

# **15 Engine**

### 15.4.4 Inlet air filter

#### Drain of impurities

To empty impurities, press the drain of impurities of the inlet air filter at least once a week.




D593016

If the F250 error code appears on the display during operation of the machine, the cartridge must be replaced, however after 500 operation hours at the latest.



**The manufacturer does not recommend you to clean the cartridges because there is a possibility of reducing the capacity by up to 40% and damaging the cartridge during the cleaning.**



593048

Remove the filter cap.



593049

Take out the main cartridge.



593034

# 17 General procedures

### 17.4.1 Calibration mode

**The calibration mode is used for:**

- selecting the HARD/SOFT ramp for the working speed,
- setting the temperature units °C/°F,
- enabling/disabling the left travel lever,
- enabling / disabling the telematics,
- calibrating the minimum current of travel coils (according to Chapter 17.4.2).

**Procedure to select parameters**



The following procedure is for the B1, B2, B3 and B4 tabs. To calibrate the foil current (B5) proceed according to Chapter 17.4.2.

Turn the key in the ignition box to the "I" position.

Sit in the driver's seat (activation of the seat switch).

Set the travel control to the parking brake position "P".

Press the calibration button (B) for 5 seconds. While the button is held down, the display shows the "CAL" status.





After 5 seconds, the display shows B1 and at the same time the error message indicator lamp (21) starts flashing. The error message indicator lamp (21) flashes for the duration of the calibration mode.

Use the select button (13) to select the tab and press OK (12) to confirm. The display will show the current state of the set parameter (e.g. SOFT when choosing the ramp – B1). Note: This does not apply to the B5 tab when the calibration of the minimum coil current of the travel pump is started by pressing the button.

**Note:**

To display the B5 tab, press the brake test button (A) for 5 seconds.



**Kubota engine errors**

## Error severity

- High – The engine failure indicator lamp is red.
- Medium – The error message indicator lamp is yellow.
- Low – The emergency stop indicator lamp is yellow.

If an engine error is displayed, stop the machine and contact service.


<b>Error</b>	<b>Description</b>	<b>Error severity</b>
F100	Pressure limiter emergency open	High
F101	SCV(MPROP) stuck	High
F102	Fuel leak (in high pressured fuel system)	High
F103	Rail pressure sensor: Low	High
F104	Rail pressure sensor: High	High
F105	Injector charge voltage: High	High
F106	Open circuit of harness/coil in 1st cylinder injector	High
F107	Open circuit of harness/coil in 3rd cylinder injector	High
F108	Open circuit of harness/coil in 4th cylinder injector	High
F109	Open circuit of harness/coil in 2nd cylinder injector	High
F110	Engine overheat	High
F111	Engine overrun	High
F112	Oil pressure error	High
F113	ECU FLASH ROM error	High
F114	ECU CPU (Main IC) error	High
F115	ECU CPU (Monitoring IC) error	High
F116	Injector charge voltage: Low	High
F117	Open circuit of SCV (MPROP)	High
F118	SCV (MPROP) drive system error	High
F119	Injector drive IC error or Open circuit	High
F120	Internal injector drive circuit short	High
F121	Sensor supply voltage 1: Low	High
F122	Sensor supply voltage 1: High	High
F123	No.1 & 4 cylinder injector short to +B or GND	High
F124	No. 2 & 3cylinder injector short to +B or GND	High
F125	Pressure limiter not open	High
F126	Rail pressure failure after pressure limiter open	High
F127	CAN2 Bus off	High
F128	CAN1 Bus off	High
F129	CAN-KBT Frame error	High
F150	MAF sensor: Low	High
F151	MAF sensor: High	High
F152	Emission deterioration	High
F153	Emergency Exhaust gas temperature sensor 0: High	High
F154	Emergency Exhaust gas temperature sensor 1: High	High
F155	Emergency Exhaust gas temperature sensor 2: High	High
F156	Excessive PM5	High
F157	High exhaust gas temp. after emergency high temp. DTC.	High

Measure resistance of the magnetic coil Y3/Y4.  
The resistance value is approximately 6 Ohm.



611A054

Connect the voltage of 12 V to the magnetic valve.  
The valve (arrow) must visibly switch on.



611A055

### Change the position of the magnetic coil connector


The position of the connector can be changed by turning the magnet body as needed.

Release the lock nut (1) of the magnet.

Turn the lock nut (1) by one turn to the left.



Turn the body of the magnet (2) to the required position.

Tighten the lock nut again. Tightening torque of the lock nut: 5+1 Nm.



611A056

Check the valve seat and cone for damage and contamination.





Tighten screwed joints/plugs firmly (90 Nm).



## 18.2.11.2 Magnetic coil

Connect the voltage of 12V to the magnetic valve.  
The valve (arrow) must visibly and audibly switched on.  
Check seal rings (1) for damage.




Measure resistance of the magnetic coil.  
The resistance value is 8 – 9 Ohm.


### Note

**When remounting the magnetic coil observe the torque of 50 Nm.**



# 19 Annexes






**CABLE HARNESS LEGEND:**

- Fastom
  - Ringlock
  - Důvěrná klenková
  - Spojka trebičková
  - Šokloct
  - Svislý plug
  - Síťový wire seal
  - Maticut
  - No.6.3
  - No.6.3 sleeve
  - Sijona
  - Redukce
  - Čipnja
  - Ovládací T 10-10-7.5
  - Endovka SEM 9
  - Fastektor fastor
  - Běhokmešník
  - Běhokmešník 0A 80 or 60
  - Následná konektory 1 and 2
  - Přisuvná konektory 1 and 2
- VÝŠKA:**  
 R - 1 - 1200 (100)  
 Wirebank, součet mm<sup>2</sup>, délka, číslo number
- Kabel:**  
 H03VV-F2X0.75-2500  
 Typ, délka
- Ochranná hadice:**  
 NW13 - 700  
 Type, délka


**TABLE OF COLOR SYMBOLS:**

WH	B	Bílá
BK	C	Černá
BN	H	Modrá
BU	M	Modrá
RD	R	Červená
GY	S	Žlutá
YE	Y	Žlutá
GN	Z	Zelená




**CABLE HARNESS LEGEND:**

- Fastom
- Ring conductor
- Diaphragm cover
- Splicing sleeve
- Contact
- Solder plug
- Single wire seal
- Metal cap
- Insulation sleeve
- Sleeve
- Reducer
- Clamp
- Connector
- End of line SEM straight
- Fastener
- Rivet
- Rivet spacer
- Wedge connector
- Plug connector



**TABLE OF COLOR SYMBOLS:**

WH	B	Bílá
BK	C	Čierna
BN	H	Bia
BU	M	Modrá
RD	R	Redá
GY	S	Šedá
YE	Y	Žltá
GN	Z	Zelená



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL