

Manual No. : KM-CABE  
Vol. No. : WCABE-00

# Workshop Manual

# ZAXIS 130W Wheeled Excavator

Service Manual (Manual No. KM-CABE) consists of the following three separate volumes;

|  |                   |
|--|-------------------|
| Technical Manual (Operational Principle) | : Vol. No. TOCABE |
| Technical Manual (Troubleshooting)       | : Vol. No. TTCABE |
| Workshop Manual                          | : Vol. No. WCABE  |

**HITACHI**

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.


CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

## SAFETY

---

### OPERATE ONLY FROM OPERATOR'S SEAT

- Inappropriate engine starting procedures may cause the machine to runaway, possibly resulting in serious injury or death.
  - Start the engine only when seated in the operator's seat.
  - NEVER start the engine while standing on the track or on ground.
  - Do not start engine by shorting across starter terminals.
  - Before starting the engine, confirm that all control levers are in neutral.




SA-084

012-E01B-0444

### JUMP STARTING

- Battery gas can explode, resulting in serious injury.
  - If the engine must be jump started, be sure to follow the instructions shown in the "OPERATING THE ENGINE" chapter in the operator's manual.
  - The operator must be in the operator's seat so that the machine will be under control when the engine starts. Jump starting is a two-person operation.
  - Never use a frozen battery.
  - Failure to follow correct jump starting procedures could result in a battery explosion or a runaway machine.



SA-032

S013-E01A-0032

# SAFETY

---

## PRACTICE SAFE MAINTENANCE

To avoid accidents:

- Understand service procedures before doing work.
- Keep work area clean and dry.
- Do not spray water or steam inside cab.
- Never lubricate or service the machine while it is moving.
- Keep hands, feet and clothing away from power-driven parts.
  
- Before servicing the machine:
  - 1) Park the machine on a level surface.
  - 2) Lower the bucket to the ground.
  - 3) Turn the auto-idle / acceleration selector off.
  - 4) Run the engine at slow idle speed without load for 5 minutes.
  - 5) Turn the key switch to OFF to stop engine.
  - 6) Relieve the pressure in the hydraulic system by moving the control levers several times.
  - 7) Remove the key from the switch.
  - 8) Attach a “Do Not Operate” tag on the control lever.
  - 9) Pull the pilot control shut-off lever to the LOCK position.
  - 10) Allow the engine to cool.

## SAFETY

---

### REMOVE PAINT BEFORE WELDING OR HEATING

- Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch. If inhaled, these fumes may cause sickness.
  - Avoid potentially toxic fumes and dust.
  - Do all such work outside or in a well-ventilated area. Dispose of paint and solvent properly.
- Remove paint before welding or heating:
  - 1) If you sand or grind paint, avoid breathing the dust.  
Wear an approved respirator.
  - 2) If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.




SA-029

511-E01A-0029

### PREVENT BATTERY EXPLOSIONS

- Battery gas can explode.
  - Keep sparks, lighted matches, and flame away from the top of battery.
  - Never check battery charge by placing a metal object across the posts. Use a voltmeter or hydrometer.
  - Do not charge a frozen battery; it may explode. Warm the battery to 16 °C ( 60 °F ) first.
  - Do not continue to use or charge the battery when electrolyte level is lower than specified. Explosion of the battery may result.
  - Loose terminals may produce sparks. Securely tighten all terminals.
- Battery electrolyte is poisonous. If the battery should explode battery electrolyte may be splashed into eyes, possibly resulting in blindness.
  - Be sure to wear eye protection when checking electrolyte specific gravity.



SA-032


512-E01C-0032

# GENERAL / Precautions for Disassembling and Assembling

## Floating Seal Precautions

1. In general, replace the floating seal with a new one after disassembling. If the floating seal is to be reused, follow these procedures:




- (1) Keep seal rings together as a matched set with seal ring faces together. Insert a piece of cardboard to protect surfaces.
- (2) Check the slide surface on seal ring (A) for scuffing, scoring, corrosion, deformation or uneven wear.
- (3) Check O-ring (B) for tears, breaks, deformation or hardening.




W105-03-05-019

2. If incorrectly assembled, oil leakage or damage will occur. Be sure to do the following, to prevent trouble.

- (1) Clean the floating seal and seal mounting bores with cleaning solvent. Use a wire brush to remove mud, rust or dirt. After cleaning, thoroughly dry parts with compressed air.
- (2) Clean the floating seal and seal mounting bores. Check the bore surface for scuffing or scoring by touching the surface with touch.
- (3) Check that the O-ring is not twisted, and that it is installed correctly on the seal ring.



- (4) After installing the floating seal, check that seal ring surface (A) is parallel with seal mating face (C) by measuring the distances (A) and (C) at point (a) and (b), as illustrated. If these distances differ, correct the O-ring seating.



W105-03-05-020


W110-03-05-004

## GENERAL / Tightening

### O-ring Seal Joint

O-ring (6) seats against the end face of adapter (7) to seal pressure oil.

- IMPORTANT:**
1. Be sure to replace O-ring (6) with a new one when reconnecting.
  2. Before tightening nut (9), confirm that O-ring (6) is seated correctly in O-ring groove (e). Tightening nut (9) with O-ring (6) displaced will damage O-ring (6), resulting in oil leakage.
  3. Take care not to damage O-ring groove (e) or sealing surface (10).  
Damage to O-ring (6) will cause oil leakage.
  4. If nut (9) is loose and oil is leaking, do not re-tighten nut (9). Replace O-ring (6) with a new one and check that O-ring (6) is correctly seated in place, tighten nut (9).








| Wrench Size<br>mm | Wrench Size<br>mm | Tightening Torque   |
|-------------------|-------------------|---------------------|
| Union Nut         | Hose Fittings     | N·m (kgf·m, lbf·ft) |
| 19                | 17                | 29.5 (3.0, 21.5)    |
| 22                | 19                | 69 (7.0, 51)        |
| 27                | 22                | 93 (9.5, 69)        |
| 32                | 27                | 137 (14.0, 101)     |
| 36                | 30,32             | 175 (18.0, 129)     |
| 41                | 36                | 205 (21.0, 151)     |
| 46                | 41                | 205 (21.0, 151)     |



# UPPERSTRUCTURE / Cab

Unit: mm



## UPPERSTRUCTURE / Main Frame





**CAUTION: Front attachment assembly weight:**

**Monoblock boom: 2000 kg (4410 lb)**  
**2-Piece boom: 2410 kg (5320 lb)**

6. Install front attachment assembly. Then, fill with hydraulic oil.  
 (Refer to "Remove and Install Front Attachment" group on page W4-1-2.)


- : 27 mm
- : 93 N·m (9.5 kgf·m, 69 lbf·ft)
- : 30 mm
- : 540 N·m (55 kgf·m, 400 lbf·ft)
- : 36 mm
- : 175 N·m (18 kgf·m, 129 lbf·ft)

7. Start the engine and set the front attachment in posture for checking hydraulic oil level in its tank. Inspect the hydraulic oil level and check if there is any oil leakage.



# UPPERSTRUCTURE / Pump Device


## ASSEMBLE MAIN PUMP



T1F3-03-01-003


T1F3-03-01-003

- |                               |                                 |                               |                            |
|-------------------------------|---------------------------------|-------------------------------|----------------------------|
| 1 - Socket Bolt (2 Used)      | 19 - Servo Piston (2 Used)      | 37 - Needle Bearing           | 55 - Spring Pin            |
| 2 - *Steering Pump            | 20 - O-Ring (2 Used)            | 38 - Gear                     | 56 - Pin                   |
| 3 - Cover                     | 21 - Backup Ring (2 Used)       | 39 - O-Ring                   | 57 - *O-Ring (2 Used)      |
| 4 - O-Ring                    | 22 - Stopper (2 Used)           | 40 - Socket Bolt (4 Used)     | 58 - *Plug (2 Used)        |
| 5 - Retaining Ring (2 Used)   | 23 - *O-Ring (2 Used)           | 41 - Cover                    | 59 - *O-Ring               |
| 6 - Spacer (2 Used)           | 24 - *Plug (2 Used)             | 42 - Oil Seal                 | 60 - Spring Pin (2 Used)   |
| 7 - Bearing (2 Used)          | 25 - O-Ring (2 Used)            | 43 - O-Ring                   | 61 - Pin                   |
| 8 - Spacer (2 Used)           | 26 - *Plug (8 Used)             | 44 - Shaft                    | 62 - Socket Bolt (4 Used)  |
| 9 - Shaft                     | 27 - Socket Bolt (4 Used)       | 45 - Housing                  | 63 - Cover                 |
| 10 - Cover                    | 28 - Swash Plate (2 Used)       | 46 - O-Ring (18 Used)         | 64 - *Socket Bolt (2 Used) |
| 11 - Nut (2 Used)             | 29 - Bushing (2 Used)           | 47 - O-Ring (2 Used)          | 65 - *Cover                |
| 12 - Adjusting Screw (2 Used) | 30 - Shoe Plate (2 Used)        | 48 - Valve Plate              | 66 - *O-Ring               |
| 13 - Spring Pin (2 Used)      | 31 - Plunger (18 Used)          | 49 - Needle Bearing           | 67 - *PTO Gear Case        |
| 14 - Stopper (2 Used)         | 32 - Retainer (2 Used)          | 50 - *Eye Bolt                | 68 - *Socket Bolt (4 Used) |
| 15 - Backup Ring (2 Used)     | 33 - Spherical Bushing (2 Used) | 51 - Nut (2 Used)             | 69 - *O-Ring               |
| 16 - O-Ring (2 Used)          | 34 - Spring (18 Used)           | 52 - Adjusting Screw (2 Used) | 70 - *Pilot Pump           |
| 17 - Housing                  | 35 - Cylinder Block (2 Used)    | 53 - Plug (8 Used)            | 71 - *Socket Bolt (2 Used) |
| 18 - Tilt Pin (2 Used)        | 36 - Valve Plate                | 54 - Valve Cover              |                            |

 **NOTE:** As for the components with \* mark, refer to W2-3-4.


# UPPERSTRUCTURE / Pump Device

## ASSEMBLE REGULATOR (MAIN PUMP 2 SIDE)




T1F3-03-01-006

### Section B-B




T1F3-03-01-007

### Section A-A



T1F3-03-01-008



# UPPERSTRUCTURE / Pump Device



W1F3-02-04-007


# UPPERSTRUCTURE / Pump Device

## ASSEMBLE PTO GEAR BOX



- |                     |                          |                      |                       |
|---------------------|--------------------------|----------------------|-----------------------|
| 1 - Spacer (2 Used) | 5 - Retaining Ring       | 9 - Plug             | 12 - Bearing (2 Used) |
| 2 - Retaining Ring  | 6 - Pin                  | 10 - O-Ring (1B P24) | 13 - Gear             |
| 3 - Bearing         | 7 - Pin (2 Used)         | 11 - Gear case       | 14 - Retaining Ring   |
| 4 - Gear            | 8 - Socket Bolt (4 Used) |                      |                       |

# UPPERSTRUCTURE / Control Valve



W1F1-02-05-004


- 19 - Spring
- 20 - Washer
- 21 - O-Ring
- 22 - Spool

- 53 - Plug
- 54 - Backup Ring
- 55 - O-Ring
- 56 - Spring

- 57 - Poppet
- 68 - Overload Relief Valve
- 69 - Overload Relief Valve


- 70 - Backup Ring
- 71 - O-Ring
- 72 - Housing

# UPPERSTRUCTURE / Control Valve




WCAB-02-05-006

# UPPERSTRUCTURE / Control Valve




W1F1-02-05-007

Main Spool (28, 46, 52)




Main Spool (36)



Boom 1


Section A



W176-02-05-022



Boom Anti-Drift Valve

W176-02-05-024





W176-02-05-025

# UPPERSTRUCTURE / Control Valve



Main Spool  
(154, 170, 176, 182)


Main Spool (160)



Arm Anti-Drift Valve

W176-02-05-024


Section B



W176-02-05-027

# UPPERSTRUCTURE / Control Valve


## DISASSEMBLE AUXILIARY CONTROL VALVE



W198-02-05-001

- |                  |                  |                           |                  |
|------------------|------------------|---------------------------|------------------|
| 1 - Nut          | 17 - Sleeve      | 33 - Backup Ring          | 48 - Socket Bolt |
| 2 - Bolt         | 18 - O-Ring      | 34 - Valve                | 49 - Socket Bolt |
| 3 - O-Ring       | 19 - Nut         | 35 - Sleeve               | 50 - Cover       |
| 4 - Spring       | 20 - Bolt        | 36 - O-Ring               | 51 - End Spool   |
| 5 - Valve        | 21 - O-Ring      | 37 - Seat                 | 52 - Seat        |
| 6 - Sleeve       | 22 - Spring      | 38 - O-Ring               | 53 - Spring      |
| 7 - Backup Ring  | 23 - Valve       | 39 - Valve                | 54 - Spring      |
| 8 - O-Ring       | 24 - Sleeve      | 40 - Spring               | 55 - Seat        |
| 9 - O-Ring       | 25 - Backup Ring | 41 - Sleeve               | 56 - O-Ring      |
| 10 - Spring      | 26 - O-Ring      | 42 - O-Ring               | 57 - Spool       |
| 11 - Spring      | 27 - O-Ring      | 43 - Spring               | 58 - O-Ring      |
| 12 - Pin         | 28 - Spring      | 44 - Poppet               | 59 - Plug        |
| 13 - Valve       | 29 - Spring      | 45 - Socket Bolt (2 Used) | 60 - Drive Screw |
| 14 - O-Ring      | 30 - Pin         | 46 - Cover                | 61 - Plate       |
| 15 - Backup Ring | 31 - Valve       | 47 - O-Ring               | 62 - Housing     |
| 16 - Valve       | 32 - O-Ring      |                           |                  |


# UPPERSTRUCTURE / Swing Device



W176-02-06-003


# UPPERSTRUCTURE / Swing Device

---



W176-02-06-004

# UPPERSTRUCTURE / Swing Device



W176-02-06-012


## UPPERSTRUCTURE / Swing Device

---

(Blank)

## UPPERSTRUCTURE / Pilot Valve

### ASSEMBLE FRONT/SWING PILOT VALVE




W1F3-02-07-002

- |                       |                          |                      |                           |
|-----------------------|--------------------------|----------------------|---------------------------|
| 1 - Screw Joint       | 6 - Bushing (4 Used)     | 11 - Spring (4 Used) | 16 - Bushing              |
| 2 - Cam               | 7 - O-Ring (4 Used)      | 12 - Washer (4 Used) | 17 - Spring Pin           |
| 3 - Universal Joint   | 8 - Pusher (4 Used)      | 13 - Spool (4 Used)  | 18 - Port Plate           |
| 4 - Plate             | 9 - Spring Seat (4 Used) | 14 - Casing          | 19 - Seal Washer (2 Used) |
| 5 - Oil Seal (4 Used) | 10 - Spring (4 Used)     | 15 - O-Ring          | 20 - Socket Bolt (2 Used) |

# UPPERSTRUCTURE / Pilot Shut-Off Valve

## DISASSEMBLE PILOT SHUT-OFF VALVE



W178-02-08-005

- 1 - Washer
- 2 - Backup Ring
- 3 - O-Ring
- 4 - Body


- 5 - Socket Bolt
- 6 - Retaining Ring
- 7 - Washer
- 8 - Backup Ring

- 9 - O-Ring
- 10 - Spool
- 11 - Bracket
- 12 - Pin



- 13 - Socket Bolt (3 Used)

# UPPERSTRUCTURE / Travel Shockless Valve

## CONSTRUCTION OF TRAVEL SHOCKLESS VALVE




Section A



Section B

## UPPERSTRUCTURE / Solenoid Valve

### CONSTRUCTION OF 3-UNIT SOLENOID VALVE (FOR PUMP CONTROL)




T1F3-03-10-016



| Item No. | Part Name    | Q'ty | Wrench Size (mm) | Tightening Torque |                     |                     | Remark |
|----------|--------------|------|------------------|-------------------|---------------------|---------------------|--------|
|          |              |      |                  | N·m               | (kgf·m)             | (lbf·ft)            |        |
| 1        | Adjust Screw | 3    |                  |                   |                     |                     |        |
| 2        | Lock Nut     | 3    | 10               | $5^{+2}_{-0}$     | $(0.5^{+0.2}_{-0})$ | $(3.7^{+1.5}_{-0})$ |        |
| 3        | Solenoid     | 3    |                  |                   |                     |                     |        |
| 4        | Socket Bolt  | 6    | 4                | $5^{+2}_{-0}$     | $0.5^{+0.2}_{-0}$   | $3.7^{+1.5}_{-0}$   |        |
| 5        | Spring       | 3    |                  |                   |                     |                     |        |
| 6        | O-Ring       | 3    |                  |                   |                     |                     |        |
| 7        | Diaphragm    | 3    |                  |                   |                     |                     |        |
| 8        | Washer       | 3    |                  |                   |                     |                     |        |
| 9        | O-Ring       | 3    |                  |                   |                     |                     |        |
| 10       | Spring       | 3    |                  |                   |                     |                     |        |
| 11       | O-Ring       | 3    |                  |                   |                     |                     |        |
| 12       | Spool        | 3    |                  |                   |                     |                     |        |
| 13       | O-Ring       | 3    |                  |                   |                     |                     |        |
| 14       | Sleeve       | 3    |                  |                   |                     |                     |        |
| 15       | Plate        | 3    |                  |                   |                     |                     |        |
| 16       | Washer       | 3    |                  |                   |                     |                     |        |

# UPPERSTRUCTURE / Steering Valve

## ASSEMBLE STEERING VALVE




T1F3-03-07-002



T487-03-02-005


W1F3-02-13-001

Section C-C




T1F3-03-07-003

Section D-D



T487-03-02-007


Section E-E



T487-03-02-006

# UPPERSTRUCTURE / Brake Valve

## DISASSEMBLE BRAKE VALVE



W1F3-02-14-003

## UPPERSTRUCTURE / Brake Valve

---

(Blank)




## UNDERCARRIAGE / Swing Bearing


---

(Blank)


# UNDERCARRIAGE / Travel Motor



W1GL-03-02-007




W1F3-03-02-002




W1F3-03-02-003

# UNDERCARRIAGE / Travel Motor

## ASSEMBLE BRAKE VALVE



W1F3-03-02-002



T1F3-03-05-034

- |                          |                          |                                    |              |
|--------------------------|--------------------------|------------------------------------|--------------|
| 1 - O-Ring (2 Used)      | 6 - Check Valve (2 Used) | 11 - Check Valve Assembly (2 Used) | 16 - Plug    |
| 2 - Cover                | 7 - O-Ring (2 Used)      | 12 - Cover                         | 17 - Orifice |
| 3 - Socket Bolt (4 Used) | 8 - Plug                 | 13 - Socket Bolt (4 Used)          |              |
| 4 - Plug (2 Used)        | 9 - O-Ring               | 14 - Valve Casing                  |              |
| 5 - Spring (2 Used)      | 10 - Shuttle Valve       | 15 - Counterbalance Valve          |              |

## UNDERCARRIAGE / Center Joint

---


When replacing the body or spindle with a new one, the following procedures are required:

Press bushing (3) into body.

1. Clean body (4) and bushing (3).
2. Press bushing (3) into body (4) using pressing tool.


Pressing force: 0.5 to 1.5 tons

Pressing tool (1): ST 7331




W105-03-03-029


# UNDERCARRIAGE / Transmission



W1F3-03-05-005



W1F3-03-05-006



W1F3-03-05-008

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below




- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

# UNDERCARRIAGE / Transmission

## ASSEMBLE FINAL DRIVE AND DIFFERENTIAL




W1F3-03-05-008


- |                    |                     |                    |                     |
|--------------------|---------------------|--------------------|---------------------|
| 47 - Gear Case     | 85 - Bolt (2 Used)  | 92 - Bolt (7 Used) | 99 - Plate          |
| 79 - Bearing       | 86 - Plate          | 93 - Bearing       | 100 - Bolt (2 Used) |
| 80 - Cover         | 87 - O-Ring         | 94 - Seal          | 101 - Lock Plate    |
| 81 - Plate         | 88 - Gear           | 95 - Plate         | 112 - Cover         |
| 82 - Bolt (8 Used) | 89 - Seal           | 96 - O-ring        | 113 - O-ring        |
| 83 - Flange        | 90 - Retaining Ring | 97 - Bolt (8 Used) |                     |
| 84 - Lock Plate    | 91 - Cover          | 98 - Flange        |                     |

# UNDERCARRIAGE / Transmission

## ASSEMBLY TRANSMISSION




A Part




W1F3-03-05-007

# UNDERCARRIAGE / Axle



W1F3-03-05-011


# UNDERCARRIAGE / Axle



W1F3-03-05-003


# UNDERCARRIAGE / Axle

## DISASSEMBLE REAR AXLE



W1F3-03-05-018

# UNDERCARRIAGE / Axle



W1F3-03-05-018

## UNDERCARRIAGE / Axle

---


(Blank)





## FRONT ATTACHMENT / Front Attachment

---

9. Connect grease pipe (1) onto the boss at boom cylinder rod side. (2 places both left and right)


 : 17 mm

 : 24.5 N·m (2.5 kgf·m, 18 lbf·ft)



W105-04-01-002

10. Add grease to the boom cylinder rod side, bottom side and boom foot side.




W1F3-04-01-010


## FRONT ATTACHMENT / Front Attachment

### MAINTENANCE STANDARD

#### Pin and Bushing



WCAB-04-01-007




WCAB-04-01-008

Unit: mm (in)

|   | Item                    | Standard  | Allowable Limit | Remedy  |
|---|-------------------------|-----------|-----------------|---------|
| A | Pin                     | 71 (2.81) | 70.0 (2.76)     | Replace |
|   | Bushing                 | 71 (2.81) | 72.5 (2.85)     |         |
| B | Pin                     | 80 (3.15) | 79.0 (3.11)     |         |
|   | Boss (Main Frame)       | 80 (3.15) | 81.5 (3.21)     |         |
|   | Bushing (Boom Cylinder) | 80 (3.15) | 81.5 (3.21)     |         |
| C | Pin                     | 71 (2.80) | 70.0 (2.76)     |         |
|   | Bushing (Boom Cylinder) | 71 (2.80) | 72.5 (2.85)     |         |
|   | Boss (Boom)             | 71 (2.80) | 72.5 (2.85)     |         |
| D | Pin                     | 71 (2.80) | 70.0 (2.76)     |         |
|   | Bushing                 | 71 (2.80) | 72.5 (2.85)     |         |
| E | Pin                     | 71 (2.80) | 70.0 (2.76)     |         |
|   | Boss (Arm)              | 71 (2.80) | 72.5 (2.85)     |         |
|   | Bushing (Arm Cylinder)  | 71 (2.80) | 72.5 (2.85)     |         |
| F | Pin                     | 71 (2.80) | 70.0 (2.76)     |         |
|   | Boss (Boom)             | 71 (2.80) | 72.5 (2.85)     |         |
|   | Bushing (Arm Cylinder)  | 71 (2.80) | 72.5 (2.85)     |         |


## FRONT ATTACHMENT / Cylinder

6. Disconnect hoses (11) (2 used) from the bottom of arm cylinder (1). Attach a cap onto the open ends. In case the hose-rupture safety valve is equipped, refer to the "Remove and Install Hose-Rupture Safety Valve".

 : 36 mm


7. Disconnect grease hose (12) from arm cylinder (1).

Monoblock Boom



WCAB-04-01-005

2-Piece Boom




WCAB-04-01-003




**CAUTION: Arm cylinder weight:  
167 kg (370 lb)**


8. Attach a sling at the arm cylinder (1) center of gravity. Lift arm cylinder (1) off.



W102-04-02-016

9. Remove nuts (15) and bolt (17) from the tube side of arm cylinder (1). Push out pin (14). Remove thrust plates (13) and remove arm cylinder (1).

 : 30 mm



W187-04-02-007


## FRONT ATTACHMENT / Cylinder


### Install Blade Cylinder

**CAUTION:** Prevent person from injury. Metal fragments may fly when a hammer is used to install the pins. Be sure to wear necessary protection, such as goggles, hardhat and etc.


**CAUTION:** Blade cylinder (8) weight: 55 kg (120 lb)


1. Lift and hold blade cylinder (8). Align the pin (3) holes of the blade cylinder (8) bottom side and bracket (7) and the rod side and blade (9). Install thrust plate (4) and drive pins (3) (2 used). Install bolts (5) (2 used) and nuts (6) (4 used).


 : 24 mm


 : 210 N·m (21.5 kgf·m, 155 lbf·ft)

2. Connect hoses (10) (4 used) to blade cylinder (8).


 : 19 mm


 : 24.5 N·m (2.5 kgf·m, 18.0 lbf·ft)

 : 27 mm



 : 93 N·m (9.5 kgf·m, 69 lbf·ft)

3. Install protection cover (1) to blade cylinder (8) with bolts (2) (4 used).

 : 19 mm

 : 90 N·m (9.2 kgf·m, 66 lbf·ft)


**IMPORTANT:** After installation, operate the cylinder several times to stroke end to bleed air from the circuit.



# FRONT ATTACHMENT / Cylinder

## ASSEMBLE CYLINDER (Positioning)

### Positioning Cylinder




W1F3-04-04-007

- |                    |                          |                           |                 |
|--------------------|--------------------------|---------------------------|-----------------|
| 1 - Wiper Ring     | 7 - Cylinder Head        | 13 - Piston               | 19 - Shim       |
| 2 - Backup Ring    | 8 - Socket Bolt (2 Used) | 14 - Backup Ring (2 Used) | 20 - Nut        |
| 3 - U-Ring         | 9 - Backup Ring          | 15 - Seal Ring            | 21 - Set Screw  |
| 4 - Buffer Ring    | 10 - O-Ring              | 16 - O-Ring               | 22 - Steel Ball |
| 5 - Bushing        | 11 - Piston Rod          | 17 - Slide Ring           |                 |
| 6 - Retaining Ring | 12 - Cylinder Tube       | 18 - Slide Ring           |                 |

# FRONT ATTACHMENT / Cylinder


## MAINTENANCE STANDARD

### Piston Rod



W105-04-02-094

### Rod Bend and Run Out



W166-04-02-022

Unit: mm (in)

| Cylinder Name |           | Recommended Size After Re-manufacturing (A) |   |
|---------------|-----------|---|---|
| Boom          | 2-Piece   | 75 <sup>-0.023</sup> <sub>-0.053</sub>      | (2.9 <sup>-0.001</sup> <sub>5 -0.002</sub> )  |
|               | Monoblock | 70 <sup>-0.023</sup> <sub>-0.053</sub>      | (2.7 <sup>-0.001</sup> <sub>6 -0.002</sub> )  |
| Arm           |           | 80 <sup>-0.01</sup> <sub>-0.023</sub>       | (3.1 <sup>-0.0004</sup> <sub>5 -0.001</sub> ) |
| Positioning   |           | 95 <sup>-0.012</sup> <sub>-0.027</sub>      | (3.7 <sup>-0.005</sup> <sub>4 -0.001</sub> )  |
| Bucket        |           | 70 <sup>-0.023</sup> <sub>-0.053</sub>      | (2.7 <sup>-0.001</sup> <sub>6 -0.002</sub> )  |


Unit: mm (in)

| Bend        | Run out     | Remedy  |
|-------------|-------------|---------|
| 0.5 (0.020) | 1.0 (0.039) | Repair  |
| 1.0 (0.039) | 2.0 (0.079) | Replace |

### Wear to inner Diameter of Rod Bushing


Unit: mm (in)

| Cylinder Name |           | Standard inner Dimeter (C)           | Allowable Limit                             | Remedy |         |
|---------------|-----------|--------------------------------------|---|--------|---------|
| Boom          | 2-Piece   | 75 <sup>-0.06</sup> <sub>-0.19</sub> | (2.95 <sup>-0.002</sup> <sub>-0.007</sub> ) | +0.3   | Replace |
|               | Monoblock | 70 <sup>-0.06</sup> <sub>-0.19</sub> | (2.76 <sup>-0.002</sup> <sub>-0.007</sub> ) | +0.3   | Replace |
| Arm           |           | 80 <sup>-0.06</sup> <sub>-0.19</sub> | (3.15 <sup>-0.002</sup> <sub>-0.007</sub> ) | +0.3   | Replace |
| Positioning   |           | 95 <sup>-0.06</sup> <sub>-0.19</sub> | (3.74 <sup>-0.002</sup> <sub>-0.007</sub> ) | +0.3   | Replace |
| Bucket        |           | 70 <sup>-0.06</sup> <sub>-0.19</sub> | (2.76 <sup>-0.002</sup> <sub>-0.007</sub> ) | +0.3   | Replace |



## FRONT ATTACHMENT / Operate-Check Valve

### CONSTRUCTION OF OPERATE-CHECK VALVE (FOR BLADE/STABILIZER)



T1F3-03-10-003

| Item No. | Part Name   | Q'ty | Wrench Size | Tightening Torque |          |            | Remark            |
|----------|-------------|------|-------------|-------------------|----------|------------|-------------------|
|          |             |      |             | N-m               | (kgf.m)  | (lbf.ft)   |                   |
| 1        | Plug        | 1    | : 6 mm      |                   |          |            |                   |
| 2        | O-Ring      | 1    |             |                   |          |            | 1B P11            |
| 3        | Casing      | 1    |             |                   |          |            |                   |
| 4        | O-Ring      | 1    |             |                   |          |            | 1B P26            |
| 5        | Plug        | 1    | : 36 mm     | 360±36            | (37±3.7) | (265±26.5) |                   |
| 6        | Spring      | 1    |             |                   |          |            | φ1.0×φ8.5×31.0 mm |
| 7        | Poppet      | 1    |             |                   |          |            |                   |
| 8        | Check Valve | 1    |             |                   |          |            |                   |
| 9        | Piston      | 1    |             |                   |          |            |                   |
| 10       | O-Ring      | 1    |             |                   |          |            | 1B P24            |
| 11       | Plug        | 1    | : 36 mm     | 240±24            | (24±2.4) | (175±17.5) |                   |


## MAIN DATA AND SPECIFICATIONS

| Item                             | Engine Model                                | CC-4BG1TCG   | BB-4BG1TRG                              |
|----------------------------------|---|--|---|
| Engine type                      |   | Water cooled, four cycle, vertical in-line overhead valve        |   |
| Combustion chamber type          |   | Direct injection   |   |
| Cylinder liner type              |   | Dry  |   |
| No. of cylinders – bore × stroke | mm (in)                                     | 4 – 105 × 125 (4.13 × 4.92)                                      |   |
| Total piston displacement        | L (cid)                                     | 4.329 (464)  |   |
| Compression ratio                |   | 18 to 1  |   |
| Engine dimensions                | mm (in)                                     | 908 × 698 × 892<br>(35.7 × 27.5 × 27.5)                          | 900 × 718 × 892<br>(35.4 × 28.3 × 35.1) |
| Length × width × height          |   |  |   |
| Engine weight (Dry)              | kg (lb)                                     | 370 (816)  | 360 (794)                               |
| Fuel injection order             |   | 1-3-4-2  |   |
| Specified fuel                   |   | Diesel fuel (ASTM D975 No. 2D)                                   |   |
| Injection pump                   |   | In-line plunger, Bosch A type                                    |   |
| Governor                         |   | Mechanical, RSV type   |   |
| Injection nozzle                 |   | Multi hole   |   |
| Injection starting pressure      | MPa (kgf/cm <sup>2</sup> /psi)              | 18.1 (185/2,630)   |   |
| Injection timing (BTDC)          | (deg)                                       | 10   | 9                                       |
| Fuel filter type                 |   | Cartridge (spin-on)  |   |
| Water sedimentor                 | (If so equipped)                            | Sediment/water level indicating type                             |   |
| Compression pressure             | MPa (kgf/cm <sup>2</sup> /psi)<br>(At warm) | 3.04 (31/441) at 200 min <sup>-1</sup> at sea level              |   |
| Valve clearances (At cold)       | Intake mm (in)<br>Exhaust mm (in)           | 0.40 (0.016)<br>0.40 (0.016)                                     |   |
| Lubrication method               |   | Pressurized circulation  |   |
| Oil pump                         |   | Gear type  |   |
| Main oil filter type             |   | Full flow, cartridge (spin-on)                                   |   |
| Engine oil capacity              | OIL PAN L (US gal)<br>TOTAL SYSTEM capacity | MAX 13.2 (3.49), MIN 10 (2.64)<br>MAX 16.2 (4.28), MIN 13 (3.43) |   |
| Oil cooler                       |   | Water cooled integral type                                       |   |
| Cooling method                   |   | Pressurized forced circulation                                   |   |
| Coolant volume (engine only)     | L (US gal)                                  | 8.5 (2.25)   |   |
| Water pump                       |   | Belt driven impeller type  |   |
| Thermostat type                  |   | Wax pellet type  |   |
| Alternator                       | V-A   | 24-50  |   |
| Starter                          | V-KW  | 24-4.5   |   |
| Turbocharger manufacturer        |   | MITSUBISHI   |   |
| Turbocharger model               |   | TD04HL   |   |


# ANGULAR NUT AND BOLT TIGHTENING METHOD




1. Carefully wash the nuts and bolts to remove all oil and grease.



2. Apply a coat of molybdenum disulfide grease to the threads and setting faces of the nuts and bolts.




3. Tighten the nuts and bolts to the specified torque (snug torque) with a torque wrench.



4. Draw a line [A-B] across the center of each bolt.


## IDENTIFICATIONS



### MODEL IDENTIFICATION

#### Engine Serial Number

The engine number is stamped on the front left hand side of the cylinder body.



### INJECTION PUMP IDENTIFICATION

#### Injection Pump Number

Injection volume should be adjusted after referring to the adjustment data applicable to the injection pump installed.


The injection pump identification number (A) is stamped on the injection pump identification plate.

#### Note:

Always check the identification number before beginning a service operation.

Applicable service data will vary according to the identification number. Use of the wrong service data will result in reduced engine performance and engine damage.

## 2-10 MAINTENANCE




Degree

| Engine Model  | Injection Timing |
|---------------|------------------|
| AA-4BG1TCG-01 | 9                |
| CC-4BG1TCG    | 10               |
| BB-4BG1TRG    | 9                |

**Note:**

Injection pump injection timing will vary among identical engines contact your machine supplier or nearest ISUZU engine service outlet for the specifications applicable to your engine.

These specifications have been set by ISUZU and the OEM manufacturer.



7. Remove the delivery valve holder from the No. 1 plunger.

8. Reinstall the delivery valve internal parts (seat, spring, and valve) to the delivery valve holder.

9. Reinstall the delivery valve holder assembly to the No. 1 plunger and tighten it to the specified torque.

N·m (kgf·m/lb.ft)

|                              |                     |
|------------------------------|---------------------|
| Delivery Valve Holder Torque | 39-44 (4-4.5/29-33) |
|------------------------------|---------------------|

10. Install the No. 1 cylinder injection pipe and tighten it to the specified torque.

N·m (kgf·m/lb.ft)



|                           |                       |
|---------------------------|-----------------------|
| Injection Pipe Nut Torque | 28-32 (2.9-3.3/21-24) |
|---------------------------|-----------------------|

**Note:**

DO NOT OVERTIGHTEN THE INJECTION PUMP BODY.


THE INJECTION PUMP BODY IS MADE OF ALUMINUM. OVERTIGHTENING WILL DISTORT THE INJECTION PUMP BODY SHAPE AND ADVERSELY AFFECT CONTROL RACK OPERATION.



## EXTERNAL PARTS DISASSEMBLY STEPS

(Left-hand side)


MODEL CC-4BG1TRB



### Disassembly Steps

- |                            |                         |
|----------------------------|-------------------------|
| 1. Dipstick and guide tube | 6. Gasket               |
| 2. Air breather            | 7. Starter              |
| 3. Oil feed pipe           | 8. Fan belt             |
| 4. Oil drain pipe          | 9. Alternator           |
| ▲ 5. Turbocharger          | 10. Fan pulley          |
|                            | 11. Cylinder head cover |






- Use a dial indicator to measure the idler gear inside diameter.

mm (in)

|   | Standard                     | Limit          |
|---|------------------------------|----------------|
| Idler Gear and Idler Gear Shaft Clearance | 0.025–0.085<br>(0.001–0.003) | 0.2<br>(0.008) |



**CAMSHAFT**


- Use the camshaft bearing remover and installer to remove camshaft bearing from the cylinder body.

Camshaft Bearing Remover and Installer: 9-8523-1818-0


- Measure the clearance between the cam journal and the camshaft bearing.

mm (in)

|                                       | Standard                   | Limit           |
|---------------------------------------|----------------------------|-----------------|
| Cam Journal and Cam Bearing Clearance | 0.03–0.09<br>(0.001–0.004) | 0.15<br>(0.006) |




- Align the camshaft bearing oil holes with the mating oil ports (machined on the cylinder body camshaft bearing fitting bore).




- Use a micrometer to measure the cam lobe height.  
If the cam lobe height is less than the specified limit, the camshaft must be replaced.

mm (in)

|                       |     | Standard                     | Limit        |
|-----------------------|-----|------------------------------|--------------|
| Cam Journal Diameter  |     | 55.94–55.97<br>(2.202–2.204) | 55.6 (2.189) |
| Cam Nose Height (C-D) | In  | 7.34                         | 6.82         |
|                       | Exh | 7.73                         | 7.21         |





**Connecting Rod Bushing Installation**

Use the connecting rod bushing installer to install the connecting rod bushing.

Connecting Rod Bushing Installer: 9-8523-1369-0



**Note:**

The connecting rod bushing oil port must be aligned with the connecting rod oil port.

- Use a piston pin hole grinder ① fitted with a reamer ② or an adjustable pilot reamer to ream the piston pin hole.

mm (in)

|  | Standard                         |
|--|----------------------------------|
| Connecting Rod Bushing Inside Diameter | 35.017–35.025<br>(1.3786–1.3789) |




**Connecting Rod Bearing Inspection**

- Fit the connecting rod bearing lower half into the connecting rod bearing cap.
- Check the connecting rod bearing lower half tension. If the tension is insufficient, the bearing must be replaced.
- Tighten the connecting rod and the bearing cap to the specified torque.

N·m (kgf·m/lb.ft)

|   | 1st step     | 2nd step |
|---|--------------|----------|
| Connecting Rod and Bearing Cap Bolt Tightening Torque | 39<br>(4/29) | 60°–90°  |



- Use an inside dial indicator to measure the connecting rod inside diameter.


mm (in)

|   |            |
|---|------------|
| Connecting Rod Bearing Nominal Diameter | 64 (2.520) |
|---|------------|



# PISTON AND CONNECTING ROD REASSEMBLY STEPS


## MIRROR COMPONENT



01SEY00200

### Reassembly Steps


- ▲ 1. Piston
- ▲ 2. Connecting-rod
- ▲ 3. Piston pin, Snap ring
- ▲ 4. Piston ring
- ▲ 5. Connecting rod bearing



- 2) Install the oil pump with the coupling.
- 3) Tighten the oil pump bolts to the specified torque.

N·m (kgf·m/lb.ft)

|                      |                       |
|----------------------|-----------------------|
| Oil Pump Bolt Torque | 42-62 (4.3-6.3/31-46) |
|----------------------|-----------------------|




**13. Oil Pan**

- 1) Apply liquid gasket to the area indicated by the arrows in the illustration.
- 2) Install the oil pan gasket
- 3) Install the oil pan.

Tighten the oil pan bolts to the specified torque.

N·m (kgf·m/lb.ft)

|                     |                       |
|---------------------|-----------------------|
| Oil Pan Bolt Torque | 21-30 (2.1-3.1/15-22) |
|---------------------|-----------------------|



**14. Oil Cooler**

- 1) Apply liquid gasket to the oil cooler gasket.
- 2) Install the oil cooler gasket to the oil cooler body case.
- 3) Install the oil cooler.


Tighten the oil cooler bolts to the specified torque.

Start from the middle and work out to either side.

Refer to the illustration

N·m (kgf·m/lb.ft)

|                   |                       |
|-------------------|-----------------------|
| Oil Cooler Torque | 16-25 (1.6-2.6/12-19) |
|-------------------|-----------------------|



**Important Operation**




**2. Injection Nozzle**

Install the injection nozzles with the injection nozzle gaskets.

Be careful not to damage the nozzle tips.

N·m (kgf·m/lb.ft)

|                              |                             |
|------------------------------|-----------------------------|
| Injection Nozzle Bolt Torque | 17 – 21 (1.7 – 2.1/12 – 15) |
|------------------------------|-----------------------------|



**3. Injection Pipe and Fuel Leak Off Pipe**



1) Install the fuel injection pipes ① and tighten the bolts to the specified torque.

N·m (kgf·m/lb.ft)


|                       |                             |
|-----------------------|-----------------------------|
| Injection Pipe Torque | 28 – 32 (2.9 – 3.3/21 – 24) |
|-----------------------|-----------------------------|

2) Carefully position and set the clips ②.

It is very important that each clip be positioned correctly.

An improperly positioned clip will result in objectionable fuel pulsing noise and injection pipe breakage.

3) Install the fuel leak off pipes ③.



**4. Oil port cover**




Install the oil port cover with tightening the bolts securely.

N·m (kgf·m/lb.ft)

|                            |                             |
|----------------------------|-----------------------------|
| Oil Port Cover Bolt Torque | 30 – 50 (3.1 – 5.1/22 – 37) |
|----------------------------|-----------------------------|




REASSEMBLY



**Reassembly Steps**

- |                         |                         |
|-------------------------|-------------------------|
| 1. By-pass valve        | 4. By-pass valve plug   |
| 2. By-pass valve spring | 5. Element gasket       |
| 3. O-ring; plug         | ▲ 6. Oil cooler element |



**Important Operation**




**6. Oil Cooler Element**

Install the oil cooler element to the oil cooler, and tighten the cooler element fixing nuts to the specified torque.

N·m (kgf·m/lb.ft)

|   |                       |
|---|-----------------------|
| Oil Cooler Element<br>Fixing Nut Torque | 20-26 (2.0-2.7/14-20) |
|---|-----------------------|




**Important Operation**

**3. Injection Pipe Connector**



N·m (kgf·m/lb.ft)

|                         |                             |
|-------------------------|-----------------------------|
| Nozzle Connector Torque | 49 – 59 (5.0 – 6.0/36 – 43) |
|-------------------------|-----------------------------|



**4. Injection Nozzle**




There must be no oil on the contact surfaces of the injection nozzle and the injection nozzle holder.

Clean these contact surfaces with diesel fuel before installation.



The nozzle dowel pin must be aligned with the dowel hole in the nozzle holder body.




**5. Retaining Nut**



N·m (kgf·m/lb.ft)

|                             |                             |
|-----------------------------|-----------------------------|
| Nozzle Retaining Nut Torque | 59 – 78 (6.0 – 8.0/43 – 58) |
|-----------------------------|-----------------------------|



**Injection Starting Pressure Adjustment**

The injection nozzle injection starting pressure can be adjusted after the adjusting screw is installed.




Refer to "FUEL SYSTEM" on Page 2-4 of the "MAINTENANCE" Section of this Workshop Manual.


MPa (kgf/cm<sup>2</sup>/psi)

|                             |                 |
|-----------------------------|-----------------|
| Injection Starting Pressure | 18.1 (185/2630) |
|-----------------------------|-----------------|


## GENERAL DESCRIPTION



## STARTER SECTIONAL VIEW



## PERFORMANCE



## PERFORMANCE TEST

For the performance test of the starter, a no-load test is conducted according to the procedures mentioned below.

Before the performance test, fix the starter on the test bench.


**Note:** Since the rated time is 30 sec., conduct the test promptly.

### No-Load Test

See the following figure for connection.

Close the key switch, and the starter will be energized and will start rotating.

Then, measure the current and the number of revolutions.



### REASSEMBLY

To reassemble the alternator, follow the reverse of disassembling procedure, and observe the following precautions:

- (1) Lubrication is not required. Both bearing are prelubricated.

**Note:**

For the rotor bearing with resin bands, grease should not be applied. Remove oils completely to prevent creep of the bearing if found on the bearing box.

- (2) High temperature solder (Melting point of 466° F) should be used.

Solder quickly, use a 180–270 watts soldering iron no more than about 5 seconds because the rectifier may be damaged if it is overheated.


- (3) Tightening torque.

|                                   |           |
|-----------------------------------|-----------|
| • Pulley securing nut.            | : 147 N·m |
| • Through bolts.                  | : 4.9 N·m |
| • Bearing retainer screws.        | : 3.4 N·m |
| • Coil assembly retaining screws. | : 3.4 N·m |
| • Rectifier retaining screw.      | : 3.4 N·m |
| • Regulator retaining screws.     | : 3.4 N·m |
| • Nut for stud bolt.              | : 8.8 N·m |

- (4) To assemble the rear bracket / starter assembly and front bracket / rotor assembly.

- a. Since the rotor bearing and rear bracket fitting is tight, before installing the rotor into the rear bracket assembly, heat the area around the bearing box of the rear bracket to 122 to 144° F.
- b. After the alternator has been completely assembled, rotate the pulley slowly by hand to be sure that the rotor turns smoothly.

## UNSTABLE LOW IDLING





Continued on the next page

## WHITE EXHAUST SMOKE

| Checkpoint                              | Trouble Cause  | Remedy  |
|---|--|---|
| Fuel                                    | Water particles in the fuel  | Replace the fuel  |
| OK                                      |  |   |
| Fuel injection timing                   | Delayed fuel injection timing  | Adjust the fuel injection timing                          |
| OK                                      |  |   |
| Compression pressure                    | Blown out cylinder head gasket<br>Worn cylinder liner<br>Piston ring sticking or broken<br>Improper seating between the valve and the valve seat | Replace the related parts                                 |
| OK                                      |  |   |
| Turbocharger                            | Defective turbocharger   | Replace the turbocharger                                  |
| OK                                      |  |   |
| Inlet and exhaust valves<br>Valve seals | Defective valve seals<br>Worn valves stems and valve guides  | Replace the valve seals, the valves, and the valve guides |
| OK                                      |  |   |
| Piston rings                            | Piston rings worn, broken or improperly installed  | Replace the piston rings or properly install              |
| OK                                      |  |   |
| Cylinder liners                         | Cylinder lines scored or worn  | Replace the cylinder liners                               |



13-10 REPAIR STANDARDS

| Major Category | Name of Part | Inspection Item                                    | Nominal Dimension  | Assembly Standard Value | Limit                              | Repair Procedure                       | Comments                               |                                       |  |
|----------------|--------------|--|--|-------------------------|------------------------------------|--|--|---------------------------------------|--|
| Valve System   | Valves       | Inlet valve stem wear                              | Dia. 9<br>(0.3543)   |                         | Dia. 8.88<br>(0.3496)              | Replace valve and valve guide together | Measure valve stem at three positions  |                                       |  |
|                |              | Exhaust valve stem wear                            |  |                         |                                    |  |  |                                       |  |
|                |              | Clearance between inlet valve stem and valve guide |  |                         | 0.039 - 0.071<br>(0.0015 - 0.0028) | 0.20<br>(0.008)                        | Replace valve and valve guide together |                                       |  |
|                |              | Clearance between exhaust valve stem and guide     |  |                         | 0.064 - 0.096<br>(0.0025 - 0.0038) | 0.25<br>(0.0098)                       |  |                                       |  |
|                |              | Interference between valve guide and cylinder head |  |                         | 0.024<br>(0.0009)                  |  |  | Apply oil to valve guide and press in |  |
|                |              | Valve thickness                                    | Thickness<br> | 1.5<br>(0.059)          |                                    | 1.00<br>(0.039)                        | Replace valve and valve guide together |                                       |  |
|                |              | Height of valve guide above cylinder head          |               | 14.1<br>(0.555)         |                                    |  |  | Reference value                       |  |
|                |              | Valve stem oil seal lip                            |  | Dia. 8.5<br>(0.335)     |                                    |  | Replace oil seal                       | Don't damage lip.                     |  |
|                |              | Valve spring                                       | Tension N (kgf/lb)<br>(When compressed to installed length) 44.5mm(1.752in)                      |                         |                                    | 142 (14.5/30.9)                        | 127 (13.0/28.7)                        |                                       |  |
|                |              |  | Free height  | mm<br>(in)              |                                    | 60.6 (2.39)                            | 58.0 (2.28)                            | Replace valve spring                  |  |
|                |              |  | Inclination  | mm<br>(in)              |                                    | less than 1.9 (0.075)                  | 2.7 (0.106)                            |                                       |  |

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL