

PART NO. TT4FK-E-00

**HITACHI**

# Technical Manual

## Troubleshooting

# ZW

# 100-G

# 120-G

## Wheel Loader

ZW100-G · 120-G WHEEL LOADER TECHNICAL MANUAL TROUBLESHOOTING

 **Hitachi Construction Machinery**

URL:<http://www.hitachi-c-m.com>

PRINTED IN JAPAN (K) 2011.04

Service Manual consists of the following separate Part No.  
Technical Manual (Operational Principle) : Vol. No.TO4FK-E  
Technical Manual (Troubleshooting) : Vol. No.TT4FK-E  
Workshop Manual : Vol. No.W4FK-E

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

## SAFETY

---

### OPERATE ONLY FROM OPERATOR'S SEAT

- Inappropriate engine starting procedures may cause the machine to runaway, possibly resulting in serious injury or death.
  - Start the engine only when seated in the operator's seat.
  - NEVER start the engine while standing on the track or on ground.
  - Do not start engine by shorting across starter terminals.
  - Before starting the engine, confirm that all control levers are in neutral.
  - Before starting the engine, confirm the safety around the machine and sound the horn to alert bystanders.



SA-431

012-E01B-0431

---

### JUMP STARTING

- Battery gas can explode, resulting in serious injury.
  - If the engine must be jump started, be sure to follow the instructions shown in the "OPERATING THE ENGINE" chapter in the operator's manual.
  - The operator must be in the operator's seat so that the machine will be under control when the engine starts.
  - Jump starting is a two-person operation.
  - Never use a frozen battery.
  - Failure to follow correct jump starting procedures could result in a battery explosion or a runaway machine.



SA-032


S013-E01A-0032 SA-032

## SAFETY

---

### PROTECT AGAINST FLYING DEBRIS

- If flying debris hit eyes or any other part of the body, serious injury may result.
  - Guard against injury from flying pieces of metal or debris; wear goggles or safety glasses.
  - Keep bystanders away from the working area before striking any object.



031-E01A-0432


SA-432

---

### PARK MACHINE SAFELY

To avoid accidents:

- Park machine on a firm, level surface.
- Lower bucket to the ground.
- Place the F-N-R lever in neutral, and put the park brake switch in the ON (parking brake) position.
- Run engine at slow idle speed without load for 5 minutes.
- Turn key switch to OFF to stop engine.
- Remove the key from the key switch.
- Lower the lock lever to the LOCK position.
- Close windows, roof vent, and cab door.
- Lock all access doors and compartments.



033-E07B-0456

SA-456

## SAFETY

---

### AVOID HEATING NEAR PRESSURIZED FLUID LINES

- Flammable spray can be generated by heating near pressurized fluid lines, resulting in severe burns to yourself and bystanders.
  - Do not heat by welding, soldering, or using a torch near pressurized fluid lines or other flammable materials.
  - Pressurized lines can be accidentally cut when heat goes beyond the immediate flame area. Install temporary fire-resistant guards to protect hoses or other materials before engaging in welding, soldering, etc..



SA-030

---

### AVOID APPLYING HEAT TO LINES CONTAINING FLAMMABLE FLUIDS

- Do not weld or flame cut pipes or tubes that contain flammable fluids.
- Clean them thoroughly with nonflammable solvent before welding or flame cutting them.

510-E01B-0030

---

### REMOVE PAINT BEFORE WELDING OR HEATING

- Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch. If inhaled, these fumes may cause sickness.
    - Avoid potentially toxic fumes and dust.
    - Do all such work outside or in a well-ventilated area. Dispose of paint and solvent properly.
    - Remove paint before welding or heating:
1. If you sand or grind paint, avoid breathing the dust. Wear an approved respirator.
  2. If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.



SA-029

511-E01A-0029

## OPERATIONAL PERFORMANCE TEST / Standard

### ZW100-G OPERATIONAL PERFORMANCE STANDARD TABLE

The standard Performance values are listed in the table below. Refer to the Group T4-3 to T4-5 for performance test procedures. Values indicated in parentheses are reference values.

Accelerator Pedal : Full Stroke  
 Hydraulic Oil Temperature : 50±5 °C (122±9 °F)

The following switch positions shall be selected and the hydraulic oil temperature shall be maintained as indicated below as the preconditions of performance tests unless otherwise instructed in each performance test procedure:


PERFORMANCE TEST DESIGNATION	ZW100-G (Performance Standard)	Remarks	Reference Page
<b>ENGINE SPEED</b> min <sup>-1</sup>			T4-3-1
Slow Idle Speed (without load)	1100±25		
Fast Idle Speed (without load)	2350 <sup>+0</sup> <sub>-.50</sub>		
Fast Idle Speed (with HST relieved)	2220±50		
Fast Idle Speed (with Front attachment relieved)	2160±50		
<b>ENGINE COMPRESSION PRESSURE</b> MPa(kgf/cm <sup>2</sup> ,psi)	3.4 (34, 493)	Engine speed: 200 min <sup>-1</sup>	T4-3-3
<b>VALVE CLEARANCE (IN, EX)</b> mm	0.23 to 0.27	With the engine cold	T4-3-4
<b>RADIATOR CAP OPENING PRESSURE</b> kPa(kgf/cm <sup>2</sup> ,psi)	49 (0.5, 7)		
<b>TRAVEL SPEED</b> km/h			T4-4-1
Fast Speed	34.5 <sup>+0.4</sup> <sub>-.3.5</sub>		
Slow Speed	12.5±1.2		
<b>SERVICE BRAKE CAPACITY</b> m	5 or less	Travel Speed 20 km/h	T4-4-2
<b>PARKING BRAKE CAPACITY</b> mm/5 min	0		T4-4-3

# OPERATIONAL PERFORMANCE TEST / Engine Test

## ENGINE SPEED


### Summary:

1. Measure the engine speed by using the monitor panel or Dr. ZX.
2. Measure the engine speeds in each mode.

 **NOTE:** *If the engine speed under each condition is not adjusted correctly, all other performance data will be unreliable. Consequently, measure the engine speed before performing all other tests in order to check that the engine speed meets specification.*

### Preparation:

1. Select the service mode of monitor panel or the service menu of Dr. ZX.
2. Warm up the machine until coolant temperature reaches 50 °C (122 °F) or more, hydraulic oil temperature is 50±5 °C (122±9 °F).



T4FJ-02-04-020

Engine Speed



T4FJ-05-02-003

## OPERATIONAL PERFORMANCE TEST / Wheel Loader Test

---

### Measurement:

1. Select the pedal, switch, and FNR shift lever positions as follows:

Cylinder	Accelerator Pedal	Parking Brake Switch	Forward/ Reverse Lever
Lift Arm	Fully Depressing	ON	N
Bucket	Fully Depressing	ON	N
Steering	Not Depressing	ON	N
Steering	Fully Depressing	ON	N

2. Operate each cylinder as follows (including the cushion stroke range):

#### Lift Arm Cylinder:

While moving the lift arm lever full stroke, measure the time required to raise or lower the lift arm. In addition, measure the time required to lower the lift arm from the maximum raised position to the ground with the lift arm lever in the FLOAT position.

#### Bucket Cylinder:

While moving the bucket lever full stroke, measure the time required to tilt or dump the bucket.

#### Steering Cylinder:

While turning the steering wheel full stroke, measure the time required to fully steer the machine from the right to the left and vice versa.

3. Repeat measurement three times and calculate the average value.

### Evaluation:

Refer to the Performance Standard Table in Group T4-2.

### Remedy:

Refer to the Troubleshooting B in Group T5-6.

## **OPERATIONAL PERFORMANCE TEST / Component Test**

---

(Blank)

## OPERATIONAL PERFORMANCE TEST / Component Test

---

### Measurement:



**CAUTION:** Put the blocks onto the front and rear tires in order not to move the machine and keep away from the machine.

1. Select the following positions.

	Accelerator Pedal	Parking Brake Switch	Forward/Reverse Lever	Travel Mode Switch
Engine Fast Idle	Fully depressing	OFF	F	Hi
Engine Fast Idle	Fully depressing	OFF	R	Hi

2. With the service brake pedal depressed, step on the accelerator pedal to the stroke end. Measure the pressure at the engine fast idle speed.
3. Repeat the measurement three times and calculate the mean values.

### Evaluation:

Refer to Operational Performance Standard in T4-2.

---

Malfunction of High Beam Indicator .....	T5-7-14
Malfunction of Working Light Indicator ....	T5-7-16
Malfunction of Maintenance Indicator .....	T5-7-18
Malfunction of Preheat Indicator .....	T5-7-19
Malfunction of HST Oil Temperature Indicator.....	T5-7-20
Malfunction of HST Warning Indicator ....	T5-7-22
Malfunction of Engine Oil Pressure Indicator.....	T5-7-24
Faulty Overheat Indicator .....	T5-7-25
Malfunction of Engine Warning Indicator.....	T5-7-26
Malfunction of Stop Indicator .....	T5-7-27
Malfunction of Service Indicator.....	T5-7-28
Malfunction of Parking Brake Indicator ...	T5-7-30
Malfunction of Clearance Light Indicator.....	T5-7-32
Malfunction of Brake Low Oil Level Indicator.....	T5-7-34
Malfunction of Emergency Steering Indicator (Optional).....	T5-7-36
Malfunction of Low Steering Oil Pressure Indicator (Optional).....	T5-7-38
Malfunction of Discharge Warning Indicator.....	T5-7-40
Malfunction of Monitor Display.....	T5-7-42
Malfunction of Ride Control Indicator (Optional) .....	T5-7-43
Malfunction of Engine Coolant Temperature Display.....	T5-7-44

---

## Group 8 Electrical System Inspection

Precautions for Inspection and Maintenance .....	T5-8-1
Instructions for Disconnecting Connectors .....	T5-8-3
Fuse Inspection .....	T5-8-4
Fusible Link and Fuse (100A) Inspection ..	T5-6-6
Battery Voltage Check .....	T5-6-7
Alternator Check.....	T5-6-8
Continuity Check.....	T5-6-9
Voltage and Current Measurement .....	T5-6-10
Check by False Signal .....	T5-6-15

## TROUBLESHOOTING / Dr. ZX

---

### OUTLINE

Dr. ZX is used for diagnosis of MC (main controller), ECM (engine control module), ICF (information controller) and the monitor unit. Dr. ZX is connected to ICF and the failure of each controller and each sensor is displayed as a fault code. (Self-Diagnostic Result)

Dr. ZX displays the input status of the sensors and the switches connected to each controller and the output status to the actuator including the solenoid valve from the controller with the machine operated in real time. (Controller Diagnosis)

# TROUBLESHOOTING / Dr. ZX

Push Record.

Actual Speed	700	min-1
<div style="background-color: black; width: 100%; height: 10px;"></div>		
Vehicle Speed	5	km/h
<div style="background-color: black; width: 100%; height: 10px;"></div>		
M.I/P Shaft S	1000	min-1
<div style="background-color: black; width: 100%; height: 10px;"></div>		
Output Shaft S	1000	min-1
<div style="background-color: black; width: 100%; height: 10px;"></div>		
<input type="button" value="Record"/> <input type="button" value="HOLD"/> <input type="button" value="ESC"/>		

T4FC-05-02-104

Monitor data

"Now Recording"

T1V7-05-03-096

Push Rec. No. and the recording screen for Rec. No. is made.

Select Write Data-Bank

<input type="button" value="1"/>	<input type="button" value="2"/>	<input type="button" value="3"/>	<input type="button" value="4"/>	<input type="button" value="5"/>	<input type="button" value="6"/>	<input type="button" value="7"/>	<input type="button" value="8"/>
<input type="button" value="9"/>	<input type="button" value="10"/>	<input type="button" value="11"/>	<input type="button" value="12"/>	<input type="button" value="13"/>	<input type="button" value="14"/>	<input type="button" value="15"/>	<input type="button" value="16"/>

To the lower

T1V7-05-03-097

Monitor Screen

If Rec. No. has already been recorded and push Overwrite, data is overwritten. Push ESC and return to Main Menu Screen.

Rec. No.: 1  
Data: 2011/01/12 04:01:52

Model: 04FJ  
Serial No.: 000001

(1)Actual Speed (2)Vehicle Speed  
(3)M.I/P Shaft S (4)Output Shaft S

T4FJ-05-02-105

If Rec. No. has not been recorded yet and push Overwrite, data is written to the recording screen. Push ESC and return to Main Menu Screen.

Rec. No.: 2  
Data: 2011/01/12 04:08:32

T4FJ-05-03-100

Select Write Data-Bank Screen

Push Comment. Push ESC and return to Main Menu Screen.

Rec. No.: 2  
Data: 2011/01/12 04:08:32

Model: 04FJ  
Serial No.: 000001

(1)Actual Speed (2)Vehicle Speed  
(3)M.I/P Shaft S (4)Output Shaft S

To the lower

T4FJ-05-02-106

Recording Screen

Recording Screen

Input weather and person's name in change and push OK.

Rec. No.: 2  
Data: 2011/01/12 04:08:32

.....  
.....

Model: 04FJ  
Serial No.: 000001

(1)Actual Speed (2)Vehicle Speed  
(3)M.I/P Shaft S (4)Output Shaft S

T4FJ-05-02-107

Push OK and the recording screen (making) is finished.

Rec. No.: 2  
Data: 2011/01/12 04:08:32

fine  
.....  
Mr.umino

Model: 04FJ  
Serial No.: 000001

(1)Actual Speed (2)Vehicle Speed  
(3)M.I/P Shaft S (4)Output Shaft S

T4FJ-05-02-108

Push Re-Input and return to Recording Screen (Comment Input). Push ESC and return to Monitor Screen.

Rec. No.: 2  
Data: 2011/01/12 04:08:32

fine Mr.Umino

Model: 04FJ  
Serial No.: 000001

(1)Actual Speed (2)Vehicle Speed  
(3)M.I/P Shaft S (4)Output Shaft S

T4FJ-05-02-109

Recording Screen (Comment Input)

# TROUBLESHOOTING / Dr. ZX

Push Record.

Engine Torque 20.5 %  
 Act. Eng Speed 1700 min-1  
 Coolant Temp. 40 °C

Record HOLD ESC

T4FL-05-02-114

Monitor Screen

Monitor data

Now Recording

T1V7-05-03-134

Push Rec. No. and the recording screen for Rec. No. is made.

Select Write Data-Bank

1 2 3 4 5 6 7 8  
 9 10 11 12 13 14 15 16

ESC

T1V7-05-03-135

Select Write Data-Bank Screen

If Rec. No. has already been recorded and push Overwrite, data is overwritten. Push ESC and return to Main Menu Screen.

Rec. No.: 1  
 Data: 2011/01/12 04:56:11

Model: 04FJ  
 Serial No.: 000001

(1)Engine Torque (2)Act. Eng Speed  
 (3)Coolant Temp.

Overwrite ESC

T4FL-05-02-122

Recording Screen

If Rec. No. has not been recorded yet and push Overwrite, data is written to the recording screen. Push ESC and return to Main Menu Screen.

Rec. No.: 2  
 Data: 2011/01/12 04:56:11

Overwrite ESC

T4FL-05-02-030

Recording Screen

Push Comment. Push ESC and return to Main Menu Screen.

Rec. No.: 2  
 Data: 2011/01/12 04:56:11

Model: 04FJ  
 Serial No.: 000001

(1)Engine Torque (2)Act. Eng Speed  
 (3)Coolant Temp.

Comment ESC

T4FL-05-02-123

Push Re-Input and return to Recording Screen (Comment Input). Push ESC and return to Main Menu Screen.

Input weather and person's name in change and push OK.

Rec. No.: 2  
 Data: 2011/01/12 04:56:11

Model: 04FJ  
 Serial No.: 000001

(1)Engine Torque (2)Act. Eng Speed  
 (3)Coolant Temp.

OK

T4FL-05-02-124

Recording Screen (Comment Input)

Push OK and the recording screen (making) is finished.

Rec. No.: 2  
 Data: 2011/01/12 04:56:11  
 fine  
 Mr. umino

Model: 04FJ  
 Serial No.: 000001

(1)Engine Torque (2)Act. Eng Speed  
 (3)Coolant Temp.

OK

T4FL-05-02-125

Rec. No.: 2  
 Data: 2011/01/12 04:56:11

Model: 04FJ  
 Serial No.: 000001

(1)Engine Torque (2)Act. Eng Speed  
 (3)Coolant Temp.


Re-Input ESC

T4FL-05-02-126

# TROUBLESHOOTING / Dr. ZX

## Satellite Terminal: Initialize


After starting Dr. ZX, push Select Controller.



T1V7-05-03-001

Function Selection Screen


Push Information C/U.



T4GB-05-02-053

Controller Selection Screen


Push Start.



T4GD-05-02-013

Title Screen


Push OK.



T4FJ-05-02-116

ICF Controller Screen


Push Information C/U: Various setup.



T4GD-05-02-014

Main Menu Screen


Push ▼ and move to the next screen of Information C/U: Various Setup Screen. Push Satellite Terminal: Initialize.



T1V7-05-03-035


Information C/U: Various Setup Screen

Push Exec.  
Push ESC and return to Information C/U: Various Setup Screen.




T1V7-05-03-036

Push OK and return to Information C/U: Various Setup Screen.



T1V7-05-03-145




T1V7-05-03-035

Information C/U: Various Setup Screen

# TROUBLESHOOTING / Dr. ZX

## Monitoring


After starting Dr. ZX, push Select Controller.



T1V7-05-03-001

Function Selection Screen


Push Monitor Unit.



T4GB-05-02-053

Controller Selection Screen

Push OK.




T4FJ-05-02-040

Monitor Controller Screen

To the lower


Push Start.



T1V7-05-03-025

Title Screen


Push Monitoring.



T1V7-05-03-042

Main Menu Screen

Push item for monitoring and push OK. Refer to T5-2-40 as for the monitoring item. Push ESC and return to Main Menu Screen.




T4FJ-05-02-119

Monitoring Item Selection Screen

To the lower

When pushing HOLD, the monitor is stopped temporarily. When re-starting the monitor, push HOLD again. Push ESC and return to Monitoring Item Selection Screen.




T4FJ-05-02-120

Monitoring Screen

# TROUBLESHOOTING / e-Wheel

## Data Download


After starting Dr. ZX, push Select Controller.



T1V7-05-03-001

Function Selection Screen


Push Information C/U.



T4GB-05-02-053

Controller Selection Screen


Push Start.



T4GD-05-02-013

Title Screen


Push OK.



T4FJ-05-02-116

ICF Controller Screen


Push Data Download.



T4GD-05-02-014

Main Menu Screen


While downloading data, Data Download Screen is displayed.



T1V7-05-03-038

Data Download Screen


When downloading is completed normally, Normal End Screen is displayed. Push OK and return to Main Menu Screen.



T1V7-05-03-039

Normal End Screen


If pushing Cancel on Data Download Screen, Alarm Screen is displayed. Push OK and return to Main Menu Screen.



T1V7-05-03-148

Alarm Screen

Push ESC and return to Title Screen.




T4FJ-05-02-014

Main Menu Screen

# TROUBLESHOOTING / e-Wheel


## 1.9 Enter Satellite Comm. Start/Stop

Push ▼ and move to the next screen of Information C/U: Various Setup Screen.  
Push Enter Satellite Comm. Start/Stop.




Information C/U: Various Setup Screen

In normal, Start is selected. When stopping Satellite Comm., due to some reasons, push Stop and push Exec.  
Push ESC and return to Information C/U: Various Setup Screen.



# TROUBLESHOOTING / Component Layout

## ELECTRICAL SYSTEM (OVERVIEW)




T4FJ-01-02-003

 **NOTE:** The illustration shows the cab Vehicle

- |  |                                |  |   |
|--|--------------------------------|--|---|
| 1 - Bucket Proximity Switch (Optional) | 6 - HST Oil Temperature Sensor | 11 - Rear Combination Light (Turn Signal Light/ Clearance Light/ Brake Light/ Reverse Light) | 16 - Brake Oil Level Switch             |
| 2 - Front Work Light (Optional)        | 7 - Battery Relay              | 12 - Fuel Level Sensor   | 17 - Brake Light Switch                 |
| 3 - Horn                               | 8 - Reverse Buzzer             | 13 - Solenoid Pump   | 18 - Clearance Light/ Turn Signal Light |
| 4 - Front Wiper Motor (Cab)            | 9 - Rear Work Light            | 14 - ECM (Engine Control Module)   | 19 - Head Light                         |
| 5 - Rear Wiper Motor (Cab)             | 10 - Battery                   | 15 - ECM Main Relay  |   |

## TROUBLESHOOTING / Component Layout

### TRANSMISSION



T4FJ-01-02-014

- |                                |  |   |                                    |
|--------------------------------|--|---|------------------------------------|
| 1 - Transmission               | 4 - Travel Mode Selector Solenoid Valve, Accumulator | 7 - Displacement Angel Control Solenoid Valve | 10 - Parking Brake                 |
| 2 - Vehicle Speed Sensor       | 5 - HST Motor  | 8 - Travel Control Solenoid Valve             | 11 - Parking Brake Pressure Sensor |
| 3 - Travel Mode Selector Valve | 6 - HST Pressure Sensor                              | 9 - Parking Brake Solenoid Valve              |                                    |

## TROUBLESHOOTING / Troubleshooting A

Symptoms in Machine Operation When Trouble Occurs	Remedy
The machine can travel reverse only.	<ul style="list-style-type: none"> <li>• Retrial B by using Dr. ZX.</li> <li>• Check the harness.</li> </ul>
The machine can travel forward only.	<ul style="list-style-type: none"> <li>• Retrial B by using Dr. ZX.</li> <li>• Check the harness.</li> </ul>
The abnormality cannot be recognized although HST circuit failure occurs.	<ul style="list-style-type: none"> <li>• Retrial B by using Dr. ZX.</li> <li>• Check the harness.</li> </ul>
The machine speed cannot increase as the vehicle speed is limited for the clutch is slow speed side.	<ul style="list-style-type: none"> <li>• Retrial B by using Dr. ZX.</li> <li>• Check the harness.</li> </ul>
The back-up buzzer does not sound during slow travel operation.	<ul style="list-style-type: none"> <li>• Retrial B by using Dr. ZX.</li> <li>• Check the harness.</li> </ul>
<ul style="list-style-type: none"> <li>• The machine speed cannot increase as the vehicle speed is limited for the clutch is slow speed side.</li> <li>• The machine speed cannot be shifted.</li> </ul>	<ul style="list-style-type: none"> <li>• Retrial B by using Dr. ZX.</li> <li>• Check the harness.</li> <li>• Replace the sensor.</li> </ul>
The machine cannot travel.	<ul style="list-style-type: none"> <li>• Retrial B by using Dr. ZX.</li> <li>• Check the harness.</li> <li>• Check the Forward/reverse lever.</li> </ul>
The machine speed cannot increase as the vehicle speed is limited.	<ul style="list-style-type: none"> <li>• Retrial B by using Dr. ZX.</li> <li>• Check the CAN harness.</li> <li>• Replace the ECM.</li> <li>• Replace the MC.</li> </ul>
There is no influence when operating the machine.	<ul style="list-style-type: none"> <li>• Retrial B by using Dr. ZX.</li> <li>• Check the CAN harness.</li> <li>• Replace the monitor unit.</li> <li>• Replace the MC.</li> </ul>
The machine cannot travel.	<ul style="list-style-type: none"> <li>• Retrial B by using Dr. ZX.</li> <li>• Check the harness.</li> <li>• Replace the MC.</li> </ul>

## TROUBLESHOOTING / Troubleshooting A

---

---

---

### Remedy

---

Refer to the Troubleshooting flow chart.

---

If this error code is displayed after retriial, replace the monitor unit.

---

Check the CAN harness.

---

- Retriial B by using Dr. ZX
  - Check the harness.
  - Replace the sensor.
- 

- Retriial B by using Dr. ZX
  - Check the harness.
  - Replace the sensor.
- 

- Retriial B by using Dr. ZX
  - Check the harness.
  - Replace the sensor.
- 

- Retriial B by using Dr. ZX
  - Check the harness.
  - Replace the sensor.
- 

- Retriial B by using Dr. ZX
  - Check the harness.
  - Replace the sensor.
- 

- Retriial B by using Dr. ZX
  - Check the harness.
  - Replace the sensor.
-

# TROUBLESHOOTING / Troubleshooting A

## Discontinuity Check between CAN Circuit and Ground Circuit

**IMPORTANT: Before continuity check, turn the key switch OFF.**

- In case of continuity, the circuit between CAN circuit and ground circuit is shorted.
- In case of discontinuity, the circuit is normal.

### • MC Connector

Between CAN Circuit (High Side) and Ground Circuit

Check for continuity between terminals #40 and #2 of harness end of MC connector.

Check for continuity between terminal #40 and #28 of harness end of MC connector.


Between CAN Circuit (Low Side) and Ground Circuit

Check for continuity between terminals #39 and #2 of harness end of MC connector.

Check for continuity between terminals #39 and #28 of harness end of MC connector.


### Connector

MC Connector  
(Harness end)



T4FC-05-05-001

MC Connector  
(Harness end)



T4FC-05-05-001

# TROUBLESHOOTING / Troubleshooting A

## Discontinuity Check in CAN Harness


**IMPORTANT:** Before continuity check, turn the key switch OFF.

- In case of continuity, the circuit between CAN (High side) circuit and CAN (Low side) circuit is shorted.
- In case of discontinuity, the circuit is normal.

- MC Connector

Check for continuity between terminals #40 and #39 of harness end of MC connector.

MC Connector  
(Harness end)




T4FC-05-05-001

- Connector Monitor-2B in Monitor Unit

Check for continuity between terminals #33 and #34 of harness end of connector monitor-2B in the monitor unit.

Monitor Unit  
Connector Monitor-2B  
(Harness end)




T4GB-05-05-002

- Connector ECM

Check for continuity between terminals #23 and #24 of harness end of connector in ECM.

ECM Connector  
(Harness end)




T4FL-05-07-001

- Connector ICF-C

Check for continuity between terminals C5 and C11 of harness end of connector ICF-C in ICF.

ICF  
Connector ICF-C  
(Harness end)




T1V1-05-04-002

# TROUBLESHOOTING / Troubleshooting A


## MC FAULT CODE 11455

Fault Code	Trouble	Cause	Influenced Control
11455-2	Hi/Lo Control Signal Abnormal Output	<ul style="list-style-type: none"> <li>Faulty the harness.</li> <li>Faulty the travel mode selector solenoid valve</li> </ul>	Slow Travel Speed Selection Control




Connector (Harness end of connector viewed from the open end side)

MC Connector



T4FC-05-05-001

Travel Mode Selector Solenoid Valve



T2BC-05-04-031

## **TROUBLESHOOTING / Troubleshooting A**


---

(Blank)

# TROUBLESHOOTING / Troubleshooting A


---

Fault Codes 14102-2, 14103-2



Satellite Terminal

T4FJ-01-02-008



T1V1-05-06-004

# TROUBLESHOOTING / Troubleshooting B


## TROUBLESHOOTING B PROCEDURE

Apply troubleshooting B procedure when no fault code is displayed on the service mode panel in monitor and Dr. ZX although the machine operation is abnormal.


On the front section pages of this group are the tables indicating the relationship between machine trouble symptoms and related parts which may cause such trouble if failed.

Start the troubleshooting with more probable causes selected by referring to these tables.

### • How to Read the Troubleshooting Flow Charts




- After checking or measuring item (1), select either YES (OK) or NO (NOT OK) and proceed to item (2) or (3), as appropriate.



- Special instructions or reference item are indicated in the spaces under the box. Incorrect measuring or checking methods will render troubleshooting impossible, and may damage components as well.

• Key switch: ON



- Use the service mode in monitor panel or the diagnosing system/monitor function in Dr. ZX.




- Causes are stated in a thick-line box. Scanning through thick-line boxes, possible causes can be seen without going through the flow chart.

## TROUBLESHOOTING / Troubleshooting B


Evaluation by Fault Code	Evaluation by Monitor Function	NOTE	Descriptions of Control (Operational Principle Section in T/M)
-	-	-	T2-4, T3-4
-	Monitor Item: Ride control proportional solenoid valve output	<ul style="list-style-type: none"> <li>• If the vehicle speed sensor malfunctions, monitor unit makes ride control disabled.</li> </ul>	T2-2, T2-4, T3-10
-	-	-	T2-4, T3-3
-	-	-	T2-2

# TROUBLESHOOTING / Troubleshooting B



Connector (Harness end of connector viewed from the open end side)


ECM Connector  
(Harness end)



T4FL-05-07-001

#40

Starter Relay



T8V4-05-07-001

## TROUBLESHOOTING / Troubleshooting B

---



(Blank)

# TROUBLESHOOTING / Troubleshooting B

**T-3 Even if Forward/Reverse Lever is set to N position, machine travels forward.**


**Related MC Fault Code: None**

- Check the wiring connections first.




Connector (Harness end of connector viewed from the open end side)

Forward/Reverse Lever



Forward Selection Solenoid Valve



T6LE-05-03-002

T2BC-05-04-031



# TROUBLESHOOTING / Troubleshooting B

## OTHER SYSTEM TROUBLESHOOTING

### O-1 Air conditioner is faulty


The air conditioner has a self-diagnosis function.

The self-diagnosis functions to:


- 1) Display Fault Codes
- 2) Change Displayed Fault Codes
- 3) Delete Fault Code
- 4) End Fault Code Display


• Display Fault Code

1. Push the fan OFF switch and turn the fan OFF.
2. Push and hold both upper and lower sides of the temperature control switch on the air conditioner control panel at the same time for more than 3 seconds with the key switch ON.

 **NOTE:** After connect operation has been performed, the buzzer will sound.

3. If any fault codes are found, the LCD displays the fault codes as 「E00」.

 **NOTE:** If more than one fault code is found, the lower number fault code will be displayed first.





M178-01-017

### Fault Code List

Item	Fault Code	Cause	Symptom
Abnormal circulation air sensor	E11	Open circuit in air circulation sensor	Value Y (air flow-in temperature) in response to the set temperature is fixed.
	E12	Shorted circuit in air circulation sensor	
Abnormal fresh air sensor	E13	Open circuit in fresh air sensor	Operation is controlled under such circumstance as no fresh air sensor is provided.
	E14	Shorted circuit in fresh air sensor	
Abnormal coolant temperature sensor	E15	Open circuit in coolant temperature sensor	Operation is controlled under such circumstance as the water temperature is set to 60 °C (140 °F). (Warm-up control is not performed.)
	E16	Shorted circuit in coolant temperature sensor	
Abnormal air vent sensor	E21	Open circuit in air vent sensor	Operation is controlled under such circumstance as air flow-in temperature 0 °C (32 °F).
	E22	Shorted circuit in air vent sensor	
Abnormal damper	E43	Abnormal air vent damper	Corresponding damper servo becomes inoperable.
	E44	Abnormal air mix damper	
Abnormal refrigerant	E51	Abnormal high/low refrigerant pressure	The compressor clutch is disengaged. (The compressor stops.)

## TROUBLESHOOTING / Troubleshooting B



 **NOTE:**

1. Do not quickly decide that oil is leaking when a stain around the clutch and/or gasket is found. A slight oil seepage will appear due to the seal construction. However, this oil seepage will not cause malfunction. Accurately check whether oil is leaking or seeping only.
2. When gas detector is used in the high sensitivity range, normal gas leaks from rubber hose surface may be detected. As long as the specified rubber hoses are used, the problem should not occur. (In case a large leaks is detected, the hose may be broken.)
3. After allowing the compressor to idle for 10 to 15 minutes, normal pressure difference between high-pressure side and low-pressure side is 0.5 MPa (5 kgf/cm<sup>2</sup>) or less. When the clutch is turned OFF, the pressure difference between high-pressure side and low-pressure side will disappear within about 10 seconds.

## **TROUBLESHOOTING / Troubleshooting B**

---

3. The checklist before the summer season is as follows:

- (1) Check each air conditioner component for abnormalities.
- (2) Check the line connections for oil leaks.
- (3) Check refrigerant quantity.
- (4) Check the engine cooling circuit.
- (5) Check V-belts for wear. Replace if necessary.

4. Off-Season Maintenance

- (1) During off-season, operate the idler pulley and compressor at least once a month for a short time in order to check for any abnormal sounds.
- (2) Do not remove the compressor belts during off-season. Operate the compressor occasionally at slow speed for 5 to 10 minutes with the belt slightly loosened in order to lubricate the machine parts.

## TROUBLESHOOTING / Troubleshooting B

Generated/Detected Data Position	Controller Sending Data on CAN	Inspected Position
Crank speed sensor	ECM	Communication line between ECM and ICF (CAN bus line)
Front attachment pressure sensor	MC	Communication line between MC and ICF (CAN bus line)
HST circuit pressure sensor	MC	Communication line between MC and ICF (CAN bus line)
MC	MC	Communication line between MC and ICF (CAN bus line)
Coolant temperature sensor	Monitor unit	Communication line between monitor unit and ICF (CAN bus line)
HST oil temperature sensor	Monitor unit	Communication line between monitor unit and ICF (CAN bus line)
Vehicle speed sensor	MC	Communication line between MC and ICF (CAN bus line)
MC	MC	Communication line between MC and ICF (CAN bus line)
Vehicle speed sensor	MC	Communication line between MC and ICF (CAN bus line)
ECM	ECM	Communication line between ECM and ICF
<ul style="list-style-type: none"> <li>• ECM</li> <li>• Vehicle speed sensor</li> </ul>	<ul style="list-style-type: none"> <li>• MC</li> <li>• ECM</li> </ul>	<ul style="list-style-type: none"> <li>• Communication line between MC and ICF (CAN bus line)</li> <li>• Communication line between ECM and ICF (CAN bus line)</li> </ul>
<ul style="list-style-type: none"> <li>• MC</li> <li>• Vehicle speed sensor</li> </ul>	MC	Communication line between MC and ICF (CAN bus line)
<ul style="list-style-type: none"> <li>• HST oil temperature sensor</li> <li>• Vehicle speed sensor</li> </ul>	<ul style="list-style-type: none"> <li>• Monitor unit</li> <li>• MC</li> </ul>	<ul style="list-style-type: none"> <li>• Communication line between MC and ICF (CAN bus line)</li> <li>• Communication line between monitor unit and ICF (CAN bus line)</li> </ul>


As for inspection method of the CAN line, refer to TROUBLESHOOTING / Troubleshooting A.

# TROUBLESHOOTING / Troubleshooting C


## TROUBLESHOOTING C (TROUBLESHOOTING FOR MONITOR PANEL) PROCEDURE

Use troubleshooting C when any monitor panel, such as gauges or indicators malfunction.


- How to Read Troubleshooting Flow Charts



After completing the checking and/or measuring procedures in box (1), select YES (OK) or NO (NOT OK) and proceed to box (2) or (3).




Instructions, reference, and/or instruction methods on inspection and/or measurements are occasionally described under the box. If incorrectly checked or measured, not only will troubleshooting be unsuccessful but also damage to components may result.




Use the service mode in monitor panel and the diagnosing system / controller diagnosing system in Dr. ZX.





Causes of machine problems are stated in the thick-line box. Scanning quickly through the thick-line boxes, allows you to estimate the possible causes before actually following the flow chart.

 **NOTE:** *Harness end connector viewed from the open end side by the all connectors image shown in this section.*





# TROUBLESHOOTING / Troubleshooting C

## Fuel Gauge



T4GB-05-07-007


## Fuel Level Sensor



T4GB-05-07-008


NOTE: 1 mm = 0.03937 in

Float Position	Resistance (Ω)
Upper Limit (FULL)	$10^{+0}_{-4}$
1/2	32.9
Warning Level	$77 \pm 3$
Lower Limit (EMPTY)	$90^{+10}_{-0}$




Connector (Harness end of connector viewed from the open end side)

Monitor Unit  
Connector 2-A



T183-05-04-013

Fuel level Sensor



T183-05-04-010

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below




- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL


# TROUBLESHOOTING / Troubleshooting C

---




HST Oil Temperature Indicator

Oil Temperature	Operation
Less than 100 °C (212 °F)	OFF
100 °C (212 °F) or higher	ON




Connector (Harness end of connector viewed from the open end side)

Monitor Unit  
Connector 2-A



T183-05-04-013



## TROUBLESHOOTING / Troubleshooting C

---

---

Open circuit in harness between monitor unit and parking brake switch.


Faulty monitor unit.

Faulty monitor unit.

# TROUBLESHOOTING / Troubleshooting C


Connector (Harness end of connector viewed from the open end side)

ICF  
Connector-C



T1V1-05-04-002

Monitor Unit  
Connector 2-A



T183-05-04-013

\_\_\_\_\_ Faulty monitor unit.

\_\_\_\_\_ Faulty harness between terminal L in alternator and monitor unit.

\_\_\_\_\_ Faulty regulator, or faulty alternator.

	13 V or more Less than 33.5 V	
Check voltage at terminal #2 of connector 2-A in monitor unit.		Faulty monitor unit.
· Engine: Running		Faulty harness between terminal L in alternator and monitor unit.
	Less than 13 V or 33.5 V or more	Faulty alternator.

\_\_\_\_\_ Refer to Engine System Troubleshooting in Troubleshooting B.

\_\_\_\_\_ Faulty monitor unit, or faulty charge lamp.


## TROUBLESHOOTING / Electrical System Inspection

---

### BATTERY VOLTAGE CHECK


1. Turn the key switch OFF.
2. Open the battery box cover on left side of the machine with the front attachment side facing forward.
3. Check voltage between the battery positive terminal and the vehicle frame (ground).


Normal Voltage: 24 V

 *NOTE: If voltage is abnormal, recharge or replace the battery.*

4. Start the engine. Check voltage between the battery positive terminal and the vehicle frame (ground).

Normal Voltage: 26 to 28 V

 *NOTE: If voltage is abnormal, check the charging system.*



T4FC-05-08-003



# SAFETY

## WEAR PROTECTIVE CLOTHING


- Wear close fitting clothing and safety equipment appropriate to the job.

You may need:

- A hard hat
- Safety shoes
- Safety glasses, goggles, or face shield
- Heavy gloves
- Hearing protection
- Reflective clothing
- Wet weather gear
- Respirator or filter mask.

Be sure to wear the correct equipment and clothing for the job. Do not take any chances.

- Avoid wearing loose clothing, jewelry, or other items that can catch on control levers or other parts of the machine.
- Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating the machine.



SA-438

005-E01A-0438

## PROTECT AGAINST NOISE

- Prolonged exposure to loud noise can cause impairment or loss of hearing.
  - Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortably loud noises.



006-E01A-0434

SA-434

## INSPECT MACHINE

- Inspect your machine carefully each day or shift by walking around it before you start it to avoid personal injury.
  - In the walk-around inspection be sure to cover all points described in the “PRE-START INSPECTION” chapter in the operator’s manual.



007-E01A-0435

SA-435


## SAFETY

---

### AVOID ACCIDENTS FROM BACKING UP AND TURNING

- Make sure no one is working under or close to the machine before backing up or turning the machine to avoid personal injury and/or death by being run over or entangled in the machine.
  - Keep all personnel away from the machine by sounding the horn and/or using hand signals. Use extra care to be sure no one is in from the articulation area before turning the machine.
  - Keep windows, mirrors, and lights in good condition.
  - Reduce travel speed when dust, heavy rain, fog, etc., reduce the visibility.
  - In case good visibility is not obtained, use a signal person to guide you.

021-E02A-0517



SA-383



SA-312

# SAFETY

## PREVENT BURNS

Hot spraying fluids:

- After operation, engine coolant is hot and under pressure. Hot water or steam is contained in the engine, radiator and heater lines. Skin contact with escaping hot water or steam can cause severe burns.
  - To avoid possible injury from hot spraying water. DO NOT remove the radiator cap until the engine is cool. When opening, turn the cap slowly to the stop. Allow all pressure to be released before removing the cap.
  - The hydraulic oil tank is pressurized. Again, be sure to release all pressure before removing the cap.



SA-039

Hot fluids and surfaces:

- Engine oil, gear oil and hydraulic oil also become hot during operation. The engine, hoses, lines and other parts become hot as well.
  - Wait for the oil and components to cool before starting any maintenance or inspection work.



SA-225

505-E01B-0498

## REPLACE RUBBER HOSES PERIODICALLY

- Rubber hoses that contain flammable fluids under pressure may break due to aging, fatigue, and abrasion. It is very difficult to gauge the extent of deterioration due to aging, fatigue, and abrasion of rubber hoses by inspection alone.
  - Periodically replace the rubber hoses. (See the page of "Periodic replacement of parts" in the operator's manual.)
- Failure to periodically replace rubber hoses may cause a fire, fluid injection into skin, or the front attachment to fall on a person nearby, which may result in severe burns, gangrene, or otherwise serious injury or death.



SA-019

S506-E01A-0019

---

---

# SECTION 1

# GENERAL

## — CONTENTS —

### **Group 1 Precautions for Disassembling and Assembling**

Precautions for Disassembling and Assembling ..... W1-1-1

### **Group 2 Tightening**

Tightening Bolts and Nuts..... W1-2-1

Piping Joint..... W1-2-8

### **Group 3 Painting**

Painting ..... W1-3-1

### **Group 4 Bleeding Air from Hydraulic Circuit**

Bleeding Air from Hydraulic Oil Tank..... W1-4-1

Bleeding Air from Hydraulic System..... W1-4-2

### **Group 5 Hydraulic Circuit Pressure Release Procedure**

Hydraulic Circuit Pressure

Release Procedure ..... W1-5-1

### **Group 6 Preparation**

Preparations for Inspection and


Maintenance ..... W1-6-1

# GENERAL / Tightening


## Precautions for Spilt Flange

### IMPORTANT:


- Clean the sealing surfaces. Check if there are any scratches and roughness on the surface of the seal that cause oil leaks and damage to the O-ring.
- Use only specified O-rings. Inspect O-rings for any damage. Do not file the O-ring surfaces. When installing O-ring into a groove, use grease in order to hold O-ring in place.
- While tightening the bolt by hand, check that flange is installed to the port correctly. Do not pinch the O-ring.
- Tighten the bolts up and down, left and right alternately, in order to ensure even tightening to the specified torque.
- Do not use air wrenches. Using an impact wrench often causes tightening of one bolt fully before tighten the others, resulting in damage to O-rings or uneven tightening of bolts.



W105-01-01-015



W105-01-01-016



## Nut and Bolt Locking



- Lock Plate

**IMPORTANT:** Do not reuse the lock plates. Do not try to bend the same point twice.

- Split Pin



**IMPORTANT:** Do not turn in the loosening direction in order to align the grooves and holes on the nut. Always turn in the tightening direction. Do not reuse the split pins.

W105-01-01-008



W105-01-01-009

a - Bend along edge sharply      b - Do not bend it round



c - Tighten      d - Loosen


W105-01-01-010

## GENERAL / Hydraulic Circuit Pressure Release Procedure

### HYDRAULIC CIRCUIT PRESSURE RELEASE PROCEDURE

Release the remaining pressure in hydraulic circuit as follows when front attachment etc. have been removed / installed.


1. Set front control lever lock (1) to the UN LOCK position.
2. Run the engine at low idle speed for 5 minutes to cool the engine.
3. Turn key switch OFF.
4. Move front control lever (2) to 4 or 5 turn of pressure release circuit.
5. Set front control lever lock (1) to the LOCK position.




M4FJ-01-004

## BODY / Cab

12. Remove bolts (30) (7 used), spring washers (31) (7 used), and washers (32) (7 used) from cover (29). Remove cover (29) from bracket (33).

 : 17 mm





W4FJ-02-09-001

13. Disconnect connector (36).

**IMPORTANT: Do not release chlorofluorocarbon into the atmosphere for protection of the ozone layer and prevention of global warming.**


14. Disconnect hose (35) from receiver drier (34). Cap the open ends. Attach an identification tag onto the disconnected hoses for assembling.


 : 19 mm



W4FJ-02-01-003


15. Disconnect hoses (37, 38) between air conditioner unit and compressor. Cap the open ends. Attach an identification tag onto the disconnected hoses for assembling.

 : 24 mm, 27 mm



W4FJ-02-01-004

16. Loosen bands (40) (2 used). Disconnect hoses (39) (2 used) from heater pipe (41) (2 used). Cap the open ends. Attach an identification tag onto the disconnected hoses for assembling.




W4FJ-02-01-005

## BODY / Cab

### REMOVAL AND INSTALLATION OF CANOPY

#### Removal


1. Remove bolts (6) (4 used), nuts (8) (8 used), washers (7) (8 used), and rubbers (5) (4 used) from prop assembly (2). Remove roof (1) from prop assembly (2).

 : 19 mm



**CAUTION: Prop assembly (2): 56 kg (123 lb)**

2. Attach a nylon sling onto prop assembly (2). Hoist and hold prop assembly (2).
3. Remove bolts (3) (4 used) and washers (4) (4 used) from prop assembly (2). Remove prop assembly (2) from the cockpit.


 : 24 mm


#### Installation




**CAUTION: Prop assembly (2): 56 kg (123 lb)**


1. Attach a nylon sling onto prop assembly (2). Hoist and hold prop assembly (2). Fit prop assembly (2) to the mounting hole of the cockpit.
2. Install prop assembly (2) to the cockpit with washers (4) (8 used) and bolts (3) (4 used).


 : 24 mm

 : 210 N·m (21 kgf·m, 152 lbf·ft)

3. Install roof (1) to prop assembly (2) with rubbers (5) (4 used), washers (7) (8 used), nuts (8) (8 used), and bolts (6) (4 used).

 : 19 mm

 : 35 N·m (3.5 kgf·m, 25.5 lbf·ft)




W4FL-02-01-002


## BODY / Hydraulic Oil Tank


### REMOVAL AND INSTALLATION OF HYDRAULIC OIL TANK

#### Removal


1. Set the machine position for inspection and maintenance. (Refer to PREPARATION FOR INSPECTION AND MAINTENANCE on W1-6-1.)
2. Bleed air from the hydraulic oil tank. (Refer to BLEED AIR FROM HYDRAULIC OIL TANK on W1-4-1.)
3. Remove bolts (3) (6 used), spring washers (4) (6 used), and washers (5) (6 used) from cover (2). Remove cover (2) from hydraulic oil tank (1). Prepare a container (capacity: approx. 100 L). Drain hydraulic oil from hydraulic oil tank (1) by using a pump. Install cover (2) after draining hydraulic oil.

 **NOTE:** Hydraulic Oil Amount: 90 L

 : 17 mm

 : 50 N·m (5 kgf·m, 37 lbf·ft)


4. Remove bolts (9) (4 used), spring washers (10) (4 used), and washers (11) (4 used) from brackets (7, 8). Remove rear fender (6) from brackets (7, 8). Remove rear fender (6) at the opposite side in the same way.


 : 19 mm

 **CAUTION:** Side cover (12) weight: 24 kg (53 lb)


5. Remove bolts (13) (2 used), spring washers (14) (2 used), and washers (15) (2 used) from angle (16). Remove side cover (12) from hydraulic oil tank (1).

Remove side cover (12) at the opposite side in the same way.


 : 19 mm



M4FJ-07-034




W4FJ-03-06-001




W4FJ-02-04-002


## BODY / Hydraulic Oil Tank

22. Install right side panel (20) to hydraulic oil tank (1) and grill support (21) with washers (19) (4 used), spring washers (18) (4 used), and bolts (17) (4 used).

 : 17 mm


 : 50 N·m (5 kgf·m, 37 lbf·ft)


23. Install left side panel (22) to the hinge part of rear frame (23).




W4FJ-02-04-003

24. Fit angle (16) to the mounting hole of hydraulic oil tank (1). Install side cover (12) to hydraulic oil tank (1) with washers (15) (2 used), spring washers (14) (2 used), and bolts (13) (2 used). Install side cover (12) at the opposite side in the same way.


 : 19 mm


 : 90 N·m (9 kgf·m, 66 lbf·ft)




W4FJ-02-04-002

25. Install rear fender (6) to brackets (7, 8) with washers (11) (4 used), spring washers (10) (4 used), and bolts (9) (4 used). Install rear fender (6) at the opposite side in the same way.

 : 17 mm

 : 50 N·m (5 kgf·m, 37 lbf·ft)



W4FJ-03-06-001

## BODY / Pump Device

---

01 - Rotary Group	13 - Joint Pin (2 Used)	27 - Plug	46 - Adjusting Screw
05 - Forward/Reverse Selector Control Valve	20A - Plug	31 - Pin (2 Used)	47 - Lock Nut
07A - DA Valve	20B - O-Ring	32 - Plug (2 Used)	49 - Orifice
07B - Orifice	22A - Plug (4 Used)	33 - Plug (2 Used)	54 - Orifice
10 - Housing	22B - O-Ring (4 Used)	37 - Plug (2 Used)	
01A - Cylinder Assembly	01AF - Guide	01C - Swash Plate	01H - Bearing
01AA - Cylinder	01AG - Shim (2 Used)	01D - Guide	01J - Bearing (2 Used)
01AB - Piston (9 Used)	01AH - Spring	01E - Drive Shaft	01K - Retaining Ring
01AC - Spring	01AJ - Retaining Ring	01F - Pin (2 Used)	01L - Retaining Ring (2 Used)
01AD - Shim (Several)	01B - Control Plate	01G - Bearing Cup (2 Used)	01M - Shaft Seal
01AE - Retainer			
02A - Piston Assembly	02AE - Spring Collar (2 Used)	02AK - Spring Collar (2 Used)	02E - Socket Bolt (8 Used)
02AA - Piston	02AF - Spring (2 Used)	02AL - Spring (2 Used)	02F - O-Ring (2 Used)
02AB - Adjusting Screw	02AG - Spring (2 Used)	02B - Cover	02G - Guide Ring (2 Used)
02AC - Ring (2 Used)	02AH - Retaining Ring (2 Used)	02C - Cover	02H - Ring (2 Used)
02AD - Ring (2 Used)	02AJ - O-Ring	02D - Nut	
03AA - High-Pressure Relief Valve (2 Used)	03E - Bushing	03J - Plug	03M - Bushing
03B - Low-Pressure Relief Valve	03F - Socket Bolt (4 Used)	03K - O-Ring	03N - Metal
03C - Cutoff Valve	03G - O-Ring	03LA - Plug (2 Used)	03P - O-Ring (2 Used)
03D - Port Plate	03H - Plug (2 Used)	03LB - O-Ring (2 Used)	03Q - Plug (2 Used)
04 - Internal Gear Pump	04AD - Through Drive Shaft	04AJ - Socket Bolt (8 Used)	04B - Wear Plate
04A - Gear Pump Assembly	04AE - Wheel	04AK - O-Ring	04BA - Wear Plate
04AA - Flange	04AF - Key	04AL - Seal (8 Used)	04BB - O-Ring
04AB - Pump Cover	04AG - Ring	04AM - O-Ring	04C - Element (2 Used)
04AC - Bushing	04AH - Socket Bolt (4 Used)	04AN - O-Ring	

## BODY / Pump Device

### Assembly of HST Pump

**IMPORTANT:** Before assembling, apply hydraulic oil onto parts in order to prevent them from seizing.


1. Install seal rings (02H) (2 used) to housing (10).
2. Install guide rings (02G) (2 used) to housing (10).
3. Install adjusting screw (02AB) to piston (02A).
4. Install spring collars (02AK, 02AE), and springs (02AL, 02AF, 02AG) to piston (02A).

**IMPORTANT:** Spring collars (02AK, 02AE) may fly out due to the springs (02AL, 02AF, 02AG) force.


5. While pushing spring collar (02AE), install retaining ring (02AH) and rings (02AC, 02AD) to spring collar (02AE). Install O-ring (02AJ) to adjusting screw (02AB).
6. Assemble the piston (02AA) at the opposite side in the same way as steps 4 to 5.

**IMPORTANT:** Install so that lever (01D) and groove (a) on piston assembly (02A) are positioned as illustrated.

7. Install the piston assembly (02A) to housing (10).



W4FC-03-02-011

8. Install O-rings (02F) (2 used) to covers (02B, 02C).
9. Install covers (02B, 02C) onto housing (10) with socket bolts (02E) (8 used) while aligning the matching marks made when disassembling.  
 : 5 mm
10. Install nut (02D) to adjusting screw (02AB). Adjust the adjusting screw (02AB) to the recorded dimension before disassembling with nut (02D).

## BODY / Pump Device


---


01 - Front Cover	13 - Body	52 - O-Ring (2 Used)	62 - Socket Bolt (4 Used)
02 - Body	14 - Drive Gear	53 - Socket Bolt (8 Used)	63 - Washer (20 Used)
03 - Drive Gear	15 - Driven Gear	54 - Socket Bolt (8 Used)	64 - Oil Seal
04 - Driven Gear	16 - Side Plate (2 Used)	56 - Oil Seal	65 - Coupling
05 - Bearing (2 Used)	17 - Bushing	57 - Retaining Ring	66 - Retaining Ring
06 - Bearing (4 Used)	18 - Bushing (3 Used)	58 - O-Ring (5 Used)	67 - Steel Ball (2 Used)
07 - Side Plate (2 Used)	50 - Seal (2 Used)	60 - Gasket (2 Used)	68 - O-Ring
11 - Adapter Plate	51 - Gasket (2 Used)	61 - O-Ring	69 - Collar
12 - Adapter Plate			

## BODY / Control Valve

**⚠ CAUTION: Control valve (19) weight: 21 kg (47 lb)**

12. Attach a nylon sling onto control valve (19). Hoist and hold control valve (19).
13. Remove bolts (25) (3 used), nuts (26) (3 used), and washers (27) (3 used) from control valve (19). Remove control valve (19) from bracket (28).


 : 19 mm





### Installation

**⚠ CAUTION: Control valve (19) weight: 21 kg (47 lb)**


1. Attach a nylon sling onto control valve (19). Hoist control valve (19). Fit control valve (19) to the mounting hole of bracket (28). Install control valve (19) to bracket (28) with bolts (25) (3 used), washers (27) (3 used), and nuts (26) (3 used).

 : 19 mm

 : 90 N·m (9 kgf·m, 66 lbf·ft)




2. Connect control cables (24) (2 used) to the spools (2 places) of control valve (19) with clevis pins (23) (2 used), washers (22) (2 used), and snap pins (21) (2 used).




## BODY / Control Valve


### Disassembly of Lift Arm Spool Assembly

1. Remove O-ring (5), poppet (3), and spring (4) from the housing (1) assembly.
2. Secure the housing (1) assembly in a vise by using a copper plates.
3. Remove socket bolts (22) (2 used). Remove the spool (2) assembly and seal plate (9), and spacer (18) from the housing (1) assembly.


 : 5 mm

 **NOTE:** They can be removed easily by rotating spool (2).

4. Remove screws (8) (2 used) and seal plate (9) from housing (1). Remove wiper ring (7) and seal ring (6) from housing (1).
5. Secure the spool (2) assembly in a vise by using copper plates.
6. Remove retaining ring (21) and spacer (20) from cap (17).


 **CAUTION:** Steel ball (15) and steel balls (16) (4 used) may fly out due to the spring (12) force. Do not lose them.

7. Push in steel ball (15) through the pin (10) hole by using the hexagonal wrench (a) (3 mm or less). Remove sleeve (11) and cap (17) from the spool (2) assembly.




W4FJ-02-06-010

8. Remove steel ball (15), steel balls (16) (4 used), spring (12), and shim (23) through the pin (10) hole.

 **CAUTION:** The spring (13) force is applied to pin (10).

**IMPORTANT:** Insert the round bar (b) (6 mm or less) into the steel ball (16) hole of pin (10). Release spring (13) by rotating the round bar (b) counterclockwise slowly.





W4FJ-02-06-009

9. Remove pin (10), spring seats (14) (2 used), and spring (13) from the spool (2) assembly.
10. Remove seal plate (9) and spacer (18) from the spool (2) assembly.
11. Remove wiper ring (7), seal ring (6), and O-ring (19) from spacer (18).


## BODY / Steering Valve


6. Connect hoses (10) (2 used) to steering valve (7).

 : 22 mm


 : 40 N·m (4 kgf·m, 30 lbf·ft)


7. Connect hoses (9) (2 used) to steering valve (7).


 : 22 mm

 : 40 N·m (4 kgf·m, 30 lbf·ft)

8. Connect hose (8) to steering valve (7).


 : 19 mm


 : 30 N·m (3 kgf·m, 22 lbf·ft)



W4FJ-02-07-002

9. Install covers (1, 2, and 3) to the cockpit with washers (6) (9 used), spring washers (5) (9 used), and bolts (4) (9 used).


 : 17 mm

 : 50 N·m (5 kgf·m, 37 lbf·ft)

10. Close door (27) of the cab.

**IMPORTANT: Check the hydraulic oil level. Start the engine. Check for any oil leaks at each connection.**

11. Bleed air from the hydraulic system. (Refer to BLEED AIR FROM HYDRAULIC SYSTEM on W1-4-2.)



W4FJ-02-08-001


## BODY / Brake Valve


### REMOVAL AND INSTALLATION OF BRAKE VALVE

#### Removal

1. Set the machine position for inspection and maintenance. (Refer to PREPARATION FOR INSPECTION AND MAINTENANCE on W1-6-1.)
2. Before doing any work, stop the engine and depress/release the brake pedal about 80 times in order to release any pressure in the service brake circuit. The pedal can be depressed lightly when the pressure is released.


3. Remove bolts (3) (7 used), spring washers (4) (7 used), and washers (5) (7 used) from covers (1, 2). Remove covers (1, 2) from the cockpit.

 : 17 mm




W4FJ-02-08-001


4. Remove split pin (7) and washer (8) from pin (6). Remove pin (6) from joint (10). Remove joint (10) from lever (9).



M4FC-07-015




5. Disconnect hoses (12, 13) from brake valve (11). Cap the open ends. Attach an identification tag onto the disconnected hoses for assembling.

 : 19 mm




W4FJ-02-10-001


## BODY / Brake Valve

No.	Part Name	Q'ty	Wrench Size (mm)	Tightening Torque			Remark
				N·m	(kgf·m)	(lbf·ft)	
29	Body	1					
30	O-Ring	1					
31	Washer	4					
32	Bolt	4	 : 17	32	(3.2)	(23)	
33	Piston	1					
34	Stopper	1					
35	Packing	1					
36	Piston	1					
37	C-Ring	1					
38	Plug	3	 : 6	20	(2)	(15)	LOCTITE #262
39	Connector	2	 : 19	35	(3.5)	(26)	LOCTITE #262

## BODY / Inching Valve


4. Connect hoses (7, 8) to inching valve (6).

 : 22 mm

 : 40 N·m (4 kgf·m, 30 lbf·ft)


**IMPORTANT: Check the hydraulic oil level. Start the engine. Check for any oil leaks at each connection.**


5. Bleed air from the hydraulic system. (Refer to BLEED AIR FROM HYDRAULIC SYSTEM on W1-4-2.)




W4FJ-02-10-002

6. Install covers (1, 2) to the cockpit with washers (5) (7 used), spring washers (4) (7 used), and bolts (3) (7 used).

 : 17 mm

 : 50 N·m (5 kgf·m, 37 lbf·ft)



W4FJ-02-08-001

## **TRAVEL SYSTEM / Steering Cylinder**

---

(Blank)



## TRAVEL SYSTEM / HST Motor

---

(Blank)



## TRAVEL SYSTEM / HST Motor

### STRUCTURE OF HST MOTOR DISPLACEMENT ANGLE CONTROL VALVE



W4FC-03-03-012

- |                    |                    |                    |                           |
|--------------------|--------------------|--------------------|---------------------------|
| 1 - Solenoid       | 6 - Bushing        | 11 - Spring        | 16 - Pin                  |
| 2 - Control Piston | 7 - Spool          | 12 - Spring        | 17 - Socket Bolt          |
| 3 - Spring         | 8 - Retaining Ring | 13 - Spring Collar | 18 - Nut (Seal Lock)      |
| 4 - Housing        | 9 - Spring Collar  | 14 - Spring        | 19 - Solenoid             |
| 5 - Plug (5 Used)  | 10 - Spring Collar | 15 - O-Ring        | 20 - Socket Bolt (4 Used) |



W4FC-03-03-014

- |                            |            |                    |                           |
|----------------------------|------------|--------------------|---------------------------|
| 1 - Plug (2 Used)          | 5 - O-Ring | 9 - Plunger        | 13 - O-Ring               |
| 2 - O-Ring (2 Used)        | 6 - Shim   | 10 - Orifice       | 14 - Housing              |
| 3 - Spring (2 Used)        | 7 - Plug   | 11 - Spool         | 15 - Socket Bolt (4 Used) |
| 4 - Spring Collar (2 Used) | 8 - Spring | 12 - Plug Assembly | 16 - Retaining Ring       |

## TRAVEL SYSTEM / Transmission

---

(Blank)

---

## TRAVEL SYSTEM / Transmission

---

1 - Bolt (23 Used)	26 - Bolt (3 Used)	51 - D-Ring	76 - Sleeve
2 - Spring Washer (23 Used)	27 - Bolt (4 Used)	52 - Piston	77 - Output Gear (Lo)
3 - Transmission Cover	28 - Bolt (4 Used)	53 - D-Ring	78 - Retaining Ring (3 Used)
4 - Transmission Case	29 - Spring Washer (4 Used)	54 - Oil Seal	79 - Output Shaft
5 - Breather	30 - Suction Tube	55 - Cap	80 - Output Gear (Hi)
6 - Parking Brake Solenoid Valve	31 - Gasket	56 - Spring (12 Used)	81 - Bearing
7 - Washer (4 Used)	32 - O-Ring	57 - Washer (8 Used)	82 - Oil Baffle
8 - Bolt (4 Used)	33 - Suction Strainer	58 - Spring Washer (2 Used)	83 - Washer (2 Used)
9 - Pipe	34 - Oil Gauge	59 - Bolt (2 Used)	84 - Spring Washer (2 Used)
10 - Plug	35 - Pipe	60 - Plug (4 Used)	85 - Bolt (2 Used)
11 - O-Ring	36 - Stay	61 - Flange	86 - O-Ring
12 - Spring	37 - Bolt	62 - Plug	87 - Oil Seal
13 - Spring	38 - Clip	63 - Retaining Ring	88 - Retainer Seal
14 - Piston	39 - Nut	64 - Bolt (4 Used)	89 - Spring Washer (3 Used)
15 - Plug (12 Used)	40 - Elbow	65 - Bolt (4 Used)	90 - Bolt (3 Used)
16 - Plug (2 Used)	41 - Bearing	66 - Spring Washer (4 Used)	91 - Flange
17 - Bolt	42 - O-Ring	67 - Cover	92 - O-Ring
18 - Vehicle Speed Sensor	43 - Disc Hub	68 - O-Ring	93 - Shim
19 - O-Ring	44 - Retaining Ring	69 - Plug (2 Used)	94 - Shim (5 Used)
20 - Knock Pin (2 Used)	45 - Brake Disc	70 - O-Ring (3 Used)	95 - Washer
21 - O-Ring	46 - Disc Plate	71 - Plug	96 - Washer
22 - Plug	47 - End Plate	72 - Clutch Assembly	97 - Bolt
23 - Orifice	48 - Brake Housing	73 - Retaining Ring	
24 - Control Valve	49 - O-Ring	74 - Retaining Ring	
25 - Spring Washer (7 Used)	50 - Socket Bolt (2 Used)	75 - Retaining Ring	


## TRAVEL SYSTEM / Transmission

### Assembly of Clutch Assembly



**CAUTION:** The clutch assembly weight:  
Approx. 19 kg (42 lb)

1. Install seal ring (14) to the clutch (18) shaft.
2. Install seal ring (16) to piston (15) with the lip part facing the inside. Install piston (15), spring (9), and spring seat (8) to the clutch (18) shaft.
3. Compress spring (9) by using the special tool (ST 4175) and a press. Install retaining ring (7) to the groove of clutch (18) shaft. Release spring (9).



W4FJ-03-03-015

4. Install inner discs (12) (ZW100-G: 3 used, ZW120-G: 4 used) and outer discs (13) (ZW100-G: 3 used, ZW120-G: 4 used) to the clutch (18) drum alternately.


**IMPORTANT:** Install end plate (11) with its convex side facing the inside.

5. Install end plate (11) and retaining ring (10) to the clutch (18) drum.


**IMPORTANT:** Check the position and direction to install bearings (3, 5).

6. Install bearings (3, 5) and retaining ring (4) to gear (Hi) (6).

7. Install the gear (Hi) (6) assembly to the clutch (18) shaft.

 **NOTE:** Install the gear (Hi) (6) assembly while rotating clockwise.

8. Install retaining ring (2) and bearing (1) to the clutch (18) shaft.



W4FJ-03-03-016

9. Install the parts at the gear (Lo) (21) side in the same way as step 1 to step 4.

## TRAVEL SYSTEM / Axle

### REMOVAL AND INSTALLATION OF FRONT AXLE

#### Removal

1. Set the machine position for inspection and maintenance. (Refer to PREPARATION FOR INSPECTION AND MAINTENANCE on W1-6-1.)




**CAUTION: Machine weight :**  
**ZW100-G: 6950 kg (15400 lb)**  
**ZW120-G: 7980 kg (17600 lb)**

2. Set hydraulic jack on both sides of front frame (1). Raise front frame (1). Place stand (3) under front frame (1). Set wheel stopper (4) to the rear wheel. Start the engine. Lower the bucket end on the ground. Stop the engine. Remove the hydraulic jack.



**CAUTION: Tire (2) weight:**  
**ZW100-G: 145 kg (320 lb)**  
**ZW120-G: 180 kg (400 lb)**


3. Remove front tires (2) (2 used). (Refer to REMOVAL AND INSTALLATION OF TIRE on W3-6-1.)




W4FC-03-05-051

4. Remove propeller shaft (6) from front axle (5). (Refer to REMOVAL AND INSTALLATION OF PROPELLER SHAFT on W3-5-1.)

5. Disconnect hose (7) from front axle (5). Cap the open ends. Attach an identification tag onto the disconnected hoses for assembling.

 : 19 mm



M4FJ-07-026

## TRAVEL SYSTEM / Axle


### Disassembly of Rear Axle Assembly



**CAUTION:** Place the rear axle (4) assembly on stand (16) in order to stabilize the rear axle (4) assembly.

**IMPORTANT:** Do not remove bushing (2) unless necessary.

7. Remove packing (1) and bushing (2) from axle support (5).



W4GB-03-03-113



**CAUTION:** Axle support (3) weight:  
ZW100-G: 35 kg (77 lb)  
ZW120-G: 40 kg (88 lb)



1. Attach a nylon sling onto axle support (3). Hoist and hold axle support (3). Remove axle support (3) from rear axle (4).

**IMPORTANT:** Do not remove bushing (2) unless necessary.

2. Remove packings (1) (2 used) and bushing (2) from axle support (3).



**CAUTION:** Axle support (5) weight:  
ZW100-G: 45 kg (99 lb)  
ZW120-G: 55 kg (121 lb)

3. Attach a nylon sling onto axle support (5). Hoist and hold axle support (5).
4. Remove bolts (11) (6 used), and washers (10) (6 used) from thrust cap (9). Remove thrust cap (9), and thrust washer (6) from axle support (5).  
 : 19 mm
5. Remove bolts (8) (8 used) from thrust plate (7). Remove thrust plate (7) and thrust washer (6) from axle support (5).  
 : 19 mm
6. Remove axle support (5) from rear axle (4).

## TRAVEL SYSTEM / Axle

---

(Blank)

## TRAVEL SYSTEM / Axle


---

(Blank)

## TRAVEL SYSTEM / Tire

### REMOVAL AND INSTALLATION OF TIRE


#### Removal of Front Tire


1. Set the machine position for inspection and maintenance. (Refer to PREPARATION FOR INSPECTION AND MAINTENANCE on W1-6-1.)
2. Remove nuts (3) (6 used), spring washers (4) (6 used), and washers (5) (6 used) from front fender (2). Remove front fender (2) from front frame (1). Remove front fender (2) at the other side in the same way.
3. Loosen wheel bolts (6) (12 used) of tire (7) by about one turn.  
 : 36 mm

**CAUTION:** Machine weight:  
ZW100-G: 6950 kg (15400 lb)  
ZW120-G: 7980 kg (17600 lb)


4. Raise the machine until tire (7) slightly gets away from the road surface. Support the machine securely by using the blocks.

**CAUTION:** Tire (7) weight:  
ZW100-G: 145 kg (320 lb)  
ZW120-G: 180 kg (400 lb)


5. Attach a lifting tool onto tire (7). Hoist and hold tire (7).
6. Remove wheel bolts (6) (12 used) and washers (8) (12 used) from tire (7). Remove tire (7) from the front axle.  
 : 36 mm



W4FJ-04-01-001



W4FC-03-01-001






W4GB-03-01-003

## ATTACHMENT / Front Attachment

### REMOVAL AND INSTALLATION OF FRONT ATTACHMENT

#### Removal

1. Set the machine position for inspection and maintenance. (Refer to PREPARATION FOR INSPECTION AND MAINTENANCE on W1-6-1.)
2. Release the remaining pressure. (Refer to HYDRAULIC CIRCUIT PRESSURE RELEASE PROCEDURE on W1-5-1.)
3. Disconnect connectors of head light (2) and front combination lamp (3).  
Disconnect connectors at the opposite side in the same way.
4. Remove nuts (5) (2 used) and spring washers (6) (2 used) from bracket (4). Remove bracket (4) assembly from front frame (1).  
Remove Bracket (4) assembly at the opposite side in the same way.  
 : 19 mm
5. Remove nuts (8) (3 used), spring washers (9) (3 used) and washers (10) (3 used) from front fender (7). Remove front fender (7) from front frame (1).  
Remove front fender (7) at the opposite side in the same way.  
 : 19 mm




#### CAUTION: Bucket link (12) weight:

ZW100-G: 20 kg (44 lb)

ZW120-G: 30 kg (66 lb)

6. Attach a nylon sling onto bucket link (12). Hoist and hold bucket link (12).



## ATTACHMENT / Front Attachment




**CAUTION: Bucket (11) weight:**  
**ZW100-G: 550 kg (1212 lb)**  
**ZW120-G: 710 kg (1565 lb)**


20. Attach a nylon sling onto bucket (11). Hoist bucket (11). Fit bucket (11) to the mounting hole of lift arm (13).


**IMPORTANT: Adjust quantity of spacer (25) (thickness: 1.0 mm (0.04 in)) so that the clearance should be 1.5 mm (0.06 in) or less.**

21. Install spacers (25) (2 used) to the mounting hole of bucket (11).


22. Install bucket (11) to lift arm (13) with pin (15), washer (24), spring washer (23), and bolt (22). Move O-rings (17) (2 used) which were moved to the bucket (11) side to the bucket (11) and the lift arm (13) connection part. Install pin (15) at the opposite side in the same way.

 : 19 mm

 : 90 N·m (9 kgf·m, 66 lbf·ft)



M4FJ-07-024



W4FJ-04-01-003


## ATTACHMENT / Cylinder

### Removal of Bucket Cylinder

1. Set the machine position for inspection and maintenance. (Refer to PREPARATION FOR INSPECTION AND MAINTENANCE on W1-6-1.)
2. Release the remaining pressure. (Refer to HYDRAULIC CIRCUIT PRESSURE RELEASE PROCEDURE on W1-5-1.) Bleed air from the hydraulic oil tank. (Refer to BLEED AIR FROM HYDRAULIC OIL TANK on W1-4-1.)





**CAUTION: Bucket cylinder (3) weight:**  
**ZW100-G: 58 kg (132 lb)**  
**ZW120-G: 67 kg (154 lb)**

3. Attach a nylon sling onto bucket cylinder (3). Hoist and hold bucket cylinder (3).
4. Remove grease fitting (29) from pin (1). Cap the open ends.  
 : 10 mm



**CAUTION: Metal fragments may fly off when a hammer is used. Wear necessary protection, such as goggles, helmets, etc in order to prevent personal injury.**

5. Remove bolt (7), spring washer (6), and plate (5) from pin (1). Remove pin (1) and spacers (2) (2 used) from bell crank (4).  
 : 19 mm
6. Start the engine. Retract the piston rod bucket cylinder (3). Remove bucket cylinder (3) from bell crank (4). Stop the engine. In order not to extend the rod, pass a wire through the rod hole and secure to the cylinder tube.



W4FC-04-02-016

## ATTACHMENT / Cylinder

---

(Blank)

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL