

PART NO. WAFD90-EN-00

HITACHI

Reliable solutions

Workshop Manual

ZX65USB-5B Hydraulic Excavator

ZX65USB-5B HYDRAULIC EXCAVATOR WORKSHOP MANUAL

 **Hitachi Construction Machinery Co., Ltd.**

URL:<http://www.hitachi-c-m.com>

PRINTED IN JAPAN (K) 2015, 03

WAFD90-EN-00

Service Manual consists of the following separate Part No.

Technical Manual : Vol. No.TAFD90-EN

Workshop Manual : Vol. No.WAFD90-EN

Engine Manual : Vol. No.ETDEP-EN, EWDEP-EN

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

SAFETY

General Precautions for Cab

- Always keep inside the cab clean by observing instructions below, to prevent any personal accidents from occurring.
 - Before entering the cab, thoroughly remove all dirt and/or oil such as mud, grease, soil or stones that may mess up the cab from the soles of your work boots. If any controls such as a pedal is operated while with dirt and/or oil on the soles of the operator's work boots, the operator's foot may slip off the pedal, possibly resulting in a personal accident.
 - Do not mess up around the operator's seat with parts, tools, soil, stones, obstacles that may fold up or turn over, cans or lunch box. The levers or pedals become inoperable if obstacle jams in operation stroke of the travel levers/pedals, pilot control shut-off lever or control levers, which may result in serious injury or death.
 - Avoid storing transparent bottles in the cab. Do not attach any transparent type window decorations on the windowpanes as they may focus sunlight, possibly starting a fire.
 - Refrain from listening to the radio, or using music headphones or mobile telephones in the cab while operating the machine.
 - Keep all flammable objects and/or explosives away from the machine.
 - After using the ashtray, always cover it to extinguish the match and/or tobacco.
 - Do not leave cigarette lighters in the cab. If the temperature in the cab increases, the lighter may explode.
 - Use proper floor mat dedicated to the machine. If another floor mat is used, it may be displaced and contact with the travel pedals during operation, resulting in serious injury or death.

Use Handrails and Steps

- Falling is one of the major causes of personal injury.
 - When you get on and off the machine, always use the crawler instead of the step for safety. Also get on and off from the position of the crawler that can secure your feet space enough.
 - When you get on and off the machine, always face the machine.
 - Maintain a three-point contact with the steps and handrails.
 - Do not use any controls as handholds.
 - Never jump on or off the machine. Never mount or dismount a moving machine.
 - In case adhered slippery material such as oil, grease, or mud is present on steps, handrails, or platforms, thoroughly remove such material.



SA-439

SAFETY

Avoid Injury From Back-over and Swing Accidents


- If any person is present near the machine when backing or swinging the upperstructure, the machine may hit or run over that person, resulting in serious injury or death.

To avoid back-over and swing accidents:


- Always look around BEFORE YOU BACK UP AND SWING THE MACHINE. BE SURE THAT ALL BYSTANDERS ARE CLEAR.
- Keep the travel alarm in working condition (if equipped). ALWAYS BE ALERT FOR BYSTANDERS MOVING INTO THE WORK AREA. USE THE HORN OR OTHER SIGNAL TO WARN BYSTANDERS BEFORE MOVING MACHINE.
- USE A SIGNAL PERSON WHEN BACKING UP IF YOUR VIEW IS OBSTRUCTED. ALWAYS KEEP THE SIGNAL PERSON IN VIEW.

Use hand signals, which conform to your local regulations, when work conditions require a signal person.

- No machine motions shall be made unless signals are clearly understood by both signal person and operator.
- Learn the meanings of all flags, signs, and markings used on the job and confirm who has the responsibility for signaling.
- Keep windows, mirrors, and lights clean and in good condition.
- Dust, heavy rain, fog, etc., can reduce visibility. As visibility decreases, reduce speed and use proper lighting.
- Read and understand all operating instructions in the operator's manual.



SA-383



SA-384

SAFETY

Support Machine Properly


- Never attempt to work on the machine without securing the machine first.
 - Always lower the attachment to the ground before you work on the machine.
 - If you must work on a lifted machine or attachment, securely support the machine or attachment with stays or blocks strong enough to support the machine and/or attachment weight.




SA-527

Stay Clear of Moving Parts

- Contact with moving parts can cause serious injury or death due to amputation or entanglement.
 - To prevent accidents, care should be taken to ensure that hands, feet, clothing, jewelry and hair do not become entangled when working around rotating parts.



SA-026



SA-2294

SAFETY

Handle Chemical Products Safely


- Direct exposure to hazardous chemicals can cause serious injury. Potentially hazardous chemicals used with your machine include such items as lubricants, electrolyte, coolants, paints, and adhesives.
- A Material Safety Data Sheet (MSDS) provides specific details on chemical products: physical and health hazards, safety procedures, and emergency response techniques.
- Check the MSDS before you start any job using a hazardous chemical. Then follow the correct procedures and use recommended equipment.
- See your authorized dealer for MSDS.



SA-309

Dispose of Waste Properly

- Improperly disposing of waste can threaten the environment and ecology. Potentially harmful waste used with HITACHI equipment includes such items as oil, fuel, coolant, brake fluid, filters, and battery.
- When draining fluid, use a leakproof container with a capacity larger than the drained fluid volume to receive it.
- Do not pour waste onto the ground, down a drain, or into any water source.
- Inquire on the proper way to dispose of harmful waste such as oil, fuel, coolant, brake fluid, filters, and battery from your local environmental or recycling center.




SA-226

SECTION 1 GENERAL

Group 1 Precautions for Disassembling and Assembling


Precautions for Using Nylon Sling

1. Follow the precautions below to use nylon slings safely.
 - Attach protectors (soft material) on the corners of the load so that the nylon sling does not directly contact the corners. This will prevent the nylon sling from being damaged and the lifted load from slipping.
 - Lower the temperature of the lifted load to lower than 100 °C (212 °F). If unavoidably lifting a load with a temperature of 100 °C (212 °F) or more, reduce the load weight.
 - Do not lift acid or alkali chemicals.
 - Take care not to allow the sling to become wet. The load may slip.
 - When required to use more than one sling, use slings with the same width and length to keep the lifted load balanced.
 - When lifting a load using an eyehole, be sure to eliminate any gaps between the sling and load. (Refer to the right illustration.) Reduce the load weight so that it is less than 80 % of the sling breaking force.
 - Avoid using twisted, bound, connected, or hitched slings.
 - Do not place any object on twisted or bent slings. (Refer to the right illustration.)
 - When removing the slings from under the load, take care not to damage the nylon slings. Avoid contact with protrusions.
 - Avoid dragging slings on the ground, throwing slings, or pushing slings with a metal object.
 - When using with other types of slings (wire rope) or accessories (shackle), protect the joint so that the nylon sling is not damaged.
 - Store the nylon slings indoors so that they won't deteriorate with heat, sun light, or chemicals.




W102-04-02-016

a - Correct Eyehole Lifting Method



W105-04-01-008

b - Incorrect Eyehole Lifting Method



W162-01-01-009


c - Bent of Sling

SECTION 1 GENERAL

Group 2 Tightening

Quick Coupling

1. Coupling procedure
 - Push socket ring (1) into plug (3) by rotating it fully counterclockwise and then pulling it toward you.
 - Release socket ring (1). Check that socket ring (1) is returned by the spring force and the coupling is locked completely by ball (2). At this time, check if socket ring (1) is returned to the original position (to the rightmost direction).
2. Separating procedure
 - Remove the hose by rotating socket ring (1) fully counterclockwise and then pulling it. Because no check function is attached inside, be careful that oil flows out.
 - Cap the removed hoses using special plug.



CAUTION:

- **When disconnecting, do not damage joint surface.**
- **When disconnecting, clean the joint part and thoroughly wipe off the cleaning solution to prevent any foreign material from entering.**
- **Complete the joint disconnecting / connecting procedure. Check enough if oil leaks especially after installation.**
- **After installation, check if socket ring (1) is returned to the original position (to the rightmost direction).**

SECTION 1 GENERAL

Group 5 Releasing Pressure

Releasing Pressure in Hydraulic Circuit

Release any remaining pressure in the following procedures when removing and installing the front attachment.

1. Set the machine position for inspection and maintenance. (Refer to W1-6-1.)


⚠ CAUTION: Bleed air from the hydraulic oil tank. (Refer to W1-4-1.)

2. Tilt up the floor. (Refer to the operator's manual.)


⚠ CAUTION: Each attachment may move rapidly in case the overload relief valve is loosened rapidly. Check that the machine has set in the position for inspection and maintenance and loosen it slowly. Do not loosen it more than 3/4 turns as hydraulic oil may spout.

IMPORTANT: Do not turn lock nut (8) and adjusting screw (9). If turning, the setting changes.

3. Slowly loosen body (7) of the overload relief valve in which any remaining pressure will be released.


 : 24 mm

 : 70 to 80 N·m (7 to 8 kgf·m, 52 to 59 lbf·ft)



T1N0-03-04-003

- | | |
|--|---|
| 1- Overload Relief Valve (Boom Roll-Out) | 4- Overload Relief Valve (Bucket Roll-In) |
| 2- Overload Relief Valve (Arm Roll-Out) | 5- Overload Relief Valve (Arm Roll-In) |
| 3- Overload Relief Valve (Bucket Roll-Out) | 6- Overload Relief Valve (Boom Raise) |




TAEA-03-04-013

- | | |
|-------------|--------------------|
| 7- Body | 9- Adjusting Screw |
| 8- Lock Nut | |

SECTION 2 MAINTENANCE STANDARD

Group 1 Upperstructure

Swing Motor



WADB-03-07-002

1- Rotor

2- Plunger (9 Used)

SECTION 2 MAINTENANCE STANDARD

Group 2 Undercarriage

Track


Rubber Crawler Crack

1. Outside of Rubber Crawler

If there is a crack on lug base (1) with depth of 3 mm (0.12 in) or more, repair the track.

If there is a crack between lugs (2) with depth of 3 mm (0.12 in) or more, repair the track.


If there is a crack on lugs (3) or between lugs (2) and it reaches steel code (5) or steel core (4) with length of 30 mm (1.18 in) or more, immediately repair the track.



W190-03-07-001

2. Inside of Rubber Crawler (Roller (6) Side)

If there is a crack that reaches steel code (5) or steel core (4), immediately repair the track.




W190-03-07-002


Lug Wear

1. If height (A) of lug (8) is less than 5 mm (0.2 in), replace rubber crawler (7) as an assembly.

2. If any part of steel code (5) appeared on the track, replace the worn rubber crawler as an assembly.



W190-03-07-003



W190-03-07-004

SECTION 3

UPPERSTRUCTURE

CONTENTS

Group 1 Cab

Removal and Installation of Cab	W3-1-1-1
Dimensions of Cab Glass.....	W3-1-2-1

Group 2 Counterweight

Removal and Installation of Counterweight.....	W3-2-1-1
--	----------

Group 5 Pump Device

Removal and Installation of Pump Device.....	W3-5-1-1
Disassembly of Pump Device	W3-5-2-1
Assembly of Pump Device.....	W3-5-2-5
Disassembly of Regulator	W3-5-3-1
Assembly of Regulator	W3-5-3-3

Group 6 Control Valve

Removal and Installation of Control Valve.....	W3-6-1-1
Disassembly and Assembly of Control Valve	W3-6-2-1
Disassembly of Body.....	W3-6-3-1
Assembly of Body	W3-6-3-7
Disassembly of Unload Section	W3-6-4-1
Assembly of Unload Section.....	W3-6-4-3
Disassembly of Boom Anti-Drift Valve.....	W3-6-5-1
Assembly of Boom Anti-Drift Valve	W3-6-5-3
Disassembly of Spool	W3-6-6-1
Assembly of Spool.....	W3-6-6-3
Disassembly of Shuttle Valve and Pressure Compensator	W3-6-7-1
Assembly of Shuttle Valve and Pressure Compensator	W3-6-7-3

Group 7 Swing Device

Removal and Installation of Swing Device	W3-7-1-1
Disassembly of Swing Device.....	W3-7-2-1
Assembly of Swing Device	W3-7-2-3
Disassembly of Swing Motor	W3-7-3-1
Assembly of Swing Motor.....	W3-7-3-4

Group 8 Pilot Valve

Removal and Installation of Pilot Valve (Left)	W3-8-1-1
Removal and Installation of Pilot Valve (Right) ..	W3-8-2-1
Removal and Installation of Travel Pilot Valve	W3-8-3-1
Removal and Installation of Blade Pilot Valve.....	W3-8-4-1
Removal and Installation of Boom Swing Pilot Valve.....	W3-8-5-1
Disassembly of Pilot Valves (Right and Left)	W3-8-6-1
Assembly of Pilot Valves (Right and Left)	W3-8-6-4
Disassembly of Travel Pilot Valve.....	W3-8-7-1

Assembly of Travel Pilot Valve	W3-8-7-5
Disassembly of Pilot Valves for Boom Swing, Blade, Auxiliary (Optional).....	W3-8-8-1
Assembly of Pilot Valves for Boom Swing, Blade, Auxiliary (Optional)	W3-8-8-4
Disassembly of Blade Pilot Valve (Optional).....	W3-8-9-1
Assembly of Blade Pilot Valve (Optional)	W3-8-9-4

Group 9 Solenoid Valve

Removal and Installation of 2-Spool Solenoid Valve.....	W3-9-1-1
Disassembly of 2-Spool Solenoid Valve.....	W3-9-2-1
Assembly of 2-Spool Solenoid Valve.....	W3-9-2-3
Removal and Installation of LS Cut Solenoid Valve.....	W3-9-3-1
Disassembly of LS Cut Solenoid Valve.....	W3-9-4-1
Assembly of LS Cut Solenoid Valve	W3-9-4-3

Group 10 Revolution Sensing Valve

Removal and Installation of Revolution Sensing Valve.....	W3-10-1-1
Disassembly of Revolution Sensing Valve.....	W3-10-2-1
Assembly of Revolution Sensing Valve	W3-10-2-3

Group 11 Auxiliary Flow Rate Selector Valve

Removal and Installation of Auxiliary Flow Rate Selector Valve (OP)	W3-11-1-1
Disassembly of Auxiliary Flow Rate Selector Valve (OP)	W3-11-2-1
Assembly of Auxiliary Flow Rate Selector Valve (OP)	W3-11-2-3


Group 12 Muffler Filter

Removal and Installation of Muffler Filter.....	W3-12-1-1
Disassembly of Muffler Filter	W3-12-2-1
Assembly of Muffler Filter	W3-12-2-3


SECTION 3 UPPERSTRUCTURE

Group 2 Counterweight

Removal and Installation of Counterweight




WAFA-03-02-001



WAFA-03-02-002


Removal

1. Set the machine position for inspection and maintenance. (Refer to W1-6-1.)
2. Tilt the cab assembly to the front side. (Refer to the operator's manual.)
3. Remove bolts, washers (4) (3 used) and bolts, washers (6) (2 used). Remove cover (5).


 : 17 mm

4. Open cover (3).

5. Remove bolt, washer (1) and bolts, washers (7) (5 used). Remove cover (2).

 : 17 mm


6. Remove bolts (8) (2 used) and washers (9) (2 used).

 : 24 mm

SECTION 3 UPPERSTRUCTURE

Group 5 Pump Device

Disassembly of Pump Device




W1N0-02-03-051

SECTION 3 UPPERSTRUCTURE

Group 5 Pump Device

Disassembly of Regulator




W1N0-02-03-061

- | | | | |
|-------------------------|-------------------|--------------------------|-------------------------|
| 1- Spool | 15- Orifice | 29- Socket Bolt (2 Used) | 43- Adjusting Screw Kit |
| 2- Sleeve | 16- Valve Body | 30- Nut | 44- O-Ring |
| 3- Connector | 17- Lever | 31- Adjusting Screw | 45- Spring Seat |
| 4- Spring | 18- Retainer | 32- Nut | 46- Spring |
| 5- Needle Roller | 19- Spring Washer | 33- Adjusting Screw | 47- Spool |
| 6- Retainer | 20- Socket Bolt | 34- Cover | 48- Sleeve |
| 7- O-Ring | 21- O-Ring | 35- O-Ring | 49- O-Ring (2 Used) |
| 8- Backup Ring (2 Used) | 22- Plug | 36- Spring Guide | 50- O-Ring (2 Used) |
| 9- O-Ring (2 Used) | 23- Plug | 37- O-Ring | 51- Backup Ring |
| 10- Plug | 24- O-Ring | 38- Spring Guide | 52- O-Ring |
| 11- Retaining Ring | 25- Stopper | 39- Spring | 53- O-Ring |
| 12- Plug (2 Used) | 26- Spring | 40- Spring | 54- Backup Ring |
| 13- O-Ring (2 Used) | 27- Steel Ball | 41- Spring Seat | 55- Spring |
| 14- Orifice | 28- Valve Seat | 42- O-Ring | 56- Spring Seat |

SECTION 3 UPPERSTRUCTURE

Group 6 Control Valve

Disassembly and Assembly of Control Valve



WAFA-03-06-005

- | | | | |
|---------------------------|-----------------------|----------------------|----------------------|
| A- Unload Section | G- Boom Swing Section | M- Auxiliary Section | 96- Tie Rod (4 Used) |
| B- Piping Port Section | H- Boom 2 Section | 22- O-Ring | 97- Block |
| C- Swing Section | I- Boom 1 Section | 60- Plug | 104- Plug |
| D- Blade Section | J- Arm 1 Section | 67- O-Ring | |
| E- Travel (Left) Section | K- Arm 2 Section | 94- Nut (8 Used) | |
| F- Travel (Right) Section | L- Bucket Section | 95- Washer (8 Used) | |

SECTION 3 UPPERSTRUCTURE

Group 6 Control Valve


A- Unload Section	E- Travel (Left) Section	I- Boom 1 Section	M- Auxiliary Section
B- Piping Port Section	F- Travel (Right) Section	J- Arm 1 Section	
C- Swing Section	G- Boom Swing Section	K- Arm 2 Section	
D- Blade Section	H- Boom 2 Section	L- Bucket Section	
1a- Body (Unload)	1i- Body (Boom 1)	24- O-Ring (63 Used)	95- Washer (8 Used)
1b- Body (Piping Port)	1j- Body (Arm 1)	36- O-Ring (2 Used)	96- Tie Rod (4 Used)
1c- Body (Swing)	1k- Body (Arm 2)	64- Spring (9 Used)	97- Block
1d- Body (Blade)	1l- Body (Bucket)	65- Check Valve (9 Used)	
1e- Body (Travel (Left))	1m- Body (Auxiliary)	70- Plug (3 Used)	
1f- Body (Travel (Right))	20- O-Ring (25 Used)	73- Make-Up Valve	
1g- Body (Boom Swing)	21- O-Ring	93- Overload Relief Valve (6 Used)	
1h- Body (Boom 2)	22- O-Ring (25 Used)	94- Nut (8 Used)	

SECTION 3 UPPERSTRUCTURE

Group 6 Control Valve

Disassembly of Boom Anti-Drift Valve

 NOTE: The illustration shows boom 1.



WAEB-03-06-007

- 1i- Body (Boom 1)
- 20- O-Ring
- 45- O-Ring (2 Used)
- 61- Orifice
- 74- Socket Bolt (2 Used)

- 75- Socket Bolt (2 Used)
- 81- Cover
- 83- Piston
- 84- Sleeve
- 85- Backup Ring

- 86- O-Ring
- 87- Steel Ball
- 88- Spring Guide
- 89- Spring
- 90- Orifice


- 91- Spring
- 92- Poppet

SECTION 3 UPPERSTRUCTURE

Group 6 Control Valve

Assembly of Shuttle Valve and Pressure Compensator

 NOTE: The illustration shows the swing section.



W1NG-02-04-010

1c- Body (Swing)
24- O-Ring
46- Plug
47- O-Ring

48- Seat
49- Backup Ring
51- Steel Ball
60- Plug


62- Piston
63- Spool
66- Spring
67- O-Ring (2 Used)

68- Plug

SECTION 3 UPPERSTRUCTURE

Group 7 Swing Device

Disassembly of Swing Motor



WADB-03-07-003

- | | | | |
|-------------------|--------------------------|---------------------------|---------------------|
| 1- Casing | 11- Holder | 21- Cover | 40- Spring (2 Used) |
| 2- Ball Bearing | 12- Retainer | 22- Ball Bearing | 41- Plug (2 Used) |
| 3- Shaft | 13- Plunger (9 Used) | 23- Pin | 42- O-Ring (2 Used) |
| 4- Swash Plate | 14- Disc Plate | 24- Valve Plate | 43- Plug |
| 5- Rotor | 15- Brake Piston | 25- Pin (2 Used) | 44- O-Ring |
| 6- Collar | 16- O-Ring | 26- O-Ring (2 Used) | 45- Plug |
| 7- Spring | 17- O-Ring | 27- Socket Bolt (5 Used) | 46- O-Ring |
| 8- Washer | 18- Spring Seat (2 Used) | 28- Orifice | 47- Retaining Ring |
| 9- Retaining Ring | 19- Disc Spring (2 Used) | 38- Relief Valve (2 Used) | |
| 10- Pin (3 Used) | 20- O-Ring | 39- Check Valve (2 Used) | |

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below




- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.


CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

SECTION 3 UPPERSTRUCTURE

Group 8 Pilot Valve




WADB-03-08-015




WADB-03-08-017

6. Disconnect hoses (9) (6 used) from pilot valve (2).

 : 17 mm

7. Put the matching marks on bracket (5) and pilot valve (2). Remove spring pin (8), bolt (1), washer (7), and bolts, washers (6) (3 used) from bracket (5). Remove pilot valve (2) from bracket (5).

 : 13 mm

8. Remove clip band (3) and glass wool (4) from pilot valve (2).

9. Remove the adapters with pilot valve (2) attached if necessary.

SECTION 3 UPPERSTRUCTURE

Group 8 Pilot Valve

Removal and Installation of Boom Swing Pilot Valve

IMPORTANT: The hose and pipe contain hydraulic oil. When removing the hose and pipe, receive oils with a container in order to avoid spilling oils.


IMPORTANT: Cap the open ends in case the hoses and pipes have been disconnected. In addition, attach an identification tag onto the connectors, hoses, and pipes for assembling. Connect the hoses and install the clips in case the clips which secure the hoses have been removed.

1. Set the machine position for inspection and maintenance. (Refer to W1-6-1.)


CAUTION: Bleed air from the hydraulic oil tank. (Refer to W1-4-1.)

Removal


2. Remove bolts, washers (2) (2 used). Remove pedal (3) from bracket (6).

 : 13 mm


3. Remove socket bolts (4) (2 used) and spring washers (5) (2 used). Remove bracket (6) from pilot valve (1).

 : 6 mm


4. Tilt up the floor. (Refer to Operator's Manual.)



W1M9-02-06-008



W1M9-02-06-009




M1M0-07-032

SECTION 3 UPPERSTRUCTURE

Group 8 Pilot Valve

Disassembly of Travel Pilot Valve




WAFA-03-08-001

- | | | | |
|---------------------------|-----------------------------|----------------------------|--------------------------|
| 1- Bolt, Washer (2 Used) | 11- Bracket (2 Used) | 21- Plug (2 Used) | 31- Rubber Seat (2 Used) |
| 2- Cover | 12- Spring Pin (2 Used) | 22- O-Ring (2 Used) | 32- Damper (2 Used) |
| 3- Spring Pin (2 Used) | 13- Spring Pin (2 Used) | 23- Casing | 33- O-Ring (2 Used) |
| 4- Spring Pin (2 Used) | 14- O-Ring (4 Used) | 24- Spool (4 Used) | 34- O-Ring (2 Used) |
| 5- Cam (2 Used) | 15- Bushing (4 Used) | 25- Spring (4 Used) | 35- Pin (2 Used) |
| 6- Bushing (4 Used) | 16- Pusher (4 Used) | 26- Spacer (4 Used) | 36- Steel Ball (3 Used) |
| 7- Holder | 17- Spring Guide (4 Used) | 27- Shim (12 Used) | 37- Sleeve (3 Used) |
| 8- Spring Washer (4 Used) | 18- Balance Spring (4 Used) | 28- Oil Seal (4 Used) | |
| 9- Socket Bolt (4 Used) | 19- O-Ring (5 Used) | 29- Spring Washer (2 Used) | |
| 10- Spring Pin (2 Used) | 20- Plug (5 Used) | 30- Socket Bolt (2 Used) | |

SECTION 3 UPPERSTRUCTURE

Group 8 Pilot Valve

Disassembly of Pilot Valves for Boom Swing, Blade, Auxiliary (Optional)



WADB-03-08-001

- 00- Spacer (2 Used)
- 01- Shim (6 Used)
- 02- Balance Spring (2 Used)
- 03- Spring Guide (2 Used)
- 04A- Bushing (2 Used)

- 04B- Oil Seal (2 Used)
- 04C- O-Ring (2 Used)
- 04D- Pusher (2 Used)
- 05- Cam
- 06- Holder

- 07- Bushing (2 Used)
- 08- Pin
- 09- Set Screw
- 10- Socket Bolt (2 Used)
- 11- Boot

- 15A- Casing
- 15B- Spool (2 Used)
- 16- Return Spring (2 Used)

SECTION 3 UPPERSTRUCTURE

Group 8 Pilot Valve

Assembly of Pilot Valve

IMPORTANT: Before assembling, apply hydraulic oil onto parts in order to prevent them from seizing.

IMPORTANT: The pilot valve is the susceptible hydraulic component to contamination. Keep the parts clean when assembling.

IMPORTANT: Install shim (01) as the same quantity before disassembling.

1. Install spacer (00), shims (01) (several), and balance spring (02) to spool (15B) in sequence.

IMPORTANT: Install spring guide (03) with the stepped part down.

2. Compress balance spring (02) by hand. Install spring guide (03) to spool (15B).

IMPORTANT: When installing the parts to holder (06) and casing (15A), apply hydraulic oil.

3. Secure casing (15A) in a vise. Install return spring (16) to casing (15A).


IMPORTANT: Install the spool (15B) assembly into the original port before disassembling.

4. Install the spool (15B) assembly to casing (15A) by rotating.

IMPORTANT: Do not deform and damage the sliding surface when installing oil seal (04B).

IMPORTANT: Check the direction to install oil seal (04B).

5. Apply grease onto oil seal (04B). Install oil seal (04B) to bushing (04A).



WDAD-03-11-003

6. Apply grease onto the bushing (04A) sliding surface and O-ring (04C). Install O-ring (04C) and pusher (04D) to bushing (04A).


7. Install the pusher (04D) assembly to casing (15A).

8. Install other spool (15B) and pusher (04D) in the same way as step 1 to step 7.

SECTION 3 UPPERSTRUCTURE

Group 9 Solenoid Valve

Disassembly of LS Cut Solenoid Valve



W1NG-02-07-003

1- Piston
2- Pin
3- Plate
4- Casing

5- Plate
6- Wave Washer
7- Lock Nut
8- Solenoid


9- O-Ring (2 Used)
10- O-Ring
11- Body
12- Spool

13- Spring


SECTION 3 UPPERSTRUCTURE

Group 11 Auxiliary Flow Rate Selector Valve

Removal and Installation of Auxiliary Flow Rate Selector Valve (OP)



M1M0-07-032



WAEA-03-11-001

IMPORTANT: The hose and pipe contain hydraulic oil. When removing the hose and pipe, receive oils with a container in order to avoid spilling oils.

IMPORTANT: Cap the open ends in case the hoses and pipes have been disconnected. In addition, attach an identification tag onto the connectors, hoses, and pipes for assembling. Connect the hoses and install the clips in case the clips which secure the hoses have been removed.


Removal

1. Set the machine position for inspection and maintenance. (Refer to W1-6-1.)


CAUTION: Bleed air from the hydraulic oil tank. (Refer to W1-4-1.)

2. Tilt the cab (1) assembly to the front side. (Refer to the operator's manual.)
3. Disconnect connector (2).


4. Disconnect hoses (4) (3 used).

 : 19 mm

5. Disconnect hose (3).

 : 17 mm


6. Remove socket bolts (6) (2 used) and washers (7) (2 used). Remove auxiliary flow rate selector valve (5).

 : 6 mm


7. Remove the adapters with auxiliary flow rate selector valve (5) attached if necessary.

SECTION 3 UPPERSTRUCTURE

Group 12 Muffler Filter



WDEP-03-11-007




WAFD90-03-12-003

a- Lifting Bracket

Installation

CAUTION: The muffler filter (2) assembly weight: 23 kg (51 lb)

1. Loosen bolts (4) (2 used).


 : 14 mm

2. Install shackles (2 used) to lifting brackets (a) (2 places) of muffler filter (2). Attach nylon slings onto the shackles (2 used). Hoist the muffler filter (2) assembly.

IMPORTANT: Check the direction to install the muffler filter (2) assembly.

IMPORTANT: Take care not to break pipe (3).

3. Install the muffler filter (2) assembly while fitting to pipe (3).
4. Temporarily tighten bolts, washers (5, 6) (2 used for each).

 : 14 mm

SECTION 4

UNDERCARRIAGE

CONTENTS

Group 1 Swing Bearing

Removal and Installation of Swing BearingW4-1-1-1

Group 2 Travel Device

Removal and Installation of Travel DeviceW4-2-1-1

Disassembly of Travel Device.....W4-2-2-1

Assembly of Travel DeviceW4-2-2-6

Disassembly of Brake ValveW4-2-3-1

Assembly of Brake ValveW4-2-3-3

Precautions for Using Floating Seal.....W4-2-4-1

Group 3 Center Joint

Removal and Installation of Center JointW4-3-1-1

Disassembly of Center Joint.....W4-3-2-1

Assembly of Center JointW4-3-2-3

Group 4 Track Adjuster

Removal and Installation of Track AdjusterW4-4-1-1

Disassembly of Track Adjuster.....W4-4-2-1

Assembly of Track AdjusterW4-4-2-6

Group 5 Front Idler

Removal and Installation of Front Idler.....W4-5-1-1

Disassembly of Front IdlerW4-5-2-1

Assembly of Front Idler.....W4-5-2-4

Group 6 Upper and Lower Rollers

Removal and Installation of Upper RollerW4-6-1-1

Removal and Installation of Lower RollerW4-6-2-1

Group 7 Track

Removal and Installation of Rubber CrawlerW4-7-1-1

Removal and Installation of Steel CrawlerW4-7-2-1

Group 8 Blade Cylinder

Removal and Installation of Blade CylinderW4-8-1-1

Disassembly of Blade CylinderW4-8-2-1

Assembly of Blade Cylinder.....W4-8-2-4

SECTION 4 UNDERCARRIAGE

Group 2 Travel Device

⚠ CAUTION: Metal fragments may fly off when a hammer is used. Wear necessary protection, such as goggles, helmets, etc in order to prevent personal injury.


24. Remove bearing (24) from body (27) by using a bar and a hammer.

IMPORTANT: Handle floating seal (26) with care. (Refer to W4-2-4.)

25. Remove floating seal (26) from body (27) and ring gear (20) by using a screwdriver.
26. Remove the shaft (30) assembly from body (27) by using a bar and a plastic hammer.

IMPORTANT: Oil seal (28) cannot be reused.

27. Remove oil seal (28) from the shaft (30) hole of body (27) by using a screwdriver.
28. Secure the inner race part of ball bearing (29) which is remained in shaft (30) in a vise. Remove ball bearing (29) from shaft (30) by using a bar and a plastic hammer.



W172-03-02-003

a- Bar

SECTION 4 UNDERCARRIAGE

Group 2 Travel Device

Precautions for Using Floating Seal

1. In general, replace the floating seal with a new one after disassembling.

If the floating seal is required to be reused, follow these procedures:


- Keep seal rings together as a matched set with seal ring (1) surfaces together. Apply oil onto sliding surface (e) of seal ring (1).
- Check sliding surface (e) of seal ring (1) for scuffing, scoring, corrosion, deformation, or uneven wear. Check the step part of seal ring (1).
- Check O-ring (2) for tears, breaks, deformation, or hardening.

2. If incorrectly assembled, oil leakage or damage will occur. Be sure to do the following to prevent trouble.



- Clean the floating seal and seal mounting bores with cleaning solvent.

Use a wire brush to remove mud, rust, or dirt from seal mounting bores. After cleaning, thoroughly dry parts with compressed air.

- Clean seal ring (1) and O-ring (2) mounting bores. Check the bore surface for scuffing or scoring by touching the surface with finger.
- After installing the floating seal, check that O-ring (2) is not twisted, and that it is installed correctly on seal ring (1).
- After installing the floating seal, check that O-ring (2) and seal ring sliding surface (e) is parallel with seal mating surface (f) by measuring the distances (e) and (f) at point (A) and (B), as illustrated. If these distances differ, correct O-ring (2) seating.




W178-02-11-001



W178-02-11-002

- a - Correct
- b - Incorrect
- c - Twist of O-Ring
- d - Bend of O-Ring



A=B

A≠B

W178-02-11-003


- a - Correct
- b - Incorrect
- e - Sliding Surface
- f - Seal Mating Surface

SECTION 4 UNDERCARRIAGE

Group 3 Center Joint

IMPORTANT: Install ring (4) with the chamfered surface facing to the flange (3) side.


6. Install ring (4) and retaining ring (12) to body (2).




WADB-04-03-006

a - Chamfered Surface

7. Install O-ring (8) to body (2).
8. Install flange (3) to body (2) with bolts (14) (4 used) and spring washers (15) (4 used).

 : 17 mm

 : 55 N·m (5.5 kgf·m, 41 lbf·ft)


SECTION 4 UNDERCARRIAGE

Group 4 Track Adjuster

Assembly of Track Adjuster

IMPORTANT: Before assembling, apply hydraulic oil onto parts in order to prevent them from seizing.

1. Apply grease onto the inner surfaces of seal (06) and dust seal (07). Install seal (06) and dust seal (07) to cylinder (00).
2. Apply grease onto the inner surface of cylinder (00). Fill grease in portion A at the bottom of cylinder (00).




WADB-04-04-003

3. Install piston rod (05) to the cylinder (00) assembly. Bleed air from cylinder (00).

4. Install spring (01) to cylinder (00).
5. Install eyebolt (M16, Pitch 1.5 mm) to the valve (08) hole of cylinder (00). Attach the nylon sling onto the eyebolt. Hoist the spring (01) assembly. Place the spring (01) assembly on the special tool (ST 4943).
6. Remove the eyebolt from cylinder (00).
7. Install washer (10) to spring (01).

CAUTION: Special tool (ST 4140) weight: 36 kg (80 lb)

8. Attach the nylon slings onto the eyebolts (2 used) of the special tool (ST 4140). Hoist the special tool (ST 4140). Install the special tool (ST 4140) to the special tool (ST 4943).



WDAD-04-04-004

SECTION 4 UNDERCARRIAGE

Group 6 Upper and Lower Rollers

Removal and Installation of Upper Roller

IMPORTANT: The upper roller cannot be disassembled. Replace it as an assembly.


Removal

CAUTION: The pressure inside the track adjuster cylinder is high. As valve (1) may fly out and the high-pressure grease may spout out from the grease outlet (a), do not loosen valve (1) quickly and/or excessively. Keep body parts and face away from valve (1) and loosen valve (1) carefully. Do not loosen grease fitting (2).

IMPORTANT: Loosening valve (1) by 1 to 1.5 turns is enough. Do not loosen it over those turns.


IMPORTANT: When gravel or mud is packed between the sprockets and the track links, remove them before loosening.


1. Set the machine position for inspection and maintenance. (Refer to W1-6-1.)
2. Loosen valve (1) in the track adjuster. Drain grease and loosen the track tension.


 : 19 mm

IMPORTANT: Use nonskid cloth (c) between track frame (3) and oil jack (d) in order not to slip.


3. Raise track (6) by using oil jack (d) until enough clearance is observed between upper roller (5) and track (6). Place wooden blocks (b) between track (6) and track frame (3).
4. Remove bolt (7), nut (9), and spring washer (8). Remove upper roller (5).

 : 24 mm

 **NOTE:** LOCTITE #262 has been applied on bolt (7).





W105-03-07-002




a- Grease Outlet

W1NC-03-06-001



W507-03-06-001



W507-03-06-003

b- Wooden Block
c- Nonskid Cloth

d- Oil Jack

SECTION 4 UNDERCARRIAGE

Group 7 Track

Removal and Installation of Rubber Crawler

Removal

CAUTION: Rubber crawler weight: 245 kg (545 lb)

CAUTION: Securely support the raised machine by using the blocks.


1. Raise the machine off the ground by using the front attachment.

CAUTION: The pressure inside cylinder of the track adjuster is high. As valve (1) may fly out and the high-pressure grease may spout out from the grease outlet (c), do not loosen valve (1) quickly and/or excessively. Keep body parts and face away from valve (1) and loosen valve (1) carefully. Do not loosen grease fitting (2).

IMPORTANT: Loosening valve (1) 1 to 1.5 turns is enough. Do not loosen valve (1) over those turns.


IMPORTANT: When gravel or mud is packed between sprockets and track links, remove them before loosening.

2. Loosen valve (1) in the track adjuster slowly and drain grease.

 : 19 mm


NOTE: If rotating the track in forward and reverse direction with valve (1) loosened, the track can be removed and installed easily.

3. Insert steel pipe (3) into the track. Rotate the sprocket in reverse direction. After the front idler is floated by steel pipe (3), slide and remove the track transversely.




b- 90 to 110°

M195-07-003



c- Grease Outlet

W1NC-03-06-001



a- Rotating Direction

M503-07-062

SECTION 4 UNDERCARRIAGE

Group 8 Blade Cylinder


Installation


CAUTION: Blade cylinder (1) weight: 46 kg (105 lb)

1. Apply grease onto the bushing inside and the lip part of the dust seal for blade cylinder (1) (both bottom and rod sides).
2. Apply grease onto pin (5). Attach nylon slings onto blade cylinder (1). Hoist blade cylinder (1). Fit the pin (5) holes of blade cylinder (1) and blade (9).


CAUTION: Metal fragments may fly off when a hammer is used. Wear necessary protection, such as goggles, helmets, etc in order to prevent personal injury.


3. Install blade cylinder (1) to blade (9) with pin (5) by using a hammer. Apply LOCTITE #262 onto bolt (7). Secure pin (5) with lock (6), bolts (7) (2 used), and washers (8) (2 used).


 : 19 mm

 : 110 N·m (11 kgf·m, 81 lbf·ft)

4. Connect hoses (4) (2 used) to blade cylinder (1).

 : 22 mm

 : 40 N·m (4 kgf·m, 29.5 lbf·ft)



WAFA-04-08-003

MEMO

SECTION 5 FRONT ATTACHMENT

Group 2 Cylinder

Installation

CAUTION: Boom cylinder (4) weight: 78 kg (175 lb)

IMPORTANT: Insert at least one shim to both left and right sides of all pins respectively. When the shims should be used in order to adjust the clearance, the shims should be inserted at both sides respectively. (Clearance: 0.5 mm or less)


1. Apply grease onto the lip part of the dust seal for boom cylinder (4), the boss side, and the bushing inside (both bottom and rod sides).
2. Apply grease onto pin (1). Attach the nylon sling onto boom cylinder (4). Hoist boom cylinder (4). Fit the pin (1) holes of boom cylinder (4) and swing post (3). Insert the shims to both sides of the cylinder tube boss.


CAUTION: Metal fragments may fly off when a hammer is used. Wear necessary protection, such as goggles, helmets, etc in order to prevent personal injury.

3. Fit the bolt (2) holes of swing post (3) and pin (1). Install pin (1) by using a hammer.


IMPORTANT: Install nut (5) so that the clearance between nut (5) and the swing post (3) boss should be 3 to 5 mm.


4. Apply LOCTITE #262 onto bolt (2). Install bolt (2) and nuts (5) (2 used).


 : 24 mm

 : 270 N·m (27 kgf·m, 200 lbf·ft)


5. Connect hoses (6) (2 used) to boom cylinder (4).

 : 27 mm

 : 80 N·m (8 kgf·m, 59 lbf·ft)



WAEB-05-01-002



WAFA-05-01-001

SECTION 5 FRONT ATTACHMENT

Group 2 Cylinder

Removal and Installation of Boom Swing Cylinder

IMPORTANT: The hose and pipe contain hydraulic oil. When removing the hose and pipe, receive oils with a container in order to avoid spilling oils.


IMPORTANT: Cap the open ends in case the hoses and pipes have been disconnected. In addition, attach an identification tag onto the connectors, hoses, and pipes for assembling. Connect the hoses and install the clips in case the clips which secure the hoses have been removed.


Removal


- The procedure starts on the premise that the front attachment has swung to the left.
1. Park the machine on a solid, level surface. Fully retract the bucket and arm cylinders and lower the arm top onto the ground.

CAUTION: Boom swing cylinder (4) weight: 45 kg (100 lb)


2. Set wooden blocks between boom swing cylinder (4) and main frame (5). Support boom swing cylinder (4). Remove nuts (3) (2 used). Remove stopper pin (1) from pin (2). Remove pin (2) from the swing post.

 : 22 mm

 **NOTE:** LOCTITE #262 has been applied on stopper pin (1).

 **NOTE:** When removing stopper pin (1), pin (2) may come off. Put the matching marks on the boss of swing post and pin (2) for assembling.

3. Start the engine. Retract the cylinder rod to the stroke end. In order not to extend the cylinder rod, pass wires through the boss of cylinder rod and secure it.





WADB-05-02-007

SECTION 5 FRONT ATTACHMENT

Group 2 Cylinder

11. Install steel ball (21) and set screw (22) to piston (15). Crimp set screw (22) by using a punch (2 places).


 : 6 mm


 : 20 ± 2 N·m (2 ± 0.2 kgf·m, 15 ± 1.5 lbf·ft)

IMPORTANT: When installing the cylinder rod (2) assembly, do not drop dust ring (16) and wear ring (18) from piston (15).

12. Secure cylinder tube (1) in a vise horizontally. Install the cylinder rod (2) assembly to cylinder tube (1).
13. Tighten cylinder head (3) to cylinder tube (1) by using hook wrench (a). Bend the lock washer in order not to loosen.

Diameter of cylinder head (3): 129 mm

 : 950 ± 95 N·m (95 ± 9.5 kgf·m, 700 ± 70 lbf·ft)



a- Hook Wrench


W506-04-02-019

SECTION 5 FRONT ATTACHMENT

Group 2 Cylinder

Disassembly of Bucket, Boom Swing Cylinders

Bucket Cylinder



WAFA-05-02-005

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL