

WSM

WORKSHOP MANUAL

GR1600EC2

Kubota

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Model		RCK42GREC2	
Mower	Cutting width	1067 mm (42.0 in.)	
	Cutting height	25 to 102 mm (1 to 4 in.)	
	Adjustment of cutting height	Dual gauge	
	Mounting method	Quick joint, Parallel linkage	
	Weight (Approx.)	75 kg (165 lbs)	
	Dimensions	Total length	965 mm (38.0 in.)
		Total width	1110 mm (43.7 in.)
		Total height	295 mm (11.6 in.)
	Discharge direction	Rear	
Gear box oil	0.33 L (0.35 U.S.qts, 0.29 Imp.qts)		

W1030594


Model		GCK370GREC2
Grass catcher	Container capacity	370 L (97.7 U.S.gals, 81.4 Imp.gals)
	Weight (Approx.)	40 kg (88.2 lbs)

NOTE: *Manufacture's estimate

The company reserves the right to change the specifications without notice.

W1031306


[5] HANDLING OF CIRCUIT TESTER



3TMABAB0P020A

- Use tester correctly following manual provided with tester.
- Check for polarity and range.

W10126840



Checking Transmission Fluid Level

1. Park the machine on a flat surface, lower the implement to the ground and shut off engine and remove the key.
2. Raise the operator's seat.
3. To check the oil level, draw out the dipstick (1), wipe it clean, reinsert it, and draw it out again. Check to see that the oil level lies between the two notches. If the level is too low, add new oil to the prescribed level at the oil inlet. (Refer to "4. LUBRICANTS, FUEL AND COOLANT" in this section.)


IMPORTANT

- If oil level is low, do not run engine.

(1) Oil Level Dipstick

A : Oil level is acceptable within this range.

W1050686



Checking Coolant Level

CAUTION

- Do not remove the radiator cap when the engine is hot. Loosen cap slightly, to the stop, to relieve any excess pressure before removing cap completely.

Check the coolant level daily both the radiator and the recovery tank (4) before starting engine.

1. Remove the radiator cap (1) and check to see that the coolant level is just below the fill port.
2. Check to see that the coolant level is between the "FULL" and "LOW" marks of recovery tank (4).
3. When the coolant level drops due to evaporation, add water only up to just below the fill port of the radiator and the full level of the recovery tank (4).


In case of leakage, add coolant and water in the specified mixing ratio up to the full level. (Refer to "Flushing Cooling System and Changing Coolant" of "7. CHECK AND MAINTENANCE" in this section.)

IMPORTANT



- If the radiator cap has to be removed, follow the caution above and securely retighten the cap.
- Use clean, distilled coolant and water to fill the radiator and recovery tank.

(1) Radiator Cap
 (2) Overflow Pipe
 (3) Recovery Tank Cap
 (4) Recovery Tank

A : FULL
 B : LOW



W1051701



Checking Fuel Line and Fuel Filter

CAUTION

- Be sure to stop the engine and remove the key when attempting to make the following checks and changes.
- Never fail to check the fuel lines periodically. The fuel lines are subject to wear and aging. Fuel may leak out onto the running engine, causing a fire.

The fuel line connections should be checked annually or every 100 service hours, whichever comes first.


1. The fuel line (2) is made of rubber and ages regardless of service period.
2. If the fuel line (2) and clamps (1) are found to be damaged or deteriorated, replace them.
3. Check fuel filter (3), if it is clogged by debris or contaminated with water, replace it.

IMPORTANT

- When the fuel line is disconnected for maintenance or repair, close both ends of the fuel line with a piece of clean cloth or paper to prevent dust and dirt from entering. In addition, particular care must be taken not to admit dust and dirt into the fuel pump. Entrance of even a small amount of dust or dirt cause premature wear and malfunction of the fuel pump and injector components.

- (1) Pipe Clamp (2) Fuel Line (3) Fuel Filter

W1015551



Checking Brake

CAUTION


- When making adjustments, park the machine on a flat area, block wheels, stop the engine and remove the key.





1. Correct play ranges from 15 to 25 mm (0.59 to 0.98 in.). If it is not correct, loosen the lock nut (2) and turn the nut (3) in the desired direction until the proper play is achieved. After adjustment, retighten lock nut securely.

Play (A)	Factory spec.	15 to 25 mm 0.59 to 0.98 in.
----------	---------------	---------------------------------

- (1) Brake Pedal (2) Lock Nut (3) Nut (4) Spring

W1017708





Replacing Mower Belt

1. Remove the mower deck from the machine.
2. Remove the left and right hand shield (4), (6) from the mower deck.
3. Clean around the pulleys to remove the belt (3) from the pulleys. Slip the belt (3) over the top of the left side pulley.
4. Remove the both brackets which mounts the gear box to the mower deck.
5. To install a new belt, reverse the above procedure.

Tightening torque	Bolt (1)	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.2 to 66.5 ft-lbs
	Bolt and Nut (2)	48.1 to 55.8 N·m 4.9 to 5.7 kgf·m 35.5 to 41.2 ft-lbs

- (1) Bolt
(2) Bolt, Nut
(3) Belt

- (4) Left Hand Shield
(5) Right Hand Shield
(6) Mower Gear Box

W1073387

Bleeding Fuel System

Air must be removed :

1. When the fuel filter or lines are removed.
2. When tank is completely empty.
3. After the machine has not been used for a long period of time.

Bleeding procedure is as follows :


1. Fill the fuel tank with fuel.
2. Start the engine and run for about 30 seconds, and then stop the engine.

W1074213

10. IMPLEMENT LIMITATIONS

The KUBOTA Machine has been thoroughly tested for proper performance with implements sold or approved by KUBOTA. Use of implements which are not sold or approved by KUBOTA and which exceed the maximum specifications listed below, or which are otherwise unfit for use with the KUBOTA Machine may result in malfunctions or failures of the machine, damage to other property and injury to the operator or others. [Any malfunctions or failures of the machine resulting from use with improper implements are not covered by the warranty.]

Maximum axle loading weight		
Front axle W_f	Rear axle W_r	Total gross weight
250 kg (551 lbs)	450 kg (992 lbs)	600 kg (1323 lbs)




3GLAAAI0P012A

Symptom	Probable Cause	Solution	Reference Page
Water Mixed into Lubricant Oil	Head gasket defective	Replace	1-S23
	Cylinder block or cylinder head flawed	Replace	–
Low Oil Pressure	Engine oil insufficient	Replenish	G-8, 14
	Oil strainer clogged	Clean	–
	Oil filter clogged	Replace	G-28
	Relief valve stuck with dirt	Clean	–
	Relief valve spring weaken or broken	Replace	–
	Excessive oil clearance of crankshaft bearing	Replace	1-S48
	Excessive oil clearance of crankpin bearing	Replace	1-S46
	Excessive oil clearance of rocker arm	Replace	1-S39
	Oil passage clogged	Clean	–
	Different type of oil	Use specified type of oil	G-8
	Oil pump defective	Repair or replace	1-S27
High Oil Pressure	Different type of oil	Use specified type of oil	G-8
	Relief valve defective	Replace	–
Engine Overheated	Engine oil insufficient	Replenish	G-8
	Fan belt broken or tensioned improperly	Replace or adjust	G-28, 1-S13
	Coolant insufficient	Replenish	G-8
	Radiator net and radiator fin clogged with dust	Clean	–
	Inside of radiator corroded	Clean or replace	G-32, 1-S21
	Coolant flow route corroded	Clean or replace	G-32
	Radiator cap defective	Replace	1-S14
	Radiator hose damaged	Replace	G-30
	Overload running	Reduce the load	–
	Head gasket defective	Replace	1-S23
	Incorrect injection timing	Adjust	1-S15
Unsuitable fuel used	Use specified fuel	G-8	

W1014322

(2) Lubricating System



3GFABAB1P056A

Engine Oil Pressure

1. Remove the engine oil pressure switch, and set an oil pressure tester (Code No.: 07916-32032).
2. Start the engine. After warming up, measure the oil pressure of both idling and rated speeds.
3. If the oil pressure is less than the allowable limit, check the following.
 - Engine oil insufficient
 - Oil pump defective
 - Oil strainer clogged
 - Oil filter cartridge clogged
 - Oil gallery clogged
 - Excessive oil clearance
 - Foreign matter in the relief valve


Engine oil pressure	At idle speed	Factory spec.	More than 49 kPa 0.5 kgf/cm ² 7 psi
	At rated speed	Factory spec.	196 to 441 kPa 2.0 to 4.5 kgf/cm ² 28 to 64 psi
		Allowable limit	147 kPa 1.5 kgf/cm ² 21 psi

(When reassembling)

- After checking the engine oil pressure, tighten the engine oil pressure switch to the specified torque.

W10349520

(3) Cooling System



3EEABAB1P017D

Checking Fan Drive Belt Tension

⚠ CAUTION



- **Be sure to stop the engine and remove the key before checking belt tension.**
1. Measure the deflection (A), depressing the belt halfway between the fan drive pulley (1) and dynamo pulley (2) at specified force 98 N (10 kgf, 22 lbs).
 2. If the measurement is not within the factory specifications, loosen the dynamo mounting screws and relocate the dynamo to adjust.

Deflection (A)	Factory spec.	7.0 to 9.0 mm 0.28 to 0.35 in.
----------------	---------------	-----------------------------------

(1) Fan Drive Pulley

(2) Dynamo pulley

W10356670



Cylinder Head

1. Loosen the pipe clamp, and remove the water return pipe.
2. Remove the cylinder head screw in the order of (j) to (a).
3. Lift up the cylinder head to detach.
4. Remove the cylinder head gasket and O-ring (1).

(When reassembling)

- Replace the cylinder head gasket with a new one.
- Securely fit the O-ring (1) to the pipe pin.
- Tighten the cylinder head screws after applying sufficient oil.
- Tighten the cylinder head screws diagonal sequence starting from the centre.
- Tighten them uniformly, or the head may deform in the long run.
- Retighten the cylinder head screws after running the engine for 30 minutes.

Tightening torque	Cylinder head screw	37.3 to 42.2 N·m 3.8 to 4.3 kgf·m 27.5 to 31.1 ft·lbs
-------------------	---------------------	---

(j) to (a) : To Loosen
(a) to (j) : To Tighten

(1) O-ring

W1045977

Tappets

1. Remove the tappets (1) from the crankcase.

(When reassembling)

- Visually check the contact between tappets and cams for proper rotation. If defect is found, replace tappets.
- Before installing the tappets, apply engine oil thinly around them.

IMPORTANT

- **Do not change the combination of tappet and tappet guide.**

(1) Tappet

W10209700

Valves

1. Remove the valve caps (2).
2. Remove the valve spring collet (3), pushing the valve spring retainer (4) by valve spring replacer (1).
3. Remove the valve spring retainer (4), valve spring (5) and valve stem seal (6).
4. Remove the valve (7).

(When reassembling)

- Wash the valve stem seal and valve guide hole, and apply engine oil sufficiently.
- After installing the valve spring collets, lightly tap the stem to assure proper fit with a plastic hammer.






IMPORTANT

- **Do not change the combination of valve and valve guide.**

(1) Valve Spring Replacer
(2) Valve Cap
(3) Valve Spring Collet
(4) Valve Spring Retainer

(5) Valve Spring
(6) Valve Stem Seal
(7) Valve

W10211070



Main Bearing Case Assembly

1. Remove the two main bearing case screws 1 (1), and remove the main bearing case assembly 1 (2), being careful with crankshaft bearing 3 (4), (5).
2. Remove the main bearing case assembly (3) as above. Keep in mind, however, that the thrust bearing (8) is installed in the main bearing case assembly (3).

(When reassembling)


- Clean the oil passage in the main bearing cases.
- Apply clean engine oil on the bearings.
- Install the main bearing case assemblies in original positions. Since diameters of main bearing cases vary, install them in order to marking (b) from the gear case side. (Refer to the figure.)
- Match the alignment numbers (a) on the main bearing case assembly 1.
- Do the same for the main bearing case assembly (3) too.
- When installing the main bearing case 1, face the mark “FLYWHEEL” to the flywheel.
- Install the thrust bearing (8) with its oil groove facing outward.
- Confirm that the main bearing case moves smoothly after tightening the main bearing case screw 1 to the specified torque.

Tightening torque	Main bearing case screw 1	12.7 to 15.7 N·m 1.3 to 1.6 kgf·m 9.4 to 11.6 ft·lbs
-------------------	---------------------------	--

- (1) Main Bearing Case Screw 1
- (2) Main Bearing Case Assembly 1
- (3) Main Bearing Case Assembly
- (4) Crankshaft Bearing 3 (Upper, with oil groove)
- (5) Crankshaft Bearing 3 (Lower)
- (6) Crankshaft Bearing 2 (Upper, with oil groove)
- (7) Crankshaft Bearing 2 (Lower)
- (8) Thrust Bearing

- (a) Alignment Number
- (b) Marking
- (c) Oil Groove

W1034602



3EEABAB1P139A


Oil Clearance between Piston Pin and Small End Bushing

1. Measure the piston pin O.D. where it contacts the bushing with an outside micrometer.
2. Measure the small end bushing I.D. with an inside micrometer, and calculate the oil clearance.
3. If the oil clearance exceeds the allowable limit, replace the bushing. If it still exceeds the allowable limit, replace the piston pin.

Oil clearance between piston pin and small end bushing	Factory spec.	0.014 to 0.038 mm 0.00055 to 0.00150 in.
	Allowable limit	0.10 mm 0.0039 in.

Piston pin O.D.	Factory spec.	20.002 to 20.011 mm 0.78748 to 0.78783 in.
Small end bushing I.D.	Factory spec.	20.025 to 20.040 mm 0.78839 to 0.78897 in.

W11420110



3EEABAB1P140A

Replacing Small End Bushing

(When removing)


1. Press out the used bushing using a small end bushing replacing tool.

(When installing)

1. Clean a new small end bushing and bore, and apply engine oil to them.
2. Insert a new bushing onto the tool and press-fit it with a press so that the seam (1) of bushing positions as shown in the figure, until it is flush with the connecting rod.
3. Drill a hole to the bushing with aligning the oil hole (2) of connecting rod. (Refer to the figure.)

NOTE

- Be sure to chamfer the oil hole circumference with an oil stone.



3GFABAB1P053A

Oil clearance between piston pin and small end bushing (Spare parts)	Factory spec.	0.015 to 0.075 mm 0.00059 to 0.00295 in.
	Allowable limit	0.15 mm 0.0059 in.

Small end bushing I.D. (Spare parts)	Factory spec.	20.026 to 20.077 mm 0.78845 to 0.79043 in.
--------------------------------------	---------------	---

- (1) Seam
(2) Oil Hole

- (A) When removing**
(B) When installing
(a) 0.785 rad. (45°)

W11437590

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL


- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

1. STRUCTURE



(1) Hydraulic Transmission Section

(2) Mower PTO Section

(3) Differential Gear Section


(4) Rear Axle Section

The transaxle of this machine is constructed as shown above.

SERVICING

CONTENTS

1. TROUBLESHOOTING	2-S1
2. SERVICING SPECIFICATIONS	2-S4
3. TIGHTENING TORQUES	2-S5
4. CHEKING, DISASSEMBLING AND SERVICING	2-S6
[1] CHECKING AND ADJUSTING	2-S6
[2] PREPARATION	2-S9
(1) Separating Transaxle	2-S9
(2) Separating Hydrostatic Transmission	2-S16
[3] DISASSEMBLING AND ASSEMBLING	2-S20
(1) Hydrostatic Transmission	2-S20
(2) Transaxle Case	2-S23
(3) PTO Clutch	2-S32
[4] SERVICING	2-S37
(1) Hydrostatic Transmission	2-S37
(2) Transaxle Case	2-S39





Discharge Duct

1. Remove the filter cover (1) and the duct plate (3).
2. Disconnect the connector (5) from the grass container full switch (4).
3. Remove the discharge duct (2).

(1) Filter Cover
 (2) Discharge Duct
 (3) Duct Plate
 (4) Grass Container Full Switch
 (5) Connector

W1012965





Container Base

1. Disconnect the couplers (1) from the relays (2).
2. Disconnect the connector (4).
3. Remove the container base (3).


(1) Coupler
 (2) Relay
 (3) Container Base
 (4) Connector
[A] Left Side
[B] Right Side

W1013019



[3] DISASSEMBLING AND ASSEMBLING

(1) Hydrostatic Transmission





15T Gear, 34T Gear and Bevel Gear Shaft

1. Remove the external snap ring (4). And pull out the 15T gear (1) and 34T gear (2).
2. Remove the bevel gear shaft (3).

- | | |
|----------------------|------------------------|
| (1) 15T Gear | (4) External Snap Ring |
| (2) 34T Gear | (5) Shim |
| (3) Bevel Gear Shaft | |

W1017904



Charge Pump Housing and Charge Relief Valve



1. Remove the charge pump housing (1).
2. Remove the spring (5) and the steel ball (6).
3. Remove the O-ring (4) from the charge pump housing (1).
4. Remove the internal snap ring (2) and the oil seal (3).

NOTE

- When removing the oil seal (3), take care not to damage the charge pump housing (1).
- Take care not to damage the O-ring (4).

- | | |
|-------------------------|-------------------------|
| (1) Charge Pump Housing | (5) Spring |
| (2) Internal Snap Ring | (6) Steel Ball |
| (3) Oil Seal | (7) Charge Relief Valve |
| (4) O-ring | |

W1018141



Gerotor




1. Remove the gerotor (1).
2. Draw out the drive pin (2) on the pump shaft (3).

(When reassembling)

- Apply clean transmission oil to the both side of gerotors.

- | | |
|---------------|----------------|
| (1) Gerotor | (3) Pump Shaft |
| (2) Drive Pin | |

W1018461



Rear Differential Gear, Drive Shaft and 11T Gear Shaft (RH, LH) (For Machine with Serial Number above 30001)

1. Remove the rear differential gear assembly (3), 11T gear shafts (1), (7) and drive shaft (5).
2. Remove the external snap ring (8) and bearing (4) from drive shaft (5).

(When reassembling)

- When installing the bushes (2), (6) in the rear side of transaxle case, direct the splits of bush (A) to the front side.

- | | |
|-------------------------------------|--------------------------|
| (1) 11T Gear Shaft (LH) | (5) Drive Shaft |
| (2) Bush | (6) Bush |
| (3) Rear Differential Gear Assembly | (7) 11T Gear Shaft (RH) |
| (4) Bearing | (8) External Snap Ring |
| | A : Split of Bush |

W1071079

Rear Differential Gear Assembly

1. Remove the 42T gear mounting screws (1).
2. Remove the 42T gear (2) and differential side gear (3).
3. Remove the differential pinion shaft (6).
4. Remove the differential pinion gears (5), differential side gear (7) and shims (4).

NOTE

- **Arrange the parts to know their original position.**

(When reassembling)

- Apply molybdenum disulfide (Three Bond 1901 or equivalent) to the inner circumferential surface of differential pinion gears (5), differential side gears (3), (7) and shims (4).

Tightening torque	42T gear mounting screw	9.8 to 11.3 N·m 1.00 to 1.15 kgf·m 7.23 to 8.33 lbf·ft
-------------------	-------------------------	--

- | | |
|-----------------------------|-------------------------------|
| (1) 42T Gear Mounting Screw | (5) Differential Pinion Gear |
| (2) 42T Gear | (6) Differential Pinion Shaft |
| (3) Differential Side Gear | (7) Differential Side Gear |
| (4) Shim | |

W1025887

**PTO Brake Disc Wear**

1. Measure the thickness of PTO brake disc with a vernier caliper.
2. If the thickness is less than the allowable limit, replace it.

PTO brake disc thickness	Factory spec.	3.3 to 3.5 mm 0.13 to 0.14 in.
	Allowable limit	3.00 mm 0.118 in.

W1029677


**Friction Plate Wear**

1. Measure the thickness of brake friction plate 1, 2 with vernier calipers.
2. If the thickness is less than the allowable limit, replace it.

Thickness of brake friction plate 1	Factory spec.	1.75 to 1.85 mm 0.069 to 0.073 in.
	Allowable limit	1.60 mm 0.063 in.

Thickness of brake friction plate 2	Factory spec.	0.95 to 1.05 mm 0.037 to 0.041 in.
	Allowable limit	0.80 mm 0.031 in.

W1029986

**Clearance between Differential Gear Case and Differential Side Gear**

1. Measure the differential gear case (4) bore I.D..
2. Measure the differential side gear (3) boss O.D., and calculate the clearance.
3. Measure the 42T gear (1) bore I.D..
4. Measure the differential side gear (2) boss O.D., and calculate the clearance.
5. If the clearance exceeds the allowable limit, replace faulty parts.


Clearance between differential case and differential side gear	Factory spec.	0.040 to 0.082 mm 0.0016 to 0.0032 in.
	Allowable limit	0.17 mm 0.0067 in.
Clearance between 42T gear and differential side gear	Factory spec.	0.040 to 0.082 mm 0.0016 to 0.0032 in.
	Allowable limit	0.17 mm 0.0067 in.

Differential case bore I.D.	Factory spec.	22.500 to 22.521 mm 0.8858 to 0.8867 in.
Differential side gear boss O.D.	Factory spec.	22.439 to 22.460 mm 0.8834 to 0.8843 in.
42T gear bore I.D.	Factory spec.	22.500 to 22.521 mm 0.8858 to 0.8867 in.

- (1) 42T Gear
(2) Differential Side Gear

- (3) Differential Side Gear
(4) Differential Gear Case

W1030169

**Seat**

1. Remove two snap pins (2), (4).
2. Remove the seat (1) and seat plate (3).

- | | |
|--------------|----------------|
| (1) Seat | (3) Seat Plate |
| (2) Snap pin | (4) Snap Pin |


W1011458

**Fender**

1. Remove the speed change pedal (5).
2. Peel the step sheet (4) halfway.
3. Remove the fuel cap (1).
4. Remove the fender (2).

- | | |
|---------------------------|------------------------|
| (1) Fuel Cap | (4) Step Sheet |
| (2) Fender | (5) Speed Change Pedal |
| (3) Fender Mounting Screw | |



W1011701

**Steering Wheel, Side Bonnet and Panel**

1. Remove the steering wheel (1).
2. Remove the side bonnet (3).
3. Remove the accelerator lever grip.
4. Disconnect the connectors for hour meter (4), main switch (5) and light switch.
5. Remove the indicator lamps (6).
6. Remove the fuse box (7) from the steering support.
7. Remove the panel (2).

(When reassembling)

Tightening torque	Steering Wheel mounting nut	20 to 25 N·m 2.0 to 2.5 kgf·m 14.8 to 18.4 ft·lbs
(1) Steering Wheel	(5) Main Switch	
(2) Panel	(6) Indicator Lamp	
(3) Side Bonnet	(7) Fuse Box	
(4) Hour Meter		



W1011932


Separating Engine

1. Refer to "[2] PREPARATION" of "4. CHECKING, DISASSEMBLING AND SERVICING" at "1. ENGINE" section.

W1012295

[3] DISASSEMBLING AND ASSEMBLING

(1) Front Axle Assembly



Tie-rod

1. Remove the tie-rod mounting locking nut (1).
2. Remove the tie-rod (2).


(When reassembling)

Tightening torque	Tie-rod mounting locking nut	49.9 to 54.2 N·m 5.09 to 5.53 kgf·m 36.8 to 40.0 ft·lbs
-------------------	------------------------------	---

- (1) Tie-rod Mounting Locking Nut (2) Tie-rod

W1012154

[4] SERVICING



Clearance between Center Pin Boss and Center Pin Collar


1. Measure the center pin boss (2) I.D. with a cylinder gauge.
2. Measure the center pin collar (3) O.D. with an outside micrometer and calculate the clearance.
3. If the clearance exceeds the allowable limit, replace them.

Clearance between center pin boss and center pin collar	Factory spec.	0.109 to 0.200 mm 0.00430 to 0.00789 in.
	Allowable limit	0.210 mm 0.0828 in.

Center pin boss I.D. (A)	Factory spec.	25.400 to 25.430 mm 1.00000 to 1.00118 in.
Center pin collar O.D. (B)	Factory spec.	25.230 to 25.291 mm 0.99329 to 0.99570 in.


- (1) Front Axle Frame (3) Center Pin Collar
(2) Center Pin Boss

W1012404



[3] DISASSEMBLING AND ASSEMBLING

(1) Steering Support Assembly



Steering Shaft and Sector Gear

1. Remove the shaft retainer (4).
2. Remove the sector gear mounting screw (5), and remove the sector gear (8).
3. Remove the steering bearing (1) and ball bearing (3).
4. Pull out the steering shaft (2).


(When reassembling)

- Apply to grease to the sector gear teeth.
- Apply to grease to the pinion teeth of steering shaft.
- Apply to grease to the sector bushes (6), (7).
- Apply to grease to the steering bearing.
- Adjust the clearance between the shaft retainer and the pinion gear of steering shaft.

(Reference)

- Length (L) : 1 mm (0.040 in.)


Tightening torque	Sector gear mounting screw	48.1 to 55.8 N·m 4.9 to 5.7. kgf·m 35.5 to 41.2 ft·lbs



- | | |
|----------------------|--------------------------------|
| (1) Steering Bearing | (5) Sector Gear Mounting Screw |
| (2) Steering Shaft | (6) Sector Bush |
| (3) Ball Bearing | (7) Sector Bush |
| (4) Shaft Retainer | (8) Sector Gear |

W1012713

[4] SERVICING



Steering Support Bushing Wear

1. Visually inspect the sector bushes (1) for signs of wear or damage.
2. If defect are found, replace the sector bush (1).

- (1) Sector Bush

W1013149

STARTING SYSTEM



Symptom	Probable Cause	Solution	Reference Page
Starter Motor Does Not Operate	Battery discharged or defective	Recharge or replace	G-24, 1-S19
	Slow blow fuse blown (40 A)	Replace	G-35
	Wiring harness disconnected or improperly connected (between main switch ST terminal and safety switches, between safety switches and starter motor, between battery positive terminal and starter motor)	Repair or replace	–
	Starter motor defective	Repair or replace	6-S20
	Main switch defective	Replace	6-S8, 9
	Seat switch defective	Replace	6-S13
	Brake switch defective	Replace	6-S12
	PTO switch defective	Replace	6-S12
	Top cover open switch defective	Replace	6-S13
	Grass container open switch defective	Replace	6-S13
Engine Does Not Stop When Main Switch is Turned OFF	Fuse blown (15 A)	Replace	G-35
	Wiring harness disconnected or improperly connected (between main switch ACC terminal and engine stop solenoid)	Repair or replace	–
	Engine stop solenoid defective	Replace	6-S14
	Timer relay defective	Replace	6-S15
Engine Does Not Start	Engine stop solenoid defective	Replace	6-S14
	Timer relay defective	Replace	6-S15

W1013580

CHARGING SYSTEM

Charging Lamp Does Not Light when Main Switch is Turned ON	Fuse blown (15 A)	Replace	G-35
	Bulb blown	Replace	G-35
	Wiring harness disconnected or improperly connected (between main switch ACC terminal and regulator connector terminal (yellow), between regulator connector terminal (green) and charge lamp)	Repair or replace	–
	Regulator defective	Replace	–
Charging Lamp Does Not Go Off When Engine is Running	Dynamo defective	Repair or replace	6-S21
	Regulator defective	Replace	6-S15, 16

W1019547

(5) Safety Switch**PTO Switch**

1. Remove the battery.
2. Remove the fender.
3. Disconnect the connector from the PTO switch (1).
4. Measure the resistance with an ohmmeter between the terminals.
5. If the PTO switch is defective, replace it.

Resistance (between terminal a and b)	When plunger is pushed	0 Ω
	When plunger is released	Infinity
Resistance (between terminal c and d)	When plunger is pushed	0 Ω
	When plunger is released	Infinity

- (1) PTO Switch
(2) PTO Lever

a to d :Safety Switch Terminal

W10158610

Brake Switch

1. Remove the battery.
2. Remove the fender.
3. Disconnect the connector from the brake switch (1).
4. Measure the resistance with an ohmmeter between the terminals.
5. If the brake switch is defective, replace it.

Resistance (between terminal a and b)	When plunger is pushed	0 Ω
	When plunger is released	Infinity
Resistance (between terminal c and d)	When plunger is pushed	0 Ω
	When plunger is released	Infinity


- (1) Brake Switch

a to d :Safety Switch Terminal


W10413270

[3] SERVICING


(1) Starter




3EEABAB1P188A




3EEABAB1P182A



3EEABAB1P183A



3EEABAB1P184A



3TAAAB9P037A

Overrunning Clutch

1. Inspect the pinion for wear or damage.
2. If there is any defect, replace the overrunning clutch assembly.
3. Check that the pinion turns freely and smoothly in the overrunning direction and does not slip in the cranking direction.
4. If the pinion slips or does not rotate in the both directions, replace the overrunning clutch assembly.

W1016990

Commutator and Mica

1. Check the contact face of the commutator for wear, and grind the commutator with emery paper if it is slightly worn.
2. Measure the commutator O.D. with an outside micrometer at several points.
3. If the minimum O.D. is less than the allowable limit, replace the armature.
4. If the difference of the O.D.'s exceeds the allowable limit, correct the commutator on a lathe to the factory specification.
5. Measure the mica undercut.
6. If the undercut is less than the allowable limit, correct it with a saw blade and chamfer the segment edges.

Commutator O.D.	Factory spec.	28.0 mm 1.102 in.
	Allowable limit	27.0 mm 1.063 in.

Difference of O.D.'s	Factory spec.	Less than 0.05 mm 0.002 in.
	Allowable limit	0.4 mm 0.016 in.

Mica undercut	Factory spec.	0.50 to 0.80 mm 0.0197 to 0.0315 in.
	Allowable limit	0.20 mm 0.0079 in.

- (1) Segment
(2) Undercut
(3) Mica

(a) Correct
(b) Incorrect

W1017092

Brush Wear

1. If the contact face of the brush is dirty or dusty, clean it with emery paper.
2. Measure the brush length (A) with vernier calipers.
3. If the length is less than the allowable limit, replace the yoke assembly and brush holder.

Brush length (A)	Factory spec.	16.0 mm 0.630 in.
	Allowable limit	10.5 mm 0.413 in.

W1017544

3. TIGHTENING TORQUES

Tightening torques of screws, bolts and nuts on the table below are especially specified.
(For general use screws, bolts and nuts : Refer to "5. TIGHTENING TORQUES" at "G.GENERAL" section.)

Item	N·m	kgf·m	ft·lbs
Mower blade screw	98 to 118	10.0 to 12.0	72.3 to 86.8
Gear box mounting screw	77.5 to 90.2	7.9 to 9.2	57.2 to 66.5
Gear box bracket mounting screw and nut	48.1 to 55.8	4.9 to 5.7	35.5 to 41.2
Pulley mounting screw (gear box)	77.5 to 90.2	7.9 to 9.2	57.2 to 66.5
Pulley mounting nut (pulley holder)	103 to 118	10.5 to 12.0	76.0 to 87.0
Pulley holder mounting screw	48.1 to 55.8	4.9 to 5.7	35.5 to 41.2

W1012736

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL