

# WSM

---

## WORKSHOP MANUAL **TRACTOR**

**L3130, L3430, L3830,  
L4630, L5030**

---

# Kubota

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

## ROPS Type

Model		L3830		L4630	
		Manual Transmission			
Engine	Model	D1803-MA-E-GST-EU		V2203-MA-E-GST-EU	
	Type	Indirect injection vertical, water-cooled, 4-cycle diesel			
	Number of cylinders	3		4	
	Total displacement	1.826 L (111.4 cu.in.)		2.197 L (134.1 cu.in.)	
	Bore and stroke	87 × 102.4 mm (3.4 × 4.0 in.)		87 × 92.4 mm (3.4 × 3.6 in.)	
	Net power	27.9 kW (37.4 HP)*		33.3 kW (44.7 HP)*	
	PTO power (factory observe)	23.9 kW (32.5 HP)* / 2700 min <sup>-1</sup> (rpm)		29.5 kW (40.1 HP)* / 2700 min <sup>-1</sup> (rpm)	
	Maximum torque	120.7 N·m (12.3 kgf·m, 89.0 ft-lbs)		146.2 N·m (14.9 kgf·m, 107.8 ft-lbs)	
	Battery capacity	12 V, RC : 133 min, CCA : 582 A			
	Fuel	Diesel fuel No. 1 [below -10 °C (14 °F)], Diesel fuel No. 2-D [above -10 °C (14 °F)]			
Capacities	Fuel tank	40 L (10.6 U.S.gals, 8.8 Imp.gals)			
	Engine crankcase (with filter)	6.7 L (7.1 U.S.qts, 5.9 Imp.qts)		8.2 L (8.7 U.S.qts, 7.2 Imp.qts)	
	Engine coolant	7.5 L (7.9 U.S.qts, 6.6 Imp.qts)			
	Transmission case	43 L (11.4 U.S.gals, 9.5 Imp.gals)			
Dimensions	Overall length (without 3P)	3075 mm (121.1 in.)		3170 mm (124.8 in.)	
	Overall width (min. tread)	1485 mm (58.5 in.)			
	Overall height (with ROPS)	2420 mm (95.3 in.)			
	Wheel base	1840 mm (72.4 in.)		1895 mm (74.6 in.)	
	Min. ground clearance	400 mm (15.7 in.)			
	Tread	Front	1145 mm (45.1 in.)		
Rear		1140 mm (44.9 in.), 1210 mm (47.6 in.), 1310 mm (51.6 in.), 1410 mm (55.5 in.)			
Weight (with ROPS)		1500 kg (3305 lbs)		1520 kg (3351 lbs)	
Travelling system	Standard tire size	Front	8-16		
		Rear	13.6-24		
	Clutch	Dry type single stage			
	Steering	Hydrostatic power steering			
	Transmission	F8, R8 fully synchronized main and shuttle transmission (with creep speed model : F16, R16 fully synchronized main and shuttle transmission)			
	Braking system	Wet disk type			
Min. turning radius (with brake)	2.7 m (8.9 feet)				
Hydraulic system	Hydraulic control system	Position control			
	Pump capacity	31.5 L (8.3 U.S.gals, 6.9 Imp.gals) / min.		37.0 L (9.8 U.S.gals, 8.1 Imp.gals) / min.	
	Three point hitch	SAE Category 1			
	Max. lift force	At lift points	1750 kg (3860 lbs)		
		24 in. behind lift points	1250 kg (2760 lbs)		
System pressure	17.7 MPa (180 kgf/cm <sup>2</sup> , 2560 psi)				
PTO	Rear PTO	SAE 1-3/8, 6 splines			
	PTO / Engine speed	540 min <sup>-1</sup> (rpm) / 2550 min <sup>-1</sup> (rpm), 750 min <sup>-1</sup> (rpm) / 2250 min <sup>-1</sup> (rpm)			







Note : \* Manufacturer's estimate

The company reserves the right to change the specifications without notice.

W10359440

# 1. TRACTOR IDENTIFICATION

When contacting your local KUBOTA distributor, always specify engine serial number, tractor serial number and hour meter reading.



- (1) Tractor Identification Plate
- (2) CABIN Identification Plate (CABIN Serial Number)
- (3) Tractor Serial Number
- (4) Engine Serial Number
- (5) Hour Meter (IntelliPanel Display)
- (6) ROPS Identification Plate (ROPS Serial Number)

W10106000

## 6. MAINTENANCE


No.	Item		Period	Indication on hour meter										Important	Reference page
				50	100	150	200	250	300	350	400	450	500		
1	Brake	Adjust	★	☆		☆		☆		☆		☆			G-18
2	Engine oil	Change	★	☆		☆		☆		☆		☆			G-15
3	Engine oil filter	Replace	★			☆				☆					G-15
4	Hydraulic oil filter	Replace	★			☆				☆					G-16
5	Transmission fluid	Change	★							☆					G-17
6	Front axle case oil	Change	★							☆					G-18
7	Engine start system	Check	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆			G-20, 21
8	Wheel bolt torque	Check	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆			G-21
9	Greasing	–	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆			G-19
10	Battery condition	Check		☆		☆		☆		☆		☆	*5		G-25
11	Air cleaner element [Double type]	Primary element	Clean		☆		☆		☆		☆		☆	*1	G-22
			Replace											*2	G-32
		Secondary element	Replace												
12	Clutch	Adjust		☆		☆		☆		☆		☆			G-24
13	Parking brake (cable)	Adjust		☆		☆		☆		☆		☆			G-27
		Replace													G-27
14	Fuel filter element	Clean		☆		☆		☆		☆		☆			G-23
		Replace								☆					G-31
15	Fan belt	Adjust		☆		☆		☆		☆		☆			G-23
16	Fuel line	Check		☆		☆		☆		☆		☆			G-24
		Replace													G-32
17	Transmission oil filter [HST]	Replace				☆				☆					G-16
18	HST oil line [HST]	Check				☆				☆					G-29
		Replace											*3		G-32
19	Radiator hose and clamp	Check				☆				☆					G-27
		Replace													G-32
20	Power steering oil line	Check				☆				☆					G-29
		Replace													G-32
21	Toe-in	Adjust				☆				☆					G-28
22	Front axle pivot	Adjust					☆								G-31
23	Engine valve clearance	Adjust						☆					*4		1-S27
24	Cooling system	Flush										☆			G-33
25	Coolant	Change										☆			G-33
26	Fuel system	Bleed													G-34
27	Clutch housing water	Drain													G-35
28	Fuse	Replace													G-36
29	Light bulb	Replace													G-37

### ■ IMPORTANT

- The jobs indicated by ★ must be done after the first 50 hours of operation.
- \*1 : Air cleaner should be cleaned more often in dusty conditions than in normal conditions.
- \*2 : Every year or every 6 times of cleaning.
- \*3 : Replace only if necessary.
- \*4 : Consult your local KUBOTA distributor for this service.
- \*5 : When the battery is used for less than 100 hours per year, check the battery condition by reading the indication annually.
- The items listed above (@ marked) are registered as emission related critical parts by KUBOTA in the U.S.EPA nonroad emission regulation. As the engine owner, you are responsible for the performance of the required maintenance on the engine according to the above instruction. Please see the Warranty Statement in detail.

W10357690





**Checking Air Conditioner Condenser (Cabin Model)**

1. Check the air conditioner condenser (1).
2. If dust and dirt, wash off all dirt and dust from the condenser (1) with a soft brush, use care not to damage or bend the fins.

(1) Air Conditioner Condenser

W1019699

**[6] CHECK POINTS OF EVERY 400 HOURS**

**Changing Transmission Fluid**

1. See page G-17.

W10365120

**Changing Front Axle Case Oil**

1. See page G-18.


W10365590

**Replacing Fuel Filter Element**

1. See page G-23.

W1085936

**[7] CHECK POINTS OF EVERY 600 HOURS**



**Adjust Front Axle Pivot**

1. Loosen the lock nut (2), tighten the adjusting screw (1) all the way, and then loosen the adjusting screw (1) by 1/6 turn.
2. Retighten the lock nut (2).

**■ NOTE**

- If the axle pivot pin adjustment is not correct, front wheel vibration can occur causing vibration in the steering wheel.

**(Reference)**

Tightening torque	Front axle adjusting screw	19.6 to 29.4 N·m 2.0 to 3.0 kgf·m 14.5 to 21.7 ft-lbs
	Lock nut	98.1 to 147.1 N·m 10.0 to 15.0 kgf·m 72.3 to 108.5 ft-lbs

(1) Adjusting Screw

(2) Lock Nut


W1036668

**[8] CHECK POINTS OF EVERY 800 HOURS**

**Checking Valve Clearance**

1. See page 1-S27.

W1036805



3TMABAB0P058A


**Plastigage**

Code No.: 07909-30241

Application: Use to check the oil clearance between crankshaft and bearing, etc.

Measuring: Green .... 0.025 to 0.076 mm (0.001 to 0.003 in.)  
 range Red ..... 0.051 to 0.152 mm (0.002 to 0.006 in.)  
 Blue ..... 0.102 to 0.229 mm (0.004 to 0.009 in.)

W10247190




3TMABAB0P059A

**Red Check**

Code No.: 07909-31371

Application: Use to check cracks on cylinder head, cylinder block, etc.

W10249090




3TMABAB0P060A

**Crankshaft Nut Socket 46**

Code No.: 07916-30821

Application: Use exclusively for removing or installing the crankshaft nut.

W10443610




3TMABAB0P061A

**Socket Wrench 46**

Code No.: 07916-30901

Application: Use exclusively for removing or installing the crankshaft nut.

W10444600



3TMABAB0P062A

**Auxiliary Socket For Fixing Crankshaft Sleeve**


Code No.: 07916-32091

Application: Use to fix the crankshaft sleeve of the diesel engine.

W10771140

■ NOTE

- Special tools for R134a refrigerant air conditioning system introduced below are available from NIPPONDENSO CO. LTD.




**Air Conditioner Service Tool**

Code No.: DENSO.CO. 95048-00061


Application: Use for charging, testing or discharging the air conditioning system.

W1013507



- |                               |             |
|-------------------------------|-------------|
| (1) Manifold Gauge Assembly   | 95048-10090 |
| (2) Charging Hose (Red : HI)  | 95948-10270 |
| (3) Charging Hose (Blue : LO) | 95948-10280 |
| (4) Charging Hose (Green)     | 95948-10260 |
| (5) Can Tap Valve             | 95048-10150 |
| (6) T Joint                   | 95048-10160 |
| (7) Quick Coupler (HI)        | 95048-10130 |
| (8) Quick Coupler (LO)        | 95048-10140 |
| (9) Service Valve Packing     | 95906-10310 |
| (10) Charging Hose Packing    | 95906-10300 |
| (11) Tool Case                | 95949-10610 |

W1014733




**Electric Gas Leak Tester**

Code No.: DENSO.CO. 95146-00060

Application: Use for gas leak testing the air conditioning system.

W1013817



**Vacuum Pump**

Code No.: DENSO.CO. 95046-00040 (AC220V)

95046-00050 (AC240V)

Application: Use for evacuating the air conditioning system.

- |                        |                 |
|------------------------|-----------------|
| (1) Adaptor (For 134a) | (2) Vacuum Pump |
|------------------------|-----------------|

W1013764



# 1 ENGINE

## 2. SERVICING SPECIFICATIONS

### ENGINE BODY

Item		Factory Specification	Allowable Limit
Cylinder Head Surface	Flatness	–	0.05 mm / 500 mm 0.0020 in. / 19.69 in.
Compression Pressure (When Cranking with Starting Motor)		3.53 to 4.02 MPa / 290 min <sup>-1</sup> (rpm) 36 to 41 kgf/cm <sup>2</sup> / 290 min <sup>-1</sup> (rpm) 512 to 583 psi / 290 min <sup>-1</sup> (rpm)	2.55 MPa / 290 min <sup>-1</sup> (rpm) 26 kgf/cm <sup>2</sup> / 290 min <sup>-1</sup> (rpm) 370 psi / 290 min <sup>-1</sup> (rpm)
Difference among Cylinders		–	10 % or less
Top Clearance		0.55 to 0.70 mm 0.0217 to 0.0276 in.	–
Valve Clearance (When Cold)		0.18 to 0.22 mm 0.0071 to 0.0087 in.	–
Valve Seat	Width (Intake)	2.12 mm 0.0835 in.	–
	Width (Exhaust)	2.12 mm 0.0835 in.	–
Valve Seat	Angle (Intake)	1.047 rad 60 °	–
	Angle (Exhaust)	0.785 rad 45 °	–
Valve Face	Angle (Intake)	1.047 rad 60 °	–
	Angle (Exhaust)	0.785 rad 45 °	–
Valve Stem to Valve Guide	Clearance	0.040 to 0.070 mm 0.00157 to 0.00276 in.	0.1 mm 0.0039 in.
Valve Stem	O.D.	7.960 to 7.975 mm 0.31339 to 0.31398 in.	–
Valve Guide	I.D.	8.015 to 8.030 mm 0.31555 to 0.31614 in.	–
Valve Recessing	Protrusion	0.05 mm 0.0020 in.	–
	Recessing	0.15 mm 0.0059 in.	0.4 mm 0.0157 in.

W1013874



**Draining Coolant**

**CAUTION**

- Never remove the radiator cap until coolant temperature is well below its boiling point. Then loosen cap slightly to the stop to relieve any excess pressure before removing cap completely.

1. Stop the engine and let cool down.
2. Loosen the drain plug (3) to drain the coolant.
3. Remove the radiator cap (1) to completely drain the coolant.
4. After all coolant is drained, retighten the drain plug (3).


**(When refilling)**

- Fill the coolant between the “FULL” and “LOW” marks of recovery tank (2).

Coolant capacity (with recovery tank)	L3130 L3430	6.0 L 6.3 U.S.qts 5.3 Imp.qts
	L3830 (ROPS) L4630 (ROPS)	7.5 L 7.9 U.S.qts 6.6 Imp.qts
	L3830 (CABIN) L4630 (CABIN)	8.7 L 9.2 U.S.qts 7.7 Imp.qts
	L5030	9.2 L 9.7 U.S.qts 8.1 Imp.qts

- (1) Radiator Cap
  - (2) Recovery Tank
  - (3) Drain Plug
- A : FULL**  
**B : LOW**

W10314120



**ROPS (Center ROPS Type)**

1. Remove the upper frame (1) from ROPS lower frame (2).
2. Disconnect the light connectors.
3. Remove the shields (3).
4. Remove the lower frames (2).

**(When reassembling)**

**NOTE**

- Do not firmly tighten all screws until most components are attached.

Tightening torque	Lower frame mounting screw	260 to 304 N-m 26.5 to 31.0 kgf-m 192 to 224 ft-lbs
-------------------	----------------------------	---

- (1) Upper Frame
- (2) Lower Frame
- (3) Shield

W1031307



**Battery, Front Grill, Skirt and Bonnet**


1. Open the bonnet and disconnect the battery negative cable.
2. Disconnect the head light connector and remove the front grill (4).
3. Remove the left and right side skirts (3).
4. Disconnect window washer hoses (2). (Cabin model only.)
5. Remove the bonnet (1).

**NOTE**

- When disconnecting the battery cords, disconnect the negative cord first, when connecting, positive cord first.

- (1) Bonnet
- (2) Window Washer Hose
- (3) Skirt
- (4) Front Grill

W1057856




**Radiator Assembly**

1. Disconnect the air cleaner hose (3). (ROPS model)
2. Remove the battery (1). (ROPS model)
3. Remove the oil cooler mounting screws. (ROPS model)
4. Remove the battery stay (4). (ROPS model)
5. Disconnect the radiator hoses (5), (7).
6. Remove the radiator assembly.

- |                                 |                         |
|---------------------------------|-------------------------|
| (1) Battery                     | (5) Radiator Upper Hose |
| (2) Oil Cooler (HST Model Only) | (6) Radiator            |
| (3) Air Cleaner Hose            | (7) Radiator Lower Hose |
| (4) Battery Stay                |                         |

W1015759



**Hydraulic Pipes and Fuel Filter**



1. Disconnect the hoses and remove the oil cooler (4). (HST model)
2. Remove the oil cooler outlet pipe (1) and inlet pipe (5). (HST model)
3. Remove the power steering delivery pipe (2).
4. Disconnect the power steering return hose (7). (Except HST model.)
5. Remove the fuel filter (6) with bracket (3).

**(When reassembling)**

Tightening torque	Joint bolt for power steering delivery pipe	39.2 to 49.0 N-m 4.0 to 5.0 kgf-m 28.9 to 36.2 ft-lbs
	Cap nut of power steering delivery pipe	49.0 to 58.8 N-m 5.0 to 6.0 kgf-m 36.1 to 43.4 ft-lbs

- |                                  |  |
|----------------------------------|--|
| (1) Oil Cooler Outlet Pipe       | (7) Power Steering Return Hose             |
| (2) Power Steering Delivery Pipe | (8) Hydraulic Pump with Regulating Valve   |
| (3) Bracket                      | (9) Steering Controller                    |
| (4) Oil Cooler                   | <b>[A] HST Model</b>                       |
| (5) Oil Cooler Outlet Pipe       | <b>[B] GST / Manual Transmission Model</b> |
| (6) Fuel Filter                  |  |

W1015859



**Front Axle Frame**






1. Hoist the engine by the chain at the engine hook (1).
2. Remove the dipstick stay mounting screw (3) and front axle frame mounting screws.
3. Separate the front axle frame (1) from engine.

**(When reassembling)**

Tightening torque	Front axle frame mounting screw (7T) (L3130, L3430, L3830)	77.5 to 90.2 N-m 7.9 to 9.2 kgf-m 57.1 to 66.5 ft-lbs
	Front axle frame mounting screw (9T) (L4630, L5030)	102.9 to 117.6 N-m 10.5 to 12.0 kgf-m 76.0 to 86.8 ft-lbs

- |                      |                                  |
|----------------------|----------------------------------|
| (1) Engine Hook      | (3) Dipstick Stay Mounting Screw |
| (2) Front Axle Frame |                                  |

W1016162




### Governor Springs and Speed Control Plate (Continued)

#### (When reassembling)

- Hook the small spring (4) first and then the large governor spring (2) on the speed control plate (6).
- Put the specific tool (1) from the injection pump side to catch the large governor spring (2). Keep this spring slightly extended and place the speed control plate (6) in its specified position.
- Using the specific tool (1), hook the small governor spring onto the fork lever (3).

#### ■ NOTE

- Be careful not to stretch the small governor spring (4) too long because otherwise it may get deformed permanently.
- Using the specific tool (1), hook the large governor spring (2) onto the fork lever (3).
- Make sure both the governor springs (2), (4) are tight on the fork lever (3).
- Apply and tighten up the two bolts and two nuts on the speed control plate (6).
- Check that the speed control lever (5) positions low idle, after assembling governor springs.
- Check that the speed control lever (5) returns to the high idle position rather than the low idle position, after moving the lever to the maximum speed position.
- Finally attach the injection pump cover in position.








- (1) Specific Tool  
 (2) Large Governor Spring  
 (3) Fork Lever

- (4) Small Governor Spring  
 (5) Speed Control Lever  
 (6) Speed Control Plate

W1152334

### (3) Servicing

#### (A) Cylinder Head and Valves



#### Cylinder Head Surface Flatness

1. Clean the cylinder head surface.
2. Place a straightedge on the cylinder head's four sides and two diagonal as shown in the figure.
3. Measure the clearance with a feeler gauge.
4. If the measurement exceeds the allowable limit, correct it with a surface grinder.

■ **IMPORTANT**

- Do not place the straightedge on the combustion chamber.
- Be sure to check the valve recessing after correcting.

Cylinder head surface flatness	Factory spec.	0.05 mm / 500 mm 0.0020 in. / 19.69 in.
--------------------------------	---------------	--

W1027737

#### Cylinder Head Flaw

1. Prepare an air spray red check (Code No. 07909-31371).
2. Clean the surface of the cylinder head with detergent (2).
3. Spray the cylinder head surface with the red permeative liquid (1). Leave it five to ten minutes after spraying.
4. Wash away the red permeative liquid on the cylinder head surface with the detergent (2).
5. Spray the cylinder head surface with white developer (3).
6. If flawed, it can be identified as red marks.

- (1) Red Permeative Liquid  
(2) Detergent

- (3) White Developer

W1076542

#### Valve Recessing


1. Clean the cylinder head surface, valve face and valve seat.
2. Insert the valve into the valve guide.
3. Measure the valve recessing with a depth gauge.
4. If the measurement exceeds the allowable limit, replace the valve.
5. If it still exceeds the allowable limit after replacing the valve, correct the valve seat face of the cylinder head with a valve seat cutter (Code No. 07909-33102) or valve seat grinder.
6. Then, correct the cylinder head surface with a surface grinder, or replace the cylinder head.

Valve recessing	Factory spec.	0.05 (protrusion) to 0.15 (recessing) mm 0.0020 (protrusion) to 0.0059 (recessing) in.
	Allowable limit	0.40 (recessing) mm 0.0157 (recessing) in.

- (1) Cylinder Head Surface

- (A) Recessing  
(B) Protrusion

W1076880



**Replacing Connecting Rod Small End Bushing**


**(A) (When removing)**

1. Press out the small end bushing with a connecting rod small end bushing replacing tool.

**(B) (When installing)**

1. Clean a new small end bushing and bore, and apply engine oil to them.
2. Press fit a new bushing, taking due care to see that the connecting rod hole matches the bushing hole.

W1032140



**Piston Ring Gap**


1. Insert the piston ring into the lower part of the liner (the least worn out part) with the piston.
2. Measure the ring gap with a feeler gauge.
3. If the gap exceeds the allowable limit, replace the ring.

Top ring	Factory spec.	D1503-M	0.20 to 0.35 mm 0.0079 to 0.0138 in.
		D1703-M D1803-M V2203-M V2403-M	0.20 to 0.40 mm 0.0079 to 0.0157 in.
		Allowable limit	1.25 mm 0.0492 in.

Second ring	Factory spec.	0.30 to 0.45 mm 0.0118 to 0.0179 in.
	Allowable limit	1.25 mm 0.0492 in.

Oil ring	Factory spec.	0.25 to 0.45 mm 0.0098 to 0.0177 in.
	Allowable limit	1.25 mm 0.0492 in.

W1032246



**Clearance between Piston Ring and Groove**

1. Remove carbon from the ring grooves.
2. Measure the clearance between the ring and the groove with a feeler gauge.
3. If the clearance exceeds allowable limit, replace the ring since compression leak and oil shortage result.
4. if the clearance still exceeds the allowable limit after replacing the ring, replace the piston.

Second ring	Factory spec.	D1503-M	0.093 to 0.120 mm 0.0037 to 0.0047 in.
		D1703-M D1803-M V2203-M V2403-M	0.093 to 0.128 mm 0.0037 to 0.0050 in.
		Allowable limit	0.2 mm 0.0079 in.





Oil ring	Factory spec.	0.020 to 0.060 mm 0.0008 to 0.0021 in.
	Allowable limit	0.15 mm 0.0059 in.

W1032489

## [5] FUEL SYSTEM

### (1) Checking and Adjusting

#### (A) Injection Pump



#### Injection Timing

1. Remove the stop solenoid.
2. Remove the injection pipes and nozzle.
3. Set the speed control lever to maximum fuel discharge position.

#### (Reference)

- Turn the flywheel with screwdriver.

#### NOTE

- For V2203-M and V2403-M, the pumps have a displacement angle. In adjusting the injection timing, pull the stop lever from its free position by  $0.267 \pm 0.035$  rad ( $15.3 \pm 2^\circ$ ) toward the stop position.


4. Turn the flywheel counterclockwise (facing the flywheel) until the fuel fills up to the hole of the delivery valve holder for 1st cylinder.
5. Turn the flywheel further and stop turning when the fuel begins to flow over, to get the present injection timing.
6. (The flywheel has mark 1TC and four lines indicating every  $0.087$  rad ( $5^\circ$ ) of crank angle from  $0.175$  rad ( $10^\circ$ ) to  $0.436$  rad ( $25^\circ$ ) before mark 1TC) Calculate the angle which the center of the window points out. If the calculation differs from specified injection timing, add or remove the shim to adjust.

#### (Injection Timing)

$0.297$  to  $0.331$  rad ( $17^\circ$  to  $19^\circ$ ) B.T.D.C.

#### NOTE

- The sealant is applied to both sides of the soft metal gasket shim. The liquid gasket is not required for assembling.
- Shims are available in thickness of  $0.20$  mm,  $0.25$  mm and  $0.30$  mm. Combine these shims for adjustments.
- Addition or reduction of shim ( $0.05$  mm,  $0.0020$  in.) delays or advances the injection timing by approx.  $0.0087$  rad ( $0.5^\circ$ ).
- In disassembling and replacing, be sure to use the same number of new gasket shims with the same thickness.



(1) Speed Control Lever

(2) Stop Lever

(3) Delivery Valve Holder

(4) Timing Mark

(5) 2-Holes:  $0.20$  mm (Shim)

(6) 1-hole:  $0.25$  mm (Shim)

(7) Without hole:  $0.30$  mm (Shim)

(A) To STOP Position

(B) To Max. Speed Position



(C) Stop Lever in Free Position

(a)  $0.267 \pm 0.035$  rad ( $15.3 \pm 2^\circ$ )

W1036402

## [2] DISASSEMBLING AND ASSEMBLING

### (1) Separating Clutch Housing and Engine



#### Draining the Transmission Fluid

1. Place oil pans underneath the transmission case.
2. Remove the drain plugs (1).
3. Drain the transmission fluid.
4. Reinstall the drain plugs (1).

#### **(When refilling)**

- Fill up from filling port after removing the filling plug (2) until reaching the upper notch on the dipstick (3).
- After running the engine for few minutes, stop it and check the oil level again, add the fluid to prescribed level if it is not correct level.

Transmission fluid capacity	L3130 L3430	42 L 11.1 U.S.gals 9.2 Imp.gals
	L3830 L4630	43 L 11.4 U.S.gals 9.5 Imp.gals
	L5030	45 L 11.9 U.S.gals 9.9 Imp.gals


#### ■ **IMPORTANT**

- **Use only KUBOTA SUPER UDT fluid. Use of other oils may damage the transmission or hydraulic system. Refer to “LUBRICANTS, FUEL AND COOLANT”. (See page G-7, 8.)**
- **Do not mix different brands of fluid together.**

- (1) Drain Plugs  
(2) Filling Plug  
(3) Dipstick

(A) Oil level is acceptable within this range.

W1018004



#### ROPS (Center ROPS Type)

1. Remove the upper frame (1) from ROPS lower frame (2).
2. Disconnect the light connectors.
3. Remove the shields (3).
4. Remove the lower frames (2).

#### **(When reassembling)**

#### ■ **NOTE**


- **Do not firmly tighten all screws until most components are attached.**

Tightening torque	Lower frame mounting screw	260 to 304 N·m 26.5 to 31.0 kgf·m 192 to 224 ft·lbs
-------------------	----------------------------	---

- (1) Upper Frame  
(2) Lower Frame

(3) Shield

W1015588



**Release Holder and Clutch Lever**

1. Draw out the clutch release hub (6) and the release bearing (4) as a unit.
2. Remove the release fork setting screws (2).
3. Draw out the clutch lever (3) to remove the release fork (1).

**(When reassembling)**


- Make sure the direction of the release fork (1) is correct.
- Inject grease to the release hub (6).
- Be sure to set the snap pins (5).

Tightening torque	Release fork setting screws	23.5 to 27.5 N·m 2.4 to 2.8 kgf·m 17.4 to 20.3 ft·lbs
-------------------	-----------------------------	---

- |                   |                     |
|-------------------|---------------------|
| (1) Release Fork  | (4) Release Bearing |
| (2) Setting Screw | (5) Snap Pin        |
| (3) Clutch Lever  | (6) Release Hub     |

W1015118

**[3] SERVICING**




**Backlash between Clutch Disc Boss and Gear Shaft**

1. Mount the clutch disc to the gear shaft.
2. Hold the gear shaft so that it may not turn.
3. Rotate disc lightly and measure the displacement around the disc edge.
4. If the measurement exceeds the allowable limit, replace the disc.

Displacement around disc edge	Allowable limit	2.0 mm 0.079 in.
-------------------------------	-----------------	---------------------

W1016866




**Thrust Ball Bearing**

1. Remove the thrust ball bearing from release hub with a puller.
2. Check for abnormal wear on contact surface.
3. Hold bearing inner race and rotate outer race, while applying pressure to it.
4. If the bearing rotation is rough or noisy, replace the bearing.

**NOTE**

- Do not depress outer race, while installing thrust ball bearing

W1017028




**Clutch Disc Wear**

1. Measure the depth from clutch disc surface to the top of rivet at least 10 points with a depth gauge.
  2. If the depth is less than the allowable limit, replace the disc.
  3. If oil is sticking to clutch disc, or disc surface is carbonized, replace the disc.
- In this case, inspect transmission gear shaft oil seal, engine rear oil seal and other points for oil leakage.

Disc surface to rivet top (Depth)	Allowable limit	0.3 mm 0.012 in.
-----------------------------------	-----------------	---------------------

W1017162

**(5) Creep Gear Shift Lever**

The links are connected from the shift lever (3) to the shift fork (1) as shown in the left figure.

When the shift lever (3) is moved to the **A** side, the shift fork (1) is moved to the **A** side by means of the rod (4), sub-arm (5), and shift arm (2), thereby causing the creep shift.

When the shift lever (3) is moved to the **B** side, the shift fork (1) is moved to the **B** side to cause the normal shift.




- (1) Shift Fork
- (2) Shift Arm
- (3) Shift Lever
- (4) Rod
- (5) Sub-arm

**A : Creep Speed Shift**  
**B : Normal Speed Shift**

W1021330

## (2) Construction and Function of Components

### (A) Regulating Valve




The oil from the hydraulic pump for the power steering system flows to the GST circuit to set the pressure of the circuit. Other oil flows to the power steering circuit.

The oil from the power steering hydraulic pump (2) flows through the pressure reducing valve (5) to the GST circuit. When the oil is filled into the circuit, the pressure reducing valve (5) is closed to maintain the pressure in the GST system circuit to 2.45 MPa (25.0 kgf/cm<sup>2</sup>, 356 psi).

The oil from the power steering pump passes through the regulating valve (3) and check valve (4), and then it flows to power steering circuit. The regulating valve (3) is provided to maintain 2.94 MPa (30.0 kgf/cm<sup>2</sup>, 427 psi) at inlet pressure of the pressure reducing valve (5) except when the power steering is operated. Thereby getting 2.45 MPa (25.0 kgf/cm<sup>2</sup>, 356 psi) of the GST circuit pressure.

- (1) Regulating Valve Assembly     **A : To Power Steering Circuit**
- (2) Hydraulic Pump                    **B : To GST Circuit and PTO Clutch Valve**
- (3) Regulating Valve
- (4) Check Valve                         **C : From Power Steering Circuit**
- (5) Pressure Reducing Valve         **D : From Hydraulic Pump**

W1019304



- (1) Fixed Swashplate
- (2) Variable Swashplate
- (3) Charge Pump
- (4) Servo Piston
- (5) Feedback Rod
- (6) Control Shaft

- (7) Regulator Assembly
- (8) Port Block Cover
- (9) Cylinder Block (Pump)
- (10) Input Shaft (Pump Shaft)
- (11) Piston
- (12) Output Shaft (Motor Shaft)


- (13) Cylinder Block (Motor)
- (14) Bypass Pipe (Servo Pipe)
- (15) Case Relief Valve
- (16) Check and High Pressure Relief Valve
- (17) Charge Relief Valve

- A : Sectional View W-W**
- B : Sectional View X-X**
- C : Sectional View Y-Y**
- D : Sectional View Z-Z**

### [3] SHIFT LINKAGE MECHANISM

The shift linkage mechanism of "Front Wheel Drive Lever", refer to page 3-M6.







#### (1) Range Gear Shift Lever



The links are connected from the shift lever (3) to the shift fork (1) as shown in figure.

- |                            |                         |
|----------------------------|-------------------------|
| (1) Shift Fork             | <b>H : High Speed</b>   |
| (2) Shift Arm              | <b>M : Middle Speed</b> |
| (3) Range Gear Shift Lever | <b>L : Low Speed</b>    |
| (4) Rod                    |                         |
| (5) Sub-arm                |                         |

W1025045


Display on LCD Screen	Trouble Item	Probable Cause	Solution	Reference Page
	Solenoid 1 failure (At forward or neutral)	<ul style="list-style-type: none"> <li>• Solenoid output terminal's voltage is out of specification</li> <li>• Solenoid broken or short-circuited</li> <li>• Wiring harness broken or short-circuited</li> <li>• Grounding plate of solenoid is poor contact with chassis</li> </ul>	<ul style="list-style-type: none"> <li>• Able to travel at speeds other than 1, 7 and 8 (Forward) or 1 and 5 (Reverse)</li> <li>• Check the wiring connector of solenoid</li> <li>• Check a resistance between solenoid and GND</li> <li>• Replace GST valve</li> </ul>	—
	Solenoid 1 failure (At reverse)			9-S30, S32  3-S79
	Solenoid 2 failure (At forward or neutral)			—
	Solenoid 2 failure (At reverse)			9-S30, S32  3-S79
	Solenoid 3 failure (At forward or neutral)			—
	Solenoid 3 failure (At reverse)			9-S30, S32  3-S79

W1011845

**[4] HST**

Item		Factory Specification	Allowable Limit
Check and High Pressure Relief Valve Condition <ul style="list-style-type: none"> <li>• Engine Speed : Maximum</li> <li>• Oil Temperature : 40 to 60 °C 104 to 140 °F</li> <li>• Range Gear Shift Lever : H Position</li> <li>• HST Pedal : Depress Forward or Reverse with Brake</li> </ul>	Setting Pressure	33.3 to 36.3 MPa 340 to 370 kgf/cm <sup>2</sup> 4836 to 5262 psi	–
Charge Relief Valve Condition <ul style="list-style-type: none"> <li>• Engine Speed : Maximum</li> <li>• Oil Temperature : 40 to 60 °C 104 to 140 °F</li> <li>• HST Pedal : Neutral</li> </ul>	Setting Pressure	2.26 to 2.45 MPa 23 to 25 kgf/cm <sup>2</sup> 327 to 355 psi	–
Cruise Control Lever	Operating Force (Forward Direction)	54 to 64 N 5.5 to 6.5 kgf 12.1 to 14.3 lbs	–

W1277262



**Propeller Shaft**


1. Slide the propeller shaft cover (4) and (8) after removing the screws (7).
2. Tap out the spring pins (2), (6) and slide the couplings (1), (5) and then remove the propeller shaft with covers (4), (8).

**(When reassembling)**

- Apply grease to the splines of propeller shaft 1 (3).

- |                           |                           |
|---------------------------|---------------------------|
| (1) Coupling              | (5) Coupling              |
| (2) Spring Pin            | (6) Spring Pin            |
| (3) Propeller Shaft 1     | (7) Screws                |
| (4) Propeller Shaft Cover | (8) Propeller Shaft Cover |

W1015712



**Separating Engine and Clutch Housing**

1. Place the disassembling stand under the engine and clutch housing case.
2. Remove the fuel tank support mounting bolts.
3. Remove the engine and clutch housing mounting screws and nuts.
4. Separate the engine and clutch housing while lifting up the tank frame.

**(When reassembling)**




- Apply grease to the spline of clutch shaft.
- Apply liquid gasket (Three Bond 1211 or equivalent) to joint face of the flywheel housing and clutch housing.

Tightening torque	Engine and clutch housing mounting screw and nut	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 ft-lbs
	Engine and clutch housing mounting stud bolt	39.2 to 49.0 N·m 4.0 to 5.0 kgf·m 28.9 to 36.2 ft-lbs

W1015876

**(C) Transmission Case****■ NOTE**

- For the disassembling procedure from “Draining the Transmission Fluid” to “Step and Floor Seat”, refer to page 3-S18 to 3-S24.

**Rear Wheel**

- Place disassembling stand under the transmission case, and support it with a jack.
- Remove the rear wheels.
- After removing the rear wheels, support it at both sides of rear axle by stands.

**(When reassembling)**

Tightening torque	Rear wheel mounting screw and nut	215 N-m 22 kgf-m 160 ft-lbs
	Rear wheel mounting stud bolt	98.1 to 112.8 N-m 10.0 to 11.5 kgf-m 72.3 to 83.2 ft-lbs

W1021882

**ROPS, 3 Point Linkages, Hydraulic Cylinders and Others**

- Remove the top link.
- Remove the lift rods (2), lower links (6) and check chains (1) as a unit.
- Remove the ROPS lower frames (3).
- Remove the PTO shaft cover (5).
- Remove the drawbar frame (7).
- Disconnect the hydraulic cylinder hoses (8) and return hoses (10) at the rear hydraulic block (9).
- Remove the two pins and remove the hydraulic cylinders (4).
- Remove the main gear shift lever (11).
- Disconnect the brake rods (12).

**(When reassembling)**


- Apply grease to the lower link pins and hydraulic cylinder pins.

Tightening torque	Lift arm pin mounting nut	77.5 to 90.2 N-m 7.9 to 9.2 kgf-m 57.1 to 66.5 ft-lbs
	Lift arm pin lock nut	62.8 to 72.6 N-m 6.4 to 7.4 kgf-m 46.3 to 53.5 ft-lbs
	Drawbar frame mounting screw (M12)	77.5 to 90.2 N-m 7.9 to 9.2 kgf-m 57.1 to 66.5 ft-lbs
	Drawbar frame mounting screw (M14)	167 to 196 N-m 17.0 to 20.0 kgf-m 123 to 145 ft-lbs
	Hydraulic cylinder hose	34.3 to 48.1 N-m 3.5 to 4.9 kgf-m 25.3 to 35.4 ft-lbs
	ROPS lower frame mounting screw	167 to 196 N-m 17.0 to 20.0 kgf-m 123 to 145 ft-lbs

- |                             |                            |
|-----------------------------|----------------------------|
| (1) Check Chain             | (9) Rear Hydraulic Block   |
| (2) Lift Rod                | (10) Return Hose           |
| (3) ROPS Lower Frame        | (11) Main Gear Shift Lever |
| (4) Hydraulic Cylinder      | (12) Brake Rod             |
| (5) PTO Shaft Cover         | (13) Screw (M14 × 155)     |
| (6) Lower Link              | (14) Screw (M14 × 30)      |
| (7) Drawbar Frame           | <b>A : L3130, L3430</b>    |
| (8) Hydraulic Cylinder Hose | <b>B : L3830, L4630</b>    |

W1142329

KiSC issued 02, 2007 A

**(B) Synchronized Gear**


3TLABAB3P154A

**Clearance between Shift Fork and Shifter Groove**

1. Measure the width of shift fork.
2. Measure the shifter groove width, and calculate the clearance.
3. If the clearance exceeds the allowable limit, replace them.

Clearance between shift fork and shifter groove	Factory spec.	Shuttle F-R	0.20 to 0.45 mm 0.0079 to 0.0177 in.
		Other	0.15 to 0.40 mm 0.0059 to 0.0157 in.
	Allowable limit	Shuttle F-R	0.80 mm 0.031 in.
		Other	0.80 mm 0.031 in.

W1020704




3TLABAB3P155A

**Checking Contact between Coupling and Shifter**

1. Check to see if there is flaw or wear on the spline of the coupling and shifter, and the key groove on the coupling.
2. Engage the shifter with the coupling, and check that they slide smoothly.
3. Similarly, check that there is any flaw or wear on the gear splines.
4. If there is any defect, replace them.

W1020860




3TLABAB3P156A

**Flaw on Synchronizer Key and Spring**

1. Check the projection in the center of the synchronizer key for wear.
2. Check the spring for fatigue or wear on the area where the spring contacts with the keys.
3. If there is any defect, replace them.

W1021026



3TLABAB3P153A



**Side Clearance between Synchronizer Ring and Gear (In Contact)**

1. Press the synchronizer ring against the tapered portion of the gear, and measure the side clearance.
2. Apply thin film of red lead to the tapered portion, press the ring against it by hand, rub them together a few times, and check the contact.
3. Check the tooth surface and key grooves of the ring for wear.
4. If the side clearance exceeds the allowable limit or if there is any defect, replace the synchronizer ring.

Side clearance	Allowable limit	0.35 mm 0.0138 in.
----------------	-----------------	-----------------------

Contact condition of tapered portion	Allowable limit	More than 80 %
--------------------------------------	-----------------	----------------

W1026696



**Checking Clutch Pack Pressure**

1. Start the engine and warm up the transmission fluid, and then stop the engine.
2. Remove the clutch pack pressure checking port plug (PT 1/8) on the GST valve (2).
3. Install the adaptor “D” or GST valve adaptor to the checking port (1), and then install the threaded joint, cable and pressure gauge.
4. Start the engine and set the idling speed.
5. Disengage the main clutch and shift the GST lever to “1st” position, shuttle shift lever to “Forward” position.
6. Measure the pressure.
7. When the clutch pack pressure is not within factory specifications:  
Check the clutch valve and clutch pack.
8. Check the pressure changes while shifting the shuttle shift lever “Reverse” to “Forward” and shifting the GST lever from “Neutral” to “12th” or “8th”.
9. If the pressure does not change correctly, check the low-pass valve and proportional reducing valve.

■ **IMPORTANT**

- Do not engage the main clutch while checking.

Clutch pack pressure	Factory spec.	2.30 to 2.50 MPa 23.5 to 25.5 kgf/cm <sup>2</sup> 334 to 363 psi
Pressure changing while shifting the shuttle shift lever and main shift lever		It drops on 0.29 MPa (3 kgf/cm <sup>2</sup> , 43 psi) once, and it rises to factory specification quickly.

**Condition**

- Engine speed : Maximum
- Oil temperature : 40 to 60 °C  
104 to 140 °F
- Shifting : GST lever “Neutral” to “1st” to “12th” or “8th”  
Shuttle shift lever “Neutral” to “Forward” or “Reverse”

(1) Clutch Pack Pressure Checking Port (PT 1/8)      (2) GST Valve  
(3) Adaptor


W1032163

**(C) Others**

**Operating Pressure of PTO Clutch Valve**

1. See page 3-S17.


W1032841

**Counter Shaft**

- (1) Internal Snap Ring
- (2) Bearing
- (3) Needle Bearing
- (4) 24T Gear (4th)
- (5) External Snap Ring
- (6) Synchronizer Ring
- (7) Synchronizer Spring
- (8) Hub
- (9) Synchronizer Key
- (10) Shifter
- (11) 29T Gear (3rd)
- (12) Counter Shaft
- (13) 34T Gear (2nd)
- (14) Needle Bearing
- (15) 37T Gear (1st)
- (16) Bearing
- (17) Bearing Holder
- (18) Inner Synchronizer Ring
- (19) Center Ring
- (20) Outer Synchronizer Ring

W1050216

3TLABAB3P330A




1. Remove the internal snap ring (1) and remove both side of the bearings (2), (16).
2. Remove the gears on the counter shaft (12) and external snap rings (5).

**(When reassembling)**

- Reinstall the synchronizer keys (9) in the key grooves of the synchronizer rings (6) or (20) firmly.
- Be sure to install the synchronizer rings (18), (19), (20) with referring to page 3-S31.

W1050447

3TLABAB3P331A



**Transmission Bearing Holder**

1. Remove the transmission bearing holder mounting screws.
2. Jack up the bearing holder (7) by using the two jack screws until the taper roller bearing (9) can be removed.

■ **NOTE**

- Jack up the bearing holder while hitting the two shafts (2) (5) by copper hammer or soft hammer.

3. Jack up more and remove the transmission bearing holder (7).


**(When reassembling)**

- Tap in the transmission bearing holder with soft hammer until contact to transmission case, and then tighten the screws to specified torque.

Tightening torque	Transmission bearing holder mounting screw	48.1 to 55.9 N·m 4.9 to 5.7 kgf·m 35.5 to 41.2 ft·lbs
-------------------	--	---

- (1) Creep Gear Shaft (Creep Gear Type) (6) Front Wheel Drive Shaft  
 (2) Spiral Bevel Pinion Shaft (7) Transmission Bearing Holder  
 (3) Range Gear Shaft (8) Pinion Bearing Case  
 (4) Shift Fork Rod for Range Gear Shift (9) Taper Roller Bearing  
 (5) PTO Drive Shaft

W1054992





**Shaft Assemblies**

1. Remove the traveling speed sensor (1).
2. Remove the external snap ring (3) of the creep gear shaft (4) to the rear.
3. Take out the range gear shaft assembly (8) with the shift fork rod (9).
4. Take out the creep shaft assembly (4) and spiral bevel pinion shaft assembly (7) with shift fork (10) and shift fork rod (11).
5. Take out the PTO drive shaft assembly (6) and front wheel drive shaft assembly (5).

- (1) Traveling Speed Sensor (7) Spiral Bevel Pinion Shaft  
 (2) Creep Gear (8) Range Gear Shaft  
 (3) External Snap Ring (9) Shift Fork Rod  
 (4) Creep Gear Shaft (10) Shift Fork  
 (5) Front Wheel Drive Shaft (11) Shift Fork Rod  
 (6) PTO Drive Shaft

W1198652



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

**(3) Servicing****(A) Bearing, Gear and Shaft**

See page 3-S43.

**(B) Synchronizer Gear**


See page 3-S44.

**(C) PTO Clutch**

See page 3-S45.

**(D) Differential Gears**


See page 3-S46 to 3-S48.

**(E) GST Clutch****Clutch Disc Wear**

1. Measure the thickness of GST clutch disc with vernier calipers.
2. If the thickness is less than the allowable limit, replace it.

Thickness of GST clutch disc	Factory spec.	2.55 to 2.65 mm 0.100 to 0.104 in.
	Allowable limit	2.50 mm 0.098 in.


W1060836

**Steel Plate Wear**

1. Measure the thickness of GST steel plate with vernier calipers.
2. If the thickness is less than the allowable limit, replace it.

Thickness of GST steel plate	Factory spec.	1.55 to 1.65 mm 0.061 to 0.065 in.
	Allowable limit	1.50 mm 0.059 in.

W1061099


**Flatness of Piston and Steel Plate**

1. Place the part on a surface plate.
2. Check it unable to insert a feeler gauge (allowable limit size) underneath it at least four points.
3. If the gauge can be inserted, replace it.

Flatness of GST piston	Allowable limit	0.15 mm 0.006 in.
------------------------	-----------------	----------------------

Flatness of GST steel plate	Allowable limit	0.30 mm 0.012 in.
-----------------------------	-----------------	----------------------






W1061290

**Piston Return Spring Free Length**

1. Measure the free length of spring with vernier calipers.
2. If the measurement is less than the allowable limit, replace it.

Piston return spring free length	Factory spec.	19.9 to 20.1 mm 0.78 to 0.79 in.
	Allowable limit	18.0 mm 0.71 in.

W1060662



**Clutch Rod, Brake Pedal Rod and Electric Wiring**

1. Disconnect the brake pedal rod (5) and clutch rod (4).
2. Disconnect the wiring connectors for alternator (1), coolant temperature sensor (9), oil pressure switch (2), fuel unit (3), starter motor (6) and battery.
3. Remove the clamps and ground earth of wiring harness and collect wiring harness to the step or cabin.
4. Remove the clamps (7) of A/C hoses (8). (A/C model only.)

**(When reassembling)**

- Be sure to check and adjust the clutch and brake pedal free travel. (See page G-18, 24.)

- |                         |                                |
|-------------------------|--------------------------------|
| (1) Alternator          | (6) Starter Motor              |
| (2) Oil Pressure Switch | (7) Clamps                     |
| (3) Fuel Unit           | (8) A/C Hoses                  |
| (4) Clutch Rod          | (9) Coolant Temperature Sensor |
| (5) Brake Pedal Rod     |                                |

W1065311

**Air Conditioner Parts**

1. Remove the muffler (2).
2. Remove the air conditioner belt (4) and remove the compressor (1) mounting screw.
3. Remove the recovery tank (6) and window washer tank (7).
4. Disconnect the air cleaner hose (8).
5. Disconnect the recovery tank hose (5).
6. Disconnect the radiator upper hose (3).
7. Remove the oil cooler mounting screw.
8. Remove the battery (10).
9. Remove the battery stay mounting bolt.
10. Take out the compressor (1), condenser (11), receiver (12), hoses (13), battery stay (9) and etc. as a unit.

**(When reassembling)**

- After reassembling the compressor, be sure to adjust the air conditioner belt tension. (See page G-29.)

Tightening torque	Compressor mounting screw	24.5 to 29.4 N·m 2.5 to 3.0 kgf·m 18.1 to 21.7 ft·lbs
	Muffler mounting screw	31.4 to 37.2 N·m 3.2 to 3.8 kgf·m 23.1 to 27.5 ft·lbs

- |                          |                           |
|--------------------------|---------------------------|
| (1) Compressor           | (8) Air Cleaner Hose      |
| (2) Muffler              | (9) Battery Stay          |
| (3) Radiator Upper Hose  | (10) Battery              |
| (4) Air Conditioner Belt | (11) Condenser            |
| (5) Recovery Tank Hose   | (12) Receiver             |
| (6) Recovery Tank        | (13) Air Conditioner Hose |
| (7) Window Washer Tank   |                           |

W1248025



**Servo Piston Assembly**

1. Remove the servo piston under cover (1).
2. Remove the servo piston assembly mounting hex. head screw.
3. Push the piston from bottom side slightly and pull out the servo piston assembly (2).

**(When reassembling)**

**NOTE**

- Take care not to do damage the surface of servo piston.
- Do not disassemble the servo piston assembly, since it has been factory-adjusted.

Tightening torque	Servo piston and cover mounting hex. head screw	28 to 35 N-m 2.9 to 3.6 kgf-m 21 to 26 ft-lbs
-------------------	---	---

(1) Servo Piston Under Cover

(2) Servo Piston Assembly

W1019685




**1) Checking and Adjusting HST Neutral Position**

**CAUTION**

- Park the tractor on a flat place and keep all the levers at neutral position.
- Jack up the engine tractor and bring it in the 2WD mode.

1. Fit the HST mechanism first and then exterior components until the engine can get started.
2. Remove the hex. socket head plug from F and R ports.
3. Assemble adaptor 58 (07916-52391) and thread joint (07916-50341) with the gasket between them.
4. Install the assembled adaptor 58 and thread joint F and R ports.
5. Measure the low and high HST charge pressures. Place 5 MPa (50 kgf/cm<sup>2</sup>, 725 psi) gauges on the two spots in the photo.
6. Lift the entire steps, as shown below, so that the piston can be adjusted.
7. If any of the servo piston parts has been replaced, readjust the HST neutral position, referring to the dimension A of the servo piston adjusting screw (1).
8. Start the engine and measure the low and high charge pressures. Now adjust the piston neutral position so that the low-side pressure and the high-side one be the same. (Take the measurement with the engine rpm at MAX.) Move the servo valve lever (2) and watch the tires' movement to ensure the neutral positioning.
9. Finally lock the piston adjusting nut and fit the exterior components.



Charge pressure (Oil temperature 50 to 60 °C (122 to 140 °F))	Factory spec.	2.26 to 2.45 MPa 23 to 25 kgf/cm <sup>2</sup> 327 to 355 psi
---	---------------	--


**(Reference)**

- Dimension A : 26.3 mm (1.04 in.)


- (1) Adjusting Screw
- (2) Servo Valve Lever

- F : Forward Side
- R : Reverse Side

W1299424



3TMABAB3P027A



3TMABAB3P028A

**Differential Lock Shift Fork**


1. Tap out the left side spring pin (4).
2. Remove the cotter pin and take out the clevis pin (3).
3. Draw out the differential lock fork shaft (1) and take out the differential lock shift fork (2).

**(When reassembling)**

- Apply grease to the left and right oil seals on the transmission case.
- Insert the clevis pin (3) from the top and install the washer and cotter pin.
- Tap in the spring pin (4) so that its split portion **a** may face outward as shown in the figure.

- (1) Differential Lock Fork Shaft                      **a : Split Portion**
- (2) Differential Lock Shift Fork
- (3) Clevis Pin
- (4) Spring Pin

W10744620




3TLABAB3P150A

**PTO Shaft**

1. Remove the PTO shaft cover.
2. Remove the bearing case mounting screws, and draw out the PTO shaft (1) with bearing case (2).
3. Remove the internal snap ring (3).
4. Top out the PTO shaft (1) to the front.

**(When reassembling)**

- If the lock nut (6) was removed, replace it with a new one. After replacing, be sure to stake it firmly.
- Install the slinger (7) firmly.
- Apply grease to the oil seal (4) and install it, noting its direction.




3TLABAB3P339A

Tightening torque	Lock nut	147 to 196 N·m 15 to 20 kgf·m 108 to 145 ft·lbs
	Bearing case mounting screw	23.5 to 27.5 N·m 2.4 to 2.8 kgf·m 17.4 to 20.3 ft·lbs

- (1) PTO Shaft
- (2) Bearing Case
- (3) Internal Snap Ring
- (4) Oil Seal
- (5) Oil Seal Collar
- (6) Lock Nut
- (7) Slinger

W12700450



3TMABAB3P031A

**Differential Gear Assembly**

1. Remove the differential support, noting the number of left shims.
2. Take out the differential gear assembly, noting the number of right shims.

**(When reassembling)**

- Check the spiral bevel gear for wear or damage. If it is no longer serviceable, replace it. Then, also replace the spiral bevel pinion.
- Use same number of shims as before disassembling.

Tightening torque	Differential support mounting screw	48.1 to 55.9 N·m 4.9 to 5.7 kgf·m 35.4 to 41.2 ft·lbs
-------------------	-------------------------------------	---

W10750520

## 2. TIGHTENING TORQUES

Tightening torques of screws and nuts on the table below are especially specified.  
(For general use screws and nuts : See page G-10.)

Item	N-m	kgf-m	ft-lbs
Rear wheel mounting screw and nut	215	22	160
Rear wheel mounting stud bolt	98.1 to 112.8	10.0 to 11.5	72.3 to 83.2
ROPS lower frame mounting screw	166.7 to 196.1	17 to 20	123 to 144
Cabin mounting bolt and nut	124 to 147	13.0 to 15.0	91.0 to 108.0
Cabin mount bracket mounting screw	166.7 to 196.1	17 to 20	123 to 144
Rear axle case mounting screw (M10)	48.1 to 55.9	4.9 to 5.7	35.4 to 41.2
Rear axle case mounting nut (M10, 9T)	60.8 to 70.5	6.2 to 7.2	44.9 to 52.1
Rear axle case mounting screw (M12)	77.5 to 90.2	7.9 to 9.2	57.1 to 66.5
Rear axle case mounting stud bolt	24.5 to 31.4	2.5 to 3.2	18.1 to 23.1
Rear axle lock nut	196 to 245	20 to 25	145 to 181


W10127360

# 1. TROUBLESHOOTING

Symptom	Probable Cause	Solution	Reference Page
<b>Uneven Braking Force</b>	<ul style="list-style-type: none"> <li>• Brake pedal play unevenly adjusted</li> <li>• Brake disc worn</li> <li>• Cam plate warped</li> </ul>	Adjust Replace Replace	5-S4 5-S11 5-S11
<b>Brake Drags</b>	<ul style="list-style-type: none"> <li>• Brake pedal play too small</li> <li>• Ball holes of cam plate for uneven wear</li> <li>• Brake pedal return spring weaken or broken</li> <li>• Brake cam rusted</li> </ul>	Adjust Replace Replace Repair	5-S4 5-S11 5-S6 5-S11
<b>Poor Braking Force</b>	<ul style="list-style-type: none"> <li>• Brake pedal play excessive</li> <li>• Brake disc worn</li> <li>• Cam plate warped</li> <li>• Brake cam or lever damaged</li> <li>• Transmission fluid improper</li> </ul>	Adjust Replace Replace Replace Change	5-S4 5-S11 5-S11 5-S11 G-7, 8

W10143220

**(2) Servicing**




**Brake Cam Lever Movement**

1. Assemble the brake cam (1) and brake cam lever (2).
2. Move the brake cam lever by hand to check the movement.
3. If the movement is heavy, refine the brake cam lever or brake case with sandpaper.

(1) Brake Cam (2) Brake Cam Lever

W10144750




**Cam Plate Flatness**

1. Place the cam plate on the surface plate.
2. Measure the flatness of cam plate with a feeler gauge at four points on a diagonal line.
3. If the measurement exceed the allowable limit, replace it.

Cam Plate Flatness	Allowable limit	0.3 mm 0.012 in.
--------------------	-----------------	---------------------

W10145650




**Height of Cam Plate and Ball**

1. Measure the dimension of the cam plate with the ball installed.
2. If the measurement is less than the allowable limit, replace the cam plate and balls.
3. Inspect the ball holes of cam plate for uneven wear. If the uneven wear is found, replace it.

Height of cam plate and ball	Factory spec.	20.9 to 21.1 mm 0.823 to 0.831 in.
	Allowable limit	20.5 mm 0.807 in.

W10147220




**Brake Disc Wear**

1. Measure the brake disc thickness with vernier calipers.
2. If the measurement is less than the allowable limit, replace it.

Brake disc thickness	Factory spec.	4.6 to 4.8 mm 0.181 to 0.189 in.
	Allowable limit	4.2 mm 0.165 in.

W10148530



**Plate Wear**


1. Measure the plate thickness with vernier calipers.
2. If the measurement is less than the allowable limit, replace it.

Plate thickness	Factory spec.	2.54 to 2.66 mm 0.1000 to 0.1047 in.
	Allowable limit	2.1 mm 0.083 in.


W10149690

# 4. CHECKING, DISASSEMBLING AND SERVICING

## [1] CHECKING AND ADJUSTING



3TMABAB0P042A



3TLABAB0P029D

### Toe-in

1. Park the tractor on the flat place.
2. Inflate the tires to the specified pressure.
3. Turn steering wheel so front wheels are in the straight ahead position.
4. Lower the implement, lock the parking brake and stop the engine.
5. Measure distance between tire beads at front of tire, hub height.
6. Measure distance between tire beads at rear of tire, hub height.
7. Front distance should be 2 to 8 mm (0.08 to 0.32 in.) less than rear distance.
8. If the measurement is not within the factory specifications, adjust by changing the tie-rod length.

Toe-in (B - A)	Factory spec.	2 to 8 mm 0.08 to 0.32 in.
----------------	---------------	-------------------------------

### Adjusting

1. Detach the snap ring (3).
2. Loosen the tie-rod lock nut (1).
3. Turn the tie-rod joint (2) to adjust the rod length until the proper toe-in measurement is obtained.
4. Retighten the tie-rod lock nut (1).
5. Attach the snap ring (3).


Tightening torque	Tie-rod lock nut	166.7 to 196.1 N·m 17.0 to 20.0 kgf·m 123 to 145 ft-lbs
-------------------	------------------	---

### IMPORTANT

- A right and left tie-rod joint is adjusted to the same length.

- |                   |                                      |
|-------------------|--------------------------------------|
| (1) Tie-rod Nut   | (A) Wheel to Wheel Distance at front |
| (2) Tie-rod Joint | (B) Wheel to Wheel Distance at rear  |
| (3) Snap Ring     | (C) Front                            |

W10213280



3TMABAB6P008A


### Axial Sway of Front Wheel

1. Jack up the front side of tractor.
2. Set a dial gauge on the outside of rim.
3. Turn the wheel slowly and read the runout of rim.
4. If the measurement exceeds the factory specifications, check the bearing, rim and front wheel hub.

Axial sway of front wheel	Factory spec.	Less than 5.0 mm 0.197 in.
---------------------------	---------------	-------------------------------

W10120920

### [3] SERVICING



3TMABAB6P040A

#### Clearance between Differential Case (Differential Case Cover) and Differential Side Gear

1. Measure the differential side gear O.D..
2. Measure the differential case bore I.D. and calculate the clearance.
3. Measure the differential case cover bore I.D. and calculate the clearance.
4. If the clearance exceeds the allowable limit, replace faulty parts.

#### **(L3130, L3430, L3830 and L4630)**

Clearance between differential case (differential case cover) and differential side gear	Factory spec.	0.050 to 0.151 mm 0.00197 to 0.00594 in.
	Allowable limit	0.20 mm 0.0079 in.

Differential case bore I.D.	Factory spec.	32.000 to 32.062 mm 1.25984 to 1.26228 in.
Differential case cover bore I.D.	Factory spec.	32.000 to 32.025 mm 1.25984 to 1.26083 in.
Differential side gear O.D.	Factory spec.	31.911 to 31.950 mm 1.25634 to 1.25789 in.

#### **(L5030)**

Clearance between differential case (differential case cover) and differential side gear	Factory spec.	0.050 to 0.114 mm 0.00197 to 0.00449 in.
	Allowable limit	0.20 mm 0.0079 in.

Differential case bore I.D.	Factory spec.	32.000 to 32.025 mm 1.25984 to 1.26083 in.
Differential case cover bore I.D.	Factory spec.	32.000 to 32.025 mm 1.25984 to 1.26083 in.
Differential side gear O.D.	Factory spec.	31.911 to 31.950 mm 1.25634 to 1.25789 in.

W10182040


#### Clearance between Pinion Shaft and Differential Pinion

1. Measure the pinion shaft O.D.
2. Measure the differential pinion I.D. and calculate the clearance.
3. If the clearance exceeds the allowable limit, replace faulty parts.

Clearance between pinion shaft and differential pinion	Factory spec.	0.064 to 0.100 mm 0.00252 to 0.00394 in.
	Allowable limit	0.25 mm 0.0096 in.


Pinion shaft O.D.	Factory spec.	13.950 to 13.968 mm 0.54921 to 0.54992 in.
Differential pinion I.D.	Factory spec.	14.032 to 14.050 mm 0.55244 to 0.55315 in.

W10183690



3TMABAB6P041A

### 3. HYDRAULIC PUMP



The gear type hydraulic pump is adopted for these tractor. This pump is tandem type and it is composed two pair of gears, side plates, bushings and other components as shown in the figure.

The hydraulic pump pressure-fed the oil drawn from the transmission case through oil filter to power steering circuit and main hydraulic circuit.

- (1) Drive Gear 1
- (2) Coupling
- (3) Drive Gear 2
- (4) Driven Gear 1
- (5) Bushing
- (6) Bushing
- (7) Driven Gear 2
- (8) Side Plate

- A : From Power Steering Controller**
- B : From Transmission Case**
- C : To Power Steering Controller**
- D : To Main Hydraulic Circuit**

W1014335

### 3. TIGHTENING TORQUES


Tightening torques of screws, bolts and nuts on the table below are especially specified.  
(For general use screws, bolts and nuts : See page G-10.)

Item	N·m	kgf·m	ft-lbs
Regulator delivery pipe joint bolt	39.2 to 49.0	4.0 to 5.0	28.9 to 36.2
Power steering delivery pipe joint bolt (HST model)	39.2 to 49.0	4.0 to 5.0	28.9 to 36.2
Power steering delivery pipe joint bolt (Except HST model)	49.0 to 68.6	5.0 to 7.0	36.2 to 50.6
GST/PTO delivery pipe joint bolt	34.3 to 39.2	3.5 to 4.0	25.3 to 28.9
Regulator valve mounting screw	17.7 to 20.6	1.8 to 2.1	13.0 to 15.2
Hydraulic pump assembly mounting screw and nut	23.5 to 27.5	2.4 to 2.8	17.4 to 20.3
Pump cover mounting screw	39.2 to 44.1	4.0 to 4.5	28.9 to 32.5
Power steering hose retaining nut	24.5 to 29.4	2.5 to 3.0	18.1 to 21.7
Power steering delivery pipe retaining nut	49.0 to 58.8	5.0 to 6.0	36.2 to 43.4
Front wheel mounting nut	137.3	14.0	101.3
Tie-rod end slotted nut (L3130, L3430, L3830, L4630) (L5030)	39.2 to 45.1 156.9 to 176.5	4.0 to 4.6 16.0 to 18.0	28.9 to 33.3 115.7 to 130.2
Tie-rod joint lock nut	166.7 to 196.1	17.0 to 20.0	123.0 to 144.7
Steering wheel mounting nut	48.1 to 55.9	4.9 to 5.7	35.4 to 41.2
Tie-rod joint	166.7 to 196.1	17.0 to 20.0	123.0 to 144.7

W1012736

### [3] STEERING CYLINDER

#### (1) Disassembling and Assembling



#### Front Wheel, Cylinder Cover and Tie-rod

1. Place a disassembly stand under the engine and support it with a jack.
2. Remove the front wheel and cylinder cover (2).
3. Pull out the cotter pin and remove the tie-rod end slotted nut.
4. Disconnect the tie-rod (1).

#### (When reassembling)




- After tightening the tie-rod end slotted nut to the specified torque, install a cotter pin as shown in the figure.

Tightening torque	Front wheel mounting nut		137.3 N·m 14.0 kgf·m 101.3 ft-lbs
	Tie-rod end slotted nut	L3130	39.2 to 45.1 N·m
		L3430	4.0 to 4.6 kgf·m
		L3830 L4630	28.9 to 33.3 ft-lbs
	L5030	156.9 to 176.5 N·m 16.0 to 18.0 kgf·m 115.7 to 130.2 ft-lbs	

(1) Tie-rod

(2) Cylinder Cover

W1018390



#### Steering Cylinder

1. Disconnect the power steering hoses (1), (3) and remove the elbows.
2. Disconnect the tie-rod joint LH (4).
3. Remove the internal snap ring (2).
4. Take out the steering cylinder to the left.
5. Remove the head cover (7) and draw out the cylinder rod (6).

#### (When reassembling)

- Apply transmission fluid to the oil seal and O-ring.
- Apply liquid lock (Three Bond 1324B or equivalent) to the thread of tie-rod joint (4).

Tightening torque	Power steering hose retaining nut	24.5 to 29.4 N·m 2.5 to 3.0 kgf·m 18.1 to 21.7 ft-lbs
	Tie-rod joint	166.7 to 196.1 N·m 17.0 to 20.0 kgf·m 123.0 to 144.7 ft-lbs
	Tie-rod joint lock nut	166.7 to 196.1 N·m 17.0 to 20.0 kgf·m 123.0 to 144.7 ft-lbs

(1) Power Steering Hose RH

(5) Lock Nut

(2) Internal Snap Ring

(6) Cylinder Rod


(3) Power Steering Hose LH

(7) Head Cover

(4) Tie-rod Joint


W1018590

### [3] HYDROSTATIC TRANSMISSION



- |                                    |                           |   |   |
|------------------------------------|---------------------------|---|---|
| (1) Position Control Valve         | (3) Hydraulic Cylinder    | (5) Auxiliary Control Valve                               | (7) Hydraulic Pump 2                                |
| (2) Lowering Speed Adjusting Valve | (4) Cylinder Safety Valve | (6) Power Steering Controller (Refer to STEERING Section) | (8) Servo Regulator (Refer to TRANSMISSION Section) |

## ■ Draft Control Operation



- (1) Draft Control Rod  
(Connected to Top Link  
Bracket)
- (2) Draft Control Link 4
- (3) Draft Control Link 2
- (4) Draft Control Link 1
- (5) Arm 1
- (6) Draft Control Lever
- (7) Position Control Lever
- (8) Return Spring
- (9) Roller
- (10) Draft Cam
- (11) Arm 2
- (12) Feedback Rod (Connected  
to Lift Arm)
- (13) Draft Control Link 3

**a : Lift**  
**b : Down**

W1016549

When the draft control lever (6) is operated in the draft control operated range, the draft control lever shaft is rotated, causing the draft cam (10) to move toward the roller (9) installed on the draft control link 2 (3).

### (Reference)

- The sensitivity of the draft control can be adjusted by changing the gap between the draft cam (10) and the roller (9) by the draft control lever (6).

### ■ Movement of the Link Under Increased Load (a)

1. When the traction load is increased, the torsion bar is twisted according to the load, the draft control rod (1) and the draft cam (10) are pushed to come into contact with the roller (9).
2. Using the **A** portion as the fulcrum, the draft control link 2 (3) and the draft control link 1 (4) move to push the arm 1 (5).
3. At the same time, the arm 2 (11) is moved, the connected position control valve becomes the lift circuit, and the lift arm goes up.

### ■ Movement of the Link Under Decreased Load (b)

1. When the lift arm goes up, the traction load is decreased, and the draft control rod (1) is returned.
2. At the same time, the arm 2 (11), arm 1 (5), and draft control link 1 (4) are returned by the return spring (8).
3. The position control valve becomes the down circuit, and the lift arm is lowered.

### (Reference)

- The feedback rod (12) of the draft control is provided to maintain the position relation of the draft cam (10) and the roller (9) to certain state regardless of the height of the lift arm.


# 1. TROUBLESHOOTING

Symptom	Probable Cause	Solution	Reference Page
<b>Implement Does Not Rise (Not Noise)</b>	<ul style="list-style-type: none"> <li>Control linkage improperly adjusted</li> <li>Control linkage improperly assembled or damaged</li> <li>Position control valve malfunctioning</li> </ul>	Adjust Repair or replace  Repair or replace	8-S12 –  8-S15 to S17
<b>(Noise)</b>	<ul style="list-style-type: none"> <li>Relief valve spring weaken or broken</li> <li>Hydraulic piston O-ring, cylinder damaged</li> <li>Transmission fluid improper or insufficient</li> <li>Oil filter clogged</li> <li>Suction pipe loosen or broken</li> <li>Relief valve setting pressure too low</li> <li>Relief valve spring weaken or damaged</li> <li>Hydraulic pump malfunctioning</li> </ul>	Replace Replace  Change or replenish Replace Repair or replace Adjust Replace Repair pr replace	8-S11 8-S19  G-7, 8 G-16 – 8-S11 8-S11 8-S7 to S10
<b>Implement Does Not Reach Maximum Height</b>	<ul style="list-style-type: none"> <li>Position control feedback rod improperly adjusted</li> <li>Top link length improperly adjusted</li> <li>Hydraulic arm shaft, lift arm improperly assembled</li> <li>3 point link improperly set</li> </ul>	Adjust  Adjust Adjust Adjust	8-S12 – 8-S20 –
<b>Implement Does Not Lower</b>	<ul style="list-style-type: none"> <li>Position control valve malfunctioning               <ul style="list-style-type: none"> <li>- Spool damaged</li> <li>- Poppet 2, push rod improperly adjusted</li> </ul> </li> </ul>	Replace Adjust	8-S17 8-S17
<b>Implement Drops by Weight</b>	<ul style="list-style-type: none"> <li>Hydraulic cylinder worn or damaged</li> <li>Safety valve damaged</li> <li>Hydraulic piston and O-ring worn or damaged</li> <li>Lowering speed adjusting valve damaged</li> <li>Position control valve malfunctioning               <ul style="list-style-type: none"> <li>- Poppet 2 seat surface damaged</li> <li>- Poppet 2 seat sleeve O-ring damaged</li> </ul> </li> </ul>	Replace Replace Replace Replace  Replace Replace	8-S19 8-S16 8-S19 8-S15  8-S17 8-S17
<b>Implement Hunts (Moves Up and Down)</b>	<ul style="list-style-type: none"> <li>Position control valve malfunctioning               <ul style="list-style-type: none"> <li>- Poppet 2 seat surface damaged</li> <li>- Poppet 2 seat sleeve O-ring damaged</li> </ul> </li> <li>Poppet 2, push rod improperly adjusted</li> </ul>	Replace Replace Adjust	8-S17 8-S17 8-S17
<b>Oil Temperature Increases Rapidly</b>	<ul style="list-style-type: none"> <li>Relief valve operating               <ul style="list-style-type: none"> <li>- Relief valve malfunctioning</li> <li>- Hydraulic line is clogged</li> </ul> </li> <li>Hydraulic pump leak or damaged</li> <li>Oil leaks from valves</li> </ul>	Adjust or replace Clean or replace Repair or replace Repair or replace	8-S11 – 8-S7 to S10 –

W10143220

## [2] RELIEF VALVE

### (1) Checking and Adjusting



#### Relief Valve Setting Pressure Test

1. Remove the delivery pipe joint bolt from front hydraulic block.
2. Install the adaptor E. Then connect the cable and pressure gauge to adaptor E.
3. Start the engine and set at maximum speed.
4. Move the position control lever (1) all way up to operate the relief valve and read the gauge.
5. If the pressure is not within the factory specifications, remove the relief plug (2) of front hydraulic block (3) and adjust with the adjusting shims (4).
6. After the relief valve setting pressure test, reset the position control lever stopper firmly.

Relief valve setting pressure	Factory spec.	L3130	17.1 to 18.1 MPa
		L3430	174.4 to 184.6 kgf/cm <sup>2</sup>
		L3830	2480 to 2625 psi
		L4630	18.1 to 19.1 MPa
		L5030	184.6 to 194.8 kgf/cm <sup>2</sup>
			2625 to 2770 psi

#### Condition

- Engine speed.....Maximum
- Oil temperature.....40 to 60 °C  
104 to 140 °F


#### (Reference)

- Thickness of shims (4) : 0.1 mm (0.0039 in.)  
0.2 mm (0.0079 in.)  
0.4 mm (0.0157 in.)
- Pressure change per  
0.1 mm (0.0039 in.) shim : Approx. 264.8 kPa  
2.7 kgf/cm<sup>2</sup>  
38.4 psi

- |                            |                    |
|----------------------------|--------------------|
| (1) Position Control Lever | (4) Adjusting Shim |
| (2) Relief Plug            | (5) Washer         |
| (3) Front Hydraulic Block  |                    |

W1014806

### (2) Disassembling and Assembling



#### Relief Valve

1. Remove the plug (9), and draw out the spring (5) and the poppet (4).
2. Take out the valve seat (3).

#### (When reassembling)

- Take care not to damage the O-ring.

Tightening torque	Relief valve plug	49.0 to 68.6 N·m 5.0 to 7.0 kgf·m 36.2 to 50.6 ft·lbs
-------------------	-------------------	---

#### ■ IMPORTANT

- After disassembling and assembling the relief valve, be sure to adjust the relief valve setting pressure.


- |                           |                    |
|---------------------------|--------------------|
| (1) Front Hydraulic Block | (6) Adjusting Shim |
| (2) Cap                   | (7) Washer         |
| (3) Valve Seat            | (8) O-ring         |
| (4) Poppet                | (9) Plug           |
| (5) Spring                |                    |

W1015237

**(2) Servicing**



3TLABAB8P045B




3TAAAAB8P033A



3TLABAB8P050A



3TLABAB8P051A



3TAAAAB8P033A

**Hydraulic Cylinder Rod Bushing**

1. Visually inspect the DX bushings for signs of wear or damage. (The DX bushing tends to show concentrated wear.)
  2. If the DX bushing is worn beyond the alloy portion (**A**), replace it.
- (Reference)**

Hydraulic cylinder rod bushing	Alloy thickness ( <b>A</b> )	0.57 mm 0.0224 in.
--------------------------------	------------------------------	-----------------------

W1019611

**Hydraulic Cylinder I.D.**

1. Measure the hydraulic cylinder I.D. with a cylinder gauge.
2. If the cylinder I.D. exceed the allowable limit, replace the cylinder tube.

Hydraulic cylinder I.D.	Factory spec.	55.000 to 55.074 mm 2.16535 to 2.16827 in.
	Allowable limit	55.100 mm 2.16929 in.

W1019902

**Lift Arm Support Bushing**

1. Visually inspect the DX bushings for signs of wear or damage. (The DX bushing tends to show concentrated wear.)
  2. If the DX bushing is worn beyond the alloy portion (**A**), replace it.
- (Reference)**

Lift arm support bushing	Alloy thickness ( <b>A</b> )	0.57 mm 0.0224 in.
--------------------------	------------------------------	-----------------------

W1020043

## 2. ELECTRONIC CONTROL PANEL

### [1] SYSTEM OUTLINE AND ELECTRICAL CIRCUIT

#### (1) System Outline



- |  |                         |
|--|-------------------------|
| (1) Combination Switch                         | (4) Hazard Switch       |
| (2) Liquid Crystal Display (LCD)               | (5) Travel Speed Switch |
| (3) Electronic Instrument Panel (IntelliPanel) | (6) Display Mode Switch |

W1012906

The Electronic Instrument Panel (IntelliPanel) adopted in the L30 series tractors consists of an 8-bit Central Processing Unit (CPU<sup>\*1</sup>), sensors and input devices, memory devices such as RAM and ROM, and others. The CPU executes multiplex-communication<sup>\*2</sup> with ECU (Electronic Control Unit) and various sensors, switches and other related devices in order to give the functions that accurately and timely provide an operator with various information necessary for tractor operation. The contents include corrective procedure in case of an erroneous operation, precautions, and various alerts. If the tractor gets in trouble, a defective location, for example, is displayed with a message (sign) on the liquid crystal display (LCD<sup>\*3</sup>) or indicated with a monitor lamp.

The messages are displayed with segments, which gives approximately 130 patterns.

In the LCD, characters appear over reflected illumination, and are always back-lit by a small yellow lamp while the main switch is "ON".

#### \*1 CPU

This CPU is the core part of computers that controls the input/output devices to receive data, processes the data, and sends out the computing results.

The CPU comes in different types : 8 bits, 16 bits, 32 bits, etc., according to the number of bits as the unit of internal data processing. In general, the larger the number is, the higher the performance is.

#### \*2 Multiplex communication



In multiplex communication, just one transmission (signal) line is effectively used to send and receive signals for digital transmission. In data communication, the transmission capacity of the line and the capacity of signal transmission/reception are represented by the number of bits that can be transmitted or received for one second. When the capacity of the transmission line is extremely larger than the ability of the transmission/reception performed by a terminal device, signals from plural terminals can be transmitted by means of time-sharing and multiplexing of one transmission path.

The merits of multiplex communication are as follows :

1. It permits high-performance control that allows three units to share information from sensors and information required for control.
2. It provides the smaller number of wire harnesses.
3. It allows each control unit to independently control the connected devices if communication should fail for some reason and become impossible.

#### \*3 LCD

LCD is a displaying device that utilizes the characteristic of liquid crystal, in which the application of voltage triggers the molecules to change their orientations. The principle of indication is that when a voltage is applied on a liquid crystal sandwiched between two glass plates, the direction of molecules changes, with the resultant variation of the oscillatory direction of light that penetrates the liquid crystal. The set-up of a polarizing plate makes light go through or get blocked according to a change in voltage. Since the use of only the polarizing plate results in peculiar color, the film to counteract colored light is superimposed. However, the liquid crystal itself does not generate light, so it is back-lit by a fluorescent tube, for example, which makes the display easy to read in a dark space.



### ■ Emergency Connector : for GST Model

This is a device which compulsorily operates the shift solenoid when the tractor does not move due to the trouble of the GST system and moves the tractor.

#### (Situation for necessity of emergency connector)

- The defect in ECU
- The tractor does not move at all even if the shuttle lever and GST lever are operated though the trouble is repaired.

#### (Use of emergency connector)

1. Stop the engine.
2. Disconnect the ECU connector (3).
3. Remove the each cap from connectors (1), (2).
4. Connect the connector **A** and **B**.
5. Start the engine and move the tractor.

#### ■ NOTE

- When connecting the emergency connectors, the GST valve is set at 1st speed position even if the GST lever is at any position. And the stop and the start of the tractor is operated by shuttle lever.

#### ■ IMPORTANT

- Be sure to disconnect the ECU connector when using the emergency connector.

- (1) Emergency Connector A      (3) ECU Connector  
 (2) Emergency Connector B

W1031207

**(D) Glow Control**

The electronic meter incorporates the glow control which was external single parts so far, and controls it with CPU.

When the main switch is turned **ON**, the temperature of the coolant is detected with the coolant temperature sensor, and the time to supply current to the glow plug and the glow indicator lamp is controlled by CPU according to the detected temperature. And the supply current to the glow plug is stopped automatically when the preheating time is completed, and monitor lamp on the electronic meter panel is turned off. (Refer to “**STARTING SYSTEM**”.)

**CHARGING SYSTEM**

Symptom	Probable Cause	Solution	Reference Page
<b>Charging Lamp Does Not Light when Main Switch is Turned ON</b>	• Wiring harness disconnected or improperly connected (between main switch terminal and IntelliPanel, between IntelliPanel and alternator)	Repair or replace	–
	• Alternator defective	Repair or replace	9-S44
<b>Charging Lamp Does Not Go Off When Engine is Running</b>	• Wiring harness disconnected or improperly connected (between main switch terminal and alternator, between IntelliPanel and alternator)	Repair or replace	–
	• Alternator defective	Repair or replace	9-S44

W10135800

**LIGHTING SYSTEM**

<b>Head Light Does Not Light</b>	<ul style="list-style-type: none"> <li>• Fuse blown</li> <li>• Bulb blown</li> <li>• Wiring harness disconnected or improperly connected (between main switch terminal and combination switch <b>B1</b> terminal, between combination switch <b>1</b> terminal and head light, between combination switch <b>2</b> terminal and head light)</li> </ul>	Replace Replace Repair or replace	G-36 G-37 –
<b>Hazard Light Does Not Light</b>	<ul style="list-style-type: none"> <li>• Fuse blown</li> <li>• Bulb blown</li> <li>• Wiring harness disconnected or improperly connected</li> <li>• Flasher unit defective</li> <li>• Hazard switch defective</li> </ul>	Replace Replace Repair or replace  Replace Replace	G-36 G-37 –  9-S52 9-S51
<b>Position Light Does Not Light</b>	<ul style="list-style-type: none"> <li>• Fuse blown</li> <li>• Bulb blown</li> <li>• Wiring harness disconnected or improperly connected</li> <li>• Flasher unit defective</li> <li>• Position switch defective</li> </ul>	Replace Replace Repair or replace  Replace Replace	G-36 G-37 –  9-S52 9-S52

W10137180

**EASY CHECKER**

<b>Engine Oil Pressure Lamp Lights Up When Engine Is Running</b>	<ul style="list-style-type: none"> <li>• Engine oil pressure too low</li> <li>• Engine oil insufficient</li> <li>• Engine oil pressure switch defective</li> <li>• Short circuit between engine oil pressure switch lead and chassis</li> <li>• Circuit in panel defective</li> </ul>	Repair engine Replenish Replace Repair  Replace	– G-7, 8 9-S53 –  9-S23
<b>Engine Oil Pressure Lamp Does Not Light When Main Switch Is Turned ON and Engine Is Not Running</b>	<ul style="list-style-type: none"> <li>• Bulb blown</li> <li>• Engine oil pressure switch defective</li> <li>• Wiring harness disconnected or improperly connected (between IntelliPanel and engine oil pressure switch)</li> <li>• Circuit in panel defective</li> </ul>	Replace Replace Repair or replace  Replace	G-37 9-S53 –  9-S23

W10137180

## [2] ELECTRONIC INSTRUMENT PANEL (INTELLIPANEL)


### (1) Testing, Setting and Adjusting by Electronic Instrument Panel (IntelliPanel)

The following settings, adjustments and testing can be done by using the IntelliPanel.

- Testing : Check a voltage of various sensor or rotation of engine.
- Setting or Adjusting : Input the various data to IntelliPanel or ECU.
- Error Information : Confirm or clear the error information.

#### CAUTION

- To perform the testing of the IntelliPanel the operator must be seated on the tractor.



#### ■ Mode Selection

Select a corresponded mode by the following procedure, and do the test, the adjustment, the setting, and the confirmation respectively.

1. While holding down both the display mode switch (2) and the travel speed switch (3) at once, turn the main switch to **ON** or **START** position.
2. Mode selection display is indicated on the LCD.
3. Press the display mode switch (2) and the flashing part moves.
4. Hold down the display mode switch (2) for more than 2 seconds, and the buzzer rings and flashing symbol is selected.

#### ■ NOTE

- To save entire and review the conditions, usually hold down the Display Mode switch (2) until the buzzer rings.
- When a setting has been saved or an adjustment mode in any mode, be sure to turn off the main switch to end the procedure.


- (1) Liquid Crystal Display (LCD)  
 (2) Display Mode Switch  
 (3) Travel Speed Switch

- (A) Mode Selection Display for HST and Manual Transmission Model  
 (B) Mode Selection Display for GST Model

W1010725


Symbol	Mode	Necessary Situation
A	Test Mode	<ul style="list-style-type: none"> <li>• When the checking of sensor voltage or engine revolution is required.</li> </ul>
B	Traveling Speed Coefficient Input Mode	<ul style="list-style-type: none"> <li>• When the IntelliPanel is replaced or changed.</li> <li>• When the tire size is changed.</li> </ul>
C	PTO Coefficient Number Input Mode	<ul style="list-style-type: none"> <li>• When the IntelliPanel is replaced or changed.</li> </ul>
D	Error Information Reset Mode	<ul style="list-style-type: none"> <li>• When deleting the error information.</li> </ul>
E	GST Lever Sensor Fine-adjustment Mode	<ul style="list-style-type: none"> <li>• When the GST lever sensor is replaced or changed.</li> <li>• When the ECU is replaced or changed.</li> </ul>
F	GST Valve Fine-adjustment Mode	<ul style="list-style-type: none"> <li>• When the GST valve is replaced or changed.</li> <li>• When the ECU is replaced or changed.</li> </ul>
G	GST Shift Shock Fine-adjustment Mode	<ul style="list-style-type: none"> <li>• When the shifting shock is not comfortable.</li> </ul>
H	Error Information Display Mode	<ul style="list-style-type: none"> <li>• When checking the error history.</li> </ul>
I	Transmission Model Input Mode	<ul style="list-style-type: none"> <li>• When the IntelliPanel is replaced or changed.</li> <li>• When the HST range shift lever sensor is replaced or changed.</li> </ul>
J	Speed Unit Input Mode	<ul style="list-style-type: none"> <li>• When the IntelliPanel is replaced or changed.</li> </ul>

W1083952

**(B) Checking by Electronic Instrument Panel Connector****(A) Connector A (20P Connector) of Wire Harness Side**

No.	Color of wiring			Terminal Name		
	M/T*	GST	HST	M/T*	GST	HST
1	-			-		
2	Light green / Black			Display mode switch		
3	Blue			Travel speed switch		
4	Brown / Yellow			Low-beam		
5	Red / White	Black / Yellow		Main switch ON		HST pedal neutral switch
6	Black / Red			PTO switch output		
7	Black / Yellow			PTO switch input		
8	Black / Yellow			Shuttle switch		Clutch switch
9	Red / Black	Green / White		PTO speed change switch input	-	
10	-			-		
11	Blue			Oil switch		
12	-			-		
13	White / Red			Charge		
14	Violet			Trailer indicator		
15	-		Violet / White	-		Cruise switch
16	Blue / White	-		PTO speed change switch output	-	
17	Black / White			Main switch ST		
18	Black / White			Turn signal switch RH		
19	Green / Blue			Turn signal switch LH		
20	Black / Red			Glow relay		

\*M/T : Manual Transmission




**Oil Temperature Sensor Resistance**

1. Measure the resistance between the sensor terminals.
2. It is OK if the resistance value approximates to the value shown in the table below.
3. If there exists a large difference, replace the sensor.

Resistance	Reference value	16.4 to 21.1 kΩ at -20°C (-4°F) 1.04 to 1.23 kΩ at 40°C (104°F) 0.15 to 0.16 kΩ at 100°C (212°F)
------------	-----------------	--

(1) Oil Temperature Sensor

W1042316




**Proportional Reducing Valve Resistance**

1. Measure the resistance between the valve terminals.
2. It is OK if the resistance comes to have shown in the table below.

Resistance	Reference value	8 to 9 Ω
------------	-----------------	----------

W1042539




**Shift Solenoid Resistance**






1. Measure the resistance between each connector terminal and each valve body.
2. It is OK if the resistance comes to have shown in the table below.

Measuring point		Resistance
Solenoid	Connector terminal	
(1) Solenoid 1	1	11 to 15 Ω
(2) Solenoid 2	2	
(3) Solenoid 3	3	
(4) Solenoid 4	4	
(5) Solenoid 5 (Sub-range)	5	
(6) Solenoid 6 (Main range)	6	

A : Connector of Solenoid Side

W1042693





**Commutator and Mica**

1. Check the contact face of the commutator for wear, and grind the commutator with emery paper if it is slightly worn.
2. Measure the commutator O.D. with an outside micrometer at several points.
3. If the minimum O.D. is less than the allowable limit, replace the armature.
4. If the difference of the O.D.'s exceeds the allowable limit, correct the commutator on a lathe to the factory specification.
5. Measure the mica undercut.
6. If the undercut is less than the allowable limit, correct it with a saw blade and chamfer the segment edges.

Commutator O.D.	Factory spec.	30.0 mm 1.181 in.
	Allowable limit	29.0 mm 1.142 in.

Difference of O.D.'s	Factory spec.	Less than 0.02 mm 0.0008 in.
	Allowable limit	0.05 mm 0.0020 in.

Mica undercut	Factory spec.	0.50 to 0.80 mm 0.0197 to 0.0315 in.
	Allowable limit	0.20 mm 0.0079 in.

- (1) Segment
  - (2) Undercut
  - (3) Mica
- (a) Correct
  - (b) Incorrect

W10170920

**Brush Wear**

1. If the contact face of the brush is dirty or dusty, clean it with emery paper.
2. Measure the brush length **A** with vernier calipers.
3. If the length is less than the allowable limit, replace the yoke assembly and brush holder.

Brush length <b>A</b>	Factory spec.	15.0 mm 0.591 in.
	Allowable limit	11.0 mm 0.433 in.

W10175440

**Brush Holder**

1. Check the continuity across the brush holder and the holder support with an ohmmeter.
2. If there is continuity, replace the brush holder.

Resistance	Brush holder – Holder support	Infinity
------------	----------------------------------	----------

W10176720




**Position Switch**

1. Remove the meter panel and disconnect the connector from position switch (1) after disconnect the battery negative code.
2. Remove the position switch (1).
3. Perform the following checking.

(1) Position Switch

W1046485




**1) Connector Voltage**

1. Connect the battery negative code, then measure the voltage between the terminal **a** and chassis.
2. If the voltage differ from the battery voltage, the wiring harness is faulty.

Voltage	Terminal <b>a</b> – Chassis	Approx. battery voltage
---------	-----------------------------	-------------------------

(1) Connector

W1046902




**2) Position Switch Continuity**

1. Measure the resistance with ohmmeter between the terminal **a** and terminal **c**, and between the terminal **d** and terminal **e**.
2. If the measurement is not following below, the position switch or the bulb are faulty.

Resistance (Switch at <b>OFF</b> )	Terminal <b>a</b> – Terminal <b>c</b>	Infinity
Resistance (Switch at <b>ON</b> )	Terminal <b>a</b> – Terminal <b>c</b>	0 Ω
Resistance (Bulb)	Terminal <b>d</b> – Terminal <b>e</b>	Approx. 13 Ω

- |                               |                                  |
|-------------------------------|----------------------------------|
| (1) Position Switch Connector | (4) Terminal <b>c</b>            |
| (2) Terminal <b>a</b>         | (5) Terminal <b>e</b>            |
| (3) Terminal <b>d</b>         | (6) Terminal <b>b</b> (not used) |

W1047271



**Flasher Unit**


1. Disconnect the connector from the flasher unit.
2. Turn the main switch at **ON** position.
3. Measure the voltage between the terminal **12** and chassis.
4. If the voltage differ from the battery voltage, the wiring harness is faulty.

Voltage	Terminal <b>12</b> – Chassis	Approx. battery voltage
---------	------------------------------	-------------------------

W1047788

## [2] SYSTEM CONTROL

### (1) A/C Model



- |                               |  |  |  |
|-------------------------------|--|--|--|
| (1) Air Mode Lever            | (7) Recirculated Air                         | (12) Air Outlet Door D3<br>(Mode Door) | <b>(A) Control Plate</b>                         |
| (2) Blow Switch               | (8) Blower                                   | (13) DEFOGGER                          | <b>(B) Air Selection Lever</b>                   |
| (3) Air Conditioner Switch    | (9) Evaporator                               | (14) FACE                              | <b>(C) Block Diagram of Air Flow<br/>Passage</b> |
| (4) Temperature Control Lever | (10) Temperature Door D2<br>(Air Mixed Door) | (15) DEF and FACE                      | <b>O1 :Front air outlet</b>                      |
| (5) Fresh Air                 | (11) Heater Core                             | (16) Air Selection Lever               | <b>O2 :Side air outlet</b>                       |

#### 1) Selection of recirculated air (7) or fresh air (5) is done with door D1.

##### ■ RECIRC

By setting the air selection lever (16) in rear control panel to **RECIRC** position, door **D1** (6) shuts the fresh air inlet port. Air inside the cabin is recirculated.

##### ■ FRESH

By moving the air selection lever (16) to **FRESH** position, door **D1** opens the fresh air inlet port. Outside air comes into cabin.

#### 2) Temperature control of outlet air is done with door D2.

##### ■ COOL

By setting the temperature control lever (4) in control panel to **COOL** position, door **D2** (10) is moved to close water valve. The air flows to door **D3** (12) side without passing the heater core.

##### ■ WARM

By moving the temperature lever to **WARM** position door **D2** (10) is moved to open water valve. The air flows to door **D3** (12) side passing through the heater core.

#### 3) Outlet air flow is controlled by door D3.

Moving the air mode lever (1) opens and shuts door **D3** and establishes the air passage according to the lever position.

##### ■ DEF + FACE

By moving the mode lever to **DEF + FACE** position, the door **D3** (12) is moved to establish the air passages to outlets **O1** and **O2**. Air comes out from both outlets.

##### ■ DEF

Moving the mode lever to **DEF** position, door **D3** is moved to set up the air passage to outlet **O1**. Air comes out from outlet **O1**.

**WINDSHIELD WIPER**


Symptom	Probable Cause	Solution	Reference Page
<b>Windshield Wiper Does Not Operate</b>	<ul style="list-style-type: none"> <li>Wiring defective</li> <li>Fuse blown (Short-circuit, burnt component inside motor or other part for operation)</li> <li>Wiper motor defective (Broken armature, worn motor brush or seized motor shaft)</li> <li>Wiper switch defective</li> <li>Foreign material interrupts movement of link mechanism</li> <li>Wiper arm seized or rusted</li> </ul>	Check and repair Correct cause and replace Replace  Replace Repair  Lubricate or replace	– G-36  10-S37  10-S36 10-S39, S40 10-S42
<b>Windshield Wiper Operating Speed Is Too Low</b>	<ul style="list-style-type: none"> <li>Wiper motor defective (Short-circuit of motor armature, worn motor brush or seized motor shaft)</li> <li>Low battery voltage</li> <li>Humming occurs on motor in arm operating cycle due to seized arm shaft</li> <li>Wiper switch contact improper</li> </ul>	Replace  Recharge or replace Lubricate or replace  Replace	10-S42  G-25 – 10-S36
<b>Windshield Wiper Does Not Stop Correctly</b>	<ul style="list-style-type: none"> <li>Wiper motor defective (Contaminated auto-return contacts or improper contact due to foreign matter)</li> </ul>	Replace	10-S42

W1066515

**WASHER MOTOR**

<b>Washer Motor Does Not Operate</b>	<ul style="list-style-type: none"> <li>Fuse blown</li> <li>Washer switch defective</li> <li>Washer motor defective</li> <li>Wiring defective</li> </ul>	Correct cause and replace Replace Replace Repair	– 10-S36 – –
<b>Washer Motor Operate but Washer Fluid Is Not Ejected</b>	<ul style="list-style-type: none"> <li>No washer fluid</li> <li>Clogged washer nozzle</li> </ul>	Replenish Clean or replace	– –

W1011118




### Moisture Entered in the Cycle

1. Symptoms seen in refrigerating cycle
  - The air conditioner operates normally at the beginning, but over time, **LO** pressure side (1) pressure is **vacuum** and **HI** pressure side (2) is low pressure.
  - LO** pressure side (1) : Vacuum
  - HI** pressure side (2) : 0.69 to 0.98 MPa  
(7 to 10 kgf/cm<sup>2</sup>, 99.6 to 142.2 psi)
2. Probable cause
  - The moisture in the refrigerating cycle freezes in the expansion valve orifice and causes temporary blocking. After a time, the ice melts and condition returns to normal.
3. Solution
  - Replace receiver.
  - Remove moisture in cycle by means of repeated evacuation. (See page 10-S17.)
  - Recharge new refrigerant to the proper level. (See page 10-S21.)

(1) LO Pressure Side

(2) HI Pressure Side

W1017013



### Refrigerant Fails to Circulate

1. Symptoms seen in refrigerating cycle
  - **LO** pressure side (1) pressure is **vacuum** and, **HI** pressure side (2) is **low** pressure.
  - LO** pressure side (1) : Vacuum
  - HI** pressure side (2) : 0.49 to 0.59 MPa  
(5 to 6 kgf/cm<sup>2</sup>, 71.2 to 85.3 psi)
  - Frost or dew formed on piping at front and rear sides of expansion valve or receiver.
2. Probable cause
  - Refrigerant flow obstructed by moisture or dirt in the refrigerating cycle freezing or sticking on the expansion valve orifice.
3. Solution
 





Allow to stand for same time and then resume operation to decide whether the plugging is due to moisture or dirt.

  - If caused by moisture, correct by referring to instructions in previous.
  - If caused by dirt, remove the expansion valve and blow out the dirt with compressed air.
  - If unable to remove the dirt, replace the expansion valve. Replace the receiver. Evacuate and charge in proper amount of new refrigerant. (See page 10-S18 to S20.)
  - If caused by gas leakage in heat sensitizing tube, replace the expansion valve.

(1) LO Pressure Side

(2) HI Pressure Side

W1017346



### Electric Connector for GST

1. Disconnect the ECU connector (1).
2. Disconnect the GST lever sensor connector (2).
3. Remove the GST valve cover.
4. Disconnect the pressure switch connector (4), proportional reducing valve connector (5), solenoid valve connector (6), oil temperature sensor connector (8) and ground cables (7).

- |  |   |
|--|---|
| (1) ECU Connector                      | (5) Proportional Reducing Valve Connector |
| (2) GST Lever Sensor Connector         | (6) Solenoid Valve Connector              |
| (3) Wiring Harness of GST Lever Sensor | (7) Ground Cable                          |
| (4) Pressure Switch Connector          | (8) Oil Temperature Sensor Connector      |



W1062110

### Electric Connector for HST

1. Remove the lowering speed adjusting knob (4).
2. Disconnect the differential lock rod (2).
3. Disconnect the range gear shift lever sensor connector (3).
4. Disconnect the cruise switch connector (1).
5. Disconnect the HST pedal neutral switch connector (5).
6. Disconnect the ground earth **(a)**.

- |   |  |
|---|--|
| (1) Cruise Switch Connector                 | (4) Lowering Speed Adjusting Knob      |
| (2) Differential Lock Pedal                 | (5) HST Pedal Neutral Switch Connector |
| (3) Range Gear Shift Lever Sensor Connector |  |
- (a) Ground earth is connected here**

W1062242



**Pressure Switch**

**1) HI Pressure Side**

1. Connect the manifold gauge (6) to compressor as following procedure.  
Close the **HI** and **LO** pressure valves (5), (7) of manifold gauge tightly, and connect the charging hoses (red and blue) (1), (4) to the respective compressor service valves. (Refer to **HANDLING OF SERVICE TOOLS** : See page 10-S9.)

■ **NOTE**

- **Be sure to drive out the air in the charging hoses at the manifold gauge connection end by utilizing the refrigerant pressure in the refrigerant cycle.**
2. Start the engine and set at approx. 1500 min<sup>-1</sup> (rpm). Turn on the A/C switch, then set the blower switch to **HI** position.
  3. Raise pressure on the **HI** pressure side of the refrigerant cycle by covering the condenser front with a corrugated carboard, and the pressure switch (9) is activated and the compressor magnetic clutch is turned off. At this time, read the **HI** pressure gauge of the manifold gauge. If this pressure reading differs largely with the setting pressure, replace the pressure switch with a new one.

Setting pressure	Factory spec.	Pressure switch <b>OFF</b>	More than approx. 3.14 MPa 32 kgf/cm <sup>2</sup> 455 psi
------------------	---------------	-------------------------------	--

**2) LO Pressure Side**

1. Disconnect **2P** connector of pressure switch.
2. Measure the resistance with an ohmmeter across the connector terminals.
3. If 0 ohm is not indicated at normal condition, there is no refrigerant in the refrigerating cycle because gas leaks or pressure switch is defective.

**(Reference)**

Setting pressure	Factory spec.	Pressure switch <b>OFF</b>	Less than approx. 0.196 MPa 2.0 kgf/cm <sup>2</sup> 28.4 psi
------------------	---------------	-------------------------------	---

- The resistance of pressure switch is 0 ohm in normal running, but is becomes infinity if the pressure is abnormal (out of factory spec.). Because the pressure switch starts to work.

- |   |                              |
|---|------------------------------|
| (1) Charging Hose (Red)                           | (5) <b>HI</b> Pressure Valve |
| (2) <b>HI</b> (High Pressure Side) Charging Valve | (6) Manifold Gauge           |
| (3) <b>LO</b> (Low Pressure Side) Charging Valve  | (7) <b>LO</b> Pressure Valve |
| (4) Charging Hose (Blue)                          | (8) Air Conditioner Unit     |
|   | (9) Pressure Switch          |


W1020509

**Defogger Switch**

1. Remove the outer roof and disconnect the defogger switch connector (1).
2. Perform the following checkings **1)** and **2)**.

- |                               |                     |
|-------------------------------|---------------------|
| (1) Defogger Switch Connector | (2) Defogger Switch |
|-------------------------------|---------------------|

W1015868



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL