

WSM

WORKSHOP MANUAL
UTILITY VEHICLE

RTV900

Kubota

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

SPECIFICATIONS


| Model | | General Purpose | Worksite | Turf | Recreational | |
|-------------------|--|---|------------------------------|-----------------------------|------------------------------|---------------------------|
| Engine | Maker | KUBOTA | | | | |
| | Model | D902-E-UV / D902-E2-UV | | | | |
| | Type | Indirect Injection. Vertical, water-cooled, 4-cycle diesel | | | | |
| | Number of cylinders | 3 | | | | |
| | Bore and stroke | 72 × 73.6 mm (2.83 × 2.90 in.) | | | | |
| | Total displacement | 898 cm ³ (54.8 cu.in.) | | | | |
| | Engine gross power (DIN) | 16.1 kW (21.6 HP) | | | | |
| | Rated revolution | 53.3 r/s [3200 min ⁻¹ (rpm)] | | | | |
| | Maximum torque | 54.7 N·m (5.6 kgf·m, 40.5 lbf·ft) / 30.0 to 36.7 r/s [1800 to 2200 min ⁻¹ (rpm)] | | | | |
| | Battery | 12 V, CCA : 535 A, RC : 80 min. | | | | |
| | Starting system | Electric starting with cell starter, 12 V, 1.2 kW | | | | |
| | Lubrication system | Forced lubrication by trochoidal pump | | | | |
| | Cooling system | Pressurized radiator, forced circulation with water pump | | | | |
| | Fuel | Diesel fuel No. 2-D [above -10 °C (14 °F)], Diesel fuel No. 1 [below -10 °C (14 °F)] | | | | |
| Capacities | Fuel tank | 28 L (7.4 U.S.gals, 6.2 Imp.gals) | | | | |
| | Engine crankcase (with filter) | 3.1 L (3.3 U.S.qts, 2.7 Imp.qts) | | | | |
| | Engine coolant (with recovery tank) | 4.0 L (4.2 U.S.qts, 3.5 Imp.qts) | | | | |
| | Transmission case | 10.0 L (2.6 U.S.gals, 2.2 Imp.gals) | | | | |
| | Front axle case | 0.6 L (0.63 U.S.qts, 0.52 Imp.qts) | | | | |
| | Knuckle case | Ref. 0.1 L (0.10 U.S.qts, 0.09 Imp.qts) | | | | |
| | Brake fluid (reservoir and lines) | 0.4 L (0.42 U.S.qts, 0.35 Imp.qts) | | | | |
| | Hydraulic lift oil (Hydraulic dumping system model) | 8.0 L (2.1 U.S.gals, 1.8 Imp.gals) | | | | |
| | Hydraulic lift oil (Hydraulic PTO model) | 7.0 L (1.8 U.S.gals, 1.5 Imp.gals) | | | | |
| | Power steering oil | 5.9 L (1.6 U.S.gals, 1.3 Imp.gals) | | | | |
| Travelling system | Tires | Front | 25 × 10 – 12 Knobby, 6PLY | 25 × 10 – 12 HDWS, 6PLY | 23 × 10.5 – 12 Turf, 4PLY | 25 × 10 – 12 ATV, 6PLY |
| | | Rear | 25 × 10 – 12 Knobby, 6PLY | 25 × 10 – 12 HKDWS, 6PLY | 23 × 10.5 – 12 Turf, 4PLY | 25 × 11 – 12 ATV, 6PLY |
| | Steering | Hydrostatic power | | | | |
| | Transmission | Continuously variable hydro transmission (VHT) | | | | |
| | Wheels and drive | 4 wheels, rear 2WD or 4WD | | | | |
| | Gear selection | Hi-Med-Lo range, forward, neutral, reverse | | | | |
| | Differential lock | Standard; foot operated with mechanical holder | | | | |
| | Brake | Front / Rear | Wet disc type | | | |
| | | Parking brake | Rear wheel, hand lever | | | |
| | Turning diameter | 7.5 m (24.6 feet) | | | | |
| Suspension | Front | Independent, macpherson strut-type | | | | |
| | Rear | Semi-independent, devion axle with leaf springs and shock absorber | | | | |

NOTE: * Manufacture's estimate

The company reserves the right to change the specifications without notice.

W1028103

[2] BATTERY




- Take care not to confuse positive and negative terminal posts.
- When removing battery cables, disconnect negative cable first. When installing battery cables, check for polarity and connect positive cable first.
- Do not install any battery with capacity other than is specified (Ah).
- After connecting cables to battery terminal posts, apply high temperature grease to them and securely install terminal covers on them.
- Do not allow dirt and dust to collect on battery.

⚠ CAUTION

- **Take care not to let battery liquid spill on your skin and clothes. If contaminated, wash it off with water immediately.**
- **Before recharging the battery, remove it from the machine.**
- **Before recharging, remove cell caps.**
- **Do recharging in a well-ventilated place where there is no open flame nearby, as hydrogen gas and oxygen are formed.**

W10118160

[3] FUSE




- Use fuses with specified capacity. Neither too large or small capacity fuse is acceptable.
- Never use steel or copper wire in place of fuse.
- Do not install working light, radio set, etc. on machine which is not provided with reserve power supply.
- Do not install accessories if fuse capacity of reserve power supply is exceeded.

(1) Fuse

(2) Fusible Link

W10120920

[4] CONNECTOR



- For connector with lock, push lock to separate.

(A) Push

W10122110

[2] FROM EVERY 600 HOURS TO EVERY 4 YEARS


■ IMPORTANT

- *1 : Air cleaner should be cleaned more often in dusty conditions than in normal conditions.
- *2 : Every year or every 6 times of cleaning.
- *3 : Replace only if necessary.
- *4 : When the battery is used for less than 100 hours per year, check the fluid level annually.
- The items listed below (@ marked) are registered as emission related critical parts by KUBOTA in the U.S.EPA nonroad emission regulation. As the engine owner, you are responsible for the performance of the required maintenance on the engine according to the following instruction.

(To be continued)

| No. | Item | Period | Indication on hour meter | | | | | | | After purchase | | | Impor- tant | Refer- ence page | |
|-----|---|---------|--------------------------|-----|-----|-----|-----|------|------|----------------|---------|---------|----------------|------------------------|------|
| | | | 600 | 650 | 700 | 750 | 800 | 1500 | 3000 | 1 year | 2 years | 4 years | | | |
| 1 | Engine start system | Check | ☆ | ☆ | ☆ | ☆ | ☆ | | | | | | | | G-30 |
| 2 | Greasing | Apply | ☆ | ☆ | ☆ | ☆ | ☆ | | | | | | | | G-31 |
| 3 | Engine oil | Change | ☆ | | ☆ | | ☆ | | | | | | | | G-23 |
| 4 | Muffler | Clean | ☆ | | ☆ | | ☆ | | | | | | | | G-25 |
| 5 | Wheel screw torque | Check | ☆ | | ☆ | | ☆ | | | | | | | | G-25 |
| 6 | Spark arrester | Clean | ☆ | | ☆ | | ☆ | | | | | | | | G-33 |
| 7 | Battery condition | Check | ☆ | | ☆ | | ☆ | | | | | | *4 | | G-35 |
| 8 | Fan belt | Adjust | ☆ | | ☆ | | ☆ | | | | | | | | G-36 |
| 9 | VHT neutral spring | Check | ☆ | | ☆ | | ☆ | | | | | | | | G-32 |
| 10 | Toe-in | Adjust | ☆ | | ☆ | | ☆ | | | | | | | | G-38 |
| 11 | Fuel filter element | Check | ☆ | | ☆ | | ☆ | | | | | | | @ | G-37 |
| | | Replace | | | | | | | | | | | | | - |
| 12 | Air cleaner element | Clean | ☆ | | ☆ | | ☆ | | | ☆ | | | *1 | @ | G-34 |
| | | Replace | | | | | | | | | | | *2 | | - |
| 13 | Fuel line | Check | ☆ | | ☆ | | ☆ | | | | | | | @ | G-24 |
| | | Replace | | | | | | | | | ☆ | | *3 | | - |
| 14 | Engine oil filter | Replace | ☆ | | | | ☆ | | | | | | | | G-24 |
| 15 | Transmission oil filter (HST) (Yellow color) | Replace | ☆ | | | | ☆ | | | | | | | | G-27 |
| 16 | Transmission oil filter (Suction) (Orange color) | Replace | ☆ | | | | ☆ | | | | | | | | G-27 |
| 17 | Transmission oil | Change | ☆ | | | | ☆ | | | | | | | | G-26 |
| 18 | Brake pedal | Adjust | ☆ | | | | ☆ | | | | | | | | G-28 |
| 19 | Parking brake lever | Adjust | ☆ | | | | ☆ | | | | | | | | G-28 |
| 20 | Brake light switch | Check | ☆ | | | | ☆ | | | | | | | | G-29 |
| 21 | Front brake case | Check | ☆ | | | | ☆ | | | | | | | | G-29 |
| 22 | Power steering oil | Change | ☆ | | | | ☆ | | | | | | | | G-41 |
| 23 | Hydraulic lift oil | Change | ☆ | | | | ☆ | | | | | | | | G-40 |

W10402640



Cleaning Muffler

This vehicle is equipped with a spark arrester muffler approved by the U.S. Forest Service. It requires periodic maintenance to ensure its effectiveness.

CAUTION

- Before touching any part of an exhaust system, be absolutely sure that it has sufficient time to cool.
- Always wear safety goggles and a (face) mask.
- Keep head and face away from possible drainage.
- The particulate matter contained in the muffler contains chemicals that are harmful to people, animals and marine life.
- Be sure to stop the engine before removing the drain plug.

■ Cleaning Procedure

The first interval for clean out will be after approx. 50 hours of operation.


1. Shut the vehicle engine off and then remove the Spark Arrester.
2. The vehicle engine shall be restarted and run at 1/2 throttle for 1 minutes to pressurized the muffler and force the particulate to drain out the opening in the spark arrester.
3. After the 1 minutes time period, shut the engine down, reinstall the plug, and tighten the bolts 35 lbf-ft of torque.
4. Repeat this procedure every 100 hours (with every oil change) as part of a first echelon maintenance schedule for the lift of the vehicle.

■ IMPORTANT

- Visually check the muffler for cracks or holes in the body, weldment or pipes at regular intervals.
- Replace the entire muffler if it is damaged.
- Do not operate the vehicle with a damaged muffler.

(1) Drain Plug

W1058476



Checking Wheel Screw Torque

CAUTION


- Never operate vehicle with a loose wheel screw.
- Any time screws are loosened, retighten to the specified torque.
- Check all screw frequently and keep them tight.

1. Check wheel screws (1) regularly especially when new. If they are loose, tighten them as follows.

| | | |
|-------------------|----------------------|---|
| Tightening torque | Wheel mounting screw | 75 to 90 N·m 7.6 to 9.2 kgf·m 55.3 to 66.4 lbf·ft |
|-------------------|----------------------|---|

(1) Wheel Mounting Screw

W1059106



Checking Battery Condition

To avoid the possibility of battery explosion:

For the refillable type battery, follow the instructions below.

- Do not use or charge the refillable type battery if the fluid level is below the LOWER (lower limit level) mark. Otherwise, the battery component parts may prematurely deteriorate, which may shorten the battery's service life or cause an explosion. Check the fluid level regularly and add distilled water as required so that the fluid level is between the UPPER and LOWER levels.

⚠ CAUTION

- Never remove the vent caps while the engine is running.
- Keep electrolyte away from eyes, hands and clothes. If you are splattered with it, wash it away completely with water immediately and get medical attention.
- Wear eye protection and rubber gloves when working around the battery.

The factory-installed battery is of non-refillable type. If the battery is weak, charge the battery or replace it with new one.

■ Battery Charging

⚠ CAUTION

- When the battery is being activated, hydrogen and oxygen gases in the battery are extremely explosive. Keep open sparks and flames away from the battery at all times, especially when charging the battery.
- When charging the battery, ensure the vent caps are securely in place (if equipped).
- When disconnecting the cable from the battery, start with the negative terminal first. When connecting the cable to the battery, start with the positive terminal first.
- Never check battery charge by placing a metal object across the posts.

Use a voltmeter or hydrometer.

1. To slow charge the battery, connect the battery positive terminal to the charger positive terminal and the negative to the negative, then recharge in the standard fashion.
2. A boost charge is only for emergencies. It will partially charge the battery at a high rate and in a short time.
When using a boost-charged battery, it is necessary to recharge the battery as early as possible.
Failure to do this will shorten the battery's service life.
3. When exchanging an old battery for a new one, use battery of equal specification shown in table 1.

| Battery Type | Volts (V) | Reserve Capacity (min.) | Cold Cranking Amps | Normal Charging Rate (A) |
|--------------|-----------|-------------------------|--------------------|--------------------------|
| 526RA | 12 | 80 | 535 | 6.5 |

(1) Battery

W1066595

Anti-Freeze

CAUTION

- When using antifreeze, put on some protection such as rubber gloves. (Antifreeze contains poison.)
- If should drink antifreeze, throw up at once and take medical attention.
- When antifreeze comes in contact with the skin or clothing, wash it off immediately.
- Do not mix different types of antifreeze.
The mixture can produce chemical reaction causing harmful substances.
- Antifreeze is extremely flammable and explosive under certain conditions. Keep fire and children away from antifreeze.
- When draining fluids from the engine, place some container underneath the engine body.
- Do not pour waste onto the grounds, down a drain, or into any water source.
- Also, observe the relevant environmental protection regulations when disposing of antifreeze.

If it freezes, coolant can damage the cylinders and radiator. If the ambient temperature falls below 0 °C (32 °F) or before a long-term storage, let out coolant completely, or mix fresh water with long-life coolant and fill the radiator and recovery tank with the mixture.

1. Long-life coolant (hereafter LLC) comes in several types. Use ethylene glycol (EG) type for this engine.
2. Before employing LLC-mixed coolant, fill the radiator with fresh water and empty it again.

Repeat this procedure 2 or 3 times to clean up the inside.

3. Mixing the LLC
Put the LLC in coolant in the percentage (%) for a target temperature. When mixing, stir it up well, and then fill into the radiator.
4. The procedure for the mixing of water and antifreeze differs according to the make of the antifreeze and the ambient temperature. Refer to SAE J1034 standard, more specifically also to SAE J814c.


■ IMPORTANT

- When the antifreeze is mixed with water, the antifreeze mixing ratio must be less than 50 %.

| Vol % Anti-freeze | Freezing Point | | Boiling Point * | |
|-------------------|----------------|-----|-----------------|-----|
| | °C | °F | °C | °F |
| 40 | -24 | -12 | 106 | 222 |
| 50 | -37 | -34 | 108 | 226 |

* At 1.013 x 10 Pa (760 mmHg) pressure (atmospheric). A higher boiling point is obtained by using a radiator pressure cap which permits the development of pressure within the cooling system.

Axle Support




3XVAAAB0P049A

Application: Use for removing and installing rear axle bracket.

| | | | | | |
|----------|---------------------|----------|------------------------------|----------|--------------------|
| A | 254.0 mm (10.0 in.) | H | 44.5 mm (1.75 in.) | O | 79.5 mm (3.13 in.) |
| B | 12.7 mm (0.50 in.) | I | 28.7 mm dia. (1.13 in. dia.) | P | 69.9 mm (2.75 in.) |
| C | 38.1 mm (1.50 in.) | J | 3.3 mm dia. (0.13 in. dia.) | Q | 3.81 mm (1.50 in.) |
| D | 12.7 mm (0.50 in.) | K | 50.8 mm (2.0 in.) | R | 25.4 mm (1.0 in.) |
| E | 63.5 mm (2.50 in.) | L | 127.0 mm (5.0 in.) | S | 0.52 rad (30 °) |
| F | 203.2 mm (8.0 in.) | M | 381.0 mm (15.0 in.) | T | R6.4 (R0.25) |
| G | 152.4 mm (6.0 in.) | N | 965.2 mm (38.0 in.) | U | 6.35 mm (1/4 in.) |

1. ENGINE BODY


[1] HALF-FLOATING HEAD COVER




The rubber packing is fitting in to maintain the head cover 0.5 mm or so off the cylinder head. This arrangement helps reduce noise coming from the cylinder head.

- (1) Cylinder Head Cover (2) Rubber Packing

W1012671



[2] GEAR CASE



The engine has a gear case where the cooling fins are set up around the oil passage. Therefore, the temperature of engine is decreased by the wind generated by the cooling fan.

- (1) Cooling Fin

W1012841


ENGINE BODY (Continued)

| Item | | Factory Specification | Allowable Limit |
|---|--------------------|---|------------------------|
| Rocker Arm Shaft to Rocker Arm | Oil Clearance | 0.016 to 0.045 mm 0.00063 to 0.00177 in. | 0.15 mm 0.0059 in. |
| Rocker Arm Shaft | O.D. | 10.473 to 10.484 mm 0.41232 to 0.41276 in. | – |
| Rocker Arm | I.D. | 10.500 to 10.518 mm 0.41339 to 0.41410 in. | – |
| Push Rod | Alignment | – | 0.25 mm 0.0098 in. |
| Tappet to Tappet Guide | Clearance | 0.016 to 0.052 mm 0.00063 to 0.00205 in. | 0.10 mm 0.0039 in. |
| Tappet | O.D. | 17.966 to 17.984 mm 0.70732 to 0.70803 in. | – |
| Tappet Guide Bore | I.D. | 18.000 to 18.018 mm 0.70866 to 0.70937 in. | – |
| Timing Gear | | | |
| Idle Gear to Crank Gear | Backlash | 0.043 to 0.124 mm 0.00169 to 0.00488 in. | 0.15 mm 0.0059 in. |
| Idle Gear to Cam Gear | Backlash | 0.047 to 0.123 mm 0.00185 to 0.00484 in. | 0.15 mm 0.0059 in. |
| Idle Gear to Injection Pump Gear | Backlash | 0.046 to 0.124 mm 0.00185 to 0.00488 in. | 0.15 mm 0.0059 in. |
| Oil Pump Drive Gear to Crank Gear | Backlash | 0.041 to 0.123 mm 0.00161 to 0.00484 in. | 0.15 mm 0.0059 in. |
| Idle Gear | Side Clearance | 0.20 to 0.51 mm 0.0079 to 0.0201 in. | 0.80 mm 0.0315 in. |
| Camshaft | Side Clearance | 0.15 to 0.31 mm 0.0059 to 0.0122 in. | 0.50 mm 0.0197 in. |
| | Alignment | – | 0.01 mm 0.0004 in. |
| Cam Height | Intake and Exhaust | 26.88 mm 1.0583 in. | 26.83 mm 1.0563 in. |
| Camshaft Journal to Cylinder Block Bore | Oil Clearance | 0.050 to 0.091 mm 0.00197 to 0.00358 in. | 0.15 mm 0.0059 in. |
| Camshaft Journal | O.D. | 32.934 to 32.950 mm 1.29661 to 1.29724 in. | – |
| Cylinder Block Bore | I.D. | 33.000 to 33.025 mm 1.29921 to 1.30020 in. | – |

W1013874

CAUTION

- When removing the radiator cap, wait at least ten minutes after the engine has stopped and cooled down. Otherwise, hot water may gush out, scalding nearby people.



3XVAAAB1P009A

Radiator Cap Air Leakage


- Set a radiator tester (1) and an adaptor (2) on the radiator cap.
- Apply the specified pressure (88 kPa, 0.9 kgf/cm², 13 psi), and measure the time for the pressure to fall to 59 kPa (0.6 kgf/cm², 9 psi).
- If the measurement is less than the factory specification, replace the radiator cap.

| | | |
|-----------------------|---------------|---|
| Pressure falling time | Factory spec. | More than 10 seconds for pressure fall from 88 to 59 kPa (from 0.9 to 0.6 kgf/cm ² , from 13 to 9 psi) |
|-----------------------|---------------|---|

(1) Radiator Tester

(2) Adaptor

W1054156



3XVAAAB1P010A

Radiator Water Leakage

- Pour a specified amount of water into the radiator.
- Set a radiator tester (1) and an adaptor (2) and raise the water pressure to the specified pressure.
- Check the radiator for water leaks.
- For water leak from the pinhole, repair with the radiator cement. When water leak is excessive, replace the radiator.

| | | |
|--------------------------------------|---------------|--|
| Radiator water leakage test pressure | Factory spec. | 157 kPa 1.6 kgf/cm ² 23 psi |
|--------------------------------------|---------------|--|




(1) Radiator Tester

(3) Radiator

(2) Adaptor

W1016903

(2) Oil Pan, Timing Gears, Camshaft and Fuel Camshaft



Oil Pan and Oil Strainer

1. Remove the oil pan mounting screws (1).
2. Remove the oil pan (2) by lightly tapping the rim of the pan with a wooden hammer.
3. Remove the oil strainer (3).

(When reassembling)

- After cleaning the oil strainer, check to see that the filter mesh is clean, and install it.
- Visually check the O-ring (4), apply engine oil, and install it.
- Securely fit the O-ring to the oil strainer.
- To avoid uneven tightening, tighten oil pan mounting screws in diagonal order from the center.
- Using the hole (5) numbered "3", install the oil strainer by mounting screw.


■ IMPORTANT

- **Scrape off the old adhesive completely. Wipe the sealing surface clean. Now apply new adhesive 3 to 5 mm (0.12 to 0.20 in.) thick all over the contact surface. Apply the adhesive also on the center of the flange as well as on the inner wall of each screw hole.**
- **Cut the nozzle of the "liquid gasket" (Three Bond 1207D or equivalent) container at its second notch. Apply "liquid gasket" about 5 mm (0.20 in.) thick. Within 20 minutes after the application of fluid sealant, reassemble the components. Wait then for about 30 minutes, and pour oil in the crankcase.**

- | | |
|----------------------------|------------|
| (1) Oil Pan Mounting Screw | (4) O-ring |
| (2) Oil Pan | (5) Hole |
| (3) Oil Strainer | |

W1028046

(6) Injection Nozzle



Nozzle Holder

1. Secure the nozzle retaining nut (7) with a vise.
2. Remove the nozzle holder (1), and take out parts inside.

(When reassembling)

- Assemble the nozzle in clean fuel oil.
- Install the push rod (4), noting its direction.
- After assembling the nozzle, be sure to adjust the fuel injection pressure.


| | | |
|-------------------|------------------------|---|
| Tightening torque | Nozzle holder | 34.3 to 39.2 N·m 3.5 to 4.0 kgf·m 25.3 to 28.9 lbf·ft |
| | Overflow pipe nut | 19.6 to 24.5 N·m 2.0 to 2.5 kgf·m 14.5 to 18.1 lbf·ft |
| | Nozzle holder assembly | 49.0 to 68.6 N·m 5.0 to 7.0 kgf·m 36.2 to 50.6 lbf·ft |

- | | |
|----------------------|--------------------------|
| (1) Nozzle Holder | (5) Distance Piece |
| (2) Adjusting Washer | (6) Nozzle Piece |
| (3) Nozzle Spring | (7) Nozzle Retaining Nut |
| (4) Push Rod | |

W1038321

[4] SERVICING

(1) Cylinder Head and Valve



Cylinder Head Surface Flatness


1. Clean the cylinder head surface.
2. Place a straightedge on the cylinder head's four sides and two diagonal lines as shown in the figure.
3. Measure the clearance with a thickness gauge.
4. If the measurement exceeds the allowable limit, correct it with a surface grinder.


■ IMPORTANT

- Do not place the straightedge on the combustion chamber.
- Be sure to check the valve recessing after correcting.

| | | |
|--------------------------------|-----------------|-----------------------|
| Cylinder head surface flatness | Allowable limit | 0.05 mm 0.0020 in. |
|--------------------------------|-----------------|-----------------------|

W1038765





Piston Ring Gap

1. Insert the piston ring into the lower part of the cylinder (the least worn out part) with piston.
2. Measure the ring gap with a thickness gauge.
3. If the measurement exceeds the allowable limit, replace the piston ring.

| | | | |
|-----------------|-------------|-----------------|---|
| Piston ring gap | Top ring | Factory spec. | 0.20 to 0.35 mm 0.0079 to 0.0138 in. |
| | | Allowable limit | 1.25 mm 0.0492 in. |
| | Second ring | Factory spec. | 0.35 to 0.50 mm 0.0138 to 0.0197 in. |
| | | Allowable limit | 1.25 mm 0.0492 in. |
| | Oil ring | Factory spec. | 0.20 to 0.35 mm 0.0079 to 0.0138 in. |
| | | Allowable limit | 1.25 mm 0.0492 in. |

W1045599



Clearance between Piston Ring and Piston Ring Groove

1. Clean the rings and the ring grooves, and install each ring in its groove.
2. Measure the clearance between the ring and the groove with a thickness gauge.
3. If the clearance exceeds the allowable limit, replace the piston ring.
4. If the clearance still exceeds the allowable limit with new ring, replace the piston.

| | | | |
|--|-------------|-----------------|---|
| Clearance between piston ring and piston ring groove | Second ring | Factory spec. | 0.090 to 0.120 mm 0.00354 to 0.00472 in. |
| | | Allowable limit | 0.15 mm 0.0059 in. |
| | Oil ring | Factory spec. | 0.04 to 0.08 mm 0.0016 to 0.0031 in. |
| | | Allowable limit | 0.15 mm 0.0059 in. |


W1046097

MECHANISM

CONTENTS

| | |
|---|-------|
| 1. STRUCTURE | 2-M1 |
| 2. POWER TRAIN | 2-M2 |
| [1] HYDROSTATIC TRANSMISSION (HST) | 2-M2 |
| (1) Structure | 2-M2 |
| (2) Oil Flow | 2-M4 |
| (3) Function of Components | 2-M5 |
| [2] RANGE GEAR SHIFT SECTION AND FRONT WHEEL DRIVE SECTION | 2-M20 |

[2] RANGE GEAR SHIFT SECTION AND FRONT WHEEL DRIVE SECTION



R : Reverse
 L : Low Speed
 M : Middle Speed
 H : High Speed

a : 4 Wheel Drive
 A : From HST Output Shaft

W1020797


■ Range Gear Shift Section

First, power is transmitted to the HST at the back of the transmission case. The HST power is then taken out to the front and transmitted further to the range shift section.

The speed can be changed in 3 steps forward and in single step backward. The shifting is made through the cable linkage of the shift lever at the operator's seat. The speed change system is of constant mesh type.

■ Front Wheel Drive Section

This section is located near the range gear shift section. The front wheel drive select lever at the operator's seat is used to switch between the two wheel and four wheel drive. The front wheel drive select lever and the range gear shift lever are cable connected. Sliding gear system is adopted, in which the shifter gears are directly moved.



Checking Charge Relief Pressure

⚠ CAUTION

- If it is necessary to run engine in an enclosed area, use a gas tight exhaust pipe extension to remove the fumes.
- Always try to work in a well-ventilated area.
- When checking, park the machine on flat ground, apply the parking brake.
- Work by two people when you measure pressure.
- Note that the allen wrench does not come off firmly because the plug is not loose hard. Otherwise, the plug (1) might be damaged, and the plug not be loosened.

1. Remove the hex. socket head plug from P3 port (1).

■ NOTE

- The hex. socket plug is securely tightened. Therefore, it is very important to use a proper-sized allen wrench and fit it securely onto the plug. Do not give a shock but put your weight on the plug slowly, paying attention not to damage its hex. socket section. If the allen wrench is fitted on the plug at a slant or an improper-sized allen wrench is used to loose the plug, the hex. socket section will be damaged and you won't be able to loose the plug.

2. Install the HST adaptor and high pressure gauge to P3 port (1).
3. Place the range gear shift lever in neutral.
4. Set the 4WD lever to 2WD position.
5. Start the engine.
6. Depress the speed control pedal, and measure the charge pressure.
7. If the measurement is not within the factory specification, check the charge relief valve. (See page 2-S36.)

(When reassembling)

- Apply liquid lock (Three Bond 1324B or its equivalent) to the hex. socket head plug.

| | | |
|-----------------|---------------|---|
| Charge pressure | Factory spec. | 0.52 to 0.72 MPa 5.3 to 7.3 kgf/cm ² 75 to 104 psi |
|-----------------|---------------|---|

■ NOTE





- Low pressure gauge is 2.9 MPa (30 kgf/cm², 427 psi) full scale.

Condition

- Engine speed : Maximum
- Oil temperature : 45 to 55 °C
113 to 131 °F

(1) P3 Port (Charge)

W1020209



Piston Case and Motor Case

1. Place oil pan underneath the motor case (3).
2. Loosen the piston case (1) with return piston, springs and stopper rod.
3. Remove the motor case (3) with variable swashplate (4).
4. Remove the thrust ball bearing (8) and the assist motor cylinder block (10).
5. Remove the valve plate (7).





(When reassembling)

- Take care not to damage O-ring on the piston case.
- Replace the motor case gasket (5) with new one.
- Apply a thin coat of oil soluble grease to the surface of valve plate (7) and the variable swashplate (4) and thrust ball bearing (8). This is to hold the parts in place while assembling.
- Be sure to install the motor case (3) and variable swashplate (3) with thrust ball bearing to part block cover (8).
- Be careful not to loose the spring (6) for charge relief valve.
- Thrust ball bearing sequence thin race inside variable swashplate (4), ball bearing (open side down), thick race out side.
- Be careful to note the location of three different length screws (2).
- Wrap the seal tape around the tread of three long screws (4).

| | | |
|-------------------|---------------------------|---|
| Tightening torque | Piston ease | 70.0 to 80.0 N-m 7.0 to 8.0 kgf-m 51.6 to 59.6 lbf-ft |
| | Motor case mounting screw | 18.0 to 21.0 N-m 1.8 to 2.1 kgf-m 13.3 to 15.5 lbf-ft |

- | | |
|-------------------------|-----------------------------|
| (1) Piston Case | (6) Spring (Charge Relief) |
| (2) Long Screw | (7) Valve Plate |
| (3) Motor Case | (8) Port Block Cover |
| (4) Variable Swashplate | (9) Thrust Ball Bearing |
| (5) Motor Case Gasket | (10) Cylinder Block (Motor) |

W1028557




Detent Ball, Interlocking Ball and Back Idle Gear Shaft

1. Remove the stopper bolt (3) from bearing holder (1).
2. With a magnet, remove the three interlock balls (6).
3. Tap out the roll pins (2) and remove the springs (8) and detent balls (7).
4. Loosen the nut (4) and tap out the back idle shaft (5) to the case side.
5. Remove the bearing holder mounting screws and pull out the bearing holder (1).

(1) Bearing Holder
 (2) Roll Pin
 (3) Stopper Bolt
 (4) Nut

(5) Back Idle Shaft
 (6) Interlock Ball
 (7) Detent Ball
 (8) Spring

W1037897



3TMABAB3P015A

Checking Bearing

1. Hold the inner race, and push and pull the outer race in all directions to check for wear and roughness.
2. Apply transmission fluid to the bearing, and hold the inner race. Then, turn the outer race to check rotation.
3. If there is any defect, replace it.

W1046357



3XVAAAB3P103A

Checking Gear

1. Visually check the tooth of gear which comes in contact.
2. If there is any doubt as to the condition of gears, replace it.

W1046499



3XVAAAB3P104A

6T Spiral Bevel Pinion Shaft, Gear and Needle Bearing

1. Remove the 33T gear by using the gear puller.
2. Check the needle bearing for abrasion, color change or other damage.
3. If there is any doubt as to the condition of a needle bearing, replace it.
4. Check both the shaft and the gear surface of the bearing contact point for abrasion, color change or other damage.
5. If there are any doubt as to the condition of shaft and gear.

W1046658



3XVAAAB3P105A

MECHANISM

CONTENTS

| | |
|--------------------|------|
| 1. STRUCTURE | 3-M1 |
|--------------------|------|

4 BRAKES

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

2. SERVICING SPECIFICATIONS

TRAVELLING BRAKE





| Item | | Factory Specification | Allowable Limit |
|----------------|-----------|---|-----------------------|
| Brake Pedal | Play | 7 to 14 mm 0.28 to 0.55 in. | – |
| | Stroke | Less than 120 mm 4.7 in. | – |
| Brake Disc | Thickness | 3.3 to 3.5 mm 0.130 to 0.138 in. | 3.0 mm 0.118 in. |
| Friction Plate | Thickness | 1.92 to 2.08 mm 0.0756 to 0.0819 in. | 1.52 mm 0.0598 in. |

W1013874

PARKING BRAKE

| Item | | Factory Specification | Allowable Limit |
|---------------------|-------------------------------------|-----------------------|-----------------|
| Parking Brake Lever | Lever Travel (Number of notches) | 1 notch | – |

W1012949



Brake Piston, Brake Disc and Friction Plate (To be continued)

■ IMPORTANT

- It is recommended to replace the brake seal with a new one every four years.
 - Therefore, do not remove the piston unnecessarily from the knuckle case.
 - If the piston should be removed, replace the seal ring with a new one.
1. Remove the oil seal (1).
 2. Remove the snap ring collar (2) and remove the external snap ring (3).
 3. Tap out the front axle (5) with plastic hammer.
 4. Remove the knuckle case (4) mounting screw.
 5. Separate the knuckle case and knuckle case cover (6).
 6. Remove the brake piston (7) by compressed air.

(When reassembling)

- Be sure install the external snap ring.
- Replace the oil seal (1) with new one.
- Take care not to damage the O-ring.
- Replace the brake seal 1 (8), 2 (9), and brake seal 3 (11), 4 (10).
- Insert the bearing and oil seal first to the knuckle cover (6), and install the knuckle case cover to front axle (5).

⚠ CAUTION

- The brake seal 1 (8), 2 (9) are used for brake fluid only.
- The brake seal 3 (11), 4 (10) are used for transmission fluid only.
- Degrease both the piston (7) and the knuckle case (4) before installing each brake seal.
- Before inserting the piston (7), apply a thin coat of the special grease (KLUBER LUBRICATION : SEALUB-L-101 or equivalent) to the brake seal surface. The special grease is a dual use type that can be applied to the oil seals and the O-rings for both of the brake fluid and the transmission fluid.
- When servicing the brake, pay due attention to any oil adhered to your hands.
- Exert full care when handling the mineral oil (transmission fluid) and the brake fluid.

■ NOTE

- Align the each alignment mark (12) of piston and knuckle case.
- Assemble the bearing and oil seal of rear axle into the knuckle case cover side, and then assemble the rear axle.


| | | |
|-------------------|-----------------------------------|---|
| Tightening torque | Knuckle case cover mounting screw | 48.1 to 55.8 N·m 4.9 to 5.7 kgf·m 35.5 to 41.2 lbf·ft |
|-------------------|-----------------------------------|---|

- | | |
|------------------------|------------------------|
| (1) Oil Seal | (5) Front Axle |
| (2) Snap Ring Roller | (6) Knuckle Case Cover |
| (3) External Snap Ring | (7) Piston |
| (4) Knuckle Case | |

W1019414

1. STRUCTURE



[1] FRONT AXLE



- | | | | |
|---------------------------|----------------|----------------------------------|----------------|
| (1) Bevel Gear Shaft (8T) | (4) Strut | (7) Ball Joint | (9) Front Case |
| (2) Bevel Gear (35T) | (5) Knuckle | (8) Constant Velocity (CV) Joint | (10) Lower Arm |
| (3) Side Gear | (6) Front Axle | | |

The front axle consists mainly of knuckles (5) (right and left), front case (9) and CV (constant velocity) joint (8). (See the above illustration.)

Power is transmitted from the transmission output shaft through the propeller shaft to the bevel gear shaft (1). The power is further transmitted through the differential bevel gear (2) and differential side gear (3) to the CV joint (8), and finally reaches the front axle (6) in the knuckles. The knuckles and the front case are partitioned from each other. Which means each of the cases must be separately lubricated.



Drive Shaft and Lower Arm

1. Remove the front case cover mounting screw (1).
2. Draw out the drive shaft assembly (4).
3. Remove the lower arm mounting bolt and nut (2).
4. Remove the lower arm (3).

(When reassembling)

- Take care not to damage the O-ring of front case cover.

■ NOTE


- **Tighten the lower arm mounting bolt and nut (2) with the specified torque after setting up the wheel and unloading the machine on ground.**

| | | |
|-------------------|---------------------------------|---|
| Tightening torque | Front case cover mounting screw | 17.7 to 20.6 N·m 1.8 to 2.1 kgf·m 13.3 to 15.5 lbf·ft |
| | Lower arm mounting bolt and nut | 102.9 to 117.6 N·m 10.5 to 12.0 kgf·m 75.9 to 86.7 lbf·ft |

- (1) Front Case Cover Mounting Screw (3) Lower Arm
(2) Lower Arm Mounting Screw and Nut (4) Drive Shaft Assembly

W1018017

2. HYDRAULIC CIRCUIT



This model is provided with a full hydrostatic power steering.



In the full hydrostatic power steering, the steering controller is connected to the steering cylinder (1) with only the hydraulic piping. Accordingly, it does not have mechanical transmitting parts such as steering gear, pitman arm, drag link, etc. Therefore, it is simple in construction. This steering system consists of the power steering oil tank (3), hydraulic pump (4), steering controller (2), steering cylinder, etc.

An oil tank dedicated for power steering is located below the operator's seat. The oil in this tank is fed by the engine driven hydraulic pump to the steering controller (3.5 to 8.4 L/min., 0.92 to 2.22 U.S.gals./min.). With the steering wheel at neutral, the oil returns through the controller to the oil tank. Turn the steering wheel, and just a required amount of oil is sent to the steering cylinder. The oil at the side opposite to the cylinder flows back to the tank.

This power steering controller is of non-load reaction type.

- | | |
|-------------------------|--------------------|
| (1) Steering Cylinder | (3) Oil Tank |
| (2) Steering Controller | (4) Hydraulic Pump |

W1012902



Steering Controller

1. Disconnect the power steering hoses (2), (3), (4), (5).
2. Remove the steering controller mounting screws and remove the steering controller (1).

(When reassembling)



- Be sure to connect the power steering hoses to their original position, and tighten them to the specified torque.

| | | |
|-------------------|----------------------------------|---|
| Tightening torque | Power steering hose mounting nut | 28.4 to 30.0 N-m 2.9 to 3.1 kgf-m 20.9 to 22.1 lbf-ft |
|-------------------|----------------------------------|---|

- | | |
|-------------------------------|-------------------------------|
| (1) Steering Controller | (4) Cylinder Hose RH (L Port) |
| (2) Delivery Hose (Pump Port) | (5) Cylinder Hose LH (R Port) |
| (3) Return Hose (Tank Port) | |

W1015456

(2) Separating Power Steering Cylinder



Power Steering Cylinder

1. Place the stand under the frame.
2. Remove the front wheels.
3. Remove the cotter pin and remove the slotted nut (2) for tie-rod end (1).
4. Disconnect the power steering cylinder hoses (3), (4).
5. Cut the cords clamp.
6. Remove the power steering cylinder bracket (5), (7) mounting screws and remove the power steering cylinder (6) with tie-rod.


(When reassembling)

- When inserting the cotter pin, if the slots in the nut do not align with the cotter pin hole in tie-rod end, tighten the nut clockwise up to next alignment.
- If should be within 30 degree.
- Loosen once and tighten again when the slit goes past the nearest hole.
- After tightening the these slotted nut to specified torques, install a cotter pin as shown in the figure left.

| | | |
|-------------------|------------------------------|---|
| Tightening torque | Tie-rod slotted nut | 17.7 to 34.3 N-m 1.8 to 3.5 kgf-m 13.0 to 25.3 lbf-ft |
| | Power steering cylinder hose | 28.4 to 30.0 N-m 2.9 to 3.1 kgf-m 20.9 to 22.1 lbf-ft |
| | Bracket mounting screw | 103 to 117 N-m 10.5 to 12.0 kgf-m 76.0 to 86.7 lbf-ft |

- | | |
|------------------------------|-----------------------------|
| (1) Tie-rod End RH | (5) Bracket RH |
| (2) Slotted Nut | (6) Power Steering Cylinder |
| (3) Power Steering Hose (RH) | (7) Bracket LH |
| (4) Power Steering Hose (LH) | |


W1015900



3TMABAB6P017A

2. HYDRAULIC CIRCUIT

[1] HYDRAULIC CARGO BED LIFT (IF EQUIPPED)



(1) Hydraulic Control Valve
(2) Hydraulic Pump

(3) Oil Tank
(4) Transmission

(5) Hydraulic Cylinder


A : In
B : Out

The cargo bed lifting system of RTV900 is composed of the hydraulic pump, control valve, hydraulic cylinder, oil tank and other components as shown in the figure.

This system has the following functions.

1. Oil is supplied by hydraulic pump which is driven by input shaft in the transmission case. As the input shaft is connected to the idle gear, hydraulic pump starts running when engine is started.
2. The hydraulic pump forces out the oil to hydraulic control valve for cargo bed lift system or hydraulic power take off.

■ Floating



- (1) Spool
- (2) Check Valve
- (3) Detent Ball
- (4) Detent Sleeve

A : A Port (Lift Cylinder)
B : B Port (Lift Cylinder)
P : Pump Port
T : Tank Port

3XVAAAB8P012A

When the spool (2) moves to extreme right, the detent ball (3) and detent sleeve (4) holds the spool (1) at the floating position as shown in the figure. The pressure-fed oil from the hydraulic pump flows to oil tank through **T** port. And, the **A** port and **B** port lead to the **T** port along the notched sections of the spool (2). This result in the attached implement to follow the power from implement.


3 Position Valve (Continued)

1. Loosen the plug (8) and draw out the spool (16) with other component parts from valve body (19).
2. Remove the internal snap ring (14) and detent stopper (12).
3. Loosen the detent bolt (7) from spool (16) and then separate the spool and the detent bolt.
4. Remove the plug (23) and take out the spring (21) and poppet (20).
5. Remove the check valve seat (27) assembly.
6. Remove the plug (38) and take out the shim (36), spring (35) poppet (34) and seat (33).

(When reassembling)

- Clean all parts with a suitable solvent, and dry with a lint-free cloth or air.
- Visually inspect all parts for signs of scoring or damage.
- Install the spool and spacer to the valve housing, using care not to damage the O-ring.
- Tightning torque of plug (38) : 29.4 to 43.3 N·m (3.0 to 3.5 Kgf·m, 21.7 to 25.3 lbf·ft)
- Tightning torque of plug (23) : 19.6 to 24.5 N·m (2.0 to 2.5 Kgf·m, 14.5 to 18.1 lbf·ft)
- Tightning torque of check valve seat (27) : 34.3 to 39.2 N·m (3.5 to 4.0 Kgf·m, 25.3 to 28.9 lbf·ft)
- Tightning torque of plug (31) : 24.5 to 29.4 N·m (2.5 to 3.0 Kgf·m, 18.1 to 21.7 lbf·ft)

3. CHARGING SYSTEM



(1) Alternator
 (2) Battery Charge Lamp

(3) Slow Blow Fuse (50 A)
 (4) Fuse

(5) Slow Blow Fuse (60 A)
 (6) Main Switch

(7) Battery

The charging system supplies electric power for various electrical devices and also charges the battery while the engine runs.

This alternator has IC regulator.

1. TROUBLESHOOTING


| Symptom | Probable Cause | Solution | Reference Page |
|---|---|---------------------|----------------|
| All Electrical Equipments Do Not Operate | Battery discharged or defective | Recharge or replace | G-35 |
| | Battery positive cable disconnected or improperly connected | Repair or replace | 8-S8 |
| | Battery negative cable disconnected or improperly connected | Repair or replace | 8-S8 |
| | Slow blow fuse blown | Replace | G-48 |
| Fuse Blown Frequently | Short-circuited | Repair or replace | – |

W1014322

BATTERY

| Symptom | Probable Cause | Solution | Reference Page |
|---------------------------------------|---|-------------------|----------------|
| Battery Discharges Too Quickly | Battery defective | Replace | 8-S8 |
| | IC Regulator defective | Replace | 8-S27 |
| | Wiring harness disconnected or improperly connected (between battery positive terminal and regulator B terminal) | Repair or replace | – |
| | Cooling fan belt slipping | Adjust tension | G-36 |

W1012216



Main Switch Continuity

1) Main Switch Key at OFF Position

1. Set the main switch **OFF** position.
2. Measure the resistance with an ohmmeter across the **B** terminal and the **ACC** terminal, **B** terminal and **ST** terminal, **B** terminal and **G** terminal.
3. If infinity is not indicated, the contacts of the main switch are faulty.

| | | |
|------------|---------------------------|----------|
| Resistance | B terminal - ACC terminal | Infinity |
| | B terminal - ST terminal | |
| | B terminal - G terminal | |

2) Main Switch Key at ON Position

1. Set the main switch **ON** position.
2. Measure the resistance with an ohmmeter across the **B** terminal and the **ACC** terminal.
3. If 0 ohm is not indicated, the **B - ACC** contact of the main switch are faulty.

| | | |
|------------|---------------------------|-----|
| Resistance | B terminal - ACC terminal | 0 Ω |
|------------|---------------------------|-----|

3) Main Switch Key at PREHEAT Position

1. Set and hold the main switch key at the **PREHEAT** position.
2. Measure the resistance with an ohmmeter across the **B** terminal and the **G** terminal, and measure the resistance across the **B** terminal and the **ACC** terminal.
3. If 0 ohm is not indicated, these contacts of the main switch are faulty.

| | | |
|------------|---------------------------|-----|
| Resistance | B terminal - G terminal | 0 Ω |
| | B terminal - ACC terminal | |

4) Main Switch Key at START Position

1. Set and hold the main switch key at the **START** position.
2. Measure the resistance with an ohmmeter across the **B** terminal and the **G** terminal, across the **B** terminal and the **ST** terminal, and across the **B** terminal and the **ACC** terminal.
3. If 0 ohm is not indicated, these contacts of the main switch are faulty.





| | | |
|------------|---------------------------|-----|
| Resistance | B terminal - G terminal | 0 Ω |
| | B terminal - ST terminal | |
| | B terminal - ACC terminal | |

(1) **G** Terminal
(2) **ACC** Terminal

(3) **ST** Terminal
(4) **B** Terminal

W1024464

(10) Cooling System



Fan Motor Wiring Harness

1. Disconnect the wiring lead (1) from the engine oil pressure switch after turning the main switch **OFF**.
2. Turn the main switch **ON** and connect a jumper lead from the lead to the chassis.
3. If the fan motor does not rotate wiring harness or relay is faulty.

- (1) Wiring Lead
- (2) Coolant Temperature Sensor
- (a) From Fan Motor Relay

W1037767

Coolant Temperature Switch

1. Measure the resistance with an ohmmeter across the switch terminal and the switch body.
2. If 0 ohm is not indicated in the coolant temperature at 194 °C (201 °F) or more, the sensor is faulty.
3. If infinity is not indicated in the coolant temperature at lower than 90 °C (194 °F), the sensor is faulty.

| | | |
|--|--|----------|
| Resistance (Switch terminal - Switch body) | At coolant temperature lower than 90 °C (194 °F) | Infinity |
| | At coolant temperature more than 94 to 100 °C (201 to 212 °F) | 0 Ω |

- (1) Coolant Temperature Sensor
- (2) Coolant


W1038343

(1) Part No. K1211-6115-1



1BDABARAP108A

(2) Part No. K1211-6116-1




1BDABARAP109A

(4) Part No. K7561-6550-1




1AYAAAAAP112A

(3) Part No. K7561-6544-1




1AYAAAAAP110A

(5) Part No. K7561-6551-1




1AYAAAAAP113A



3XVAAAEP002A

2. GENERAL PRECAUTIONS



- During disassembly, carefully arrange removed parts in a clean area to prevent confusion later. Bolts and nuts should be installed in their original position to prevent reassembly errors.
- When special tools are required, use KUBOTA genuine special tools. Special tools which are not frequently used should be made according to the drawings provided.
- Before disassembling or servicing electrical wires, always disconnect the ground cable from the battery first.
- Remove oil and dirt from parts before measuring.
- Use only KUBOTA genuine parts for parts replacement to maintain tractor performance and to assure safety.
- Gaskets and O-rings must be replaced during reassembly. Apply grease to new O-rings or oil seals before assembling. See the figure left side.
- When reassembling external snap rings or internal snap rings, they must be positioned so that sharp edge faces against the direction from which a force is applied. See the figure left side.
- When inserting spring pins, their splits must face the direction from which a force is applied. See the figure left side.
- To prevent damage to the hydraulic system, use only specified fluid or equivalent.

- (1) Grease
- (2) Force
- (3) Sharp Edge
- (4) Axial Force
- (5) Rotating Movement

- (A) External Snap Ring
- (B) Internal Snap Ring

W10109040

(Continued)

| No. | Item | Period | Indication on hour meter | | | | | | | | | | Important | Reference page | | | |
|-----|--|---------|--------------------------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----------|----------------|-----|--|------|
| | | | 50 | 100 | 150 | 200 | 250 | 300 | 350 | 400 | 450 | 500 | | | 550 | | |
| 28 | Tire wear | Check | ★ | | | | | | ☆ | | | | | | | | G-30 |
| 29 | Front axle case oil | Change | | | | | | | | ☆ | | | | | | | G-42 |
| 30 | Knuckle axle case oil | Change | | | | | | | | ☆ | | | | | | | G-42 |
| 31 | Engine valve clearance | Adjust | | | | | | | | | | | | | | | – |
| 32 | Fuel injection nozzle injection pressure | Check | | | | | | | | | | | | | | | – |
| 33 | Injection pump | Check | | | | | | | | | | | | | | | – |
| 34 | Brake master cylinder inner parts | Replace | | | | | | | | | | | | | | | – |
| 35 | Brake fluid | Change | | | | | | | | | | | | | | | – |
| 36 | Remote hydraulic hose (if equipped) | Replace | | | | | | | | | | | | | | | – |
| 37 | Rear brake cylinder seal | Replace | | | | | | | | | | | | | | | – |
| 38 | Front brake seal | Replace | | | | | | | | | | | | | | | – |
| 39 | Cooling system | Flash | | | | | | | | | | | | | | | – |
| 40 | Coolant | Change | | | | | | | | | | | | | | | – |
| 41 | Fuel system | Bleed | | | | | | | | | | | | | | | – |
| 42 | Fuse | Replace | | | | | | | | | | | | | | | – |
| 43 | Light bulb | Replace | | | | | | | | | | | | | | | – |


W1020106

SERVICING

CONTENTS

| | |
|---------------------------------------|-------|
| 1. TIGHTENING TORQUES | H2-S1 |
| 2. DISASSEMBLING AND ASSEMBLING | H2-S2 |
| [1] DISMOUNTING TRANSAXLE | H2-S2 |

3. HYDRAULIC PUMP



The hydraulic pump is composed of the casing (3), cover (4), and two spur gears (drive gear (2) and driven gear (5)) that are in mesh.

Hydraulic pump is driven by the input shaft in the transmission case.

Maximum displacement is as follows.

| Displacement | Engine speed | Condition |
|---|---------------------------------|------------|
| 18.9 L/min. 5.0 U.S.gals./min. 4.2 Imp.gals./min. | At 3200 min ⁻¹ (rpm) | at no load |

- | | |
|----------------|-----------------|
| (1) Cover | (4) Cover |
| (2) Drive Gear | (5) Driven Gear |
| (3) Casing | |

W1013860

2. SERVICING SPECIFICATIONS


| Item | | Factory Specification | Allowable Limit |
|--------------|------------------|--|-----------------|
| Relief Valve | Setting Pressure | 14.7 to 15.7 MPa 150 to 160 kgf/cm ² 2133 to 2276 psi | – |

W1013874

10 NEW TRANSMISSION

The machine RTV900 serial number of the new transmission for North America was changed into those starting with "50001".

3. BYPASS VALVE



- (1) Spool **A** (Connects with VHT Pressure Release Knob)
- (2) Spool **B** (Connects with Brake Cam Lever)
- (3) Port Block Cover

- [A] At Running
- [B] At Dynamic Braking
- [C] When Applying the Brake and Stopping
- [D] When Pull the VHT Pressure Release Knob After It Stops

W1013315

The purpose of this bypass valve is to release any residual torque within the transmission system by bypass both high pressure and low pressure sides in HST.

Spool **B** (2) is interlocked with a foot brake and is subject to frequent use, which may give impact on the oil seal. Therefore, spool **B** has been installed on the low pressure side.

Spool **A** (1) is operated manually (by pulling the VHT pressure release knob).

When the foot brake is applied (or the parking brake activated), the low pressure circuit is directed to the bypass circuit **[C]**.

Pull the VHT pressure release knob for the bypass valve to operate spool **A** (1), the circuit on the high pressure side is also connected to the bypass circuit.

As a result, the pressure on the high pressure side balances that of the low pressure side, this in turn releases any drive from the transmission.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL