

# **WSM**

---

**WORKSHOP MANUAL**

**ZD321,ZD323,ZD326,ZD331**

---

**Кубота**


CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL



(1) Part No. K5681-7312-1



1BDACAEAP015B

(2) Part No. K5681-7311-1




1BDACAEAP016B


(3) Part No. K5681-7310-1



1BDACAEAP017B



(4) Part No. K3181-2491-3



1BDABCQAP122A

(5) Part No. K3181-6532-1



1BDABCQAP102A

9Y12102651CI006US


9Y12102651NI0004US0

**CARE OF DANGER, WARNING AND CAUTION LABELS**

1. Keep danger, warning and caution labels clean and free from obstructing material.
2. Clean danger, warning and caution labels with soap and water, dry with a soft cloth.
3. Replace damaged or missing danger, warning and caution labels with new labels.
4. If a component with danger, warning and caution label(s) affixed is replaced with new part, make sure new label(s) is (are) attached in the same location(s) as the replace component.
5. Mount new danger, warning and caution labels by applying on a clean dry surface and pressing any bubbles to outside edge.

9Y12102651NI0005US0

### 3. CYLINDER NUMBER



The cylinder numbers of KUBOTA diesel engine are designated as shown in the figure.









The sequence of cylinder numbers is given as No.1, No.2 and No.3 starting from the gear case side.

9Y1210265GEG0002US0

# 6. TIGHTENING TORQUES

## [1] GENERAL USE SCREWS, BOLTS AND NUTS

Tighten screws, bolts and nuts whose tightening torques are not specified in this Workshop Manual according to the table below.


| Indication on top of bolt |  No-grade or 4T   |            |            |           |            |           |  7T |            |            |           |            |           |  9T   |            |            |
|---------------------------|--|------------|------------|-----------|------------|-----------|---|------------|------------|-----------|------------|-----------|--|------------|------------|
| Indication on top of nut  |   No-grade or 4T |            |            |           |            |           |   |            |            |           |            |           |    6T |            |            |
| Material of opponent part | Ordinariness   |            |            | Aluminum  |            |           | Ordinariness  |            |            | Aluminum  |            |           | Ordinariness   |            |            |
| Unit                      | N·m  | kgf·m      | lbf·ft     | N·m       | kgf·m      | lbf·ft    | N·m   | kgf·m      | lbf·ft     | N·m       | kgf·m      | lbf·ft    | N·m  | kgf·m      | lbf·ft     |
| <b>M6</b>                 | 7.9  | 0.80       | 5.8        | 7.9       | 0.80       | 5.8       | 9.81  | 1.00       | 7.24       | 7.9       | 0.80       | 5.8       | 12.3   | 1.25       | 9.05       |
|                           | to<br>9.3  | to<br>0.95 | to<br>6.8  | to<br>8.8 | to<br>0.90 | to<br>6.5 | to<br>11.2  | to<br>1.15 | to<br>8.31 | to<br>8.8 | to<br>0.90 | to<br>6.5 | to<br>14.2   | to<br>1.45 | to<br>10.4 |
| <b>M8</b>                 | 18   | 1.8        | 13         | 17        | 1.7        | 13        | 24  | 2.4        | 18         | 18        | 1.8        | 13        | 30   | 3.0        | 22         |
|                           | to<br>20   | to<br>2.1  | to<br>15   | to<br>19  | to<br>2.0  | to<br>14  | to<br>27  | to<br>2.8  | to<br>20   | to<br>20  | to<br>2.1  | to<br>15  | to<br>34   | to<br>3.5  | to<br>25   |
| <b>M10</b>                | 40   | 4.0        | 29         | 32        | 3.2        | 24        | 48  | 4.9        | 36         | 40        | 4.0        | 29        | 61   | 6.2        | 45         |
|                           | to<br>45   | to<br>4.6  | to<br>33   | to<br>34  | to<br>3.5  | to<br>25  | to<br>55  | to<br>5.7  | to<br>41   | to<br>44  | to<br>4.5  | to<br>32  | to<br>70   | to<br>7.2  | to<br>52   |
| <b>M12</b>                | 63   | 6.4        | 47         | -         | -          | -         | 78  | 7.9        | 58         | 63        | 6.4        | 47        | 103  | 10.5       | 76.0       |
|                           | to<br>72   | to<br>7.4  | to<br>53   | -         | -          | -         | to<br>90  | to<br>9.2  | to<br>66   | to<br>72  | to<br>7.4  | to<br>53  | to<br>117  | to<br>12.0 | to<br>86.7 |
| <b>M14</b>                | 108  | 11.0       | 79.6       | -         | -          | -         | 124   | 12.6       | 91.2       | -         | -          | -         | 167  | 17.0       | 123        |
|                           | to<br>125  | to<br>12.8 | to<br>92.5 | -         | -          | -         | to<br>147   | to<br>15.0 | to<br>108  | -         | -          | -         | to<br>196  | to<br>20.0 | to<br>144  |
| <b>M16</b>                | 167  | 17.0       | 123        | -         | -          | -         | 197   | 20.0       | 145        | -         | -          | -         | 260  | 26.5       | 192        |
|                           | to<br>191  | to<br>19.5 | to<br>141  | -         | -          | -         | to<br>225   | to<br>23.0 | to<br>166  | -         | -          | -         | to<br>304  | to<br>31.0 | to<br>224  |
| <b>M18</b>                | 246  | 25.0       | 181        | -         | -          | -         | 275   | 28.0       | 203        | -         | -          | -         | 344  | 35.0       | 254        |
|                           | to<br>284  | to<br>29.0 | to<br>209  | -         | -          | -         | to<br>318   | to<br>32.5 | to<br>235  | -         | -          | -         | to<br>402  | to<br>41.0 | to<br>296  |
| <b>M20</b>                | 334  | 34.0       | 246        | -         | -          | -         | 368   | 37.5       | 272        | -         | -          | -         | 491  | 50.0       | 362        |
|                           | to<br>392  | to<br>40.0 | to<br>289  | -         | -          | -         | to<br>431   | to<br>44.0 | to<br>318  | -         | -          | -         | to<br>568  | to<br>58.0 | to<br>419  |

WSM000001GEG0001US0

## [2] STUD BOLTS

| Material of opponent part | Ordinariness |            |            | Aluminum |           |           |
|---------------------------|--------------|------------|------------|----------|-----------|-----------|
| Unit                      | N·m          | kgf·m      | lbf·ft     | N·m      | kgf·m     | lbf·ft    |
| <b>M8</b>                 | 12           | 1.2        | 8.7        | 8.9      | 0.90      | 6.5       |
|                           | to<br>15     | to<br>1.6  | to<br>11   | to<br>11 | to<br>1.2 | to<br>8.6 |
| <b>M10</b>                | 25           | 2.5        | 18         | 20       | 2.0       | 15        |
|                           | to<br>31     | to<br>3.2  | to<br>23   | to<br>25 | to<br>2.6 | to<br>18  |
| <b>M12</b>                | 30           | 3.0        | 22         | 31       | 3.2       | 23        |
|                           | to<br>49     | to<br>5.0  | to<br>36   |          |           |           |
| <b>M14</b>                | 62           | 6.3        | 46         | -        | -         | -         |
|                           | to<br>73     | to<br>7.5  | to<br>54   | -        | -         | -         |
| <b>M16</b>                | 98.1         | 10.0       | 72.4       | -        | -         | -         |
|                           | to<br>112    | to<br>11.5 | to<br>83.1 | -        | -         | -         |
| <b>M18</b>                | 172          | 17.5       | 127        | -        | -         | -         |
|                           | to<br>201    | to<br>20.5 | to<br>148  | -        | -         | -         |

WSM000001GEG0002US0



### Replacing Engine Oil Filter Cartridge

#### ⚠ CAUTION

- Be sure to stop the engine before changing the oil filter cartridge.
- Allow engine to cool down sufficiently, oil can be hot and may cause burns.


1. Remove the engine oil filter cartridge (1) with the filter wrench.
2. Apply a slight coat of oil onto the rubber gasket of new cartridge.
3. To install the new cartridge, screw it in by hand. Over tightening may cause deformation of rubber gasket.
4. After the cartridge has been replaced, the engine oil level normally lowers a little. Add engine oil to proper level. Check for oil leaks around filter gasket.

#### ■ IMPORTANT

- To prevent serious damage to the engine, element of recommended type must be used. Use only a genuine KUBOTA filter or its equivalent.

(1) Engine Oil Filter Cartridge

9Y1210265GEG0017US0



### Replacing HST Transmission Oil Filter Cartridge

#### ⚠ CAUTION

- Be sure to stop the engine before changing the oil filter cartridge.
- Allow transmission case to cool down sufficiently; oil can be hot and may cause burns.

1. The HST transmission oil filter cartridge must be changed every 200 service hours.
2. Place an oil pan underneath the oil filter cartridge. (Do not drain oil.)
3. Remove the oil filter cartridge by using the filter wrench.
4. Apply a slight coat of oil onto the cartridge gasket.
5. Tighten the filter quickly until it contacts the mounting surface. Tighten filter by hand an additional 1/2 turn only.
6. After the new cartridge has been replaced, the transmission fluid level normally lowers a little. Add fluid to proper level. Check for oil leaks around filter gasket.


#### ■ IMPORTANT



- To prevent serious damage or premature failure to the hydraulic system, use only a KUBOTA genuine filter.

(1) HST Transmission Oil Filter Cartridge

(2) Gasket

9Y1210265GEG0018US0





**Checking Fuel Lines and Fuel Filter**

**CAUTION**

- Be sure to stop the engine and remove the key when attempting to make the following checks and changes.
- Never fail to check the fuel lines periodically. The fuel lines are subject to wear and age. Fuel may leak out onto the running engine, causing a fire.

The fuel line connections should be checked annually or every 100 service hours, whichever comes first.

1. The fuel lines is made of rubber and ages regardless of service period.
2. If the fuel line and clamps are found damages or deteriorated, replace them.
3. Check fuel filter, if it is clogged by debris, and replace it.

**IMPORTANT**


- When the fuel line is disconnected for maintenance or repair, close both ends of the fuel line with a piece of clean cloth or paper to prevent dust and dirt from entering. In addition, particular care must be taken not to admit dust and dirt into the fuel pump. Entrance of dust and dirt causes malfunction of the fuel pump and injector components.

- (1) Pipe Clamps
- (2) Fuel Line
- (3) Fuel Filter
- (4) Fuel Pump

[A] ZD321, ZD323

[B] ZD326, ZD331

9Y1210265GEG0030US0



**Adjusting Fan Belt Tension**

**CAUTION**

- Be sure to stop the engine and remove the key before checking belt tension.

1. If the fan drive belt becomes loose, the engine may overheat.
2. To adjust, loosen bolts and turn the alternator to tighten the belt.
3. After adjustment, securely tighten the bolts.

**Moderate belt tension:**

The belt deflect approx. 10 mm (0.4 in.) when the center of the belt is depressed with finger pressure of 98 N (10 kgf, 22 lbf).

|                      |                       |                             |
|----------------------|-----------------------|-----------------------------|
| Fan belt tension (A) | Factory specification | Approx.<br>10 mm<br>0.4 in. |
|----------------------|-----------------------|-----------------------------|



**IMPORTANT**

- When replacing fan belt, be careful not to catch it on the cap under the water pump. See the illustration to the left.

- (1) Tension Bolt
- (2) Alternator

(3) Adjustment Bolt

9Y1210265GEG0031US0



**Checking Mower Blade and Replacing Mower Blade**

1. Check the cutting edge of mower blade.
2. Sharpen the cutting edges, if the mower blades are as shown in figure (2).
3. Replace the mower blades, if they are as shown in figure (3).

**NOTE**

- To sharpen the mower blades by yourself, clamp the mower blade securely in a vise and use a large mill file along the original bevel.
- To balance the mower blade, place a small rod through the center hole and check to see if the blade balances evenly. File heavy side of the blade until it balance out even.


4. Tilt up the mower deck.
5. Wedge a wooden block securely between the mower blade and mower deck or use a box wrench over the pulley nut to prevent the spindle from rotating while removing the blade bolts; then loosen the blade bolts.
6. Pass the spline boss through the blade (5) and 2 cup washers (6), and tighten the bolt (8).

**NOTE**

- Make sure that the cup washer is not flattened out or worn; this cause blade to slip excessively. Replace the 2 cup washers if either is damaged.

- |                    |                        |
|--------------------|------------------------|
| (1) New Blade      | (6) 2 Cup Washers      |
| (2) Worn Blade     | (7) Lock Washer        |
| (3) Cracked Blade  | (8) Bolt               |
| (4) Spindle Holder |                        |
| (5) Blade          | (A) 30 mm (1-3/16 in.) |

9Y1210265GEG0058US0



**Replacing Mower Belt**

1. Remove the mower deck from the machine.
2. Remove the left and right hand shield from the mower deck.
3. Clean around the gear box.
4. Remove the belt from the tension pulley.
5. Remove the right hand bracket which mounts the gear box to the mower deck and slip the belt over the top of the gear box.
6. To install a new belt, reverse the above procedure.

|                   |                        |   |
|-------------------|------------------------|---|
| Tightening torque | Bracket mounting screw | 27.6 to 90.2 N·m<br>8.0 to 9.2 kgf·m<br>57.1 to 66.5 lbf·ft |
|-------------------|------------------------|---|

- |                    |          |
|--------------------|----------|
| (1) Tension Pulley | (3) Belt |
| (2) Bracket (RH)   |          |

9Y1210265GEG0059US0

**Bleeding Fuel System**

**Air must be removed:**

1. When the fuel filter or lines are removed.
2. When tank is completely empty.
3. After the tractor has not been used for a long period of time.

**Bleeding procedure is as follows:**


1. Fill the fuel tank with fuel.
2. Turn the key switch to "ON" position for about 30 seconds. Doing so allows fuel pump to work and pump air out of the fuel system.
3. Start the engine and run for about 30 seconds, and then stop the engine.

9Y1210265GEG0060US0

# 10. IMPLEMENT LIMITATIONS

The KUBOTA Tractor has been thoroughly tested for proper performance with implements sold or approved by KUBOTA. Use with implements which are not sold or approved by KUBOTA and which exceed the maximum specifications listed below, or which are otherwise unfit for use with the KUBOTA Tractor may result in malfunctions or failures of the tractor, damage to other property and injury to the operator or others. [Any malfunctions or failures of the tractor resulting from use with improper implements are not covered by the warranty.]

|                                     | Maximum loading weight |                   | Implement weight<br>$W_1$ | Maximum total weight |
|-------------------------------------|------------------------|-------------------|---------------------------|----------------------|
|                                     | Front axle $W_f$       | Rear axle $W_r$   |                           |                      |
| ZD321N, ZD321                       | 200 kg (440 lbs)       | 920 kg (2028 lbs) | 200 kg (440 lbs)          | 1120 kg (2468 lbs)   |
| ZD323                               |                        |                   |                           |                      |
| ZD326S, ZD326P,<br>ZD326RP, ZD326HL |                        |                   |                           |                      |
| ZD331P, ZD331RP,<br>ZD331LP         |                        |                   |                           |                      |



3GZAAAG0P042A

9Y1210265GEG0070US0

# SERVICING

## CONTENTS

|  |       |
|--|-------|
| 1. TROUBLESHOOTING.....                                | 1-S1  |
| 2. SERVICING SPECIFICATIONS .....                      | 1-S5  |
| [1] D782-E2/E3, D902-E3/E4 .....                       | 1-S5  |
| [2] D1005-E2/E3/E4, D1105-E4, D1305-E3 .....           | 1-S11 |
| 3. TIGHTENING TORQUES.....                             | 1-S18 |
| 4. CHECKING, DISASSEMBLING AND SERVICING .....         | 1-S20 |
| [1] CHECKING AND ADJUSTING.....                        | 1-S20 |
| (1) Engine Body .....                                  | 1-S20 |
| (2) Lubricating System .....                           | 1-S22 |
| (3) Cooling System .....                               | 1-S22 |
| (4) Fuel System.....                                   | 1-S25 |
| [2] SEPARATING ENGINE.....                             | 1-S30 |
| [3] DISASSEMBLING AND ASSEMBLING .....                 | 1-S34 |
| (1) D782-E2/E3, D902-E3/E4 .....                       | 1-S34 |
| (2) D1005-E3/E4, D1105-E4, D1305-E3.....               | 1-S49 |
| [4] SERVICING.....                                     | 1-S63 |
| (1) Cylinder Head and Valves.....                      | 1-S63 |
| (2) Timing Gears, Camshaft and Governor Gear.....      | 1-S71 |
| (3) Piston and Connecting Rod.....                     | 1-S75 |
| (4) Crankshaft .....                                   | 1-S81 |
| (5) Cylinder .....                                     | 1-S90 |
| (6) Oil Pump (D782-E2/E3, D902-E3/E4).....             | 1-S91 |
| (7) Oil Pump (D1005-E2/E3/E4, D1105-E4, D1305-E3)..... | 1-S92 |

**FUEL SYSTEM**

| Item                        |  | Factory Specification   | Allowable Limit   |
|-----------------------------|--|---|---|
| Injection Pump [D782-E2]    | Injection Timing<br>(3200 min <sup>-1</sup> (rpm)) | 0.28 to 0.31 rad<br>(16 to 18 °)<br>before T.D.C.   | –   |
| Injection Pump [D782-E3]    | Injection Timing<br>(3200 min <sup>-1</sup> (rpm)) | 0.2837 to 0.3097 rad<br>(16.25 to 17.75 °)<br>before T.D.C.   | –   |
| Injection Pump [D902-E3/E4] | Injection Timing<br>(3200 min <sup>-1</sup> (rpm)) | 0.3011 to 0.3272 rad<br>(17.25 to 18.75 °)<br>before T.D.C.   | –   |
| Pump Element                | Fuel Tightness                                     | –   | 13.73 MPa<br>140.0 kgf/cm <sup>2</sup><br>1991 psi  |
| Delivery Valve              | Fuel Tightness                                     | 10 seconds<br>13.73 → 12.75 MPa<br>140.0 → 130.0 kgf/cm <sup>2</sup><br>1991 → 1849 psi                                   | 5 seconds<br>13.73 → 12.75 MPa<br>140.0 → 130.0<br>kgf/cm <sup>2</sup><br>1991 → 1849 psi |
| Injection Nozzle            | Injection Pressure                                 | 13.73 to 14.70 MPa<br>140.0 to 149.8 kgf/cm <sup>2</sup><br>1992 to 2132 psi  | –   |
| Injection Nozzle Valve Seat | Valve Seat<br>Tightness                            | When the pressure is<br>12.75 MPa<br>(130.0 kgf/cm <sup>2</sup> , 1849<br>psi), the valve seat must<br>be fuel tightness. | –   |

9Y1210265ENS0075US0

# 4. CHECKING, DISASSEMBLING AND SERVICING

## [1] CHECKING AND ADJUSTING

### (1) Engine Body



#### Compression Pressure

1. Run the engine until it is warmed up.
2. Stop the engine.
3. Remove the air cleaner, the muffler and all glow plugs (or nozzles).
4. Set a compression tester with the adaptor to the glow plug hole (or nozzle hole).  
 Nozzle hole: Adaptor H (07909-31231)  
 Glow plug hole: Adaptor L (07909-31301)
5. After making sure that the stop lever is set at the stop position (non-injection), run the engine with the starter and measure the compression pressure.
6. Repeat steps 4 and 5 for each cylinder.
7. If the measurement is below the allowable limit, apply a small amount of oil to the cylinder wall through the glow plug hole (or nozzle hole) and measure the compression pressure again.
8. If the compression pressure is still less than the allowable limit, check the top clearance, valve clearance and cylinder head.
9. If the compression pressure increases after applying oil, check the cylinder wall and piston rings.

■ **NOTE**

- Check the compression pressure with the specified valve clearance.
- Always use a fully charged battery for performing this test.
- Variances in cylinder compression values should be under 10 %.

#### **[D782-E2/E3]**

|                      |                       |  |
|----------------------|-----------------------|--|
| Compression pressure | Factory specification | 2.85 to 3.23 MPa<br>29.1 to 32.9 kgf/cm <sup>2</sup><br>414 to 468 psi |
|                      | Allowable limit       | 2.26 MPa<br>23.0 kgf/cm <sup>2</sup><br>328 psi                        |

#### **[D902-E3/E4]**




|                      |                       |  |
|----------------------|-----------------------|--|
| Compression pressure | Factory specification | 3.53 to 4.02 MPa<br>36.0 to 40.9 kgf/cm <sup>2</sup><br>512 to 583 psi |
|                      | Allowable limit       | 2.55 MPa<br>26.0 kgf/cm <sup>2</sup><br>370 psi                        |

#### **[D1005-E2/E3/E4, D1105-E4, D1305-E3]**

|                      |                       |  |
|----------------------|-----------------------|--|
| Compression pressure | Factory specification | 3.73 to 4.11 MPa<br>38.1 to 41.9 kgf/cm <sup>2</sup><br>541 to 596 psi |
|                      | Allowable limit       | 2.26 MPa<br>23.0 kgf/cm <sup>2</sup><br>328 psi                        |

9Y1210265ENS0003US0

## [2] SEPARATING ENGINE



### Draining Engine Oil

1. Park the machine on level ground.
2. Start and warm up the engine for approx. 5 minutes.
3. Place an oil pan underneath the engine.
4. Remove the drain plug (1) to drain oil.
5. After draining, screw in the drain plug (1).

### (When refilling)

- Fill the engine oil up to the upper line on the dipstick (3).

|                     |                |                                       |
|---------------------|----------------|---------------------------------------|
| Engine oil capacity | ZD321<br>ZD323 | 3.5 L<br>3.70 U.S.qts<br>3.08 Imp.qts |
|                     | ZD326          | 3.9 L<br>4.1 U.S.qts<br>3.4 Imp.qts   |
|                     | ZD331          | 5.7 L<br>6.0 U.S.qts<br>5.0 Imp.qts   |

### ■ IMPORTANT

- Never mix two different type of oil.
- Use the proper SAE Engine Oil according to ambient temperatures.

Refer to "LUBRICANTS, FUEL AND COOLANT". (See page G-9.)

- (1) Drain Plug
- (2) Oil Inlet Plug
- (3) Dipstick


[A] ZD321, ZD323

[B] ZD326, ZD331

A: Upper Level

B: Lower Level

9Y1210265ENS0020US0



**Gear Case**


1. Disconnect the start spring (2) from the fork lever 1 (3).
2. Remove the screw (1) of inside the gear case and outside screws.
3. Remove the gear case (4).

**(When reassembling)**

- Apply a liquid gasket (Three Bond 1215 or equivalent) to both sides of the gear case gasket.
- Be sure to set three O-rings inside the gear case.

- |                    |                  |
|--------------------|------------------|
| (1) Screw (Inside) | (3) Fork Lever 1 |
| (2) Start Spring   | (4) Gear Case    |

9Y1210265ENS0038US0




**Idle Gear**


1. Remove the external snap ring (3), the collar (2) and the idle gear (1).
2. Remove the idle gear shaft mounting screws (4).
3. Remove the idle gear shaft (5) (if necessary).

**(When reassembling)**

- Apply engine oil to the idle gear shaft mounting screw (4). And tighten them.
- Install the idle gear, aligning the mark (6) on the gears referring to the photo.







|                   |                                |   |
|-------------------|--------------------------------|---|
| Tightening torque | Idle gear shaft mounting screw | 9.81 to 11.2 N·m<br>1.00 to 1.15 kgf·m<br>7.24 to 8.31 lbf·ft |
|-------------------|--------------------------------|---|



- |                        |                                    |
|------------------------|------------------------------------|
| (1) Idle Gear          | (4) Idle Gear Shaft Mounting Screw |
| (2) Idle Gear Collar   | (5) Idle Gear Shaft                |
| (3) External Snap Ring | (6) Alignment Mark                 |

9Y1210265ENS0039US0





**Nozzle Holder Assembly and Glow Plug**

1. Remove the overflow pipe (1).
2. Remove the nozzle holder assemblies (4).
3. Remove the copper gasket (5) and heat seal (6).
4. Remove the lead (2) from the glow plugs (3).
5. Remove the glow plugs (3).

**(When reassembling)**

- Replace the copper gasket and heat seal with new one.

|                   |   |  |
|-------------------|---|--|
| Tightening torque | Overflow pipe retaining nut<br>(Serial No.: below BTZ999) | 20 to 24 N·m<br>2.0 to 2.5 kgf·m<br>15 to 18 lbf·ft    |
|                   | Overflow pipe retaining nut<br>(Serial No.: above BU0001) | 35 to 39 N·m<br>3.5 to 4.0 kgf·m<br>26 to 28 lbf·ft    |
|                   | Nozzle holder assembly                                    | 49 to 68 N·m<br>5.0 to 7.0 kgf·m<br>37 to 50 lbf·ft    |
|                   | Glow plug   | 7.9 to 14 N·m<br>0.80 to 1.5 kgf·m<br>5.8 to 10 lbf·ft |

- |                   |                            |
|-------------------|----------------------------|
| (1) Overflow Pipe | (4) Nozzle Holder Assembly |
| (2) Lead          | (5) Copper Gasket          |
| (3) Glow Plug     | (6) Heat Seal              |

9Y1210265ENS0053US0

**Nozzle Heat Seal Service Removal Procedure**

■ **IMPORTANT**

- Use a plus (phillips head) screw driver (1) of which diameter is bigger than the heat seal hole (Approx. 6 mm (1/4 in.)).

1. Drive screw driver (1) lightly into the heat seal hole.
2. Turn screw driver three or four times each way.
3. While turning the screw driver, slowly pull the heat seal (4) out together with the injection nozzle gasket (3).
4. If the heat seal drops, repeat the above procedure.


**(When reassembling)**

- Heat seal and injection nozzle gasket must be changed when the injection nozzle is removed for cleaning or for service.

- |                       |                             |
|-----------------------|-----------------------------|
| (1) Plus Screw Driver | (3) Injection Nozzle Gasket |
| (2) Nozzle Holder     | (4) Heat Seal               |

9Y1210265ENS0054US0

**[D] Flywheel and Crankshaft**



**Flywheel**

1. Secure the flywheel to keep it from turning, using a flywheel stopper.
2. Remove all flywheel screws (1) and then remove the flywheel (2).

**(When reassembling)**


- Align the "1TC" mark (a) on the outer surface of the flywheel horizontally with the alignment mark (b) on the rear end plate. Now fit the flywheel in position.
- Apply engine oil to the threads and the undercut surface of the flywheel screw and fit the screw.

|                   |                |   |
|-------------------|----------------|---|
| Tightening torque | Flywheel screw | 54 to 58 N·m<br>5.5 to 6.0 kgf·m<br>40 to 43 lbf·ft |
|-------------------|----------------|---|

- (1) Flywheel Screw
- (2) Flywheel

- (a) 1TC Mark
- (b) Alignment Mark

9Y1210265ENS0070US0



**Bearing Case Cover**


1. Remove the bearing case cover mounting screws.
2. Remove the bearing case cover (6).

**■ IMPORTANT**

- The length of inside screws (1) and outside screws (2) are different. Do not take a mistake using inside screws and outside screws.

**(When reassembling)**

- Fit the bearing case gasket (3) and the bearing case cover gasket (4) with correct directions.
- Install the bearing case cover (6) to position the casting mark "UP" on it upward.
- Apply engine oil to the oil seal (5) lip and be careful that it is not rolled when installing.
- Tighten the bearing case cover mounting screws with even force on the diagonal line.





|                   |                                   |   |
|-------------------|-----------------------------------|---|
| Tightening torque | Bearing case cover mounting screw | 10.8 to 12.2 N·m<br>1.10 to 1.25 kgf·m<br>7.96 to 9.04 lbf·ft |
|-------------------|-----------------------------------|---|

- (1) Bearing Case Cover Mounting Screw (Inside) (Long)
- (2) Bearing Case Cover Mounting Screw (Outside) (Short)
- (3) Bearing Case Gasket
- (4) Bearing Case Cover Gasket

- (5) Oil Seal
- (6) Bearing Case Cover
- (a) Top Mark "UP"
- (b) Upside

9Y1210265ENS0071US0




CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL




**Push Rod Alignment**

1. Place the push rod on V blocks.
2. Measure the push rod alignment.
3. If the measurement exceeds the allowable limit, replace the push rod.

|                    |                 |                       |
|--------------------|-----------------|-----------------------|
| Push rod alignment | Allowable limit | 0.25 mm<br>0.0098 in. |
|--------------------|-----------------|-----------------------|

9Y1210265ENS0089US0



**Oil Clearance between Tappet and Tappet Guide Bore**

1. Measure the tappet O.D. with an outside micrometer.
2. Measure the I.D. of the tappet guide bore with a cylinder gauge, and calculate the oil clearance.
3. If the oil clearance exceeds the allowable limit or the tappet is damaged, replace the tappet.

**[D782-E2/E3, D902-E3/E4]**

|  |                       |  |
|--|-----------------------|--|
| Oil clearance between tappet and tappet guide bore | Factory specification | 0.016 to 0.052 mm<br>0.00063 to 0.0020 in. |
|  | Allowable limit       | 0.10 mm<br>0.0039 in.                      |

|             |                       |   |
|-------------|-----------------------|---|
| Tappet O.D. | Factory specification | 17.966 to 17.984 mm<br>0.70733 to 0.70803 in. |
|-------------|-----------------------|---|

|                        |                       |   |
|------------------------|-----------------------|---|
| Tappet guide bore I.D. | Factory specification | 18.000 to 18.018 mm<br>0.70866 to 0.70937 in. |
|------------------------|-----------------------|---|



**[D1005-E2/E3/E4, D1105-E4, D1305-E3]**

|  |                       |  |
|--|-----------------------|--|
| Oil Clearance between tappet and tappet guide bore | Factory specification | 0.020 to 0.062 mm<br>0.00079 to 0.0024 in. |
|  | Allowable limit       | 0.07 mm<br>0.003 in.                       |

|             |                       |   |
|-------------|-----------------------|---|
| Tappet O.D. | Factory specification | 19.959 to 19.980 mm<br>0.78579 to 0.78661 in. |
|-------------|-----------------------|---|

|                        |                       |   |
|------------------------|-----------------------|---|
| Tappet guide bore I.D. | Factory specification | 20.000 to 20.021 mm<br>0.78741 to 0.78822 in. |
|------------------------|-----------------------|---|

9Y1210265ENS0090US0



**Clearance between Piston ring and Piston Ring Groove**

1. Clean the rings and the ring grooves, and install each ring in its groove.
2. Measure the clearance between the ring and the groove with a feeler gauge or depth gauge.
3. If the clearance exceeds the allowable limit, replace the piston ring.
4. If the clearance still exceeds the allowable limit with new ring, replace the piston.

**[D782-E2/E3, D902-E3/E4]**

|  |             |                       |  |
|--|-------------|-----------------------|--|
| Clearance between piston ring and piston ring groove | Second ring | Factory specification | 0.090 to 0.120 mm<br>0.0036 to 0.00472 in. |
|  |             | Allowable limit       | 0.15 mm<br>0.0059 in.                      |
|  | Oil ring    | Factory specification | 0.040 to 0.080 mm<br>0.0016 to 0.0031 in.  |
|  |             | Allowable limit       | 0.15 mm<br>0.0059 in.                      |

**[D1005-E2/E3]**

|  |             |                       |  |
|--|-------------|-----------------------|--|
| Clearance between piston ring and piston ring groove | Second ring | Factory specification | 0.085 to 0.112 mm<br>0.0034 to 0.00440 in. |
|  |             | Allowable limit       | 0.20 mm<br>0.0079 in.                      |
|  | Oil ring    | Factory specification | 0.020 to 0.055 mm<br>0.00079 to 0.0021 in. |
|  |             | Allowable limit       | 0.15 mm<br>0.0059 in.                      |

**[D1305-E3]**

|  |             |                       |  |
|--|-------------|-----------------------|--|
| Clearance between piston ring and piston ring groove | Second ring | Factory specification | 0.095 to 0.122 mm<br>0.0038 to 0.00480 in. |
|  |             | Allowable limit       | 0.20 mm<br>0.0079 in.                      |
|  | Oil ring    | Factory specification | 0.020 to 0.060 mm<br>0.00079 to 0.0024 in. |
|  |             | Allowable limit       | 0.15 mm<br>0.0059 in.                      |

**[D1005-E4, D1105-E4]**



|  |             |                       |  |
|--|-------------|-----------------------|--|
| Clearance between piston ring and piston ring groove | Second ring | Factory specification | 0.085 to 0.112 mm<br>0.0034 to 0.00440 in. |
|  |             | Allowable limit       | 0.20 mm<br>0.0079 in.                      |
|  | Oil ring    | Factory specification | 0.02 to 0.06 mm<br>0.0008 to 0.002 in.     |
|  |             | Allowable limit       | 0.15 mm<br>0.0059 in.                      |

|                           |                                  |
|---------------------------|----------------------------------|
| Factory specification : a | More than<br>0.2 mm<br>0.008 in. |
|---------------------------|----------------------------------|

**(A) Top Ring (Key Stone Type)**

**(B) 2nd, Oil Ring**

9Y1210265ENS0104US0



**Replacing Crankshaft Sleeve**

1. Remove the used crankshaft sleeve.
2. Set the sleeve guide (2) to the crankshaft.
3. Heat a new sleeve to a temperature between 150 and 200 °C (302 and 392 °F), and fix the sleeve to the crankshaft as shown in figure.
4. Press fit the sleeve using the auxiliary socket for pushing (3).



**NOTE**

- Mount the sleeve with its largely chamfered surface facing outward.
- Should heating is not enough, a sleeve might stop halfway, so careful.

- (1) Crankshaft Sleeve (3) Auxiliary Socket for Pushing  
 (2) Sleeve Guide (4) Crankshaft

9Y1210265ENS0111US0

**(5) Cylinder**



**Cylinder Wear**

1. Measure the I.D. of the cylinder at the six positions (see figure) with a cylinder gauge to find the maximum and minimum I.D.'s.
2. Get the difference (Maximum wear) between the maximum and the minimum I.D.'s.
3. If the wear exceeds the allowable limit, bore and hone to the oversize dimension. (Refer to "Correcting Cylinder".)
4. Visually check the cylinder wall for scratches. If deep scratches are found, the cylinder should be bored. (Refer to "Correcting Cylinder".)

**[D782-E2/E3]**

|                     |                       |   |
|---------------------|-----------------------|---|
| Cylinder liner I.D. | Factory specification | 67.000 to 67.019 mm<br>2.6378 to 2.6385 in. |
|                     | Allowable limit       | 67.150 mm<br>2.6437 in.                     |

**[D902-E3/E4]**

|                     |                       |   |
|---------------------|-----------------------|---|
| Cylinder liner I.D. | Factory specification | 72.000 to 72.019 mm<br>2.8347 to 2.8353 in. |
|                     | Allowable limit       | 72.150 mm<br>2.8406 in.                     |

**[D1005-E2/E3/E4]**

|               |                       |   |
|---------------|-----------------------|---|
| Cylinder I.D. | Factory specification | 76.000 to 76.019 mm<br>2.9922 to 2.9928 in. |
|               | Allowable limit       | 76.15 mm<br>2.998 in.                       |

**[D1105-E4, D1305-E3]**


|               |                       |   |
|---------------|-----------------------|---|
| Cylinder I.D. | Factory specification | 78.000 to 78.019 mm<br>3.0709 to 3.0716 in. |
|               | Allowable limit       | 78.15 mm<br>3.077 in.                       |

- (A) Top  
 (B) Middle  
 (C) Bottom (Skirt)

- (a) Right-angled to Piston Pin  
 (b) Piston Pin Direction

9Y1210265ENS0112US0

### (5) Control Linkage



(1) Motion Control Lever (2) Speed Shaft (3) Speed Limit Spring (4) Speed Control Rod (5) Trunnion Arm

The motion control lever (1) and the trunnion shaft of variable swashplate are linked with the speed shaft (2), speed control rod (4) and the trunnion arm (5). As the motion control lever (1) is pushed, the swashplate rotates and forward travelling speed increases. Pulling the motion control lever (1) increases reverse speed.

Moreover, it is possible to fix to a neutral position by putting the motion control lever (1) in the neutral slot. The motion control lever (1) is pushed by the speed limit spring's (3) working when the motion control lever (1) is removed from the neutral slot. As the result, the machine synchronizes with the movement of the motion control lever (1) and begins to move slowly. (The machine is set like this.) The damper connected to the speed shaft (2) restricts the movement of the linkage to prevent abrupt operation or reversing.

■ **Steering**

The Zero-Turn Mower does not have a separate steering system. Steering is controlled by varying the wheel motor speeds. This gives the machine a zero-turn capability.

As the control levers are moved to a full left turn position, the right hydraulic pump is moved to the full-speed forward position and the left pump is moved to the full-speed reverse position. This will allow the machine to pivot around its center.

9Y1210265TXM0006US0

### 3. TIGHTENING TORQUES




Tightening torques of screws, bolts and nuts on the table below are especially specified.  
 (For general use screws, bolts and nuts: See page G-13.)

| Item   | N·m            | kgf·m        | lbf·ft       |
|--|----------------|--------------|--------------|
| Motion control lever mounting bolt and nut   | 18 to 20       | 1.8 to 2.1   | 13 to 15     |
| Hydrostatic transmission mounting screw (M10, 7T, Aluminum)                                  | 40 to 44       | 4.0 to 4.5   | 29 to 32     |
| Universal joint mounting screw   | 26.5 to 28.4   | 2.7 to 2.9   | 19.6 to 20.9 |
| Rear axle gear case mounting assembly screw (M12, 7T)  | 85 to 90       | 8.7 to 9.2   | 63 to 66     |
| Rear axle gear case mounting screw (M10, 7T, Aluminum)                                       | 40 to 44       | 4.0 to 4.5   | 29 to 32     |
| Hydraulic pump mounting screw  | 40 to 44       | 4.0 to 4.5   | 29 to 32     |
| Center case rear cover mounting screw  | 40 to 44       | 4.0 to 4.5   | 29 to 32     |
| Center section mounting hex. socket head screw   | 25 to 29       | 2.6 to 3.0   | 18 to 21     |
| Check and high pressure relief valve plug  | 59 to 78       | 6.0 to 8.0   | 44 to 58     |
| Engine mounting nut  | 24 to 27       | 2.4 to 2.8   | 18 to 20     |
| ROPS mounting screw (M10, 7T)  | 48 to 55       | 4.9 to 5.7   | 36 to 41     |
| Rear wheel mounting screw  | 108.5 to 130.2 | 11.1 to 13.3 | 80 to 96     |
| Center case front cover mounting screw (M10, 7T, Aluminum)                                   | 40 to 44       | 4.0 to 4.5   | 29 to 32     |
| Hydrostatic transmission and rear axle gear case assembly mounting screw (M10, 7T, Aluminum) | 48 to 56       | 4.9 to 5.7   | 35 to 41     |
| ROPS connecting plate mounting screw (M8, 7T)  | 24 to 27       | 2.4 to 2.8   | 18 to 20     |
| ROPS connecting plate under mounting screw (M10, 7T)   | 48 to 55       | 4.9 to 5.7   | 36 to 41     |

9Y1210265TXS0003US0

# 5. DISASSEMBLING AND ASSEMBLING

## [1] SEPARATING TRANSAXLE ASSEMBLY



### Draining Transmission Fluid

#### ⚠ CAUTION

To avoid personal injury:

- Be sure to stop the engine and remove the key before changing or checking the oil.
- Allow transmission case to cool down sufficiently; oil can be hot and may cause burns.

The fluid in the transmission case is also used for the hydrostatic drive system.

1. To drain the transmission oil, place oil pan underneath the transmission case and the rear axle gear case (RH and LH) and remove the drain plug at the bottom of the transmission case and the rear axle gear case (RH and LH).
2. After draining, reinstall the drain plugs.
3. Fill with new fluid from filling port after removing the filling plug (4) up the upper notch on the dipstick.

#### ■ IMPORTANT

- It takes time to pour the oil from the transmission case to the rear axle case RH and LH. Pour the regulated amount of oil slowly.

4. After running the engine for a few minutes, stop it and check the oil level again; add oil to the prescribed level.

#### ■ IMPORTANT

- Operate only at low RPM's immediately after changing the transmission fluid and filter cartridge. Keep the engine at medium speed for a few minutes to ensure proper lubrication of all parts so there is no damage to transmission.
- Use only multi-grade transmission oil. Use of other oils may damage the transmission of hydraulic system. Refer to "LUBRICANTS, FUEL AND COOLANT". (See page G-9.)
- Do not mix different brands oil together.

|                             |  |
|-----------------------------|--|
| Transmission fluid capacity | 12.1 L<br>12.8 U.S.qts<br>10.6 Imp.qts |
|-----------------------------|--|

- (1) Transmission Oil Filter
- (2) Drain Plug
- (3) Rear Axle Gear Case LH
- (4) Oil Plug and Breather Cup
- (5) Dipstick

A : Oil level acceptable within this range.

9Y1210265TXS0014US0

### Battery


#### ⚠ CAUTION

- When disconnecting the battery cables, disconnect the negative cable from the battery first. When connecting, connect the positive cable to the battery first.

1. Remove the battery cover (1).
2. Disconnect the negative cable (3) from the battery.
3. Disconnect the positive cable (2) from the battery.

- (1) Battery Cover
- (2) Positive Cable
- (3) Negative Cable

9Y1210265TXS0015US0





**Oil Cooler, Radiator, Universal Joint and Others**



1. Remove the bonnet cover (1) and ROPS connecting plate.
2. Remove the oil cooler (2).
3. Remove the radiator (3).
4. Remove the ROPS connecting plate under (4).
5. Remove the universal joint (5).
6. Remove the oil cooler pipe (6).
7. Remove the hydraulic pump assembly (7).
8. Remove the oil filter cartridge (8).

**(When reassembling)**

■ **NOTE**


- **Make sure to mount the cushion rubber on the oil cooler pipe.**

|                   |  |   |
|-------------------|--|---|
| Tightening torque | ROPS connecting plate mounting screw (M8)        | 24 to 27 N·m<br>2.4 to 2.8 kgf·m<br>18 to 20 lbf·ft |
|                   | ROPS connecting plate under mounting screw (M10) | 48 to 55 N·m<br>4.9 to 5.7 kgf·m<br>36 to 41 lbf·ft |
|                   | Hydraulic pump mounting screw                    | 40 to 44 N·m<br>4.0 to 4.5 kgf·m<br>29 to 32 lbf·ft |



- |                                  |                             |
|----------------------------------|-----------------------------|
| (1) Bonnet Cover                 | (5) Universal Joint         |
| (2) Oil Cooler                   | (6) Oil Cooler Pipe         |
| (3) Radiator                     | (7) Hydraulic Pump Assembly |
| (4) ROPS Connecting Plate, Under | (8) Oil Filter Cartridge    |

9Y1210265TXS0036US0



**Universal Joint and PTO Shaft Oil Seal**


1. Disconnect the universal joint (2).
2. Remove the PTO shaft oil seal (1).


**(When reassembling)**

- Replace the PTO shaft oil seal with new one.

- |                        |                     |
|------------------------|---------------------|
| (1) PTO Shaft Oil Seal | (2) Universal Joint |
|------------------------|---------------------|

9Y1210265TXS0037US0





### **Parking Brake**

1. Remove the internal snap ring (1), friction plates (2) and brake discs (3).
2. Remove the external snap ring (4), brake cam (5) and balls (6).


#### **(When reassembling)**

- Align splines of brake shaft and brake discs (3).
- Do not damage brake discs (3).
- Apply transmission fluid to brake discs (3).

- |                        |                        |
|------------------------|------------------------|
| (1) Internal Snap Ring | (4) External Snap Ring |
| (2) Friction Plate     | (5) Brake Cam          |
| (3) Brake Disc         | (6) Ball               |



9Y1210265TXS0053US0




# 1. TROUBLESHOOTING

| Symptom                                     | Probable Cause  | Solution   | Reference Page |
|---|---|--|----------------|
| <b>Front Wheels Wander to Right or Left</b> | Clearance between center pin and front axle excessive         | Check the clearance and replace the center pin or front axle | 3-S6           |
|   | Tightening torque of locking nut for the wheel bracket weak   | Adjust   | 3-S5           |
|   | Clearance between front axle and front axle support excessive | Adjust   | 3-S4           |

9Y1210265FAS0001US0

### 3. HYDRAULIC CONTROL VALVE



3GZAAAG8P003A

The hydraulic system is composed of the transmission case (oil tank), cushion oil filter, hydraulic pump, control valve, hydraulic cylinder and etc..

The new series product is provided with a built-in control valve in the case.


The oil flows through the oil filter, and then the oil is sent to the control valve by the pump.

After flowing through the control valve, the oil is sent to the PTO clutch and the HST charge circuit.

(1) Control Valve




**A : From Hydraulic Pump**  
**B : To PTO Clutch**  
**C : To Hydrostatic Transmission**

9Y1210265HYM0003US0



3GZAAAG8P004A

## (2) Disassembling and Assembling the Hydraulic Control Valve



### Draining Transmission Fluid

#### ⚠ CAUTION

To avoid personal injury:

- Be sure to stop the engine and remove the key before changing or checking the oil.
- Allow transmission case to cool down sufficiently; oil can be hot and may cause burns.

The fluid in the transmission case is also used for the hydrostatic drive system.

1. To drain the transmission oil, place oil pan underneath the transmission case and the rear axle gear case (RH and LH) and remove the drain plug at the bottom of the transmission case and the rear axle gear case (RH and LH).
2. After draining, reinstall the drain plugs.
3. After removing the oil plug (4), up the upper notch on the dipstick fill with new fluid from filling port.

#### ■ IMPORTANT

- It takes time to pour the oil from the transmission case to the rear axle case RH and LH. Pour the regulated amount of oil slowly.

4. After running the engine for a few minutes, stop it and check the oil level again; add oil to the prescribed level.

#### ■ IMPORTANT


- Operate only at low RPM's immediately after changing the transmission fluid and filter cartridge. Keep the engine at medium speed for a few minutes to ensure proper lubrication of all parts so there is no damage to transmission.
- Use only multi-grade transmission oil. Use of other oils may damage the transmission of hydraulic system. Refer to "LUBRICANTS, FUEL AND COOLANT". (See page G-9.)
- Do not mix different brands oil together.

|                             |              |
|-----------------------------|--------------|
| Transmission fluid capacity | 12.1 L       |
|                             | 12.8 U.S.qts |
|                             | 10.6 Imp.qts |

- (1) Transmission Oil Filter
- (2) Drain Plug
- (3) Rear Axle Gear Case LH
- (4) Oil Plug and Breather Cup
- (5) Dipstick

**A :** Oil level acceptable within this range.

9Y1210265TXS0050US0



**Mower Linkage**


1. Remove the clevis pins (5) and horizon plate (2).
2. Remove the front pin (4) and front arm (3).
3. Remove the clevis pin, and disconnect the lift shaft (1) and lift cylinder.
4. Remove the plates (7) and lift shaft (1) with bushings (6).

**(When reassembling)**



- Apply grease to front pins (4).

- |                   |                |
|-------------------|----------------|
| (1) Lift Shaft    | (5) Clevis Pin |
| (2) Horizon Plate | (6) Bushing    |
| (3) Front Arm     | (7) Plate      |
| (4) Front Pin     |                |

9Y1210265HYS0020US0



## [1] AC DYNAMO




The dynamo is an 8-8 pole rotating magnet type generator. It is simple in construction, consisting of a stator and rotor. The rotor is made up of eight permanent magnet pole pieces assembled on a shaft and rotates on the center of the stator around which eight electromagnetic coils are provided for.

This dynamo produces higher voltage in slow speed rotation, and charges electric current to the battery during engine idling.

9Y1210265ELM0010US0

## [2] REGULATOR





The regulator performs rectification and voltage regulation.

The regulator converts AC into DC which flows through the power consuming circuits and the battery, and also charges the battery.

If however, the battery voltage exceeds a certain level, the DC current is cut off from the charging circuit to prevent overcharging.

9Y1210265ELM0011US0



**Battery Specific Gravity**

1. Check the specific gravity of the electrolyte in each cell with a hydrometer.
2. When the electrolyte temperature differs from that at which the hydrometer was calibrated, correct the specific gravity reading following the formula mentioned in (Reference).
3. If the specific gravity is less than 1.215 (after it is corrected for temperature), charge or replace the battery.
4. If the specific gravity differs between any two cells by more than 0.05, replace the battery.

■ **NOTE**

- **Hold the hydrometer tube vertical without removing it from the electrolyte.**
- **Do not suck too much electrolyte into the tube.**
- **Allow the float to move freely and hold the hydrometer at eye level.**
- **The hydrometer reading must be taken at the highest electrolyte level.**

**(Reference)**

- Specific gravity slightly varies with temperature. To be exact, the specific gravity decreases by 0.0007 with an increase of 1 °C (0.0004 with an increase of 1 °F) in temperature, and increases by 0.0007 with a decreases of 1 °C (0.0004 with a decrease of 1 °F).

Therefore, using 20 °C (68 °F) as a reference, the specific gravity reading must be corrected by the following formula:

- Specific gravity at 20 °C = Measured value + 0.0007 × (electrolyte temperature – 20 °C)
- Specific gravity at 68 °F = Measured value + 0.0004 × (electrolyte temperature – 68 °F)

| Specific Gravity | State of Charge             |
|------------------|-----------------------------|
| 1.260 Sp. Gr.    | 100 % Charged               |
| 1.230 Sp. Gr.    | 75 % Charged                |
| 1.200 Sp. Gr.    | 50 % Charged                |
| 1.170 Sp. Gr.    | 25 % Charged                |
| 1.140 Sp. Gr.    | Very Little Useful Capacity |
| 1.110 Sp. Gr.    | Discharged                  |

At an electrolyte temperature of 20 °C (68 °F)

9Y1210265ELS0007US0



# 1. TROUBLESHOOTING

| Symptom                    | Probable Cause                            | Solution   | Reference Page            |
|----------------------------|---|--|---------------------------|
| <b>Blade Does Not Turn</b> | PTO system malfunctioning                 | Check transmission                               | 2-S11,<br>2-S21,<br>2-S39 |
|                            | Broken mower belt                         | Replace mower belt                               | 6-S8                      |
| <b>Blade Speed Is Slow</b> | Loosen mower belt                         | Replace mower belt or tension spring             | 6-S8                      |
|                            | Clogged grass                             | Remove grass                                     | –                         |
|                            | Flattened out or worn cup washer          | Replace cup washer                               | 6-S7                      |
|                            | Engine rpm too low                        | Mow at full throttle, check and reset engine rpm | 1-S32                     |
| <b>Cutting Is Poor</b>     | Worn or bent mower blade                  | Sharpen or replace mower blade                   | 6-S7                      |
|                            | Loosen mower blade screw                  | Retighten mower blade screw                      | 6-S7                      |
|                            | Cutting height improper                   | Adjust cutting height                            | 6-S5                      |
|                            | Ground speed too fast                     | Slow-down  | –                         |
|                            | Low wheel inflation                       | Add air to correct                               | 6-S4                      |
|                            | Anti-scalp rollers not adjusted correctly | Adjust anti-scalp rollers                        | 6-S4                      |
| <b>Mower Is Not Lifted</b> | Broken linkage system                     | Replace linkage system                           | 4-S14 to<br>4-S15         |
|                            | Trouble of hydraulic system               | Check hydraulic system                           | 4-S4, 4-S5                |

9Y1210265MOS0001US0

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL