




# Workshop Manual

chassis

## PAJERO SPORT '99




CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL




**WHEN USING THE WARNING LAMP**

1. Use the special tool to earth No.1 terminal (diagnosis control terminal) of the diagnosis connector.
2. Turn on the ignition switch.
3. Read out a diagnosis code by observing how the warning lamp flashes.

**Applicable systems**

System name	Warning lamp name
MPI	Engine warning lamp
Auto-cruise	Auto-cruise control indicator
ABS	ABS warning lamp

**Indication of diagnosis code by warning lamp**



**METHOD OF ERASING DIAGNOSIS CODES**

**WHEN USING THE MUT-II**

Connect the MUT-II to the diagnosis connector and erase the diagnosis code.


**Caution**

Turn off the ignition switch before connecting or disconnecting the MUT-II.

**WHEN NOT USING THE MUT-II**


1. Turn the ignition switch to OFF.
2. After disconnecting the battery cable from the battery (-) terminal for 10 seconds or more, reconnect the cable.
3. After the engine has warmed up, run it at idle for about 15 minutes.

No.	Items	Contents
9	Steering wheel location	L: Left hand
		R: Right hand
10	Destination	8: For Europe

**CHASSIS NUMBER**

00100560142

The chassis number is stamped on the side wall of the frame near the rear wheel (R.H.).



No.	Items	Contents
1	Fixed figure	J Asia
2	Distribution channel	M Japan channel
3	Destination	A Right hand drive
		B Left hand drive
4	Body style	0 4 door tailgate
5	Transmission type	N 5-speed manual transmission
6	Vehicle line	K Pajero sport
7	Body type	9 4WD
8	Engine type	4 4D56: 2,477 ml diesel engine
		6 6G72: 2,972 ml petrol engine
9	Body style	0 Frame
10	Model year	X 1999

# SUPPORT LOCATIONS FOR LIFTING AND JACKING





00100070096

## Caution



Do not support the vehicles at locations other than specified supporting points. If do so, this will cause damage, etc.

## SUPPORT POSITIONS FOR A GARAGE JACK AND AXLE STANDS

### AXLE STANDS



### GARAGE JACK



## ON-VEHICLE SERVICE

11100090623


## DRIVE BELT TENSION CHECK AND ADJUSTMENT

## ALTERNATOR DRIVE BELT TENSION CHECK

Inspect the drive belt following the instructions below.

**Standard value:**

Vibration frequency Hz	At A	197 - 241
	At B	133 - 164
Tension N	At A	392 - 588
	At B	392 - 588
Deflection (Reference value) mm	At A	6.5 - 9.0
	At B	9.0 - 12.5



## &lt;When using MUT-II&gt;

1. Connect the special tool (belt tension meter set) to the MUT-II.
2. Connect the MUT-II to the diagnosis connector.
3. Turn on the ignition switch and select "Belttension measurement" from the MUT-II menu screen.
4. As shown in the illustration, keep the microphone (MB991668) 10 to 20mm away from the back side of the belt perpendicularly (within an inclination of  $\pm 15$  degrees).
5. With your finger tip lightly tap the centre of the belt between the pulleys in the location shown by the arrow in the illustration to check whether the belt frequency is within the standard.

**Caution**


1. Measure when the belt surface temperature is close to room temperature.
2. Make sure that water or oil, etc., does not get on the microphone.
3. If a strong wind blows or noise is made close to the microphone during measure, the meter will show a value that differs from the actual value.
4. If the measurement is taken with the microphone touching the belt, the meter will show a value that differs from the actual value.
5. Do not measure while the engine is running.

**CRANKSHAFT PULLEY****REMOVAL AND INSTALLATION****Pre-removal Operation**


- Skid Plate and Under Cover Removal

**Post-installation Operation**

- Drive Belt Tension Adjustment (Refer to P.11A-8.)
- Skid Plate and Under Cover Installation

**Removal steps**

1. Radiator shroud cover
2. Drive belt (for A/C)
3. Drive belt (for power steering oil pump)
4. Drive belt (for alternator)
5. Crankshaft pulley

**REMOVAL SERVICE POINT****◀A▶ CRANKSHAFT PULLEY REMOVAL**

Use special tools to remove the crankshaft pulley from the crankshaft.


## TIMING BELT

11200430800

## REMOVAL AND INSTALLATION

**Pre-removal Operation**


- Engine Coolant Draining and Refilling (Refer to GROUP 14 - On-vehicle Service.)
- Cooling Fan Removal (Refer to GROUP 14 - Cooling Fan.)
- Alternator Removal and Installation (Refer to GROUP 16 - Alternator.)



A01V0122

**Removal steps**

1. Cover
2. Power steering oil pump assembly
3. A/C compressor assembly
4. Compressor bracket
5. Timing indicator bracket
6. Accessory mount assembly




- 21. Power steering drive belt cover
- 22. Drive belt (for power steering)
- 23. Power steering oil pump assembly
- 24. Drive belt (for A/C)




- 25. A/C compressor assembly
- 26. Heat protector




- 27. Front insulator stopper
- 28. Front engine support insulator
- 29. Engine assembly



6. If the clearance is outside the standard value, loosen the lock nut of the rocker arm and adjust by turning the adjusting screw while using a thickness gauge to measure the clearance.
7. Tighten the lock nut while holding the adjusting screw with a screwdriver so that it doesn't turn.
8. Turn the crankshaft 360° clockwise to bring No. 4 cylinder to the top dead centre position.




9. Measure the valve clearances at the places indicated by arrows in the illustration. If the clearance is not within the standard value, repeat steps 7 and 8 above.



10. Apply specified sealant to the section of the semi-circular packing shown in the illustration.

**Specified sealant: 3M ATD Part No. 8660 or equivalent**


11. Install the rocker cover.
12. Install the timing belt upper cover.




## INJECTION TIMING CHECK AND ADJUSTMENT

11100180085

1. Warm up the engine and then check to be sure that the fast idle lever is separated from the accelerator lever.
2. Remove all of the glow plugs.
3. Remove the timing belt upper cover.




4. Align the timing marks of the camshaft sprocket and set the No. 1 cylinder to the top dead centre position.

**REMOVAL SERVICE POINTS****◀A▶ CAMSHAFT SPROCKET REMOVAL**


1. Rotate crankshaft clockwise (to the right) and align timing marks.

**Caution**

**Never turn the crankshaft anticlockwise.**




2. Tie the camshaft sprocket and timing belt together with cord so that timing mark is not maladjusted.



3. Use the special tool to stop the camshaft sprocket from turning, and then remove the camshaft sprocket with the timing belt still attached.

**Caution**

**Do not rotate crankshaft after removing camshaft sprocket.**

**◀B▶ CAMSHAFT OIL SEAL REMOVAL**

1. Make a notch in the oil seal lip section with a knife, etc.
2. Cover the end of a (-) screwdriver with a rag and insert into the notched section of the oil seal, and lever out the oil seal to remove it.

**Caution**


**Be careful not to damage the camshaft and the cylinder head.**

**◀C▶ ROCKER ARM AND SHAFT ASSEMBLY REMOVAL**

Loosen the rocker arm and shaft assembly mounting bolt, and then remove the rocker arm and shaft assembly with the bolt still attached.

**Caution**


**Never disassemble the rocker arm and shaft assembly.**




4. Loosen the tensioner mounting bolts and apply tension with the spring.
5. Turn the crankshaft clockwise and stop at the second lobe of the camshaft sprocket.

**Caution**

- (1) When turning the crankshaft in item (5), strictly observe the specified amount of rotation (2 teeth on the camshaft sprocket) in order to apply a constant force to the tension side of the belt.
- (2) Do not turn the crankshaft counterclockwise.
- (3) Do not touch the belt during adjustment.



6. Make sure that the part indicated by arrow A does not float upward.
7. Tighten the tensioner mounting bolts, starting with the bolt in the elongated hole. If the lower bolt is tightened first, belt tension will become too tight.




8. Turn the crankshaft anticlockwise and align the timing mark. Next, make sure that the timing marks of all sprockets are aligned.
9. Press on the centre of the bolt with an index finger to check the amount of deflection.

**Standard value: 4 - 5 mm**

### ►C◀ CRANKSHAFT PULLEY INSTALLATION

Using the special tool to install the crankshaft pulley as same as removal procedure.



5. Refill with specified quantity of oil.

**Specified Engine Oil (API classification):**

**<6G7> SG or higher**

**<4D5> CD or higher**

**Total quantity (Includes volume inside oil filter and oil cooler):**

**<6G7> 4.5 ℓ**

**<4D5> 6.5 ℓ**

6. Install the engine oil filler cap.
7. Check oil level.

## OIL FILTER REPLACEMENT


12100110272

1. Start the engine and allow it to warm up until the temperature of the coolant reaches 80°C to 90°C.
2. Remove the engine oil filler cap.
3. Remove the under cover.
4. Remove the drain plug to drain oil.

**Caution**

**Use care as oil could be hot.**

5. Remove the air cleaner, and cover the alternator with a rag so that oil will not get on the alternator. <4D56>
6. Use the respective tool in the following table to remove the engine oil filter.
7. Clean the filter bracket side mounting surface and ensure the old O-ring has been removed.



## SERVICE SPECIFICATIONS

13100030513

Items		Specifications
Basic idle speed r/min		700 ± 50
Throttle position sensor adjusting voltage mV		400 – 1,000
Throttle position sensor resistance kΩ		3.5 – 6.5
Idle speed control servo coil resistance Ω		28 – 33 (at 20°C)
Intake air temperature sensor resistance kΩ	At 20°C	2.3 – 3.0
	At 80°C	0.30 – 0.42
Engine coolant temperature sensor resistance kΩ	At 20°C	2.1 – 2.7
	At 80°C	0.26 – 0.36
Oxygen sensor output voltage V		0.6 – 1.0
Fuel pressure kPa	Vacuum hose disconnection	324 – 343 at kerb idle
	Vacuum hose connection	Approx. 265 at kerb idle
Injector coil resistance Ω		13 – 16 (at 20°C)





## SEALANT

13100050229


Item	Specified sealant	Remark
Engine coolant temperature sensor threaded portion	3M Nut Locking Part No. 4171 or equivalent	Drying sealant

## SPECIAL TOOLS

13100060574

Tool	Number	Name	Use
<p><b>A</b></p> 	<p>MB991223</p> <p>A: MB991219</p> <p>B: MB991220</p> <p>C: MB991221</p> <p>D: MB991222</p>	<p>Harness set</p> <p>A: Test harness</p> <p>B: LED harness</p> <p>C: LED harness adapter</p> <p>D: Probe</p>	<p>Measurement of terminal voltage</p> <p>A: Connector pin contact pressure inspection</p> <p>B: Power circuit inspection</p> <p>C: Power circuit inspection</p> <p>D: Commercial tester connection</p>
<p><b>B</b></p> 			
<p><b>C</b></p> 			
<p><b>D</b></p> 			

Code No. 21 Engine coolant temperature sensor system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> <li>● Ignition switch: ON</li> <li>● Excluding 60 seconds after the ignition switch is turned to ON or immediately after the engine starts.</li> </ul> <p>Set conditions</p> <ul style="list-style-type: none"> <li>● Sensor output voltage is 4.6 V or more (corresponding to an engine coolant temperature of -45°C or less) for 4 seconds.</li> </ul> <p>or</p> <ul style="list-style-type: none"> <li>● Sensor output voltage is 0.1 V or less (corresponding to an engine coolant temperature of 140°C or more) for 4 seconds.</li> </ul>	<ul style="list-style-type: none"> <li>● Malfunction of the engine coolant temperature sensor</li> <li>● Improper connector contact, open circuit or short-circuited harness wire of the engine coolant temperature sensor circuit</li> <li>● Malfunction of the engine-ECU</li> </ul>
<p>Range of Check</p> <ul style="list-style-type: none"> <li>● Ignition switch: ON</li> <li>● Engine speed is approx. 50 r/min or more</li> </ul> <p>Set conditions</p> <ul style="list-style-type: none"> <li>● The sensor output voltage increases from 1.6 V or less (corresponding to an engine coolant temperature of 40°C or more) to 1.6 V or more (corresponding to an engine coolant temperature of 40°C or less).</li> <li>● After this, the sensor output voltage is 1.6 V or more for 5 minutes.</li> </ul>	




Items		Symptom
Driving	Shock	The feeling of a comparatively large impact or vibration when the engine is accelerated or decelerated.
	Surge	This is repeated surging ahead during constant speed travel or during variable speed travel.
	Knocking	A sharp sound like a hammer striking the cylinder walls during driving and which adversely affects driving.
Stopping	Run on (“Dieseling”)	The condition in which the engine continues to run after the ignition switch is turned to OFF. Also called “Dieseling”.

**INSPECTION PROCEDURE FOR TROUBLE SYMPTOMS**


**INSPECTION PROCEDURE 1**

Communication with MUT-II is not possible. (Communication with all systems is not possible.)	Probable cause
The cause is probably a defect in the power supply system (including earth) for the diagnosis line.	<ul style="list-style-type: none"> <li>Malfunction of the connector</li> <li>Malfunction of the harness wire</li> </ul>




**INSPECTION PROCEDURE 2**

MUT-II communication with engine-ECU is not possible.	Probable cause
One of the following causes may be suspected. <ul style="list-style-type: none"> <li>No power supply to engine-ECU.</li> <li>Defective earth circuit of engine-ECU.</li> <li>Defective engine-ECU.</li> <li>Improper communication line between engine-ECU and MUT-II</li> </ul>	<ul style="list-style-type: none"> <li>Malfunction of engine-ECU power supply circuit</li> <li>Malfunction of engine-ECU</li> <li>Open circuit between engine-ECU and diagnosis connector</li> </ul>




**INSPECTION PROCEDURE 15**

Hesitation, sag or stumble	Probable cause
In cases such as the above, the cause is probably that ignition system, air/fuel mixture or compression pressure is defective.	<ul style="list-style-type: none"> <li>● Malfunction of the ignition system</li> <li>● Malfunction of air-fuel ratio control system</li> <li>● Malfunction of the fuel supply system</li> <li>● Malfunction of the EGR control solenoid valve system</li> <li>● Poor compression</li> </ul>




**INSPECTION PROCEDURE 16**

The feeling of impact or vibration when accelerating	Probable cause
In cases such as the above, the cause is probably that there is an ignition leak accompanying the increase in the spark plug demand voltage during acceleration.	<ul style="list-style-type: none"> <li>● Malfunction of the ignition system</li> </ul>




INSPECTION PROCEDURE 34

EGR control solenoid valve system	Probable cause
The EGR control solenoid valve is controlled by the negative pressure resulting from EGR operation leaking to port "A" of the throttle body.	<ul style="list-style-type: none"> <li>• Malfunction of solenoid valve</li> <li>• Improper connector contact, open circuit or short-circuited harness wire.</li> <li>• Malfunction of the engine-ECU</li> </ul>



INSPECTION PROCEDURE 35

MUT-II: Inspection of no initial combustion



## DATA LIST REFERENCE TABLE

13100890593

**Caution**


When shifting the select lever to D range, the brakes should be applied so that the vehicle does not move forward.

**NOTE**

- \*1. In a new vehicle [driven approximately 500 km or less], the air flow sensor output frequency is sometimes 10% higher than the standard frequency.
- \*2. The idle position switch normally turns off when the voltage of the throttle position sensor is 50 – 100 mV higher than the voltage at the idle position. If the idle position switch turns back on after the throttle position sensor voltage has been by 100 mV and the throttle valve has been opened, the idle position switch and the throttle position sensor need to be adjusted.
- \*3. The injector drive time represents the time when the cranking speed is at 250 r/min or below when the power supply voltage is 11 V.
- \*4. In a new vehicle [driven approximately 500 km or less], the injector drive time is sometimes 10% longer than the standard time.
- \*5. In a new vehicle [driven approximately 500 km or less], the step of the stepper motor is sometimes 30 steps greater than the standard value.



Item No.	Inspection item	Inspection contents	Normal condition	Inspection procedure No.	Reference page	
11	Oxygen sensor	Engine:After having warmed up Air/fuel mixture is made leaner when decelerating, and is made richer when racing.	When at 4,000 r/min, engine is suddenly decelerated	200 mV or less	Code No. 11	13A-13
			When engine is suddenly raced	600 – 1,000 mV		
		Engine:After having warmed up The oxygen sensor signal is used to check the air/fuel mixture ratio, and control condition by the engine-ECU.	Engine is idling	400 mV or less ↑ (Changes) ↓ 600 – 1,000 mV		
			2,500 r/min	400 mV or less ↑ (Changes) ↓ 600 – 1,000 mV		
12	Air flow sensor*1	<ul style="list-style-type: none"> <li>● Engine coolant temperature: 80 – 95°C</li> <li>● Lamps and all accessories: OFF</li> <li>● Transmission: Neutral (A/T: P range)</li> </ul>	Engine is idling	25 – 51 Hz	-	-
			2,500 r/min	74 – 114 Hz		
			Engine is raced	Frequency increases in response to racing		

## Engine-ECU Harness Side Connector Terminal Arrangement



9FU0392

Terminal No.	Inspection item	Normal condition (Check condition)
1 – 12	No. 1 injector	13 – 16 $\Omega$ (At 20°C)
14 – 12	No. 2 injector	
2 – 12	No. 3 injector	
15 – 12	No. 4 injector	13 – 16 $\Omega$ (At 20°C)
3 – 12	No. 5 injector	
16 – 12	No. 6 injector	
4 – 12	Stepper motor coil (A1)	28 – 33 $\Omega$ (At 20°C)
17 – 12	Stepper motor coil (A2)	
5 – 12	Stepper motor coil (B1)	
18 – 12	Stepper motor coil (B2)	
6 – 12	EGR control solenoid valve	36 – 44 $\Omega$ (At 20°C)
24 – 12	Purge control solenoid valve	36 – 44 $\Omega$ (At 20°C)
13 – Body earth	Engine-ECU earth	Continuity (0 $\Omega$ )
26 – Body earth	Engine-ECU earth	
72 – 92	Intake air temperature sensor	5.3 – 6.7 k $\Omega$ (When intake air temperature is 0°C)
		2.3 – 3.0 k $\Omega$ (When intake air temperature is 20°C)
		1.0 – 1.5 k $\Omega$ (When intake air temperature is 40°C)
		0.30 – 0.42 k $\Omega$ (When intake air temperature is 80°C)
83 – 92	Engine coolant temperature sensor	5.1 – 6.5 k $\Omega$ (When coolant temperature is 0°C)
		2.1 – 2.7 k $\Omega$ (When coolant temperature is 20°C)
		0.9 – 1.3 k $\Omega$ (When coolant temperature is 40°C)
		0.26 – 0.36 k $\Omega$ (When coolant temperature is 80°C)
87 – 92	Idle position switch	Continuity (when throttle valve is at idle position)
		No continuity (when throttle valve is slightly open)



**Examples of Abnormal Wave Patterns**

● Example 1

Wave pattern during engine cranking

**Cause of problem**

Open-circuit in ignition primary circuit

**Wave pattern characteristics**

Top-right part of the build-up section cannot be seen, and voltage value is approximately 2 V too low.

● Example 2

Wave pattern during engine cranking

**Cause of problem**

Malfunction in power transistor

**Wave pattern characteristics**


Power voltage results when the power transistor is ON.

**ON-VEHICLE SERVICE**

13100100498

**THROTTLE BODY (THROTTLE VALVE AREA) CLEANING**

1. Start the engine and warm it up until the coolant is heated to 80°C or higher and then stop the engine.
2. Remove the air intake hose from the throttle body.




3. Plug the bypass passage inlet of the throttle body.

**Caution**

**Do not allow cleaning solvent to enter the bypass passage.**

4. Spray cleaning solvent into the valve through the throttle body intake port and leave it for about 5 minutes.
5. Start the engine, race it several times and idle it for about 1 minute. If the idling speed becomes unstable (or if the engine stalls) due to the bypass passage being plugged, slightly open the throttle valve to keep the engine running.
6. If the throttle valve deposits are not removed, repeat steps 4 and 5.
7. Unplug the bypass passage inlet.
8. Attach the air intake hose.
9. Use the MUT-II to erase the self-diagnosis code.




4. Apply sealant to threaded portion.

**Specified sealant:**

**3M Nut Locking Part No.4171 or equivalent**

5. Install the engine coolant temperature sensor and tighten it to the specified torque.

**Tightening torque: 29 Nm**



**THROTTLE POSITION SENSOR CHECK** 1310320467

1. Disconnect the throttle position sensor connector.
2. Measure the resistance between the throttle position sensor side connector terminal 1 and terminal 4.

**Standard value: 3.5 – 6.5 kΩ**

3. Measure the resistance between the throttle position sensor side connector terminal 1 and terminal 3.


**Normal condition:**

Throttle valve slowly open until fully open from the idle position	Changes smoothly in proportion to the opening angle of the throttle valve
--	---

4. If the resistance is outside the standard value, or if it doesn't change smoothly, replace the throttle position sensor.

**NOTE**

For the throttle position sensor adjustment procedure, refer to P.13A-77.



**IDLE POSITION SWITCH CHECK** 13100330446

1. Disconnect the throttle position sensor connector.
2. Check the continuity between the throttle position sensor connector side terminal 1 and terminal 2.

**Normal condition:**

Accelerator pedal	Continuity
Depressed	Non-conductive
Released	Conductive (0 Ω)



3. If out of specification, replace the throttle position sensor.

**NOTE**

After replacement, the idle position switch and throttle position sensor should be adjusted. (Refer to P.13A-77.)

## CLEANING THROTTLE BODY PARTS

1. Clean all throttle body parts.  
Do not use solvent to clean the following parts:
  - Throttle position sensor
  - Accelerator pedal position sensor
  - Idle speed control body assembly
 If these parts are immersed in solvent, their insulation will deteriorate.  
Wipe them with cloth only.
2. Check if the vacuum port or passage is clogged. Use compressed air to clean the vacuum passage.



## REASSEMBLY SERVICE POINT

### ▶◀ THROTTLE POSITION SENSOR (TPS) INSTALLATION

1. Install the TPS so that it faces as shown in the illustration, and then tighten it with the screw.
2. Connect a multimeter between terminal (4) (TPS power supply) and terminal (3) (TPS output) of the TPS connector, and check that the resistance increases gradually as the throttle valve is opened slowly to the fully-open position.
3. Check the continuity between terminal (2) (idle position switch) and terminal (1) (earth) of the TPS connector when the throttle valve is fully closed and fully open.

#### Normal condition:

Throttle valve condition	Continuity
Fully closed	Continuity
Fully open	No continuity

If there is no continuity when the throttle valve is fully closed, turn the TPS body anti-clockwise and then check again.

4. If there is an abnormality, replace the TPS.

INJECTION PUMP

13300240035


REMOVAL AND INSTALLATION

**Pre-removal Operation**

- Engine Coolant Draining
- Intercooler Removal (Refer to GROUP 15.)
- Timing Belt Removal (Refer to GROUP 11B.)

**Post-installation Operation**

- Timing Belt Installation (Refer to GROUP 11B.)
- Intercooler Installation (Refer to GROUP 15.)
- Engine Coolant Supplying
- Injection Timing Adjustment (Refer to GROUP 11B - On-vehicle Service.)
- Accelerator Cable Adjustment (Refer to GROUP 17 - On-vehicle Service.)



AW0280AA

**Removal steps**

1. Fuel injection pump wiring harness
2. Water hose connection <Vehicles with cold start device>
3. Fuel hoses
4. Accelerator cable connection



5. Boost hose connection
6. Fuel injection pipe
7. Fuel injection pump sprocket
8. Fuel injection pump

**GENERAL INFORMATION**

14100010286

The cooling system is designed to keep every part of the engine at appropriate temperature in whatever condition the engine may be operated. The cooling method is of the water-cooled, pressure forced circulation type in which the water pump pressurizes coolant and circulates it throughout the engine. If the coolant temperature exceeds the prescribed temperature, the thermostat opens to circulate the coolant through the radiator as well so that the heat absorbed by the coolant may be radiated into the air.

The water pump is of the centrifugal type and is driven by the drive belt from the crankshaft. The radiator is the corrugated fin, down flow type.

Items			Specifications
Radiator	Performance kJ/h	6G7	203,000
		4D5	230,200

**SERVICE SPECIFICATIONS**

14100030305

Items			Standard value	Limit
High pressure valve opening pressure of radiator cap kPa			74 – 103	64
Range of coolant antifreeze concentration of radiator %			30 – 60	–
Thermostat	Valve opening temperature of thermostat °C	6G7	88 ± 2.0	–
		4D5	82 ± 1.5	–
	Full-opening temperature of thermostat °C	6G7	100	–
		4D5	95	–
	Valve lift mm	6G7	10 or more	–
		4D5	8.5 or more	–

**LUBRICANT**

14100040209

Items		Quantity ℓ
MITSUBISHI GENUINE COOLANT OR AN EQUIVALENT	6G7	9.0 (10.0)
	4D5	8.0 (9.0)


**NOTE**

( ) indicates figure for vehicles with rear heater.

**SEALANTS**


14100050226

Items	Specified sealant	Remarks
Cylinder block drain plug	3M Nut Locking Part No. 4171 or equivalent	Drying sealant



**▶B◀ WATER PUMP ASSEMBLY INSTALLATION**

No.	Hardness category (head mark)	Bolt diameter x length mm
1	4T	8 x 25
2		8 x 40
3	7T	8 x 14
4		8 x 20
5		8 x 25
6		8 x 70




**▶C◀ RADIATOR UPPER HOSE CONNECTION**

1. Insert each hose as far as the projection of the water outlet fitting.
2. Align the mating marks on the radiator hose and hose clamp, and then connect the radiator hose.

**INTERCOOLER AND INTERCOOLER FAN-ECU**

15100420079

**REMOVAL AND INSTALLATION**



05V0045  
00009215

**Intercooler fan-ECU removal steps**

1. Scuff plate
2. Cowl side trim
3. Intercooler fan-ECU


**Intercooler removal steps**

4. Intake air temperature switch connector
5. Intercooler fan motor connector
6. Air hose B connection (Intake manifold side)
7. Air hose A-2 connection (Turbocharger side)
8. Intercooler and bracket assembly

**TURBOCHARGER**

15100600039


**DISASSEMBLY AND REASSEMBLY**



DEN0248

**Disassembly steps**

- ▶E◀ 1. Coupling
- ▶D◀ 2. Turbine housing
- ▶C◀ 3. Snap ring
- ▶B◀ 4. Turbine wheel assembly
- ▶B◀ 5. Compressor cover
- ▶A◀ 6. O-ring



**DISASSEMBLY SERVICE POINTS**

◀A▶ **SNAP RING REMOVAL**

Lay the unit with the compressor cover side facing down and using snap ring pliers, remove the compressor cover attaching snap ring.

**Caution**

When removing the snap ring, hold it with fingers to prevent it from springing away.

6. Reconnect the negative battery cable.
7. Connect a tachometer or the MUT-II. (Refer to GROUP 11 – On-vehicle Service.)
8. Leave the hood open.
9. Start the engine.
10. With the engine running at 2,500 r/min, turn the headlamps and other lamps on and off to adjust the alternator load so that the value displayed on the ammeter is slightly above 30 A.  
Adjust the engine speed by gradually decreasing it until the value displayed on the ammeter is 30 A. Take a reading of the value displayed on the voltmeter at this time.

**Limit: max. 0.3 V**


**NOTE**

When the alternator output is high and the value displayed on the ammeter does not decrease until 30 A, set the value to 40 A. Read the value displayed on the voltmeter at this time. When the value range is 40 A, the limit is max. 0.4 V.






11. If the value displayed on the voltmeter is above the limit value, there is probably a malfunction in the alternator output wire, so check the wiring between the alternator "B" terminal and the battery (+) terminal (including fusible link). If a terminal is not sufficiently tight or if the harness has become discolored due to overheating, repair and then test again.
12. After the test, run the engine at idle.
13. Turn off all lamps and the ignition switch.
14. Remove the tachometer or the MUT-II.
15. Disconnect the negative battery cable.
16. Disconnect the ammeter and voltmeter.
17. Connect the alternator output wire to the alternator "B" terminal.
18. Connect the negative battery cable.

## OUTPUT CURRENT TEST

16100100536



7EN0987



### ►B◄ ROTOR INSTALLATION

1. When installing the rotor on the alternator rear bracket, wrap vinyl tape around the splined shaft to prevent damage to the oil seal. <4D5>
2. After rotor has been installed, remove the wire.


### ►C◄ ROTOR/VANES INSTALLATION <4D5>

1. Carefully check the housing, rotor, etc. for chips and foreign matter. Then, apply engine oil and install.
2. Install the vanes with the round end facing outward.
3. Apply grease to the O-ring and fit in the housing groove so that it will not come out from the groove when the bolts are tightened.
4. When tightening the housing, lightly push it in the direction of arrow so as to minimize the clearance at "A" and tighten the bolts uniformly.


#### NOTE

After assembly, be sure to conduct a performance test to check to see that the maximum vacuum is as specified below.

**Standard value of maximum vacuum:**  
80.00 kPa or greater at 3,000 r/min


**FIELD COIL GROUND TEST <4D5>**

Check the continuity between field coil brush and yoke. If there is no continuity, the field coil is free from earth.

**BRUSH HOLDER CHECK**

Check the continuity between brush holder plate and brush holder.


If there is no continuity, the brush holder is in order.

**OVERRUNNING CLUTCH CHECK**


1. While holding clutch housing, rotate the pinion. Drive pinion should rotate smoothly in one direction, but should not rotate in opposite direction. If clutch does not function properly, replace overrunning clutch assembly.
2. Inspect pinion for wear or burrs. If pinion is worn or burred, replace overrunning clutch assembly. If pinion is damaged, also inspect ring gear for wear or burrs.

**FRONT AND REAR BRACKET BUSHING CHECK**

Inspect bushing for wear or burrs. If bushing is worn or burred, replace front bracket assembly or rear bracket assembly.

**BRUSH AND SPRING REPLACEMENT****<6G7>**

1. Brushes that are worn beyond wear limit line, or oil-soaked, should be replaced.
2. When replacing ground brush, slide the brush from brush holder by prying retaining spring back.



**Ignition Primary Voltage Waveform Check  
MEASUREMENT METHOD**


1. Disconnect the power transistor connector and connect the special tool (harness connector: MB991348) in between.
2. Connect the analyzer primary pickup to the power transistor connector terminal 13 when observing the No. 1 - No. 4 cylinder group, terminal 12 for the No. 2 - No. 5 cylinder group, and terminal 11 for the No. 3 - No. 6 cylinder group.
3. Connect the primary pickup earth terminal.
4. Clamp the spark plug cable with the trigger pickup.



**NOTE**

- (1) Clamp the spark plug cable for No. 1, No. 3 and No. 5 cylinders of the same group with the cylinder that is connected to the primary pickup.
- (2) The wave-form of either cylinder in the same group will appear at the left edge of the screen.

**STANDARD WAVE-FORM  
Observation Conditions**

FUNCTION	SECONDARY
PATTERN HEIGHT	HIGH (or LOW)
PATTERN SELECTOR	RASTER
Engine Speed	Curb idle speed





## ENGINE COOLANT TEMPERATURE SENSOR CHECK

16400280031

1. Remove the engine coolant temperature sensor.
2. While the sensor section of the engine coolant temperature sensor is immersed, measure the resistance between (B) terminal and the body.

Temperature (°C)	Resistance value (kΩ)
0	8.6
20	3.25 ± 0.33
40	1.5
80	0.3

3. After applying specified sealant to the threaded portion, tighten to the specified torque.

### Specified sealant:

**3M Nut Locking Part No. 4171 or equivalent**

**Tightening torque: 35 Nm**

**Service Data Output**

Items No.	Service data item		Unit
01	Auto-cruise control switch	Main	ON/OFF
02		Set	ON/OFF
03		Resume	ON/OFF
04		Cancel	ON/OFF
05	Stoplamp switch		ON/OFF
10	Vehicle speed sensor		km/h
13	TPS		mV
14	Clutch pedal position switch		ON/OFF
15	Over drive detective		ON/OFF


**INSPECTION CHART FOR DIAGNOSIS CODES**

17200220478

Code No.	Diagnosis item	Reference page
11	Auto-cruise vacuum pump drive system	17-10
12	Vehicle speed signal system	17-10
14	Auto-cruise vacuum pump power supply system	17-11
15	Auto-cruise control switch	17-11
16	Auto-cruise control-ECU	17-11
17	Throttle position sensor system	17-12


**Inspection Procedure 8**

<b>Hunting (repeated acceleration and deceleration) occurs at the set vehicle speed.</b>	<b>Probable cause</b>
The cause is probably a malfunction of vehicle speed sensor or incorrect vacuum in the auto-cruise vacuum pump or vacuum actuator.	<ul style="list-style-type: none"> <li>● Malfunction of the vehicle speed sensor</li> <li>● Malfunction of the auto-cruise vacuum pump</li> <li>● Malfunction of the vacuum actuator</li> <li>● Malfunction of the auto-cruise control-ECU</li> </ul>



**Inspection Procedure 9**

<b>Auto-cruise control indicator lamp inside combination meter does not illuminate. (However, auto-cruise control is normal.)</b>	<b>Probable cause</b>
The cause is probably a malfunction of bulb or a malfunction of connector or harness.	<ul style="list-style-type: none"> <li>● Malfunction of the bulb</li> <li>● Malfunction of the harness</li> <li>● Malfunction of the connector</li> <li>● Malfunction of the auto-cruise control-ECU</li> </ul>



**SERVICE SPECIFICATIONS**


17300030371

Items	Standard value
Purge control solenoid valve coil resistance (at 20°C) Ω	28-36
EGR control solenoid valve coil resistance (at 20°C) Ω	28-36

**VACUUM HOSE**

**VACUUM HOSE PIPING DIAGRAM**

17300090508



7EM0528

## CATALYTIC CONVERTER

17300530154


### GENERAL INFORMATION

The three-way catalytic converter, together with the closed loop air-fuel ratio control based on the oxygen sensor signal, oxidizes carbon monoxides (CO) and hydrocarbons (HC) and reduces nitrogen oxides (NOx).

When the mixture is controlled at stoichiometric air-fuel ratio, the three-way catalytic converter provides the highest purification against the three constituents, namely, CO, HC and Nox.

### REMOVAL AND INSTALLATION

17300390325



#### Removal steps

1. Front exhaust pipe
2. Center exhaust pipe
3. Catalytic converter

**GENERAL INFORMATION**

21100010093

The clutch is a dry single-disc, diaphragm type; hydraulic pressure is used for the clutch control.

**SERVICE SPECIFICATIONS**


21100030136

Items	Standard value
Clutch pedal height mm	176 - 181
Clutch pedal clevis pin play mm	1 - 3
Clutch pedal free play mm	6 - 13
Distance between the clutch pedal and the toeboard when the clutch is disengaged mm	56 or more

**LUBRICANTS**

21100040078

Items	Specified lubricants	Quantity
Clutch fluid	Brake fluid DOT 3 or DOT 4	As required
Push rod assembly	Rubber grease	
Boot		
Release cylinder push rod	MITSUBISHI genuine grease Part No. 0101011	


**ON-VEHICLE SERVICE**

21100090127

**CLUTCH PEDAL INSPECTION AND ADJUSTMENT**

1. Turn up the carpet, etc. under the clutch pedal.
2. Measure the clutch pedal height.

**Standard value (A): 176 - 181 mm**



3. If the height of the clutch pedal is outside the standard value, loosen the lock nut and adjust the pedal height to the standard value using the adjusting bolt or push rod.

TRANSMISSION CONTROL

22100380306



REMOVAL AND INSTALLATION

**Pre-removal Operation**




- Shift the Transmission Control Lever to the N Position.
- Shift the Transfer Control Lever to the 4H Position.
- Floor Consol Removal (Refer to GROUP 52A - Floor Consol.)

**Post-installation Operation**

- Floor Consol Installation (Refer to GROUP 52A - Floor Consol.)
- Check the Operation of the Transmission and Transfer Control Levers and the Movement in Each Lever Position.



W0314AA  
00009330



**Transmission control lever assembly removal steps**

- 1. Retainer plate
- 2. Dust cover
- 3. Shift lever shaft
- 4. Transmission control lever assembly
- 5. Gasket
- 6. Stopper plate
- 7. Gasket
- 8. Control lever bushing
- 9. Transmission control lever

**Transfer control lever assembly removal steps**

- 1. Retainer plate
- 2. Dust cover
- 10. Transfer control lever assembly
- 11. Gasket
- 12. Stopper plate
- 13. Gasket
- 14. Transfer control lever

**PROPELLER SHAFT**

25100100163


**REMOVAL AND INSTALLATION**

**Pre-removal Operation**

- Set the Transfer Shift Lever to "2H"
- Front Under Cover, Middle Under Cover and Transfer Protector Removal
- Transfer Gear Oil Draining (Refer to GROUP 22 - On-vehicle Service.)

**Post-installation Operation**

- Transfer Gear Oil Supplying (Refer to GROUP 22 - On-vehicle Service.)
- Front Under Cover, Middle Under Cover and Transfer Protector Installation




**Removal steps**



1. Rear propeller shaft assembly
2. Front propeller shaft assembly

3. Spacer <6G7>



**REMOVAL SERVICE POINT**

**REAR PROPELLER SHAFT ASSEMBLY/FRONT PROPELLER SHAFT ASSEMBLY REMOVAL**

1. Make mating marks on the differential companion flange and flange yoke and remove the propeller shaft.
2. Use the plug as a cover so that no foreign material gets into the transmission or transfer.







**SEALANTS**

26100050069

Items	Specified sealants	Remarks
Contact surface of drive flange and front hub assembly	3M ATD Part No. 8663 or equivalent	Semi-drying sealant
Contact surface of hub cap and drive flange		
Contact surface of differential cover and differential carrier		
Vent plug		
Freewheel clutch assembly		
Drive gear threaded hole	3M Stud Locking 4170 or equivalent	Anaerobic sealant


**SPECIAL TOOLS**

26100060253

Tool	Number	Name	Use
 B990954	MB990954	Lock nut wrench	Removal and adjustment of lock nut
 B990925	MB990925	Bearing and oil seal installer set	<ul style="list-style-type: none"> <li>● Press-out and press-fitting of bearing</li> <li>● Press-fitting of oil seal</li> <li>● Press-fitting of drive shaft</li> <li>● Tapping in of side bearing outer race</li> <li>● Checking of drive gear tooth contact</li> </ul>
 B990955	MB990955	Oil seal installer	<ul style="list-style-type: none"> <li>● Press-fitting of housing tube dust seal</li> <li>● Press-fitting of front axle hub oil seal (Used together with MB990938)</li> </ul>
 B991113	MB991113 or MB990635	Steering linkage puller	<ul style="list-style-type: none"> <li>● Disconnection of tie rod</li> <li>● Disconnection of upper ball joint</li> <li>● Disconnection of lower ball joint</li> </ul>
 B990956	MB990956	Needle bearing installer	Press-fitting of knuckle needle bearing (Used together with MB990938)
 B990985	MB990985	Oil seal installer	Press-fitting of knuckle oil seal (Used together with MB990938)

DISASSEMBLY AND REASSEMBLY


26100190143



**Disassembly steps**


- ▶B◀ 1. Outer bearing inner race
- ▶B◀ 2. Oil seal
- ▶A◀ ▶A◀ 3. Inner bearing inner race
- ▶A◀ ▶A◀ 4. Outer bearing outer race

- ▶A◀ ▶A◀ 5. Inner bearing outer race
- ▶B◀ 6. Rotor <vehicles with ABS>
- 7. Brake disc
- 8. Front hub assembly



**REMOVAL SERVICE POINTS**

▶A◀ OUTER BEARING OUTER RACE/INNER BEARING OUTER RACE REMOVAL



▶B◀ BRAKE DISC REMOVAL

Make the mating marks on the brake disc and front hub, and then separate the front hub and brake disc, if necessary.

**Caution**



Lock disc in vise and grip with copper or aluminium board.

DISASSEMBLY AND REASSEMBLY

26100370332


Caution

Never disassemble the B.J. assembly except when replacing the B.J. boot.




00004932


B.J. Repair Kit (B.J.)



B.J. Repair kit L.H.



D.O.J. Repair kit



Boot repair kit (D.O.J.)

Disassembly steps

1. D.O.J. boot band (large)
2. D.O.J. boot band (small)
3. Circlip
4. D.O.J. outer race
5. Dust cover
6. Balls
7. D.O.J. cage
8. Snap ring
9. D.O.J. inner race
10. D.O.J. boot
11. B.J. assembly
12. Circlip
13. B.J. boot band (small)
14. B.J. boot band (large)
15. B.J. boot



Reassembly steps

12. Circlip
11. B.J. assembly
9. D.O.J. inner race
8. Snap ring
7. D.O.J. cage
6. Balls
4. D.O.J. outer race
5. Dust cover
3. Circlip
10. D.O.J. boot
2. D.O.J. boot band (small)
1. D.O.J. boot band (large)




**DIFFERENTIAL CARRIER  
REMOVAL AND INSTALLATION**

26200210064

**Pre-removal and Post-Installation**

- Under Cover Removal and Installation
- Front Axle Gear Oil Level Check (Refer to P.26-10.)
- Drive shaft Removal and Installation (Refer to P.26-21.)
- Inner Shaft Removal and Installation (Refer to P.26-31.)






<6G7>





**Removal steps**

- ▶C◀ 1. Vacuum hose connection
- 2. Pin
- ▶A▶B◀ 3. Actuator assembly
- 4. Front propeller shaft connection
- 5. Freewheel engage switch connection
- 6. Vacuum hose connection
  - Support the differential by a transmission jack.
- 7. Pin
- 8. Spacer
- 9. Differential mounting cushion
- 10. Differential mounting bracket <L.H.>
- 11. Differential support bracket
- 12. Differential mount insulator assembly
- 13. Front suspension crossmember
- 14. Front differential, housing tube and differential mounting bracket <R.H.>
- 15. Differential mounting bracket <R.H.>
- 16. Housing tube
- 17. Freewheel engage switch
- ▶A◀ 18. Freewheel clutch assembly
  - Clutch gear bearing axial play inspection.
- 19. Vacuum hose connection
- 20. Front differential carrier assembly

Lubrication, Sealing and Adhesive Points



<4D5>



11V0047  
00009263

**Freewheel clutch removal steps**

1. Inner shaft (Refer to P. 26-31.)
2. Circlip
3. Freewheel engage switch connector
4. Freewheel engage switch
5. Vacuum hose
6. Pin
7. Actuator assembly
- Support the differential by a transmission jack.

►E◄

8. Pin
9. Spacer
10. Differential mounting cushion
11. Differential mounting bracket (R.H.)
12. Housing tube assembly
13. Freewheel clutch assembly
- Clutch gear bearing axial play inspection.

►D◄








## SEALANTS

27100050110

Items	Specified sealants	Remarks
Bearing case	3M ATD Part No. 8663 or equivalent	Semi-drying sealant
Axle housing (differential carrier mounting part)		
Drive gear and differential case mounting part	3M Stud Locking 4170 or equivalent	Anaerobic sealant

## SPECIAL TOOLS

27100060298

Tool	Number	Name	Use
 A B A8990590	MB990590 A: MB990212 B: MB990211	Rear axle shaft oil seal remover A: Adapter B: Sliding hammer	<ul style="list-style-type: none"> <li>Removal of axle shaft (Use together with MB990241, MB990211)</li> <li>Removal of axle housing oil seal</li> </ul>
 B990241	MB990241	Rear axle shaft puller	Removal of axle shaft (Use together with MB990211)
 B990925	MB990925	Bearing and oil seal installer set	<ul style="list-style-type: none"> <li>Press-fitting of oil seal</li> <li>Inspection of drive gear tooth contact</li> <li>Removal of bearing outer race</li> </ul> For details of each installer, refer to GROUP 26 – Special Tools.
 B991552	MB991552	Axle shaft bearing and case remover	Removal of the axle shaft bearing and bearing case
 B990560	MB990560	Bearing remover	Removal of bearing inner race
 B990799	MB990799	Bearing inner race installer	<ul style="list-style-type: none"> <li>Removal of axle shaft bearing inner race</li> <li>Press-fitting of the axle shaft bearing inner race</li> <li>Press-fitting of the axle shaft retainer</li> </ul>
 B990890	MB990890 or MB990891	Rear suspension bushing base	Press-fitting of bearing outer race





CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL



## DISASSEMBLY SERVICE POINTS

### ◀A▶ RETAINER RING REMOVAL

1. Remove one retainer bolt from the backing plate.
2. Apply gummed cloth tape around the edge of the bearing case for protection.
3. As shown in the figure, hold the axle shaft. Using a grinder, shave off a point of its circumference locally until the wall thickness becomes as follows:
  - 1.0 – 1.5 mm for axle shaft side
  - 2.0 mm for bearing side

#### Caution

**Be careful not to damage the bearing case and the axle shaft.**

4. Fix the axle shaft and shave off the remaining 2.0 mm on the side of the retainer bearing.


#### Caution

**Be careful not to damage the bearing case and the axle shaft.**

5. Cut in with a chisel the place where the retainer ring has been shaven and remove the retainer ring.


#### Caution

**Be careful not to damage the axle shaft.**



### ◀F▶ SELF-LOCKING NUT REMOVAL

Use special tool to hold the companion flange, and then remove the companion flange self-locking nut.




### ◀G▶ DRIVE PINION ASSEMBLY REMOVAL

1. Make the mating marks to the drive pinion and companion flange.

#### Caution


**Do not make mating marks on the contact surfaces of the companion flange and propeller shaft.**

2. Drive out the drive pinion together with the drive pinion spacer and drive pinion front shims.




### ◀H▶ DRIVE PINION REAR BEARING INNER RACE REMOVAL

Use special tools to pull out the front bearing inner race.



### ◀I▶ OIL SEAL/DRIVE PINION FRONT BEARING INNER RACE/DRIVE PINION FRONT BEARING OUTER RACE REMOVAL

Use special tool to remove drive pinion front bearing outer race.



### ◀J▶ DRIVE PINION REAR BEARING OUTER RACE REMOVAL

Use special tool to remove the drive pinion rear bearing outer race.

## 31-2 WHEEL AND TYRE - General Information/Service Specifications

### GENERAL INFORMATION

31100010269

Both steel type and aluminium type wheels have been adopted. The type of wheel used depends on the vehicle model.

Items		Vehicles without wide fender	Vehicles with wide fender
Wheel	Type	Steel type	Aluminium type
	Size	15 x 6JJ	16 x 7JJ
	Amount of wheel offset	33	10 ± 1
	Pitch circle diameter (P.C.D.) mm	139.7	139.7
Tyre	Size	235/75 R15	245/70 R16

### SERVICE SPECIFICATIONS

31100030036

Items		Limit
Tread depth of tyre mm		1.6
Wheel runout (Radial runout) mm	Steel wheel	1.2 or less
	Aluminium wheel	1.0 or less
Wheel runout (Lateral runout) mm	Steel wheel	1.2 or less
	Aluminium wheel	1.0 or less


# FRONT DIFFERENTIAL MOUNTING

32100170100

## REMOVAL AND INSTALLATION

**Pre-removal and Post-Installation Operation**


- Under Skid Plate and Under Cover Removal and Installation



**Removal steps**


- Hold the front differential with a transmission jack.
1. Drive shaft (Refer to Group 26 - drive shaft.)
  2. Inner shaft (Refer to Group 26 - inner shaft.)
  3. Pin

4. Spacer
5. Differential mounting rubber B
6. Differential mounting bracket
7. Differential mounting rubber A
8. Differential support bracket
9. Differential mounting bracket



## FRONT DIFFERENTIAL MOUNTING INSULATOR REPLACEMENT


1. Use special tool to press-fit and remove the insulator.

**REMOVAL SERVICE POINTS****◀A▶ REAR ANCHOR ARM ADJUSTING NUT LOOSENING**

Loosen the anchor arm bolt of the torsion bar all the way.

**Caution**

When the rear anchor arm adjusting nut is loosened, use a jack to support the lower arm of the side to be loosened.

**◀B▶ UPPER ARM BALL JOINT DISCONNECTION**


Use special tools to disconnect the upper arm ball joint from the knuckle.

**Caution**


1. Support special tool with a cord, etc. to prevent it from coming off.
2. Only loosen the mounting nut, do not remove it from the ball joint.

**◀C▶ SHIMS REMOVAL****NOTE**

The camber and caster adjustment shims should be kept for use during assembly.

**INSTALLATION SERVICE POINTS****▶A▶ UPPER ARM INSTALLATION**






Install the upper arm so that the "OUT" mark on the upper arm shaft is facing toward the outside of the vehicle.

**▶B▶ REBOUND STOPPER INSTALLATION**

Install the rebound stopper so that its arrow faces inside of the vehicle.

**SPECIAL TOOLS**

3410060197

Tool	Number	Name	Use
 B990650	MB990650	Lower arm bushing arbor	<ul style="list-style-type: none"> <li>• Lateral rod bushing removal and installation</li> <li>• Lateral rod removal and press fitting</li> </ul>
 B991318	MB991318	Lower arm bushing arbor	<ul style="list-style-type: none"> <li>• Lower arm rear bushing removal and press fitting</li> <li>• Lower arm bushing removal and press fitting</li> </ul>
	MB990971	Rear wheel bearing and installer joint	
	MB990891	Bushing remover and installer base	
 B991411	MB991411	Rear wheel bearing and hub installer joint	

**ON-VEHICLE SERVICE**

34101100034

**REAR WHEEL ALIGNMENT**

The rear suspension assembly must be free of worn, loose or damaged parts prior to measurement of rear wheel alignment.

**Standard value:**

**Toe-in 0 mm**

**Camber 0°**

**NOTE**

Toe-in and camber are set at the factory and cannot be adjusted. If toe-in or camber is not within the standard value, check or replace bent or damaged parts.

**SERVICE SPECIFICATIONS**

35100030386

Items		Standard value	Limit
Brake pedal height mm		176 – 181	–
Brake pedal free play mm		3 – 8	–
Brake pedal to floor board clearance mm		95 or more	–
Load sensing spring length mm		164 – 168	–
Load sensing proportioning valve output pressure kPa (Input pressure kPa)	When load sensing spring length is 144 mm (when unladen)	3,633 (5,884)	–
		5,610 (13,730)	–
	When load sensing spring length is 208 mm (when laden)	11,160 (13,730)	–
Disc brake pad thickness mm		10	2.0
Brake disc run-out mm	Front	–	0.06
	Rear	–	0.08
Front hub end play mm		0.05	–
Rear axle shaft end play mm		0 – 0.25	–
Brake disc thickness mm	Front	24	22.4
	Rear	18	16.4
Brake lining thickness mm		–	4.5
Brake drum inside diameter mm		197.0	198.0
Booster push rod to master cylinder piston clearance mm	Vehicle which brake booster of power cylinder is 180 mm and 205 mm in effective diameter	0.90 – 1.30	–
	Vehicle which brake booster of power cylinder is 205 mm and 230 mm in effective diameter	0.70 – 1.10	–
Disc brake drag force (tangential force of wheel mounting bolts) N	Front	106 or less	–
	Rear	56 or less	–


Standard value:

Spring length H mm	Input fluid pressure kPa	Output fluid pressure kPa
144*1	5,884	3,633
	13,730	5,610
208*2	13,730	11,160

NOTE

\*1 and \*2 indicate the applicable lengths for unladen and laden vehicles respectively.

- After making the check, install the spring. Disconnect the pressure gauges from the load sensing proportioning valve and bleed the air. (Refer to P.35A-13.)




DISC BRAKE PAD CHECK AND REPLACEMENT

35100150242

NOTE

The brake pads have indicators that contact the brake disc when the brake pad thickness becomes 2 mm, and emit a squealing sound to warn the driver.



<Front>

- Check the brake pad thickness through the caliper body check port.

Standard value: 10 mm




Limit: 2.0 mm

Caution

- When the limit is exceeded, replace the pads at both sides, and also the brake pads for the wheels on the opposite side at the same time.
- If there is a significant difference in the thicknesses of the pads on the left and right sides, check the sliding condition of the piston, lock pin and guide pin.

**MASTER CYLINDER  
DISASSEMBLY AND REASSEMBLY**

35100420206



W0320AA  
00009335


**Disassembly steps**

1. Reservoir cap assembly
2. Reservoir cap
3. Diaphragm
4. Brake fluid level sensor
5. Float
6. Reservoir stopper bolt
7. Reservoir tank
8. Reservoir seal
9. Piston stopper bolt

10. Gasket
11. Piston stopper ring
12. Primary piston assembly
13. Secondary piston assembly
14. Master cylinder body



**Caution**  
Do not disassemble the primary piston and secondary piston assembly.



**DISASSEMBLY SERVICE POINT**

**◀▶ PISTON STOPPER BOLT/PISTON STOPPER RING DISASSEMBLY**

Remove the piston stopper bolt and piston stopper ring while depressing the piston.


**INSPECTION**

35100430056


- Check the inner surface of master cylinder body for rust or pitting.
- Check the primary and secondary pistons for rust, scoring, wear or damage.
- Check the diaphragm for cracks and wear.

DISASSEMBLY AND REASSEMBLY


35100720184




V0121AA  
00009337



Brake caliper kit



Seal and boot kit



Caliper assembly disassembly steps

1. Clip
2. K-spring
3. Pad pin
4. Spring
5. Inner shim
6. Pad and wear indicator assembly
7. Pad assembly
8. Outer shim
9. Retaining ring
10. Piston boot
11. Piston
12. Piston seal
13. Sleeve bolt
14. Bushing
15. Sleeve


16. Pin boot
17. Inner caliper
18. Torque plate
19. Bleeder screw

Pad assembly disassembly steps

1. Clip
2. K-spring
3. Pad pin
4. Spring
5. Inner shim
6. Pad and wear indicator assembly
7. Pad assembly
8. Outer shim



Code No. 15 Wheel speed sensor (Abnormal output signal)	Probable cause
A wheel speed sensor outputs an abnormal signal (other than an open or short-circuit).	<ul style="list-style-type: none"> <li>• Improper installation of wheel speed sensor</li> <li>• Malfunction of wheel speed sensor</li> <li>• Malfunction of ABS rotor</li> <li>• Malfunction of wheel bearing</li> <li>• Malfunction of wiring harness or connector</li> <li>• Malfunction of hydraulic unit assembly</li> </ul>




Code No. 16 Power supply system	Probable cause
The voltage of the ABS-ECU power supply drops lower or rises higher than the specified value. If the voltage returns to the specified value, this code is no longer output.	<ul style="list-style-type: none"> <li>• Malfunction of wiring harness or connector.</li> <li>• Malfunction of hydraulic unit assembly</li> </ul>

**Caution**

If battery voltage drops or rises during inspection, this code will be output as well. If the voltage returns to standard value, this code is no longer output.

Before carrying out the following inspection, check the battery level, and refill distilled water if necessary.



**DATA LIST REFERENCE TABLE**

35201150299

The following items can be read by the MUT-II from the ABS-ECU input data.

**1. When the system is normal**

Item No.	Check item	Checking requirements	Normal value
11	Front-right wheel speed sensor	Perform a test run	Vehicle speeds displayed on the speedometer and MUT-II are identical.
12	Front-left wheel speed sensor		
13	Rear-right wheel speed sensor		
14	Rear-left wheel speed sensor		
16	ABS-ECU power supply voltage	Ignition switch power supply voltage and valve monitor voltage	9 - 16 V
25	4WD position detection switch	Place the transfer lever at 4H.	ON
		Place the transfer lever at 2H.	OFF
26	Free wheel engage switch	Engage 4WD	ON
		Engage 2WD	OFF
32	G-sensor output voltage	Stop the vehicle.	2.4 - 2.6 V
		Perform a test run.	Display value fluctuates with a mean value of 2.5 V.
33	Stop lamp switch	Depress the brake pedal.	ON
		Release the brake pedal.	OFF

**2. When the ABS-ECU shut off ABS operation.**

When the diagnosis system stops the ABS-ECU, the MUT-II display data will be unreliable.

**ACTUATOR TEST REFERENCE TABLE**

35201160209

The MUT-II activates the following actuators for testing.

**NOTE**

1. If the ABS-ECU runs down, actuator testing cannot be carried out.
2. Actuator testing is only possible when the vehicle is stationary. If the vehicle speed during actuator testing exceeds 10 km/h, forced actuation will be cancelled.
3. During the actuator test, the ABS warning lamp will illuminate and the anti-skid control will be cancelled.

# 35B-28 ABS <4WD> – Master Cylinder and Brake Booster/Hydraulic Unit

## INSPECTION

35200460027

- Check the inner surface of master cylinder body for rust or pitting.
- Check the primary and secondary pistons for rust, scoring, wear, damage or wear.
- Check the diaphragm for cracks and wear.

## HYDRAULIC UNIT

35200860391



### REMOVAL AND INSTALLATION

#### Pre-removal Operation

- Brake Fluid Draining



#### Post-Installation Operation

- Brake Fluid Filling
- Brake Line Bleeding (Refer to GROUP 35A – On-vehicle Service.)



<6G7, 4D5 – R.H. drive vehicles>


<4D5 – L.H. drive vehicles>



W0329AA

00009342

#### Removal steps



1. Brake tube
2. Harness connector
3. Bracket assembly
4. Hydraulic unit assembly

## PARKING BRAKE CABLE REMOVAL AND INSTALLATION


36100190418

### Pre-removal Operation

- Floor Console Removal  
(Refer to GROUP 52A - Floor Console.)

### Post-installation Operation

- Floor Console Installation  
(Refer to GROUP 52A - Floor Console.)
- Parking Brake Lever Stroke Adjustment  
(Refer to P.36-3.)




AW0253AA

### Removal steps

- Shoe and lining assembly (Refer to P.36-7.)
1. Cable adjuster
  2. Pin


3. Nut holder
4. Front parking brake cable
5. Cable equalizer
6. Parking brake cable



### STEERING GEAR BACKLASH CHECK 37100120032

1. Jack up the vehicle front and hold the steering wheel in the straight ahead position.
2. Apart the pitman arm and the relay rod. (Refer to P.37A-41.)
3. Measure the steering gear backlash at the pitman arm top end with a dial indicator.


**Limit: 0.5 mm**



4. If the measured value exceeds the limit, screw in the steering gear box adjusting bolt until steering wheel free play is within the standard value.

#### Caution

- (1) Be sure to make the adjustment with the steering wheel in the straight ahead position.
- (2) If the adjusting bolt is overtightened, more steering effort will be required, and return of the wheel will be adversely affected.



### TIE ROD END BALL JOINT VARIATION CHECK (SHAFT DIRECTION) 37100130011

1. Hold the ball joint with the special tool.
2. Set the special tool scale at its highest and measure variation with ball stud compressed. The variation should locate between the highest and centre scales.

**Limit: 1.5 mm**

3. When the variation exceeds the centre scale, replace the tie rod end.

#### Caution

Even if the variation is within the limit, check ball joint starting torque.

POWER STEERING GEAR BOX

37200390375

REMOVAL AND INSTALLATION



**Caution: SRS**  
 For vehicles with SRS, before removal of the steering gear box refer to GROUP 52B – Supplemental Restraint System (SRS), center the front wheels and remove the ignition key. Failure to do so may damage the SRS clock spring and render the SRS system inoperative, risking serious driver injury.

**Pre-removal Operation**

- Power Steering Fluid Draining (Refer to P.37A-11.)

**Post-installation Operation**

- Power Steering Fluid Supplying (Refer to P.37A-11.)
- Power Steering Fluid Line Bleeding (Refer to P.37A-12.)
- Checking Steering Wheel Position with Wheels Straight Ahead
- Front Wheel Alignment Adjustment (Refer to GROUP 33A – On-vehicle Service.)
- Press the dust cover with a finger to check whether the dust cover is cracked or damaged.




**Removal steps**

1. Connecting bolt for steering gear box and steering shaft
2. Split pin
3. Connection for pitman arm and relay rod


4. Pressure tube
5. Return tube
6. O-ring
7. Self-locking nut
8. Power steering gear box





**DISASSEMBLY SERVICE POINT**


◀A▶ SNAP RING REMOVAL



**REASSEMBLY SERVICE POINTS**


▶A◀ OIL SEAL INSTALLATION

Use special tool to install the oil seal.



**▶B◀ O-RINGS INSTALLATION**

No.	I.D. X Width mm
1	11 × 1.9
2	13 × 1.9
3	17.8 × 2.4
4	13.5 × 1.5
5	3.8 × 1.9
6	16.8 × 2.4



**▶C◀ SPRING INSTALLATION**



Fit the spring to the oil pump body with the larger-diameter end at the terminal assembly side.

# STEERING LINKAGE

## REMOVAL AND INSTALLATION

### Post-installation Operation

- Checking Steering Wheel Position with the Wheels Straight Ahead
- Front Wheel Alignment (Refer to GROUP 33A - On-vehicle Service.)
- Press the dust cover with a finger to check whether the dust cover is cracked or damaged.



### Removal steps

1. Cotter pin
2. Tie rod assembly
3. Relay rod

4. Self-locking nut
5. Idler arm assembly



# WINDOW GLASS


42200050154

## ADHESIVES

Items	Specified adhesives
<ul style="list-style-type: none"> <li>• Windshield</li> <li>• Quarter window glass</li> <li>• Tailgate window glass</li> </ul>	3M ATD Part No. 8609 Super Fast Urethane Auto Glass Sealants or equivalent
Windshield moulding	Double-sided tape (6 mm wide and 0.125 mm thick)

## SPECIAL TOOL

42200060089

Tool	Number	Name	Use
 <p>B990480</p>	MB990480	Glass holder	Removal and installation of windshield

## WINDOW REPAIR

42200560107

The following glass sections are installed by means of a liquid urethane adhesive method.





- Windshield
- Quarter window glass
- Tailgate window glass





## ITEMS NEEDED

Name	Remarks
Adhesive	3M ATD Part No. 8609 Super Fast Urethane Auto Glass Sealant or equivalent
Primer	3M ATD Part No. 8608 Super Fast Urethane Primer or equivalent
Spacers	Available as service part
Dam	Available as service part
Anti-rust solvent (or Tectyl 506T...Valvoline Oil Company)	For rust prevention
Isopropyl alcohol	For grease removal from bonded surface
Steel piano wire	Dia. × length...0.6mm × 1m for cutting adhesive
Adhesive gun	For pressing-out adhesive

### NOTE

The TEROSON 127.37V auto window sealer kit can also be used. If using the TEROSON 127.37V auto window sealer kit, follow the instructions in the manual included with the kit.

Tool	Number	Name	Use
<p data-bbox="161 271 185 297"><b>A</b></p>  <p data-bbox="161 421 185 448"><b>B</b></p>  <p data-bbox="161 622 185 649"><b>C</b></p>  <p data-bbox="161 728 185 754"><b>D</b></p>  <p data-bbox="336 808 416 831">C991223</p>	<p data-bbox="459 232 592 259">MB991223</p> <p data-bbox="459 271 647 297">A: MB991219</p> <p data-bbox="459 300 647 327">B: MB991220</p> <p data-bbox="459 329 647 356">C: MB991221</p> <p data-bbox="459 358 647 385">D: MB991222</p>	<p data-bbox="687 232 831 259">Harness set</p> <p data-bbox="687 271 895 297">A: Test harness</p> <p data-bbox="687 300 895 327">B: LED harness</p> <p data-bbox="687 329 919 385">C: LED harness adapter</p> <p data-bbox="687 387 807 414">D: probe</p>	<p data-bbox="941 232 1331 259">Measurement of terminal voltage</p> <p data-bbox="941 271 1490 297">A: Connector pin contact pressure inspection</p> <p data-bbox="941 300 1270 327">B: Power circuit inspection</p> <p data-bbox="941 329 1270 356">C: Power circuit inspection</p> <p data-bbox="941 358 1342 385">D: Commercial tester connection</p>



## ON-VEHICLE SERVICE

42300090159

### DOOR FIT ADJUSTMENT

1. If the clearance between the door and body is uneven, remove the splash shield, loosen the mounting bolt of the body side door hinges from inside the fender, and then move the door to adjust so that the clearance is even.
2. If there is a step between the door and body, loosen the mounting bolts and nuts of the door hinges, and adjust the door alignment.
3. If the striker and latch do not engage properly, move the striker up and down or to the left and right.

### DOOR WINDOW GLASS ADJUSTMENT

42300100272

Check that the window glass moves smoothly and touches the glass runchannel firmly when it is fully raised and fully lowered. If the window glass doesn't move properly, adjust by the following procedure.

1. Remove the door trim and waterproof film. (Refer to P.42-32.)
2. Raise the window glass, loosen the channel guide mounting bolts and adjust the vertical tilt of the glass.

### ADJUSTMENT AND REPLACEMENT WHEN THERE IS A MALFUNCTION OF THE POWER WINDOWS

42900190093

If the window glass automatically starts moving downwards at the wrong time while it is being raised, carry out the following adjustment or replacement procedures.

1. Remove the door trim and waterproof film. (Refer to P.42-32.)
2. Remove the window regulator assembly from the door window glass, and then raise and lower the door window glass by hand to check the operation force.


#### NOTE

Insert a cushion or similar object to prevent damage to the glass if it should happen to fall down.

**INSTALLATION SERVICE POINTS**

**►A◄ REAR LOWER SASH INSTALLATION**

Securely insert the rear lower sash into the window rear sash.




**►B◄ DOOR GLASS HOLDER INSTALLATION**

Install the glass pad and the glass holders to the window glass as shown in the illustration.

Standard value:

- (A) 106.7 - 108.2 mm
- (B) 417.5 - 420.5 mm
- (C) 127 - 131 mm



**INSPECTION**

42900180069

**POWER WINDOW RELAY CONTINUITY CHECK**

System voltage	Terminal No.			
	1	2	3	4
Not applied		○	—	○
Applied	○	⊕	○	⊖


**POWER WINDOW MOTOR CHECK**

42900150053




1. Connect a battery directly to the motor terminals and check that the motor runs smoothly.
2. Check that the motor runs in the opposite direction when the battery is connected with the polarity reversed.

**TAILGATE TRIM AND WATERPROOF FILM  
REMOVAL AND INSTALLATION**

42400140062




**NOTE**  
 : Resin clip position



18V0244  
 00007531

**Removal steps**

1. Cover <vehicles without roof spoiler>
2. Tailgate upper trim <L.H.>
3. Tailgate upper trim <R.H.>
4. Tailgate lower trim
5. Waterproof film




**►E◄ SUNROOF GLASS SEAL INSTALLATION**

1. Starting at the rear centre of the sunroof glass, begin installing the seal by pushing it onto the edge of the glass panel and gently pulling on it while installing.
2. Approximately 102 mm before completing installation, lay the end of the seal over top of the beginning of the seal. Cut the seal so there is an extra 3.18 mm of the seal past the point where the seal lines up with the beginning of the seal.
3. Apply the specified adhesive to the splice joint area where two ends of the seal meet.

**Specified adhesive:**

**3M Part No. 8155 or equivalent**

4. With the approximately 102 mm of the seal unattached, push two ends of the seal together at glue joint.
5. Install remainder of the seal by pushing the seal onto the edge of the glass panel. The 3.18 mm of extra seal material should strengthen the seal at the splice joint.



**►F◄ SUNROOF GLASS INSTALLATION**

1. Position the sunroof glass onto the guide assemblies and align the mounting holes.
2. Apply the specified sealant to the sunroof glass attaching screws and install them, going to the next step before tightening.


**Specified sealant:**

**3M Stud locking Part No. 4170 or equivalent**

**EXTERIOR PARTS**

51101750014

**REMOVAL AND INSTALLATION**



AW0169AA

**Roof rail removal steps**

- Headlining
- 1. Roof rail

**Roof spoiler removal steps**



- 2. Spoiler cover
- 3. Roof spoiler
- 4. High-mounted stop lamp

**Rear under guard bar removal steps**

- 5. Towing hook
- 6. Tie down bracket
- 7. Rear under guard bar

**INSTALLATION SERVICE POINT**

**▶A◀ SPOILER COVER INSTALLATION**

Install with the arrow shown on the rear surface facing forward.


**REAR WIPER AND WASHER  
SERVICE SPECIFICATION**

51100030249

Item	Standard value
Rear wiper blade installation position mm	65 – 75

**REAR WIPER AND WASHER  
REMOVAL AND INSTALLATION**


51100850210



18V0235  
00007542

**NOTE**

For removal and installation of the column switch assembly (rear wiper and washer switch), refer to GROUP 37A – Steering Wheel and Shaft.



- 1. Rear intermittent wiper relay

**Wiper motor removal steps**




- 2. Wiper arm and blade assembly
- 3. Grommet
  - Tailgate garnish (Refer to P.51-8.)
- 4. Grommet
- 5. Wiper motor

**Washer hose removal steps**

- Quarter trim, lower <R.H.> (Refer to GROUP 52A – Trims.)
- 6. Washer hose
- 7. Washer nozzle

**Washer tank and motor removal steps**


- Quarter trim lower <R.H.> (Refer to GROUP 52A – Trims.)
- Washer fluid draining
- 6. Washer hose
- 8. Washer tank
- 9. Washer motor




**REMOVAL SERVICE POINT**

**◀A▶ MIRROR REMOVAL**

1. Tilt the mirror upward by hand, insert a flat-tipped screwdriver onto which protective tape has been wound, and then pry the claws off of the actuator.



2. Pull the mirror downward to release the hooks.



**INSPECTION**

51100650162

**REMOTE CONTROLLED MIRROR ASSEMBLY CHECK**

<Vehicles without heated mirror>

Check to be sure that the mirror moves as described in the table when each terminal is connected to the battery.

Battery connection terminal			Direction operation
1	2	3	
⊖		⊕	UP
⊕		⊖	DOWN
⊖	⊕		RIGHT
⊕	⊖		LEFT

## INSTRUMENT PANEL &lt;R.H. DRIVE VEHICLES&gt;










52100170368

**Caution**

For removal and installation of the passenger's side air bag module, always observe the service procedures described in GROUP 52B - Air Bag Module and Clock Spring.

**REMOVAL AND INSTALLATION**

The bolts and screws described below are used, for installation of the instrument panel. They are indicated by symbols in the illustration.

Name	Symbol	Size (D x L) mm	Colour	Shape	
Tapping screw	a	5 x 12	-	 19Z0004	
	b	5 x 14			
	c	5 x 16			
	d	5 x 20			
	e	5 x 25			
	f	5 x 12	Black		
	g	5 x 16			
	h	5 x 20			
	i	5 x 20	Black		 19Z0003
	j	5 x 12	-		 19Z0022
k	5 x 16				
Washer assembled screw	l	5 x 12	-	 19Z0007	
	m	5 x 16	-	 19Z0006	
	n	5 x 20	Black	 19Z0030	
Washer assembled bolt	o	6 x 16	-	 19Z0012	
	p	8 x 20	-	 19Z0019	
	q	6 x 16	-	 19Z0010	
	r	8 x 20			



D = Thread diameter

L = Effective thread length


**REAR SEAT**

**REMOVAL AND INSTALLATION**

<Bench seat>



<Split seat>



1. Head restraint

**Rear seat removal steps**

- 2. Rear seat cushion assembly
- 3. Striker cover

4. Striker assembly

- 5. Catch
- 6. Parcel hook
- 7. Luggage floor box, front
- 8. Rear seatback assembly

00009139

**TROUBLESHOOTING**

52400310257

**STANDARD FLOW OF DIAGNOSTIC TROUBLESHOOTING**

Refer to GROUP 00 – How to Use Troubleshooting/Inspection Service Points.

**DIAGNOSIS FUNCTION**

52400320205

**DIAGNOSIS CODES CHECK**

Connect the MUT-II to the diagnosis connector (16-pin) under the instrument cover, then check diagnosis codes.

(Refer to GROUP 00 – How to Use Troubleshooting/Inspection Service Points.)

**ERASING DIAGNOSIS CODES****WHEN USING THE MUT-II**

Connect the MUT-II to the diagnosis connector and erase the diagnosis code.

**Caution**

Turn off the ignition switch before connecting or disconnecting the MUT-II.

**INSPECTION CHART FOR DIAGNOSIS CODES**



52400330369

Inspect according to the inspection chart that is appropriate for the malfunction code.

Code No.	Diagnosis item	Reference page
11, 12, 13	Front impact sensor system	52B-7
14	Analog G-sensor system in the SRS-ECU	52B-8
15,16	Safing G-sensor system in the SRS-ECU	52B-8
21, 22, 61, 62	Driver's side air bag module (squib) system	52B-9
24, 25, 64, 65	Front passenger's side air bag module (squib) system	52B-10
31, 32	SRS-ECU capacitor system	52B-8
34*	Connector lock system	52B-10
35	SRS-ECU (deployed air bag) system	52B-11
41*	Power circuit system (fuse No.10 circuit)	52B-11
42*	Power circuit system (fuse No.11 circuit)	52B-11
43	SRS warning lamp drive circuit system	Lamp does not illuminate.*
		Lamp does not switch off.
44	SRS warning lamp drive circuit system	52B-13
45	SRS-ECU non-volatile memory (EEPROM) and A/D converter system	52B-8
51, 52	Driver's side air bag module (squib ignition drive circuit) system	52B-8
54, 55	Front passenger's side air bag module (squib ignition drive circuit) system	52B-8

**NOTE**

- \*: If the vehicle condition returns to normal, the diagnosis code will be automatically erased, and the SRS warning lamp will return to normal.
- If the vehicle has a discharged battery it will store the fault codes 41 or 42. When these diagnosis codes are displayed, check the battery.



## AIR BAG MODULES, STEERING WHEEL AND CLOCK SPRING

1. Remove the air bag modules, steering wheel and clock spring. (Refer to P.52B-25.)

### Caution

The removed air bag modules should be stored in a clean, dry place with the pad cover face up.

2. Check pad cover for dents, cracks or deformation.
3. Check connector for damage, terminal deformities, and harness for binds.
4. Check air bag inflator case for dents, cracks or deformities.
5. Check harness and connectors for damage, and terminals for deformation.

6. Check clock spring connectors and protective tube for damage, and terminals for deformation.
7. Visually check the clock spring case for damage.
8. Align the mating marks of the clock spring and, after turning the vehicle's front wheels to straight-ahead position, install the clock spring to the column switch.

### Mating Mark Alignment

Turn the clock spring clockwise fully, and then turn back it approx. 3 4/5 turns counterclockwise to align the mating marks.

### Caution

If the clock spring's mating mark is not properly aligned, the steering wheel may not be completely rotational during a turn, or the flat cable within the clock spring may be severed, obstructing normal operation of the SRS and possibly leading to serious injury to the vehicle's driver or front passenger.

9. Install the steering column covers, steering wheel and the air bag module.
10. Check steering wheel for noise, binds or difficult operation.
11. Check steering wheel for excessive free play.  
REPLACE ANY VISUALLY INSPECTED PART IF IT FAILS THAT INSPECTION. (Refer to P.52B-25.)

### Caution

The SRS may not activate if any of the above components is not installed properly, which could result in serious injury or death to the vehicle's driver or front passenger.


5. Do not expose the air bag modules to temperatures over 93°C.
6. After deployment of an air bag, replace the air bag modules. Check the clock spring, and if faulty, replace it with a new part.
7. Wear gloves and safety glasses when handling air bags that have already deployed.
8. An undeployed air bag module should only be disposed of in accordance with the procedures (Refer to P.52B-33.)

**REMOVAL AND INSTALLATION**

<Air bag module (driver’s side), clock spring>

**Pre-removal Operation**

- After setting the steering wheel and the front wheels to the straight ahead position, remove the ignition key.





AT0201AA

**Air bag module removal steps**

- ▶F◀ • Post-installation inspection
- Negative (-) battery cable connection
- ◀A▶ ▶E◀ 1. Air bag module
- ▶A◀ • Pre-installation inspection

**Clock spring removal steps**

- ▶F◀ • Post-installation inspection
- Negative (-) battery cable connection
- ◀A▶ ▶E◀ 1. Air bag module
- ◀B▶ ▶D◀ 2. Steering wheel
- ◀C▶ ▶C◀ 3. Column cover lower
- ▶A◀ 4. Clock spring
- Pre-installation inspection



3. Connect two wires, each six meters or longer, to the two leads of SRS air bag adapter harness B <driver's side> or SRS air bag adapter harness A <front passenger's side>, and cover the connections with insulation tape. The other ends of the two wires should be connected to each other (short-circuited), to prevent sudden unexpected deployment of the air bag module.


4. Set the air bag modules as follows:

**<Air bag module (driver's side)>**

- (1) Take the SRS air bag adapter harness B that is connected to the wires, pass it beneath the old tyre wheel assembly, and connect it to the air bag module.
- (2) Pass the thick wire through the air bag module mounting hole, and then secure the air bag module to an old tyre with a wheel in it so that the pad on the module is facing upwards.

**Caution**

**Leave some space below the wheel for the adaptor harness. If there is no space, the reaction when the air bag deploys could damage the adaptor harness.**




- (3) Place three old tyres with no wheels on top of the tyre secured to the air bag module.

**BATTERY TESTING PROCEDURE**

54100120237

**TEST STEP**



**LOAD TEST RATE CHART**

Battery type	75D26R	80D26R	95D31R
Charging time when fully discharged h [5-amp rated current charging]	12	12	14
Load test (Amps)	240	290	310


**LOAD TEST CHART**

Temperature °C	21 and above	16	10	4	-1	-7	-12	-18
Minimum voltage V	9.6	9.5	9.4	9.3	9.1	8.9	8.7	8.5

# 54-16 CHASSIS ELECTRICAL - Ignition Switch and Immobilizer System

## Inspection Procedure 4


Engine does not start (Cranking but no initial combustion). <4D5>	Probable cause
If no fuel injection, there might be a problem with the fuel injection system in addition to a malfunction of the immobilizer system. It is normal for this to occur if an attempt is made to start the engine using a key that has not been properly registered.	<ul style="list-style-type: none"> <li>● Malfunction of diesel fuel injection system</li> <li>● Malfunction of immobilizer-ECU</li> </ul>



INSPECTION PROCEDURE FOR TROUBLE SYMPTOMS


Inspection Procedure 1

Speedometer does not work.	Probable cause
The cause may be a defective vehicle speed sensor circuit system or a defective speedometer. Vehicle speed sensor is co-used among the engine-ECU and A/T-ECU.	<ul style="list-style-type: none"> <li>• Malfunction of vehicle speed sensor</li> <li>• Malfunction of speedometer</li> <li>• Malfunction of harness or connector</li> </ul>



Inspection Procedure 2

Tachometer does not work.	Probable cause
The ignition signal may not be input from the engine, or there may be a malfunction in the power supply or earth circuit.	<ul style="list-style-type: none"> <li>• Malfunction of tachometer</li> <li>• Malfunction of harness or connector</li> </ul>




**Inspection Procedure 3**

Bearing indicator is off when moving forward. (for electric compass)	Probable cause
The vehicle magnetism tends to be disturbed particularly at such places as tunnel, railway crossing, area along railway, elevated road, urban above subway, etc. if disturbed, the driving direction marker will fluctuate.	<ul style="list-style-type: none"> <li>• The vehicle magnetic compensation failed</li> </ul>

Vehicle magnetic compensation. (Refer to P.54-38)


**Inspection Procedure 4**

Vehicle magnetic compensation cannot be made. (for electronic compass)	Probable cause
The multi-meter (outside temperature meter of the electronic compass) may be defective.	<ul style="list-style-type: none"> <li>• Malfunction of the multi-meter (outside temperature meter and electronic compass)</li> </ul>



**Inspection Procedure 5**


Discrepancy between the actual outside temperature and displayed temperature.	Probable cause
The outside thermo sensor, multi-meter (outside temperature meter and electronic compass), harness, or connector may be defective.	<ul style="list-style-type: none"> <li>• Malfunction of the outside thermo sensor</li> <li>• Malfunction of the multi-meter (outside temperature meter and electronic compass)</li> <li>• Malfunction of the harness or connector</li> </ul>



# 54-46 CHASSIS ELECTRICAL – Headlamp and Front Combination Lamp

## Inspection procedure 6



<p>The headlamps do not illuminate when the vehicle is in the following condition and the ignition switch is moved to the ON position. However, they illuminate when the lighting switch is moved to the HEAD position. &lt;Vehicles with daytime running lamp&gt;</p> <ul style="list-style-type: none"> <li>● Lighting switch: OFF</li> <li>● Passing switch: OFF</li> </ul>	<p><b>Probable cause</b></p>
<p>The cause is probably a malfunction of the daytime running lamp control unit (DRL-ECU) circuit system. If there is a blown fuse, there may also be a short-circuit in a harness.</p>	<ul style="list-style-type: none"> <li>● Malfunction of fuse</li> <li>● Malfunction of connector</li> <li>● Malfunction of harness wire</li> <li>● Malfunction of the DRL relay (1)</li> <li>● Malfunction of the DRL-ECU</li> </ul>



# TURN-SIGNAL LAMP

54200330138

## REMOVAL AND INSTALLATION



**NOTE**

For removal and installation of the column switch assembly (turn-signal switch), refer to GROUP 37A - Steering Wheel and Shaft.


**Front turn-signal lamp removal steps**

1. Front turn-signal lamp
2. Bulb socket
3. Bulb



**Side turn-signal lamp removal steps**

4. Side turn-signal lamp
5. Bulb socket
6. Bulb
7. Packing
8. Hook



**REMOVAL SERVICE POINT**


**◀A▶ SIDE TURN-SIGNAL LAMP REMOVAL**

Use a flat-tipped screw driver or similar tool to remove the lock from the fender panel, and then remove the side turn-signal lamp.

# ACCESSORY SOCKET


54300890059

## REMOVAL AND INSTALLATION



### Removal steps

1. Quarter trim, lower <R.H.> (Refer to GROUP 52A - Trims.)
2. Outer case
3. Socket




### INSPECTION

54300900042


#### Accessory socket relay continuity check

Battery voltage	Terminal No.			
	1	2	3	4
Not supplied		○	○	○
Supplied	○	⊕	○	⊖

**B-3 There is noise but no reception for both AM and FM or no sound from AM, or no sound from FM.**



**B-4 Insufficient sensitivity.**




\* For multipath noise and fading noise problems, refer to P. 54-72.

## ANTENNA

5440060064

## SPECIAL TOOL

Tool	Number	Name	Use
 B990784	MB990784	Ornament remover	Meter bezel assembly removal

## ANTENNA


54400290340

## REMOVAL AND INSTALLATION

**Pre-removal and Post-installation Operation**

- Front Floor Console Assembly Removal and Installation (Refer to GROUP 52A.)
- Driver's Side Under Cover, Meter Bezel Assembly, Glove Box Assembly, Center Under Cover Removal

and Installation (Refer to GROUP 52A - Instrument Panel.)




B16V0133

**Removal steps**

1. Pole
2. Radio and tape player
  - Front scuff plate (driver's side), cowl side trim (driver's side) (Refer to GROUP 52A - Trim.)



3. Cable clipped portion
4. Antenna base




## ON-VEHICLE SERVICE

55200840096

### SIGHT GLASS REFRIGERANT LEVEL TEST

The sight glass is a refrigerant level indicator. To check the refrigerant level, clean the sight glass and start the vehicle engine. Push the A/C button to operate the compressor, place the blower switch to high and move the temperature control lever to max cool. After operating for a few minutes in this manner, check the sight glass.

1. If the sight glass is clear, the magnetic clutch is engaged, the compressor discharge line is warm and the compressor inlet line is cool; the system has a full charge.
2. If the sight glass is clear, the magnetic clutch is engaged and there is no significant temperature difference between compressor inlet and discharge lines; the system has lost some refrigerant.
3. If the sight glass shows foam or bubbles, the system could be low on charge. The system has to be recharged with refrigerant.



### MAGNETIC CLUTCH TEST

55200850280

1. Disconnect the magnetic clutch connector to the magnetic clutch.
2. Connect battery (+) voltage directly to the connector for the magnetic clutch.
3. If the magnetic clutch is normal, there will be "click". If the pulley and armature do not make contact ('click'), there is a malfunction.

### RECEIVER DRIER TEST


55200860139

Operate the unit and check the piping temperature by touching the receiver drier outlet and inlet.



If there is a difference in the temperatures, the receiver assembly is restricted.

Replace the receiver assembly.

Rear heater relay



T0092AA


20Z0001

00009186



**REAR HEATER RELAY**

Battery voltage	Terminal No.			
	1	2	3	4
Power is not supplied		○	—	○
Power is supplied	○	⊖	—	⊕

Condenser fan control relay



18V0190


20Z0001

00005069

**A/C COMPRESSOR RELAY, CONDENSER FAN RELAY,  
CONDENSER FAN CONTROL RELAY**

Battery voltage	Terminal No.			
	1	2	3	4
Power is not supplied		○	—	○
Power is supplied	○	⊖	—	⊕

# BLOWER ASSEMBLY AND RESISTOR REMOVAL AND INSTALLATION




BV0113AA

### Resistor, blower fan and motor removal steps

- Under cover and glove box assembly (Refer to GROUP 52A – Instrument Panel.)
- 1. Resistor
- 2. Blower fan and motor

### Blower case removal steps

- Instrument panel (Refer to GROUP 52A.)
- Glove box frame or center frame B (Refer to GROUP 52A – Instrument Panel.)
- 3. Joint duct <Vehicles without A/C>
- 4. Cover <L.H. drive vehicles, Vehicles with A/C>
- 5. Evaporator <Vehicles with A/C> (Refer to P.55-30.)
- ▶◀ 6. Inside/outside air changeover damper cable connection
- 7. Blower case assembly

**►E◄ AIR GAP ADJUSTMENT**

Check whether or not the air gap of the clutch is within the standard value.

**Standard value: 0.3 – 0.5 mm**

**NOTE**

If there is a deviation of the air gap from the standard value, make the necessary adjustment by adjusting the number of shims.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL