

## Workshop literature

### High-level order picker

EK-X 2101

EK-X10 2101



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

|                                       |              |
|---------------------------------------|--------------|
| Carbon brushes .....                  | 71-5         |
| Repairs .....                         | 71-5         |
| <b>76 Valves</b>                      |              |
| <b>Pressure relief valve</b> .....    | <b>76-1</b>  |
| General .....                         | 76-1         |
| <b>Control valves</b> .....           | <b>76-2</b>  |
| General .....                         | 76-2         |
| <b>Proportional valve</b> .....       | <b>76-3</b>  |
| General .....                         | 76-3         |
| Testing .....                         | 76-3         |
| Repair .....                          | 76-3         |
| <b>Valve coil</b> .....               | <b>76-5</b>  |
| General .....                         | 76-5         |
| Testing .....                         | 76-5         |
| Repair .....                          | 76-6         |
| <b>80 Load support device</b>         |              |
| <b>Mast bracing</b> .....             | <b>80-1</b>  |
| Repair .....                          | 80-1         |
| <b>Lift mast bearing</b> .....        | <b>80-2</b>  |
| Telescopic lift mast .....            | 80-2         |
| Repair .....                          | 80-2         |
| <b>81 Lift mast</b>                   |              |
| <b>Load chains</b> .....              | <b>81-1</b>  |
| Test steps for load chains .....      | 81-1         |
| <b>Lift cylinder</b> .....            | <b>81-6</b>  |
| Bleeding .....                        | 81-6         |
| Repair .....                          | 81-7         |
| <b>Line break safety valve</b> .....  | <b>81-8</b>  |
| General .....                         | 81-8         |
| Line break safety valve, type 1 ..... | 81-9         |
| <b>Single mast</b> .....              | <b>81-10</b> |
| General .....                         | 81-10        |
| Repair .....                          | 81-11        |
| <b>Telescopic lift mast</b> .....     | <b>81-12</b> |
| Repair .....                          | 81-12        |

## "Diagnosis" menu



The guided diagnosis operations are organised according to function and should be worked through in sequence. Each point can also be carried out separately and repeated.

### ⚠ WARNING

In diagnosis mode, various monitoring functions are switched off.

Please note the remarks in the diagnosis menu! If a diagnosis session is aborted or ended, always reset the truck by switching the key switch OFF and then ON again.

- [F2:display diagnosis] diagnosis menu (1).
- Select the required diagnosis function (2).
- Confirm with [Execute] (3).
- Instructions appear in the window (4) with the option of making an entry for each diagnosis function.
- Window (5) shows a detailed set of instructions for the selected diagnosis function.
- Carry out the instructions (5) and confirm entries with [Done/OK] (6).
- If appropriate, follow further instructions.
- Acknowledge safety instructions.
- End order/sitting with [Reset].
- In the event of **abort or error** in the diagnosis function: End the diagnosis function with file/reset session (7).
- [Protocol] (8) displays a detailed list of all the operations that have been carried out.



## Selecting a control system

After a truck / truck group has been selected, you must select the control system into which the software download is to be carried out.

- Use the mouse pointer to click on the arrow (1).

A selection window (2) opens which contains all the control systems for the selected truck / selected truck group to which a software download can be made.




### NOTE


Depending on the type of truck / truck group, there may be one (3) or more (2) control systems displayed in the selection window.

- Use the mouse pointer to click on the control system.


The display window closes automatically. Only the selected control system (4) is then displayed. In the "Remark" (5) window, additional information or instructions are displayed for downloading the software into the selected control system.



2 1



3



4 5

- Check traction motor.
- Change the controller.

**Error: 131**

- Description: - Error in the transistor control for the traction motor  
Voltage is too high when moving off.
- Response: - Contactors K1 and K2 open.
- Cause: - Short circuit, traction motor is defective.  
- Internal error
- Remedy: - Reset the error by switching off and on again.  
- Check traction motor.  
- Change the controller.

**Error: 132**

- Description: - Error in the evaluation of the digital and analogue signals for height measurement
- Response: - Reduction of the driving, lifting and lowering speeds
- Cause: - Measured height is outside the monitoring window for the analogue value.  
- Lifting movements and lowering movements occur without being activated.  
- Lifting movement or lowering movement is too fast (> 1 m/s).  
- No impulses, despite movement activation.  
- Maximum lift height from the teach-in was exceeded.
- Remedy: - Reset the error by switching off and on again.  
- Carry out height measurement system teach-in.  
- Lower cab completely.  
- Check height measurement system.  
- Check wiring.  
- Check IOZ1.

**Error: 133**

- Description: - Switch statuses for the NC and NO contacts of the foot switch are invalid.
- Response: - Drive stop
- Cause: - Check the 1+24-V power supply. Switch statuses for the foot switch are > 400 ms  
and therefore invalid.  
- Wiring is defective.
- Remedy: - Actuate the correct signal exchange and the foot switch once.  
- Reset the error by switching off and on again.  
- Check the foot switch and the wiring.

**Error: 136**

- Description: - ZAG reports a stop to FPS.
- Response: - Drive stop

- Cause: - Dependent on the program  
Remedy: - Dependent on the program

**Error: 193**

- Description: - 2. Braking stage cannot be switched off.  
Response: - Contactors K1 and K2 open.  
Cause: - The A10-X1:1 connection is continuously at 0 V.  
Remedy: - Check the wiring for the second braking stage. Replace the FPS.

**Error: 194**

- Description: - Automation controller not OK (parameter C60).  
Response: -  
Cause: -  
Remedy: - Reset the error by switching off and on again.

**Error: 195**

- Description: - Automation controller fails to report in at the CAN bus (parameter C60).  
Response: -  
Cause: -  
Remedy: - Reset the error by switching off and on again.

**Error: 196**

- Description: - Internal error  
Response: - Contactors K1 and K2 open.  
Cause: - Error in the controller  
Remedy: - Reset the error by switching off and on again.

**Error: 197**

- Description: - The control processor detects an error at the output for the proportional valve.  
Response: - Lift stop and lowering stop  
Cause: - Error in the controller  
Remedy: - Reset the error by switching off and on again.

**Error: 199**

- Description: - Internal error  
Response: - Contactors K1 and K2 open.  
Cause: - Error in the controller  
Remedy: - Reset the error by switching off and on again.

- Cause: - Software update or BPS is faulty.  
Remedy: - Reset the error by switching off and on again.  
- Reflash the software. Replace the controller.

## Error list for operating panel controller (BPS) 8U62, load side (LS)

### Error2501

- Description: - Evaluation of driving setpoint value.  
Response: - Drive stop/lift stop.  
Cause: - The driving setpoint devices are calibrated incorrectly. The BPS is faulty.  
Remedy: - Reset the error by switching off and on again.  
- Replace the setpoint devices or the controller.

### Error2502

- Description: - Evaluation of lifting setpoint value.  
Response: - Drive stop/lift stop.  
Cause: - The lifting setpoint devices are calibrated incorrectly. The BPS is faulty.  
Remedy: - Reset the error by switching off and on again.  
- Replace the setpoint devices or the controller.

### Error2510

- Description: - Parameter error.  
Response: - Drive stop/lift stop.  
Cause: - The check sum may have changed after flashing new BPS software.  
Remedy: - Reset the error by switching off and on again twice.  
- Replace the controller.

### Error2511

- Description: - CAN bus error.  
Response: - Industrial truck stops.  
Cause: - CAN bus is malfunctioning.  
Remedy: - Reset the error by switching off and on again.  
- Check the individual controllers using the diagnostic software.  
- Remove the cause of the CAN bus malfunction.

### Error2512, Error2513

- Description: - Internal error.  
Response: - Industrial truck stops.  
Cause: - Software update or BPS is faulty.

- Cause: - Defective wiring/sensors.  
Remedy: - Check all inputs for correct wiring, change IOX if necessary.

### FE2946

- Description: - Level monitoring of inputs. With a high-active input the input voltage must be >8V for the input signal to be identified as active.  
Response: - Drive speed reduction  $v = 0\text{km/h}$ , after overriding with the Q button the truck can still be driven at 1km/h.  
- Raise main lift is deactivated.  
Cause: - Defective wiring/sensors.  
Remedy: - Check all inputs and outputs for correct wiring, change IOX if necessary.

### FE2950

- Description: - Internal IOX error.  
Response: - Drive speed reduction  $v = 0\text{km/h}$ , after overriding with the Q button the truck can still be driven at 1km/h.  
- Raise main lift is deactivated.  
Cause: - Internal hardware fault.  
Remedy: - Replace IOX.

### FE2960, FE2961, FE2962, FE2963

- Description: - IOX is receiving no CAN bus data.  
Response: - Drive speed reduction  $v = 0\text{km/h}$ , after overriding with the Q button the truck can still be driven at 1km/h.  
- Raise main lift is deactivated.  
Cause: - CAN bus defective.  
- CAN controller in IOX module defective.  
Remedy: - Check CAN bus or change IOX.

- Cause: - Battery voltage is too low  
Remedy: - Check the battery, battery male connector X1.

**Error: 3451**

- Description: - Excess voltage (UE)  
Response: - The industrial truck stops.  
Cause: - Incorrect battery  
Remedy: - Check the battery.

**Error: 3452**

- Description: - Excess current at end piece (UE)  
Response: - The industrial truck stops.  
Cause: - Internal error  
Remedy: - Reset the error by switching off and on again.  
- Update the software. If the error appears again, replace the steering.

**Error: 3453, 3454**

- Description: - Internal error (UE)  
Response: - The industrial truck stops.  
Cause: - Steering error  
Remedy: - Reset the error by switching off and on again.  
- Update the software. If the error appears again, replace the steering.

**Error: 3455**

- Description: - Internal error (UE)  
Response: - The industrial truck stops.  
Cause: - Incorrect steering software  
Remedy: - Check the software version and parameters.

**Error: 3500**

- Description: - Hour meter error (SR)  
Response: - The industrial truck stops.  
Cause: - Steering error  
Remedy: - Reset the error by switching off and on again.  
- Update the software. If the error appears again, replace the steering.

**Error: 3501**

- Description: - Internal error (SR)  
Response: - The industrial truck stops.  
Cause: - Steering error

**Error: 3646, 3647, 3648, 3649**

- Description: - Setpoint device error (UE)  
Response: - The industrial truck stops.  
Cause: - Short circuit or interruption  
Remedy: - Check the wiring and setpoint device.

**Error: 3650**

- Description: - Angle difference between (SR) and (UE) is too great.  
Response: - The industrial truck stops.  
Cause: - Short circuit or interruption, setpoint device or actual value device is faulty  
Remedy: - Reset the error by switching off and on again.  
- Check the setpoint device and actual value device.  
- Perform steering teach-in.  
- Perform the "Load basic parameters" function using the diagnostic software.  
- Update the software. If the error appears again, replace the steering.

**Error: 3651**

- Description: - Rotational speed of the setpoint device is too high (UE).  
Response: - The industrial truck stops.  
Cause: - Rotational speed of the setpoint device is too high.  
Remedy: - Check the actual value device.  
- Reset the error by switching off and on again.  
- Perform the "Load basic parameters" function using the diagnostic software.  
- Update the software. If the error appears again, replace the steering.

**Error: 3653, 3654, 3655**

- Description: - Internal error (UE)  
Response: - The industrial truck stops.  
Cause: - Steering error  
Remedy: - Reset the error by switching off and on again.  
- Perform the "Load basic parameters" function using the diagnostic software.  
- Update the software. If the error appears again, replace the steering.

**Error: 3657, 3658**

- Description: - Difference between the target speed and actual speed is too great (UE).  
Response: - The industrial truck stops.  
Cause: - Steering is stiff.  
Remedy: - Check the steering turntable for ease of movement.  
- Reset the error by switching off and on again.  
- Perform the "Load basic parameters" function using the diagnostic software.  
- Update the software. If the error appears again, replace the steering.

- Check CAN bus and antennas.
- Replace antenna and controller.

**Error4310, Error4311, Error4312, Error4313**

- Description: - Antenna CAN bus error.
- Response: - Emergency off.
- Cause: - Unknown message from antenna 0–3.
- Remedy: - Reset by switching the truck off and then on again.  
- Check antenna and software version.  
- Update antenna and controller software.

**Error4314, Error4315, Error4316, Error4317**

- Description: - Incorrect antenna signal.
- Response: - Emergency off.
- Cause: - Antenna mode of antenna 0–3 is invalid for control.
- Remedy: - Reset by switching the truck off and then on again.  
- Check antenna.  
- Replace antenna and controller.

**Error4318, Error4319, Error4320, Error4321**

- Description: - Incorrect antenna mode.
- Response: - Emergency off, only in IZF automatic mode of operation.
- Cause: - Antenna mode of antenna 0–3 is invalid.
- Remedy: - Reset by switching the truck off and then on again.  
- Check CAN bus and antenna.  
- Replace antenna and controller.

**Error4322, Error4323, Error4324, Error4325**

- Description: - Incorrect antenna channel.
- Response: - Emergency off.
- Cause: - Antenna 0–3 not active on the selected channel.
- Remedy: - Reset by switching the truck off and then on again.  
- Check antenna.  
- Replace antenna and controller.

**Error4326, Error4327, Error4328, Error4329**

- Description: - Antenna digital distance error.
- Response: - Emergency off, only in IZF automatic mode of operation and guided on wire and at a distance of < 10 cm.
- Cause: - Redundant antenna evaluation of antenna 0–3 is invalid.
- Remedy: - Reset by switching the truck off and then on again.

**Error4705**

- Description: – Internal error.
- Response: – Emergency off.
- Cause: – Error response must be known for every error.
- Remedy: – Reset by switching the truck off and then on again.  
– Replace the controller.

**Error4706**

- Description: – IZF does not receive the OK signal from the steering.
- Response: – Emergency off, if automatic mode (IZF) is selected.
- Cause: – Steering malfunction (ELK), CAN bus error.
- Remedy: – Switch to manual operation. Reset by switching the truck off and then on again.  
– Check steering, parameters and CAN bus.

**Error4707**

- Description: – When the truck is switched off, the IZF must be correctly shut down. This is checked when the truck is switched on.
- Response: – Drive stop.
- Cause: – Loss of voltage, controller defective.
- Remedy: – Reset by switching the truck off and then on again.  
– Replace the controller.

**Error4708**

- Description: – Errors cannot be saved internally.
- Response: – Emergency off.
- Cause: – Internal error.
- Remedy: – Reset by switching the truck off and then on again.  
– Replace the controller.

**Error4710, Error4711, Error4712, Error4713**

- Description: – Monitoring of the guide wire current of antenna 0–3 (within the aisle).
- Response: – Emergency off, only in IZF automatic mode of operation.
- Cause: – In the guided status, the current measured by antenna 0–3 must not be 0.  
– Short to earth, no guide wire current.
- Remedy: – Reset by switching the truck off and then on again or by deselecting IZF.  
– Check antennas, connections and guide wire current.  
– Perform field strength teach-in.

**Error4714**

- Description: – Monitoring of the takeover when the IZF takes over the guidance.
- Response: – Emergency off, only in IZF automatic mode of operation.

- Cause: – Malfunction.  
Remedy: – Reset by switching the truck off and then on again.

**Error4836, Error4837, Error4838**

- Description: – Invalid frequency channel for control on LS/DS antenna or auxiliary antenna.  
Response: – Emergency off, only in IZF automatic mode of operation.  
Cause: – Malfunction.  
Remedy: – Reset by switching the truck off and then on again.

**Error4839**

- Description: – Speed limit for cornering exceeded.  
Response: – Emergency off, only in IZF automatic mode of operation.  
Cause: – Malfunction.  
Remedy: – Reset by switching the truck off and then on again.

**Error4840**

- Description: – Error during switchover to cornering.  
Response: – Emergency off, only in IZF automatic mode of operation.  
Cause: – Switchover to cornering before the antennas were switched over.  
Remedy: – Reset by switching the truck off and then on again.

**Error4900**

- Description: – Invalid error message from the monitoring processor.  
Response: – Emergency off, immediate.  
Cause: – Monitoring processor checking function.  
Remedy: – Reset by switching the truck off and then on again.  
– If error recurs, replace the controller.

**Error4901**

- Description: – Telegram request not received simultaneously by the main processor and monitoring processor.  
Response: Not an error.  
Cause: – Monitoring processor checking function.  
Remedy: – Reset by switching the truck off and then on again.  
– If error recurs, replace the controller.

**Error4902, Error4903, Error4904, Error4905, Error4906**

- Description: – Error when reading/writing data from/to EEPROM.  
Response: – Immediate drive stop.  
Cause: – Monitoring processor checking function.

**Error4990, Error4991**

- Description: – Status of the sensor for the steering angle limiter (locked/unlocked) must be the same in the main processor and the monitoring processor.
- Response: – Drive stop.
- Cause: – Monitoring processor checking function.
- Remedy: – Reset by switching the truck off and then on again.  
– Check sensors. If error recurs, replace the controller.

**Error4993**

- Description: – Speed setting in the main processor (setpoint value) is higher than in the monitoring processor.
- Response: – Drive stop.
- Cause: – Monitoring processor checking function.
- Remedy: – Reset by switching the truck off and then on again.  
– If error recurs, replace the controller.

**Error4994**

- Description: – The aisle detection status must be the same in the main and monitoring processors.
- Response: – Drive stop.
- Cause: – Monitoring processor checking function.
- Remedy: – Reset by switching the truck off and then on again.  
– If error recurs, replace the controller.

**Error4995**

- Description: – Changeover between standard and extended antennas must be the same in the main processor and monitoring processor.
- Response: – Emergency off.
- Cause: – Monitoring processor checking function.
- Remedy: – Reset by switching the truck off and then on again.  
– If error recurs, replace the controller.

**Error4996**

- Description: – Frequency channel selection must be the same in the main processor and monitoring processor.
- Response: – Emergency off.
- Cause: – Monitoring processor checking function.
- Remedy: – Reset by switching the truck off and then on again.  
– If error recurs, replace the controller.

**FE6174**

- Description - Overload at the "10 V power supply" output.
- Response: -
- Cause: - Wiring or IOZ faulty.
- Remedy: - Reset by switching the truck off then on again.  
- Check wiring or IOZ.  
- Change the controller.

**FE6175**

- Description - Overload at the free digital outputs.
- Response: - Free digital outputs are switched off.
- Cause: - The switch-on current, single current or total current is too large.
- Remedy: - Reset by switching the truck off then on again.  
- Check consumers at the free digital outputs. Modify the external suppressor circuit, e.g. the capacitor.  
- Change the controller.

**FE6176**

- Description - Error at the analogue inputs.
- Response: -
- Cause: - Faulty connections, IOZ faulty.
- Remedy: - Reset by switching the truck off then on again.  
- Check connections or IOZ.  
- Change the controller.

## Testing

### Supply voltage

- Switch off the truck.
- Release the connector plug from the rev sensor.
- Connect the voltage measuring device to the connector plug.
- Switch on the truck.
- Perform voltage measurement.

The supply voltage must be approximately 12V.


If this is not the case, check the wiring from the rev sensor to the inverter.

### Output signals

- Raise the truck and support securely.
- Connect the rev sensor.
- Switch on the truck.
- Connect the voltage measuring device to the rev sensor connector plug between 0V and channel A or B.
- Perform the voltage measurement while the motor is rotating at a low speed. Each channel must have an AC voltage of approximately 0V or 12V.

If no alternating signals can be measured, then measure them with the device removed. It is possible that the sensing distance to the gear is incorrect or the rev sensor is contaminated with metal chips.

If the voltage is significantly less or no voltage is detected, the rev sensor is defective and must be replaced.



## Maintenance

### Activities

- **Oil change:** The gearbox oil must be changed for the first time after 1000 operating hours. After that, the gearbox oil must be changed every 2000 operating hours or on a yearly basis.

### Gearbox lubricant

#### Oil grades

The oils used must correspond at least to the following specifications:

Standard:

- Classification according to API GL-5
- SAE class 80W-90

Cold store:

- Classification according to API GL-5
- SAE class 75W-90

#### Oil filling quantity

Volume: 1.5 l

## Repair

### Removing the steering unit




*It is **not** necessary to remove the collision protection for removal of the steering unit.*

- Jack up the truck and secure it against rolling away.
- Disconnect the battery male connector.
- Mark connection cables U, V, W and disconnect them.
- Unplug the internal incremental transducer and temperature sensor.
- Undo the 4 screws (1) at the motor flange.
- Pull the steering unit upwards to take it out.
- Place the assembly lever (5) on the collision protection (4) and engage it on the shaft end (3) underneath the steering pinion gear (2).
- Push the pinion gear with shaft and flange upwards.



img61200770394m1



img61200770392m1

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below




- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

## Connections

Connections, 6-pin plug X1

| Pin | Signal   |
|-----|--|
| 1   | Main potentiometer actual value, approx. 0.5V - 4.5V |
| 2   | 5V supply  |
| 3   | Free   |
| 4   | Free   |
| 5   | 0V supply  |
| 6   | Free   |



img61200440546m2

## Test

### Test procedure


If the actual value potentiometer is defective, an error message appears in the display.

While it is installed, the following values can be checked using the diagnostic software:


- Voltage of the main potentiometer.
- Current draw of the potentiometer

The resistance can be measured with the device removed. Main potentiometer / control potentiometer have a zero transition offset by 90°:

- Total resistance between pins 2 + 5.
- Resistance measuring between pins 1 + 2 or pins 1 + 5 of the main potentiometer.
- Resistance measuring between pins 6 + 2 or pins 6 + 5 of the control potentiometer.
- Measure the resistance of the slider between pins 1 + 2 and pins 1 + 5 with the main potentiometer in the centre position. The resistance is **not linear** due to the parallel connection of the main potentiometer / control potentiometer.



img61200440551m2



img61200440552m1

## Technical data

|  |   |
|--|---|
| Pin 2 power supply   | +5V   |
| Pin 5 power supply   | 0V  |
| Setpoint signal from main potentiometer / control potentiometer                  | approx. 0.5V - 4.5V   |
| Current draw   | approx. 3mA   |
| Total resistance   | 1900Ω ±15%  |
| Resistance range of the slider of the main potentiometer / control potentiometer | approx. 200Ω - 1700Ω  |
| Resistance of the slider of the main potentiometer in the centre position        | approx. 1325Ω (symmetrically arranged, difference max. 50Ω) |

## Setpoint device

### General

#### Identification



#### NOTE

*From 01/2017 the ES30-24 steering unit is installed, with a Hall sensor for the setpoint device.*

The setpoint device (2) can be accessed under the operating panel once the cover has been removed.

### Function

The setpoint device specifies the desired steering direction. It generates two setpoint signals—channel A and channel B—both of which are evaluated by the steering unit.




#### NOTE

Check that the steering wheel and steering knob move easily.

#### ⚠ CAUTION

**Only** clean the steering wheel and steering knob mechanisms.

**Do not use lubricants.**



img612016\_0061m1

### Function of the steering wheel

After switch-on, the drive wheel turns to the straight-ahead position. This is determined by the reference switch and actual value transmitter. The current steering wheel position is adopted as the straight-ahead position.


When configuring the "steering wheel", an internal conversion of the setpoint value is calculated in the steering unit, depending on the rotation of the steering wheel.

The drive wheel turns by 30 or 45 degrees (this can be configured via the diagnostic software) according to the rotation of the steering wheel. The steering wheel has no mechanical stop. If the steering wheel is turned further, the maximum steering angle of the steering unit is restricted to  $\pm 95^\circ$ . When the steering wheel is turned back out of an end position, the current steering wheel position is immediately adopted as the setpoint value. There is no dead range.

# Inductive guidance

## General

Block diagram (for industrial trucks up to 12/2016)



img612012\_0004m1

- |   |   |    |   |
|---|---|----|---|
| 1 | Wire guidance controller (IZF) 3A21                   | 7  | Antenna 0 = Antenna load side                     |
| 2 | Display (DIS) 8A12, integrated in the operating panel | 8  | Antenna 1 = Antenna drive side                    |
| 3 | Steering motor 3M1                                    | 9  | Steering controller (ELK) 3A20                    |
| 4 | Actual value potentiometer                            | 10 | Traction motor rev sensor                         |
| 5 | Operating panel controller (BPS) 8U62                 | 11 | Traction controller and pump controller (FPS) A10 |
| 6 | Light barriers for aisle detection                    | 12 | Steering motor incremental transducer             |

## Controller (IZF) 3A21

### General

#### Function


The controller monitors and controls all functions of the IZF.

#### Technical data

|                         |   |
|-------------------------|---|
| Power supply            | +24V DC (16V to 32V)                                |
| Operating temperature   | -32°C to +70°C                                      |
| Digital control outputs | 24V, 1.5A, short-circuit proof                      |
| Digital power outputs   | 24V, 5A, short-circuit proof with current detection |
| Digital inputs          | +24V  |
| Analogue inputs         | 0 to 10V  |
| Relay contact           | 2A, inductive                                       |
| Protection type         | IP64  |

#### Identification

Cast aluminium housing (1) with 42-pin connector plug, nameplate with ID number.



#### Connections

| PIN | Signal                       | Pin | Signal  |
|-----|------------------------------|-----|---|
| 1   | GND, 0V                      | 22  | S GND, DS antenna cable screen, free              |
| 2   | D+, 24V signal "save"        | 23  | Emergency stop relay (NO contact)                 |
| 3   | GND, LS antenna              | 24  | Emergency stop relay (NO contact)                 |
| 4   | Antenna 0 analogue input, LS | 25  | Aisle detection digital output, 0V = in the aisle |
| 5   | +6.5V LS antenna             | 26  | Digital output, free                              |
| 6   | +6.5V DS antenna             | 27  | +10V, free  |
| 7   | Antenna 1 analogue input, DS | 28  | +24V supply for outputs                           |
| 8   | GND, DS antenna              | 29  | L GND, 0V supply for outputs                      |

# Wheels

## Traction wheel

### General

|                     |                   |
|---------------------|-------------------|
| Dimensions when new | ∅ 250 mm x 100 mm |
| Wear limit          | ∅ 225 mm          |

The drive wheel (1) must be changed if:

- The tread is significantly chipped or irregular, or is cracked.
- The tyre diameter is reduced by a maximum of 10%.



**i** NOTE

From 07/2013 onwards, skids are no longer used for collision protection. Instead, M16x40 hexagon head screws are usually fitted as anti-tipping supports for chassis widths of 980 mm.

**⚠ CAUTION**

Risk of truck tipping! After the drive wheel has been exchanged, the distance between the anti-tipping supports and the ground must be checked and adjusted.

The distance is specified individually on the load capacity diagram (2).



## Test

### Checking the solenoid coils.

- Switch off the truck.
- Disconnect the magnetic brake from connection assembly 1X44.
- Measure the resistance for braking stage 1+2.
- Connect connection assembly 1X44.
- Switch on the truck.
- Measure the voltage for braking stage 1+2.

### 1-stage brake test values


|                        | Braking stage 1 |
|------------------------|-----------------|
| Coil resistance        | approx. 10.5Ω   |
| Relay drop-out voltage | approx. 23 V    |
| Rated power            | 40 W            |

### 2-stage brake test values

|                        | Braking stage 1 | Braking stage 2 |
|------------------------|-----------------|-----------------|
| Coil resistance        | approx. 10.5Ω   | approx. 45Ω     |
| Relay drop-out voltage | approx. 23 V    | approx. 23 V    |
| Rated power            | 40 W            | 12.5 W          |

### Checking the clearance

- Using a feeler gauge (1), test the clearance between the magnet component (2) and the anchor disc (3) at 3 positions near the screw.
- If the clearance  $> < 0.4$  mm, it must be set to the correct value (see Repair).



### Testing the brake retardation

The retardation of the magnetic brake must be checked during the regular testing and after any repairs are carried out, so that the truck:

- Does not brake too sharply. The stability of the truck must be ensured at all times
- Does not exceed the maximum permissible braking distance to a standstill

The test must be carried out in the drive direction with the higher maximum speed. If the maximum speed is the same for both drive directions, the test only has to be carried out in the load side direction.

Following this the battery discharge status is displayed continuously. No other display elements can be selected using the arrow buttons.



img61200880445m1

### Error display and information display

Information is shown in the 7-segment display. Each information display consists of the two letters **IN** followed by the information number.

Errors are shown in the 7-segment display. Each error display consists of the two letters **FE** followed by the error number.



img6120088437m1

### Repair

The display itself cannot be repaired, instead it must be exchanged as a complete unit.



## Plug X862.2, pin assignment

| Pin | Signal for EM                         | Signal for TE                         |
|-----|---------------------------------------|---------------------------------------|
| 1   | Right/left barrier switch, NC contact | Right/left barrier switch, NC contact |
| 2   | Right/left barrier switch, NO contact | Right/left barrier switch, NO contact |
| 3   | Barrier switch, load side, NC contact | Barrier switch, load side, NC contact |
| 4   | Barrier switch, load side, NO contact | Barrier switch, load side, NO contact |
| 5   | 1.2 m position switch                 | Left chain switch, NO contact         |
| 6   | Lift mast position switch             | Right chain switch, NO contact        |
| 7   | 2-hand button, load side              | 2-hand button, load side              |
| 8   | Button for lifting auxiliary lift.    | Button for lifting auxiliary lift.    |
| 9   | Button for lowering auxiliary lift.   | Auxiliary lift lowering button.       |
| 10  | Auxiliary lift up limit switch        | Auxiliary lift up limit switch        |
| 11  | Auxiliary lift down limit switch      | Auxiliary lift down limit switch      |
| 12  | Free                                  | Free                                  |

## Plug X862.3, pin assignment

| Pin | Signal   |
|-----|--|
| 1   | 1+24 V power supply  |
| 2   | 0 V power supply   |
| 3   | CAN_H  |
| 4   | CAN_L  |
| 5   | Emergency stop button  |
| 6   | Emergency stop button  |
| 7   | Detection of the operating panel on both sides                   |
| 8   | +5 V power supply for steering setpoint potentiometer, load side |
| 9   | 0 V power supply for steering setpoint potentiometer, load side  |
| 10  | Detection of the operating panel mounting position               |
| 11  | Free   |
| 12  | Free   |
| 13  | Enable hydraulics  |
| 14  | Enable driving   |
| 15  | Free   |
| 16  | Free   |
| 17  | Slider 1 for steering setpoint potentiometer, load side          |
| 18  | Slider 2 for steering setpoint potentiometer, load side          |

## Plug support chassis

### General

#### Mounting position

The chassis plug holder (1) is on the right of the control board in the control compartment.

There are 4 chassis plug holder variants:

- **Distributor 1:** industrial trucks with simplex mast without options
- **Distributor 2:** industrial trucks with simplex mast with options
- **Distributor 3:** industrial trucks with telescopic mast without options
- **Distributor 4:** industrial trucks with telescopic mast with options



| Plug | Function                        | Distributor 1 | Distributor 2 | Distributor 3 | Distributor 4 |
|------|---------------------------------|---------------|---------------|---------------|---------------|
| X1   | Trailing cable                  | X             | X             | X             | X             |
| X70  | Emergency off                   |               | X             | X             | X             |
| X71  | ZAG emergency off               |               | X             |               | X             |
| X72  | External traction cut-out       | X             | X             | X             | X             |
| X75  | ZAG coding                      |               | X             |               | X             |
| X99  | MPSE personal protection system |               | X             |               | X             |
| X140 | Pedestrian mode                 |               | X             | X             | X             |
| X320 | Right rail switch               |               | X             |               | X             |
| X321 | Left rail switch                |               | X             |               | X             |
| X700 | ZAG                             |               | X             |               | X             |
| X720 | ZAG sensors (S1–S4)             |               | X             |               | X             |
| X722 | ZAG sensors (S5–S8)             |               | X             |               | X             |
| A    | Free, CO                        | X             | X             | X             | X             |

#### Plug X1, pin assignment

| Pin | Signal for EM        | Signal for TE        |
|-----|----------------------|----------------------|
| 1   | 0 V power supply     | 0 V power supply     |
| 2   | +24 V power supply   | +24 V power supply   |
| 3   | 1+24 V power supply  | 1+24 V power supply  |
| 4   | Emergency stop chain | Emergency stop chain |
| 5   | CAN_H                | CAN_H                |
| 6   | CAN_L                | CAN_L                |
| 7   | Enable hydraulics    | Enable hydraulics    |

## Drive/pump controller

### General

#### Function

The drive controller and pump controller (1) (FPS) controls an AC traction motor and a DC pump motor. The converters are activated according to the principle of pulse width modulation (PWM) via a logic card with a main processor and a monitoring processor.

The FPS uses the CAN bus to communicate with other controllers.

The FPS contains the following software:

- Truck program
- Truck-specific parameters and options
- CAN configuration
- Error memory

#### Monitoring

The FPS monitors:

- Battery polarity
- Battery charge
- Inputs and outputs
- Temperature at the heat sink
- Temperature of the motors
- Switch-on sequence
- Switchover if there are operating panels on both sides
- Uncontrolled setting off

The main contactor does not close if the following has occurred:

- Error in the power module
- CAN bus error
- Logic fault
- Incorrect input statuses



#### NOTE

***From 01/2017, a modified drive/pump controller (FPS) is installed. The FPS is not compatible for installation in older industrial trucks.***

#### Diagnostics

The computer is connected to the diagnostic interface in the control compartment, or from 01/2017 to the diagnostic interface in the driver's cab.



img61200770062m1


| Pin | "IOZ2" cab installation signal             | Description of functions  |
|-----|--|---|
| 1   | 1+24V supply                               |   |
| 2   | 0V supply                                  |   |
| 3   | Digital output 1                           | UPA program with digital output                                   |
| 4   | Digital output 2                           | UPA program with digital output                                   |
| 5   | Digital output 3                           | UPA program with digital output                                   |
| 6   | +10V supply, 0.15A for analogue connection |   |
| 7   | 0V supply for analogue connection          |   |
| 8   | Free                                       |   |
| 9   | Free                                       |   |
| 10  | Analogue input 1                           | UPA program with analogue input                                   |
| 11  | Analogue input 2                           | UPA program with analogue input                                   |
| 12  | Free                                       |   |
| 13  | Free                                       |   |
| 14  | Variant 1: free                            |   |
| 14  | Variant 2: Linde FleetManager™ input       | Enable signal from Linde FleetManager™, PIN was entered correctly |

## Operating panel controller (BPS) 8U62 up to 12/2016

### General

### Function

The **operating panel controller (BPS)** actuates all operating devices and is located under the operating panel.



img61200880440m1

## Traction batteries and accessories

### Replacing the battery

#### ⚠ CAUTION

Risk of accident

Before the start of each shift, check that the battery is correctly latched in place.

As standard, the battery is installed in a recess in the chassis (1).

Alternatively, the battery rests on roller channels and can be removed from the side of the truck using a battery change frame. Latches with knurled-head screws secure the battery in place to prevent it rolling out to the side.

#### Battery replacement up to 12/2016

##### Removing the battery:



- Release the knurled-head screw and the rubber buffer.
- Remove the latch (2).

##### Installing the battery:

- Insert the latch (2) and tighten the knurled-head screw (3).

#### NOTE

Ensure that the knurled-head screws are tightened symmetrically on both sides. The thread on the rubber buffer must not be screwed to a dead stop.



- Fasten the sling (2) under the connections (3) on the pump motor. Lift the complete hydraulic power unit up and out of the control compartment using a lifting system (1).




### Pump unit – installation



*The sealing ring (2) between the pump unit and the tank is located in a groove on the flange (1) of the pump unit. During installation, make sure that the sealing ring remains in the groove.*

To install, simply follow the removal steps in the reverse order.





## Mast bracing

### Repair

#### Assembly instructions

The mast bracing is attached for lift masts with an overall height of 2900mm.

- Screw on the mast bracing at the upper mounting with a screw and self-locking nut.
- Set the length of the mast bracing with threaded rod (1).
- Screw on the mast bracing at the lower mounting. Secure the screw (2) with chemical screw locking of medium strength (e.g. Loctite 243).
- Tighten the connections. Torque **MA=195Nm**.
- Pre-tighten the mast bracing at the threaded rod (2) with a maximum of 1/4 turn (MA= 50Nm) and secure with lock nuts.



## Repair

According to the lifting tools available (crane, forklift truck, truck hydraulics), a lift cylinder can be removed in various ways.

### **⚠ DANGER**

**Risk of fatality when lowering the lift mast / cab.**

Support the lift mast / cab securely.

### **⚠ DANGER**

**Risk of crushing when lifting the cylinder.**

Secure the cylinder with a sling and lift using the crane / forklift truck.

### Variant 1

Simplest method.


- Release the piston (1) on both sides and raise the lift mast with a crane.

### Variant 2

- Raise the lift mast using truck hydraulics.
- Support the lift mast securely and push the pistons back by hand.

### Variant 3

- On one cylinder, release and close the hydraulic line. Release the top of the piston on the cylinder that is not connected. Then raise the lift mast with the other cylinder.



## Audible and visual emergency signal

### Emergency signal option



#### NOTE

This option is available for **industrial trucks from 2017 onwards**. If the relevant alarm has been triggered, the barrier (5) or foot switch (6) symbols flash. Software versions V2.30 and later support the flashing display for the drive/pump controller (FPS).

The "Acoustic and optical emergency signal" purchase option can be deactivated on the "Truck options/default parameters" diagnostics page using parameter C68 (1).

### Function

The parameters "(P 107) Timeout barrier"(2), "(P 108) Timeout inactivity"(3) and "(P 109) Timeout foot switch"(4) can be used to set monitoring times of 0.5 minutes to 5 minutes.



#### NOTE

"(P107) Timeout barrier" is only evaluated if the lift height of the cab is higher than specified in parameter "P31 Maximum height with open barrier".

At the end of the timeout, the buzzer is activated on the display as a warning. A total of 10 cyclical acoustic signals is generated within 15 seconds. If the alarm is not reset, the horn and the direction indicator are activated five times. If the alarm is not reset, the procedure is repeated.

Actuating the following operating devices resets the alarm:

- Foot switch (parameter P 107)
- Barrier (parameter P 108/P 109)



#### NOTE

The pause function can only be activated below the lift height of the cab at which the barriers may be open.

### Pause function

If the ESC button on the display is actuated for approximately 2 seconds, a cyclical acoustic signal sounds 10 times. The pause function is then active and the timeout parameters are no longer evaluated.

Fahrzeugooptionen / Grundparameter | Haupthub / Zusatzhub



**Fahrzeugooptionen / Grundparameter**

**Akustisches und optisches Notsignal**

|  | Vorhanden |
|--|-----------|
| (C68) Notsignal bei Zeitüberschreitung         | 1 min     |
| (P107) Zeitüberschreitung Schranke in [min]    | 1 min     |
| (P108) Zeitüberschreitung Inaktivität in [min] | 1 min     |
| (P109) Zeitüberschreitung Fusschalter in [min] | 1 min     |

img612017\_0169m1

1 2 3 4



## End of aisle slow down and stop (ZAG)

| LED               | Description  | Level       |
|-------------------|--|-------------|
| GE2-Z2            | Rail switch 2, aisle detection                     | Low active  |
| S1, S3,<br>S5, S7 | Sensor inputs for zone recognition                 | Low active  |
| S2, S4,<br>S6, S8 | Inverse signal of the sensor inputs S1, S3, S5, S7 | High active |

## Zone partitioning

|                             | Outside the aisle                        | Aisle end zone, not an absolute stop         | Plate offset zone                    | Rapid travel zone                    | Absolute stop   |
|-----------------------------|--|--|--------------------------------------|--------------------------------------|---|
| <b>Sensor status</b>        |  |  |                                      |                                      |   |
| S1, S3                      | S1, S3 any                               | S1=1 and S3=1                                | S1=1 and S3=0 or S1=0 and S3=1       | S1=0 and S3=0                        | S1=1 and S3=1   |
| S5, S7                      | S5, S7 any                               | S5=0 and S7=0                                | S5=0 and S7=0                        | S5=0 and S7=0                        | S5=1 or S7=1  |
| Aisle detection<br>GE1, GE2 | GE1=1 and<br>GE2=1, ZAG<br>is not active | GE1=0 and/or<br>GE2=0, ZAG is<br>active      | GE1=0 and<br>GE2=0, ZAG<br>is active | GE1=0 and<br>GE2=0, ZAG<br>is active | GE1=0 and<br>GE2=0, ZAG<br>is active                      |
| <b>Speeds</b>               | V <sub>max</sub>                         |  |                                      |                                      |   |
| Towards the aisle end       | -  | V <sub>RED</sub> (2.5 km/h)                  | V <sub>max</sub>                     | V <sub>max</sub>                     | Braking to STOP, with acknowledgement<br>V <sub>RED</sub> |
| Towards the aisle centre    | -  | V <sub>max</sub>                             | V <sub>max</sub>                     | V <sub>max</sub>                     | V <sub>max</sub>  |
| <b>STOP option</b>          | V <sub>max</sub>                         |  |                                      |                                      |   |
| Towards the aisle end       | -  | *) Braking to STOP, then<br>V <sub>RED</sub> | V <sub>max</sub>                     | V <sub>max</sub>                     | Braking to STOP, with acknowledgement<br>V <sub>RED</sub> |
| Towards the aisle centre    | -  | V <sub>max</sub>                             | V <sub>max</sub>                     | V <sub>max</sub>                     | V <sub>max</sub>  |
| <b>After switching on</b>   | V <sub>max</sub>                         |  |                                      |                                      |   |
| Towards the aisle end       | -  | V <sub>RED</sub>                             | V <sub>RED</sub>                     |                                      | STOP, with acknowledgement<br>V <sub>RED</sub>            |
| Towards the aisle end       | -  | V <sub>RED</sub>                             | V <sub>RED</sub>                     |                                      | STOP, with acknowledgement<br>V <sub>RED</sub>            |

## Inductive ZAG error list



## NOTE

- In the event of an **error**, the truck will be braked to a (STOP), even if the Q button is pressed. After stopping, the truck can be driven in both directions at crawling speed by holding down the Q button.
- On speeding up, ZAG (FE36) error is briefly displayed -> hardware test.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL