

Workshop Service Manual

FENDT 700 Vario SCR (Stage 3b)

732 .. 1001-
733 .. 1001-
734 .. 1001-
735 .. 1001-
736 .. 1001-

737 .. 1001-



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Only start the engine once all safety guards have been attached and nobody is standing in the danger area.
- Never let the engine run in enclosed spaces with no exhaust gas suction system.
- Cleaning, maintenance and repair work may only be carried out once the engine is switched off and secured to prevent it starting.
- Injection pipes and high-pressures lines must not be deformed.
- Any damaged injection pipe or high-pressure line must be replaced.
- Do not loosen any injection pipes for high-pressure fuel lines while the engine is running.
- Before carrying out checks to the running engine, always perform a visual check of all high-pressure components. Suitable protective clothing (e.g. protective goggles) should be worn while doing this. Leaks indicate potential sources of danger for workshop personnel.
- In the event of leaks to the high-pressure fuel system, always remain out of range of any possible fuel spray to avoid serious injury.
- Even when no leaks to the high-pressure fuel system can be detected, workshop personnel should avoid the immediate danger area and wear suitable protective clothing (such as protective goggles) when carrying out checks to the running engine and during the first test run.
- Smoking is forbidden while carrying out work to the fuel system.
- Do not work in the proximity of sparks or naked flames.
- Never disconnect an injector while the engine is running.

5. Working on the PTO

- Always switch off the engine before fitting or removing the drive shaft. PTO in "0" position!
- When working on the PTO, allow no-one in the vicinity of the rotating PTO or drive shaft.
- Make sure drive shaft and PTO are equipped with shield pipes and protective funnels.
- After deactivating the PTO, it is possible that parts on the mounted implement may continue to run. In this case, do not get too close to the implement. Work may only be carried out to the implement when nothing is moving!
- When the drive shaft is removed, cover the PTO shaft with its protective cap.
- Nobody should be in the cab when installing and removing the drive shaft.
Operation of controls for the tractor and mounted implements by people in the cab, especially children, may result in severe or fatal injury.

6. Working on the front loader

- Before undertaking maintenance work, lower the front loader to the ground, switch off the engine and remove the ignition key.
- In the event of a collapsed pipe rupture feature, support the load before starting repair work, and slowly retract the cylinder.
- Check hydraulic hoses and pipes for signs of damage and aging regularly and replace with genuine spare parts in good time.
- Following installation and repairs, operate the tractor for a short time, then retighten all nuts and bolts and check them regularly.
- Retighten eccentric bolt for front loader attachment, if necessary.

Disposal

The work described in the operator's manual and workshop manual includes replacing parts, fuel and lubricants. These renewed parts/fuel/lubricants must be stored, transported and disposed of in accordance with regulations. The repairing workshop bears responsibility for this. The disposal encompasses the recycling and final disposal of parts, fuel and lubricants with recycling having the higher priority. Details about disposal and monitoring are specified in regional, national and international laws and directives, the observation of which is the sole responsibility of the repairing workshops.

2 Technical data: 1000 transmission

| Tractor type | | 714 Vario | 716 Vario | 718 Vario | 720 Vario | 722 Vario | 724 Vario |
|--|-----------------|--|-----------|-----------|-----------|-----------|-----------|
| Chassis no.: | | 732/.. | 733/.. | 734/.. | 735/.. | 736/.. | 737/.. |
| Transmission oil (Vario transmission) | | | | | | | |
| Oil grade | - | FENDT Extra Trans 10W-40 or STOU SAE 10W-40 STOU SAE 15W-40 | | | | | |
| Transmission, initial fill | l | approx. 58 | | | | | |
| Transmission, subsequent fills | l | approx. 47 | | | | | |
| Oil quantity between Min. and Max. marks | l | approx. 3 | | | | | |
| Oil change interval | Op. hrs / years | 2000 / 2 | | | | | |
| | | | | | | | |

| Tractor type | | 714 Vario | 716 Vario | 718 Vario | 720 Vario | 722 Vario | 724 Vario |
|---|-------|---------------------------|-----------|-----------|-----------|-----------|-----------|
| Chassis no.: | | 732/.. | 733/.. | 734/.. | 735/.. | 736/.. | 737/.. |
| Vario: continuously variable transmission | | | | | | | |
| Transmission | Model | ML 140 | | ML 180 | | | |
| Transmission unit (Vario insert) | Model | ML 180 | | | | | |
| Travel range | - | I (Field) II (Road) | | | | | |
| Speed (forwards) | | | | | | | |
| Speed range I (Field) | km/h | 0.02 ... 28 | | | | | |
| Speed range II (Road) | km/h | 0.02 ... 50 | | | | | |
| Speed (backwards) | | | | | | | |
| Speed range I (field) | km/h | 0.02 ... 17 | | | | | |
| Speed range II (road) | km/h | 0.02 ... 33 | | | | | |
| Acceleration rate I (if the joystick is touched once at rated engine speed) | km/h | 0.02 ... 0.5 (adjustable) | | | | | |
| Acceleration rate II (if the joystick is touched once at rated engine speed) | km/h | 0.5 | | | | | |
| Acceleration rate III (if the joystick is touched once at rated engine speed) | km/h | 1.0 | | | | | |

Specifications apply to: 732/././... – 737/././...

| Torque values: diesel engine (DEUTZ TCD 6.1) | | |
|---|----|--|
| Cylinder head bolts: - Sealing surfaces (cylinder head/crankcase), oil-free. - Bolts oiled. - Tighten crosswise from interior to exterior. Note: Cylinder head bolts can be used a maximum of 3 times with written confirmation; otherwise replace each time they are loosened. | Nm | 1. stage 1: 40 (pre-load value) 2. stage 2: 70 (pre-load value) 3. stage 3: +90° (1st retightening angle) 4. stage 4: +90° (2nd retightening angle) |
| Cylinder head cover | Nm | 8.5 |
| Crankshaft main bearing cap | Nm | 1. stage 1: 50 (pre-load value) 2. stage 3: 90° (retightening angle) 3. stage 3: 90° (retightening angle) |
| Locknut (hexagon socket) to the valve adjustment screw | Nm | 20 |
| Valve cover to rocker arm housing | Nm | 9 |
| Rocker arm housing to cylinder head | Nm | 20 |
| Upper rocker arm shaft to rocker arm housing | Nm | 10 |
| Lower rocker arm shaft to rocker arm housing | Nm | 25 |
| Big-end bearing cap to connecting rod Screws oiled Note: Use new screws each time they are loosened. | Nm | 1. stage 1: 30 (pre-load value) 2. stage 3: 60° (retightening angle) 3. stage 3: 60° (retightening angle) |
| Lubricating oil sump to crankcase Note: Note the length of the screws. | Nm | 30 |
| Oil sump drain plug (replace copper washer) | Nm | 55 |
| Flywheel to crankshaft Note: Tighten the bolts in the specified sequence. Use new screws each time they are loosened. | | |
| M10x1 x85 | Nm | 1. stage 1: 30 (pre-load value) 2. stage 3: 60° (retightening angle) 3. stage 3: 60° (retightening angle) |
| M10x1 x80 | | |
| M10x1 x75 | | |
| M10x1 x70 | | |
| M10x1 x55 | | |
| M10x1 x50 | | |
| M10x1 x45 | | |
| M10x1 x40 | | |
| M10x1 x35 | | |

B - Faults

| | | |
|----|---|-----|
| 1 | Note on the fault code table | .55 |
| 2 | Confirming, calling up, deleting fault codes | .56 |
| 3 | Fault code 00.1.00 - | .57 |
| 4 | Fault code 01.1.00 - | .61 |
| 5 | Fault code 02.1.00 - | .65 |
| 6 | Fault code 03.1.00 - | .67 |
| 7 | Fault code 04.1.00 - | .69 |
| 8 | Fault code 05.1.00 - | .79 |
| 9 | Fault code 06.1.00 - | .83 |
| 10 | Fault code 07.1.00 - | .88 |
| 11 | Fault code 08.1.00 - | .90 |
| 12 | Fault code 09.1.00 - | .95 |
| 13 | Fault code 0A.1.00 - | .99 |
| 14 | Fault code 0B.1.00 - | 109 |
| 15 | Fault code 0D.1.00 - | 112 |
| 16 | Fault code 0E.1.00 - | 117 |
| 17 | Fault code 0F.1.00 - | 122 |
| 18 | Fault code 10.1.00 - | 127 |
| 19 | Fault code 11.1.00 - | 129 |
| 20 | Fault code 15.1.00 - | 130 |
| 21 | Fault code 18.1.00 - | 131 |
| 22 | Fault code 1D.1.00 - | 134 |
| 23 | Fault messages: manual air-conditioning system | 139 |
| 24 | Calibration fault codes | 141 |
| 25 | List of fault codes for Deutz TCD 4.1/6.1/7.8 engines | 149 |

| Fault code | DIN brief description | Cause | Consequences | Reference | FENDIAS/Note |
|------------|--------------------------------|---|-------------------------------------|-----------|--------------|
| 02.2.45 | A103 - Terminal NT01/02 | In the previous terminal 15 cycle, a different VarioGuide system was detected | | | |
| 02.2.46 | A103 - Terminal NT01/02 | The combination of terminal and VarioGuide is not permitted | Not possible to activate VarioGuide | | |

8 Fault code 05.1.00 -

| Fault code | DIN brief description | Cause | Consequences | Reference | FENDIAS/Note |
|------------|---|--|-------------------------------|--|-----------------|
| 05.1.00 | A050 - Basic control ECU | EEPROM fault in basic control ECU | | | |
| 05.1.31 | A100 - MFA, multifunction armrest 4WD 100% button | Faulty button, Signal fault | | | |
| 05.1.32 | A100 - MFA, multifunction armrest Auto 4WD button | Faulty button, Signal fault | | | |
| 05.1.33 | Y009 - 4WD solenoid valve | Actuation fault | 4WD engages | Circuit diagram Transmission control system | |
| 05.1.34 | B168 - Steering angle sensor | Sensor faulty, Signal fault | | Circuit diagram Suspension | |
| | | Faulty 8.5 V supply | A013, fuse 16 | | |
| 05.1.51 | A100 - MFA, multifunction armrest Differential lock 100% button | Faulty button, Signal fault | Other functions remain active | | |
| | | Faulty BUS | | | |
| 05.1.52 | A100 - MFA, multifunction armrest Differential lock auto system button | Faulty button, Signal fault | | | |
| 05.1.53 | Y010 - Differential lock solenoid valve | Actuation fault | Differential lock disengages | Circuit diagram Transmission control system | |
| 05.1.54 | S106 - Left brake switch | Faulty switch, Signal fault | TMS is switched off | Circuit diagram Trailer brake/brake | |
| 05.1.55 | S105 - Right brake switch | Faulty switch, Signal fault | TMS is switched off | Circuit diagram Trailer brake/brake | |
| 05.1.56 | A050 - Basic control ECU | Checksum error, 4WD/differential lock parameters | No auto mode possible | | EOL programming |
| 05.1.5C | B097 - Hydraulic parking brake pressure release sensor | Sensor faulty, Signal fault | | Circuit diagram Trailer brake/brake | |
| | | 12 V supply fault | A013, fuse 30 | | |

732 : 1001-
733 : 1001-
734 : 1001-
735 : 1001-
736 : 1001-

737 : 1001-

TT012065
Version 2
31-12-2012

| Fault code | DIN brief description | Cause | Consequences | Reference | FENDIAS/Note |
|------------|--|--|---|----------------------------|-----------------|
| 08.1.4A | Y062 - Rear field pressure control solenoid valve | Faulty valve | Valve moves to neutral and locks | Circuit diagram Hydraulics | |
| 08.1.4B | A100 - MFA, multifunction armrest Rear power lift auto button | Faulty button (output via TeachIn) | No auto mode | | |
| 08.1.4F | A100 - MFA, multifunction armrest | Switch actuation/timeout time | | | |
| 08.1.A2 | Y184 - Rear power lift control valve | EEPROM is faulty (Valve) | Valve moves to neutral and locks | | EOL programming |
| 08.1.A3 | Y184 - Rear power lift control valve | RAM_Test | Valve moves to neutral and locks Pilot pressure OFF | | |
| 08.1.A4 | Y184 - Rear power lift control valve | Flash_Test | Valve moves to neutral and locks Pilot pressure OFF | | |
| 08.1.A5 | Y184 - Rear power lift control valve | Incorrect valve code (SA/DA) for selecting EOL | Valve moves to neutral and locks | | EOL programming |
| 08.1.B0 | B145 - Rear power lift position sensor | Position sensor not calibrated | No control possible, operable only via external button | Calibration code "8002" | |
| 08.1.B2 | A100 - MFA, multifunction armrest Rear power lift setpoint value potentiometer | Setpoint value potentiometer not calibrated | Setpoint values cannot be set, only position control possible | Calibration code "8001" | |
| 08.1.B3 | X015 - External control socket | External sensor not calibrated | Default values are used | | |
| 08.1.C0 | A100 - MFA, multifunction armrest | MFA not fitted | No auto mode possible, operable only via external button | | |
| 08.1.C1 | A103 - Terminal NT01/02 | Terminal not fitted | Configuration cannot be changed | | |
| 08.1.CE | Y184 - Rear power lift control valve | Visual temperature limit warning | | | |
| 08.1.CF | Y184 - Rear power lift control valve | Visual temperature limit warning | | | |

| Fault code | DIN brief description | Cause | Consequences | Reference | FENDIAS/Note |
|------------|---|--|--|---|--------------|
| 0A.1.D5 | S022 - External front power lift lower button | Faulty button, Signal fault | Button inoperable until next trouble-free cold start | Circuit diagram Hydraulics | |
| 0A.1.D6 | S021 - External front power lift raise button | Faulty button, Signal fault | Button inoperable until next trouble-free cold start | Circuit diagram Hydraulics | |
| 0A.1.D7 | B084 - Hydraulic oil level sensor | Sensor faulty, Signal fault | Fill level is no longer monitored | Circuit diagram Instrument panel/ABS/operator's seat | |
| 0A.1.D8 | B084 - Hydraulic oil level sensor | Warning, hydraulic oil tank | Warning display only | | |
| 0A.1.D9 | B084 - Hydraulic oil level sensor | Hydraulic oil tank empty | Valves are locked and pilot control is switched off | Circuit diagram Instrument panel/ABS/operator's seat | |
| 0A.1.DA | B013 - Hydraulic oil temperature sensor | Warning, hydraulic oil temperature too high | Warning display only (without storing) | | |
| 0A.1.DB | B013 - Hydraulic oil temperature sensor | Hydraulic oil temperature too high | Is stored | Circuit diagram Instrument panel/ABS/operator's seat | |
| 0A.1.DC | B013 - Hydraulic oil temperature sensor | Warning, hydraulic oil temperature not plausible | Warning display only | | |
| 0A.1.DD | S119 - Hydraulic oil filter contamination switch | Filter clogged | Warning display only | | |
| 0A.1.DE | S119 - Hydraulic oil filter contamination switch | Faulty switch, Signal fault | Warning display only | | |

732 : 1001-
733 : 1001-
734 : 1001-
735 : 1001-
736 : 1001-

737 : 1001-

TO12074
Version 3
31-12-2012

118

T012077
Version 4
31-12-2012732 .. 1001-
733 .. 1001-
734 .. 1001-
735 .. 1001-
736 .. 1001-

737 .. 1001-

| Fault code | DIN brief description | Cause | Consequences | Reference | FENDIAS/Note |
|---|---|--|--|-----------|--------------------|
| 0E.1.A3 | A101 - VarioDoc ECU U004 - GNSS aerial | PPS signal not available, Short circuit or break in the wiring | No GPS position, System cannot be operated | | |
| 0E.1.A4 | A101 - VarioDoc ECU U004 - GNSS aerial | IMU sensor has an internal fault, cannot respond | No GPS position, System cannot be operated | | |
| 0E.1.A5 | A101 - VarioDoc ECU U004 - GNSS aerial | Vehicle type not recognised | System cannot be operated | | |
| 0E.1.A6 | A101 - VarioDoc ECU U004 - GNSS aerial | Internal temperature of control unit above 80°C | | | |
| 0E.1.A7 | A101 - VarioDoc ECU U004 - GNSS aerial | Input voltage over 20 V | | | |
| 0E.1.A8 | A101 - VarioDoc ECU U004 - GNSS aerial | Current input above 1 amp, possible internal short circuit | | | |
| 0E.1.A9 | A101 - VarioDoc ECU U004 - GNSS aerial | Short circuit in GPS receiver power supply | | | |
| 0E.1.AA | A101 - VarioDoc ECU U004 - GNSS aerial | Incorrect GPS receiver | | | |
| 0E.1.AB | A101 - VarioDoc ECU U004 - GNSS aerial | K bus CAN buffer (CAN 1) full | | | |
| 0E.1.AC | A101 - VarioDoc ECU U004 - GNSS aerial | ISO bus CAN buffer (CAN 4) full | | | |
| 0E.1.AD | A101 - VarioDoc ECU U004 - GNSS aerial | Tractor serial number in EEPROM is incorrect | | | EOL programming |
| Note: The following fault codes are displayed on the A103 - Terminal NT01/02 | | | | | |
| 0E.1.06 | A102 - VarioGuide GNSS ECU | Switch off the automatic steering | | | |
| 0E.2.40 | A102 - VarioGuide GNSS ECU | The maximum contour line is too long | | | |
| 0E.2.41 | A102 - VarioGuide GNSS ECU | The current wayline exceeds the maximum bend radius. | | | |

21 Fault code 18.1.00 -

| Fault code | DIN brief description | Cause | Consequences | Reference | FENDIAS/Note |
|------------|---|--|--|--|--------------|
| 18.1.01 | A100 - MFA, multifunction armrest VarioGuide partial activation button | Partial activation button in MFA faulty, Signal fault | | | |
| 18.1.02 | A100 - MFA, multifunction armrest VarioGuide full activation button | Full activation button in MFA faulty, Signal fault | | | |
| 18.1.03 | A100 - MFA, multifunction armrest | MFA fails to report | | | |
| 18.1.06 | S053 - Seat contact switch | Seat switch faulty, Signal fault | Seat switch diagnostics (fault code is output by the "EHL" function) | | |
| 18.1.07 | Y099 - VarioGuide pilot pressure switch-off solenoid valve | Solenoid valve faulty, Signal fault | | Circuit diagram Suspension/VarioGuide | |
| 18.1.08 | Y099 - VarioGuide pilot pressure switch-off solenoid valve | Solenoid valve faulty, Signal fault | | Circuit diagram Suspension/VarioGuide | |
| 18.1.1A | B168 - Steering angle sensor | Steering angle sensor faulty, Signal fault | | | |
| 18.1.1C | B168 - Steering angle sensor | Invalid calibration values for steering angle sensor in EEPROM | | Calibration code "2401" Calibration code "2403" | |
| 18.1.2A | B081 - 360° steering wheel sensor | Steering wheel sensor faulty, Signal value faulty | | | |
| | | 12 V supply | A013, fuse 29 | | |
| 18.1.2C | B081 - 360° steering wheel sensor | Invalid calibration values for steering wheel sensor in EEPROM | | Calibration code "2401" Calibration code "2403" | |

732, 1001-
733, 1001-
734, 1001-
735, 1001-
736, 1001-

737, 1001-

Version 2
31-12-2012

Fault code for calibration code 4003

| Fault code | Cause | DIN short description |
|------------|--|---------------------------------|
| F01 | User terminated calibration with "ESC" | A050 - Basic control ECU |
| F02 | Speed above 0,1 Km/h | |
| F03 | Engine speed below 600 rpm | |
| F04 | Engine speed above 900 rpm | |
| F05 | Transmission not in neutral | |
| F06 | Clutch not depressed | |
| F07 | - B015 - Bevel pinion sensor faulty | |
| F08 | - B014 - Collecting shaft sensor faulty | |
| F09 | - B010 - Engine speed sensor faulty | |
| F10 | Neutral switch, joystick faulty (A100 - MFA, multi-function armrest) | |
| F11 | - B016 - Travel speed range detection sensor faulty | |
| F12 | - Y002 - Travel speed range 1 — solenoid valve faulty | |
| F13 | - Y003 - Travel speed range 2 — solenoid valve faulty | |
| F20 | Calibrated values for neutral position incorrect | |
| F21 | Calibrated values for travel speed range I incorrect | |
| F22 | Calibrated values for travel range II incorrect | |
| F23 | Calibrated values do not match | |
| F30 | Error reading from EEPROM (A050 - Basic control ECU) | |
| F31 | Error while writing to EEPROM (A050 - Basic control ECU) | |

Fault code for calibration code 4005

| Fault code | Cause | DIN short description |
|------------|--|---|
| F21 | Transmission in "ACTIVE STANDSTILL". (Remedy: Put transmission into neutral) | A050 - Basic control ECU B055 - Foot throttle sensor |
| F22 | Signal smaller than 3 mA _{DC} | |
| F23 | Signal greater than 21 mA _{DC} | |
| F24 | Rotation angle of B055 - Foot throttle sensor is too great (more than 250 steps) | |
| F25 | Distance between idle and full throttle too short (less than 12 mA _{DC}) or B055 - Foot throttle sensor incorrectly calibrated | |
| F26 | Distance between idle and full throttle too short (less than 70%) or B055 - Foot throttle sensor incorrectly calibrated | |
| F27 | Time for a calibration increment exceeded (longer than 60 seconds) | |
| F28 | Internal error in the A050 - Basic control ECU Error while saving calibrated values to EEPROM (EOL reprogramming may be necessary) | |
| F30 | User interrupted with ESC | |

| Deutz KWP code | Bosch SPN/FMI code | FENDT Fault code | FENDT — component | Fault description |
|----------------|--------------------|------------------|-------------------|---|
| 472 | 94/3 | 1D.1.02 | B087 sensor | Fuel system Fuel low pressure "primary pressure" Sensor signal has exceeded upper limit |
| 473 | 94/4 | 1D.1.02 | B087 sensor | Fuel system Fuel low pressure "primary pressure" Sensor signal has underrun lower limit |
| 474 | 94/1 | 1D.1.02 | B087 sensor | Fuel system Power low pressure "pilot pressure" has exceeded the limit Warning message output |
| 475 | 94/1 | - | - | Fuel system Power low pressure "pilot pressure" has exceeded the limit Engine switches off |
| 481 | 174/0 | - | - | Fuel system Fuel temperature has exceeded the limit Warning message output |
| 482 | 174/0 | - | - | Fuel system Fuel temperature has exceeded the limit Engine switches off |
| 488 | 523619 / 2 | - | B105 sensor | SCR catalytic converter (AdBlue) Excess temperature in SCR catalytic converter Exhaust gas temperature of above 570°C |
| 500 | 523915 / 0 | - | - | Diesel particulate filter (DPF) HCl flow valve (DV1); Overcurrent at the end of the injection phase |
| 501 | 523915 / 12 | - | - | Diesel particulate filter (DPF) HCl flow valve (DV1); Excess temperature at power level |
| 502 | 523915/3 | - | - | Diesel particulate filter (DPF) Power level at HCl flow valve (DV1) Short circuit to battery+ |
| 503 505 | 523915/11 | - | - | Diesel particulate filter (DPF) Power level (plus side) at HCl flow valve (DV1) Short circuit to battery+ |
| 504 | 523915/4 | - | - | Diesel particulate filter (DPF) Power level at HCl flow valve (DV1) Earth connection |
| 506 | 523916/2 | - | - | Diesel particulate filter (DPF) Pressure sensor Pressure downstream of HCl flow valve (DV1) implausible |
| 508 | 523916/0 | - | - | Diesel particulate filter (DPF) Pressure sensor Pressure downstream of HCl flow valve is too high (above the limit) |
| 511 | 523916/1 | - | - | Diesel particulate filter (DPF) Pressure sensor Pressure downstream of HCl flow valve is too low (below the limit) |


| Deutz KWP code | Bosch SPN/FMI code | FENDT Fault code | FENDT — component | Fault description |
|----------------|--------------------|------------------|--|---|
| 974 | 523612/14 | 1D.1.1B | ECU A099/A127 | Engine control unit CPU software reset SWReset_1 |
| 975 | 523612/14 | 1D.1.1B | ECU A099/A127 | Engine control unit CPU software reset SWReset_2 |
| 976 | 91/11 | 1D.1.06 | B055 sensor | Speed control Foot throttle sensor APP1 signal and APP2 signal implausible or APP1 signal and low fuel switch signal implausible |
| 980 | 523550/12 | 1D.1.1C | S002 ignition switch ECU A099/A127 | Starter Ignition switch (start) Terminal 50 active for too long |
| 981 | 172/3 | 1D.1.27 | B138 sensor | Charge air system Temperature sensor downstream of air filter Sensor fault Signal has exceeded upper limit |
| 982 | 172/4 | 1D.1.27 | B138 sensor | Charge air system Temperature sensor downstream of air filter Sensor fault Signal is below the lower limit |
| 984 | 523921/11 | - | - | Diesel particulate filter (DPF) Temperature sensor in combustion space Temperature in combustion space implausible |
| 986 | 523921/0 | - | - | Diesel particulate filter (DPF) Temperature sensor in combustion space Temperature in combustion space has exceeded upper limit (too high) |
| 989 | 523921/1 | - | - | Diesel particulate filter (DPF) Temperature sensor in combustion space Temperature in combustion space has underrun lower limit (too low) |
| 994 | 105/3 | 1D.1.03 | B092 sensor | Charge air system Charge air temperature sensor Sensor fault Signal has exceeded upper limit |
| 995 | 105/4 | 1D.1.03 | B092 sensor | Charge air system Charge air temperature sensor Sensor fault Signal is below the lower limit |
| 996 | 105/0 | - | B092 sensor | Charge air system Charge air temperature sensor Charge air temperature has exceeded upper limit Warning message output |
| 997 | 105/0 | - | - | Charge air system Charge air temperature sensor Charge air temperature has exceeded upper limit Engine switches off |

| Deutz KWP code | Bosch SPN/FMI code | FENDT Fault code | FENDT — component | Fault description |
|----------------|--------------------|------------------|-------------------|---|
| 1412 | 1186 / 11 | 1D.1.30 | A124 | Exhaust system Wastegate actuator; EOL calibration not carried out correctly |
| 1413 | 1186 / 13 | 1D.1.30 | A124 | Exhaust system Wastegate actuator; deviation from calibration value too great, recalibration required |
| 1414 | 1186 / 2 | 1D.1.30 | A124 | Exhaust system Wastegate; no status message from control unit |
| 1415 | 1186 / 7 | 1D.1.30 | A124 | Exhaust system Wastegate actuator; blocked |
| 1416 | 1186 / 11 | 1D.1.30 | A124 | Exhaust system Wastegate actuator; excess temperature (> 145°C) |
| 1417 | 1186 / 11 | 1D.1.30 | A124 | Exhaust system Wastegate actuator; excess temperature (> 135°C) |
| 1418 | 1186 / 11 | 1D.1.30 | A124 | Exhaust system Wastegate actuator; operating voltage fault |
| 1431 | 524028 / 2 | - | - | CAN BUS system CAN message PROEGRActr implausible |
| 1432 | 524029 / 2 | - | - | CAN BUS system Timeout during receipt of CAN message ComE-GRActr — exhaust-gas recirculation control system |
| 1436 | 524034 / 5 | - | - | Exhaust system Disc separator; cable break |
| 1437 | 524034 / 12 | - | - | Exhaust system Disc separator; excess temperature at power level |
| 1438 | 524034 / 3 | - | - | Exhaust system Disc separator; battery short circuit |
| 1439 | 524034 / 4 | - | - | Exhaust system Disc separator; earth short circuit |
| 1448 | 175/0 | - | - | Engine oil system Temperature of oil supplied by customer too high; warning threshold reached |
| 1449 | 175/0 | - | - | Engine oil system Temperature of oil supplied by customer too high; shut-off threshold reached |
| 1458 | 523960 / 0 | - | - | Exhaust system EGR exhaust temperature too high; warning threshold reached |
| 1459 | 523960 / 1 | - | - | Exhaust system EGR exhaust temperature too high; shut-off threshold reached |
| 1460 | 1180 / 0 | 1D.1.29 | B140 sensor | Exhaust system Exhaust temperature upstream of turbine; warning threshold reached |
| 1461 | 1180 / 1 | 1D.1.29 | B140 sensor | Exhaust system Exhaust temperature upstream of turbine; shut-off threshold reached |
| 1462 | 1180 / 0 | 1D.1.29 | B140 sensor | Exhaust system Exhaust temperature upstream of turbine; warning threshold reached |

B008 - High-pressure Sensor 1



Right side of transmission, on transmission hydraulic system valve block



Remove right rear wheel and panel





Fig. 26.

I028120

B009 - Discharge temperature sensor



Right side of transmission on high-pressure filter



Remove right rear wheel and panel




Fig. 27.

I028572

B013 - Hydraulic oil temperature sensor



Right side of tractor, on the hydraulic oil tank interior





Fig. 28.

I027987

B014 - Collecting shaft sensor



Right side of transmission, below transmission hydraulic system valve block



Remove right rear wheel and panel




Fig. 29.

I028121

E158 - Right LED cab lighting



Fig. 78.

1028856

E171 - Licence plate LED lighting




Fig. 79.

1028015

E172 - Left LED cab lighting



Fig. 80.

1028857

E173 - Entry LED lighting



Fig. 81.

1028870

9 Electrical/electronic components - S

S002 - Ignition switch



In cab, steering column right.



Fig. 124.

I028031

S015 - Parking brake switch



Right rear axle




Fig. 125.

I029285

S017 - Filter contamination switch



Right side of transmission, on transmission oil filter



Remove right rear wheel and panel




Fig. 126.

I028607

S019 - Left-hand external rear PTO button



Rear of tractor, on left mudguard



Fig. 127.

I028032

X1586 - V-BUS cable coupling (VarioGuide)
X1587 - cable coupling for Y087



Under the cab, next to the steering unit





Fig. 172.

1038397

X1590 - Separation point on S079
X1591 - Separation point on S079



Cab, right side of steering column on the ignition switch



Detach panel




Fig. 173.

1028894

X1611 - Separation point on X400 PCB, ISO (bus terminal)
X1612 - Separation point on X400 PCB, ISO (bus terminal)



Rear of tractor






Fig. 174.

1028693

X1616 - Separation point on X1806
X1617 - Separation point on X1806
X1618 - Separation point on X1806



Right side of tractor, behind the hydraulic oil tank



Detach panel





Fig. 175.

1028694

X4107 - UB 30 connector



Cab, bottom of left mudguard



Detach panel




Fig. 224.


1029625

X4108 - UB 15 connector

X4109 - UB 30 EDC connector



Cab, right side on the cab floor



Detach panel




Fig. 225.

1030073

X4111 - EXT earth connector



Cab, bottom of left mudguard



Detach panel




Fig. 226.

1029625


X4112 - Sensor system earth connector

X4113 - Sensor system earth connector

X4114 - Sensor system earth connector



Cab, right side on the cab floor



Detach panel




Fig. 227.

1030073

X4238 - Interior lighting connector
X4239 - UB 30D connector



Cab, top right in roof lining



Remove connection panel





Fig. 276.

1030094

X4240 - Sensor system earth connector
X4241 - Sensor system earth connector



Left side of transmission



Detach left rear wheel and panel




Fig. 277.

1029855

X4243 - UB 15 connector



Cab, top right in roof lining




ECU, remove air conditioning control




Fig. 278.

1029647

X4244 - Connector 58



Left side of transmission



Detach left rear wheel and panel





Fig. 279.

1029855

Y120 - AdBlue flow valve



Right side of engine, in the exhaust pipe



Open bonnet.





Fig. 328.

I027941

Y122 - Transmission cooler bypass solenoid valve



Right side of transmission, on the valve block (inlet or outlet)



Remove right rear wheel and panel





Fig. 329.

I029406

Y169 - AdBlue tank heater solenoid valve



Left side of tractor, on frame



Detach cover panel



Fig. 330.

I028129

Y170 - Engine brake solenoid valve



Bulkhead between engine and cab

NOTE: Photographed without the cab for clarity.





Fig. 331.

I028124

MVV2 [Y060] - Side pre-heating solenoid valve



Right side of tractor, in the Power Beyond end plate



Detach panel





Fig. 380.

1029681

OETR - Oil temperature regulator



Right side of transmission, in the connector plate of the heat exchanger





Fig. 381.

1030173

PEX - External pressure supply (Power Beyond)



Rear of tractor





Fig. 382.

1029519

PH - Auxiliary pump

PNL - Emergency steering pump

PR - LS pump



Centre of tractor, fitted on the transmission housing




Fig. 383.

1029834



Rear PTO calibration, Display (A)



Select factory setting for auto mode switch-on point, Display (B) (see also: Operating Manual)



Change auto mode switch-on point, Display (C) (see also: Operating Manual)

4 Calibration code 1001 (crossgate lever)

3. Calibrating the crossgate lever (1001)

Important: The following preparatory steps must be carried out.

- Hand brake applied
- Ignition ON
- If fault messages are displayed, the faults must be confirmed one by one.

IMPORTANT: Refer to KDM 18/2012!



Press "ESC" to confirm the warning and fault messages displayed on the A007 instrument panel




Fig. 49.

1029265



Press "Return" and the first main menu appears in the multiple display



Press one of the buttons repeatedly until the symbol (A) flashes



Press "Return", the second main menu appears in the multiple display




Fig. 50.

1029138

The second main menu appears in the multiple display



Press one of the buttons repeatedly until the symbol (A) flashes



Press "Return" to confirm




Fig. 51.

EK108149
1000935

7 Calibration code 2401 (steering angle sensor)

9. Calibrating the steering angle sensor (2401)

NOTE: Calibration only possible on tractors with VarioGuide

Important: The following preparatory steps must be carried out.

- Engine is running
- If fault messages are displayed, the faults must be confirmed one by one.



Press "ESC" to confirm the warning and fault messages displayed on the A007 instrument panel





Fig. 89.


I029265



Press "Return" and the first main menu appears in the multiple display



Press one of the buttons repeatedly until the symbol (A) flashes



Press "Return", the second main menu appears in the multiple display




Fig. 90.

I029138

The second main menu appears in the multiple display



Press one of the buttons repeatedly until the symbol (A) flashes



Press "Return" to confirm





Fig. 91.

EK108167
I000980

The transmission menu appears in the multiple display



Press one of the buttons repeatedly until the symbol (A) flashes



Press "Return" to confirm




Fig. 127.

1029542

Input code **4001**



Press one of the buttons until desired number is displayed



Press "Return" to confirm




Fig. 128.

EKI07829

1000773

Clutch pedal **not** depressed

Press "Return" to confirm



Fig. 129.

EKI07842

1000990

Clutch pedal depressed

Press "Return" to confirm





Fig. 130.

EKI07843

1000991

Input code **4007**



Press one of the buttons until desired number is displayed



Press "Return" to confirm





Fig. 168.

EKI07829
I000773

Step1 (test step 1) to ...




Fig. 169.

I000555

... Step 7 (test step 7) is carried out automatically



Fig. 170.

I000556

If calibration completes successfully, the image is displayed and the new sensor values are saved

Press "ESC" to confirm




Fig. 171.

I000558

The transmission menu appears in the multiple display



Press one of the buttons repeatedly until the symbol (A) flashes



Press the "Enter" key, the following screen is displayed.




Fig. 202.

BETR1777
 1002923

The first digit for the track information flashes.
 The measured track length for the track information must now be entered.
 E.g. 100 m



Repeatedly press one of the keys repeatedly until the desired figure shows. E.g. 1



Press "Enter" to confirm. Enter the remaining two positions in the same manner.



Fig. 203.

BETR2248
 1002924

After confirming the last digit, "START" will flash.



Press the key, the display changes from "START" to "STOP".

Drive off with the tractor and stop with the front wheel on the end marker of the measured distance (stop with clutch).



Press "Enter" to confirm.




Fig. 204.

BETR2249
 1002925

If incorrect values are detected or the conditions are not met, an **ERROR** message appears

If the calibration has run correctly the message **OK** is displayed and the new tyre circumference and the radar impulses are saved.



Using the "ESC" key, work back until Time and Operating Hours are displayed




Fig. 205.

EKI09015
 1003578

3 Transmission control system functional sequence

Transmission type ML 180

M – Marschall, designer of this development

L – Power distribution, mechanical and hydrostatic power transmission

180 – Vario transmission size

The ML 180 transmission

The ML 180 is a continuously variable transmission for forwards and reverse travel.

Power transmission can be hydrostatic or mechanical, or hydrostatic and mechanical.

Basically this means:

Slow forward travel = high hydrostatic transmission power/low mechanical transmission power

Fast forward travel = low hydrostatic transmission power/high mechanical transmission power

For a detailed explanation, see transmission function plan

Hydrostatic power distribution

The ML transmission unit is flexibly mounted in the transmission housing. The transmission housing is also the oil reservoir for the hydrostatic drive.

Oil fill: Fendt Extra Trans 10W-40 or STOU oil, viscosity SAE 10W-40 or 15W-40

Initial fill: approx. 58 litres

Refill: approx. 47 litres, e.g. at oil change

Functional sequence, see transmission hydraulic circuit diagram

The servo pump draws in oil through the suction filter.

The temperature sensor (B009) monitors the temperature of the transmission oil.

Flow through the oil cooler is temperature-dependent.

This means that if the transmission oil is cold, little oil flows through the oil cooler, while most flows through the bypass valve. The bypass valve opens when the pressure differential exceeds approx. 3.5 bar. The transmission oil temperature is monitored by the temperature sensor.

The servo pump generates the system pressure for the ML control valves and enhanced control valves. The system pressure of approx. 18 bar is restricted by the pressure relief valve and restrictor orifice.

The system uses two different pressures.

1. System pressure for the ML transmission control system and the comfort pressure for the rear PTO clutch, rear PTO shaft control, differential lock and 4WD switchover approx. 18 bar
2. High pressure in the ML transmission, maximum 550 bar + 15 bar

Pressure filter contamination is monitored by a pressure switch (S017) as a function of the transmission oil temperature. Filter contamination is not monitored if the transmission oil temperature is below 50°.

Two non-return valves (2V1 and 2V2) alternately feed cooled transmission oil into the high-pressure circuit.

Hot transmission oil is discharged from the high-pressure circuit via the flushing valve (2V5).

The high-pressure circuit incorporates: a variable-displacement pump (2P1) and a variable-displacement motor (2A1), two non-return valves (2V1 and 2V2), two servo-assisted high-pressure limiting valves (2V3 and 2V4), a flushing valve (2V5), a clutch/turbo-clutch pressure relief valve (4V4), a high-pressure safety valve (4V7) and a test connection (PH).

The servo cylinders (3A1 and 3A2) on the variable-displacement pump and motor are actuated by two 4/3-directional control valves (3V1 and 3V2).

The 4/3 directional control valves are mechanically actuated by the actuator shaft (3Z1).

The actuator shaft (3Z1) is rotated as required by the actuator unit (A009), thereby setting the correct quantity of oil to be supplied or consumed.

The variable-displacement pump (2P1) and variable-displacement motor (2A1) swivel accordingly.

In the emergency mode switch position, the actuator shaft (3Z1) is actuated manually from the cab.

In the emergency mode switch position, the transmission is automatically locked at approx. 30 km/h after the engine has been started.

If the clutch pedal, hand brake or neutral switch is operated, the high-pressure circuit is depressurised by the two high-pressure limiting valves (2V3 and 2V4).

The clutch and turbo-clutch function is controlled by the pressure relief valve (4V4).

Important note on filling the ML 180 transmission with oil:

During normal maintenance work, e.g. for a transmission oil change, the transmission oil should be added as in a normal mechanical gear transmission.

If there is no oil in the high-pressure circuit, the transmission must be filled from an external pressurised filling unit.

During filling, the transmission oil is additionally filtered through connection PU (measuring point M5).

6 Pressure measuring points on transmission and control hydraulics




Fig. 47. Pressure measuring points on the transmission hydraulics

1029484

Tightening torque for mini measuring connection/plug

| Test point | Tightening torque |
|------------|-------------------|
| M1 - M6 | 7 Nm + 2 Nm |
| M7 - M9 | 10 Nm + 3 Nm |
| M10 - M16 | 12 Nm |
| M22 - M24 | 10 Nm + 3 Nm |

- M10** System pressure, rear axle
- M11** Rear PTO clutch pressure (V)





Fig. 48.

1029506




Pry off the circlip



Fig. 5.

1036147




Remove shims



Fig. 6.

1036149



Remove upper banjo bolt





Fig. 7.

1036150



Remove lower banjo bolt





Fig. 8.

1036151



2. Fit lubrication oil line and tighten banjo bolts




Fig. 51.

I037247



The following subsequent work must be carried out

- Install the ML vario insert [see 1080, §2, page 156](#)
- Fit rear wheel brake [see 1070, §3, page 114](#)
- Fit drive axle [see 1015, §3, page 92](#)
- Fill with oil

7 Install differential and set backlash

IMPORTANT: The pinion shaft and crown wheel must be fitted in pairs!





Fig. 90.

1034192

- | | | | |
|----|--------------------------|----|-------------------------|
| 1 | Bearing flange | 20 | Lip seal |
| 2 | Hex bolt | 21 | Axle bevel gear |
| 3 | O-ring | 22 | Cross bearing |
| 4 | Circlip | 23 | Axle |
| 5 | Shim pack | 24 | Axle |
| 6 | Ring | 25 | Roll pin |
| 7 | Taper roller bearing | 26 | Roll pin |
| 10 | Housing flange | 27 | Cylinder roller ring |
| 11 | Rectangular-section ring | 28 | Pinion gear |
| 12 | Hex bolt | 29 | Thrust ring |
| 13 | Spring washer | 32 | Internally toothed disc |
| 15 | Ring | 33 | Externally toothed disc |
| 16 | Dowel pin | 34 | Axle bevel gear |
| 18 | Piston | 36 | Housing |
| 19 | Lip seal | | |

⚠ DANGER:
Falling loads can cause injury!
Do not walk or stand under suspended loads!



Fit suspension cylinder bolt and tighten
 Tightening torque: 85 Nm





Fig. 41.

1032666



Install compressed air block and install all compressed air hoses and electrical plugs





Fig. 42.

1032667



Install and tighten nuts





Fig. 43.

1032668



Mount compressed air line on the bulkhead union




Fig. 44.

1032669





Fig. 2. Adjust the piston rod play (0,5 mm)

I033493



Mount sheet metal bracket



Fig. 41.

1032815

Characteristic curve of the relay valve





Fig. 66. Characteristic curve of the relay valve, pressure measurement at PE and PA

1035477

PA (M17) Pressure to cardan brake
 PE Pressure from booster



Remove the screws on the transmission housing cover





Fig. 40.

1032747



Remove transmission housing cover





Fig. 41.

1032750



Unplug all electrical connectors on the transmission valve block and the feed valve block





Fig. 42.

1032807

NOTE: The following steps were carried out on a model for greater clarity!




Remove hexagon socket head screws from the actuator unit



Fig. 43.

1032759



Install feed valve block with new gas-
ket





Fig. 89.

I033025




Tighten the securing bolts
Tightening torque: **25 Nm**



Fig. 90.

I033026



Install and tighten both lines





Fig. 91.

I032767



Install bracket and clamp





Fig. 92.

I032769



Install retaining screws of the distribution box





Fig. 141.

1032708



Mount all cable fixings





Fig. 142.

1032711



Mount cable clip.





Fig. 143.

1032707

IMPORTANT: After the transmission has been installed, it must be filled using the external filling station!
Unscrew the cap screw labelled PU
Connect external oil filling unit and fill the transmission externally
Observe instructions for oil type and quantity



Fit piston (14) and valve spool (26)





Fig. 16.

I033892




Insert valve spool (26) into the piston (14)



Fig. 17.

I033893



Fit the Belleville spring pack (18)
NOTE: Insert the first Belleville spring with the convex end facing upwards.





Fig. 18.

I033894



Fit locating ring (19)



Fig. 19.

I033895

1 Technical drawing of rear PTO





Fig. 1. Engine PTO 737.150.220.000

1030788




Insert a new lip seal (27) into piston groove (25) and grease it. The sealing lips must face towards the oil pressure chamber



Fig. 43.

I034640



Slide the piston (25) onto the shaft





Fig. 44.

I034641



Insert two rectangular-section rings (31) into grooves on the spur gear shaft (7) so that they are offset relative to each other, then secure and grease them.





Fig. 45.

I034656



Fit the pre-assembled flange into the rear axle cover





Fig. 46.

I034643



Remove special tool and take out shims





Fig. 91.

1034705



Remove set of spur gear shafts





Fig. 92.

1034706




Remove bearing inner ring



Fig. 93.

1034707



Take taper roller bearing off shaft II




Fig. 94.

1034769

- | | |
|-------------------------|-------------------------|
| 15 Needle bearing | 25 Locating ring |
| 16 Spur gear | 26 Shim pack |
| 17 Circlip | 27 Taper roller bearing |
| 18 Thrust ring | 28 Bush |
| 19 Taper roller bearing | 29 Shim pack |
| 20 Shim pack | 31 Spur gear |
| 22 Bush | 32 Spur gear |
| 23 Spur gear | 33 Circlip |
| 24 Circlip | 34 Taper roller bearing |

⚠ DANGER:
Risk of burns!
Wear protective gloves




Heat taper roller bearing (19) to approx. 90°C and mount on shaft (5)



Fig. 137.

I034785




Mount the thrust ring (18)



Fig. 138.

I034788



Snap on circlip (17)




Fig. 139.

I034782

1 Front-wheel drive clutch




Fig. 1.

1031530

Apply the sealant Stucarit 203 = X903.050.864.000 to the cover sealing surface.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

2000 - Engine

| | | |
|------|--------------------------|-----|
| 2000 | Engine | 5 |
| 2010 | Cylinder head | 73 |
| 2050 | Cooling system | 87 |
| 2060 | Fuel system | 93 |
| 2400 | Exhaust gas system | 131 |

| KWP | DTC Code | DTC Beschreibung | Häufigkeit |
|------|-----------------------------------|---|------------|
| 1090 | UHtrBLOL [SPN=4345/FMI=5] | | 1 |
| 1094 | UHtrPLOL [SPN=4343/FMI=5] | | 1 |
| 101 | ClntLvSysReac [SPN=111/FMI=1] | Kühlmittelstand zu niedrig | 22 |
| 1089 | UHCenfShOffWEmp [SPN=4243/FMI=11] | Heizvorgang nicht erfolgreich | 1 |
| 1118 | UPmpMotOL [SPN=4375/FMI=5] | Kabelbruch Leistungsstufe Pumpenmotor | 1 |
| 306 | ComTSC1TRTO [SPN=520/FMI=9] | Timeout der Empfangsbotschaft TSC1TR | 1 |
| 171 | ComEngPrtTO [SPN=523212/FMI=9] | Timeout der Empfangsbotschaft ComEngPrt | 1 |
| 305 | ComTSC1TETO [SPN=898/FMI=9] | Timeout Fehler der CAN-Empfangsbotschaft TSC1TE | 1 |
| 126 | ComAMBTO | | 1 |
| 198 | ComPrHEncmdTO [SPN=523216/FMI=9] | | 1 |

Fig. 17. Update fault memory

EK112899
I032580

| KWP | DTC Code | DTC Beschreibung | Häufigkeit |
|-----|----------|------------------|------------|
|-----|----------|------------------|------------|

Fig. 18. Call up fault memory 2 (not deletable)

EK112900
I032581

Fully depress foot throttle (B055 foot throttle sensor), accelerate the tractor using the joystick (A039 multi-function armrest) until the engine speed reaches approx. 1800..1900 rpm. (Diesel engine running a maximum power)

Calculation example:

- Tractor power = 155 HP (max. engine power)
- Tractor operating under full load

Approx. fuel consumption per running hour = 2 l x (155/10) HP x 1 Rhr

Fuel consumption per operating hour = approx. 31 l

Operating the diesel engine for optimum fuel consumption (l/Rhr)

Opt. = Economical operating level of the diesel engine

In the partial-load operating range = 2/3 of full load operating ("driving with reduced engine speed")



Fig. 21. EK103159
1003106

Driving in the partial-load operating range of the diesel engine

Using the foot throttle (B055 foot throttle sensor), set the engine speed to approx. 2000 rpm and accelerate the tractor using the A034 joystick until the engine speed reaches approx. 1800..1900 rpm. (The diesel engine is running in the partial-load operating range)

Measuring fuel consumption with the A008 terminal (approx. value)

Press (F4)




Fig. 22. BETR2180
1004788

The sub-menu is displayed.

Press (F4)




Fig. 23. BETR1481
1004789




Fig. 37. Applies to chassis numbers: 737/./...

1037274

HZ Engine speed [U/min]
 W Rear PTO speed (level 1000) [U/min]
 KV Fuel consumption [l/h]
 n Engine speed [U/min]
 ZWL PTO power [kW]

| | | | |
|-------------|--|-------------|---|
| A007 | Instrument panel | K065 | Starter relay |
| A050 | Basic control ECU | K083 | AdBlue relay |
| A082 | Nitrogen oxide NOx sensor 1, upstream of SCR | K090 | AdBlue module relay heater |
| A083 | Nitrogen oxide NOx sensor 2, downstream of SCR | K091 | AdBlue suction and return line heater relay |
| A084 | AdBlue module | K092 | AdBlue pressure line heater relay |
| A124 | Wastegate ECU | R002 | Heater flange |
| A127 | Engine control ECU (EDC 17) | R006 | Engine BUS terminating resistance |
| B004 | Air filter vacuum switch | R007 | Engine BUS terminating resistance |
| B055 | Foot throttle sensor | S002 | Ignition switch |
| B086 | Rail pressure sensor | S047 | Engine brake switch |
| B087 | Fuel low pressure sensor | S074 | Starter lockout & clutch pedal limit switch |
| B088 | Crankshaft speed sensor | Y091 | Fuel dispensing unit |
| B089 | Engine temperature sensor (Deutz) | Y095 | Injector 1 |
| B090 | Oil pressure sensor | Y096 | Injector 2 |
| B091 | Water in fuel sensor | Y097 | Injector 3 |
| B092 | Boost pressure/charge air temperature sensor | Y098 | Injector 4 |
| B102 | AdBlue temperature/level sensor | Y100 | Injector 5 |
| B105 | Exhaust temperature before SCR sensor | Y101 | Injector 6 |
| B180 | Ambient air temperature sensor (EDC) | Y120 | AdBlue flow valve |
| K063 | Heater flange relay | Y169 | AdBlue tank heater solenoid valve |
| | | Y170 | Engine brake solenoid valve |

Functions of the A127 - Engine control ECU (EDC 17)

The **A127** - Engine control ECU (EDC 17) **manages and controls the engine.**

The **A127** - Engine control ECU (EDC 17) has the following management functions:

All speed control

The **A127** - Engine control ECU (EDC 17) keeps the engine under constant load at the speed set by the foot throttle, hand throttle and memory key (target value), as long as the engine is capable of providing the necessary power.

Restriction of the maximum engine speed ("engine cut-off speed")

Torque restriction

Restriction of the maximum torque (maximum injection volume)

Rail pressure restriction

The **Y091** - Fuel dispensing unit dispenses the exact fuel quantity to the rail that will be discharged by the injectors (Y095 to Y101). Control is exercised by the **B086** - Rail pressure sensor, which reports the actual pressure to the **A127** - Engine control ECU (EDC 17).

Multiple injection

With a view to a reduction in exhaust gas and noise emissions, the injectors (Y095 to Y101) are activated by the **A127** - Engine control ECU (EDC 17) up to 3 times per working cycle.

Cylinder switch-off

If the **A127** - Engine control ECU (EDC 17) detects a short circuit at an injector (Y095 to Y101) (short circuit low-high), this injector is no longer activated (shut down).

Engine start

If all input signals are present the start procedure is initiated.

NOTE: If the rotational speed signals (camshaft / crankshaft) are not present after 5 sec, the start process is aborted

Engine stop

The injectors cease to be activated.

Monitoring and signal output functions

Coolant temperature and charge-air temperature → for fault displays and/or reductions in power see chapter 0000 Reg. B - Fault code table

Charge pressure-dependent engine management ("LDA function")

If the charge-air temperature increases, the injection quantity will be restricted. If the boost pressure drops, the injection quantity will be restricted.

20 B092 - Boost pressure/charge air temperature sensor

| Pin | Function |
|-----|--------------------|
| -1 | Earth |
| +2 | Temperature signal |
| -3 | + supply |
| +4 | Pressure signal |




Fig. 59.

EKI03152
I005051

Duty:

Component **B092** - Boost pressure/charge air temperature sensor reports the boost pressure and charge air temperature to the **A127** - Engine control ECU (EDC 17)

The **B092** - Boost pressure/charge air temperature sensor is a combination sensor. Two sensors with a shared power supply are mounted in the same component

Function of the pressure sensor:

The charge pressure (physical variable) is converted into a voltage signal (electrical variable). The pressure and the signal voltage are proportional, so that as the charge pressure increases, the signal voltage increases proportionately. ("LDA function")

Function of the temperature sensor:

The resistance of the temperature sensor changes depending on the temperature. The sensor has either an NTC (negative temperature coefficient) or a PTC (positive temperature coefficient) characteristic.

The **B092** - Boost pressure/charge air temperature sensor is an NTC sensor, i.e. as the temperature rises, the resistance of the sensor falls.

Circuit diagram of the B092 charge air pressure/temperature sensor




Fig. 60.

EKI03153
I005052

Duty:

Used for controlling the engine (A127 - Engine control ECU (EDC 17))

The **B092** - Boost pressure/charge air temperature sensor picks up the boost pressure and the charge air temperature.

The signals are forwarded to the **A127** - Engine control ECU (EDC 17).

In the **A127** - Engine control ECU (EDC 17), the boost pressure is used to control the engine ("LDA function").

For charge air temperature warning message (on the A007 - Instrument panel)

The **A127** - Engine control ECU (EDC 17) picks up the charge air temperature from the **B092** - Charge air pressure/temperature sensor and forwards it to the A050 basic control ECU via the G BUS.

The "Warning threshold" for the charge air temperature is stored in the A050 basic control ECU.

If the charge air temperature rises above the "warning threshold", the **A050** - Basic control ECU issues an error message.

Valve adjustment diagram, engine rotating backwards

Note: Rotate the G002/G004 alternator motor against its rotational direction

| | | | | | | |
|---|----------|----------|----------|----------|----------|----------|
| Overlap | 6 | 3 | 5 | 1 | 4 | 2 |
| Inlet valve closes Exhaust valve opens | | | | | | |
| Adjust | 1 | 4 | 2 | 6 | 3 | 5 |

Set the valves




Fig. 23.

1024629

- Fit the **X899.980.236.051** adjustment tool
- Loosen locknut
- Screw in the adjustment screw until the rocker arm touches the valve with no clearance
- Set the indicator to 0
- Turn back the adjustment screw until the required clearance is achieved.
- Tighten locknut
- Tightening torque: **20 Nm**

Intake valve (IN) = in. 75° (=0.3 mm)
Exhaust valve (EX) = ex. 120° (=0,5 mm)





Fig. 24.

1002496



Clean the sealing surfaces (use vacuum cleaner)



Fig. 25.

1024301

8 Y095 to Y101 – Injectors 1 to 6

! DANGER:
After switching the engine off, wait at least 30 seconds before starting any work on the fuel system!

! WARNING:
Ensure the utmost cleanliness!
See Service Information 14/2007.




Fig. 11.

EK106825
1006262

| Item | Designation | Item | Designation |
|------|-----------------------|------|------------------------------------|
| -1 | Electrical connection | +4 | External high-pressure connection |
| +2 | Return flow | -5 | High-pressure connection from rail |
| -3 | Nozzle | | |

10 Measuring fuel low pressure

Measuring fuel low pressure "primary pressure" (B087 sensor)




Fig. 24.

1024816

B086 - Rail pressure sensor

B087 - Fuel low pressure sensor

DBV Pressure relief valve 2300 bar

FCU Fuel control unit

HDP High-pressure pump

HP Hand pump

INJ Injectors

KF Main fuel filter

KFP Fuel pump

NFD Zero-delivery restrictor

NW Camshaft

Rail High-pressure accumulator

USV Bypass valve

VF Pre-filter with water sedimentor:

Connect the pressure gauge (measuring range: 15 bar) to the fuel filter measuring connection




Fig. 25.

1022713

Note: the fuel low pressure is influenced by the fuel temperature

| Fuel low pressure "primary pressure" at operating temperature | Signal from B087 sensor |
|---|-------------------------|
| 0 bar | Approx. 0.5 VDC |
| Approx. 6.0 bar, irrespective of engine speed. | approx. 3.9 VDC |

1 General explanation about the SCR system




Fig. 1.

1030348

| | | | |
|-------------|--|-------------|---------------------------------------|
| A082 | Nitrogen oxide NOx sensor 1, upstream of SCR | A084 | AdBlue module |
| A083 | Nitrogen oxide NOx sensor 2, downstream of SCR | B102 | AdBlue temperature/level sensor |
| Y120 | AdBlue flow valve | B105 | Exhaust temperature before SCR sensor |
| | | Y169 | AdBlue tank heater solenoid valve |

| | |
|---------|---|
| A | AdBlue injection |
| B | Chemical reaction between ammonia and nitrogen oxide |
| C | Discharge of water vapour and nitrogen, as well as the remaining exhaust gas components |
| SCR cat | S elective C atalytic R eduction - cat |
| T | AdBlue tank |

Wheel-driven steering pump supplies oil to steering





Fig. 4.

1031527

Operation from the emergency steering pump (PNL)

If the diesel engine is not in use and the tractor is being towed, the emergency steering pump is active. The oil flows from the emergency steering pump (PNL) to the steering non-return valve 3 (RVL3), opens it and closes steering non return valves 1 + 2 (RVL1 + 2) in addition to the spring force. The pressure at the steering priority valve (PVL) falls below 6 bar () and is pushed fully to the left by the spring force, thereby severing the connection from the emergency steering pump to the tank. This allows oil to flow to the steering unit (LE).




Fit the rubber mat



Fig. 47.

1033774




Fit the seat



Fig. 48.

1033773




Fit the nuts to the seat bracket



Fig. 49.

1033772



Plug in the electrical connectors to the seat



Fig. 50.

1033771

Lower linkage (release)




Fig. 9.

1031498

The **MVUL [Y083]** - Lower link stabiliser release solenoid valve is energised continuously. This frees the lower linkages.

NOTE: If the linkage is operated externally, the hydraulic lower linkage stabiliser will switch from "automatic mode" to "manual mode" for safety reasons.

3V1 - Trailer spool valve



Right side of tractor, behind the bulk-head




Fig. 6.


1038275

3V2 [Y023] - Compressed air pilot control system solenoid valve

3V3 - Pressure controller for compressed air pilot control system



Right side of transmission.



Remove right rear wheel and panel





Fig. 7.

1038274

3V5 - Parking brake valve



Cab, in the left-hand side of the steering column



Detach panel



Fig. 8.

1038281

3Z1 - Spring-loaded cylinder



On the rear axle




Fig. 9.

1038282




Fig. 8. Valve bus

1031399

| | | | |
|-------------|----------------------------------|-------------|---------------------------------|
| A013 | PCB, microfuses | Y178 | Spool valve, position 3 (red) |
| A050 | Basic control ECU | Y179 | Spool valve, position 4 (green) |
| A100 | MFA, multifunction armrest | Y180 | Spool valve, position 5 (brown) |
| A103 | Terminal NT01/02 | Y181 | Front power lift control valve |
| R009 | Valve BUS terminating resistance | Y182 | Spool valve, position 7 (olive) |
| Y087 | VarioGuide steering valve | Y183 | Spool valve, position 8 (grey) |
| Y176 | Spool valve, position 1 (yellow) | Y184 | Rear power lift control valve |
| Y177 | Spool valve, position 2 (blue) | | |

| Pin | Description | condition | Signal Specified value | Wire interrupted | |
|-----|--|---|------------------------|------------------|-----------------------|
| | | | | Signal from A007 | Signal from component |
| | | Rear power lift, lower limit position | 0 VDC | 0 VDC | 0 VDC |
| | | Rear power lift, upper limit position | 10 VDC | 10 VDC | 0 VDC |
| -23 | Not assigned | | | | |
| -24 | Not assigned | | | | |
| *25 | Not assigned | | | | |
| -26 | Comfort Bus (CAN high) Note: end resistor in the A013 PCB (120 ohms) and in the A007 instrument panel (120 ohms) | Ignition OFF, measure resistance between CAN low (pin 13) and CAN high (pin 26) | approx. 60 ohms | | |
| | | Ignition ON, measure voltage between CAN high (pin 26) and earth (X101, pin 12) | 2.5 VDC | 2.7 VDC | 1.8 VDC |

Measurement at X101 - Separation point on A007 (yellow)

NOTE:

- The following measurements are from separation point X101 "yellow"
- Pin 12 earth, X101 separation point, "yellow"
- Ignition on
- All measurements ± 10%

| Pin | Description | condition | Signal Specified value | Wire interrupted | |
|-----|--|------------------------------|------------------------|------------------|-----------------------|
| | | | | Signal from ECU | Signal from component |
| -1 | A128 - Control panel, right/left dashboard "Enter" button | | | 5.0 VDC | 0 VDC |
| | | "Enter" button not depressed | 1.7 VDC | | |
| | | "Enter" button depressed | 0.5 VDC | | |
| +2 | A128 - Control panel, right/left dashboard "ESC" button | | | 5.0 VDC | 0 VDC |
| | | "ESC" button not depressed | 1.7 VDC | | |
| | | "ESC" button depressed | 0.5 VDC | | |
| -3 | A128 - Control panel, right/left dashboard UP arrow key | | | 5.0 VDC | 0 VDC |
| | | "UP arrow" key not actuated | 1.7 VDC | | |
| | | "UP arrow key" actuated | 0.5 VDC | | |
| +4 | A128 - Control panel, right/left dashboard | | | 5.0 VDC | 0 VDC |

| Fuses (X202 separation point) "area C" | | | |
|--|------|-------------------|--|
| Vehicle earth | | | |
| Pin | Fuse | Specified value | Component |
| C1 | - | - | - |
| C2 | - | approx. 2.2 VDC | Valve bus_Low |
| C3 | - | approx. 2.5 VDC | Valve bus_High |
| Ignition OFF, C2 and C3 Measure | - | approx. 60 ohms | Valve bus 2x 120 ohms parallel Terminating resistance: A013 - PCB, microfuses (120 ohms) R009 - Valve BUS terminating resistance (120 ohms) |
| C4 | S 32 | 12.0 VDC | B008 - High-pressure Sensor 1 |
| C5 | S 31 | 12.0 VDC | B039 - High-pressure sensor 2 |
| C6 | S 30 | 12.0 VDC | B097 - Hydraulic parking brake pressure release sensor |
| C7 | S 29 | 12.0 VDC | B081 - 360° steering wheel sensor (for Auto-Guide only) |
| C8 | S 37 | 12.0 VDC | S074 - Starter lockout & clutch pedal limit switch |
| C9 | S 36 | 12.0 VDC | B002 - Front PTO speed sensor |
| C10 | S 35 | 12.0 VDC | B020 - Rear PTO stub shaft speed sensor |
| C11 | S 34 | 12.0 VDC | B021 - Rear PTO clutch speed sensor |
| C12 | | approx. 2.5 VDC | ISO bus_Low In |
| C13 | | approx. 2.5 VDC | ISO bus_Low Out |
| C14 | | approx. 2.6 VDC | ISO bus_High In |
| C15 | | approx. 2.6 VDC | ISO bus_High Out |
| C12 and C14 | | 1.5 VDC - 3.5 VDC | ISO bus |
| C16 | | 12 VDC | ISO bus terminal, bus on |
| C17 | | | Serial Rx (receiving) |
| C18 | | | Serial Tx (transmitting) |

| | | | | |
|--------|------------|---------------------|--|---|
| Signal | # 10 (A93) | 8.5 V _{DC} | Pump OFF | Exhaust temperature upstream of the SCR catalytic converter must be higher than 200°C |
| | | 7.2 V _{DC} | Pump running in normal mode | |
| | | 2.1 V _{DC} | Pump running in extraction mode | |
| Earth | # 8 (A7) | | | |

NOTE: If the AdBlue was operated previously, the AdBlue extraction system solenoid valve is not energised until the diesel engine is switched off.

AdBlue extraction system solenoid valve

| Test | Pin | Specified value | condition | Note |
|---------|------------|-----------------|---------------------|--------------------------------------|
| MV_high | # 11 (A8) | 7.4 ohms | Ignition OFF | Reading with coil resistance of 20°C |
| MV_low | # 12 (A30) | | | |


| | | | | |
|---------|------------|--------------------|--------------------------------|--|
| MV_high | # 11 (A8) | 12 V _{DC} | Switch position Suction | The solenoid valve is energised for max. 120 seconds 10 seconds after the engine has been switched OFF |
| | | 0 V _{DC} | Switch position OFF | |
| MV_low | # 12 (A30) | | | |



Recommended tools

- Diagnostic PC with current FENDIAS software
- Adapter cable X899.980.246.217 - connection to AdBlue module
- Adapter box X899.980.304.000
- Adapter cable X899.980.304.205 - pin connection to adapter box

NOTE:



To continue dismantling the A100 multi-function armrest, an anti-static strap must be used.

An **anti-static strap** is used to earth persons and also to prevent electrostatic discharge (ESD). If the strap is not used, this discharge would easily destroy the integrated circuits (PCB).




Fig. 48.

EKI13096
I034572





Fig. 49.

EKI13048
I034475




Remove the **console for the joystick and the crossgate lever**.
Mark and disconnect the joystick separation points.



EK113078
1034505

Fig. 80. Carefully route the wiring harnesses. Make sure that no chafing points develop.



Carefully route the wiring set for the camera connections along the armrest and secure using cable ties.




Fig. 112.



Fit panel.





Fig. 113.



Tighten the bolts (arrowed).




Fig. 114.

Once the circuit board has been replaced, EOL programming must be completed.

Once the circuit board has been replaced, EOL programming must be completed.




Fig. 115.

| Pin | Description | Signal type/condition | Signal | Wire interrupted | |
|---------------|--|---|-------------------------------------|-------------------------------------|-----------------------|
| | | | | Signal from A111 | Signal from component |
| | | Left wide vehicle marker light/tail light (58L) ON | 12 V _{DC} | 12 V _{DC} | 0 V _{DC} |
| C9 (X2242) | Signal "Right wide vehicle marker light/tail light (58R)" | Right wide vehicle marker light/tail light (58R) OFF | 0 V _{DC} | 0 V _{DC} | 0 V _{DC} |
| | | Right wide vehicle marker light/tail light (58R) ON | 12 V _{DC} | 12 V _{DC} | 0 V _{DC} |
| C5 (X2242) | Signal "Brake light (54)" | Brake light OFF | 12 V _{DC} not load-able | 12 V _{DC} not load-able | 0 V _{DC} |
| | | Brake light ON | 12 V _{DC} | 12 V _{DC} | 0 V _{DC} |

NOTE: see 9000, §15, page 92

| Pin | Description | Signal type/condition | Signal | Wire interrupted | |
|-----|----------------------------|--|--------------------|--------------------|-----------------------|
| | | | | Signal from A111 | Signal from component |
| G17 | Air con. clutch relay (86) | Air conditioning compressor OFF | 0 V _{DC} | 0 V _{DC} | 0 V _{DC} |
| | | Air conditioning compressor ON | 14 V _{DC} | 0 V _{DC} | 14 V _{DC} |
| G19 | Air con. clutch relay (87) | Air conditioning compressor OFF | 0 V _{DC} | 0 V _{DC} | 0 V _{DC} |
| | | Air conditioning compressor ON | 14 V _{DC} | 14 V _{DC} | 0 V _{DC} |

NOTE:

| X2524 - Separation point on A127 | | | | |
|----------------------------------|----------|-------------------|--------------------|---|
| +UB 5 V | | | | |
| Test | Pin | Specified value | condition | Possible cause of fault |
| + supply | B24 | 5 V _{DC} | Ignition ON | wiring set also see circuit diagram: supply to electronics S002 - Ignition switch3 |
| | | 5 V _{DC} | Engine is running | |
| Earth | B40, B57 | | | |

| X2523 - Separation point on A127 | | | | |
|----------------------------------|------------|--------------------|---|---|
| 50a (ignition switch) | | | | |
| Test | Pin | Specified value | condition | Possible cause of fault |
| + supply | A35 | 12 V _{DC} | Clutch pedal depressed S002 - Ignition switch position II | wiring set also see circuit diagram: supply to electronics S002 - Ignition switch3 |
| Earth | A2, A4, A6 | | | |

Signal voltages

| Pin | Description | Signal type/condition | Signal | Wire interrupted | |
|-----------------------|----------------|---|--------------------|--------------------|-----------------------|
| | | | | Signal from A127 | Signal from component |
| Supply (UB 30) | | | | | |
| A1 (X2523) | Supply (UB 30) | Ignition OFF | 12 V _{DC} | 12 V _{DC} | 12 V _{DC} |
| A3 (X2523) | Supply (UB 30) | Ignition OFF | 12 V _{DC} | 12 V _{DC} | 12 V _{DC} |
| A5 (X2523) | Supply (UB 30) | Ignition OFF | 12 V _{DC} | 12 V _{DC} | 12 V _{DC} |
| Supply (UB 15) | | | | | |
| A88 (X2523) | Supply (UB 15) | Ignition OFF (min. 2 minutes) | 0 V _{DC} | 0 V _{DC} | 0 V _{DC} |
| | | Ignition ON | 12 V _{DC} | 0 V _{DC} | 12 V _{DC} |
| + UB sensors | | | | | |
| A68 (X2523) | + UB sensors | Ignition OFF (min. 2 minutes) | 0 V _{DC} | 0 V _{DC} | 0 V _{DC} |
| | | Ignition ON | 12 V _{DC} | 12 V _{DC} | 0 V _{DC} |
| 50a | | | | | |
| A35 (X2523) | 50a | Clutch pedal depressed, S002 - Ignition switch in position II | 12 V _{DC} | 0 V _{DC} | 12 V _{DC} |
| Earth | | | | | |
| A2 (X2523) | Earth | - | - | - | - |

32 B007 - Fuel level sensor

| | |
|---|------------------------------------|
| Connect e-adapter box (68 pin) X899.980.208.100 with adapter cable X899.980.208.204 to the A007 instrument panel | |
| Pin at separation point | Pin on the adapter box (68-pin) |
| X101 separation point "yellow" (1 to 26) | 1 to 26 |
| X100 separation point "blue" (1 to 26) | 31 to 56 |




Fig. 151.

EKI10850
1014447

Measuring points and signal values

| Pin assignment | B007 - Fuel level sensor | A007 - Instrument panel |
|----------------|--------------------------|-------------------------|
| Earth | # 1 (X156) | - |
| Signal | # 2 (X156) | # 21 (X101) |

Checking the B007 - Fuel level sensor

Remove **B007** - Fuel level sensor
 Connect adapter cable X899.980.246.205 to **B007** -
 Fuel level sensor
 Move float (arrow) by hand.




Fig. 152.

1019268

When the float reaches the switch, the switch closes.
 Total resistance is achieved by via series connection of resistors.
 Test the total resistance using a multimeter (ohmmeter).
 (For resistance values, see table below).

Test fuel gauge on the A007 instrument panel

Check fuel gauge display on A007 - Instrument panel

Connect adapter cable X899.980.246.205 to the
 X156 separation point (connection to B007 remains
 separate).
 Connect the X 899.980.224 resistance decade.
 Switch on ignition.
 Select corresponding resistance (see table) and
 compare with display on the **A007** - Instrument
 panel.

NOTE: Allow preconditioning time of approx. 1
 minute.




Fig. 153.

EKI07615
1001514

39 B017 - Clutch pedal sensor




Fig. 163.


I016403

| Pin assignment | B017 - Clutch pedal sensor | A050 - Basic control ECU (EXT) |
|----------------|----------------------------|--------------------------------|
| Earth | # 1 (X166) | # A45 (X1403) |
| UB | # 2 (X166) | - |
| Signal | # 3 (X166) | # B29 (X1402) |

Measurement at component separation point (X166)

| Test | Pin | Specified value | condition | Note |
|-------|-----|---------------------|--------------------|--|
| UB | # 2 | 8.5 V _{DC} | Ignition ON | Microfuse (S5) in A013 or wiring set faulty. |
| Earth | # 1 | | | |

| | | | | |
|--------|-----|---|--------------------------------------|--|
| Signal | # 3 | 1.2 V _{DC} (6 mA _{DC}) | Clutch pedal not depressed | |
| | | 3.6 V _{DC} (17 mA _{DC}) | Clutch pedal depressed | |
| Earth | # 1 | | | |



Recommended tools

- Diagnostic PC with current FENDIAS software
- X899.980.246.205 adapter cable - connection to sensor
- Adapter box X899.980.304.000
- Adapter cable X899.980.304.201 - connection to adapter box

NOTE:

see F, §11, page 338
see 9000, §6, page 40

| Voltage | Pressure | Display |
|---------|----------|-----------|
| VDC | bar | Bars |
| 0.31 | 0 | 1 flashes |
| 0.40 | 0.5 | 1 |
| 0.51 | 1.1 | 2 |
| 0.65 | 1.9 | 3 |
| 0.80 | 2.7 | 4 |
| 0.94 | 3.5 | 5 |
| 1.09 | 4.4 | 6 |
| 1.24 | 5.2 | 7 |
| 1.37 | 5.9 | 8 |
| 1.53 | 6.8 | 9 |
| 1.67 | 7.6 | 10 |
| 1.79 | 8.3 | 11 |
| 1.8 | 8.4 | 12 |




Fig. 173.

A00645
I005064

Checking display (compressed air supply) on A007 - Instrument panel instrument panel.

Connect adapter cable X899.980.246.205 to component separation point X1410.
 Connect X899.980.224 resistance decade and select corresponding resistance (see table).
 Switch ignition ON.
 Compressed air supply is displayed on the instrument panel.




Fig. 174.

A00646
I005065

| Resistance | Display |
|------------|-----------|
| Ohms | Bars |
| 20 | 1 flashes |
| 25 | 1 |
| 32 | 2 |
| 41 | 3 |
| 50 | 4 |
| 59 | 5 |
| 68 | 6 |
| 77 | 7 |
| 86 | 8 |
| 96 | 9 |
| 104 | 10 |
| 112 | 11 |
| 113 | 12 |

54 B088 - Crankshaft speed sensor

Measuring points and signal values




Fig. 190.

1031098

| Pin assignment | B088 - Crankshaft speed sensor | A127 - Engine control ECU (EDC 17) |
|--------------------------------|--------------------------------|------------------------------------|
| Signal | # 1 | # B39 (X2524) |
| Earth | # 2 | # B54 (X2524) |
| Shielding against interference | # 3 | # B38 (X2524) |

- Connect adapter cable X899.980.246.202 to the sensor only
- Ignition off

Measuring the internal resistance

| Test | Pin | Specified value | condition | Possible cause of fault |
|--------|-----|-----------------|---------------------|------------------------------------|
| Signal | -1 | Approx. 990 Ohm | Ignition OFF | Reading infinity: component fault. |
| Earth | +2 | | | |

59 B102 - AdBlue temperature/level sensor

Measuring points and signal values




Fig. 206.

1031124

| Pin assignment | B102 - AdBlue temperature/level sensor | A127 - Engine control ECU (EDC 17) |
|---------------------------|--|------------------------------------|
| Earth | # 1 (X2017) | # A64 (X2523) |
| AdBlue temperature signal | # 2 (X2017) | # A58 (X2523) |
| AdBlue level signal | # 3 (X2017) | # A39 (X2523) |

Check B102 - AdBlue temperature/level sensor

Remove **B102** - AdBlue temperature/level sensor
 Connect adapter cable X899.980.246.205 to **B102** -
 AdBlue temperature/level sensor
 Move float (see arrow) by hand.




Fig. 207.

1019268

When the float reaches the switch, the switch closes.
 Total resistance is achieved by via series connection of resistors.
 Test the total resistance using a multimeter (ohmmeter).
 (For resistance values, see table below).

69 G002 - Alternator 1

Circuit diagram: G002 alternator




Fig. 222.

1038229

- | | | | |
|-------------|---------------------|-------------|---------------|
| A007 | Instrument panel | M001 | Starter |
| G002 | Alternator 1 | R002 | Heater flange |
| K063 | Heater flange relay | | |

NOTE: The G002 alternator must not be operated unless a battery or another consumer (e.g. vehicle lighting) is connected, otherwise the rectifier or controller may be damaged

Check regulating voltage (B+):

Measure B+ (rt 16) at G002 alternator and earth

| | Voltage (VDC) |
|--------------------------|----------------|
| Ignition OFF | 12 VDC |
| Ignition ON | 12 VDC |
| Engine is running | Approx. 14 VDC |

In the event of deviations, have G002 alternator repaired by a specialist workshop.




Fig. 223.

EKI08599
1002398

74 S015 hand brake switch




Fig. 241.

| Pin assignment | S015 - Parking brake switch | A050 - Basic control ECU (EXT) |
|----------------|-----------------------------|--------------------------------|
| Not assigned | # 1 (X226) | - |
| Not assigned | # 2 (X226) | - |
| Signal | # 3 (X226) | B34 (X1402) |
| Earth | # 4 (X226) | A45 (X1403) |

Measurement at component separation point (X226)

| Test | Pin | Specified value | condition | Note |
|------------|-----|-----------------|---------------------|------|
| Resistance | # 3 | 510 ohms | Hand brake applied | |
| | | 121 ohms | Hand brake released | |
| Earth | # 4 | | | |

| | | | | |
|--------|-----|---------------------|---------------------|---|
| Signal | # 3 | 3.8 V _{DC} | Hand brake applied | Unplug component: If measured value is 0 V _{DC} , there is a fault with the wiring set or the A050 ECU |
| | | 1.8 V _{DC} | Hand brake released | |
| Earth | # 4 | | | If measured value is 6.2 V _{DC} , there is a fault with the component. |



Recommended tools

- Diagnostic PC with current FENDIAS software
- Adapter cable X899.980.246.206 - connection to sensor
- Adapter box X899.980.304.000
- Adapter cable X899.980.304.201 - connection to adapter box

NOTE:

see 9000, §6, page 40

83 S047 - Engine brake switch

Measuring points and signal values

| Pin assignment | S047 - Engine brake switch | A127 - Engine control ECU (EDC 17) |
|---------------------|----------------------------|------------------------------------|
| Engine brake switch | # 1 (X140) | # A40 (X2523) |
| + UB sensors | # 2 (X140) | # A68 (X2523) |

Measurement at component (X140)

| Test | Pin | Specified value | condition | Possible cause of fault |
|---------------|-----|--------------------|-----------|--|
| + UB sensors | +2 | 12 V _{DC} | | Earth connection, component fault, A127 - Engine control ECU (EDC 17) |
| Vehicle earth | | | | |

| Test | Pin | Specified value | condition | Possible cause of fault |
|---------------------|-----|--------------------|-----------------------------|-------------------------|
| + UB sensors | +2 | 0 V _{DC} | Switch not activated | |
| | | 12 V _{DC} | Switch pressed | |
| Engine brake switch | -1 | | | |



Recommended tools

- Diagnostic PC with current FENDIAS software
- Adapter cable X899.980.246.206 - connection to sensor
- Adapter box X899.980.304.000
- Adapter cable X899.980.304.208 - connection to adapter box

NOTE:

94 X007 implement socket "black"

X007 implement socket "black"

The X007 implement socket (7-pin) delivers signals for the operation of towed and mounted implements.

For example: Speed signals for the operation of a sprayer computer.



Cab, C-pillar, top right



Fig. 255.

I028687

Plug an adapter cable (self-made with G312.810.210.030 plug) into the X007 implement socket.

The measurement can also be carried out without an adapter cable, though measurement errors may result due to the small socket pins.



Fig. 256.

EKI08808

I002749

Pin assignment on the X007 implement socket

1 = actual road speed (A011 radar sensor, optional)
 (130 pulses per metre travelled)

| Speed | Voltage level (U) |
|-----------------------|------------------------------|
| less than 1,0 km/h | 14 VDC |
| greater than 1,0 km/h | approx. 6.5 VDC (UBatt/2) |




Fig. 257.

A00782

I002748

2 = theoretical road speed (Transmission signal)
 (130 pulses per metre travelled)

| Speed | Voltage level (U) |
|-----------------------|------------------------------|
| less than 1,0 km/h | 14 VDC |
| greater than 1,0 km/h | approx. 6.5 VDC (UBatt/2) |




Fig. 258.

A00782

I002748

NOTE:

Solenoid is controlled during the PWM start-up process, depending on the PTO calibration.

[see F, §9, page 332](#)

[see 9000, §6, page 40](#)

Measurement on electronics box - separation point X1403

NOTE: Measurement of Y026: Remove bridge at pin **54** on adapter box.

| Test | Pin | Specified value | condition | Note |
|---------|------|-----------------|---------------------|--|
| Current | # 54 | 1.7 A | Switch position ON | Remove bridge at pin 54 on adapter box |
| | | 0 A | Switch position OFF | |

NOTE: Measurement of Y027: Remove bridge at pin **53** on adapter box.

| Test | Pin | Specified value | condition | Note |
|---------|------|-----------------|---------------------|--|
| Current | # 53 | 1.7 A | Switch position ON | Remove bridge at pin 53 on adapter box |
| | | 0 A | Switch position OFF | |

NOTE: Measurement of Y028: Remove bridge at pin **76** on adapter box.

| Test | Pin | Specified value | condition | Note |
|---------|------|-----------------|---------------------|--|
| Current | # 76 | 1.7 A | Switch position ON | Remove bridge at pin 76 on adapter box |
| | | 0 A | Switch position OFF | |



Recommended tools

- Diagnostic PC with current FENDIAS software
- Adapter cable X899.980.246.201 - connection to solenoid valve
- Adapter box X899.980.304.000
- Adapter cable X899.980.304.201 - connection to adapter box

NOTE:

[see 9000, §6, page 40](#)



After the high-pressure limiting valve opens, the warning message "**High-pressure limiting valve opened**" is displayed on the **A007** - Instrument panel

Since high pressure (approx. 700 bar) is relieved via the pressure-limiting valve, the fuel is heated.

Therefore, the engine is switched off automatically by the **A127** - Engine control ECU (EDC 17) after **approx. 4 minutes**.

Restart the tractor:

Switch ignition off.

Wait at least 30 seconds until the pressure in the rail (high-pressure accumulator) has dissipated and the pressure-limiting valve can close.

Restart the tractor.

5 Test report – fax template for tractors with VarioGuide equipment

Pressure testing

| | | | | |
|--------------|-------------------|----------|-------|-----------------|
| FENDT | | | | Measurement no. |
| Chassis no.: | Op. hrs. reading: | Keyword: | Name: | Date: |

NOTE: Initial condition of tractor for all measurements:

- Engine in idle (800 rpm)
- Valves and EPC are locked
- No steering
- In tractors with hydraulic trailer brakes, release the pressure with the trailer brake button while the hand-brake is applied
- Oil temperature 40-50°C

| | LS pump test [PR] | Auxiliary pump (PH) M2 (bar) | LS pump (PR) M3 (bar) | Load sensing (LS pressure) M4 (bar) | Control pressure M5 (bar) | Oil temperature (°C) |
|-----|--|------------------------------|--------------------------------------|--------------------------------------|---------------------------|----------------------|
| A | | SETPOINT ACTUAL | SETPOINT ACTUAL | SETPOINT ACTUAL | SETPOINT ACTUAL | |
| A1 | Minimum standby pressure (Valves locked) | 10–16 | 28–32 | 5–11 | 0 | |
| A2 | Minimum standby pressure (Valves unlocked) | 30–36 | 28–32 | 5–11 | 18–24 | |
| A3 | Free steering when stationary To left/right (Valves unlocked) | 30–36 / | Depend- ing on resistance / | Depend- ing on resistance / | 18–24 | |
| A4 | Turn steering to stop To left/right (Valves unlocked) | 30–36 / | 190–195 / | 175–180 / | 18–24 | |
| A5 | Yellow spool valve Raise/lower | 30–36 / | 198-210 / | 198-210 / | 18–24 | |
| A6 | Blue spool valve Raise/lower | 30–36 / | 198-210 / | 198-210 / | 18–24 | |
| A7 | Red spool valve Raise/lower | 30–36 / | 198-210 / | 198-210 / | 18–24 | |
| A8 | Green spool valve Raise/lower | 30–36 / | 198-210 / | 198-210 / | 18–24 | |
| A9 | Brown spool valve Raise/lower | 30–36 / | 198-210 / | 198-210 / | 18–24 | |
| A10 | Olive spool valve Raise/lower | 30–36 / | 198-210 / | 198-210 / | 18–24 | |
| A11 | Grey spool valve Raise/lower | 30–36 / | 198-210 / | 198-210 / | 18–24 | |

Functional description of components with pulse width output A050 - Basic control ECU

Actuators with pulse width outputs

| DIN | Designation | Pin at A050 |
|------|--|-------------|
| Y004 | - Turbo-clutch solenoid valve | B21 |
| Y005 | - Speed governor solenoid valve | A75 |
| Y008 | - Rear PTO clutch solenoid valve | A77 |
| Y011 | - Front PTO clutch solenoid valve | A86 |
| Y021 | - Standard front power lift raise solenoid valve (SA) | A49 |
| Y021 | - Front pressure compensator lock valve | |
| Y022 | - Standard front power lift lower solenoid valve (SA) | A73 |
| Y022 | - Front field pressure control solenoid valve | |
| Y026 | - Rear PTO solenoid valve, stage I | A54 |
| Y027 | - Rear PTO solenoid valve, stage II | A53 |
| Y032 | - Control pressure solenoid valve | A52 |
| Y055 | - Rear pressure compensator lock valve | A31 |
| Y061 | - Hydraulic oil pre-heater solenoid valve (middle) | A74 |
| Y062 | - Rear field pressure control solenoid valve | A56 |
| Y063 | - Wobble stabiliser solenoid valve | A01 |
| Y064 | - Suspension load pressure & lowering solenoid valve | A26 |
| Y084 | - Power Beyond solenoid valve | A50 |
| Y085 | - VarioGuide pilot pressure switch-off solenoid valve (High) | A07 |
| Y085 | - VarioGuide pilot pressure switch-off solenoid valve (Low) | A78 |
| Y086 | - VarioGuide steering disconnect solenoid valve (High) | A06 |
| Y086 | - VarioGuide steering disconnect solenoid valve (Low) | A79 |
| Y088 | - Trailer brake release solenoid valve (High) | A02 |
| Y088 | - Trailer brake release solenoid valve (Low) | A85 |

NOTE: For safety critical circuits, both the positive and negative sides are connected via the A050 - ECU, basic control unit.

The positive side is called _High in the E-box.

The negative side is called _Low in the E-box.

The **A050** - Basic control ECU supplies a voltage of **0 V_{DC} to 12 V_{DC}** for energising the solenoid valves

The voltage increase to 12 V_{DC} or the voltage shutoff to 0 V_{DC} is proportionally controlled.

The **A050** - Basic control ECU is capable of having diagnostics run at the outputs; this means that if a break in wiring or a short circuit occurs, this output is switched off and an error code is output.

NOTE: *A pulse width output can also be programmed to a given current value, e.g. Y005 - Speed governor solenoid valve 800 mA.*

Error pattern for a break in the signal wiring




Fig. 20.

I026984

| | Reading | Note |
|----|---------|---|
| U1 | 8.5 V | Ignition ON, E-box supplies 8.5 V (stabilised) Microfuse OK |
| A1 | 0 mA | No current flow when there is a break in the wiring |
| U2 | 0 V | The signal comes from the sensor, (no basic signal voltage from the E-box at the current input) |
| U3 | 6.8 V | Sensor tries to supply a current. A current cannot flow due to a wiring break, therefore voltage is used. Voltage is not dependent on the sensor position. |

Error pattern for an earth connection in the signal wiring




Fig. 33.

1027023

| | U2 | Note |
|---------------|-------------------|---|
| Error pattern | 0 V _{DC} | U1 = 5 V _{DC} , the sensor can only provide a signal if it has a power supply |

| Diagnostic steps | U4 | Note |
|----------------------------------|-------------------|---|
| 1. Connect multimeter U4 | 5 V _{DC} | Earth connection in the sensor, wire or E-box |
| 2. Disconnect sensor | 0 V _{DC} | Sensor faulty |
| | 5 V _{DC} | Earth connection in the wire or E-box |
| 3. Bridge to Open adapter box | 0 V _{DC} | E-box faulty |
| | 5 V _{DC} | Earth connection in signal line |

Other rotary position sensors (angle/voltage) that are installed on the tractor:

| DIN | Designation | Note |
|-------------|----------------------------------|--|
| B055 | Sensor, foot throttle | Combination sensor (A050 current divider/A051 voltage reducer) |
| B030 | Sensor, rear power lift position | Supply 10 V _{DC} |

To compensate for mechanical and electrical tolerances in sensors, the sensor must be calibrated.

X899.980.304.201
Adapter cable (96/58/4x41-pin)
for testing the **A050** - Basic control ECU



Fig. 21.

X899.980.304.203
adapter cable (21/1x41-pin)
for testing the **A111** - Central electrical system ECU



Fig. 22.

X899.980.304.204
Adapter cable (68/2x41-pin)
Adapter for all adapter cables with a 68-pin separation point.



Fig. 23.

X899.980.304.205
Adapter cable (94/60/4x41) pin
For testing **A127** - Engine control ECU (EDC 17)




Fig. 24.








Fig. 6. Central electrical system - relay assignment

1028098

| Relay | Consumer | Relay | Consumer |
|-------|--|-------|---|
| 1 | K1 (ZE) - UB15 relay | 11 | K11 (ZE) - Rear lamp work light relay |
| 2 | Not assigned | 12 | K12 (ZE) - 3rd hydraulic circuit relay; |
| 3 | K3 (ZE) - Not assigned | 13 | K13 (ZE) - 4th hydraulic circuit relay; |
| 4 | K4 (ZE) - Rear window heater relay | 14 | K14 (ZE) - A pillar work light relay |
| 5 | K5 (ZE) - Rotating beacon relay | 15 | K15 (ZE) - Work light relay (NA) |
| 6 | K6 (ZE) - Front inner roof work light relay | 16 | K16 (ZE) - Not assigned |
| 7 | K7 (ZE) - Not assigned | 17 | K17 (ZE) - Not assigned |
| 8 | K8 (ZE) - Front outer roof work light relay | 18 | K18 (ZE) - Not assigned |
| 9 | K9 (ZE) - Rear inner roof work light relay | 19 | K19 (ZE) - Clutch & turbo-clutch relay |
| 10 | K10 (ZE) - Rear outer roof work light relay | 20 | K20 (ZE) - Air conditioning clutch relay |

NOTE: When testing the relay supply voltage, see WHB Chapter 9000 Reg. E, Measuring and testing **A111** - Central electrical system ECU

| DIN component designation | Circuit diagram sheet no. |
|---|--------------------------------|
| X2241 - Separation point on A111 | 9, 14, 23, 25, 26, 28, 30, 37 |
| X2242 - Separation point on A111 | 23, 25, 26, 27, 31 |
| X2243 - Separation point on A111 | 16, 23, 24, 26, 27, 28, 30, 38 |
| X2244 - Separation point on A111 | 22, 23, 24, 26, 27, 30, 31, 38 |
| X2245 - Separation point on A111 | 18, 23, 24, 25, 31, 32 |
| X2246 - Separation point on A111 | 9, 11, 16, 24, 28, 33, 36 |
| X2250 - Separation point on S125 | 8 |
| X2251 - Separation point on A112 | 11, 28 |
| X2253 - Separation point on B158 | 28 |
| X2254 - Separation point on A112 | 28 |
| X2255 - Cab/air conditioning system cable coupling | 28, 29 |
| X2256 - Cab/air conditioning system cable coupling | 28, 29 |
| X2257 - Separation point on Y172 | 17 |
| X2258 - Separation point on E158 | 25 |
| X2259 - 10 amp socket | 31 |
| X2277 - Separation point for operator's seat | 16, 22 |
| X2285 - Steering angle sensor cable coupling | 19 |
| X2320 - Separation point on E171 | 25 |
| X2321 - Separation point on E171 | 25 |
| X2322 - Separation point on E172 | 25 |
| X2323 - Separation point on E173 | 25 |
| X2324 - Separation points on Y176 | 13, 18 |
| X2325 - Separation points on Y177 | 13, 18 |
| X2326 - Separation points on Y178 | 13, 18 |
| X2327 - Separation points on Y179 | 13, 18 |
| X2329 - Separation points on Y181 | 13, 18 |
| X2331 - Separation points on Y183 | 13, 18 |
| X2332 - Separation point on M033 | 26 |
| X2334 - Separation point on U004 | 37 |
| X2364 - Separation point on S132 | 18 |
| X2379 - Separation point on Y184 | 13, 18 |
| X2415 - Separation point on B167 | 28 |
| X2420 - Separation point on B187 | 29 |
| X2421 - Separation point on M048 | 29 |
| X2422 - Separation point on M049 | 29 |
| X2423 - Separation point on M050 | 29 |
| X2424 - Separation point on K093 | 29 |
| X2425 - Separation point on A129 | 29 |
| X2426 - Separation point on A129 | 29 |
| X2456 - Separation point on B180 | 33 |
| X2457 - Separation point on S144 | 21 |
| X2458 - Separation point on S134 | 17 |
| X2513 - Separation point on B188 | 28 |
| X2521 - Separation point on S142 | 25 |
| X2522 - Separation point on S142 | 25 |



A127
A127_X2524

| | | |
|-------|-----|----------------------------|
| 03.A4 | 01 | Injector 4_Low |
| 03.A5 | 02 | Injector 5_Low |
| 03.A6 | 03 | Injector 6_Low |
| 03.A7 | 04 | Charging_mil_High |
| 03.A8 | 05 | UB oil pressure |
| 03.A9 | 06 | UB oil pressure |
| 03.AA | 07 | Water in fuel signal |
| 03.AB | 08 | Ambient temperature signal |
| 03.AC | 09 | 03.A4 |
| 03.AD | 10 | 03.A5 |
| 03.AE | 11 | Injector 1_Low |
| 03.AF | 12 | Injector 2_Low |
| 03.B0 | 13 | Start pin 2 relay |
| 03.B1 | 14 | Start pin 1 relay |
| 03.B2 | 15 | 03.A4 |
| 03.B3 | 16 | 03.A5 |
| 03.B4 | 17 | 03.A6 |
| 03.B5 | 18 | 03.A7 |
| 03.B6 | 19 | 03.A8 |
| 03.B7 | 20 | 03.A9 |
| 03.B8 | 21 | 03.AA |
| 03.B9 | 22 | 03.AB |
| 03.C0 | 23 | 03.AC |
| 03.C1 | 24 | 03.AD |
| 03.C2 | 25 | 03.AE |
| 03.C3 | 26 | 03.AF |
| 03.C4 | 27 | 03.B0 |
| 03.C5 | 28 | 03.B1 |
| 03.C6 | 29 | 03.B2 |
| 03.C7 | 30 | 03.B3 |
| 03.C8 | 31 | 03.B4 |
| 03.C9 | 32 | 03.B5 |
| 03.CA | 33 | 03.B6 |
| 03.CB | 34 | 03.B7 |
| 03.CC | 35 | 03.B8 |
| 03.CD | 36 | 03.B9 |
| 03.CE | 37 | 03.C0 |
| 03.CF | 38 | 03.C1 |
| 03.D0 | 39 | 03.C2 |
| 03.D1 | 40 | 03.C3 |
| 03.D2 | 41 | 03.C4 |
| 03.D3 | 42 | 03.C5 |
| 03.D4 | 43 | 03.C6 |
| 03.D5 | 44 | 03.C7 |
| 03.D6 | 45 | 03.C8 |
| 03.D7 | 46 | 03.C9 |
| 03.D8 | 47 | 03.CA |
| 03.D9 | 48 | 03.CB |
| 03.DA | 49 | 03.CC |
| 03.DB | 50 | 03.CD |
| 03.DC | 51 | 03.CE |
| 03.DD | 52 | 03.CF |
| 03.DE | 53 | 03.D0 |
| 03.DF | 54 | 03.D1 |
| 03.E0 | 55 | 03.D2 |
| 03.E1 | 56 | 03.D3 |
| 03.E2 | 57 | 03.D4 |
| 03.E3 | 58 | 03.D5 |
| 03.E4 | 59 | 03.D6 |
| 03.E5 | 60 | 03.D7 |
| 03.E6 | 61 | 03.D8 |
| 03.E7 | 62 | 03.D9 |
| 03.E8 | 63 | 03.DA |
| 03.E9 | 64 | 03.DB |
| 03.EA | 65 | 03.DC |
| 03.EB | 66 | 03.DD |
| 03.EC | 67 | 03.DE |
| 03.ED | 68 | 03.DF |
| 03.EE | 69 | 03.E0 |
| 03.EF | 70 | 03.E1 |
| 03.F0 | 71 | 03.E2 |
| 03.F1 | 72 | 03.E3 |
| 03.F2 | 73 | 03.E4 |
| 03.F3 | 74 | 03.E5 |
| 03.F4 | 75 | 03.E6 |
| 03.F5 | 76 | 03.E7 |
| 03.F6 | 77 | 03.E8 |
| 03.F7 | 78 | 03.E9 |
| 03.F8 | 79 | 03.EA |
| 03.F9 | 80 | 03.EB |
| 03.FA | 81 | 03.EC |
| 03.FB | 82 | 03.ED |
| 03.FC | 83 | 03.EE |
| 03.FD | 84 | 03.EF |
| 03.FE | 85 | 03.F0 |
| 03.FF | 86 | 03.F1 |
| 04.00 | 87 | 03.F2 |
| 04.01 | 88 | 03.F3 |
| 04.02 | 89 | 03.F4 |
| 04.03 | 90 | 03.F5 |
| 04.04 | 91 | 03.F6 |
| 04.05 | 92 | 03.F7 |
| 04.06 | 93 | 03.F8 |
| 04.07 | 94 | 03.F9 |
| 04.08 | 95 | 03.FA |
| 04.09 | 96 | 03.FB |
| 04.0A | 97 | 03.FC |
| 04.0B | 98 | 03.FD |
| 04.0C | 99 | 03.FE |
| 04.0D | 100 | 03.FF |

A127
A127_X2523

| | | |
|-------|-----|----------|
| 03.FE | 01 | UB 30 |
| 71.0A | 02 | Earth 31 |
| 03.FE | 03 | UB 30 |
| 03.FE | 04 | UB 30 |
| 03.FE | 05 | UB 30 |
| 03.FE | 06 | UB 30 |
| 03.FE | 07 | UB 30 |
| 03.FE | 08 | UB 30 |
| 03.FE | 09 | UB 30 |
| 03.FE | 10 | UB 30 |
| 03.FE | 11 | UB 30 |
| 03.FE | 12 | UB 30 |
| 03.FE | 13 | UB 30 |
| 03.FE | 14 | UB 30 |
| 03.FE | 15 | UB 30 |
| 03.FE | 16 | UB 30 |
| 03.FE | 17 | UB 30 |
| 03.FE | 18 | UB 30 |
| 03.FE | 19 | UB 30 |
| 03.FE | 20 | UB 30 |
| 03.FE | 21 | UB 30 |
| 03.FE | 22 | UB 30 |
| 03.FE | 23 | UB 30 |
| 03.FE | 24 | UB 30 |
| 03.FE | 25 | UB 30 |
| 03.FE | 26 | UB 30 |
| 03.FE | 27 | UB 30 |
| 03.FE | 28 | UB 30 |
| 03.FE | 29 | UB 30 |
| 03.FE | 30 | UB 30 |
| 03.FE | 31 | UB 30 |
| 03.FE | 32 | UB 30 |
| 03.FE | 33 | UB 30 |
| 03.FE | 34 | UB 30 |
| 03.FE | 35 | UB 30 |
| 03.FE | 36 | UB 30 |
| 03.FE | 37 | UB 30 |
| 03.FE | 38 | UB 30 |
| 03.FE | 39 | UB 30 |
| 03.FE | 40 | UB 30 |
| 03.FE | 41 | UB 30 |
| 03.FE | 42 | UB 30 |
| 03.FE | 43 | UB 30 |
| 03.FE | 44 | UB 30 |
| 03.FE | 45 | UB 30 |
| 03.FE | 46 | UB 30 |
| 03.FE | 47 | UB 30 |
| 03.FE | 48 | UB 30 |
| 03.FE | 49 | UB 30 |
| 03.FE | 50 | UB 30 |
| 03.FE | 51 | UB 30 |
| 03.FE | 52 | UB 30 |
| 03.FE | 53 | UB 30 |
| 03.FE | 54 | UB 30 |
| 03.FE | 55 | UB 30 |
| 03.FE | 56 | UB 30 |
| 03.FE | 57 | UB 30 |
| 03.FE | 58 | UB 30 |
| 03.FE | 59 | UB 30 |
| 03.FE | 60 | UB 30 |
| 03.FE | 61 | UB 30 |
| 03.FE | 62 | UB 30 |
| 03.FE | 63 | UB 30 |
| 03.FE | 64 | UB 30 |
| 03.FE | 65 | UB 30 |
| 03.FE | 66 | UB 30 |
| 03.FE | 67 | UB 30 |
| 03.FE | 68 | UB 30 |
| 03.FE | 69 | UB 30 |
| 03.FE | 70 | UB 30 |
| 03.FE | 71 | UB 30 |
| 03.FE | 72 | UB 30 |
| 03.FE | 73 | UB 30 |
| 03.FE | 74 | UB 30 |
| 03.FE | 75 | UB 30 |
| 03.FE | 76 | UB 30 |
| 03.FE | 77 | UB 30 |
| 03.FE | 78 | UB 30 |
| 03.FE | 79 | UB 30 |
| 03.FE | 80 | UB 30 |
| 03.FE | 81 | UB 30 |
| 03.FE | 82 | UB 30 |
| 03.FE | 83 | UB 30 |
| 03.FE | 84 | UB 30 |
| 03.FE | 85 | UB 30 |
| 03.FE | 86 | UB 30 |
| 03.FE | 87 | UB 30 |
| 03.FE | 88 | UB 30 |
| 03.FE | 89 | UB 30 |
| 03.FE | 90 | UB 30 |
| 03.FE | 91 | UB 30 |
| 03.FE | 92 | UB 30 |
| 03.FE | 93 | UB 30 |
| 03.FE | 94 | UB 30 |
| 03.FE | 95 | UB 30 |
| 03.FE | 96 | UB 30 |
| 03.FE | 97 | UB 30 |
| 03.FE | 98 | UB 30 |
| 03.FE | 99 | UB 30 |
| 03.FE | 100 | UB 30 |

10 Earth layout – Sheet 10

- A007** - Instrument panel (Item A7)
- A013** - PCB, microfuses (Item A8)
- A050** - Basic control ECU (Items A4 and A5)
- A077** - Immobiliser ECU (Item A7)
- A082** - Nitrogen oxide NOx sensor 1, upstream of SCR (Item A2)
- A083** - Nitrogen oxide NOx sensor 2, downstream of SCR (Item A2)
- A100** - MFA, multifunction armrest (Item C8)
- A103** - Terminal NT01/02 (Item A8)
- A111** - Central electrical system ECU (Item A6)
- A127** - Engine control ECU (EDC 17) (Item A1)
- A128** - Control panel, right/left dashboard (Item A6)
- G001** - Battery 1 (Item F1)

- X2184** - Separation point on A100 (Item D8)
- X4001** - Operator platform/front right chassis cable coupling (Item C3)
- X4046** - Operator platform/front left chassis cable coupling (Item C3)
- X4111** - EXT earth connector (Item C5)
- X4112** - Sensor system earth connector (Item B3)
- X4113** - Sensor system earth connector (Item B3)
- X4114** - Sensor system earth connector (Item A3)
- X4115** - Earth connector (Item C6)
- X4225** - Sensor system earth connector (Item D4)
- X4227** - Sensor system earth connector (Item D3)
- X4228** - Sensor system earth connector (Item D4)
- X4229** - Sensor system earth connector (Item D3)
- X4240** - Sensor system earth connector (Item D3)
- X4241** - Sensor system earth connector (Item D2)
- X5000** - Cab earth point (Item E7)
- X5001** - Cab earth connector (Item D8)
- X5002** - Cab earth connector (Item D8)
- X5003** - Cab earth connector (Item E8)
- X5004** - Cab earth connector (Item E8)
- X5005** - Cab earth connector (Item E8)
- X5006** - Earth connector (Item E8)
- X5010** - Earth point on right of operator platform (Item E7)
- X5011** - Earth point on right of operator platform (Item E6)
- X5012** - Earth point on right of operator platform (Item E6)
- X5013** - Earth point on left of operator platform (Item E5)
- X5014** - Earth point on right of operator platform (Item E6)
- X5015** - Earth point on left of operator platform (Item E5)
- X5016** - Frame earth point (Item F2)
- X5017** - Cab aerial earth point (Item E8)
- X5020** - Engine earth point (Item F5)
- X5026** - Frame earth point (Item F4)
- X5027** - Frame earth point (Item F2)
- X5028** - Frame earth point (Item F3)
- X5029** - Frame earth connector (Item F3)
- X5030** - Frame earth connector (Item E3)
- X5031** - Frame earth connector (Item E3)
- X5032** - Frame earth connector (Item E3)
- X5033** - Frame earth connector (Item E3)
- X5034** - Frame earth point (Item F4)
- X5035** - Frame earth connector (Items B1 and E4)
- X5036** - Frame earth connector (Item E4)
- X5037** - Frame earth connector (Item F4)
- X5039** - Earth connector (Item E3)
- X5045** - Frame earth connector (Item E3)
- X5079** - Outer operator platform earth point (Item E4)

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL