

Model W14H Articulated Loader

Parts Catalog

1268

Reprinted

CASE


CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL


- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below







- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.


CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL















ISSUED APRIL, 1973


INSTRUMENT PANELS AND GAUGES VIEWED FROM BACK SIDE



B TO FRONT FLOOD AND DRIVING LIGHTS—PAGE 57








CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL


- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below





- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.


CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL




































1



11



5

SAFETY LINK
 ENGAGE LINK FOR LOCKING
 MACHINE IN STRAIGHT-
 AHEAD POSITION ONLY!

8

TRANSMISSION OIL LEVEL
 CHECK OIL LEVEL WITH ENGINE AT
 IDLE AND TRANS. AT OPERATING TEMP.
 OBSERVE ADD AND FULL MARKINGS.
 DO NOT OVER FILL!




9

SHUT OFF AIR VALVE THEN
 UNSCREW FILLER DIP STICK
 SLOWLY FOR DAILY CHECK

6



⚠ DANGER
 KEEP CLEAR OF THIS AREA
 WHEN ENGINE IS RUNNING



7

DRAIN AIR TANK DAILY

↓



MODEL W14H ARTICULATED LOADER

NUMERICAL INDEX

PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.	PART NO.	PAGE NO.	REF. NO.
L 35330	209	12	L 35806	165B	18	L 47724	91	
L 35331	209	10	L 35919	97	35	L 47787	157	13
L 35332	213	13	L 35919	101	35	L 47816	199	8
L 35333	213	10	L 35925	95		L 47816	199	14
L 35334	215	9	L 35925	99		L 47816	201	9
L 35334	215	18	L 35926	99		L 47816	201	14
L 35334	215	30	L 35928	95		L 47832	89	50
L 35340	197	17	L 35928	99		L 47901	87	31
L 35341	197		L 35929	101		L 47938	51	7
L 35342	197		L 35930	101		L 47997	157	18
L 35343	197	12	L 35931	97	39	L 47998	199	12
L 35344	197		L 35931	101	39	L 47998	201	12
L 35345	197	4	L 35932	95		L 48002	63	5
L 35347	131		L 35933	95		L 48003	63	3
L 35348	131	10	L 35933	99		L 48004	63	1
L 35349	131	6	L 35934	95	9	L 48006	87	2
L 35350	131	3	L 35934	99	9	L 48006	137	4
L 35386	205	3	L 35952	107		L 48011	87	6
L 35386	207	4	L 35973	77	2A	L 48020	87	16
L 35386	215		L 35973	77	13A	L 48024	63	13
L 35399	65	27	L 35974	77	2	L 48025	127	26B
L 35408	115	2	L 35974	77	13	L 48026	127	37
L 35409	115	1	L 35977	105	41	L 48027	63	9
L 35410	119	58	L 35984	59	5	L 48029	111	3
L 35411	119	64	L 35985	59	8	L 48042	149	28
L 35474	197		L 36055	77	3	L 48042	149B	35
L 35486	107	4	L 36056	77	12	L 48046	163	2
L 35508	69	3	L 36058	77	7	L 48061	123	38
L 35533	71	2	L 36059	79		L 48104	63	16
L 35534	75	15	L 36060	79B	43	L 48106	171	21
L 35535	71	11	L 36061	79	25	L 48119	47	2
L 35635	131		L 36062	79B	44	L 48120	111	34
L 35676	139		L 36063	79B	45	L 48124	171	26
L 35712	175	25	L 40280	59	25	L 48127	111	42
L 35713	175	25	L 40314	87	35	L 48127	133	
L 35717	165D	5	L 40315	87	36	L 48128	123	24
L 35732	165B	44	L 40793	51	8	L 48128	133	
L 35737	165B	22	L 41692	61		L 48129	127	30
L 35738	165B	21	L 43738	161		L 48129	133	
L 35743	165B	3	L 43738	163	5A	L 48131	113	29
L 35748	165B	32	L 43856	203	11	L 48137	123	20
L 35753	165B	6	L 44173	111	1	L 48191	127	16
L 35759	165B	45	L 44173	123	14	L 48193	127	5
L 35767	205	6	L 44173	127	1	L 48196	127	18
L 35767	207	11	L 44173	129		L 48237	157	26
L 35767	209		L 46279	61	9	L 48238	157	27
L 35768	209	27	L 46411	115		L 48249	157	31
L 35789	165B	46	L 46479	147	16	L 48388	183	16
L 35790	165B	7	L 46484	159		L 48438	157	9
L 35791	165B	8	L 46821	43	13	L 48480	47	50
L 35792	165B	13	L 47141	83		L 48480	111	32
L 35793	165B	14	L 47141	83	7	L 48484	159	18
L 35794	165B	15	L 47157	153	24	L 48485	159	19
L 35795	165B	16	L 47158	153	25	L 48503	159	14
L 35796	165B	19	L 47159	153	19	L 48529	83	17
L 35797	165B	20	L 47224	147	20	L 48558	85	14
L 35798	165B	42	L 47270	47	41	L 48573	159	23
L 35799	165B	43	L 47277	51	42	L 48624	203	14
L 35800	165B	31	L 47277	57	20	L 48674	63	2
L 35801	165B	47	L 47468	185	18	L 48760	151	32
L 35802	165B	35	L 47468	187	18	L 48782	53	66
L 35803	165B	17	L 47502	137	2	L 48820	43	18
L 35804	165B	26	L 47619	111	13	L 48838	189	10
L 35805	165B	27	L 47700	175	14	L 48916	91	10

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL