

Spare Parts Catalogue

4812157997.pdf

Valid from roller serial number:

10000149x0A009649 -



Diesel engines:

Cummins QSB 4.5 (III A/T3)

Published catalogue issues valid for these rollers:

<i>Catalogue</i>	<i>Issue date</i>	<i>Valid for serial numbers</i>
4812157997.pdf	2012-07	10000149x0A009649 -



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

TABLE OF CONTENTS

Page

Connector kit	276
Connector kit	278
Hydraulic system, steering	280
Hydraulic cylinder	282
4812113826 Hydraulic cylinder	284
Steering valve module	286
Hydraulic hoses, steering	288
Emergency steering valve module	290
4812110361 Steering valve	292
Hydraulic system, engine room	294
Hydraulic pump module	296
4812112170 Hydraulic pump, propel pump	298
Front section	300
Rear section	302
Hydraulic pump module	304
Hydraulic oil filter assy	306
Hydraulic pump module	308
4812110927 Hydraulic pump	310
Hydraulic system, engine room Adjustable frequency, eco opti	312
Hydraulic pump module	296
4812112170 Hydraulic pump, propel pump	298
Front section	300
Rear section	302
Hydraulic pump	314
Hydraulic oil filter assy	306
Hydraulic pump module	308
4812110927 Hydraulic pump	310
Hydraulic pump module	316
4812112192 Hydraulic pump	318
Electric equipment	320
Electric cables, power supply, 1-pole	322
Battery module	324
Battery disconnecter module	326
Electric cables, power supply, 2-pole, option	328
Battery module	324
Battery disconnecter, 2-pole	330
Electrical cables, engine - ECU Horn, back-up alarm	332
Standard ECU assembly	334
Power converter module	336
Inclination sensor module	338
Back-up alarm module	340
Back-up alarm module	342
Horn module	344
Bracket module	346
Driving & side direction lights, number plate light, option	348

4812156993 Service kit, 50h incl. oil

Item	Part No	Rem Qty	Description	Code
	4812156993		Service kit, 50h incl. oil (Page 6)	A
5	4812112262	1	Hydraulic oil filter element	A
15	4812156456	1	Dynapac drum oil 1000 5l	A
16	4812030756	1	Gear Oil 300 / 5 ltr.	

4812158370 Service kit, up to 1000h Cummins QSB 4.5

Item	Part No	Rem Qty	Description	Code
	4812158370		Service kit, up to 1000h Cummins QSB 4.5 (Page 16)	
1	4812156993	1	Service kit, 50h incl. oil (Page 6)	A
2	4812158281	1	Service kit, 500h incl. oil Cummins QSB 4.5 (Page 8)	
3	4812158282	1	Service kit, 1000h incl. oil Cummins QSB 4.5 (Page 12)	

4812157275 Drum rotation kit

Item	Part No	Rem Qty	Description	Code
1	4700116041	1	Taper roller bearing	B
2	4700167023	1	Seal ring	B
3	4700929447	1	V-ring	B
4	4700160105	1	O-ring 70	C

Frame, front

Item	Part No	Rem Qty	Description	Code
1	4812113505	1	Side plate	
2	4812113506	1	Side plate	
3	4700904233	70	Washer 21x36x3	C
4	4700500284	14	Screw	D
5	4700927411	16	Screw	D
6	4700925208	32	Screw M20x90	D
7	4812112159	1	Ballast weight	D
8	4700500287	8	Screw M20x80 10,9	C
9	4812114179	1	Cross beam	
11	4812112898	1	Cross beam	
12	4812112162	2	Cover	
13	4700904228	4	Washer 6,4x12x1,5	C
14	4700232041	2	Filter plug	D
15	4700500013	4	Screw M6-1x16 8,8	C
16	4700629064	1	Spring pin, slotted	
17	4812113132	1	Steering hitch, cpl (Page 38)	D
18	4700904230	11	Steel plain washer	C
19	4700500028	4	Screw	C
20	4812113607	2	Bracket	
21	4700500028	4	Screw	C
22	4812113885	1	Protective hood	
23	4700902166	A 1XL	Edge trim	D
24	4700500161	3	Hexagon head screw	C
25	4700377742	2	Reflector, red	D
26	4700791396	2	Plug	C

A) L = 0.315m

Scraper module Hardox, Static linear load high

Item	Part No	Rem Qty	Description	Code
1	4812111020	1	Scraper, hardox	B
3	4812111103	2	Holder	C
4	4700904558	4	Washer 17X30X6 300HV	C
5	4700500102	4	Screw M16x45	D

Scraper module PD Hardox

Item	Part No	Rem Qty	Description	Code
1	4812115673	1	Scraper tooth	B
2	4812111103	1	Holder	C
3	4700904558	2	Washer 17X30X6 300HV	C
4	4811000109	2	Screw	D

Frame, rear

Item	Part No	Rem Qty	Description	Code
1	4812114270	1	Frame, rear	
2	4700151021	4	Snap ring	B
3	4700792611	2	Radial spherical plain bearing	D
4	4700202057	A 1XL	Edge trim	D
5		1	Cover assembly (Page 68)	
6	4700389857	3	Threaded plate	D
7	4700513012	6	Screw M6x20 10,9	D
10	4700377744	2	Reflector, yellow	D
11	4812111010	1	Cover plate	D
12	4700904557	12	Steel plain washer	C
13	4700500031	6	Screw M10x040 8.8	C
14	4812112439	1	Protective plate	D
15	4700500161	6	Hexagon head screw	C
16		1	Articulated Joint Module (Page 70)	B
17	4700500239	1	Screw M8x50H 8,8	C
18	4700570005	1	Nut M8	C
19	4812113904	1	Cover plate	D
20	4700901832	2	Screw	C
29	4700926215	5	Protective plug	C

A) L = 1.83m

Tool box module, Option

Item	Part No	Rem	Qty	Description	Code
1	4812114756		1	Tool box	
2	4700903615	A	1XL	Rubber strip	D
3	4700372658		1	Lock	D
4	4700394536		1	Wiring clip	D
5	4700624018		2	Blind rivet	D
6	4700358881		1	Pad lock	D
7	4700902041		3	Screw M8 x 25	
8	4700355889		1	Tool set Cpl	D

A) L=0.48m

Fender module

Item	Part No	Rem Qty	Description	Code
1	4812115231	1	Fender	
2	4812115232	1	Fender	
3	4812115233	1	Fender	
4	4812115234	1	Fender	
5	4812115022	2	Bracket	D
6	4812115722	2	Bracket	D
7	4812115723	2	Bracket	D
8	4812116308	2	Bracket	
9	4700500031	6	Screw M10x040 8.8	C
10	4700615061	16	Steel plain washer	C
11	4700500509	22	Hexagon screw with flange	D
12	4700615050	4	Washer	C
13	4700500021	4	Screw M8-1,25x25 8.8	C
14	4700586018	5	Hexagon lock nut M10	C
16	4700904230	11	Steel plain washer	C

Safety link module

Item	Part No	Rem Qty	Description	Code
1	4812112736	1	Safety link	
2	4812112952	1	Spacer	C
3	4812112950	1	Control wire	D
4	4812112951	1	Holder	D
5	4811000462	1	Compression spring	D
6	4700904230	1	Steel plain washer	C
7	4700500031	1	Screw M10x040 8.8	C
8	4700904735	1	Washer	C
9	4700500040	1	Screw M6-1x20 8,8	C

Tooth wheel module

Item	Part No	Rem Qty	Description	Code
1	4812114223	1	Wheel	D
2	4700349715	1	Spring	D
3	4700340863	1	Splined sleeve	D
4	4812113832	1	Washer	
5	4700502053	1	Screw	D
7	4812030096	N	Dynapac Roller Grease	A

4812158087 Drum cartridge, drive side (D, comp. data high)

Item	Part No	Rem Qty	Description	Code
1	4812112784	1	Housing	D
2	4812111122	1	Bearing housing	D
3	4700390896	2	Spherical roller bearing	B
4	4700900776	1	O-ring	D
5	4700904232	12	Washer	C
6	4700500082	12	Screw M16x70 8,8	D
7	4700900775	6	Plug	C
8	4700162017	2	Seal ring	B
9	4700343744	2	Magnetic plug	C
11	4700162027	6	Sealing	B
12	4700500163	6	Screw M12x16	D
13	4700900782	1	Seal ring	D
15	4700900776	1	O-ring	D
16	4700922552	1	Oil level glass	B
18	4812114324	1	Eccentric shaft	D
19	4700380018	1	Splined shaft	D
20	4700791156	8	Screw M10-1,5x55 12,9	D

Diesel engine

Item	Part No	Rem Qty	Description	Code
1	4812113480	1	Diesel engine Cummins QSB4.5 119kW - 3A	
	4812116424	1	Diesel engine Cummins QSB4.5 119kW - 3A	
	4812116425	1	Diesel engine Cummins QSB4.5 119kW - 3A	
2	4700945624	1	. Fuel filter element	
3	4700945145	1	. Oil filter element	A
4	4812158083	C 1	. V-belt	
5	4700945768	1	. Alternator	C
6	4700945767	1	. Starter	C
7	4812158064	2	. Sensor, Position	
8	4700950140	1	. Pressure sensor	
9	4700940533	1	. Oil pressure switch	
10	4812158065	1	. Sensor, Prs temperature	
11	4700945887	1	. Sensor, Water temp	C
12	4700945770	1	. Oil dipstick	
13	4700945147	1	. Pre-fuel filter element	
14	4812158196	1	. Fuel filter head	

C) Without AC/ACC installation. For AC/ACC see section for optional equipment.

Hose assy kit

Item	Part No	Rem Qty	Description	Code
1	4812115539	1	Coolant hose	
2	4812113195	1	Cooler hose	
3	4700921050	2	Clamp	C
4	4700313004	1	Hose clamp	D
5	4700313010	4	Hose clamp	C
6	4700904352	5	Clamp	
7	4700902286	8	Hexagon lock nut with flange	C
8	4700923008	1	Clamp	D
9	4700904230	1	Steel plain washer	C
10	4700500048	1	Screw M10-1,5x20 8,8	C
11	4812116107	1	Holder	
12	4812114150	1	Cooler hose	

Fuel tank

Item	Part No	Rem Qty	Description	Code
1	4812112357	1	Fuel tank	D
2	4812114949	1	Gasket	D
3	4812114813	1	Adapter	C
4	4812114935	1	Level sensor	C
5	4700904281	5	Washer 5,3x10x1 300HV	C
6	4700904206	8	Screw	C
7	4700513012	5	Screw M6x20 10,9	D
8	4700378589	2	Gasket	D
9	4812112653	2	Fuel pipe	D
10	4700904698	10	Washer 4,3x8x0,8	C
11	4700903236	10	Screw, Thread rolling K40x20	C
12	4812112655	2	Flange gasket	D
13	4812112656	1	Flange connection	D
14	4812114909	1	Fuel hose	C
15	4700313033	2	Hose clamp	D
17	4700500009	5	Hexagon head screw	
19	4812112729	1	Rubber cloth	
20	4700395785	3	Expansion rivet	D

Fuel tank module

Item	Part No	Rem Qty	Description	Code
1		1	Fuel tank (Page 158)	
2		1	Brackets assy (Page 148)	
3	4700904229	8	Steel plain washer 8,4x16x1,5	C
4	4700500024	16	Screw M8x45	D
5	4700904640	16	Washer 8,4x22x3	C
6	4700500021	8	Screw M8-1,25x25 8.8	C

Transmission

Item	Part No	Rem Qty	Description	Code
1		1	Rear axle and wheels (Page 168)	

Hub reduction

Item	Part No	Rem Qty	Description	Code
1		2	. Snap ring	
2		2	. Bush	
3		2	. Half shaft	
4		2	. Half shaft	
5		1	. Seal ring	
6	4812158476	2	. Bearing	
7	4812158477	2	. Wheel hub kit	
8	4812158478	20	. . Stud	
9		2	. O-ring	
10		2	. Spacer	
11		2	. Crown gear	
12		2	. Lock ring	
13		6	. Bolt	
14		2	. Ring nut	
15		2	. Locking plate	
16		2	. Wheel carrier	
17		12	. Washer	
18		12	. Nut	
19		2	. Planetary carrier assy	
20		4	. Bolt	
21	4812158479	2	. Plug	
22		12	. Snap ring	
23		12	. Thrust washer	
24	4812158480	6	. Rollers bearing	
25		6	. Gear	
26		6	. Thrust washer	
27		6	. Snap ring	

Hydraulic system

Item	Part No	Rem Qty	Description	Code
1		1	Hydraulic system, drum Traction control (Page 188)	
2		1	Hydraulic system, drum Anti-spin system (Page 206)	
3		1	Hydraulic system, drum Traction control, static linear load high (Page 218)	
4		1	Hydraulic system, drum Anti spin system, static linear load high (Page 220)	
5		1	Hydraulic system, rear axle Traction control, limited slip (Page 222)	
6		1	Hydraulic system, rear axle Traction control, no slip (Page 234)	
7		1	Hydraulic system, rear axle Anti-spin system (Page 242)	
8		1	Hydraulic system, rear axle Dual speed (Page 252)	
9		1	Hydraulic system, oil tank Up to 0A009752 (Page 258)	
10		1	Hydraulic system, oil tank From 0A009753 (Page 272)	
11		1	Hydraulic system, frame rear (Page 274)	
12		1	Hydraulic system, steering (Page 280)	
13		1	Hydraulic hoses, steering (Page 288)	
14		1	Emergency steering valve module (Page 290)	
15		1	Hydraulic system, engine room (Page 294)	
16		1	Hydraulic system, engine room Adjustable frequency, eco opti (Page 312)	

Flush & boost pressure valve with orifice

Item	Part No	Rem	Qty	Description	Code
1	4812158169		1	. Flush & boost pressure valve with orifice	
2			1	.. Housing piston	
3			1	.. Flushing piston	
4			1	.. Valve piston	
5			2	.. Locking screw	
6			1	.. Locking screw	
7			2	.. Washer	
8			2	.. Pressure spring	
9			1	.. Pressure spring	
15			4	.. Socket head screw	
16			2	.. Locking screw	
18	4812157460	A	1	.. O-ring	
19	4812157170	A	2	.. O-ring	
20	4812157184	A	1	.. O-ring	
21	4812157185	A	2	.. O-ring	
22			1	.. Retaining ring	
24			1	.. Shim	
30	4812158172		1	.. Orifice	

A) Included in seal kit.

Hydraulic system, drum Anti-spin system

Item	Part No	Rem Qty	Description	Code
1		1	Hydraulic motor (Page 190)	
2		1	Hydraulic motor (Page 208)	
3	4812114684	1	Hydraulic hose	C
4	4812114685	1	Hydraulic hose	C
5	4812114686	1	Hydraulic hose	C
6	4812114671	1	Hydraulic hose	C
7	4812114670	1	Hydraulic hose	C
8	4812114672	1	Hydraulic hose	C
9	4812114673	1	Hydraulic hose	C
10	4811000416	1	Straight connector orfs	D
11	4812117326	1	Cable tie holder	D
12	4700904229	7	Steel plain washer 8,4x16x1,5	C
13	4700500019	1	Hexagon head screw M8x16H 8,8	C
14	4812117915	2	Bracket	
15	4700500022	6	Screw M8x30H 8.8	C
16	4812112304	4	Hose holder	
17	4700791860	24	Stud	D
18	4700902286	24	Hexagon lock nut with flange	C
19	4812113963	2	Bracket	
20	4700904230	4	Steel plain washer	C
21	4700500028	8	Screw	C
22	4812113569	2	Bracket	
23	4812112306	6	Hose holder	
24	4700904557	4	Steel plain washer	C
25	4812117325	1	Cable tie	
26	4812117015	2	Hose holder	
27	4812116857	2	Hose holder	

Drum motor. Rear section

Item	Part No	Rem Qty	Description	Code
1		1	Synch shaft assembly	
2		1	Cylinder block assembly	
3	4812157056	1	Bearing plate	
4		1	Shaft assembly, 14 tooth, DIN, speed ring	
5		1	Housing, cartridge with speed sensor port	
6	4812157058	1	Lip seal	
7	4812157059	1	Retaining ring	
8		2	Pin	
9		1	Plug assembly	
10		1	O-ring	
11		2	Plug assembly	
12		2	O-ring	
13	4812157064	1	Gasket	
14	4812157073	1	Speed sensor	
15	4812157057	1	O-ring	
16		1	Screw	
17		1	Set screw, 0-19 cc, M12x65mm	
18	4700909525	1	Seal nut	
19	4700902996	1	Plastic cap, green	

4812112208 Rear axle motor

Item	Part No	Rem Qty	Description	Code
1		1	. Front section (Page 228)	
2		1	. Rear section (Page 230)	
3	4812158273	1	. Seal kit, cpl	

Hydraulic motor

Item	Part No	Rem Qty	Description	Code
1	4812112211	1	Rear axle motor (Page 238)	
2	4700904005	2	O-ring	B
3	4700923384	4	Flange half	C
4	4700904638	8	Washer 12x22x2	C
5	4700928791	8	Screw	D
6	4700791231	1	Elbow 90°	D
7	4700160043	1	O-ring	D

4812112210 Rear axle motor

Item	Part No	Rem Qty	Description	Code
1		1	. Front section (Page 248)	
2		1	. Rear section (Page 250)	
3	4812158153	1	. Seal kit,cpl	

4812112207 Axle motor

Item	Part No	Rem Qty	Description	Code
	4812112207	1	Axle motor (Page 256)	
1		3	. Screw	
2		1	. Retainer plate	
3		1	. Seal assy	
4	4700901327	1	. . Lip seal	
5	4700935633	1	. . O-ring	
6		1	. Retaining ring	
7	4700901465	1	. Roller bearing	
8	4812158456	1	. Shaft 14 tooth spline	
9		2	. Plug assy	
10		2	. . O-ring	
11		1	. Housing	
12		2	. Pin	
13		1	. Plug assy	
14		1	. . O-ring	
15		1	. Thrust plate	
16	4812158454	1	. Cylinder block kit	
17		9	. . Piston assy	
18		1	. . Slipper guide	
19		1	. . Slipper guide retainer	
20		1	. . Slipper guide retainer spacer	
21		1	. . Cylinder block assy	
22		1	. . . Spring seat	
23		1	. . . Cylinder block spring	
24		1	. . . Spring retainer	
25		1	. . . Retaining ring	
26		1	. Hold down tube	
27	4700935626	1	. Valve plate	
28	4812158453	1	. End cap gasket	
29		1	. End cap assy, twin ports	
30	4812158455	1	. . Journal bearing	
31		2	. . Plug assy	
32		2	. . . O-ring	
33		1	. . Plug assy	
34		1	. . . O-ring	
35		1	. Loop flushing spool	
36		2	. Spring guide assy	
37		2	. . Spring guide	
38		2	. . Spring	
39		2	. Plug assy	
40	4700923087	2	. . O-ring	C
41		1	. Plug assy	
42		1	. . O-ring	
43		1	. Screw	
44		4	. Screw	
45	4700937283	1	. Seal kit, cpl	

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Connector assy

Item	Part No	Rem Qty	Description	Code
1	4812113237	1	Bracket	
2	4812113338	1	Bracket	
3	4700791807	4	Stud	D
4	4700287295	8	Clamp	D
5	4700904872	4	Cover plate	D
6	4700902286	4	Hexagon lock nut with flange	C
7	4700904230	2	Steel plain washer	C
8	4700500029	2	Hexagon head screw	C
9	4700904229	2	Steel plain washer 8,4x16x1,5	C
10	4700500053	2	Screw M8x20H 8.8	C
11	4700923008	1	Clamp	D
12	4700904735	1	Washer	C
13	4700904228	1	Washer 6,4x12x1,5	C
14	4700570004	1	Nut M6X1,00 -8 A2K	C
15	4700500040	1	Screw M6-1x20 8,8	C
16	4812113941	4	Hose holder clip	D

Connector kit

Item	Part No	Rem Qty	Description	Code
1	4812111768	1	Hydraulic block	
2	4700792339	6	Straight connector orfs	D
3	4700791212	4	Elbow 45°	C
4	4812111771	2	Hose holder	
5	4812111770	1	Holder	
6	4812114492	1	Bulkhead union	
7	4700904229	4	Steel plain washer 8,4x16x1,5	C
8	4700500019	2	Hexagon head screw M8x16H 8,8	C
9	4700500090	2	Screw	C
10	4700904556	2	Washer 8,4x16x3,0	C
11	4700500022	2	Screw M8x30H 8.8	C

Steering valve module

Item	Part No	Rem Qty	Description	Code
1	4812112290	1	Steering valve	D
4	4812115063	2	Elbow connector 90°	C
5	4811000074	2	Straight connector orfs	D
6	4812115064	2	Elbow connector 90°	C
7	4812115065	1	Elbow connector 90°	C

Hydraulic pump module

Item	Part No	Rem Qty	Description	Code
1	4812112170	1	Hydraulic pump, propel pump (Page 298)	
2	4700500194	4	Screw	C
3	4700904703	4	Washer	B
4	4812115051	1	Straight connector orfs	
5	4700791213	1	Flange fitting 90	D
6	4700900229	3	Measuring nipple	C
7	4812112560	1	Straight connector orfs	
8	4812112561	1	T-adapter	
9	4700923384	4	Flange half	C
10	4700904005	2	O-ring	B
11	4700904638	8	Washer 12x22x2	C
12	4700928791	8	Screw	D
13	4700904496	1	Connector	C
14	4812115965	1	Flange fitting 90	

Hydraulic oil filter assy

Item	Part No	Rem Qty	Description	Code
1	4812112260	1	Hydraulic oil filter	C
	4812112262	1	. Hydraulic oil filter element	A
2	4700904230	4	Steel plain washer	C
3	4700500048	4	Screw M10-1,5x20 8,8	C
4	4812118650	1	Bracket	D
6	4700792339	2	Straight connector orfs	D
7	4700904229	3	Steel plain washer 8,4x16x1,5	C
8	4700508092	3	Screw	C

Hydraulic pump module

Item	Part No	Rem Qty	Description	Code
1	4812112192	1	Hydraulic pump (Page 318)	
2	4700904231	2	Washer 13x24x2 300 HV	C
3	4700500046	2	Screw M12x025H	C
4	4700791231	1	Elbow 90°	D
5	4812113633	1	Flange connector	
6	4700904774	1	O-ring	D
7	4700508048	4	Hexagon socket head cap screw	C
8	4700904586	1	Elbow 45°	C
9	4812113621	1	Hydraulic block	
10	4812114189	1	Straight connector orfs	
11	4700904171	1	O-ring	C
12	4700904637	4	Washer	C
13	4700508060	2	Screw	D
14	4700508014	2	Screw M10x60	D

Battery disconnecter module

Item	Part No	Rem	Qty	Description	Code
1	4812116861		1	Holder	
2	4700903640		1	Battery switch	D
3	4812111981		1	Fuse holder	
4	4812112000		2	Fuse holder	
5	4700792441		2	Cable tie with holder	C
6	4700904229		4	Steel plain washer 8,4x16x1,5	C
7	4700508019		2	Screw M8x25 8.8	C
8	4700904228		8	Washer 6,4x12x1,5	C
9	4700500040		4	Screw M6-1x20 8,8	C
10	4700586002		6	Lock nut M6 -8	C
11	4700586003		2	Lock nut M8	C
12	4700792310	B	1	Relay 120A	
13	4700792309	A	1	Relay 50A	D
14	4700500075		2	Screw M6-1,0x25 8.8	C
15	4700904556		2	Washer 8,4x16x3,0	C
16	4700500019		2	Hexagon head screw M8x16H 8,8	C

A) Starter relay.

B) Grid heater relay.

Power converter module

Item	Part No	Rem Qty	Description	Code
1	4812112017	1	Power converter	
2	4700792210	3	Screw torx	
3	4700901227	1	Fuse 10A	A

Bracket module

Item	Part No	Rem Qty	Description	Code
1	4812117149	1	Bracket	
2	4700904228	2	Washer 6,4x12x1,5	C
3	4700500012	2	Screw M6x12	C

Registration plate light

Item	Part No	Rem Qty	Description	Code
1	4700355797	1	Licence plate holder	
2	4700929455	1	Licence plate light	D
3	4700792354	1	Bulb 24V 5W	
4	4700792035	2	Push-on terminal	

Holder

Item	Part No	Rem Qty	Description	Code
1	4700395888	1	Bracket	
2	4700394542	1	Ball joint	
3	4700904228	4	Washer 6,4x12x1,5	C
4	4700500040	4	Screw M6-1x20 8,8	C

Rotating beacon

Item	Part No	Rem Qty	Description	Code
1	4812116622	1	Bracket	
2	4812112460	1	Bracket	
3	4700392321	1	Bracket	
4	4812115020	1	Cable harness	
5	4700792410	1	Star knob M8-50	
6	4700904640	1	Washer 8,4x22x3	C
7	4700902286	1	Hexagon lock nut with flange	C
8	4700904229	2	Steel plain washer 8,4x16x1,5	C
9	4700500189	1	Screw	C
10	4812112774	2	Bushing	

Heater

Item	Part No	Rem Qty	Description	Code
1	4700396041	1	Heater	
2	4700500006	1	Screw M5x16	
3	4700586001	1	Lock nut	C
4	4700791304	1	Washer	C
5	4700901688	1	Washer	
6	4700500053	1	Screw M8x20H 8.8	C

Holder assy

Item	Part No	Rem	Qty	Description	Code
1	4812112836	A	1	Holder	
	4812118641		1	Holder	
2	4812112837		1	Holder	
3	4812112838		1	Cover	
4	4700904735		3	Washer	C
5	4700500013		3	Screw M6-1x16 8,8	C
6	4700904698		4	Washer 4,3x8x0,8	C
7	4700500002		4	Screw M4-0,7x12H 8.8	D
8	4812118624		1	Mounting frame	

A) Can be replaced by p/n 4812118641, 4812118624 and 4812118625.

Platform, rops

Item	Part No	Rem Qty	Description	Code
1	4812112277	1	Platform with 4-post ROPS (Page 408)	
2	4812112294	4	Bracket	
3	4700359998	4	Back-up ring	C
4	4700500195	16	Screw	C
5	4812115387	2	Protective plug	
6	4700374606	4	Shock absorber Green	D
7	4700372457	4	Back-up ring	C
8	4700904233	6	Washer 21x36x3	C
9	4700903290	2	Washer 21x36x6	C
10	4700901145	4	Lock nut M20-10	
11	4700903633	4	Screw M20x150 10,9	
12		1	Manual box (Page 418)	

Cab, basic kit

Item	Part No	Rem	Qty	Description	Code
1	4700792103		10	Blind insert nut	D
2	4700902379	A	2XL	Edge trim	
4	4812115186		1	Cover	
5	4700929587		7	Grommet	
6	4700909129		2	Grommet	
7			1	Grommet	
8			1	Sign, rops	
9			4	Screw	
10			1	Sign, fops	
11			4	Screw	
A)	L=0.263m				

4812115202 Cab door, cpl

Item	Part No	Rem	Qty	Description	Code
1	4812116199		1	Door	
2		A	1XL	Sealing strip	
3	4812115200		1	Sliding screen, left hand (Page 428)	
4	4812114593		1	Screen	
5	4812115203		1	Handle	
6	4812115204		1	Washer	
7	4812115205		1	Washer	
8	4812115206		1	Washer	
9	4812115207		1	Bushing	
10	4812115216		2	Hinge	
11			4	Washer	
12	4812115217		2	Pin	
13			2	Lubricating nipple	
14			6	Screw	
15	4812115218		2	Hinge	
16	4812115214		1	Gas spring	
A)	L=4.41m				

Hose kit heater

Item	Part No	Rem	Qty	Description	Code
1	4812115167		2	Connector	
2	4812115168	A	2XL	Drain hose	
3	4812115169		2	Drain valve	
4	4700205112	B	1XL	Coolant hose	D
5	4700205112	C	1XL	Coolant hose	D
6			1	Foam	
7			1	Grommet	
8	4812115172		2	Connection pipe	
9	4700313004		2	Hose clamp	D
10	4700313041		2	Cable ties L=200 mm	B
11	4700792441		5	Cable tie with holder	C

- A) L=1.96m
B) L=2.831m
C) L=2.5m

Emergency hammer, hook

Item	Part No	Rem Qty	Description	Code
1	4700908505	2	Hook	D
2		4	Screw	
3	4700908507	1	Emergency hammer, hook	D
4		2	Screw	
5	4700908506	1	Emergency hammer	D
6		1	Splint	
7	4700903590	1	Decal "EMERGENCY EXIT"	

Air channel

Item	Part No	Rem	Qty	Description	Code
1	4812114577		1	Air channel	
2		A	2XL	Seal	
3	4812114578		1	Air channel	
4			4	Screw	
5			2	Screw	
6	4812114579		2	Air nozzle	
7	4812114580		1	Cover	
8	4812114581		1	Cover	
9			8	Screw	

A) L=0.195m

Wiper switch, front

Item	Part No	Rem Qty	Description	Code
1	4812115192	1	Switch	
2		1	Plug	

Seat frame adapter module, fixed

Item	Part No	Rem Qty	Description	Code
1	4812110891	1	Spacer	
2	4700500022	8	Screw M8x30H 8.8	C
3	4700904229	8	Steel plain washer 8,4x16x1,5	C

Forward reverse control module

Item	Part No	Rem	Qty	Description	Code
1	4812110886		1	Control box	D
2	4700391396		1	Cover	D
3	4700396662		1	Cover	C
4	4700391420		1	Control handle	D
5	4812113875		1	Control unit	D
6	4812110901		1	Ignition switch	B
	4700940451		1	. Key	D
7	4812114803		1	Membrane switch panel	C
8	4700385599		1	Buzzer	B
9	4700791582		1	Switch, parking brake	B
9-1	4812118697	A	1	Switch, parking brake	
10	4700792414		1	Switch, RPM	D
	4812117490		1	Switch, eco option	
11	4812111979		1	Cable harness	D
	4812118754	A	1	Cable harness	
12	4700392930		1	Junction box	D
13	4812111780		1	Decal	C
14	4700526010		4	Thread rolling screw	C
15	4700904698		8	Washer 4,3x8x0,8	C
16	4700904281		4	Washer 5,3x10x1 300HV	C
17	4700586001		2	Lock nut	C
18	4700500060		2	Screw M5-0,8x20 8.8	C
19	4700904228		3	Washer 6,4x12x1,5	C
20	4700586002		2	Lock nut M6 -8	C
21	4700508017		4	Hexagon socket head cap screw	C
22	4700791588		3	Panel plug	C
23	4700395785		4	Expansion rivet	D
24	4700570004		1	Nut M6X1,00 -8 A2K	C
25	4700902804		5	Plug	C
26	4700791739		1	Emergency stop	B
27	4700791733		1	Fixing collar	C
28	4700791723		2	Connector N/C	B
33	4812114214		1	Cover	D
34	4812114213		2	Lock screw	C
35	4700313041		N	Cable ties L=200 mm	B
36	4700500505		3	Screw M8x20 8.8	C
37	4700388737		1	Potentiometer	B

A) Item 4812118697 used with item 4812118754.

Control panel cover

Item	Part No	Rem Qty	Description	Code
1	4700395947	1	Instrument panel cover	D
3	4700387545	1	Latch	D
4	4700358881	1	Pad lock	D
5	4700904653	2	Screw M5x16 A2-70	C
6	4700904281	4	Washer 5,3x10x1 300HV	C
7	4700586001	2	Lock nut	C
8	4700396670	1	Bracket	D
9	4700904619	2	Blind rivet	C

Decals

Item	Part No	Rem Qty	Description	Code
1		1	Decals (Page 508)	
2		1	Decals (Page 510)	

Fire extinguisher

Item	Part No	Rem Qty	Description	Code
1	4812114804	1	Bracket	
3	4700904229	6	Steel plain washer 8,4x16x1,5	C
4	4700500021	2	Screw M8-1,25x25 8.8	C
5	4700570005	2	Nut M8	C
6	4700500024	2	Screw M8x45	D

Condensor assembly

Item	Part No	Rem Qty	Description	Code
1	4812113032	1	Condensor	
2	4812113025	4	Bracket	
3	4812113177	4	Rubber nut	
4	4700500022	4	Screw M8x30H 8.8	C
5	4700904229	2	Steel plain washer 8,4x16x1,5	C
6	4700904640	2	Washer 8,4x22x3	C
7	4700500022	4	Screw M8x30H 8.8	C
8	4700904556	4	Washer 8,4x16x3,0	C

Compressor module

Item	Part No	Rem Qty	Description	Code
1	4700391621	1	Compressor	
2	4700391622	1	Belt	
3	4700945314	2	Guide ring	
4	4700904229	4	Steel plain washer 8,4x16x1,5	C
5	4700500096	4	Screw	

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL