

# Spare Parts Catalogue

4812157088.pdf

*Valid from roller serial number:*

**10000131x0A007986 -**



*Diesel engines:*

*Deutz TCD 6.1 L6 (IIIB/4i)*

*Published catalogue issues valid for these rollers:*

<i>Catalogue</i>	<i>Issue date</i>	<i>Valid for serial numbers</i>
4812157088.pdf	2011-12	<b>10000131x0A007986 -</b>



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

**TABLE OF CONTENTS**

**Page**

Holder module Registration plate light .....	322
GPS equipment module, option .....	324
Holder .....	326
GPS equipment module .....	328
GPS equipment assy .....	330
Tachograph, option .....	332
Holder module .....	334
Holder assy .....	336
Power supply module .....	338
Speed sensor, frequency sensor, option .....	340
Pulse sensor module .....	342
Pre-heater installation, option .....	344
Rotating beacon, working light .....	346
Rotating beacon module .....	348
Rotating beacon .....	350
Working light module H3 .....	352
Wiring harness, power park, Option .....	354
Regenerating delay, displacement shift .....	356
Compaction meter .....	358
Power supply .....	360
<b>Drivers platform .....</b>	<b>362</b>
Platform, rops .....	364
Platform with 4-post ROPS .....	366
Basic kit Rops, roof, front handrail .....	368
Rear cover .....	370
Handrail .....	372
Cab, basic kit .....	374
Manual box .....	376
Cab symmetric module .....	378
4812112275 Cab, cpl Comfort .....	380
Screens .....	382
4812115202 Cab door, cpl .....	384
4812115200 Sliding screen, left hand .....	386
Windshield wiper .....	388
Roof .....	390
Hose kit heater .....	392
Cab Interior .....	394
Cab cabel harness .....	396
Cab, electrical equipment .....	398
Emergency hammer, hook .....	400
Cab, rear cover .....	402
Cab, front cover .....	404
Floor mat .....	406
Step light, wiper switch .....	408
Cab, basic kit .....	374

**4812156994 Service kit, 500h**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
2	4700950568	2	Fuel filter	A
3	4812031626	1	Pre Fuel filter element	A
4	4700394688	1	Air filter element, main	A
6	4700903942	1	Oil filter element	A

**4812157255 Service kit, 2000h**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
1	4812112262	1	Hydraulic oil filter element	A
2	4700950568	2	Fuel filter	A
3	4812031626	1	Pre Fuel filter element	A
4	4700394688	1	Air filter element, main	A
5	4700394689	1	Air filter element, safety	A
6	4700903942	1	Oil filter element	A
7	4812156456	1	Dynapac drum oil 1000 5l	A
8	4812030117	1	Gear Oil 300 / 20 ltr.	A
9	5580020624	3	Atlas Copco fluid engine 100 5l	A
10	4812030096	1	Dynapac Roller Grease	A
11	9106230330	3	Atlas Copco fluid hydraulic 300 20l	A
12	4812156455	1	V-belt	A
13	4700357138	1	Ventilating filter	A
15	4700922552	2	Oil level glass	B

**Steering hitch kits**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
	4812157779	1	Steering hitch kit, tilt	C
	4812113133	1	_Yoke	
	4812113137	1	_Shaft	D
	4700396588	2	_Sleeve bearing	B
	4700393523	2	_Slide washer	D
_10	4700390542	1	_Disc spring	D
_13	4700393115	1	_Thrust washer	D
_14	4700160277	1	_O-ring	D
_15	4700393218	1	_Back-up ring	C
_16	4700391031	1	_Radial lip-type seal	D
_30	4812030096	1	_Dynapac Roller Grease	A
	4812157780	1	Steering hitch kit, turn	C
	4700390539	2	_Sleeve bearing	B
	4700390541	2	_Slide washer	D
_11	4700390543	2	_Disc spring	D
_19	4700391566	2	_Washer	D
_20	4812113135	4	_Radial lip-type seal	D
_21	4700792611	4	_Radial spherical plain bearing	D
_27	4700167009	2	_V-ring	D
_29	4700151021	2	_Snap ring	B
_30	4812030096	1	_Dynapac Roller Grease	A

**Scraper module**

<b>Item</b>	<b>Part No</b>	<b>Rem</b>	<b>Qty</b>	<b>Description</b>	<b>Code</b>
1	4812111020		1	Scraper, hardox	B
2	4812112614	A	1	Scraper, steel	B
3	4812111103		2	Holder	C
4	4700904558		4	Washer 17X30X6 300HV	C
5	4700500102		4	Screw M16x45	D

A) Replaced by item 1 p/n 4812111020.

**Scraper mount**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
1	4812116617	1	Scraper assy	
2	4812115508	4	Adapter	
3	4700383844	9	Tooth	B
4	4700801631	9	Flexible pin 56,5x40	D
5	4812111103	4	Holder	C
6	4700904558	8	Washer 17X30X6 300HV	C
7	4700947698	8	Screw M16x55 10.9	C

Step module

Item	Part No	Rem Qty	Description	Code
1		1	Step assy ( Page 60 )	D
2	4700904230	4	Steel plain washer	C
3	4700500028	4	Screw	C

**Engine structure**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
1		1	Engine hood module ( Page 70 )	
2		1	Fender module ( Page 72 )	
3		1	Hinge module ( Page 74 )	
4		1	Lock handle module ( Page 76 )	
7		1	Gas spring module ( Page 80 )	
8		1	Safety link module ( Page 82 )	

**4812114363 Lock handle, cpl**

Item	Part No	Rem Qty	Description	Code
1	4812114363	1	Lock handle, cpl ( Page 78 )	
2	4812112403	1	. Lock handle	B
	4700902866	1	. . Key Marked "455"	
3	4812114828	1	. Spacer washer	C
4	4812114827	1	. Holder	D
5	4812114829	1	. Coupling link	D
6	4812114830	2	. Lock lever	D
7	4812112843	2	. Lock lever	D
8	4812114831	1	. Lock nut	D
9	4812112884	2	. Slide plate	
10	4812116793	2	. Thrust washer	D
12	4700792119	2	. Screw	C
13	4812116792	4	. Slide plate	
14	4700500502	4	. Hexagon screw with flange M6 -25	C
15	4700586002	4	. Lock nut M6 -8	C
16	4700630003	1	. Cotter pin	D
18	4812117473	4	. Locking clip for shaft	

## 4812111831 Drum gear, cpl

Item	Part No	Rem Qty	Description	Code
1		13	Screw	
2		2	Oil breather plug	
3		2	Wascher	
4		1	Cover assembly	
5	4812157157	1	O-ring	
6		1	Pad	
7		1	Sun gear	
8		1	1st Red assembly	
9		1	2nd red assembly	
10		5	Circlip	
11		5	Planetary assembly	
12		5	Spacer	
13		1	Nut	
14	4812157158	1	Housing and bearing	
15	4812157159	1	Lifetime seal	
16		1	Hub	
17		1	Brake shaft	
18		7	Sintered disc	
19		6	Steel disc	
20		1	Backup ring	
21	4812157160	1	O-ring	
22	4812157161	1	O-ring	
23		1	Backup ring	
24		1	Brake piston	
25		17	Spring	
26		1	Spring retainer plati	
27		1	Circlip	
28	4812157162	1	O-ring	
29		1	Motor adaptor	
30		6	Screw	
31		1	Extension	
32		4	Wascher	
33		3	Plug	

**Vibration motor adapter**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
1	4812116023	1	Adapter	C
4	4700116041	1	Taper roller bearing	B
6	4700343318	1	Bearing housing	D
8	4700167023	1	Seal ring	B
9	4700929447	1	V-ring	B
16	4700904231	4	Washer 13x24x2 300 HV	C
17	4700500133	4	Screw	C
19	4812113903	1	O-ring	B
20	4812112413	1	Shaft nut	C
22	4812113476	1	Plug	C
23	4700904228	1	Washer 6,4x12x1,5	C
24	4700903795	1	Screw	C
33	4700160105	1	O-ring 70	C

**Bracket module**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
1	4812114545	1	Bracket	D
2	4812114546	1	Bracket	D
3	4812114547	1	Bracket	D
4	4812114548	1	Bracket	D
5	4812114397	4	Shock absorber	C
6	4700375132	8	Steel spacer	
7	4700904558	8	Washer 17X30X6 300HV	C
8	4700500102	4	Screw M16x45	D
9	4700500056	8	Screw	
10	4700586021	4	Nut M16	

**Air cleaner**

Item	Part No	Rem	Qty	Description	Code
1			1	Air cleaner module ( Page 120 )	
2	4812114107		1	Air intake hose	C
3	4812112513		1	Air intake hose	C
4	4811000264	A	1XL	Coolant hose	C
5	4700389600		3	Hose clamp	D
6	4700392810		1	Hose clamp	D
7	4812111245		2	Clamp	B
8	4812112487		1	Bracket	
9	4812112550		2	Hose holder	
10	4700904229		16	Steel plain washer 8,4x16x1,5	C
11	4700500053		4	Screw M8x20H 8.8	C
12	4700500021		4	Screw M8-1,25x25 8.8	C
13	4812113573		1	Air intake duct	
14	4700500019		8	Hexagon head screw M8x16H 8,8	C

A) L=0.5m

**Brackets assy**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
1	4812112343	1	Bracket	D
2	4812112344	1	Bracket	D
3	4812112639	4	Spacer	D
4	4812112761	6	Rubber cloth	
5	4812113640	1	Bracket	D
6	4812112647	1	Bracket	D
7	4812113641	1	Bracket	D
8	4812112777	2	Bracket	D
9	4812112776	2	Bracket	D
10	4812114913	1	Bracket	D

**Transmission**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
1		1	Rear axle and wheels ( Page 140 )	

**Planet gear**

Item	Part No	Rem Qty	Description	Code
1	4700939263	2	Axle case	D
2	4700939003	32	Spring washer	C
3	4700939264	24	Bolt	C
4	4700939265	2	Seal	
5	4700939266	4	Bearing	
6	4700926781	20	Wheel screw	
7	4700901987	20	Wheel nut	
8	4700939015	4	Screw	
9	4700330333	6	Copper washer	D
10	4700909596	4	Plug	C
11	4700939016	20	Nut	D
12	4700939275	2	Lock plate	
13	4700939017	20	Stud	D
14	4700909609	2	O-ring	D
15	4700939276	2	Wheel hub	
16	4700939350	2	Magnetic plug	
17	4700939277	2	Half shaft	D
18	4700909586	2	Seal	D
19	4700939019	8	Nut	D
20	4700939278	8	Stud	D
21	4700939351	2	Planet gear carrier Cpl.	D
22	4700939267	2	. Circlip	
23	4700939268	2	. Ring gear	D
24	4700939269	2	. Ring gear support	
25	4700939270	2	. Washer	
26	4700939271	8	. Seal	
27	4700939272	8	. Planet gear	
28	4700939273	8	. Bearing	
29	4700939349	2	. Planet gear carrier Cpl.	

**Hydraulic systems**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
1		1	Hydraulic system, drum ( Page 160 )	
2		1	Hydraulic system, drum Anti-spin option ( Page 180 )	
3		1	Hydraulic system, steering ( Page 192 )	
4		1	Hydraulic system, rear axle ( Page 200 )	
5		1	Hydraulic system, rear axle Anti-spin option ( Page 210 )	
6		1	Hydraulic system, oil tank ( Page 222 )	
7		1	Hydraulic system, engine ( Page 236 )	
8		1	Hydraulic system, engine Adjustable frequency, Eco opti ( Page 258 )	
9		1	Hydraulic system, frame rear ( Page 274 )	
10		1	Hydraulic hoses, steering ( Page 280 )	
11		1	Emergency steering option ( Page 282 )	

**Pilot valve**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
1		1	Housing	
2		1	Piston	
3		1	Piston valve	
4		2	Screw	
5		1	Screw	
6		2	Washer	
7		2	Pressure spring	
8		1	Pressure spring	
9		4	Cap screw	
10		2	Screw	
11	4812157183	1	O-ring	
12	4812157170	2	O-ring	
13	4812157184	1	O-ring	
14	4812157186	2	Shaft sealing ring	
15		1	Shim	
16	4812157180	1	Pilot valve ( Page 170 )	

**Loop flushing**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
1	4812157060	1	Spool	
2	4812157061	2	Spring	
3		2	Plug assembly	
4		2	O-ring	
5	4812157062	1	Loop flushing relief valve, 10 l/min	
6	4812157063	1	O-ring	

**Loop flushing**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
1	4812157060	1	Spool	
2	4812157061	2	Spring	
3		2	Plug assembly	
4		2	O-ring	
5	4812157062	1	Loop flushing relief valve, 10 l/min	
6	4812157063	1	O-ring	

**Steering valve module**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
1	4812112290	1	Steering valve	D
4	4812115063	2	Elbow connector 90	C
5	4811000074	2	Straight connector orfs	D
6	4812115064	2	Elbow connector 90	C
7	4812115065	1	Elbow connector 90	C

Hose holder

Item	Part No	Rem Qty	Description	Code
1	4812114652	1	Hose holder	C
2	4700500189	2	Screw	C
3	4812114623	2	Hose holder	
4	4700902286	4	Hexagon lock nut with flange	C

**Loop flushing**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
1	4812157060	1	Spool	
2	4812157061	2	Spring	
3		2	Plug assembly	
4		2	O-ring	
5	4812157062	1	Loop flushing relief valve, 10 l/min	
6	4812157063	1	O-ring	

**Hose holder assy kit**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
1	4812112542	1	Bracket	
2	4700792500	4	Stud	D
3	4700287295	4	Clamp	D
4	4700904872	4	Cover plate	D
5	4700902286	4	Hexagon lock nut with flange	C
6	4700904230	2	Steel plain washer	C
7	4700500029	2	Hexagon head screw	C
8	4700923008	1	Clamp	D
9	4700904229	1	Steel plain washer 8,4x16x1,5	C
10	4700500018	1	Screw M8-1,25x12 8,8	C
11	4812113941	2	Hose holder clip	D

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

**Hydraulic pump module**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
1	4812112171	1	Hydraulic pump ( Page 240 )	
2	4700500037	4	Screw	C
3	4700904703	4	Washer	B
4	4812115051	1	Straight connector orfs	
5	4700904496	1	Connector	C
6	4700900229	3	Measuring nipple	C
7	4812112560	1	Straight connector orfs	
8	4812112561	1	T-adapter	
9	4700904005	2	O-ring	B
10	4700928791	8	Screw	D
11	4700904638	8	Washer 12x22x2	C
12	4700923384	4	Flange half	C

**Rotary group**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
1		1	Engine hydraulic part	
2		1	Control panel	
3		1	Cradle	
4		1	Sliding ring	
5		1	Drive shaft	
6		1	Wire	
7		1	Hinge pin	
8		1	Wire	
9	4812157193	1	Bearing pair	
10	4812157194	1	Cylindrical roller bearings	
11	4812157195	1	Cage pair	
12		1	Circlip	
13		1	Circlip	
14		1	Shaft sealing ring	
15		1	Circlip	
16		1	. Cylinder with bushing	
17		9	. Piston slipper pad	
20	4812157196	1	. Retaining plate	
21	4812157197	1	. Retaining ball	
22		2	. Washer	
23		1	. Pressure spring	
24		1	. Circlip	

Hydraulic system, engine Adjustable frequency, Eco opti

Item	Part No	Rem Qty	Description	Code
1		1	Hydraulic pump module ( Page 238 )	
2		1	Hydraulic pump ( Page 260 )	
3	4811000221	1	Hydraulic hose	C
4	4811000220	1	Hydraulic hose	C
5	4811000223	1	Hydraulic hose	C
6	4811000224	1	Hydraulic hose	C
7	4811000212	1	Hydraulic hose	C
8	4811000218	1	Hydraulic hose	C
9	4811000216	1	Hydraulic hose	C
10	4811000226	1	Hydraulic hose	C
11	4811000222	1	Hydraulic hose	C
12	4811000225	2	Hydraulic hose	C
13	4812113941	2	Hose holder clip	D
14	4700791711	2	Pipe clamp	D
15	4700791712	2	Cover plate	D
16	4700902286	2	Hexagon lock nut with flange	C
17	4700791805	2	Stud	D
18		1	Hydraulic oil filter assy ( Page 254 )	
19		A 1	Hydraulic pump module ( Page 272 )	
		B 1	Hydraulic pump module ( Page 256 )	

- A) Eco option
- B) Adjustable frequency option

**Rotary group**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
1		1	Slide ring	
2	4812157092	1	Bearing liner (Pair)	
3	4812157093	1	Plain roller bearing	
4		2	Retaining ring	
5	4812157094	1	Drive shaft	
6		1	Retaining ring	
7		2	Wire	
8		1	Cradle bearing assembly	
9		1	Cradle	
10		1	Control plate	
11		1	Retaining ball	
12		1	Retaining plate	
13		1	Pressure spring	
14		1	Retaining ring	
15		2	Washer	
16		9	Piston slipper pad	
90	4812157091	1	Seal kit drive shaft	

**Connector kit**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
1	4812115463	1	Holder	
2	4812115464	1	Holder	
3	4700904640	2	Washer 8,4x22x3	C
4	4700500021	2	Screw M8-1,25x25 8.8	C
5	4812111769	1	Hydraulic block	
6	4700792339	1	Straight connector orfs	D
7	4812112555	1	Straight connector orfs	D
8	4700792299	1	Elbow 90	
9	4700791212	1	Elbow 45	C
10	4700791318	1	Straight connector	D
11	4700904229	4	Steel plain washer 8,4x16x1,5	C
12	4700500023	2	Screw M8-1,25x40 8,8	C
13	4700500090	2	Screw	C
14	4812113177	2	Rubber nut	

**Electrical equipment**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
1		1	Electric cables, power supply ( Page 290 )	
2		1	Electrical cables, engine - ECU Horn, back-up alarm, sensor ( Page 296 )	
3		1	Wiring harness kit Power supply cab ( Page 310 )	
6		1	Driving & side direction lights, option ( Page 312 )	
7		1	GPS equipment module, option ( Page 324 )	
8		1	Tachograph, option ( Page 332 )	
9		1	Speed sensor, frequency sensor, option ( Page 340 )	
10		1	Pre-heater installation, option ( Page 344 )	
11		1	Rotating beacon, working light ( Page 346 )	
12		1	Wiring harness, power park, Option ( Page 354 )	
13		1	Regenerating delay, displacement shift ( Page 356 )	
14		1	Compaction meter ( Page 358 )	

**Horn module**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
1	4812115767	1	Horn	
2	4700904230	2	Steel plain washer	C
3	4700500027	1	Screw M10-1,55x22 8.8	D
4	4700570006	1	Nut	B

**Inclination sensor module**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
1	4812112686	1	Inclination sensor	
2	4812112691	1	Holder	
3	4700904504	4	Screw M5 x 18	C
4	4700904281	4	Washer 5,3x10x1 300HV	C
5	4700570003	4	Nut M5	C
6	4700904228	2	Washer 6,4x12x1,5	C
7	4700500013	2	Screw M6-1x16 8,8	C

Registration plate light module

Item	Part No	Rem Qty	Description	Code
1		1	Registration plate light ( Page 320 )	
2	4700928784	2	Screw	
3	4700904735	2	Washer	C

**GPS equipment module**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
1		1	GPS equipment assy ( Page 330 )	
2	4812113238	1	Cable harness	
3	4700313041	N	Cable ties	B
4	4700792392	1	Grommet with membrane	
5	4700792210	4	Screw torx	

**Power supply module**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
1	4700904015	1	Fuse holder	D
2	4700960067	1	Cable clip	
3	4700904024	1	Splicing sleeve	
4	4700901227	1	Fuse 10A	A

**Rotating beacon module**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
1		1	Rotating beacon ( Page 350 )	
2	4700904230	2	Steel plain washer	C
3	4700500048	2	Screw M10-1,5x20 8,8	C
4	4812111326	1	Rotating beacon	
	4812156777	1	. Bulb H1 24V	

**Compaction meter**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
1	4812115921	1	Dcm unit	
2	4812112072	1	Cable entry insert	
3	4700923876	1	Clamp	D
4	4700904228	8	Washer 6,4x12x1,5	C
5	4700923859	1	Cover plate	C
6	4700500079	4	Screw M6-1x50 8,8	C
7	4700508026	4	Screw	D
8	4700791453	2	Pipe clamp block	
9	4700791454	1	Cover plate	
10	4812116181	1	Bracket	
11	4700904231	2	Washer 13x24x2 300 HV	C
12	4700500035	2	Screw M12x020H	
13		1	Power supply ( Page 360 )	
14	4700792210	2	Screw torx	

**Basic kit Rops, roof, front handrail**

Item	Part No	Rem	Qty	Description	Code
1	4812115193		1	Handrail	
3			4	Screw	
4	4812115194		1	Plate	
6			4	Screw	
7	4700202028	A	1XL	Edge trim	D
8	4700202028	B	1XL	Edge trim	D
9	4700202028	C	1XL	Edge trim	D
10	4700202028	D	1XL	Edge trim	D
11	4700202028	E	1XL	Edge trim	D
12	4700202028	F	1XL	Edge trim	D
13			2	Cap	
20	4812115195		1	Roof	
21	4812115164	G	1XL	Rubber strip	
22		H	1XL	Foam strip	
23	4812115196		1	Roof plate	
24	4812115166		5	Rubber washer	
25	4700601003		5	Washer 8,4x25x2	C
26			5	Screw	
27	4812115170		4	Seal washer	
28	4812115171		4	Washer	
29			4	Screw	
30	4700601003		2	Washer 8,4x25x2	C
31	4700947680		2	Screw M8-1,25x25 10.9	D
40	4700908505		1	Hook	D
41			4	Screw	

- A) L=0.508m
- B) L=0.133m
- C) L=1.415m
- D) L=1.43m
- E) L=0.856m
- F) L=1.515m
- G) L=6.7m
- H) L=2.513m

**Cab symmetric module**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
1	4812112275	1	Cab, cpl Comfort ( Page 380 )	
	4812112276	1	Cab, cpl Basic ( Page 414 )	
2	4812112294	4	Bracket	
3	4700359998	4	Back-up ring	C
4	4700500195	16	Screw	C
5	4812115387	2	Protective plug	
6	4700374606	4	Shock absorber Green	D
7	4700372457	4	Back-up ring	C
8	4700904233	6	Washer 21x36x3	C
9	4700903290	2	Washer 21x36x6	C
10	4700901145	4	Lock nut M20-10	
11	4700903633	4	Screw M20x150 10,9	
12		1	Manual box ( Page 376 )	

Windshield wiper

Item	Part No	Rem	Qty	Description	Code
1	4812114606		1	Bracket	
2			3	Washer	
3			3	Screw	
4	4812114598		1	Bolt	
5	4812114599		1	Clamp	
6	4812114602		1	Washer	
7	4812114603		1	Plate	
8	4812114600		1	Wiper motor, front	
9	4812114604		1	Wiper arm	
10	4812114605		1	Wiper blade, front	
11	4700601003		2	Washer 8,4x25x2	C
12	4700791182		2	Lock nut M8	
13			2	Spacer	
14			2	Washer	
15	4812114601		1	Wiper motor, rear	
16	4812114607		1	Wiper arm	
17	4812114608		1	Wiper blade, rear	
18	4812114610		1	Nozzle	
19	4812114609		1	Clamp	
20	4812114611	A	1XL	Hose	
21	4812114612		1	Water tank	
22		F	1XL	Rubber seal	
23	4812114613		1	Bracket	
24	4700904228		7	Washer 6,4x12x1,5	C
25	4700904563		3	Lock nut M6	C
26	4812115162		1	Filling pipe	
27	4700313023		2	Hose clamp	
28	4700500013		4	Screw M6-1x16 8,8	C
29	4812114611	B	1XL	Hose	
30	4700908564		2	Check valve	C
31	4812114611	C	1XL	Hose	
32	4700908561		2	Grommet	D
33	4812114611	D	1XL	Hose	
34	4812114611	E	1XL	Hose	

- A) L=0.415
- B) L=0.122
- C) L=4.4
- D) L=2.55
- E) L=0.161
- F) L=0.201m

**Cab, electrical equipment**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
1	4812115184	1	Bracket	
2	4700792309	1	Relay	D
3		2	Screw	
4	4700904504	2	Screw M5 x 18	C
5	4812115185	1	Bracket	
6		3	Screw	
7	4812115187	1	Switch	
8	4700792505	1	Switch	D
9	4700791185	1	Fuse box	
10	4700901227	2	Fuse 10A	A
11	4700901228	1	Fuse 15A	A
12	4700791966	2	Head screw M4 x 12	

**Step light, wiper switch**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
1	4812115188	1	Switch, front wiper	
2	4812115189	1	Potentiometer	
3		1	Decal	
4		1	Knob	
5		1	Cap	
6	4812115190	1	Relay interval	
7	4812115191	1	Time control unit	
8	4812115199	1	Step light	
9	4812115224	1	Bracket	
10		2	Screw	
11		2	Washer	
12		2	Screw	

**Cab, front cover**

Item	Part No	Rem	Qty	Description	Code
1			1	Front cover Left	
2			1	Front cover Right	
3	4812114572		1	Bracket	
4			1	Bracket	
5	4812114567		5	Speed nut	
6			9	Screw	
7	4700202028	A	2XL	Edge trim	D
A)	L=0.473m				

**Seat frame adapter module, rotating**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
1	4700359125	1	Ball bearing	B
2	4700379728	1	Locking disc	C
3	4700395383	1	Coupling link	C
4	4700359819	1	Bushing	C
5	4700630008	1	Pin	D
6	4700359043	1	Spring	D
7	4700792678	4	Screw	C
8	4700904229	8	Steel plain washer 8,4x16x1,5	C
9	4700904640	4	Washer 8,4x22x3	C
10	4700573008	4	Nut M8	C
11	4700947679	4	Screw	C

**Control module**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
1	4700391241	1	Bracket	D
2	4812111216	1	Control, cpl	D
2-1	4700393496	1	. Cable 675	
3	4700392965	1	Control cover	C
4	4700791524	2	Screw M6X20	C
5	4700904228	4	Washer 6,4x12x1,5	C
6	4700500040	4	Screw M6-1x20 8,8	C
7	4700586002	4	Lock nut M6 -8	C
8	4700904229	4	Steel plain washer 8,4x16x1,5	C
9	4700500053	4	Screw M8x20H 8.8	C

**Car stereo module**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
1	4811000268	2	Loud speaker	
2	4811000269	2	Loud speaker grille	
3	4811000265	1	Car stereo	
	4812116986	1	Spacer frame	
4	4812114194	1	Antenna	

**Decals**

Item	Part No	Rem Qty	Description	Code
1	4700904068	2	Decal "DYNAPAC" L=1770 mm	
2	4700588176	1	Decal "LIFT POINT"	D
3	4700382751	2	Decal "TIE DOWN POINT"	D
4	4700908229	1	Safety decal	D
5	4700904870	1	Lifting sign	D
	4700624005	4	Blind rivet 3,2x6,1	C
6	4700903422	2	Decal "SAFETY"	D
7	4700903459	1	Decal "SAFETY"	D
8	4700904895	2	Safety decal "Brake release"	D
9	4700904870	1	Lifting sign	D
10	4700908229	1	Safety decal	D
11	4700382751	2	Decal "TIE DOWN POINT"	D
12	4700588176	1	Decal "LIFT POINT"	D
13	4700904835	1	Decal "BATTERY POWER"	D
14	4700272373	1	Decal "HYDRAULIC OIL"	D
15	4700385080	A 2	Decal "TYRE PRESSURE" 150-170kPa/21-24psi	D
	4700390900	B 2	Decal "TYRE PRESSURE" 110kPa/16psi	D
	4700355983	C 2	Decal "TYRE PRESSURE" 200kPa/29psi	D
16	4700388449	1	Decal "COOLING LEVEL"	
17	4811000422	2	Decal "MODEL CODE", Red CA6000	D
18	4700903985	4	Decal "SAFETY", "TYRE IN BALLAST"	
19	4700272372	1	Decal "HYDRAULIC OIL"	D
	4700792772	1	Decal "BIO HYDRAULIC OIL" PANOLIN	D
20	4811000345	1	Decal "ULTRA LOW SULFUR FUEL ONLY"	
21	4700903425	1	Decal "SAFETY MANUAL"	D
22	4700791642	1	Decal "WARNING" Use of starting fluid prohib.	D
23	4811000344	2	Decal "LOW SULFUR"	
24		1	Product identification plate	
25	4700791273	1	Decal "Sound power level" 103 dB	D

- A) Used with all-weather wheel.
- B) Used with tractor wheel.
- C) Used with premium wheel.

**SMV-sign**

Item	Part No	Rem Qty	Description	Code
1	4700476019	1	SMV-sign	D
2	4700904228	2	Washer 6,4x12x1,5	C
3	4700500012	2	Screw M6x12	C

**AC module**

Item	Part No	Rem Qty	Description	Code
1	4812113622	1	Ac kit	
2	4700904228	4	Washer 6,4x12x1,5	C
3	4700500040	4	Screw M6-1x20 8,8	C
4	4700792718	1	Rubber strip	D
5	4812114311	1	Bracket	
6	4811000458	2	Speed nut	
7	4700601001	4	Washer	C
8	4700508099	1	Screw	
9	4700926537	2	Screw M5-0,8x16H 8,8	
10	4700570003	1	Nut M5	C
11	4812113623	1	Evaporator coil	
12	4812115013	1	Air intake assy	C
13	4700313041	10	Cable ties	B
14	4812117349	A 1XL	Cork tape	

A) L = 0.5m

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL