

編 番
PART NO.
PIHI-EI-3

PARTS CATALOG

パーツカタログ

EX300-5 Series シリーズ

EQUIPMENT COMPONENTS PARTS

機器インナーパーツ

EX300-5
EX300LC-5
EX330LC-5
EX350H-5
EX350LCH-5
EX350K-5
EX350LCK-5
EX370-5
EX370HD-5

適用号機
Serial No. 020001~

HITACHI

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

目 次
CONTENTS

PB-93
PB-A14
CONTROL-1366

部品番号 PART NO.	コード CODE	部 品 名	PART NAME	適用号機 SERIAL NO.	頁 PAGE
		ポンプ	PUMP		
9166355	9166355A	ポンプ装置	PUMP DEVICE		001
9166356	9166356	・ポンプ;ユニット	・PUMP;UNIT		003
9166357	9166357	・レギュレータ	・REGULATOR		005
4181700	4181700A	ポンプ;ギヤ	PUMP;GEAR		007
		モータ;オイル	MOTOR;OIL		
4371768	0719600	モータ;オイル (旋回)	MOTOR;OIL (SWING)		009
9149125	9149125	モータ;オイル (走行) <スタンダートトラック, LC トラック>	MOTOR;OIL (TRAVEL) <STD. TRACK, LC TRACK>		011
9157762	9157762	・バルブ;ブレーキ	・VALVE;BRAKE		013
9134147	9134147A	・バルブ;リリーフ	・VALVE;RELIEF		015
9157588	9157588	・ピストン;サーボ	・PISTON;SERVO		017
4389274	-----	モータ;オイル (走行) <HD トラック>	MOTOR;OIL (TRAVEL) <HD TRACK>		---
4389275	-----	モータ;オイル	MOTOR;OIL		---
++++++	0720200	・モータ;オイル (1/2)	・MOTOR;OIL (1/2)		019
++++++	0720300	・モータ;オイル (2/2)	・MOTOR;OIL (2/2)		021
4389276	0720400	バルブ;ブレーキ	VALVE;BRAKE		023
		バルブ	VALVE		
4363127	-----	バルブ;コントロール	VALVE;CONTROL		---
++++++	0718900	・バルブ;コントロール (1/6)	・VALVE;CONTROL (1/6)		025
++++++	0719000	・バルブ;コントロール (2/6)	・VALVE;CONTROL (2/6)		027
++++++	0719100A	・バルブ;コントロール (3/6)	・VALVE;CONTROL (3/6)		029
++++++	0719200	・バルブ;コントロール (4/6)	・VALVE;CONTROL (4/6)		031
++++++	0719300	・バルブ;コントロール (5/6)	・VALVE;CONTROL (5/6)		033
++++++	0719400	・バルブ;コントロール (6/6)	・VALVE;CONTROL (6/6)		035
9156581	9156581A	バルブ;パイロット (フロント, 旋回)	VALVE;PILOT (FRONT & SWING)		037
9151777	9151777	バルブ;パイロット (走行)	VALVE;PILOT (TRAVEL)	020001-020004	039
9169583	9169583	バルブ;パイロット (走行)	VALVE;PILOT (TRAVEL)	020005-	041
9137384	9137384	バルブ;パイロット	VALVE;PILOT		043
4392529	0728300	バルブ;フロウコントロール	VALVE;FC		045
4351142	0670500	バルブ;リリーフ	VALVE;RELIEF		047
4203447	0361000A	バルブ;シャトル	VALVE;SHUTTLE		049

ポンプ;ユニット
PUMP;UNIT

020001-

符号 ITEM	部品番号 PART NO.	部品名 PART NAME	コード CODE	数量 Q'TY	サービス コード S.C	適用号機 SERIAL NO.	互換性 I.C.A	代替部品 REPLACEABLE PART	
								部品番号 PART NO.	数量 Q'TY
53	4355081	・O-RING		1					
59	4294621	・O-RING		1					
60	4367533	・STOPPER		1		-H1938	Y	4216295	1
60	4216295	・STOPPER		1	#	H1939-			
63	M340820	・BOLT;SOCKET		8					
64	4514388	・WASHER;SPRING		8					
66	9166357	・REGULATOR <for assembly of machine>	9166357	1			I	9169053	1
66	(9169053)	・REGULATOR <for transportation>		1	S				
69	4348665	・O-RING		1					
70	4515041	・PIN;SPRING		2					
75	3081038	・NAME-PLATE		1					
76	M492564	・SCREW;DRIVE		2					
82	9134111	・PLUG		1					
82A	4509180	・・O-RING		1					
83	4355012	・SENSOR;PRES.		1					
83A	4365826	・・O-RING		1					

モータ;オイル (走行)
MOTOR;OIL (TRAVEL)

020001-

符号 ITEM	部品番号 PART NO.	部品名 PART NAME	コード CODE	数量 Q' TY	サービス コード S. C	適用号機 SERIAL NO.	互換性 ICA	代替部品 REPLACEABLE PART	
								部品番号 PART NO.	数量 Q' TY
	9149125	MOTOR;OIL <for assembly of machine>	9149125	1			1	9155694	1
	(9155694)	MOTOR;OIL <for transportation>		1	S				
02	1019564	・CASING;MOTOR		1					
03	2040523	・DISC;DRIVING		1					
06	4199108	・BRG.;ROL.		1					
07	4199072	・BRG.;ROL.		1					
09	4191665	・NUT;BRG.		1					
10	4389598	・SPACER		1					
11	4191666	・SEAL;OIL		1					
12	4038529	・RING;RETAINING		1					
13	2040520	・ROTOR		1					
16	8068583	・PISTON		7					
18	3078298	・SHAFT;CENTER		1					
20	4194362	・SPRING;COMPRES.		1					
21	4198956	・PIN		1					
24	3036457	・PLATE;FRICTION		4					
25	3036456	・PLATE		5					
26	4193996	・SPACER		1					
27	3078190	・PISTON		1					
29	4252401	・D-RING		1					
30	4269474	・D-RING		1					
31	3054505	・SPRING;DISC		1					
33	4269473	・O-RING		1					
34	4506415	・O-RING		1					
35	9157762	・VALVE;BRAKE <for assembly of machine>	9157762	1			1	9158391	1
35	(9158391)	・VALVE;BRAKE <for transportation>		1	S				
38	M341850	・BOLT;SOCKET		4					
40	2035236	・PLATE		1					
42	4364104	・PIN;KNOCK		2					
44	2040522	・VALVE		1					
46	4234628	・BUSHING		1					
49	4255238	・PLUG		2					
50	2040803	・LINK		1					
51	4262561	・BOLT;REAMER		1					
52	9157588	・PISTON;SERVO	9157588	1					
55	4260308	・RING;PISTON		2					

モータ;オイル (1/2)
MOTOR;OIL (1/2)

020001-

符号 ITEM	部品番号 PART NO.	部品名 PART NAME	コード CODE	数量 Q' TY	サービス コード S. C	適用号機 SERIAL NO.	互換性 ICA	代替部品 REPLACEABLE PART	
								部品番号 PART NO.	数量 Q' TY
	4389275	MOTOR;OIL (1/2)	0720200	1					
	コノ 部品番号ノ 構成部品ハ MOTOR;OIL(1/2) カラ (2/2)ノ 部品ヲ 含ミヌ。 This PART NO consists of all parts shown in MOTOR;OIL(1/2) to (2/2)								
1	0657301	・CASE ASS' Y		1					
1A	++++++	・・CASE		1	D				
1B	++++++	・・PISTON		4	D				
3	0352203	・SHAFT		1					
4	0419802	・BLOCK;CYL. ASS' Y		1					
4A	++++++	・・BLOCK;CYL.		1	D				
4B	++++++	・・PLATE		1	D				
4C	++++++	・・PISTON		9	D				
7	0419803	・PLATE ASS' Y		1					
7A	++++++	・・PLATE		1	D				
7B	++++++	・・HOLDER		1	D				
9	0720201	・PLATE		1					
10	0352207	・CASE		1					
11	0352208	・BRG. ;ROLLER		1					
13	0352210	・RACE; INNER		1					
15	0419805	・SPRING		9					
18	0352214	・WASHER		1					
22	0352215	・RING;RETAINING		1					
23	0352216	・RING;RETAINING		1					
24	0311317	・RING;RETAINING		1					
29	0352218	・SEAL;OIL		1					
30	0419806	・O-RING		1					
31	A811105	・O-RING		1					
36	0419807	・PISTON		1					
38	0352221	・PLATE;FRICTION		3					
39	0419808	・PLATE;DISK		3					
42	0419809	・O-RING		1					
44	4506320	・O-RING		3					
47	0352225	・PLUG		6					
50	0419811	・SPRING		4					
51	0352227	・BALL;STEEL		2					
58	0311336	・PLUG		2					
59	4509180	・O-RING		2					
60	0419812	・RING;BACK-UP		1					
61	0419813	・RING;BACK-UP		1					

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

バルブ;ホルディング
 VALVE;HOLDING

020001-

符号 ITEM	部品番号 PART NO.	部品名 PART NAME	コード CODE	数量 Q' TY	サービス コード S. C	適用号機 SERIAL NO.	互換性 I C A	代替部品 REPLACEABLE PART	
								部品番号 PART NO.	数量 Q' TY
	4398513	VALVE;HOLDING	0742700	1					
01	0343614	・SPRING		1					
02	0343615	・POPPET		1					
03	0669401	・PLUG		1					
04	0343602	・PLUG		1					
05	0343603	・HOLDER;SPRING		1					
06	0343604	・POPPET		1					
07	0343607	・SPRING		1					
08	0742701	・SEAL		1					
09	0742702	・SPRING		1					
10	0742703	・SPRING		1					
13	+++++	・NAME-PLATE		1	D				
27	0314205	・PLUG		2					
28	0309805	・PLUG		1					
29	0343611	・PLUG		2					
31	0208717	・SCREW;DRIVE		2					
33	957366	・O-RING		2					
34	4509180	・O-RING		1					
35	4506418	・O-RING		2					
36	4506424	・O-RING		1					
37	4095210	・O-RING		1					
41	0343514	・PLUG		6					
43	0742704	・VALVE;RELIEF		1					
43/14	+++++	・・ADAPTER		1	D				
43/15	+++++	・・BODY		1	D				
43/16	+++++	・・POPPET		1	D				
43/17	+++++	・・POPPET		1	D				
43/18	+++++	・・SPRING		1	D				
43/19	+++++	・・SPRING		1	D				
43/20	+++++	・・SPRING		1	D				
43/21	+++++	・・VALVE;NEEDLE		1	D				
43/22	+++++	・・RING;BACK-UP		2	D				
43/23	+++++	・・RING;BACK-UP		2	D				
43/24	+++++	・・PIN		1	D				
43/25	+++++	・・SCREW		1	D				
43/30	+++++	・・NUT		1	D				
43/32	+++++	・・O-RING		1	D				
43/38	+++++	・・O-RING		2	D				
43/39	+++++	・・O-RING		1	D				
43/40	+++++	・・O-RING		1	D				

シリンダ ;アーム
CYL. ;ARM

300, 300LC, 330LC, 350H, 350LCH,
350K, 350LCK, 370 : -021764
370HD : -021832

符号 ITEM	部品番号 PART NO.	部品名 PART NAME	コード CODE	数量 Q' TY	サービス コード S. C	適用号機 SERIAL NO.	互換性 I CA	代替部品 REPLACEABLE PART	
								部品番号 PART NO.	数量 Q' TY
	9164990	CYL. ;ARM <for assembly of machine>	9164990A	1			I	9170171	1
	(9170171)	CYL. ;ARM <for transportation>		1	S				
06-35	9173702	・CYL. (PIPELESS) <for assembly of machine>		1			I	9173705	1
06-35	(9173705)	・CYL. (PIPELESS) <for transportation>		1	S				
06	7031746	・・TUBE;CYL. <for assembly of machine>		1			I	9173708	1
06	(9173708)	・・TUBE;CYL. <for transportation>		1	S				
06A	4381859	・・・BUSHING		2					
07	1025101	・・HEAD;CYL.		1					
08	M342700	・・BOLT; SOCKET		8					
09	4370927	・・SEAL; DUST		1	K				
10	4370060	・・SEAL		1	K	-D98/08	I	4411659	1
10	4411659	・・SEAL		1	#K	D98/09-			
11	4370059	・・RING		1	K	-D98/08	I	4411656	1
11	4411656	・・RING		1	#K	D98/09-			
12	4370058	・・RING; RETAINING		1					
13	4393350	・・O-RING		1	K				
14	7031751	・・ROD; PISTON		1					
14A	4381859	・・・BUSHING		2					
15	4372816	・・RING; RETAINING		1					
16	4370337	・・BUSHING		1					
18	4370338	・・RING; CUSHION		1					
19	4370063	・・RING; TEFLON		2					
20	4370064	・・RING; WEAR		2					
21	4370062	・・RING; SEAL		1	K				
22	3080654	・・PISTON		1					
23	3062096	・・NUT		1					
24	4201806	・・SCREW; SET		1					
35	J75581	・・FITTING; GREASE		1					
56	4260204	・CAP		1					
57	4260205	・CAP		1					
61	M341245	・BOLT; SOCKET		4					
62	M341260	・BOLT; SOCKET		4					
63	A811035	・O-RING		2					
66	8070112	・PIPE		1					

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL