

AT-110-1 42084132000 LOWER,HINO BDG-XZU304X-TYMMB6

PB3000031-00 POWER UNIT
PO1000149-00 INDICATION PLATES
PX2000916-00 CARRIER UNIT
PX3000436-00 MOUNTING UNIT
PY1000656-02 OPTIONS
ASSEMBLY

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below




- Please note: If there is no response to **CLICKING** the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

AT-110-1 42084132000 LOWER,HINO BDG-XZU304X-TYMMB6

Pos No.	Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End)
1	(*****)	POWER SUPPLY (LOWER)	1				
2	(*****)	BOX, TOOL (OPTION)	1				
3	(*****)	MOUNT, SUPPORT	1				
4	(*****)	EARTHING DEVICE (8X20M)	1				
	(*****)	EARTHING DEVICE (8X10M, OPTION)	1				
6	(*****)	OPE. ASSY (LEVELING/WITH POWER SUPPLY)	1				
	(*****)	OPE. ASSY (LEVELING/WITHOUT POWER SUPPLY)	1				
8	(*****)	STEP	1				
9	(*****)	VIEW SYSTEM (FOR ISUZU/ST-900)	1				

AT-110-1 42084132000 LOWER,HINO BDG-XZU304X-TYMMB6
PB1380138-03 POWER SUPPLY (LOWER)



AT-110-1 42084132000 LOWER,HINO BDG-XZU304X-TYMMB6

Pos No.	Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End)	R
1	80400160190	JOINT (WITH O-RING)	1					
2	37002501360	HOSE	1		L=450			
3	91803880070	CLIP	6		D=13.1-16.2			
5	90101208030	BOLT	2		M8X30			
6	90302040801	WASHER,SPRING	11		8			
7	80321618050	VALVE,CHECK	1					
8	37002467850	HOSE	1		L=1050			
9	91002801400	O-RING	3		1B P14			
13	80400160129	JOINT	1					
14	37002513560	HOSE	1		L=210			
15	91803600550	CLIP	8		D=40-55			
16	37002513090	HOSE	1		L=380			
17	91803600250	CLIP	1		D=18-25			
18	81408000160	PIPE,STEEL	2	M	12X1.4T			
19	37000711000	CLAMP ASSY	1		12-1			
21	90101208060	BOLT	2		M8X60			
23	37002512290	HOSE	1		L=500			
24	91803600400	CLIP	4		D=27-40			
25	37000711090	CLAMP ASSY	1		18X2			
26	44340011200	JOINT	1		PF1			
27	91002802900	O-RING	2		1B P29			
28	36672280000	FILTER,OIL (YAMASHIN)	1					
29	80303130141	FITTING,ELBOW	1		KLO12-020E			
30	42643050300	JOINT	1					
31	37002513570	HOSE	1		L=520			
32	91803600300	CLIP	4		D=22-30			
33	90101208016	BOLT	6		M8X16			
34	42645400400	FITTING,FLANGE	1					
35	91001204500	O-RING	1		1A G45			
36	37002512280	HOSE	1		L=820			
37	42645400500	SUPPORT	1					
38	37002513580	HOSE	1		L=800			
39	91810132530	FASTENER	3					
40	37000300750	SLEEVE	2		18-15			
41	81408000241	PIPE,STEEL	1	M	18X1.9T			
42	37000714030	CLAMP ASSY	1		18X1			
43	42645400600	SUPPORT	1					
44	90101210025	BOLT	1		M10X25			
45	90201201000	NUT	1		M10			
46	90302041001	WASHER,SPRING	1		10			
47	90101208020	BOLT	1		M8X20			
48	90201200800	NUT	1		M8			
49	37000601600	CLAMP	1		WR54			
61	91002801100	O-RING	4		1B P11			
71	80400160190	JOINT (WITH O-RING)	1					
72	80316070040	PLUG	1		PF1/4			
73	42645400100	JOINT	1					
81	42645400310	JOINT	1					
82	80302090151	FITTING	1		KCO12-040N			
83	91002801800	O-RING	3		1B P18			
84	80302090201	FITTING	1		KCO15-040N			
85	42643051000	SWITCH ASSY (THERMO)	1					
86	80456950401	JOINT,SELF SEALING (COUPLER)	1					
87	80302090241	FITTING	1		KCO18-040N			
88	37000907950	JOINT	1		S,PF3/8-R1/4			
89	91002801400	O-RING	1		1B P14			

AT-110-1 42084132000 LOWER,HINO BDG-XZU304X-TYMMB6

Pos No.	Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End)	Remarks
2	42739697510	CABLE ASSY	1					
3	42739697540	CABLE ASSY	1					
4	42739697520	CLIP	1					
5	42739697530	REMOTE CONTROL ASSY	1					
100	42739931110	DISPLAY	1					

AT-110-1 42084132000 LOWER,HINO BDG-XZU304X-TYMMB6

Pos No.	Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End)	Remarks	Pages
100	42808000200	HARNESS	1						

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below




- Please note: If there is no response to **CLICKING** the link, please download this PDF first and then click on it.


CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

AT-110-1 42084132000 LOWER,HINO BDG-XZU304X-TYMMB6
PI1140136-01 VALVE,CHECK


30





AT-110-1 42084132000 LOWER,HINO BDG-XZU304X-TYMMB6
PN1012905-02 ELEC.ASSY (BUCKET/LEVELNG)





AT-110TE-1
AT-100TE-2



AT-100TG-2










AT-110-1 42084132000 LOWER,HINO BDG-XZU304X-TYMMB6
PN1350029-01 REEL,CORD (FOR EARTHING)




**AT-110-1 42084132000 LOWER,HINO BDG-XZU304X-TYMMB6
PX1170586-00 ATTACHMENT PARTS,CRANE FRAME**


FRONT ←





**AT-110-1 42084132000 LOWER,HINO BDG-XZU304X-TYMMB6
PX1290339-00 WEIGHT INSTALLATION**



AT-110-1 42084132000 LOWER,HINO BDG-XZU304X-TYMMB6
PX1350449-02 BOX,TOOL



AT-110-1 42084132000 LOWER,HINO BDG-XZU304X-TYMMB6
PX1810088-02 MOUNT,SUPPORT



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to **CLICKING** the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL