


**DYNAPAC
CC622VHF
SPARE PARTS
CATALOGUE
SCC622VHF-1EN2**



DYNAPAC

Box 504, SE-371 23 Karlskrona, Sweden
Phone: +46 455 30 60 00, Fax: +46 455 30 60 10
www.dynapac.com

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	939480		1	Oil filter element	
2	939372		1	Fuel filter element	

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	376725		1	Scraper bracket	
2			1	.Bracket	
3			1	.Bracket	
4	376728		1	.Shaft	
5	388344		2	.Guide	
6	388345		1	.Spring	
7	376729		1	.Release device	
8	586021		2	.Nut M16	
9	904232		3	.Washer 17x30x3	
10	791755		1	.Nut protection	
11	312005		1	.Ball knob	
12	792129		1	.Pin	
13	376726		1	Scraper bracket	
14			1	.Scraper bracket	
15			1	.Scraper bracket	
16	376728		1	.Shaft	
17	388344		2	.Guide	
18	388345		1	.Spring	
19	586021		2	.Nut M16	
20	904232		3	.Washer 17x30x3	
21	791755		1	.Nut protection	
22	312005		1	.Ball knob	
23	792129		1	.Pin	
24	388485		1	Sprinkler pipe	
25	384427		1	Scraper bracket	
26	384427		2	Scraper bracket	
27	384375		2	Scraper	
28	500056		18	Screw M12x45 8,8	
29	904231		40	Washer 13x24x2	
30	586019		22	Lock nut M12	
31	500049		4	Screw M12-1,75x60 8.8	
32	904703		4	Washer 13x24x4	
33	500046		4	Screw M12x30H 8,8 FZB	
34	904557		4	Washer 10,5x22x4	
35	904271		4	Bolt	
36	586018		4	Lock nut M10	
39	387690		2	Scraper bracket, cpl	
40			1	.Scraper bracket	
41			1	.Scraper bracket	
42	390809		1	.Extension spring	
43	500267		1	.Screw	
44	904231		1	.Washer 13x24x2	
45	586019		1	.Lock nut M12	
46	500240		1	.Screw M10x40H 8,8	
47	570006		1	.Nut M10	
48	500003		1	.Screw	
49	928381		1	.Washer 6,4x18x1,6	
50	388490		1	.Release device	
51	387693		1	Scraper bracket, cpl	
52			1	.Scraper bracket	
53			1	.Scraper bracket	
54	390809		1	.Extension spring	
55	500267		1	.Screw	
56	904231		1	.Washer 13x24x2	
57	586019		1	.Lock nut M12	
58	500240		1	.Screw M10x40H 8,8	
59	570006		1	.Nut M10	

Noise suppression

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	387816		1	Absorbent	
2	387815		1	Absorbent	
3	791233		17	Holder	
4	791234		17	Insulating washer	
5	387818		1	Absorbent, right hood	
6	387819		1	Absorbent, right hood	
7	387821		1	Absorbent, right hood	
8	387817		1	Absorbent, right hood	
9	387820		1	Absorbent, right hood	
10	904356		25	Screw 5 x 38	
11	904355		25	Washer 0,7 x 80	
12	373585		1	Absorbent	
13	373586		1	Absorbent	
14	387876		1	Absorbent, left hood	
15	387877		1	Absorbent, left hood	
16	387878		1	Absorbent, left hood	
17	387879		1	Absorbent, left hood	
18	387880		1	Absorbent, left hood	

Drum

Ref. No.	Part No.	Rem.	Qty	Description	Code
1				Drum, standard, front/rear (Page 42)	

Diesel engine Cummins 4B3.9 TAA

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	386458		1	Diesel engine, cpl Cummins 4B3.9 TAA	
2	939373		1	.Belt	
3	945140		1	.Alternator	
4	939504		1	.Starter	
5	939480		1	.Oil filter element	
6	939372		1	.Fuel filter element	
7	390473		1	Fan	
8	382390		1	Connector	
9	382393		1	Fan hub	
10	387384		1	Engine bracket	
11	387565		1	Engine bracket	
12	387382		1	Engine bracket	
13	387383		1	Engine bracket	
14	388113		2	Shock absorber Blue marked	
15	388114		2	Shock absorber Grey marked	
16	386688		1	Protection cover	
18	372819		1	Hydraulic hose	
19	372792		1	Bracket	
20	921028		1	Clamp	
21	747691		1	Hollow screw	
22	371727		1	Sleeve	
23	330331		3	Washer 18,2x23,9x1,5	
24	230515		1	Connector	
25	330383		1	Cap hydraulic	
26	792080		3	Screw	
28	508079		6	Screw M12-1,75x35H 8,8	
29	500025		6	Screw M8-1,25x50 8,8	
30	904229		6	Washer 8,4x16x1,5	
31	500196		4	Screw M12-1,75x80 8.8	
32	791473		4	Steel spacer	
33	500030		8	Screw M10-1,5x35H 8,8	
34	904230		9	Washer 10,5x22x2	
35	586018		9	Lock nut M10	
36	947688		2	Screw M12x35H	
37	904231		13	Washer 13x24x2	
38	500013		1	Screw M6-1x16 8,8	
39	904228		1	Washer 6,4x12x1,5	
40	570004		1	Nut M6	
41	927233		1	Nut	
42	904233		2	Washer 21x36x3	
43	904379		1	Screw M10x110H 8,8	
45	904557		1	Washer 10,5x22x4	
46	508063		2	Screw	
47	924543		8	Washer	
48	904640		2	Washer 8,4x22x3	
49	500269		2	Screw M12-1,75x50 10,9	
53	904241		1	Screw M8x40	
54			4	Existing	
55	903632		1	Temperature sensor Engine	
56	935044	1	1	Oil pressure sensor	
57	380873		1	Fan spacer	
58	904983	B	1XL	Fuel hose	
59	313075		2	Hose clamp	

1) Included on engine.

B) L=0,1 m

Ref. No.	Part No.	Rem.	Qty	Description	Code
1			1	Coupling, cpl	
2	370230		1	.Hub	
3	370232		1	.Flange	
4	904176		1	.Screw	
5	509025		8	Screw 3/8-16UNCx32 8,8	
6	508053		12	Screw M10-1,5x35H 8,8	
7	373354		1	Gear box (Page 62)	

Propulsion system, motors

Ref. No.	Part No.	Rem.	Qty	Description	Code
2	923384		8	Flange half	
5		A	1	Hydraulic hose	
6		A	1	Hydraulic hose	
7	334121		2	Straight connector	
8		A	1	Hydraulic hose	
9		A	1	Hydraulic hose	
10	387485	2	1	Hydraulic motor, propulsion, front	
	939352		1	.Seal kit	
11		A	1	Hydraulic hose	
15	904005		4	O-ring	
20	502132		16	Screw UNC 7/16" x 22	
21	904638		16	Washer 12x22x2	
25	500208		20	Screw M20x80	
26	904233		20	Washer 21x36x3	
27	380202		4	Nut	
28				Not used on this model	
34	387484	1	1	Hydraulic motor, propulsion, rear	
36	343872		2	Hose clamp	
37	343732		2	Hose clamp	
38	335914		2	Cover plate	
39	904056		2	Stud	
40	904230		10	Washer 10,5x22x2	
41	903524		2	Bolt	
42	570006		4	Nut M10	
43	383462		2	Hose clamp	
44	383461		2	Hose clamp	
45				Not used on this model	
46				Not used on this model	
49	500028		6	Screw M10-1,5x25 8,8	
54	904557		4	Washer 10,5x22x4	
61				Not used on this model	
62	372112		1	Holder plate	
63	374763		1	Hose clamp	
68	376270		1	Bracket	
79	370641		1	Hose shields	
80	313102		N	Cable ties	
84		A	1	Hydraulic hose	
90	359563		1	Hose shields	
94	500030		4	Screw M10-1,5x35H 8,8	
95	791481		20	Flat collar nut	

1) Replaced with Hydraulic motor 379005 and rebuild kit 379519.

2) Replaced with Hydraulic motor 379005 and rebuild kit 379518.

A) See Propulsion system, pump

Vibration system, motors

Ref. No.	Part No.	Rem.	Qty	Description	Code
4		A	1	Hydraulic hose	
5		A	2	Hydraulic hose	
8		A	1	Hydraulic hose	
13		A	1	Hydraulic hose	
14		A	1	Hydraulic hose	
16		A	1	Hydraulic hose	
17		A	1	Hydraulic hose	
26	500037		4	Screw M12-1,75x35 8,8	
27	904213		4	Washer 13x30x4	
28	377104		2	Hydraulic motor, vibration	
30	343872		2	Hose clamp	
33	343732		2	Hose clamp	
34	335914		2	Cover plate	
35	904056		2	Stud	
36	904230		8	Washer 10,5x22x2	
37	903524		2	Bolt	
39	500028		4	Screw M10-1,5x25 8,8	
41	160279		2	O-ring	
42	334558		2	Elbow 90G with O-ring	
44	340862		2	Splined sleeve	
50	383462		2	Hose clamp	
51	383461		2	Hose clamp	
53	500030		4	Screw M10-1,5x35H 8,8	
54	904557		4	Washer 10,5x22x4	
56	359563		1	Hose shields	
57	334138		4	Adapter	
58	334155		4	Connector	
63	334134		2	Connector	
83	370641		1	Hose shields	
84	313102	N		Cable ties	
88	372112		1	Holder plate	
89	374763		1	Hose clamp	
93	570006		4	Nut M10	

A) See vibration system, pump

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Hydraulic oil tank

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	370776		1	Cover	
2	357141		1	O-ring	
3	371707		1	Hydraulic oil tank	
4	989151		1	Oil level glass	
5	892446		2	Plug	
6	232122		1	Plug 3/4NPTF	
7	357459		6	Rubber cloth	
8	904567		2	Washer 10,5x28x6	
9	500028		2	Screw M10-1,5x25 8,8	
10	904734		14	Washer 8,4x26x4	
11	500053		14	Screw M8-1,25x20 8,8	
12	313008		2	Hose clamp	
13	205067	A	1XL	Rubber hose	
14	357139		1	Connector	
15	357138		1	Ventilating filter	
16	904603	B	1	Padlock	
17	376449	B	1	Connector	
18	904601		1	Decal "BIO HYDRAULIC OIL" Option	

A) L=220 mm

B) With Bio-oil, Option

Ref. No.	Part No.	Rem.	Qty	Description	Code
100				Electrical equipment (Page 102)	
200				Instrument box (Page 106)	
300				Instrument panel, main (Page 108)	
305				Speed and frequency, sensors (Page 110)	
325				Instrument panel, upper left (Page 112)	
350				Instrument panel, upper right (Page 114)	
375				Instrument panel, lower left (Page 116)	
400				Instrument panel, lower right (Page 118)	
450				Instrument panel, relay, fuses (Page 120)	
500				Emergency stop panel (Page 122)	
675				Working lights Rops (Page 124)	
680				Working lights, Xenon lamp (Page 126)	
800				Rotating beacon (Page 128)	
900				Offset drum Electrical equipment (Page 130)	

Speed and frequency, sensors

Ref. No.	Part No.	Rem.	Qty	Description	Code
102	372576	A	1	Sensor M12-1	
103	372618	B	2	Sensor 3/4-16	
104	376177		1	Cable harness	

- A) Read workshop manual for adj. of sensors. Item 102 is used both as speed and frequency sensor
- B) Read your workshop manual for adjustment of teh sensors

Instrument panel, relay, fuses

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	901256	A	1	Fuse box	
	908110		1	.Cover	
	901240		N	Connector	
	901224		N	Fuse 3A	
	901225	B	N	Fuse 5A	
	901226		N	Fuse 7.5A	
	901227		N	Fuse 10A	
	901228		N	Fuse 15A	
	903741		N	Fuse 20A	
	901229		N	Fuse 25A	
2	901256		1	Fuse box	
3	901256		1	Fuse box	
4	901256		1	Fuse box	
5	287597	G	1	Relay	
6	287597	E	1	Relay	
7	904989	D	1	Flash relay Option	
8	287597	C	1	Relay	
9	287597	G	1	Relay	
10	287597	H	1	Relay	
11	287598	I	1	Relay 12V-30A	
12	287597	J	1	Relay	
	374213	K	1	Time relay	
13	287598	L	1	Relay 12V-30A	
14	287597	M	1	Relay	
15	287597	N	1	Relay	
	903956	N,1	1	Relay	
16	382782		1	Relay, VBS	
17	903627		2	Junction block	
18	570004		2	Nut M6	
19	533013		6	Screw M4x20	
20	904698		6	Washer 4,3x8x0,8	
21	923976		6	Nut	
22	903625		1	Junction block	
23		P	12	Relay holder	
24	901767		8	Screw	
25	902223		9	Screw	
26	370165		1	Relay bracket	
27	387751		1	Cable harness	
	378135	2	1	Cable harness	
28	903970		1	Cable	

1) New version of relay. Used together with Cable harness PN 378135.

2) Can replace PN 387751 together with modif. kit PN 378136. (kit includes new relay 903956, item 15)

A) Without fuses

B) As required

C) Main, lights

D) Direction indicator

E) Brake light

G) Fuel level

H) Hour meter

I) Horn

J) Sprinkler

K) Sprinkler, timer, used together with timer switch 370644

L) Main

M) AVC

N) Neutral start

P) Incl in cable harness

Offset drum Electrical equipment

Ref. No.	Part No.	Rem.	Qty	Description	Code
1		A		Cable harness	
43	381556		1	Cable harness	
44	903582		1	Joystick	
45	343550		2	Connection cable	
52	371442		1	Holder plate	
53	359776		1	Cam	
54	500040		4	Screw M6-1x20 8,8	
55	533050		2	Screw	
56	904228		6	Washer 6,4x12x1,5	
57	904697		2	Washer 3,2x6x0,5	
58	930046		1	Micro switch	
A)	Existing				

Ref. No.	Part No.	Rem.	Qty	Description	Code
1			1	Steering column, cpl	
2	935229	A	1	.Frame	
3	935230	B	1	.Frame	
4	935231		1	.Screw	
5	935232		1	.Washer	
6	935233		1	.Sleeve	
7	935234		1	.Lever	
8	935235		2	.Washer	
9	935236		2	.Washer	
10	935237		2	.Screw	
11	935238		2	.Retainer ring	
12	935239		1	.Seal	
13	935240		1	.Bellows	
14	935241		1	.Nut	
15	935242		1	.Washer	
16	935243		1	.Cardan shaft	

- A) Lower
- B) Upper

Engine control

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	382213		1	Control	
2	382225		1	Yoke	
3	386876		1	Cable	
4	904228		6	Washer 6,4x12x1,5	
5	500015		2	Screw M6-1x30 8,8	
6	387634		1	Control bracket	
7	416034		1	Ball joint	
8	387633		1	Control lever	
9	904228		1	Washer 6,4x12x1,5	
10	508002		2	Screw	
11	500040		2	Screw M6-1x20 8,8	
12	586002		4	Lock nut M6	
13	387674		1	Bracket Control limit	
14	500048		2	Screw M10-1,5x20 8,8	
15	500013		2	Screw M6-1x16 8,8	
16	923874		1	Screw M8x25	
17	570005		1	Nut M8	
18	382349	A	1	Bellows	
19	389172		1	Throttle control, cpl	
20	389175		1	.Control	
21	389177		1	.Snap plate	
22	389180		1	.Cable	
23	904735		2	Washer	

A) Included in complete control.

Ref. No.	Part No.	Rem.	Qty	Description	Code
10				Standard equipment (Page 162)	

Edge cutter Hydraulics without offset

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	372266		1	Valve	
2	234388		2	Connector	
3	334196		2	Elbow 90	
4	483210		1	Hydraulic hose	
5	483045		1	Hydraulic hose	
6	483208		1	Hydraulic hose	
7	334420		2	Elbow 90	
8	483209		1	Hydraulic hose	
9	500023		3	Screw M8-1,25x40 8,8	
10	904229		3	Washer 8,4x16x1,5	
11	813500		2	Elbow 45, O-ring	
12	334264		2	Reducing	
13	483204		2	Hydraulic hose	
14	334199		2	Straight o-ring connector	
15	334199		1	Straight o-ring connector	
16	334461		1	Reducing	
17	334135		1	T-connector	

Asphalt temperature meter

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	388522		1	Cable harness	
2	378116		1	Cable harness	
3	930151		1	Switch	
4	388561		1	Sign	
5	377819		1	Cable harness	
6	388775		1	Temperature meter	
7	387981		1	Box	
8	387982		1	Temperature sender	
9	500053		4	Screw M8-1,25x20 8,8	
10	904229		4	Washer 8,4x16x1,5	
11	791594		1	Grommet	
12	925802		N	Cable ties L=142 mm	
13	313068		N	Cable ties L=92 mm	
14	387988	1	1	Bracket	
15	904653	1	8	Screw	
16	904281	1	4	Washer 5,3x10x1	
17	586001	1	4	Lock nut M5	
18	377812	2	1	Temperature meter box, cpl	
19		2	1	.Box	
20	903907	2	1	.Hinge	
21	378052	2	1	.Cover	
22	389111	2	1	.Holder	
23	904909	2	1	.Door bumper	
24	904907	2	1	.Door bumper	
25	904908	2	1	.Rubber part	
26	513008	2	4	.Screw	
27	904228	2	10	.Washer 6,4x12x1,5	
	904639	2	4	.Washer 6,7x14x1,5	
28	904563	2	8	.Lock nut	
29	500013	2	4	.Screw M6-1x16 8,8	
30	513027	2	2	.Screw	
31	904698	2	6	.Washer 4,3x8x0,8	
32	923976	2	4	.Nut	
33	902566	A,2	5XL	.Rubber strip	
34	500238	2	2	.Screw	
35	570005	2	2	Nut M8	
36	904556	2	2	Washer 8,4x16x3,0	
37	500022	2	2	Screw M8-1,25x30 8,8	
38	904640	2	2	Washer 8,4x22x3	
39	358881	2	1	Pad lock	
40	377422		1	Bracket	
41	500019		2	Screw M8-1,25x16 8.8	
42	904229		2	Washer 8,4x16x1,5	
43	921065		6	Clamp	
44	904228		6	Washer 6,4x12x1,5	
45	586002		6	Lock nut M6	

1) Valid for machines with cab.

2) Valid for platform machines.

A) L= 0,4 m

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL