

# Spare Parts Catalogue

SPL350TD-008629EN1

*Valid for planer serial number:*

**10000900C0A008629**



*Diesel engine:*

**Cummins QSB 3.3**

*Published catalogue issues valid for this planer:*

<i>Catalogue</i>	<i>Issue date</i>
<b>SPL350TD-008629EN1</b>	<b>2012 - 02</b>



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

PL350TD s/n 10000900E 0A008629

Item	Part No	Rem Qty	Description	Code
1		1	Grp. 01, Main frame ( Page 4 )	
2		1	Grp. 02, Planer unit ( Page 24 )	
3		1	Grp. 03, Material feeder ( Page 30 )	
4		1	Grp. 04, Steering and levelling 3-Radantrieb ab/from S/N 501333 ( Page 62 )	
6		1	Grp. 06, Drive (Engine) ( Page 80 )	
7		1	Grp. 07, Hydraulic 3-Radantrieb ( Page 108 )	
8		1	Grp. 08, Electric ab/from S/N 501.330 ( Page 144 )	
9		1	Grp. 09, Water system ( Page 174 )	
10		1	Grp. 10, Special equipment ( Page 178 )	
12		1	Grp. 11, Tools and accessories ( Page 196 )	
13		1	Grp. 14, Wearpart- and maintenance kits ( Page 206 )	
			_ 29.06.2011_AA	
26			_ 08.11.2011_AF	

**4812000457 Engine hood, left**

Item	Part No	Rem Qty	Description	Code
1	4812000463	1	Hinge	
2	D937626483	4	Coach bolt	
3	4700570007	4	Hex. nut	
4	D939776117	4	Locking washer	
5	4812000458	1	Engine hood, left	
6	D930288001	1	Lock	
	4700570004	4	_Hex. nut	
	4812002911	1	_Key	
7	4812000478	1	Insulating material	
8	4749301479	7	Clips for mount	
9	4812000500	1	Strap	
			_ 10.11.2009 TH	
			. LA05566-05599 TH	

**4812000735 Lamp holder**

Item	Part No	Rem Qty	Description	Code
1	D977903335	2	Working lamp	
	D977335101	1	_Bulb 70W	
2	D977903334	2	Head lamp	
	D977335020	1	_Bulb 75/70W	
	D977335670	1	_Bulb 4W	
3	D937930115	6	Cylinder screw	
4	4812000738	1	Lamp holder	
			_ 10.11.2009 TH	

**4812003483 Conveyor**

Item	Part No	Rem Qty	Description	Code
1	D501530222	1	<b>Swivel arm ( Page 44 )</b>	
2	D501530231	2	Guide	
3	D501530211	1	Angle	
4	D930256011	1	Hydraulic cylinder	
5	D501530233	1	Carrier	
6	D501530234	1	Stripper plate	
7	D501530339	1	Screw	
8	D501530102	1	Sheet	
9	D501530106	1	Covering	
10	D501530113	1	Covering	
11	D930300156	3	Bearing	
12	D930211468	1	Converyor belt	
13	D930117045	1	Drive rotor	
14	D501530121	1	Fastening	
15	D930460056	1	Drum	
16	D501530129	1	Fastening	
17	D966055000	1	Hydr. motor	
18	D930226043	2	Screw rod	
19	D930136776	3	Bow type handle	
20	D501530147	6	Support	
21	D930230611	2	Slide rail	
22	D501530124	2	Guide rail	
23	D501530125	2	Support	
24	D501530127	1	Holder	
25	D501530353	1	Sheave	
26	D501530352	1	Distance pipe	
27	D930540829	1	Winch	
	D501530159	1	_Pipe	
28	D501530361	1	Ejector flap	
29	D501530122	1	Cover	
30	D501530354	1	Bracing, compl.	
31	4749302091	1	Steel wire x m	
32	4749301573	1	Thimble	
33	D501530128	2	Sheet	
34	D501530249	2	Covering	
35	D930421804	3	Wire cable clamp	
36	4749901806	44	Screw retention DIN25201	
37	4749900700	6	Cylinder screw	
38	4749901595	6	Cylinder screw	
39	D937582014	1	Ring eye bolt	
40	4700600009	4	Washer	
41	4749901553	2	Hex. screw	
42	4700570015	6	Hex. nut M20x2,50	
43	4700600008	26	Washer	
44	4700570006	6	Hex. nut M10x1,5	
45	4700500053	26	Hex. head screw M08	
46	4749900776	6	Hex. screw	
47	4700500040	6	Hex. screw	
48	4700500048	8	Hex. screw	
49	4749901807	12	Screw retention	
50	4749901860	6	Screw retention	
51	D937930276	4	Cylinder screw	
52	4749901098	12	Hex. screw	
53	4749901596	2	Cylinder screw	
54	4700570005	18	Hex. nut M08	
55	4700500021	5	Hex. screw	
56	4700600006	9	Disc	
57	4700500111	1	Hex. screw	
58	4700570007	1	Hex. nut	
59	D939776129	8	Locking washer	

**4812003483 Conveyor**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
60	4700570008	1	Nut	
61	4749901809	1	Screw retention	
62	D937620375	4	Coach bolt	
63	D939475222	3	Countersunk screw	
64	D501530136	3	Disc	
65	D930440021	1	Clevis	
66	D938500007	2	Hex. nut	
67	4812003457	1	Release plate	
68	4812003461	1	Spray guard	
69	4812003456	1	Rubber sheeting	
70	4812003481	1	Rubber casing	
71	D501530244	1	Rubber casing	
72	4700500138	6	Hex. screw	
73	4749901109	6	Disc	
74	D938481014	2	Hex. nut	
75	D939399544	4	Cylinder screw	
76	4749901583	3	Disc	
78	4700600004	12	Disc	
			_ LAEM05917, 02.11.2010 ST	

**4812002036 Scraper hydraulic**

Item	Part No	Rem Qty	Description	Code
1	D963176081		<b>Steering block ( Page 56 )</b>	
2	D961935103	2	Straight double-ended union	
3	4812002067	1	Hose	
4	4812002068	1	Hose	
5	D961907006	2	Bulkhead union	
6	D961121006	2	Stud	
7	D933539217	2	Coupling plug	
8	D933538619	2	Coupling sleeve	
9	D960821514	1	Hose	
10	D960821404	1	Hose	
11	D961935106	2	Stud	
12	D963176092	2	Steering block	
	D963125333	1	_2/2 way valve	
	D963612216	1	_Magnet coil	
	D963142319	1	_4/3 way valve	
13	D930664027	1	Hose protection	
			_ 24.11.2009 TH	
			. LAEM05865; 02.06.10_ST	

**Grp. 04, Steering and levelling**

Item	Part No	Rem Qty	Description	Code
1	D501040127	2	Guide plate middle, right	
2	D501040126	2	Guide plate rear, right	
3	D966057210	1	Hydraulic motor	
	D932785874	1	_Seal kit for hydr. motor	
	D931701196	1	_Feather key	
	D932785830	1	_Sealing washer	
4	D501040130	1	Gear wheel	
5	D501140104	1	Plate	
6	4812002395	1	<b>Dipstick, compl. ( Page 64 )</b>	
7	D501140102	1	Distance washer	
8	4812001970	1	<b>Steering control unit s. Grp 04 ( Page 66 )</b>	
9	4812116852	1	Lock lever	
10	4811000096	8	Hex. socket countersunk screw M10x020H, 10.9	
11	4700500194	4	Screw	
12	4700500037	4	Hex. head screw M12	
13	4700904231	4	Steel plain washer M12	
14	D937580010	2	Ring eye bolt	
15	4812002652	1	Pointer	
16	4812000622	2	Torsional safety	
17	4700513013	4	Hex. socket countersunk screw	
18	4812002693	1	Bearing bolt	
19	4700500003	1	Screw	
20	4700904281	1	Steel plain washer	
21	4812000647	1	Shaft	
22	4812000624	2	Guide rail	
23	4700513009	4	Hex. socket countersunk screw	
24	D937944487	2	Threaded pin	
25	D936001069	1	Circlip	
26	D501-55160	2	<b>Rear wheel (RI, LE) ( Page 68 )</b>	
27	4812000614	1	<b>Front wheel ( Page 70 )</b>	
28	D501140103	1	Disc	
29	4700513010	1	Hex. socket countersunk screw	
30		1	<b>Leveling left ( Page 74 )</b>	
31		1	<b>Leveling right ( Page 78 )</b>	

**D951020927 Gear with motor s. Grp. 04**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
1	D937880178	2	Plug screw	
2	D951013422	2	Sealing washer	
3	4812002341		Gear oil x L _ 09.12.09_ST	

**Cooler system**

Item	Part No	Rem Qty	Description	Code
3	D501560101	1	Hose	
4	D501560104	1	Form hose	
10	D501560105	1	Holder	
11	D930235527	3	Rubber buffer	
12	4749901108	11	Washer	
13	4700500048	9	Hex. screw	
14	4700570006	5	Hex. nut M10x1,5	
15	D501160130	3	Disc	
16	D501560110	1	<b>Holder, compl. ( Page 84 )</b>	
17	4700600004	1	Disc	
18	D939570511	1	Disc	
19	D938190514	1	Nut	
20	D938165547	1	Hex. screw	
23	D501560122	1	<b>Carrier assy. ( Page 86 )</b>	
26	D501560127	1	<b>Holder, compl. ( Page 88 )</b>	
43	4700904230	4	Steel plain washer M10 10,5x22x2,0	
44	4700500048	4	Hex. screw	
45	D501510426	1	Protection	
53	D934349115	2	Clip	
54	4749301758	2	Clip	
75	4812002252	1	Insulating material	
82	4700500053	3	Hex. head screw M08	
83	4700904229	3	Steel plain washer M08 8,4x16x1,5	

**D966390010 Engine**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
1	D966600185	1	Air filter, outer element primary	
2	D966600184	1	Air filter, inner element safety	
3	D966711101	1	Gasket, valve cover	
4	D966503075	1	Starter	
5	D966630500	1	Dipstick	
6	D966720001	1	Water pump	
	D967538226	1	Sealing	
7	D966598107	1	V.belt	
8	D966600161	1	Alternator	
9	D966532453	1	Oil cover	
10	D966630430	1	Cartridge, Lub oil filter	
12	D966598318	1	Fuel filter	
13	D966695200	1	Thermostat	
	D966534100	1	Sealing washer	
			_ SHE_16.04.2008	

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

**D967045031 Pump, 3 wheel drive**

Item	Part No	Rem Qty	Description	Code
1	D967045031	1	<b>Pump, 3 wheel drive ( Page 102 )</b>	
2	D967647002	1	Control unit	
	4812003013	1	_Sealing	
3	4700679693	1	Sealing kit	
4	D932411675	1	O-ring	
			_ 12.06.2008 SHE	

**4812002031 3 wheel-Drive**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
61	D961906008	2	Bulk head union	
62	D961906020	2	Bulk head union	
63	D961907007	3	Bulkhead union elbow	
64	D961772670	1	Test connector	
65	D930664027	5	Hose protection	
66	4749300511	2	Tube clip	
67	4749300384	2	Tension plate	
68	D938165659	2	Hex. screw	
69	D961941073	1	T-connector	
70	D961919006	1	T-connector	

**D963172801 Hydr. block**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
1	4812003543	3	3/2 way valve	
2	4812003544	2	3/2 way valve	
3	4812003545	1	Flow divider	
5	4812003546	1	3/2 way valve	
6	4812003547	1	Pressure limit valve	
9	4812003548	1	3/2 way valve	
10	4812003549	1	Flow divider _ LAEM05933, 24.11.10 ST	

4812002033A Work hydraulic

Item	Part No	Rem Qty	Description	Code
1	D967088022		<b>Hydraulic pump ( Page 104 )</b>	
2	D966057210		Hydraulic motor	
	D932785874	1	_Seal kit for hydr. motor	
	D931701196	1	_Feather key	
	D932785830	1	_Sealing washer	
3	4812001970		<b>Steering control unit s. Grp 04 ( Page 66 )</b>	
4	D964006104	1	Filter	
	D932786550	1	_Seal kit	
	D964350860	1	_Filter element	
5	D961542610	1	Priority valve	
6	D963176081	1	<b>Steering block ( Page 56 )</b>	
7	D961935111	1	Straight double-ended union	
8	D961935109	1	Straight screwing	
9	4812002091	1	Hose	
10	D961935135	1	Straight double-ended union	
11	D961941086	1	Straight double-ended union	
12	D961121018	1	Intermediate stud	
13	D961951084	8	Straight double-ended union	
14	D961354051	1	Pressure banjo fittings	
15	4812001946	1	Pipe	
16	4749220648	1	Stud	
17	D960822792	1	Hose	
18	D961935106	5	Stud	
19	D961355001	2	Reduction union	
20	4812002072	1	Hose	
21	D960843953	1	Hose	
22	D961941086	2	Straight double-ended union	
23	D960843951	1	Hose	
24	4812001949	1	Pipe	
25	4749220650	1	Stud	
26	D960843700	1	Hose 2000 mm	
27	D960841406	1	Hose	
28	D960852852	1	Hose	
29	4749220734	1	Stud	
30	D961175109	2	Plug screw	
31	D961175108	2	Plug screw	
32	D961935103	4	Straight double-ended union	
33	4812002073	1	Hose	
34	D961154106	4	Threaded socket	
35	D990093005	2	Orifice	
36	4749220479	3	Union elbow both ports	
37	D960822705	1	Hose	
38	4812002074	1	Hose	
39	4812002075	1	Hose	
40	D961358220	2	Swivel bulkhead coupling	
41	D960821055	1	Hose	
42	D960821005	1	Hose	
43	4749220460	1	Stud	
44	D961772637	1	Test connector	
45	D961355014	1	Stud	
46	D963076600	4	Non return valve	
47	D965172912		Chassis leg	
	D965531583	1	_Seal kit	
48	4749220504	4	Stud	
49	D960874305	1	Hose	
50	D961835206	1	Straight double-ended union	
51	4812003507	4	Straight double-ended union	
60	4749300510	2	Tube clip	
61	4749300384	2	Tension plate	
62	D938165659	2	Hex. screw	

**4812002034 Suction/return line - hyd. diagram**

Item	Part No	Rem Qty	Description	Code
1	D503270179	1	Manifold	
2	D963404710	1	By-pass valve	
3	D964047055	1	Return/succion filter	
	D964350859	1	_Filter element	
	D932783671	1	_Repair kit	
	D964805451	1	_Low pressure switch	
4	D964152341	1	Filling filter	
5	D930211474	1	Level indicator	
6	D960881826	1	Hose	
7	D960882051	1	Hose	
8	D960880526	1	Hose	
9	D961935212	1	Straight double-ended union	
10	D961919012	1	Swivel nut run tee	
11	D961121012	1	Intermediate stud	
12	D961935312	3	Straight double-ended union	
13	D961935112	4	Straight double-ended union	
14	D961903011	2	Straight coupling	
15	D961353018	1	Straight double-ended union	
16	4749220517	1	Stud	
17	4749220518	1	Straight screwing	
18	4749220509	1	Stud	
19	4749220742	1	Straight double-ended union	
20	D961175209	1	Plug screw	
21	D961935228	1	Straight double-ended union	
22	4749220523	1	Stud	
23	D961935161	1	Stud	
			_ 17.12.09_ST	

**4812002961 Drive**

Item	Part No	Rem Qty	Description	Code
1	4812002513	1	Control box	
2	D977454254	1	Fuse 10A	
3	4749100529	1	Drive lever	
4	D977730412	2	Micro relay	
5	D977729013	2	Relay socket	
6	D977425136	1	Diode terminal	
7	4812001167	1	Back-up alarm	
8	4749120110	1	Potentiometer	
9	D977180606	2	Resistor	
10	D977425188	11	Clamp	
11	D977522357	1	Switch	
12	4812002991	1	Toggle switch	
13	D977599040	1	Control knob	
14	D977599041	1	Cover	
15	D977425196	2	Terminal	
16	4700500238	4	Hex. screw	
17	4700600002	4	Disc	
			_ LAEM05660, - 05692, -05707	
			. 26.05.2010_ST	

4812002960 Lighting equipment, Horn

Item	Part No	Rem Qty	Description	Code
1	D977903334	1	Head lamp	
	D977335020	1	_Bulb 75/70W	
	D977335670	1	_Bulb 4W	
2	D977900137	1	<b>Working lamp ( Page 164 )</b>	
3	D977999004	1	Slip-on pipe	
4	4749140026	1	Rotary light	
	D977335101	1	_Bulb 70W	
5	D977903335	1	Working lamp	
	D977335101	1	_Bulb 70W	
6	D977800239	2	LED element, white	
7	4812001165	1	Horn	
8	D977425137	1	Diode terminal	
9	D977512168	1	Rotary switch	
10	D977512171	1	Rotary switch	
11	D977454252	1	Fuse 5A	
12	D977425188	5	Clamp	
13	D977454254	1	Fuse 10A	
14	D977454255	1	Fuse 15A	
15	4749100425	1	Press button switch	
16	4749900575	1	Hex. screw	
17	4749900021	1	Nut	
18	4700500021	2	Hex. screw	
19	4700600006	4	Disc	
20	D938481008	2	Nut	
			_LAEM05660, - 05692, -05707	
			. 26.05.2010_ST	

4812002206 Operator panel PL350TD

Item	Part No	Rem Qty	Description	Code
1	D501580103	1	Operator panel, lower part	
2	4812001974	1	Panel	
3	D501580108	1	Mounting plate	
4	D977520011	1	Glow-start switch	
5	D977415420	5	SEM-quick connection	
6	D977415415	1	SEM-quick connection	
7	D977415412	2	SEM-quick connection	
8	D977417116	2	Cable screwing	
9	D977416517	3	Counter nut	
10	D977416520	5	Counter nut	
11	D977416512	2	Counter nut	
12	D977418901	2	Corrugated pipe	
13	D977418903	4	Corrugated pipe	
14	D977418902	2	Corrugated pipe	
15	D501580104	1	Operator panel, top part	
18	4749100744	5	Illuminated diode, red	
19	D977512168	1	Rotary switch	
20	D977580229	1	Emergency stop switch	
21	D977532036	2	Toggle switch	
22	D977532030	2	Toggle switch	
23	D977532019	2	Toggle switch	
24	D977010512	1	Service hour meter	
25	D977018411	1	Temperature gauge	
26	D977512171	1	Rotary switch	
27	D977599040	1	Control knob	
28	D977599041	1	Cover	
29	D977425101	10	Circlip terminal	
30	D977425136	18	Diode terminal	
31	D977730412	3	Micro relay	
32	D977729013	4	Relay socket	
33	D977729010	1	Relay socket	
34	D977730412	1	Micro relay	
35	D977454252	1	Fuse 5A	
36	D977425188	70	Clamp	
37	D977454254	8	Fuse 10A	
38	D977454255	1	Fuse 15A	
39	4749100529	1	Drive lever	
40	4749100425	1	Press button switch	
41	D977730415	1	Relay	
42	D978008056	1	Amplifier	
43	D977188106	1	Potentiometer	
44	D977425196	2	Terminal	
45	D977425208	2	Through clamp	
46	D977467011	2	Mounting socket	
47	D956188650	1	Water level	
48	D939475063	2	Screw	
50	4812002991	1	Toggle switch	
51	D977532031	1	Toggle switch	
52	D939390113	1	Screw	
53	4700570003	1	Hex. nut	
54	4700600003	1	Disc	
55	4749100745	1	Illuminated diode, green	
56	4749100446	2	Illuminated diode, yellow 1x Option	
57	D930406052	2	Locking bar	
58	D977532017	1	Toggle switch Option	
			_ 23.11.09_ST	
			. LAEM05796 10.Mai 2010 SB	
			. LAEM05660, -05692, -05707	
			. 06.06.2010_ST	

**D953420303 Driver seat**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
1	4812002191	1	Seat cushion	
2	4812002192	1	Back of seat	
3	4812002193	1	Arm-rest set with support frame _ LAEM05577; 13.10.09_ST	

**D501600700 Ext. Hydraulic connection**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
1	D930452599	1	Quick connection	
2	D930452598	1	Quick connection	
4	D963176082	1	<b>Steering block ( Page 50 )</b>	
11	D960852852		Hose	
12	D961919009	1	Swivel nut run tee	
13	4749220527	1	Stud	
14	4749220460	1	Stud	
15	4812001947	1	Pipe	
16	D960841406		Hose	
17	D961355011	1	Stud	
18	D961935108	2	Straight double-ended union	
19	4812001948	1	Pipe	
20	4812002069	1	Hose	
21	D961907008	2	Bulkhead union elbow	
22	4812002070	1	Hose	
26	D961772637	1	Test connector	
30	4749300510	2	Tube clip	
31	4749300384	2	Tension plate	
32	4700500024	2	Hex. screw	
			_ 09.09.2010 ST	

501-10-000 Operating materials

Item	Part No	Rem Qty	Description	Code
1	4812030103	1	Dynapac Gear Oil 200 20 l	
2	4812030102	1	Dynapac Gear Oil 200 5 l	
3	4812030095	1	Dynapac Paver Grease _ 19.05.2010_ST	

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL